

A
B
C

EXL

SECTION EXL

EXTERIOR LIGHTING SYSTEM

D
E

CONTENTS

<p>PRECAUTION 4</p> <p>PRECAUTIONS 4</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"4</p> <p style="padding-left: 20px;">Precaution for Work4</p> <p>PREPARATION 5</p> <p>PREPARATION 5</p> <p style="padding-left: 20px;">Special Service Tool5</p> <p>SYSTEM DESCRIPTION 6</p> <p>COMPONENT PARTS 6</p> <p style="padding-left: 20px;">Component Parts Location6</p> <p style="padding-left: 20px;">Component Description7</p> <p>SYSTEM 8</p> <p>HEADLAMP SYSTEM8</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : System Diagram8</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : System Description8</p> <p>AUTO LIGHT SYSTEM8</p> <p style="padding-left: 20px;">AUTO LIGHT SYSTEM : System Diagram9</p> <p style="padding-left: 20px;">AUTO LIGHT SYSTEM : System Description9</p> <p>DAYTIME RUNNING LIGHT SYSTEM9</p> <p style="padding-left: 20px;">DAYTIME RUNNING LIGHT SYSTEM : System Diagram9</p> <p style="padding-left: 20px;">DAYTIME RUNNING LIGHT SYSTEM : System Description9</p> <p>FRONT FOG LAMP SYSTEM 10</p> <p style="padding-left: 20px;">FRONT FOG LAMP SYSTEM : System Diagram... 10</p> <p style="padding-left: 20px;">FRONT FOG LAMP SYSTEM : System Description 10</p> <p>TURN SIGNAL AND HAZARD WARNING LAMPS... 10</p> <p style="padding-left: 20px;">TURN SIGNAL AND HAZARD WARNING LAMPS : System Diagram 10</p>	<p style="text-align: right;">F</p> <p style="padding-left: 20px;">TURN SIGNAL AND HAZARD WARNING LAMPS : System Description10</p> <p style="text-align: right;">G</p> <p>PARKING, LICENSE PLATE AND TAIL LAMPS11</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE AND TAIL LAMPS : System Diagram11</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE AND TAIL LAMPS : System Description11</p> <p style="text-align: right;">H</p> <p>COMBINATION SWITCH READING SYSTEM11</p> <p style="padding-left: 20px;">COMBINATION SWITCH READING SYSTEM : System Diagram (With Intelligent Key System)11</p> <p style="padding-left: 20px;">COMBINATION SWITCH READING SYSTEM : System Description (With Intelligent Key System)...12</p> <p style="padding-left: 20px;">COMBINATION SWITCH READING SYSTEM : System Diagram (Without Intelligent Key System)...15</p> <p style="padding-left: 20px;">COMBINATION SWITCH READING SYSTEM : System Description (Without Intelligent Key System)15</p> <p style="text-align: right;">I</p> <p>DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)18</p> <p style="text-align: right;">J</p> <p>COMMON ITEM18</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)18</p> <p style="text-align: right;">K</p> <p>HEADLAMP19</p> <p style="padding-left: 20px;">HEADLAMP : CONSULT Function (BCM - HEAD LAMP)19</p> <p style="text-align: right;">L</p> <p>FLASHER20</p> <p style="padding-left: 20px;">FLASHER : CONSULT Function (BCM - FLASHER)20</p> <p style="text-align: right;">M</p> <p>DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)21</p> <p style="text-align: right;">N</p> <p>COMMON ITEM21</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)21</p> <p style="text-align: right;">O</p> <p>HEADLAMP</p> <p style="text-align: right;">P</p>
--	---

EXL

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)	22	Description	90
		Component Function Check	90
		Diagnosis Procedure	90
FLASHER	23	DAYTIME LIGHT RELAY CIRCUIT	92
FLASHER : CONSULT Function (BCM - FLASHER)	23	Description	92
		Diagnosis Procedure	92
		Component Inspection	93
DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)	24	FRONT FOG LAMP CIRCUIT	94
Diagnosis Description	24	Description	94
CONSULT Function (IPDM E/R)	25	Component Function Check	94
		Diagnosis Procedure	94
DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)	28	PARKING LAMP CIRCUIT	96
Diagnosis Description	28	Description	96
CONSULT Function (IPDM E/R)	29	Component Function Check	96
		Diagnosis Procedure	96
ECU DIAGNOSIS INFORMATION	32	TURN SIGNAL LAMP CIRCUIT	99
BCM, IPDM E/R	32	Description	99
List of ECU Reference	32	Component Function Check	99
		Diagnosis Procedure	99
WIRING DIAGRAM	33	OPTICAL SENSOR	103
HEADLAMP	33	Description	103
Wiring Diagram	33	Component Function Check	103
		Diagnosis Procedure	103
DAYTIME LIGHT SYSTEM	38	HAZARD SWITCH	105
Wiring Diagram	38	Component Function Check	105
		Diagnosis Procedure	105
AUTO LIGHT SYSTEM	46	SYMPTOM DIAGNOSIS	107
Wiring Diagram	46	EXTERIOR LIGHTING SYSTEM SYMPTOMS	107
		Symptom Table	107
FRONT FOG LAMP	53	NORMAL OPERATING CONDITION	109
Wiring Diagram	53	Description	109
TURN SIGNAL AND HAZARD WARNING LAMPS	58	BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM	110
Wiring Diagram	58	Description	110
		Diagnosis Procedure	110
PARKING, LICENSE PLATE AND TAIL LAMPS	68	DAYTIME LIGHT SYSTEM INOPERATIVE	111
Wiring Diagram	68	Description	111
		Diagnosis Procedure	111
STOP LAMP	76	BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON	112
Wiring Diagram	76	Description	112
		Diagnosis Procedure	112
BACK-UP LAMP	80	PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON	113
Wiring Diagram	80	Description	113
		Diagnosis Procedure	113
BASIC INSPECTION	85	BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON	114
DIAGNOSIS AND REPAIR WORK FLOW	85		
Work Flow	85		
DTC/CIRCUIT DIAGNOSIS	88		
HEADLAMP (HI) CIRCUIT	88		
Description	88		
Component Function Check	88		
Diagnosis Procedure	88		
HEADLAMP (LO) CIRCUIT	90		

Description	114	REAR COMBINATION LAMP	126	
Diagnosis Procedure	114	Exploded View	126	A
PERIODIC MAINTENANCE	115	Removal and Installation	126	
HEADLAMP	115	Bulb Replacement	127	B
Aiming Adjustment	115	COMBINATION SWITCH	128	
FRONT FOG LAMP	117	Exploded View	128	C
Aiming Adjustment	117	Removal and Installation	128	
REMOVAL AND INSTALLATION	119	HAZARD SWITCH	129	D
FRONT COMBINATION LAMP	119	Removal and Installation	129	
Exploded View	119	OPTICAL SENSOR	130	E
Removal and Installation	119	Removal and Installation	130	
Bulb Replacement	120	UNIT DISASSEMBLY AND ASSEMBLY .	131	F
FRONT FOG LAMP	122	FRONT COMBINATION LAMP	131	
Removal and Installation	122	Exploded View	131	G
DOOR MIRROR TURN SIGNAL LAMP	123	Disassembly and Assembly	131	
Removal and Installation	123	REAR COMBINATION LAMP	133	H
HIGH-MOUNTED STOP LAMP	124	Exploded View	133	
Removal and Installation	124	Disassembly and Assembly	133	I
Bulb Replacement	124	SERVICE DATA AND SPECIFICATIONS		
LICENSE PLATE LAMP	125	(SDS)	135	J
Removal and Installation	125	SERVICE DATA AND SPECIFICATIONS		
Bulb Replacement	125	(SDS)	135	K
		Bulb Specifications	135	

EXL

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009757466

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000009757467

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009757468

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009757469



AWLIA2057ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

- | | | | |
|---|---|--|---|
| 1. IPDM E/R, (Headlamp high relay, Headlamp low relay, Taillamp relay and Front fog lamp relay (if equipped)) | 2. Stop lamp switch | 3. Parking brake switch | A |
| 4. Combination meter | 5. Combination switch (lighting and turn signal switch) | 6. BCM (view with combination meter removed) | B |
| 7. Optical sensor | 8. Front door switch LH (Other doors similar) | 9. Hazard switch | C |
| 10. Daytime light relay (if equipped) | | | |

Component Description

INFOID:000000009757470

Part	Description
BCM	Controls the exterior lighting system.
Combination switch (Lighting & turn signal switch)	Refer to BCS-9. "COMBINATION SWITCH READING SYSTEM : System Description" (with Intelligent Key system) or BCS-80. "COMBINATION SWITCH READING SYSTEM : System Description" (without Intelligent Key system).
IPDM E/R	Controls the integrated relays and supplies voltage to the load according to the request from the BCM via CAN communication.
Stop lamp switch	Transmits power when the brake pedal is pressed to operate stop lamps.
Combination meter	Refer to MWI-8. "METER SYSTEM : System Description" .
Daytime light relay (if equipped)	Sends power to the daytime lamp when operated by the IPDM E/R.
Front door switch LH/RH	Transmits the door open signal to the BCM.
Rear door switch LH/RH	
Optical sensor	Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM to operate the autolight system.
Parking brake switch	Transmits the parking brake switch signal to the combination meter to operate the autolight system.
Hazard switch	Inputs the hazard switch signal to BCM.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM

HEADLAMP SYSTEM

HEADLAMP SYSTEM : System Diagram

INFOID:000000009757471



HEADLAMP SYSTEM : System Description

INFOID:000000009757472

LOW BEAM OPERATION

When the lighting switch is in 2nd position, the BCM receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the IPDM E/R controls the headlamp low relay coil which supplies power to the low beam headlamps.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

With the lighting switch in the 2nd position and placed in HIGH position, the BCM receives input requesting the headlamp high beams to illuminate. The flash to pass feature can be used any time and also sends a signal to the BCM. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the combination meter controls the ON/OFF status of the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil which supplies power to the high beam headlamps.

The combination meter receives a high beam request signal (ON) through the CAN communication lines and turns the high beam indicator lamp ON.

EXTERIOR LAMP BATTERY SAVER CONTROL

With the combination switch (lighting and turn signal switch) in the 2nd position and the ignition switch is turned from ON or ACC to OFF, the battery saver feature is activated.

Under this condition, the headlamps remain illuminated for a period of time, unless the lighting switch position is changed. If the lighting switch position is changed, then the headlamps are turned off.


AUTO LIGHT SYSTEM

SYSTEM

< SYSTEM DESCRIPTION >

AUTO LIGHT SYSTEM : System Diagram

INFOID:000000009757473



AUTO LIGHT SYSTEM : System Description

INFOID:000000009757474

- BCM (Body Control Module) controls auto light operation according to signals from optical sensor, lighting switch and ignition switch.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates parking, license plate, tail, front fog lamps and headlamps according to CAN communication signals from BCM.
- Optical sensor detects ambient brightness of 800 to 2,500 lux. And optical sensor converts light (lux) to voltage, then sends the optical sensor signal to BCM.

OUTLINE


The auto light control system has an optical sensor that detects outside brightness.

When the lighting switch is in AUTO position, it automatically turns ON/OFF the parking, license plate, tail, front fog lamps and headlamps in accordance with the ambient light. Sensitivity can be adjusted. For the details of the setting, Refer to [EXL-19, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

DAYTIME RUNNING LIGHT SYSTEM

DAYTIME RUNNING LIGHT SYSTEM : System Diagram

INFOID:000000009757475



DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000009757476

System Description

The daytime light system is equipped with a daytime light control that activates the daytime lights when the engine is operating. If the parking brake is applied, the daytime lights will turn OFF. The daytime lights will turn ON when the parking brake is released.

SYSTEM

< SYSTEM DESCRIPTION >


OPERATION

The BCM monitors inputs from the parking brake switch and the combination switch (lighting and turn signal switch) to determine when to operate the daytime light system. The BCM sends a daytime light request to the IPDM E/R via the CAN communication lines. The IPDM E/R grounds the daytime light relay which in turn, provides power to the daytime lights.

FRONT FOG LAMP SYSTEM

FRONT FOG LAMP SYSTEM : System Diagram

INFOID:000000009757477



FRONT FOG LAMP SYSTEM : System Description

INFOID:000000009757478

The front fog lamps are activated with the combination switch (lighting and turn signal switch). The lighting switch signal to the BCM is monitored with the BCM combination switch reading function. When the fog lamps are turned ON with the lighting switch, the BCM sends a front fog lamp request signal via CAN communication lines to the IPDM E/R. The IPDM E/R grounds the front fog lamp relay coil to activate the front fog lamps.


FRONT FOG LAMP OPERATION

When the lighting switch is in front fog lamp ON position and also in 1st or 2nd position or AUTO position (headlamp is ON), the BCM detects FR FOG ON and the HEAD LAMP 1, 2 ON or the AUTO LIGHT ON. The BCM sends a front fog lamp request ON signal via the CAN communication lines to the IPDM E/R. The IPDM E/R then turns ON the front fog lamp relay sending power to the front fog lamps.

TURN SIGNAL AND HAZARD WARNING LAMPS

TURN SIGNAL AND HAZARD WARNING LAMPS : System Diagram

INFOID:000000009757479



TURN SIGNAL AND HAZARD WARNING LAMPS : System Description

INFOID:000000009757480

TURN SIGNAL OPERATION

SYSTEM

< SYSTEM DESCRIPTION >

When the combination switch (lighting and turn signal switch) is in LH or RH turn position with the ignition switch in the ON position, the BCM receives input requesting the turn RH or turn LH lamps to illuminate. The BCM controls the turn signal power to the respective turn signal lamp. The BCM also sends a turn indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates the appropriate turn signal indicator and audible buzzer.


HAZARD LAMP OPERATION

When the hazard switch is in the ON position, the BCM receives input requesting the hazard lamps illuminate. The BCM controls the turn signal power to both the LH and RH turn signal lamps. The BCM sends a hazard indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates both the LH and RH turn signal indicators and audible buzzer.

PARKING, LICENSE PLATE AND TAIL LAMPS

PARKING, LICENSE PLATE AND TAIL LAMPS : System Diagram

INFOID:000000009757481



PARKING, LICENSE PLATE AND TAIL LAMPS : System Description

INFOID:000000009757482

PARKING, LICENSE PLATE AND TAIL LAMPS OPERATION

When the lighting switch is in 1st or 2nd position, BCM detects the LIGHTING SWITCH 1st or 2nd POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which sends power to the parking and instrument illumination circuits.

EXTERIOR LAMP BATTERY SAVER CONTROL

With the combination switch (lighting and turn signal switch) in the 1st or 2nd position and the ignition switch is turned from ON or ACC to OFF, the battery saver feature is activated.

Under this condition, the exterior lamps remain illuminated for a period of time unless the lighting switch position is changed. If the lighting switch position is changed, then the exterior lamps are turned off.

COMBINATION SWITCH READING SYSTEM

COMBINATION SWITCH READING SYSTEM : System Diagram (With Intelligent Key


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

SYSTEM

< SYSTEM DESCRIPTION >

System)

INFOID:000000010295730



COMBINATION SWITCH READING SYSTEM : System Description (With Intelligent Key System)


INFOID:000000010295731

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch states.

COMBINATION SWITCH MATRIX

Combination switch circuit



Combination switch INPUT-OUTPUT system list

System	INPUT 1	INPUT 2	INPUT 3	INPUT 4	INPUT 5
OUTPUT 1	—	FR WASHER	FR WIPER LOW	TURN LH	TURN RH
OUTPUT 2	FR WIPER HI	—	FR WIPER INT	PASSING	HEADLAMP 1
OUTPUT 3	INT VOLUME 1	—	—	HEADLAMP 2	HI BEAM
OUTPUT 4	—	INT VOLUME 3	AUTO LIGHT	—	TAIL LAMP
OUTPUT 5	INT VOLUME 2	—	—	FR FOG	—


SYSTEM

< SYSTEM DESCRIPTION >

COMBINATION SWITCH READING FUNCTION


Description

- BCM reads the status of the combination switch at 10 ms intervals normally.



NOTE:

- BCM reads the status of the combination switch at 60 ms intervals when BCM is controlled at low power consumption control mode.
- BCM operates as follows and judges the status of the combination switch.
 - It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5, and outputs voltage waveform.
 - The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
 - It reads this change of the voltage as the status signal of the combination switch.



Operation Example

In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

Example 1: When a switch (TAIL LAMP) is turned ON


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

SYSTEM

< SYSTEM DESCRIPTION >


- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.



- BCM detects the combination switch status signal "5D" when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TAIL LAMP switch is ON when the signal "5D" is detected.

Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.



- BCM detects the combination switch status signal "5AD" when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal "5AD" is detected.

WIPER INTERMITTENT DIAL POSITION

BCM judges the wiper intermittent dial 1 - 7 by the status of INT VOLUME 1, 2 and 3 switches.

Wiper intermittent dial position	Switch status		
	INT VOLUME 1	INT VOLUME 2	INT VOLUME 3
1	ON	ON	ON
2	ON	ON	OFF
3	ON	OFF	OFF
4	OFF	OFF	OFF
5	OFF	OFF	ON

SYSTEM

< SYSTEM DESCRIPTION >


Wiper intermittent dial position	Switch status		
	INT VOLUME 1	INT VOLUME 2	INT VOLUME 3
6	OFF	ON	ON
7	OFF	ON	OFF

NOTE:

For details of wiper intermittent dial position, refer to [WW-8, "System Description"](#).

COMBINATION SWITCH READING SYSTEM : System Diagram (Without Intelligent Key System)

INFOID:0000000010295732



COMBINATION SWITCH READING SYSTEM : System Description (Without Intelligent Key System)


INFOID:0000000010295733

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch states.

COMBINATION SWITCH MATRIX

Combination switch circuit



SYSTEM

< SYSTEM DESCRIPTION >


Combination switch INPUT-OUTPUT system list

System	INPUT 1	INPUT 2	INPUT 3	INPUT 4	INPUT 5
OUTPUT 1	—	FR WASHER	FR WIPER LOW	TURN LH	TURN RH
OUTPUT 2	FR WIPER HI	—	FR WIPER INT	PASSING	HEADLAMP 1
OUTPUT 3	INT VOLUME 1	—	—	HEADLAMP 2	HI BEAM
OUTPUT 4	—	INT VOLUME 3	—	—	TAIL LAMP
OUTPUT 5	INT VOLUME 2	—	—	FR FOG	—

COMBINATION SWITCH READING FUNCTION

Description


- BCM reads the status of the combination switch at 10 ms intervals normally.



NOTE:

BCM reads the status of the combination switch at 60 ms intervals when BCM is controlled at low power consumption control mode.

- BCM operates as follows and judges the status of the combination switch.
 - It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5, and outputs voltage waveform.
 - The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
 - It reads this change of the voltage as the status signal of the combination switch.



Operation Example


In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

SYSTEM

< SYSTEM DESCRIPTION >

Example 1: When a switch (TAIL LAMP) is turned ON


- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.



- BCM detects the combination switch status signal "5D" when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TAIL LAMP switch is ON when the signal "5D" is detected.

Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.



- BCM detects the combination switch status signal "5AD" when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal "5AD" is detected.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM) COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000010309869

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		ECU identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN DIAG SUPPORT MNTR
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×			
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEAD LAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×	×		
Interior room lamp battery saver	BATTERY SAVER			×	×	×		
Trunk open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		

DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:0000000010304492

DATA MONITOR

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
ENGINE STATE [Stop/Stall/Crank/Run]	Indicates engine status received from ECM on CAN communication line.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of trunk switch.
OPTI SEN (DTCT) [V]	Indicates outside brightness voltage signal from optical sensor.
OPTI SEN (FILT) [V]	Indicates outside brightness voltage signal from optical sensor filtered by BCM.

ACTIVE TEST

Test Item	Description
FR FOG LAMP	This test is able to check front fog lamp operation [On/Off].
HEAD LAMP	This test is able to check head lamp operation [Hi/Low/Off].
ILL DIM SIGNAL	This test is able to check head lamp illumination dimming operation [On/Off].
TAIL LAMP	This test is able to check tail lamp operation [On/Off].

WORK SUPPORT

Support Item	Setting	Description
AUTO LIGHT LOGIC SET	MODE 1*	With twilight ON custom & with wiper INT, LO and HI
	MODE 2	With twilight ON custom & with wiper LO and HI
	MODE 3	With twilight ON custom & without
	MODE 4	Without twilight ON custom & with wiper INT, LO and HI
	MODE 5	Without twilight ON custom & with wiper LO and HI
	MODE 6	Without twilight ON custom & without
BATTERY SAVER SET	On*	Exterior lamp battery saver function ON.
	Off	Exterior lamp battery saver function OFF.

DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Support Item	Setting	Description
CUSTOM A/LIGHT SETTING	MODE 1*	Normal
	MODE 2	More sensitive setting than normal setting (Turns ON earlier than normal operation)
	MODE 3	More sensitive setting than MODE 2 (Turns ON earlier than MODE 2)
	MODE 4	Less sensitive setting than normal setting (Turns ON later than normal operation)
ILL DELAY SET	MODE 8	180 sec.
	MODE 7	150 sec.
	MODE 6	120 sec.
	MODE 4	60 sec.
	MODE 5	90 sec.
	MODE 3	30 sec.
	MODE 2	OFF
MODE 1*	45 sec.	Sets delay timer function operation time (All doors closed).

*: Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:0000000010309868

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	Indicates condition of hazard switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]	Indicates condition of panic alarm signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

WORK SUPPORT

Support Item	Setting	Description
HAZARD ANSWER BACK	Lock/Unlock*	Hazard warning lamp activation when doors are locked or unlocked with Intelligent Key.
	Unlock Only	Hazard warning lamp activation when doors are unlocked with Intelligent Key.
	Lock Only	Hazard warning lamp activation when doors are locked with Intelligent Key.
	Off	No hazard warning lamp activation when doors are locked or unlocked with Intelligent Key.

*: Initial setting

DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM) COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000010308705

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		ECU identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN DIAG SUPPORT MNTR
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×			
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEAD LAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×		×	×		
Interior room lamp battery saver	BATTERY SAVER			×	×	×		
Trunk open	TRUNK			×				
RAP system	RETAINED PWR			×		×		
Signal buffer system	SIGNAL BUFFER			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		
Panic alarm system	PANIC ALARM				×			

DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:0000000010308710

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
ACC ON SW [On/Off]	Indicates condition of ignition switch ACC position.
HI BEAM SW [On/Off]	Indicates condition of combination switch.
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
TAIL LAMP SW [On/Off]	
PASSING SW [On/Off]	
FR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
KEY ON SW [On/Off]	Indicates condition of key switch.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
PKB SW [On/Off]	Indicates park brake switch signal received from combination meter on CAN communication line.
ENGINE RUN [On/Off]	Indicates engine run signal received from ECM on CAN communication line.
VEHICLE SPEED [km/h/mph]	Indicates vehicle speed signal received from combination meter on CAN communication line.

ACTIVE TEST

Test Item	Description
TAIL LAMP	This test is able to check tail lamp operation [On/Off].
HEAD LAMP	This test is able to check head lamp operation [Hi/Low/Off].
FR FOG LAMP	This test is able to check front fog lamp operation [On/Off].
ILL DIM SIGNAL	This test is able to check head lamp illumination dimming operation [On/Off].

WORK SUPPORT

Support Item	Setting	Description
BATTERY SAVER SET	On*	Exterior lamp battery saver function ON.
	Off	Exterior lamp battery saver function OFF.

DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Support Item	Setting		Description
ILL DELAY SET	MODE 8	180 sec.	Sets delay timer function operation time (All doors closed).
	MODE 7	150 sec.	
	MODE 6	120 sec.	
	MODE 4	60 sec.	
	MODE 5	90 sec.	
	MODE 3	30 sec.	
	MODE 2	OFF	
	MODE 1*	45 sec.	

* : Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000010308709

DATA MONITOR

Monitor Item [Unit]	Description
HAZARD SW [On/Off]	Indicates condition of hazard switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

Diagnosis Description

INFOID:000000010287618

AUTO ACTIVE TEST

Description

In auto active test, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Front wiper (LO, HI)
- Parking lamp
- License plate lamp
- Tail lamp
- Front fog lamp (if equipped)
- Headlamp (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

Operation Procedure

NOTE:

Never perform auto active test in the following conditions.

- Passenger door is open
- CONSULT is connected

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

- When auto active test has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-103, "Component Inspection"](#).

Inspection in Auto Active Test


When auto active test is actuated, the following operation sequence is repeated 3 times.

Operation sequence	Inspection location	Operation
1	Front wiper	LO for 5 seconds → HI for 5 seconds
2	<ul style="list-style-type: none">• Parking lamp• License plate lamp• Tail lamp• Front fog lamp (if equipped)	10 seconds
3	Headlamp	LO for 10 seconds → HI ON ⇔ OFF 5 times
4	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
5	Cooling fan	LO for 5 seconds → MID for 3 seconds → HI for 2 seconds

DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Concept of Auto Active Test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis Chart in Auto Active Test

Symptom	Inspection contents	Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> • Parking lamp • License plate lamp • Tail lamp • Front fog lamp (if equipped) • Headlamp (HI, LO) • Front wiper (HI, LO) 	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> • BCM signal input circuit • CAN communication signal between BCM and ECM • CAN communication signal between ECM and IPDM E/R
		NO <ul style="list-style-type: none"> • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R
		NO <ul style="list-style-type: none"> • Cooling fan motor • Harness or connector between IPDM E/R and cooling fan motor • IPDM E/R

CONSULT Function (IPDM E/R)

INFOID:000000010287619

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.

DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Direct Diagnostic Mode	Description
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

ECU IDENTIFICATION

The IPDM E/R part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-20, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
MOTOR FAN REQ [%]	×	Indicates cooling fan speed signal received from ECM on CAN communication line
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch
INTER/NP SW [On/Off]		Indicates condition of CVT shift position
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line
ST/INH RLY [Off/ ST /INH]		Indicates condition of starter relay and starter control relay
DETENT SW [On/Off]		Indicates condition of CVT shift selector (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line

ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
REAR DEFOGGER	This test is able to check rear window defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].

DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Test item	Description
MOTOR FAN	This test is able to check cooling fan operation [4/3/2/1].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].

CAN DIAG SUPPORT MNTR

Refer to [LAN-13, "CAN Diagnostic Support Monitor"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

Diagnosis Description

INFOID:000000010287620

AUTO ACTIVE TEST

Description

In auto active test, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Front wiper (LO, HI)
- Parking lamp
- License plate lamp
- Tail lamp
- Front fog lamp (if equipped)
- Headlamp (LO, HI)
- A/C compressor (magnet clutch) (if equipped)
- Cooling fan

Operation Procedure

NOTE:

Never perform auto active test in the following conditions.

- Passenger door is open
- CONSULT is connected

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

- When auto active test has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-255, "Component Inspection"](#).

Inspection in Auto Active Test


When auto active test is actuated, the following operation sequence is repeated 3 times.

Operation sequence	Inspection location	Operation
1	Front wiper	LO for 5 seconds → HI for 5 seconds
2	<ul style="list-style-type: none">• Parking lamp• License plate lamp• Tail lamp• Front fog lamp (if equipped)	10 seconds
3	Headlamp	LO for 10 seconds → HI ON ⇔ OFF 5 times
4	A/C compressor (magnet clutch) (if equipped)	ON ⇔ OFF 5 times
5	Cooling fan	LO for 5 seconds → MID for 3 seconds → HI for 2 seconds

DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Concept of Auto Active Test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis Chart in Auto Active Test

Symptom	Inspection contents	Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> • Parking lamp • License plate lamp • Tail lamp • Front fog lamp (if equipped) • Headlamp (HI, LO) • Front wiper (HI, LO) 	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> • BCM signal input circuit • CAN communication signal between BCM and ECM • CAN communication signal between ECM and IPDM E/R
		NO <ul style="list-style-type: none"> • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R
		NO <ul style="list-style-type: none"> • Cooling fan motor • Harness or connector between IPDM E/R and cooling fan motor • IPDM E/R

CONSULT Function (IPDM E/R)

INFOID:000000010287621

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.

DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Direct Diagnostic Mode	Description
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

ECU IDENTIFICATION

The IPDM E/R part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-48, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
MOTOR FAN REQ [%]	×	Indicates cooling fan speed signal received from ECM on CAN communication line
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch
INTER/NP SW [On/Off]		Indicates condition of CVT shift position
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line
ST/INH RLY [Off/ ST /INH]		Indicates condition of starter relay and starter control relay
DETENT SW [On/Off]		Indicates condition of CVT shift selector (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line

ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
REAR DEFOGGER	This test is able to check rear window defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].

DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Test item	Description
MOTOR FAN	This test is able to check cooling fan operation [4/3/2/1].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].

CAN DIAG SUPPORT MNTR

Refer to [LAN-13, "CAN Diagnostic Support Monitor"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BCM, IPDM E/R

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000009757497

ECU	Reference
BCM (with Intelligent Key system)	BCS-29, "Reference Value"
	BCS-46, "Fail-safe"
	BCS-48, "DTC Inspection Priority Chart"
	BCS-49, "DTC Index"
BCM (without Intelligent Key system)	BCS-97, "Reference Value"
	BCS-108, "Fail-safe"
	BCS-108, "DTC Inspection Priority Chart"
	BCS-109, "DTC Index"
IPDM E/R (with Intelligent Key system)	PCS-13, "Reference Value"
	PCS-19, "Fail-safe"
	PCS-20, "DTC Index"
IPDM E/R (without Intelligent Key system)	PCS-41, "Reference Value"
	PCS-47, "Fail-Safe"
	PCS-48, "DTC Index"

HEADLAMP


< WIRING DIAGRAM >

WIRING DIAGRAM

HEADLAMP

Wiring Diagram

INFOID:000000009757498




ABLWA2440GB

HEADLAMP

< WIRING DIAGRAM >

HEADLAMP CONNECTORS

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3

Terminal No.	Color of Wire	Signal Name
10G	Y	-
95G	P	-
100G	L	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	O	BATTERY (FUSE)
65	B	GND
70	Y	BATTERY (F/L)

Terminal No.	Color of Wire	Signal Name
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
2	P	CAN-L
21	B	GND (ILL)
22	B	GND2 (POWER)
23	B	GND3 (CIRCUIT)
27	LG	BAT
28	GR	IGN

HEADLAMP

< WIRING DIAGRAM >


Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
5	BR	-
7	V	-
8	L	-


Terminal No.	Color of Wire	Signal Name
9	R	-
10	Y	-
11	SB	-
12	W	-
13	LG	-
14	O	-

Connector No.	M31
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	P	-
9	P	-
10	P	-
15	L	-
19	L	-
20	L	-

Connector No.	M53
Connector Name	JOINT CONNECTOR-M03
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
14	P	-
15	P	-
19	L	-
20	L	-

Connector No.	M60
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
5	LG	-
9	W	-

AALIA1017GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP

< WIRING DIAGRAM >

Connector No.	M85
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	WHITE

89	88	87	86	85	84	83	82	81
95	94	93	92	91	90			



Terminal No.	Color of Wire	Signal Name
88	O	BATTERY (FUSE)
90	Y	BATTERY (F/L)
93	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
4	BR	COMBINATION SW INPUT 3
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M84
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4

Connector No.	E4
Connector Name	WIRE TO WIRE
Connector Color	WHITE




12	11	10	9	8	7	6	5	4	3	2	1
----	----	----	---	---	---	---	---	---	---	---	---



Terminal No.	Color of Wire	Signal Name
1	L	-
5	L	-
8	P	-
12	P	-

Terminal No.	Color of Wire	Signal Name
10G	G	-
95G	P	-
100G	L	-



ABLIA5894GB

HEADLAMP

< WIRING DIAGRAM >

Connector No.	E43
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



9	8	7	6	5	4	3		
18	17	16	15	14	13	12	11	10

Terminal No.	Color of Wire	Signal Name
5	Y	H/LAMP HI RH
6	G	H/LAMP HI LH
7	L	H/LAMP LO LH
8	P	H/LAMP LO RH

Connector No.	E21
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	BLACK



8	7	6	5
4	3	2	1

Terminal No.	Color of Wire	Signal Name
1	L	-
2	G	-
5	B/R	-
6	B/R	-

Connector No.	E20
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	BLACK



8	7	6	5
4	3	2	1

Terminal No.	Color of Wire	Signal Name
1	P	-
2	Y	-
5	B	-
6	B	-

Connector No.	E48
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



59	58	57
62	61	60

Terminal No.	Color of Wire	Signal Name
57	B/Y	GND (POWER)

Connector No.	E47
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



51	50	49		
56	55	54	53	52

Terminal No.	Color of Wire	Signal Name
52	B/Y	GND (SIGNAL)

Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



42	41	40	39	38	37
48	47	46	45	44	43

Terminal No.	Color of Wire	Signal Name
40	P	CAN-L
41	L	CAN-H

AALIA1019GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL


DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

DAYTIME LIGHT SYSTEM

Wiring Diagram

INFOID:000000009757499




ABLWA2449GB

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


DAYTIME LIGHT SYSTEM CONNECTORS

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10G	Y	-
31G	V	-
95G	P	-
100G	L	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	V	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	O	BATTERY (FUSE)
65	B	GND
70	Y	BATTERY (F/L)

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3

Terminal No.	Color of Wire	Signal Name
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

ABLIA5868GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

DAYTIME LIGHT SYSTEM


< WIRING DIAGRAM >

Connector No.	M31
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	P	-
9	P	-
10	P	-
15	L	-
19	L	-
20	L	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
5	BR	-
7	V	-
8	L	-
9	R	-
10	Y	-
11	SB	-
12	W	-
13	LG	-
14	O	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
2	P	CAN-L
10	SB	PKB SW
21	B	GND (ILL)
22	B	GND2 (POWER)
23	B	GND3 (CIRCUIT)
27	LG	BAT
28	GR	IGN

Connector No.	M60
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
5	LG	-
9	W	-

Connector No.	M53
Connector Name	JOINT CONNECTOR-M03
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
14	P	-
15	P	-
19	L	-
20	L	-

ABLIA5869GB

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	M85
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



83	86	85	84	83	82	81
95	94	93	92	91	90	

Terminal No.	Color of Wire	Signal Name
88	O	BATTERY (FUSE)
90	Y	BATTERY (F/L)
93	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M84
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1

Connector No.	M130
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



1

Terminal No.	Color of Wire	Signal Name
1	SB	-

ABLIA5870GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

DAYTIME LIGHT SYSTEM


< WIRING DIAGRAM >

Connector No.	E2
Connector Name	JOINT CONNECTOR-E02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
5	L	-
8	P	-
12	P	-

Connector No.	E4
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10G	G	-
31G	R	-
95G	P	-
100G	L	-

Connector No.	E20
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
3	L	-
7	B	-
8	L	-

Connector No.	E21
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
3	L	-
7	B/R	-
8	L	-

Connector No.	E24
Connector Name	JOINT CONNECTOR-E03
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
13	R	-
14	L	-
15	L	-
16	L	-
17	L	-
18	L	-

DAYTIME LIGHT SYSTEM


< WIRING DIAGRAM >

Connector No.	E47
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
52	B/Y	GND (SIGNAL)

Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
40	P	CAN-L
41	L	CAN-H
42	Y	DTRL RLY

Connector No.	E30
Connector Name	DAYTIME LIGHT RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	LG	-
3	L	-
5	LG	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-
7	O	-
20	B	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	LG	-

Connector No.	E48
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	B/Y	GND (POWER)


ABLIA5871GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	B73
Connector Name	JOINT CONNECTOR-B01
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
19	B	-
20	B	-
23	L	-
24	B	-

Connector No.	B42
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
6	L	-

Connector No.	B25
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
6	O	-

Connector No.	B77
Connector Name	JOINT CONNECTOR-B02
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
3	G	-
4	BR	-
5	LG	-
6	GR	-

Connector No.	B75
Connector Name	LICENSE PLATE LAMP RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	B	-

Connector No.	B74
Connector Name	LICENSE PLATE LAMP LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	P	-
2	B	-

AALIA1033GB

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

Connector No.	B93
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6
7	8	9	10	11	12
			13	14	15
			16	17	18
			19	20	

Terminal No.	Color of Wire	Signal Name
1	L	-
3	G	-
7	B	-
20	B	-

AALIA1034GB


AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

AUTO LIGHT SYSTEM

Wiring Diagram

INFOID:000000009757500




ABLWA2450GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

AUTO LIGHT SYSTEM CONNECTORS

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10G	Y	-
95G	P	-
100G	L	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	O	BATTERY (FUSE)
65	B	GND
70	Y	BATTERY (F/L)

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3

Terminal No.	Color of Wire	Signal Name
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1
14	SB	AUTO LIGHT SENSOR INPUT 1 (& 2)
17	Y	AUTO LIGHT SENSOR POWER SUPPLY OUTPUT
18	V	KEYLESS & AUTO LIGHT SENSOR GND
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3

Terminal No.	Color of Wire	Signal Name
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

ABLIA5872GB


A B C D E F G H I J K L M N O P

EXL

AUTO LIGHT SYSTEM


< WIRING DIAGRAM >

Connector No.	M53
Connector Name	JOINT CONNECTOR-M03
Connector Color	PINK




Terminal No.	Color of Wire	Signal Name
14	P	-
15	P	-
19	L	-
20	L	-

Connector No.	M31
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
9	P	-
10	P	-
19	L	-
20	L	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
5	BR	-
7	V	-
8	L	-
9	R	-
10	Y	-
11	SB	-
12	W	-
13	LG	-
14	O	-

Connector No.	M72
Connector Name	OPTICAL SENSOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	SB	-
3	V	-

ABLIA5891GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1
14	SB	AUTO LIGHT SENSOR INPUT
17	Y	AUTO LIGHT SENSOR POWER SUPPLY OUTPUT
18	V	KEYLESS TUNER, AUTO LIGHT SENSOR GND
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3

Connector No.	M84
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3

Connector No.	E2
Connector Name	JOINT CONNECTOR-E02
Connector Color	BLUE



1	2	3	4	5	6	7	8	9	10	11	12
---	---	---	---	---	---	---	---	---	----	----	----

Terminal No.	Color of Wire	Signal Name
1	L	-
5	L	-
8	P	-
12	P	-

Connector No.	M85
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



81	82	83	84	85	86	87	88	89
90	91	92	93	94	95			

Terminal No.	Color of Wire	Signal Name
88	O	BATTERY (FUSE)
90	Y	BATTERY (F/L)
93	B	GND (POWER)

ABLIA5892GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


Connector No.	E43
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	Y	H/LAMP HI RH
6	G	H/LAMP HI LH
7	L	H/LAMP LO LH
8	P	H/LAMP LO RH

Terminal No.	Color of Wire	Signal Name
10G	G	-
95G	P	-
100G	L	-

Connector No.	E4
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E47
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
52	B/Y	GND (SIGNAL)

Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
40	P	CAN-L
41	L	CAN-H

Connector No.	E45
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
27	L	CLEARANCE/L RH
28	R	TAIL 1

ABLIA5873GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


Connector No.	B24
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK

104 103 102 01 100 99 98 97 96
110 109 108 107 106 105



Terminal No.	Color of Wire	Signal Name
97	GR	DOOR SW (RL)
98	Y	DOOR SW (DR)
99	P	DOOR SW (RR)
100	R	DOOR SW (AS)

Connector No.	B21
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	Y	-


Connector No.	E48
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK

59 58 57
62 61 60




Terminal No.	Color of Wire	Signal Name
57	B/Y	GND (POWER)

Connector No.	B41
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-

Connector No.	B28
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B26
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	GR	-

ABLIA5874GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	B57
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	BLACK

49	46	45	44	43	42	41
55	54	53	52	51	50	



Terminal No.	Color of Wire	Signal Name
45	R	DOOR SW (AS)
46	Y	DOOR SW (DR)
47	GR	DOOR SW (RL)
48	P	DOOR SW (RR)

ABLIA5900GB


FRONT FOG LAMP

< WIRING DIAGRAM >

FRONT FOG LAMP

Wiring Diagram

INFOID:000000009757501



ABLWA2444GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


EXL

FRONT FOG LAMP

< WIRING DIAGRAM >

FRONT FOG LAMP CONNECTORS

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	Y	-
95G	P	-
100G	L	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	O	BATTERY (FUSE)
65	B	GND
70	Y	BATTERY (F/L)


Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	O	COMBINATION SW INPUT 2

Terminal No.	Color of Wire	Signal Name
6	W	COMBINATION SW INPUT 1
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
5	BR	-
7	V	-
8	L	-
9	R	-
10	Y	-
11	SB	-
12	W	-
13	LG	-
14	O	-

ABLIA5852GB

FRONT FOG LAMP


< WIRING DIAGRAM >

Connector No.	M53
Connector Name	JOINT CONNECTOR-M03
Connector Color	PINK




Terminal No.	Color of Wire	Signal Name
14	P	-
15	P	-
19	L	-
20	L	-

Connector No.	M31
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
9	P	-
10	P	-
19	L	-
20	L	-


Connector No.	M85
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
88	O	BATTERY (FUSE)
90	Y	BATTERY (F/L)
93	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
6	W	COMBINATION SW INPUT 1
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M84
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	O	COMBINATION SW INPUT 2

ABLIA5893GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


EXL

FRONT FOG LAMP


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
10G	G	-
95G	P	-
100G	L	-

Connector No.	E4
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E2
Connector Name	JOINT CONNECTOR-E02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
5	L	-
8	P	-
12	P	-

Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
40	P	CAN-L
41	L	CAN-H

Connector No.	E28
Connector Name	FRONT FOG LAMP RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	E27
Connector Name	FRONT FOG LAMP LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-

AALIA1014GB

FRONT FOG LAMP

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

Connector No.	E48
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK

59	58	57
62	61	60



Terminal No.	Color of Wire	Signal Name
57	B/Y	GND (POWER)

Connector No.	E47
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN

51	50	49
56	55	54
53	52	



Terminal No.	Color of Wire	Signal Name
52	B/Y	GND (SIGNAL)
53	W	FR FOG/L RH
54	V	FR FOG/L LH

AALIA1015GB


TURN SIGNAL AND HAZARD WARNING LAMPS

< WIRING DIAGRAM >

TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram

INFOID:000000009757502




ABLWA2445GB

TURN SIGNAL AND HAZARD WARNING LAMPS

< WIRING DIAGRAM >

(IK) : WITH INTELLIGENT KEY SYSTEM
 (OK) : WITHOUT INTELLIGENT KEY SYSTEM
 (TM) : WITH TURN SIGNAL IN MIRROR
 *4 (IK) : 85 (OK) : 41
 *5 (IK) : 84 (OK) : 42



ABLWA2446GB


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TURN SIGNAL AND HAZARD WARNING LAMPS

< WIRING DIAGRAM >

TURN SIGNAL AND HAZARD WARNING LAMPS CONNECTORS


Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	W	-
8	Y	-

Terminal No.	Color of Wire	Signal Name
10G	Y	-
33G	Y	-
42G	W	-

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	O	BATTERY (FUSE)
65	B	GND
70	Y	BATTERY (F/L)

Terminal No.	Color of Wire	Signal Name
38C	W	-
39C	B	-

Connector No.	M13
Connector Name	WIRE TO WIRE
Connector Color	WHITE




AALIA1038GB

TURN SIGNAL AND HAZARD WARNING LAMPS

< WIRING DIAGRAM >


Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1


Terminal No.	Color of Wire	Signal Name
29	SB	HAZARD SW
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
2	P	CAN-L
21	B	GND (ILL)
22	B	GND2 (POWER)
23	B	GND3 (CIRCUIT)
27	LG	BAT
28	GR	IGN


Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
5	BR	-
7	V	-
8	L	-

Terminal No.	Color of Wire	Signal Name
9	R	-
10	Y	-
11	SB	-
12	W	-
13	LG	-
14	O	-

Connector No.	M31
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
5	P	-
10	P	-
15	L	-
20	L	-


ABLIA5853GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TURN SIGNAL AND HAZARD WARNING LAMPS


< WIRING DIAGRAM >

Connector No.	M71
Connector Name	JOINT CONNECTOR-M05
Connector Color	PINK




Terminal No.	Color of Wire	Signal Name
14	B	-
15	B	-

Connector No.	M60
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
5	LG	-
9	W	-

Connector No.	M53
Connector Name	JOINT CONNECTOR-M03
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
14	P	-
15	P	-
19	L	-
20	L	-

Connector No.	M74
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
38A	Y	-
39A	B	-

ABLIA5854GB

TURN SIGNAL AND HAZARD WARNING LAMPS

< WIRING DIAGRAM >

Connector No.	M85
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	WHITE

80	88	87	86	85	84	83	82	81
35	34	33	32	31	30			



Terminal No.	Color of Wire	Signal Name
84	W	FLASHER OUTPUT (RIGHT)
85	Y	FLASHER OUTPUT (LEFT)
88	O	BATTERY (FUSE)
90	Y	BATTERY (F/L)
93	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
29	SB	HAZARD SW
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M84
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1

Connector No.	M102
Connector Name	HAZARD SWITCH
Connector Color	WHITE

4	3	2	1
---	---	---	---



Terminal No.	Color of Wire	Signal Name
2	SB	-
3	B	-

ABLIA5855GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

TURN SIGNAL AND HAZARD WARNING LAMPS

< WIRING DIAGRAM >


Connector No.	E13
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	Y	-
3	V	-

Terminal No.	Color of Wire	Signal Name
10G	G	-
33G	Y	-
42G	V	-

Connector No.	E4
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E24
Connector Name	JOINT CONNECTOR-E03
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
19	Y	-
20	Y	-
21	Y	-
22	V	-
23	V	-
24	V	-

Connector No.	E21
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	V	-
7	B/R	-

Connector No.	E20
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
4	Y	-
7	B	-

ABLIA5856GB

TURN SIGNAL AND HAZARD WARNING LAMPS


< WIRING DIAGRAM >

Connector No.	B9
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	Y	-
3	SB	-

Connector No.	B8
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	O	-
8	LG	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
7	O	-
8	SB	-

Connector No.	B57
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
41	LG	FLASHER OUTPUT (LEFT)
42	O	FLASHER OUTPUT (RIGHT)

Connector No.	B42
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
6	L	-

Connector No.	B25
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	SB	-
6	O	-

ABLIA5857GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

TURN SIGNAL AND HAZARD WARNING LAMPS


< WIRING DIAGRAM >

Connector No.	B93
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
7	B	-
8	BR	-


Connector No.	B73
Connector Name	JOINT CONNECTOR-B01
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
6	SB	-
7	BR	-
8	LG	-
10	Y	-
11	R	-
12	O	-
19	B	-
20	B	-
23	L	-
24	B	-

Terminal No.	Color of Wire	Signal Name
38C	G	-
39C	B/W	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA5858GB

TURN SIGNAL AND HAZARD WARNING LAMPS


< WIRING DIAGRAM >

Connector No.	D7
Connector Name	DOOR MIRROR LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	B/W	-
10	G	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
38A	G	-
39A	B/W	-

Connector No.	D106
Connector Name	DOOR MIRROR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	B/W	-
10	G	-

ABLIA5907GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


PARKING, LICENSE PLATE AND TAIL LAMPS

< WIRING DIAGRAM >

PARKING, LICENSE PLATE AND TAIL LAMPS

Wiring Diagram

INFOID:000000009757503




ABLWA2448GB

PARKING, LICENSE PLATE AND TAIL LAMPS

< WIRING DIAGRAM >


PARKING, LICENSE PLATE AND TAIL LAMPS CONNECTORS

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10G	Y	-
31G	V	-
95G	P	-
100G	L	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	V	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	O	BATTERY (FUSE)
65	B	GND
70	Y	BATTERY (F/L)

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1

Terminal No.	Color of Wire	Signal Name
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

ABLIA5865GB


A B C D E F G H I J K L M N O P

EXL

PARKING, LICENSE PLATE AND TAIL LAMPS


< WIRING DIAGRAM >

Connector No.	M31
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	P	-
9	P	-
10	P	-
15	L	-
19	L	-
20	L	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
5	BR	-
7	V	-
8	L	-
9	R	-
10	Y	-
11	SB	-
12	W	-
13	LG	-
14	O	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
2	P	CAN-L
21	B	GND (ILL)
22	B	GND2 (POWER)
23	B	GND3 (CIRCUIT)
27	LG	BAT
28	GR	IGN

Connector No.	M60
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
5	LG	-
9	W	-

Connector No.	M53
Connector Name	JOINT CONNECTOR-M03
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
14	P	-
15	P	-
19	L	-
20	L	-

ABLIA5866GB

PARKING, LICENSE PLATE AND TAIL LAMPS

< WIRING DIAGRAM >

Connector No.	M85
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



83	86	85	84	83	82	81
95	94	93	92	91	90	

Terminal No.	Color of Wire	Signal Name
88	O	BATTERY (FUSE)
90	Y	BATTERY (F/L)
93	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
32	LG	COMBINATION SW OUTPUT 5
33	Y	COMBINATION SW OUTPUT 4
34	V	COMBINATION SW OUTPUT 3
35	R	COMBINATION SW OUTPUT 2
36	SB	COMBINATION SW OUTPUT 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M84
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	L	COMBINATION SW INPUT 5
3	GR	COMBINATION SW INPUT 4
4	BR	COMBINATION SW INPUT 3
5	O	COMBINATION SW INPUT 2
6	W	COMBINATION SW INPUT 1

Connector No.	E2
Connector Name	JOINT CONNECTOR-E02
Connector Color	BLUE



12	11	10	9	8	7	6	5	4	3	2	1
----	----	----	---	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name
1	L	-
5	L	-
8	P	-
12	P	-

ABLIA5895GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

PARKING, LICENSE PLATE AND TAIL LAMPS

< WIRING DIAGRAM >


Connector No.	E20
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
3	L	-
7	B	-
8	L	-

Terminal No.	Color of Wire	Signal Name
10G	G	-
31G	R	-
95G	P	-
100G	L	-

Connector No.	E4
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E30
Connector Name	DAYTIME LIGHT RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	LG	-
3	L	-
5	LG	-

Connector No.	E24
Connector Name	JOINT CONNECTOR-E03
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
13	R	-
14	L	-
15	L	-
16	L	-
17	L	-
18	L	-

Connector No.	E21
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
3	L	-
7	B/R	-
8	L	-

AALIA1048GB

PARKING, LICENSE PLATE AND TAIL LAMPS

< WIRING DIAGRAM >


Connector No.	E47
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



51	50	49
56	55	54 53 52

Terminal No.	Color of Wire	Signal Name
52	B/Y	GND (SIGNAL)


Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



42	41	40	39	38	37
48	47	46	45	44	43

Terminal No.	Color of Wire	Signal Name
40	P	CAN-L
41	L	CAN-H
42	Y	DTRL RLY


Connector No.	E45
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



29	28	27	26	25
36	35	34	33	32 31 30

Terminal No.	Color of Wire	Signal Name
27	L	CLEARANCE/L RH
28	R	TAIL 1

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



6	5	4	3	2	1
20	19	18	17	16	15 14
					8
					9
					10 11
					12 13
					14

Terminal No.	Color of Wire	Signal Name
1	L	-
3	LG	-
7	O	-
20	B	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7
8	9	10	11	12	13	14
						15 16

Terminal No.	Color of Wire	Signal Name
5	LG	-

Connector No.	E48
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



59	58	57
62	61	60

Terminal No.	Color of Wire	Signal Name
57	B/Y	GND (POWER)


ABLIA5867GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

PARKING, LICENSE PLATE AND TAIL LAMPS

< WIRING DIAGRAM >

Connector No.	B73
Connector Name	JOINT CONNECTOR-B01
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
19	B	-
20	B	-
23	L	-
24	B	-

Connector No.	B42
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
6	L	-

Connector No.	B25
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
6	O	-

Connector No.	B77
Connector Name	JOINT CONNECTOR-B02
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
3	G	-
4	BR	-
5	LG	-
6	GR	-

Connector No.	B75
Connector Name	LICENSE PLATE LAMP RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	B	-

Connector No.	B74
Connector Name	LICENSE PLATE LAMP LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	P	-
2	B	-

AALIA1050GB

PARKING, LICENSE PLATE AND TAIL LAMPS

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

Connector No.	B93
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5	6
7	8	9	10	11	12



Terminal No.	Color of Wire	Signal Name
1	L	-
3	G	-
7	B	-
20	B	-

AALIA1051GB

STOP LAMP

< WIRING DIAGRAM >


STOP LAMP

Wiring Diagram

INFOID:000000009757504

OS : WITHOUT REAR SPOILER
SP : WITH REAR SPOILER

STOP LAMP



AALWA0523GB

STOP LAMP

< WIRING DIAGRAM >


STOP LAMP CONNECTORS

Connector No.	E3
Connector Name	JOINT CONNECTOR-E01
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
11	SB	-
12	SB	-

Connector No.	E13
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	SB	-

Connector No.	E60
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	SB	-

Connector No.	E62
Connector Name	JOINT CONNECTOR-E04
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
11	W	-
12	W	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
4	P	-
7	O	-
20	B	-

Connector No.	B9
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-

ABLIA5875GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

STOP LAMP


< WIRING DIAGRAM >

Connector No.	B46
Connector Name	HIGH-MOUNTED STOP LAMP (WITHOUT REAR SPOILER)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	-
2	B	-

Connector No.	B42
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	V	-
6	L	-

Connector No.	B25
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	R	-
6	O	-

Connector No.	B77
Connector Name	JOINT CONNECTOR-B02
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	V	-
11	R	-
12	L	-

Connector No.	B73
Connector Name	JOINT CONNECTOR-B01
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
19	B	-
20	B	-
23	L	-
24	B	-

Connector No.	B71
Connector Name	HIGH-MOUNTED STOP LAMP (WITH REAR SPOILER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	L	-

AALIA1021GB

STOP LAMP

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

Connector No.	B93
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6
7	8	9	10	11	12
					13
					14
					15
					16
					17
					18
					19
					20

Terminal No.	Color of Wire	Signal Name
1	L	-
4	Y	-
7	B	-
20	B	-

AALIA1022GB

BACK-UP LAMP


< WIRING DIAGRAM >

BACK-UP LAMP

Wiring Diagram

INFOID:000000009757505

M : WITH M/T
VT : WITH CVT




ABLWA2456GB

BACK-UP LAMP

< WIRING DIAGRAM >


BACK-UP LAMP CONNECTORS

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3G	SB	-
4G	GR	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	GR	-

Connector No.	M60
Connector Name	JOINT CONNECTOR-M06
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	GR	-

AALIA1008GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

BACK-UP LAMP

< WIRING DIAGRAM >


Connector No.	E43
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	O	A/T ECU IGN

Terminal No.	Color of Wire	Signal Name
3G	W	-
4G	GR	-

Connector No.	E4
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	F23
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
6	G	R RANGE SW

Terminal No.	Color of Wire	Signal Name
5A	O	-
17A	GR	-
18A	W	-

Connector No.	E64
Connector Name	WIRE TO WIRE
Connector Color	BLACK




ABLIA5876GB

BACK-UP LAMP


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
5A	LG	-
17A	SB	-
18A	G	-

Connector No.	F50
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Connector No.	F26
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
4	LG	-
8	G	-

Connector No.	B8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	12	Color of Wire	W	Signal Name	-
--------------	----	---------------	---	-------------	---

Terminal No.	1	Color of Wire	L	Signal Name	-
Terminal No.	5	Color of Wire	W	Signal Name	-
Terminal No.	7	Color of Wire	O	Signal Name	-

Connector No.	F52
Connector Name	PARK/NEUTRAL (PNP) SWITCH
Connector Color	GREEN



Terminal No.	1	Color of Wire	G	Signal Name	-
Terminal No.	2	Color of Wire	SB	Signal Name	-


AALIA1010GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BACK-UP LAMP


< WIRING DIAGRAM >

Connector No.	B73
Connector Name	JOINT CONNECTOR-B01
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
19	B	-
20	B	-
23	L	-
24	B	-

Connector No.	B42
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	SB	-
6	L	-

Connector No.	B25
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
6	O	-

Connector No.	B93
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
5	W	-
7	B	-

Connector No.	B77
Connector Name	JOINT CONNECTOR-B02
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
13	W	-
14	SB	-
15	P	-

ABLIA5877GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000009757506

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

>> GO TO 2

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4

4. SELF-DIAGNOSIS WITH CONSULT

Perform the self diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 6

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7

NO >> GO TO 8

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform the self diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 11

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

YES >> Inspection End.

NO >> GO TO 3

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

HEADLAMP (HI) CIRCUIT

Description

INFOID:000000009757507

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp high relay based on inputs from the BCM over the CAN communication lines. When the headlamp high relay is energized, power flows through fuses 41 and 42, located in the IPDM E/R. Power then flows to the front combination lamps to the headlamp high beam.

Component Function Check

INFOID:000000009757508

1. CHECK HEADLAMP (HI) OPERATION

⊗ WITHOUT CONSULT

1. Start IPDM E/R auto active test. Refer to [EXL-24, "Diagnosis Description"](#) (with Intelligent Key system) or [EXL-28, "Diagnosis Description"](#) (without Intelligent Key system).
2. Check that the headlamp switches to the high beam.

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

Ⓜ CONSULT

1. Select EXTERNAL LAMP of IPDM E/R active test item.
2. While operating the test items, check that the headlamp switches to the high beam.

HI : Headlamp switches to the high beam.

OFF : Headlamp OFF

Is the inspection result normal?

- YES >> Headlamp (HI) circuit is normal.
NO >> Refer to [EXL-88, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009757509

Regarding Wiring Diagram information, refer to [EXL-33, "Wiring Diagram"](#).

1. CHECK HEADLAMP (HI) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	42	10A
Headlamp HI (RH)	IPDM E/R	41	10A

Is the fuse blown?

- YES >> Replace the fuse after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

Ⓜ CONSULT ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp harness connector in question.
3. Turn the ignition switch ON.
4. Select EXTERNAL LAMP of IPDM E/R active test item.
5. With EXTERNAL LAMP ON, check the voltage between the combination lamp connector and ground.

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

(+)		Terminal	(-)	Voltage
Connector				
RH	E20	2	Ground	Battery voltage
LH	E21			

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK HEADLAMP (HI) CIRCUIT FOR OPEN

- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector.
- Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E43	E20	2	Yes
LH		5		
		E21		

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-30. "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58. "Removal and Installation"](#) (without Intelligent Key system).
NO >> Repair or replace the harness or connector.

4. CHECK FRONT COMBINATION LAMP (HI) GROUND CIRCUIT

Check continuity between the front combination lamp harness connector terminal and ground.

Connector	Terminal	—	Continuity
RH	E20	6	Ground
LH	E21		

Is the inspection result normal?

- YES >> Inspect the headlamp bulb.
NO >> Repair or replace the harness or connector.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

HEADLAMP (LO) CIRCUIT

Description

INFOID:000000009757510

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp low relay based on inputs from the BCM over the CAN communication lines. When the headlamp low relay is energized, power flows through fuses 43 and 44, located in the IPDM E/R. Power then flows to the front combination lamps to the headlamp low beam.

Component Function Check

INFOID:000000009757511

1. CHECK HEADLAMP (LO) OPERATION

⊗ WITHOUT CONSULT

1. Start IPDM E/R auto active test. Refer to [EXL-24. "Diagnosis Description"](#) (with Intelligent Key system) or [EXL-28. "Diagnosis Description"](#) (without Intelligent Key system).
2. Check that the headlamp is turned ON.

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

Ⓟ CONSULT

1. Select EXTERNAL LAMP of IPDM E/R active test item.
2. While operating the test items, check that the headlamp is turned ON.

LO : Headlamp ON

OFF : Headlamp OFF

Is the inspection result normal?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-90. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009757512

Regarding Wiring Diagram information, refer to [EXL-33. "Wiring Diagram"](#).

1. CHECK HEADLAMP (LO) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	44	15A
Headlamp LO (LH)	IPDM E/R	43	15A

Is the fuse blown?

YES >> Replace the fuse after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK HEADLAMP (LO) OUTPUT VOLTAGE

Ⓟ CONSULT

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp harness connector in question.
3. Turn the ignition switch ON.
4. Select EXTERNAL LAMP of IPDM E/R active test item.
5. With EXTERNAL LAMP ON, check the voltage between the combination lamp connector and ground.

(+)		(-)	Voltage
Connector	Terminal		

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

RH	E20	1	Ground	Battery voltage
LH	E21			

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK HEADLAMP (LO) CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E43	E20	1	Yes
LH				
		E21		

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58, "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace the harness or connector.

4. CHECK FRONT COMBINATION LAMP (LO) GROUND CIRCUIT

Check continuity between the front combination lamp harness connector and ground.

Connector	Terminal	—	Continuity
RH	E20	Ground	Yes
LH	E21		

Is the inspection result normal?

YES >> Inspect the headlamp bulb.

NO >> Repair or replace the harness or connector.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

DAYTIME LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DAYTIME LIGHT RELAY CIRCUIT

Description

INFOID:000000009757513

The BCM sends a daytime light request to the IPDM E/R via the CAN communication lines. The power flows through fuse 29 located in fuse block J/B to the daytime light relay coil. When the IPDM E/R operates the daytime light relay, power is sent to the daytime lamps.

Diagnosis Procedure

INFOID:000000009757514

Regarding Wiring Diagram information, refer to [EXL-38. "Wiring Diagram"](#).

1. CHECK DAYTIME LIGHT RELAY VOLTAGE SUPPLY

1. Turn the ignition switch OFF.
2. Remove the daytime light relay.
3. Check the voltage between the daytime light relay harness connector and ground.

Daytime light relay		(-)	Voltage
Connector	Terminal		
E30	2	Ground	Battery voltage
	5		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK DAYTIME LIGHT RELAY FUSE

Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Daytime light	Fuse block J/B	29	10A

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.
NO >> Repair or replace the harness or connector.

3. CHECK DAYTIME LIGHT RELAY CONTROL CIRCUIT

1. Check continuity between the IPDM E/R harness connector and the daytime light relay harness connector.

Daytime light relay		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
E30	1	E46	42	Yes

2. Check continuity between the daytime light relay harness connector and ground.

Connector	Terminal	—	Continuity
E30	1	Ground	No

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connector.

4. CHECK DAYTIME LIGHT RELAY

Check the daytime light relay. Refer to [EXL-93. "Component Inspection"](#).

DAYTIME LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace relay.

5. CHECK DAYTIME LIGHT CIRCUIT (OPEN OR SHORT TO GROUND)

1. Check continuity between the daytime light relay harness connector and the front combination lamp harness connector.

Daytime light relay		Front combination lamp			Continuity
Connector	Terminal		Connector	Terminals	
E30	3	LH	E21	3, 8	Yes
		RH	E20		

2. Check continuity between the daytime light relay harness connector and ground.

Daytime light relay		(-)	Continuity
Connector	Terminal		
E30	3	Ground	No

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace the harness or connector.

6. CHECK DAYTIME LIGHT GROUND CIRCUIT FOR OPEN

1. Disconnect front combination lamp connector in question.
2. Check continuity between the front combination lamp connector and ground.

Connector	Terminal	—	Continuity
LH E21	7	Ground	Yes
RH E20			

Is the inspection result normal?

- YES >> Inspect daytime light bulb.
NO >> Repair or replace the harness or connector.

Component Inspection

INFOID:000000009757515

1. CHECK DAYTIME LIGHT RELAY

1. Turn ignition switch OFF.
2. Remove daytime light relay.
3. Check the continuity between daytime light relay terminals 3 and 5 when voltage is supplied between terminals 1 and 2.

Terminals	Condition	Continuity
3 and 5	12V direct current supply between terminals 1 and 2	Yes
	No current supply	No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace daytime light relay.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT FOG LAMP CIRCUIT

Description

INFOID:000000009757516

The IPDM E/R (intelligent power distribution module engine room) controls the front fog lamp relay based on inputs from the BCM over the CAN communication lines. When the front fog lamp relay is energized, power flows from the front fog lamp relay in the IPDM E/R to the front fog lamps.

Component Function Check

INFOID:000000009757517

1. CHECK FRONT FOG LAMP OPERATION

⊗ WITHOUT CONSULT

1. Activate IPDM E/R auto active test. Refer to [EXL-24, "Diagnosis Description"](#) (with Intelligent Key system) or [EXL-28, "Diagnosis Description"](#) (without Intelligent Key system).
2. Check that the front fog lamp is turned ON.

Ⓟ WITH CONSULT

1. Select EXTERNAL LAMP of IPDM E/R active test item.
2. While operating the test items, check that the front fog lamp is turned ON.

FOG : Front fog lamp ON
OFF : Front fog lamp OFF

Is the inspection result normal?

- YES >> Front fog lamp circuit is normal.
NO >> Refer to [EXL-94, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009757518

Regarding Wiring Diagram information, refer to [EXL-53, "Wiring Diagram"](#).

1. CHECK FRONT FOG LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	40	15A

Is the fuse blown?

- YES >> Replace the fuse after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK FRONT FOG LAMP OUTPUT VOLTAGE

Ⓟ CONSULT

1. Disconnect the front fog lamp harness connector in question.
2. Turn the ignition switch ON.
3. Turn the front fog lamps ON.
4. Check the voltage between the front fog lamp harness connector and ground.

(+)		Terminal	(-)	Voltage
Connector				
LH	E27	1	Ground	Battery voltage
RH	E28			

Is the inspection result normal?

- YES >> GO TO 4.

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 3.

3. CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front fog lamp harness connector.

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E47	53	E28	Yes
LH		54	E27	

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58, "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace the harness or connector.

4. CHECK FRONT FOG LAMP GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between the front fog lamp harness connector terminal 2 and ground.

Connector	Terminal	—	Continuity
RH	E28	2	Ground
LH	E27		

Is the inspection result normal?

YES >> Inspect the fog lamp bulb.

NO >> Repair or replace the harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PARKING LAMP CIRCUIT

Description

INFOID:000000009757519

The IPDM E/R (intelligent power distribution module engine room) controls the tail lamp relay based on inputs from the BCM over the CAN communication lines. When the tail lamp relay is energized, power flows through fuse 36, located in the IPDM E/R. Power then flows to the front and rear combination lamps, license plate lamps.

Component Function Check

INFOID:000000009757520

1. CHECK PARKING LAMP OPERATION

⊗ WITHOUT CONSULT

1. Activate IPDM E/R auto active test. Refer to [EXL-24, "Diagnosis Description"](#) (with Intelligent Key system) or [EXL-28, "Diagnosis Description"](#) (without Intelligent Key system).
2. Check that the parking lamp is turned ON.

Ⓟ WITH CONSULT

1. Select EXTERNAL LAMP of IPDM E/R active test item.
2. While operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON
OFF : Parking lamp OFF

Is the inspection result normal?

- YES >> Parking lamp circuit is normal.
NO >> Refer to [EXL-96, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009757521

Regarding Wiring Diagram information, refer to [EXL-68, "Wiring Diagram"](#).

1. CHECK PARKING LAMP FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Parking lamps	IPDM E/R	36	10A

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK TAIL LAMP RELAY OUTPUT (VOLTAGE)

1. Disconnect the front or rear combination lamp connector or license plate lamp connector in question.
2. Turn the ignition switch ON.
3. Turn the parking lamps ON.
4. With the parking lamps ON, check voltage between the front combination lamp front (parking) connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	E21	3	Ground	Battery voltage
RH	E20			

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

5. With the parking lamps ON, check voltage between the front combination lamp (side marker) connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	E21	8	Ground	Battery voltage
RH	E20			

6. With the parking lamps ON, check voltage between the rear combination lamp connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	B25	1	Ground	Battery voltage
RH	B42			

7. With the parking lamps ON, check voltage between the license plate lamp connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	B74	1	Ground	Battery voltage
RH	B75			

Are the inspection results normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK PARKING LAMP CIRCUIT (OPEN)

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp (parking) harness connector.

IPDM E/R			Front combination lamp (parking)		Continuity
Connector	Terminal	Connector	Terminal		
LH	E45	27	E21	3	Yes
RH			E20		

4. Check continuity between the IPDM E/R harness connector and the front combination lamp (side marker) harness connector.

IPDM E/R			Front combination lamp (side marker)		Continuity
Connector	Terminal	Connector	Terminal		
LH	E45	27	E21	8	Yes
RH			E20		

5. Check continuity between the IPDM E/R harness connector and the rear combination lamp harness connector.

IPDM E/R			Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal		

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

LH	E45	28	B25	1	Yes
RH			B42		

6. Check continuity between the IPDM E/R harness connector and license plate lamp connector.

IPDM E/R			License plate lamp		Continuity
Connector		Terminal	Connector	Terminal	
LH	E45	28	B74	1	Yes
RH			B75		

Are the inspection results normal?

YES >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58, "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace the harness or connector.

4. CHECK PARKING LAMP GROUND CIRCUITS

1. Check continuity between the front combination lamp (parking) harness connector and ground.

(+)			(-)	Continuity
Connector		Terminal		
LH	E21	7	Ground	Yes
RH	E20			

2. Check continuity between the front combination lamp (side marker) harness connector and ground.

(+)			(-)	Continuity
Connector		Terminal		
LH	E21	7	Ground	Yes
RH	E20			

3. Check continuity between the rear combination lamp harness connector and ground.

(+)			(-)	Continuity
Connector		Terminal		
LH	B25	6	Ground	Yes
RH	B42			

4. Check continuity between the license plate lamp harness connector and ground.

(+)			(-)	Continuity
Connector		Terminal		
LH	B74	2	Ground	Yes
RH	B75			

Are the inspection results normal?

YES >> Inspect the parking lamp bulb.

NO >> Repair or replace the harness or connector.

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TURN SIGNAL LAMP CIRCUIT

Description

INFOID:000000009757522

The BCM monitors inputs from the combination switch to determine when to activate the turn signals. The BCM outputs voltage direction to the left and right turn signals during turn signal operation or both during hazard warning operation. The BCM sends a turn signal indicator request to the combination meter via the CAN communication lines.

The BCM performs the fast flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

Component Function Check

INFOID:000000009757523

1. CHECK TURN SIGNAL LAMP

CONSULT

1. Select FLASHER of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp blinks.

LH : Turn signal lamps (LH) ON

RH : Turn signal lamps (RH) ON

OFF : The turn signal lamps OFF

Does the turn signal lamp blink?

- YES >> Turn signal lamp circuit is normal.
NO >> Refer to [EXL-99, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009757524

Regarding Wiring Diagram information, refer to [EXL-58, "Wiring Diagram"](#).

1. CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb to be sure the proper bulb standard is in use and the bulb is not open.

Is the bulb OK?

- YES >> GO TO 2.
NO >> Replace the bulb.


2. CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front or rear combination lamp harness connector or the door mirror harness connector (if equipped with turn signal in mirror) in question.
3. Turn the ignition switch ON.
4. Operate the turn signal switch.
5. While the turn signal is operating, check the voltage between the front combination lamp harness connector and ground.


(+)		(-)	Voltage (Approx.)
Connector	Terminal		

TURN SIGNAL LAMP CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

RH	E20	4	Ground	 <small>PKID0926E</small>
LH	E21			

6. While the turn signal is operating, check the voltage between the rear combination lamp harness connector and ground.

(+)		(-)	Voltage (Approx.)	
Connector	Terminal			
RH	B42	4	Ground	 <small>PKID0926E</small>
LH	B25			

7. While the turn signal is operating, check the voltage between the door mirror harness connector and ground.

(+)		(-)	Voltage (Approx.)	
Connector	Terminal			
RH	D106	10	Ground	 <small>PKID0926E</small>
LH	D7			

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 3.

3. CHECK TURN SIGNAL LAMP CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector in question.
3. Check continuity between the BCM harness connector and the front combination lamp harness connector.

With Intelligent Key

BCM		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	M85	E21	4	Yes
RH		E20		

Without Intelligent Key

BCM		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	B57	E21	4	Yes
RH		E20		

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between the BCM harness connector and the rear combination lamp harness connector.

With Intelligent Key

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	M85	85	B25	Yes
RH		84	B42	

Without Intelligent Key

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	B57	41	B25	Yes
RH		42	B42	

5. Check continuity between the BCM harness connector and the door mirror harness connector in question.

With Intelligent Key

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	M85	85	D7	Yes
RH		84	D106	

Without Intelligent Key

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	B57	41	D7	Yes
RH		42	D106	

Is the inspection results normal?

YES >> GO TO 4.

NO >> Repair or replace the harness or connectors.

4.CHECK TURN SIGNAL LAMP SHORT CIRCUIT

1. Check continuity between the BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M85 (with Intelligent Key)	84	Ground	No
	85		
B57 (without Intelligent Key)	41		
	42		

Are the inspection results normal?

YES >> Replace BCM. Refer to [BCS-73. "Removal and Installation"](#) (with Intelligent Key system) or [BCS-126. "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace the harness or connectors.

5.CHECK TURN SIGNAL LAMP GROUND CIRCUIT

- Turn the ignition switch OFF.
- Check continuity between the front combination lamp harness connector or the rear combination lamp harness connector or the door mirror harness connector in question and ground.

Front combination lamp		(-)	Continuity
Connector	Terminal		

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

LH	E21	7	Ground	Yes
RH	E20			

3. Check continuity between the rear combination lamp harness connector and ground.

Rear combination lamp		Terminal	(-)	Continuity
Connector				
LH	B25	6	Ground	Yes
RH	B42			

4. Check continuity between the door mirror harness connector and ground.

Door mirror		Terminal	(-)	Continuity
Connector				
LH	D7	8	Ground	Yes
RH	D106			

Are the inspection results normal?

- YES >> Replace the malfunctioning lamp.
- NO >> Repair or replace the harness or connectors.

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

OPTICAL SENSOR

Description

INFOID:000000009757525

The optical sensor measures ambient light and transmits the optical sensor signal to the BCM.

Component Function Check

INFOID:000000009757526

1.CHECK OPTICAL SENSOR SIGNAL BY CONSULT

CONSULT

1. Turn the ignition switch ON.
2. Select OPTI SEN of BCM (HEAD LAMP) DATA MONITOR item.
3. Turn the lighting switch to AUTO.

Monitor item	Condition	Voltage
OPTI SEN (DTCT)	When outside of vehicle is bright	3.1V or more *
	When outside of vehicle is dark	0.6V or less

*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the inspection result normal?

- YES >> Optical sensor is normal.
NO >> Refer to [EXL-103, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009757527

Regarding Wiring Diagram information, refer to [EXL-53, "Wiring Diagram"](#).

1.CHECK OPTICAL SENSOR POWER SUPPLY INPUT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor harness connector.
3. Turn the ignition switch ON.
4. Turn the lighting switch to AUTO.
5. Check the voltage between the optical sensor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
M72	1	Ground	5 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2.CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between the optical sensor harness connector and ground.

(+)		(-)	Continuity
Connector	Terminal		
M72	3	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 5.

3.CHECK OPTICAL SENSOR POWER SUPPLY FOR OPEN CIRCUIT

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect the BCM harness connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M72	1	M84	17	Yes

4. Check continuity between optical sensor harness connector and ground.

(+)		(-)	Continuity
Connector	Terminal		
M72	1	Ground	No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-73, "Removal and Installation"](#).
 NO >> Repair or replace the harness or connectors.

4. CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Disconnect optical sensor connector and BCM connector.
2. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M72	2	M84	14	Yes

3. Check continuity between optical sensor harness connector and ground.

Connector	Terminal	(-)	Continuity
M72	2	Ground	No

Is the inspection result normal?

- YES >> Replace the optical sensor. Refer to [EXL-130, "Removal and Installation"](#).
 NO >> Repair or replace harness or connectors.

5. CHECK OPTICAL SENSOR GROUND FOR OPEN CIRCUIT

1. Disconnect the BCM harness connector.
2. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M72	3	M84	18	Yes

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-73, "Removal and Installation"](#).
 NO >> Repair or replace harness or connector.

HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

HAZARD SWITCH

Component Function Check

INFOID:000000009757528

1. CHECK HAZARD SWITCH SIGNAL BY CONSULT

CONSULT DATA MONITOR

1. Turn ignition switch ON.
2. Select HAZARD SW of BCM (FLASHER) Data Monitor item.
3. While operating the hazard switch, check the monitor status.

Monitor item	Condition	Monitor status
HAZARD SW	Hazard switch ON	On
	Hazard switch OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.
 NO >> Refer to [EXL-105, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009757529

Regarding Wiring Diagram information, refer to [EXL-58, "Wiring Diagram"](#).

1. CHECK HAZARD SWITCH SIGNAL INPUT

1. Turn ignition switch OFF.
2. Disconnect hazard switch connector.
3. Turn ignition switch ON.
4. Check voltage between hazard switch harness connector and ground.

(+)		(-)	Voltage (Approx.)
Hazard switch			
Connector	Terminal		
M102	2	Ground	

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 2.

2. CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between hazard harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M102	2	M85 (with Intelligent Key) M21 (without Intelligent Key)	29	Yes

Is the inspection result normal?

- YES >> GO TO 3.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness or connector.

3. CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M102	2		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-73, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-126, "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace harness or connector.

4. CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M102	3		Yes

Is the inspection result normal?

YES >> Replace hazard switch. Refer to [EXL-129, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

EXTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000009757530

CAUTION:

Perform the self-diagnosis with **CONSULT** before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp does not switch to the high beam.	One side	<ul style="list-style-type: none"> • Bulb • Fuse • Harness between IPDM E/R and the front combination lamp • IPDM E/R 	Headlamp (HI) circuit Refer to EXL-88 .
	Both sides	—	Symptom diagnosis "BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM" Refer to EXL-110 .
High beam indicator lamp is not turned ON. (Headlamp switches to the high beam.)		<ul style="list-style-type: none"> • Combination meter • BCM 	<ul style="list-style-type: none"> • Combination meter. Data monitor "HI-BEAM IND" • BCM (HEAD LAMP) Active test "HEADLAMP"
Headlamp does not switch to the low beam.	One side	<ul style="list-style-type: none"> • Bulb • Fuse • Harness between IPDM E/R and the front combination lamp • IPDM E/R 	Headlamp (HI) circuit Refer to EXL-88 .
	Both sides	<ul style="list-style-type: none"> • Combination switch (lighting and turn signal switch) • Harness between the combination switch (lighting and turn signal switch) and BCM • BCM 	Combination switch (lighting and turn signal switch) Refer to EXL-12 (with Intelligent Key system) or EXL-15 (without Intelligent Key system).
		High beam request signal	<ul style="list-style-type: none"> • BCM • IPDM E/R
Headlamp does not turn ON.	One side	<ul style="list-style-type: none"> • Fuse • Bulb • Harness between IPDM E/R and the front combination lamp • Harness between the front combination lamp and ground • IPDM E/R 	Headlamp (LO) circuit Refer to EXL-90
	Both sides	—	Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-112 .
Headlamp does not turn OFF.	When the ignition switch is turned ON	<ul style="list-style-type: none"> • BCM • Combination switch (lighting and turn signal switch) 	Combination switch (lighting and turn signal switch) Refer to EXL-12 (with Intelligent Key system) or EXL-15 (without Intelligent Key system).
	The ignition switch is turned OFF (After activating the battery saver).	IPDM E/R	—

A
B
C
D
E
F
G
H
I
J
K

EXL

M
N
O
P

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

Symptom	Possible cause	Inspection item	
Headlamp is not turned ON/OFF with the lighting switch AUTO.	<ul style="list-style-type: none"> • Combination switch (lighting and turn signal switch) • Harness between the combination switch (lighting and turn signal switch) and BCM • BCM • IPDM E/R 	Combination switch (lighting and turn signal switch) Refer to EXL-12 (with Intelligent Key system) or EXL-15 (without Intelligent Key system).	
	<ul style="list-style-type: none"> • Optical sensor • Harness between the optical sensor and BCM • BCM 	Optical sensor Refer to EXL-103 .	
Daytime light system does not activate.	—	Symptom diagnosis "DAYTIME LIGHT SYSTEM INOPERATIVE" Refer to EXL-111 .	
Front fog lamp is not turned ON.	One side <ul style="list-style-type: none"> • Front fog lamp bulb • Harness between IPDM E/R and the front fog lamp • Harness between the front fog lamp and ground • IPDM E/R 	Front fog lamp circuit Refer to EXL-94 .	
	Both side	—	Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-114 .
Parking lamp is not turned ON.	One side <ul style="list-style-type: none"> • Fuse • Parking lamp bulb • Harness between IPDM E/R and the front/rear combination lamp • Harness between the front/rear combination lamp and ground • IPDM E/R 	Parking lamp circuit Refer to EXL-96 .	
	Both sides	—	Symptom diagnosis "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-113 .
Turn signal lamp does not blink.	Indicator lamp is normal. (The applicable side performs the high flasher activation).	<ul style="list-style-type: none"> • Harness between BCM and each turn signal lamp • Turn signal lamp bulb • Door mirror (if equipped with turn signals in the door mirrors) 	Turn signal lamp circuit Refer to EXL-99 .
Turn signal indicator lamp does not blink.	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> • Turn signal indicator lamp signal • Combination meter • BCM 	<ul style="list-style-type: none"> • Combination meter. • Data monitor "TURN IND" • BCM (FLASHER) • Active test "FLASHER"
	Both sides (Does blink when activating the hazard warning lamp with the ignition switch OFF)	<ul style="list-style-type: none"> • The combination meter power supply and the ground circuit • Combination meter 	Combination meter Power supply and the ground circuit Refer to MWI-52 .
<ul style="list-style-type: none"> • Hazard warning lamp does not activate. • Hazard warning lamp continues activating. (Turn signal is normal) 	<ul style="list-style-type: none"> • Hazard switch • Harness between the hazard switch and BCM • BCM 	Hazard switch Refer to EXL-105 .	

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:000000009757531

AUTO LIGHT SYSTEM

The auto light system may not turn the headlamp ON/OFF immediately after passing a dark area or a bright area (short tunnel, sky bridge, shadowed area etc.). This is normal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

< SYMPTOM DIAGNOSIS >

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

Description

INFOID:000000009757532

The headlamps (both sides) do not switch to high beam when the lighting switch is in the HI or PASS setting.

Diagnosis Procedure

INFOID:000000009757533

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-72. "Symptom Table"](#) (with Intelligent Key system) or [BCS-125. "Symptom Table"](#) (without Intelligent Key system).

Is the inspection results normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select HL HI REQ of IPDM E/R DATA MONITOR item.
2. While operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2nd)	HI or PASS	ON
		Except for HI or PASS	OFF

Is the inspection results normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-73. "Removal and Installation"](#) (with Intelligent Key system) or [BCS-126. "Removal and Installation"](#) (without Intelligent Key system).

3.HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-88. "Diagnosis Procedure"](#).

Is the inspection results normal?

YES >> Replace IPDM E/R. Refer to [PCS-30. "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58. "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace the malfunctioning part.

DAYTIME LIGHT SYSTEM INOPERATIVE

< SYMPTOM DIAGNOSIS >

DAYTIME LIGHT SYSTEM INOPERATIVE

Description

INFOID:000000009757534

The daytime light system is inoperative even though the combination switch (lighting and turn signal switch) and parking brake switch are in the normal setting, also whenever engine is operating.

Diagnosis Procedure

INFOID:000000009757535

1. CHECK DAYTIME LIGHT OPERATION

1. Perform BCM(HEADLAMP) DAYTIME RUNNING LIGHT active test. Refer to [EXL-19. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#) (with Intelligent Key system) or [EXL-22. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#) (without Intelligent Key system).
2. Check that the daytime lights turn on.

Is the inspection results normal?

- YES >> Replace BCM. Refer to [BCS-73. "Removal and Installation"](#) (with Intelligent Key system) or [BCS-126. "Removal and Installation"](#) (without Intelligent Key system).
- NO >> GO TO 2.

2. CHECK DAYTIME LIGHT RELAY FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown.

Unit	Fuse No.	Capacity
Daytime light	29	10 A

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.
- NO >> GO TO 3.

3. CHECK DAYTIME LIGHT BULBS

Check the daytime light bulbs are not open.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace the bulbs.

4. PERFORM DAYTIME LIGHT CIRCUIT INSPECTION

Check the daytime light circuit. Refer to [EXL-92. "Diagnosis Procedure"](#).

Is the inspection results normal?

- YES >> Replace IPDM E/R. Refer to [PCS-30. "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58. "Removal and Installation"](#) (without Intelligent Key system).
- NO >> Repair or replace the malfunctioning part.

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:000000009757536

The headlamps (both sides) do not turn ON in any lighting switch setting.

Diagnosis Procedure

INFOID:000000009757537

1. CHECK COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH)

Check the combination switch (lighting and turn signal switch). Refer to [BCS-72. "Symptom Table"](#) (with Intelligent Key system) or [BCS-125. "Symptom Table"](#) (without Intelligent Key system).

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Repair or replace the malfunctioning part.

2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select HL LO REQ of IPDM E/R DATA MONITOR item.
2. While operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL LO REQ	Lighting switch	2nd	ON
		OFF	OFF

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Replace BCM. Refer to [BCS-73. "Removal and Installation"](#) (with Intelligent Key system) or [BCS-126. "Removal and Installation"](#) (without Intelligent Key system).

3. HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-90. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-30. "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58. "Removal and Installation"](#) (without Intelligent Key system).
- NO >> Repair or replace the malfunctioning part.

PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:000000009757538

The parking, license plate and tail lamps do not turn ON in with any lighting switch setting.

Diagnosis Procedure

INFOID:000000009757539

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-72. "Symptom Table"](#) (with Intelligent Key system) or [BCS-125. "Symptom Table"](#) (without Intelligent Key system).

Is the inspection results normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select TAIL & CLR REQ of IPDM E/R DATA MONITOR item.
2. While operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL & CLR REQ	Lighting switch	1st	ON
		OFF	OFF

Is the inspection results normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-73. "Removal and Installation"](#) (with Intelligent Key system) or [BCS-126. "Removal and Installation"](#) (without Intelligent Key system).

3.PARK LAMP CIRCUIT INSPECTION

Check the parking lamp circuit. Refer to [EXL-96. "Diagnosis Procedure"](#).

Is the inspection results normal?

YES >> Replace IPDM E/R. Refer to [PCS-30. "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58. "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

INFOID:000000009757540

The front fog lamps do not turn ON in any setting.

Diagnosis Procedure

INFOID:000000009757541

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-72. "Symptom Table"](#) (with Intelligent Key system) or [BCS-125. "Symptom Table"](#) (without Intelligent Key system).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select FR FOG REQ of IPDM E/R DATA MONITOR item.
2. While operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR FOG REQ	Front fog lamp switch (Lighting switch 3rd)	ON	ON
		OFF	OFF

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-73. "Removal and Installation"](#) (with Intelligent Key system) or [BCS-126. "Removal and Installation"](#) (without Intelligent Key system).

3.FRONT FOG LAMP CIRCUIT INSPECTION

Check the front fog lamp circuit. Refer to [EXL-94. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-30. "Removal and Installation"](#) (with Intelligent Key system) or [PCS-58. "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace the malfunctioning part.

HEADLAMP

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

HEADLAMP

Aiming Adjustment

INFOID:000000009757542

PREPARATION BEFORE ADJUSTING

Before performing aiming adjustment, check the following:

- Ensure all tires are inflated to correct pressure.
- Place vehicle and screen on level surface.
- Ensure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position).
- Coolant and engine oil filled to correct level, and fuel tank full.
- Remove cargo and/or luggage to maintain an unloaded vehicle condition.
- Confirm spare tire, jack and tools are properly stowed.
- Carefully wipe off any dirt from headlamp lens.


CAUTION:

Do not use organic solvent (thinner, gasoline etc.)

- Place a driver or equivalent weight of 68.5 kg (150 lb) on the driver seat.
- By hand, bounce the front and rear of the vehicle to settle the suspension and eliminate any static load.
- Place the front tires in the straight ahead position.
- Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.

NOTE:

- For headlamp aiming details, refer to regulations in your area.
- By regulation, no means for horizontal aim adjustment is provided from the factory; only vertical aim is adjustable.
- Use adjusting screw to perform aiming adjustment.
- Perform headlamp aiming if:
 - The vehicle front body has been repaired.
 - The front combination lamp has been removed or replaced.
 - Any outfitting has been installed.
 - The vehicle's standard load condition has been substantially increased.



1. Front combination lamp

A. Suitable tool (for aiming adjustment) B. Adjusting screw

Aiming Adjustment procedure

1. Position the screen.

NOTE:

- Stop the vehicle facing the screen.
- Place the screen on a plain road vertically.

2. Face the screen with the vehicle. Maintain 10 m (33 ft) between the headlamp bulb center and the screen.
3. Start the engine. Turn the headlamp (LO) ON.

HEADLAMP


< PERIODIC MAINTENANCE >

CAUTION:

Do not cover the lens surface with tape, etc. The lens is made of resin.

NOTE:

- Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.
- For horizontal aiming, adjust headlamp until beam pattern is at horizontal center point.



- | | | |
|---------------------|--|--|
| A. Right | B. Left | C. Center of headlamp bulb (H-V point) |
| D. Cutoff line | E. Screen | F. Aim evaluation segment |
| G. Step | H. Horizontal center line of head lamp | J. 30 mm (1.18 in) |
| K. 4 mm (0.16 in) | L. 10 m (33 ft) | M. 480 mm (18.90 in) |
| N. 160 mm (6.30 in) | V. Vertical center line of headlamp | |

- Basic illuminating area for adjustment should be within the range shown on the aiming chart. Adjust headlamps accordingly.

FRONT FOG LAMP

< PERIODIC MAINTENANCE >

FRONT FOG LAMP

Aiming Adjustment

INFOID:000000009757543

PREPARATION BEFORE ADJUSTING

The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment procedure, check the following:

- Ensure all tires are inflated to correct pressure.
- Place vehicle and screen on level surface.
- Ensure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position).
- Coolant and engine oil filled to correct level, and fuel tank full.
- Remove cargo and/or luggage to maintain an unloaded vehicle condition.
- Confirm spare tire, jack and tools are properly stowed.
- Carefully wipe off any dirt from headlamp lens.

CAUTION:

Do not use organic solvent (thinner, gasoline etc.)

- Place a driver or equivalent weight of 68.5 kg (150 lb) on the driver seat.
- By hand, bounce the front and rear of the vehicle to settle the suspension and eliminate any static load.
- Place the front tires in the straight ahead position.
- Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.

NOTE:

- For headlamp aiming details, refer to regulations in your area.
- By regulation, no means for horizontal aim adjustment is provided from the factory; only vertical aim is adjustable.
- Use adjusting screw to perform aiming adjustment.
- Perform headlamp aiming if:
 - The vehicle front body has been repaired.
 - The front combination lamp has been removed or replaced.
 - Any outfitting has been installed.
 - The vehicle's standard load condition has been substantially increased.

Aiming Adjustment Procedure

1. Place the screen.

NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 7.62 m (25.0 ft) between the front fog lamp center and the screen.

3. Start the engine. Turn the front fog lamp ON.


NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

CAUTION:

Do not cover the lens surface with tape etc. The lens is made of resin.

4. Adjust aiming in the vertical direction by turning the adjusting screw (A).




FRONT FOG LAMP

< PERIODIC MAINTENANCE >

5. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 100 mm (4 in).

- A : Cutoff line
- B : High illuminance area
- H : Horizontal center line of front fog lamp
- V : Vertical center line of front fog lamp
- X : Cutoff line height



FRONT COMBINATION LAMP


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

FRONT COMBINATION LAMP

Exploded View

INFOID:000000009757544



- | | | |
|----------------------------------|--|---|
| 1. Large cover (not serviceable) | 2. Small cover (not serviceable) | 3. Front combination lamp |
| 4. Halogen lamp bulb (high beam) | 5. Turn signal lamp bulb | 6. Turn signal lamp bulb socket |
| 7. LED harness connector | 8. Halogen lamp bulb (high beam) harness connector | 9. Halogen lamp bulb (low beam) harness connector |
| 10. Halogen lamp bulb (low beam) | 11. Side marker lamp bulb socket | 12. Side marker lamp bulb |

Removal and Installation

INFOID:000000009757545


REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-17. "Removal and Installation"](#).

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

2. Remove the front combination lamp bolts (A).
3. Pull the front combination lamp (1) forward.
4. Disconnect the harness connectors from the front combination lamp (1).



INSTALLATION

Installation is in the reverse order of removal.

After installation, perform headlamp aiming adjustment. Refer to [EXL-115, "Aiming Adjustment"](#).

Bulb Replacement

INFOID:000000009757546

WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

HEADLAMP HIGH BEAM

Removal

1. Remove the core support cover. Refer to [EXT-23, "Exploded View"](#).
2. Rotate the plastic cover counterclockwise and remove.
3. Rotate the headlamp high beam lamp counterclockwise and remove.
4. Disconnect the harness connector from the headlamp high beam lamp.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the cover securely to ensure watertightness.

HEADLAMP LOW BEAM

Removal

1. Remove the core support cover. Refer to [EXT-23, "Exploded View"](#).
2. Rotate the plastic cover counterclockwise and remove.
3. Rotate the headlamp low beam sockets counterclockwise and remove.
4. Disconnect the harness connector from the headlamp low beam lamp.

Installation

Installation is in the reverse order of removal.

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

CAUTION:

After installing, be sure to install the cover securely to ensure watertightness.

A

SIDE MARKER LAMP

Removal

1. Remove the core support cover. Refer to [EXT-23. "Exploded View"](#).
2. Rotate the side marker lamp bulb socket counterclockwise and remove.
3. Remove the side marker bulb from the side marker bulb socket.

B

C

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb socket securely to ensure watertightness.

D

TURN SIGNAL LAMP

E

Removal

1. Remove the core support cover. Refer to [EXT-23. "Exploded View"](#).
2. Rotate the turn signal lamp bulb socket counterclockwise and remove.
3. Remove the turn signal bulb from the turn signal bulb socket.

F

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb socket securely to ensure watertightness.

G

H

Park Lamp

The park lamp LED bulb is integrated into the front combination lamp and is serviced as an assembly. Refer to [EXL-119. "Removal and Installation"](#).

I

J

K

EXL

M

N

O

P

FRONT FOG LAMP

< REMOVAL AND INSTALLATION >

FRONT FOG LAMP

Removal and Installation

INFOID:000000009757547

FOG LAMP

Removal

1. Position the fender protector aside. Refer to [EXT-28, "FENDER PROTECTOR : Removal and Installation - Front Fender Protector"](#).
2. Disconnect the harness connector from the front fog lamp.
3. Remove the screws and the front fog lamp.

Installation

Installation is in the reverse order of removal.

NOTE:

After installing, perform fog lamp aiming adjustment. Refer to [EXL-117, "Aiming Adjustment"](#).

FRONT FOG LAMP BULB

Removal

WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

1. Position the front fender protector aside. Refer to [EXT-28, "FENDER PROTECTOR : Removal and Installation - Front Fender Protector"](#).
2. Disconnect the harness connector from the front fog lamp bulb.
3. Rotate the front fog lamp bulb socket counterclockwise and remove.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb socket securely to ensure watertightness.

DOOR MIRROR TURN SIGNAL LAMP

< REMOVAL AND INSTALLATION >

DOOR MIRROR TURN SIGNAL LAMP

Removal and Installation

INFOID:000000009757548

The door mirror side turn signal lamp is integrated into the door mirror assembly and is serviced as an assembly. Refer to [MIR-18. "Exploded View"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- EXL
- M
- N
- O
- P

HIGH-MOUNTED STOP LAMP

< REMOVAL AND INSTALLATION >

HIGH-MOUNTED STOP LAMP

Removal and Installation

INFOID:000000009757549

HIGH-MOUNTED STOP LAMP - WITH REAR SPOILER

Removal

1. Remove the rear air spoiler. Refer to [EXT-46, "Removal and Installation"](#).
2. Remove the screws and the high-mount stop lamp from the rear air spoiler.


Installation

Installation is in the reverse order of removal.

HIGH-MOUNTED STOP LAMP - WITHOUT REAR SPOILER

Removal

1. Slide high-mounted stop lamp (1) rearward on parcel shelf to provide clearance for front tabs (A).
2. Lift front of lamp assembly up and pull forward to provide clearance for rear tabs (B).



3. Disconnect the harness connector from the high-mounted stop lamp and remove.

Installation

Installation is in the reverse order of removal.

Bulb Replacement

INFOID:000000009757550

HIGH-MOUNTED STOP LAMP - WITH REAR SPOILER

The high-mounted stop lamp LED bulb is integrated into the high-mounted stop lamp and is serviced as an assembly. Refer to [EXL-124, "Removal and Installation"](#).

HIGH-MOUNTED STOP LAMP - WITHOUT REAR SPOILER

The high-mounted stop lamp LED bulb is integrated into the high-mounted stop lamp and is serviced as an assembly. Refer to [EXL-124, "Removal and Installation"](#).

LICENSE PLATE LAMP

< REMOVAL AND INSTALLATION >


LICENSE PLATE LAMP


Removal and Installation

INFOID:000000009757551

REMOVAL

1. Remove the license lamp finisher. Refer to [EXT-44, "Removal and Installation"](#).
2. Disconnect the harness connector (A) from the license plate lamp (1).
3. Release pawl and remove.

 Pawl



INSTALLATION

Installation is in the reverse order of removal.

Bulb Replacement

INFOID:000000009757552

WARNING:


Do not touch bulb while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

REMOVAL

1. Position trunk lid finisher aside. Refer to [INT-45, "Removal and Installation"](#).
2. Rotate license plate lamp bulb socket (2) counterclockwise and remove from license plate lamp (1).
3. Remove license plate lamp bulb (A) from license plate lamp bulb socket (2).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

REAR COMBINATION LAMP

Exploded View

INFOID:000000009757553




- | | | |
|-------------------------------|--|---------------------------------------|
| 1. Rear combination lamp | 2. Rear turn signal lamp bulb | 3. Rear turn signal lamp socket |
| 4. LED lamp harness connector | 5. Rear combination lamp harness connector | 6. Back-up lamp bulb socket connector |
| 7. Back-up lamp bulb | | |

Removal and Installation

INFOID:000000009757554

Removal

1. Partially remove trunk side finisher. Refer to [INT-43, "TRUNK SIDE FINISHER : Removal and Installation"](#).
2. Remove the rear combination lamp nuts (B).
3. Disconnect the harness connector (A) from the rear combination lamp.



4. Pull the rear combination lamp rearward and remove.

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

Installation

Installation is the reverse order of removal.

Bulb Replacement

INFOID:000000009757555

WARNING:

Do not touch bulb while it is lit or right after being turned off. Burning may result.

CAUTION:

- **Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.**
- **Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.**

REAR TURN SIGNAL LAMP BULB

Removal

1. Remove the rear combination lamp. Refer to [EXL-126. "Removal and Installation"](#).
2. Rotate the rear turn signal lamp bulb socket counterclockwise and remove.
3. Remove the rear turn signal lamp bulb from bulb socket.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb socket securely to ensure watertightness.

STOP/TAIL LAMP

The stop/tail lamp is integrated into the rear combination lamp and is serviced as an assembly. Refer to [EXL-126. "Removal and Installation"](#).

BACK-UP LAMP BULB

Removal

1. Remove the rear combination lamp. Refer to [EXL-126. "Removal and Installation"](#).
2. Rotate the back-up lamp bulb socket counterclockwise and remove.
3. Remove the back-up lamp bulb from bulb socket.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb socket securely to ensure watertightness.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


COMBINATION SWITCH

< REMOVAL AND INSTALLATION >

COMBINATION SWITCH

Exploded View

INFOID:000000009757556



1. Combination switch

2. Combination switch harness connector

← Front

NOTE:

Shown with the steering wheel removed for clarity only.

Removal and Installation

INFOID:000000009757557

REMOVAL

CAUTION:

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
 - Do not use air or electric tools when removing or installing the combination switch.
1. Disconnect both the negative and positive battery terminals, then wait at least three minutes. Refer to [PG-50, "Removal and Installation \(Battery\)"](#).
 2. Remove the steering column covers. Refer to [IP-16, "Removal and Installation"](#).
 3. Rotate steering wheel clockwise to access first combination switch bolt and remove.
 4. Rotate steering wheel counter-clockwise to access second combination switch bolt and remove.
 5. Disconnect the harness connector from the combination switch and remove.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After the work is completed, make sure no system malfunction is detected by air bag warning lamp.
- In case a malfunction is detected by the air bag warning lamp, reset with the self-diagnosis function and delete the memory with CONSULT.
- If a malfunction is still detected after the above operation, perform self-diagnosis to repair malfunctions. Refer to [SRC-41, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

HAZARD SWITCH

< REMOVAL AND INSTALLATION >


HAZARD SWITCH

Removal and Installation

INFOID:000000009757558

REMOVAL

1. Remove cluster lid C (1). Refer to [IP-20. "Removal and Installation - Cluster Lid C"](#).
2. Release pawls at (➡) and remove hazard switch (2).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

OPTICAL SENSOR

< REMOVAL AND INSTALLATION >

OPTICAL SENSOR

Removal and Installation

INFOID:000000009757559

REMOVAL

1. Remove the defroster grille (LH) using a suitable tool.
2. Disconnect the harness connector from the optical sensor.
3. Release the pawls and remove the optical sensor.

INSTALLATION

Installation is in the reverse order of removal.

FRONT COMBINATION LAMP


< UNIT DISASSEMBLY AND ASSEMBLY >

UNIT DISASSEMBLY AND ASSEMBLY

FRONT COMBINATION LAMP

Exploded View

INFOID:000000009757560



- | | | |
|----------------------------------|--|---|
| 1. Large cover (not serviceable) | 2. Small cover (not serviceable) | 3. Front combination lamp |
| 4. Halogen lamp bulb (high beam) | 5. Turn signal lamp bulb | 6. Turn signal lamp bulb socket |
| 7. LED harness connector | 8. Halogen lamp bulb (high beam) harness connector | 9. Halogen lamp bulb (low beam) harness connector |
| 10. Halogen lamp bulb (low beam) | 11. Side marker lamp bulb socket | 12. Side marker lamp bulb |

Disassembly and Assembly

INFOID:000000009757561

DISSASSEMBLY

WARNING:

Do not touch bulb while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

1. Remove front combination lamp. Refer to [EXL-119. "Removal and Installation"](#).
2. Rotate the covers counterclockwise and remove.
3. Rotate the halogen lamp bulb (low beam) counterclockwise and remove.
4. Disconnect the harness connector from the halogen lamp bulb (low beam) and remove.
5. Rotate the halogen lamp bulb (high beam) counterclockwise and remove.
6. Disconnect the harness connector from the halogen lamp bulb (high beam) and remove.
7. Rotate the side marker bulb socket counterclockwise and remove.
8. Remove the side marker bulb from the side marker bulb socket.

A
B
C
D
E
F
G
H
I
J

K

EXL

M

N

O

P

FRONT COMBINATION LAMP

< UNIT DISASSEMBLY AND ASSEMBLY >

9. Rotate the turn signal bulb socket counterclockwise and remove.
10. Remove the turn signal bulb from the turn signal bulb socket.
11. Disconnect the harness connector from the LED circuit board and remove the harness.

ASSEMBLY

Assembly is in the reverse order of disassembly.

CAUTION:

After installing, be sure to install the bulb sockets securely to ensure watertightness.


REAR COMBINATION LAMP

< UNIT DISASSEMBLY AND ASSEMBLY >

REAR COMBINATION LAMP

Exploded View

INFOID:000000009757562



- | | | |
|-------------------------------|----------------------------------|---------------------------------------|
| 1. Rear combination lamp | 2. Rear turn signal lamp bulb | 3. Rear turn signal lamp socket |
| 4. LED lamp harness connector | 5. Rear combination lamp harness | 6. Back-up lamp bulb socket connector |
| 7. Back-up lamp bulb | | |

Disassembly and Assembly

INFOID:000000009757563

DISASSEMBLY

WARNING:

Do not touch bulb while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

1. Remove rear combination lamp. Refer to [EXL-126, "Removal and Installation"](#).
2. Rotate rear turn signal lamp bulb socket counterclockwise to remove from rear combination lamp.
3. Remove the rear turn signal lamp bulb from bulb socket.
4. Rotate back-up lamp bulb socket counterclockwise to remove from rear combination lamp.
5. Remove the back-up lamp bulb from bulb socket.
6. Disconnect the harness connector from the LED lamp.

ASSEMBLY

A
B
C
D
E
F
G
H
I
J
K
EXL

REAR COMBINATION LAMP

< UNIT DISASSEMBLY AND ASSEMBLY >

Assembly is in the reverse order of disassembly.

CAUTION:

After installing, be sure to install the bulb sockets securely to ensure watertightness.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:000000009757564

Item		Wattage (W)*
Front combination lamp	Low beam	55
	High beam	65
	Side marker lamp	3.8
	Turn signal lamp	28
	Park	LED
Door mirror side turn signal lamp (if equipped)		LED
Rear combination lamp	Stop/Tail lamp	LED
	Turn signal lamp (amber)	21
	Back-up lamp	16
Fog lamp (if equipped)		55
License plate lamp		5
High-mounted stop lamp	Without rear spoiler	LED
	With rear spoiler	LED

*: Always check with the Parts Department for the latest parts information.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P