

SECTION PWO

POWER OUTLET

CONTENTS

POWER SOCKET	
PRECAUTION	3
POWER SOCKET	3
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	3
Precaution for Work	3
PREPARATION	4
PREPARATION	4
Special Service Tool	4
WIRING DIAGRAM	5
POWER SOCKET	5
Wiring Diagram	5
REMOVAL AND INSTALLATION	9
POWER SOCKET	9
Removal and Installation	9
AC 120 V OUTLET	
PRECAUTION	11
PRECAUTIONS	11
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	11
Precaution for Work	11
PREPARATION	12
PREPARATION	12
Special Service Tool	12
SYSTEM DESCRIPTION	13
COMPONENT PARTS	13
Component Parts Location	13
Component Description	13
Inverter Unit	14
AC 120V Outlet Main Switch	14
AC 120V Outlet	14
SYSTEM	15
System Diagram	15
System Description	15
Fail-safe	15
ECU DIAGNOSIS INFORMATION	17
INVERTER UNIT	17
Reference Value	17
Fail-safe	18
WIRING DIAGRAM	20
INVERTER UNIT	20
Wiring Diagram	20
BASIC INSPECTION	27
DIAGNOSIS AND REPAIR WORK FLOW	27
Work Flow	27
DTC/CIRCUIT DIAGNOSIS	29
POWER SUPPLY AND GROUND CIRCUIT	29
Diagnosis Procedure	29
Component Inspection (Inverter Relay)	30
AC 120 V OUTLET MAIN SWITCH POWER SUPPLY CIRCUIT	32
Diagnosis Procedure	32
AC 120 V OUTLET MAIN SWITCH INPUT SIGNAL CIRCUIT	33
Diagnosis Procedure	33
Component Inspection (AC 120V Outlet Main Switch)	33
AC 120 V POWER OUTPUT CIRCUIT	35

Diagnosis Procedure	35	REMOVAL AND INSTALLATION	43
AC 120 V OUTLET MAIN SWITCH INDICA-		INVERTER UNIT	43
TOR CIRCUIT	38	Removal and Installation	43
Diagnosis Procedure (150W Indicator)	38		
Diagnosis Procedure (400W Indicator)	38		
Component Inspection (AC 120V Outlet Main		AC 120V OUTLET MAIN SW	44
Switch Indicators)	39	Removal and Installation	44
SYMPTOM DIAGNOSIS	40		
NO OUTPUT FROM AC 120 V OUTLET	40	AC 120 V OUTLET	45
Diagnosis Procedure	40	Removal and Installation - Front	45
AC 120 V OUTLET MAIN SWITCH INDICA-		Removal and Installation - Rear	45
TOR DOES NOT TURN ON	41		
Diagnosis Procedure	41	SERVICE DATA AND SPECIFICATIONS	
NORMAL OPERATING CONDITION	42	(SDS)	46
Description	42	SERVICE DATA AND SPECIFICATIONS	
		(SDS)	46
		AC 120V Power Outlet	46

< PRECAUTION >

PRECAUTION

POWER SOCKET

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000007946415

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:0000000008945752

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

PWO

N

O

P

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:0000000007946417

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.)	Description
— (J-42059) Power socket removal tool	Removing power sockets



POWER SOCKET

< WIRING DIAGRAM >

[POWER SOCKET]


WIRING DIAGRAM POWER SOCKET

Wiring Diagram

INFOID:000000007946418

: WITH FRONT CENTER CONSOLE
 : WITH FRONT BENCH SEAT

POWER SOCKET



ABMW A1749GB

POWER SOCKET

< WIRING DIAGRAM >

[POWER SOCKET]

POWER SOCKET CONNECTORS

Connector No.	M26
Connector Name	IGNITION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
B	G	-
ACC	V	-



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Connector No.	M53
Connector Name	FRONT POWER SOCKET LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-
3	-	-



Terminal No.	Color of Wire	Signal Name
3G	V	-
8G	G	-
9G	G	-
10G	G	-



ABMIA4044GP

POWER SOCKET


< WIRING DIAGRAM >

[POWER SOCKET]

Connector No.	M56
Connector Name	FRONT POWER SOCKET
Connector Color	WHITE



Connector No.	M56
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	L/W	-
14	B	-
16	-	-

Terminal No.	Color of Wire	Signal Name
7	G/W	-
14	B	-
16	-	-

Connector No.	M54
Connector Name	FRONT POWER SOCKET
Connector Color	RH BLACK



Terminal No.	Color of Wire	Signal Name
1	G/W	-
2	B	-
3	-	-

Connector No.	M78
Connector Name	FRONT POWER SOCKET
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	B	-



Connector No.	M207
Connector Name	CONSOLE POWER SOCKET
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	B	-
3	-	-

Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	B	-



Connector No.	M201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	B	-



Connector No.	E55
Connector Name	ACCESSORY RELAY-2
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	B	-



Connector No.	PWO
Connector Name	—
Connector Color	—



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	B	-




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
PWO

POWER SOCKET

< WIRING DIAGRAM >

[POWER SOCKET]



ABMIA4046GB

REMOVAL AND INSTALLATION

POWER SOCKET

Removal and Installation

INFOID:000000007946419

FRONT POWER SOCKET (RH/LH), FRONT POWER SOCKET (CENTER ARMREST) OR CONSOLE POWER SOCKET.

NOTE:


If unable to use the tool because of power socket location or access to the harness connector, then further removal of interior components may be required. Refer to [IP-14, "Exploded View"](#) (Front Power Socket) to remove cluster lid C and/or [IP-20, "Removal and Installation"](#) [Console Power Socket or Front Power Socket (Center Armrest) if equipped] to remove the center console.

Removal


1. Remove the fuse for the power socket.
2. Insert one end of the Tool (A) into one of the square holes inside the power socket.

Tool number: — (J-42059)

3. Lift up the handle of the Tool until the other end of the Tool is inside the socket and snaps into the other square hole in the power socket.
4. Pull the power socket straight out with the Tool.



5. Disconnect power socket connector.
6. Remove ring from power socket finisher while pressing pawls.




Installation

Installation is in the reverse order of removal.

NOTE:

Make sure to align the tab with the square notched area during installation.



REAR CARGO POWER SOCKET (CARGO BED)

Removal

1. Remove the fuse for the power socket.
2. Remove the rivets attaching the rear cargo power socket finisher to the cargo bed.
3. Disconnect the harness connector from the power socket and remove.

POWER SOCKET

< REMOVAL AND INSTALLATION >

[POWER SOCKET]

Installation

Installation is in the reverse order of removal.

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000008945759

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:0000000008934198

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000008934199

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.)	Description
— (J-46534) Trim tool set	 AWJIA04832Z

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[AC 120 V OUTLET]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000008940722



A
B
C
D
E
F
G
H
I
J
K
L

PWO

1. IPDM E/R
2. Inverter relay (view with relay box cover removed)
3. AC 120V outlet main switch
4. Center console
5. AC 120V outlet front
6. AC 120V outlet rear
7. Inverter unit (behind left rear seat back) (view with rear panel removed)

Component Description

INFOID:0000000008940723

N
O
P

Component	Reference
Inverter unit	PWO-14, "Inverter Unit"
AC 120V outlet main switch	PWO-14, "AC 120V Outlet Main Switch"
AC 120V outlet	PWO-14, "AC 120V Outlet"

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[AC 120 V OUTLET]

Inverter Unit

INFOID:0000000008940724

The inverter unit converts 12V DC to 120V AC.

AC 120V Outlet Main Switch

INFOID:0000000008940725

The AC outlet main switch allows operation of the inverter unit in 150W AC 120V and 400W AC 120V modes.

AC 120V Outlet


INFOID:0000000008940726

The AC 120V outlet front and AC 120V outlet rear allow use of AC components up to 400W.

< SYSTEM DESCRIPTION >

SYSTEM**System Diagram**

INFOID:0000000008940727



AWMIA1207GB

System Description

INFOID:0000000008940728

- When turning ON the AC 120V outlet main switch with the ignition switch ON, the 150W indicator turns ON and the inverter unit is activated allowing the use of devices up to 150W.
- When the vehicle is placed in P (Park) with the ignition switch ON, turning ON the AC 120V outlet main switch turns ON the 400W indicator and the inverter unit is activated, allowing the use of devices up to 400W.
- The inverter unit converts 12V DC to 120V AC and outputs the converted voltage to the AC 120V outlet front and AC 120V outlet rear two seconds after the AC 120V outlet main switch is turned ON.

Fail-safe

INFOID:0000000008940729

When a malfunction listed below occurs, the inverter unit turns OFF the AC 120V outlet main switch indicator and stops the output.

Malfunction item	Fail-safe condition	Fail-safe cancellation condition
Inverter unit power supply voltage is greater than 15V	When inverter unit input voltage rises above 15V, the output will be suspended to protect the inverter unit.	After the inverter unit power supply voltage drops below 15V, the AC 120V outlet main switch ON \Rightarrow OFF \Rightarrow ON operation allows normal return.
Inverter unit power supply voltage is less than 11.5V for 2 seconds or more	When inverter unit input voltage is lowered, the output will be suspended to protect the battery from running out.	After the inverter unit power supply voltage rises above 11.5V, the AC 120V outlet main switch ON \Rightarrow OFF \Rightarrow ON operation allows normal return.
Inverter unit power supply voltage is less than 9V		
Inverter unit AC 120V output voltage is greater than 170V	When inverter unit AC 120V output voltage is greater than 170V, the output will be suspended.	After the inverter unit AC 120V output voltage drops below 170V, the AC 120V outlet main switch ON \Rightarrow OFF \Rightarrow ON operation allows normal return.
Inverter unit output current is greater than 3.7A (400W mode)	When inverter unit output current rises above 3.7A, the output will be suspended to prevent over current (e.g., connecting an electric appliance exceeding rated output).	After the inverter unit output current drops below 3.7A, the AC 120V outlet main switch ON \Rightarrow OFF \Rightarrow ON operation allows normal return.
Inverter unit input current is greater than 13.3A (150W mode)	When inverter unit input current rises above 13.3A, the output will be suspended to prevent over current (e.g., connecting an electric appliance exceeding rated output).	After the inverter unit input current drops below 13.3A, the AC 120V outlet main switch ON \Rightarrow OFF \Rightarrow ON operation allows normal return.

PWO

SYSTEM

< SYSTEM DESCRIPTION >

[AC 120 V OUTLET]

Malfunction item	Fail-safe condition	Fail-safe cancellation condition
Inverter unit is overheated	When the inverter unit is overheated [thermistor temperature above 100°C (212°F)], the output will be suspended to protect the inverter unit.	After the inverter unit temperature is lowered, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.
Inverter unit output signal (AC 120V output signal) is shorted	When inverter unit output signal is shorted, the output will be suspended.	After recovering from inverter unit output signal short, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.

INVERTER UNIT

< ECU DIAGNOSIS INFORMATION >


[AC 120 V OUTLET]

ECU DIAGNOSIS INFORMATION INVERTER UNIT


Reference Value

INFOID:000000008940730

TERMINAL LAYOUT




PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (L)	Ground	AC sw signal input	Input	Ignition switch ON	AC 120V outlet main switch OFF
					12V
3 (G)		400W indicator drive signal	Input	Ignition switch ON	AC 120V outlet main switch OFF
					12V
5 (G)	11 (BR)	AC output 1	Output	Ignition switch ON	AC 120V outlet main switch OFF
					0V
					AC 120V
					Reference value
					 <p>(V) 150 100 50 0 -50 -100 -150 + -5ms</p> <p>RMS 120V</p> <p>JSMIA0397GB</p> <p>AC 120V</p>
6 (W)	Ground	Input park signal	Input	Ignition switch ON	AC 120V outlet main switch OFF
					12V
7 (SB)		RLY output signal	Input	Ignition switch ON	AC 120V outlet main switch OFF
					0V
					12V

INVERTER UNIT

< ECU DIAGNOSIS INFORMATION >

[AC 120 V OUTLET]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
11 (BR)	5 (G)	AC output 2	Output	Ignition switch ON	AC 120V outlet main switch OFF
					AC 120V
					Reference value  AC 120V
13 (B)	Ground	Ground	—	Ignition switch ON	
14 (W)		Battery power supply	Input	Ignition switch ON	0V
				AC 120V outlet main switch OFF	0V
				AC 120V outlet main switch ON	Battery voltage

CAUTION:

- To measure AC 120V output signal, always use the circuit tester or oscilloscope AC range. Never allow the probes to contact each other.
- Because of modified sine wave output of the AC 120V output signal, voltage cannot be measured accurately without using a circuit tester that can measure true RMS (root mean square).

Fail-safe

INFOID:0000000008940731

When a malfunction listed below occurs, the inverter unit turns OFF the AC 120V outlet main switch indicator and stops the output.

Malfunction item	Fail-safe condition	Fail-safe cancellation condition
Inverter unit power supply voltage is greater than 15V	When inverter unit input voltage rises above 15V, the output will be suspended to protect the inverter unit.	After the inverter unit power supply voltage drops below 15V, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.
Inverter unit power supply voltage is less than 11.5V for 2 seconds or more	When inverter unit input voltage is lowered, the output will be suspended to protect the battery from running out.	After the inverter unit power supply voltage rises above 11.5V, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.
Inverter unit power supply voltage is less than 9V		
Inverter unit AC 120V output voltage is greater than 170V	When inverter unit AC 120V output voltage is greater than 170V, the output will be suspended.	After the inverter unit AC 120V output voltage drops below 170V, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.
Inverter unit output current is greater than 3.7A (400W mode)	When inverter unit output current rises above 3.7A, the output will be suspended to prevent over current (e.g., connecting an electric appliance exceeding rated output).	After the inverter unit output current drops below 3.7A, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.
Inverter unit input current is greater than 13.3A (150W mode)	When inverter unit input current rises above 13.3A, the output will be suspended to prevent over current (e.g., connecting an electric appliance exceeding rated output).	After the inverter unit input current drops below 13.3A, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.

INVERTER UNIT

< ECU DIAGNOSIS INFORMATION >

[AC 120 V OUTLET]

Malfunction item	Fail-safe condition	Fail-safe cancellation condition
Inverter unit is overheated	When the inverter unit is overheated [thermistor temperature above 100°C (212°F)], the output will be suspended to protect the inverter unit.	After the inverter unit temperature is lowered, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.
Inverter unit output signal (AC 120V output signal) is shorted	When inverter unit output signal is shorted, the output will be suspended.	After recovering from inverter unit output signal short, the AC 120V outlet main switch ON ⇒ OFF ⇒ ON operation allows normal return.

A

B

C

D

E

F

G

H

I

J

K

L

PWO

N

O

P

INVERTER UNIT

< WIRING DIAGRAM >

[AC 120 V OUTLET]


WIRING DIAGRAM

INVERTER UNIT

Wiring Diagram

INFOID:000000008934210

DV : WITH REAR A/C 120V OUTLET



ABMW A1748GP

INVERTER UNIT

< WIRING DIAGRAM >

[AC 120 V OUTLET]

INVERTER SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5P	O/L	-
13P	Y/G	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	P	-
4	B/R	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
4	B/R	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1G	G	-
91G	BR	-

P

Z

PWO

N

L

—

G

T

A

B

C

D

M

F

—

K

—

O


P

INVERTER UNIT

< WIRING DIAGRAM >

[AC 120 V OUTLET]

Connector No.	M48
Connector Name	A/C 120V OUTLET MAIN SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	L	-	8	SHIELD	-
2	R	-	10	B/R	-
3	G	-	11	L/R	-
4	V	-	15	BR	-
5	BR	-	16	G	-
6	R	-			
7	SB	-			
8	-	-			
9	-	-			
10	-	-			
11	-	-			
12	-	-			

Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
3	G	-
4	V	-
5	BR	-
6	R	-
7	SB	-
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
3	G	-
4	V	-
5	BR	-
6	R	-
7	SB	-
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
8	SHIELD	-	10	P	-
12	P	-			



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
10	P	-	12	P	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
5	B/R	-	6	L/R	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
3	G	-
4	V	-
5	BR	-
6	R	-
7	SB	-
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
10	B/R	-	11	B/R	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
5	B/R	-	6	L/R	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
3	G	-
4	V	-
5	BR	-
6	R	-
7	SB	-
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
8	SHIELD	-	10	P	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
5	B/R	-	6	L/R	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
3	G	-
4	V	-
5	BR	-
6	R	-
7	SB	-
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-



INVERTER UNIT

< WIRING DIAGRAM >

[AC 120 V OUTLET]


Connector No.	E13
Connector Name	FUSE AND FUSIBLE LINK BOX
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-
2	-	-
3	SHIELD	-
4	BR	-



Connector No.	M208
Connector Name	A/C 120V OUTLET FRONT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	-
2	-	-
3	SHIELD	-
4	BR	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-




Connector No.	E36
Connector Name	INVERTER RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-
3	B	-
4	BR	-

Connector No.	E35
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	L/W	-
3	R	-
4	W	-



Terminal No.	Color of Wire	Signal Name
2C	BR	-
4C	G	-
11C	B	-

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z PWO


ABMIA4042GB

INVERTER UNIT

< WIRING DIAGRAM >


[AC 120 V OUTLET]

Connector No.	C1
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1G	G	-
91G	BR	-

Terminal No.	Color of Wire	Signal Name
1G	G	-
91G	BR	-



Connector No.	C15
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2C	BR	-
4C	G	-
11C	B	-



Terminal No.	Color of Wire	Signal Name
2C	BR	-
4C	G	-
11C	B	-

Terminal No.	Color of Wire	Signal Name
1	G	-
3	B	-
4	BR	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	BR	-
3	B	-
4	-	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	BR	-
3	B	-
4	-	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	BR	-
3	B	-
4	-	-



ABMIA4043GB

INVERTER UNIT

< WIRING DIAGRAM >


[AC 120 V OUTLET]

A B C D E F G
 J K L M N P Q

Connector No.	B16
Connector Name	INVERTER UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	AC SW SIGNAL INPUT
2	-	-
3	G	400W INDICATOR DRIVE
4	-	-
5	G	AC OUTPUT 1
6	W	INPUT PARK SIGNAL
12	-	-



Terminal No.	Color of Wire	Signal Name
7	SB	RLY OUTPUT
8	-	-
9	-	-
10	-	-
11	BR	BR AC OUTPUT 2
12	-	-

HS logo

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	SB	-

ABMIA4059GB

Connector No.	B25
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Connector No.	B25
Connector Name	WIRE TO WIRE
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-

PWO

INVERTER UNIT

< WIRING DIAGRAM >

[AC 120 V OUTLET]



ABMIA4065GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000008940732

OVERALL SEQUENCE



ALMIA0520GB

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Interview the customer about the symptom.

>> GO TO 2.

PWO

2. SYMPTOM CHECK

Check the symptom from the customer's information.

>> GO TO 3.

3. FAIL-SAFE ACTIVATION CHECK

Check that the symptom is a fail-safe condition.

Is fail-safe activated?

N

O

P

YES >> GO TO 4.

NO >> GO TO 5.

4. SYSTEM DIAGNOSIS

Perform diagnosis for the fail-safe activated system. Specify the malfunctioning component.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[AC 120 V OUTLET]

>> GO TO 6.

5. SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Specify the malfunctioning component.

>> GO TO 6.

6. MALFUNCTIONING COMPONENT REPAIR

Repair or replace the malfunctioning component.

>> GO TO 7.

7. REPAIR CHECK (OPERATION CHECK)

Check operation of AC 120V outlets.

Do the outlets operate normally?

YES >> Inspection End.

NO >> GO TO 3.

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000008940733

Regarding Wiring Diagram information, refer to [PWO-20, "Wiring Diagram".](#)

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse or Fusible Link No. or Letter
Ignition switch ON or START	59 (10A)
Battery power supply	N (60A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK INVERTER RELAY

Check inverter relay. Refer to [PWO-30, "Component Inspection \(Inverter Relay\)".](#)

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace inverter relay.

3. CHECK INVERTER UNIT POWER SUPPLY CIRCUIT

1. Connect inverter relay connector.
2. Disconnect inverter unit connector B16.
3. Connect a fused jumper wire between inverter unit connector B16 terminal 7 and ground.
4. Turn ignition switch ON.
5. Check voltage between inverter unit connector B17 terminal 14 and ground.

Inverter unit		Ground	Voltage (Approx.)
Connector	Terminal		
B17	14	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 4.

4. CHECK INVERTER RELAY POWER SUPPLY CIRCUITS

1. Turn ignition switch OFF.
2. Disconnect inverter relay connector.
3. Check voltage between inverter relay connector E36 terminal 3 and ground.

Inverter relay		Ground	Voltage (Approx.)
Connector	Terminal		
E36	3	—	Battery voltage

4. Turn ignition switch ON.
5. Check voltage between inverter relay connector E36 terminal 1 and ground.

Inverter relay		Ground	Condition	Voltage (Approx.)
Connector	Terminal			

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

E36	1	—	Ignition switch ON	Battery voltage
			Ignition switch OFF	0V

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the inverter relay power supply circuit.

5. CHECK INVERTER UNIT POWER SUPPLY CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect inverter unit connector B17.
3. Check continuity between inverter relay connector E36 terminal 5 and inverter unit connector B17 terminal 14.

Inverter relay		Inverter unit		Continuity
Connector	Terminal	Connector	Terminal	
E36	5	B17	14	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the inverter unit power supply circuit.

6. CHECK INVERTER RELAY COIL CIRCUIT FOR OPEN

Check continuity between inverter relay connector E36 terminal 2 and inverter unit connector B16 terminal 7.

Inverter relay		Inverter unit		Continuity
Connector	Terminal	Connector	Terminal	
E36	2	B16	7	Yes

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the inverter unit coil circuit.

7. CHECK INVERTER UNIT GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between inverter unit connector B17 terminal 13 and ground.

Inverter unit		Ground	Continuity
Connector	Terminal		
B17	13	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace the inverter unit ground circuit.

Component Inspection (Inverter Relay)

INFOID:0000000008940734

1. CHECK INVERTER RELAY

1. Turn ignition switch OFF.
2. Disconnect inverter relay connector.
3. Apply battery voltage to inverter relay terminal 1 and ground to terminal 2.
4. Check continuity between inverter relay terminals 3 and 5.

Inverter relay terminals	Condition	Continuity
3 – 5	Battery voltage applied to terminal 1 and ground to terminal 2	Yes
	Voltage and ground removed	No

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace inverter relay.

A

B

C

D

E

F

G

H

I

J

K

L

PWO

N

O

P

AC 120 V OUTLET MAIN SWITCH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

AC 120 V OUTLET MAIN SWITCH POWER SUPPLY CIRCUIT

Diagnosis Procedure

INFOID:0000000008940735

Regarding Wiring Diagram information, refer to [PWO-20, "Wiring Diagram"](#).

1. CHECK FUSE

Check that the following fuse is not blown.

Signal name	Fuse No.
Ignition switch ON or START	14 (10A)

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK POWER SUPPLY FOR AC 120V OUTLET MAIN SWITCH

1. Turn ignition switch ON.
2. Check for voltage between the AC 120V outlet main switch connector and ground.

AC 120V outlet main switch		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M48	2	—	Ignition switch ON	Battery voltage
			Ignition switch OFF	0V

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace the AC 120V main switch power supply circuit.

AC 120 V OUTLET MAIN SWITCH INPUT SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

AC 120 V OUTLET MAIN SWITCH INPUT SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:0000000008940736

Regarding Wiring Diagram information, refer to [PWO-20, "Wiring Diagram"](#).

1. CHECK AC 120V OUTLET MAIN SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. AC 120V outlet main switch ON.
3. Check for voltage between the inverter unit harness connector B16 terminal 1 and ground.

Inverter unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
B16	1	—	AC 120V outlet main switch OFF	0V
			AC 120V outlet main switch ON	Battery voltage

Is the inspection result normal?

YES >> Inspection End.
NO >> GO TO 2.

2. CHECK AC 120V OUTLET MAIN SWITCH

Check AC 120V outlet main switch. Refer to [PWO-33, "Component Inspection \(AC 120V Outlet Main Switch\)"](#).

Is the inspection result normal?

YES >> GO TO 3.
NO >> Replace AC 120V outlet main switch. Refer to [PWO-44, "Removal and Installation"](#).

3. CHECK HARNESS BETWEEN INVERTER UNIT AND AC 120V OUTLET MAIN SWITCH

1. Disconnect inverter unit connector B16.
2. Check for continuity between the inverter unit connector B16 terminal 1 and AC 120V outlet main switch connector M48 terminal 1.

Inverter unit		AC 120V outlet main switch		Continuity
Connector	Terminal	Connector	Terminal	
B16	1	M48	1	Yes

3. Check for continuity between inverter unit connector B16 terminal 1 and ground.

Inverter unit		Ground	Continuity
Connector	Terminal		
B16	1	—	No

Is the inspection result normal?

YES >> Inspection End.
NO >> Repair or replace the AC 120V outlet main switch input signal circuit.

Component Inspection (AC 120V Outlet Main Switch)

INFOID:0000000008940737

1. CHECK AC 120V OUTLET MAIN SWITCH

1. Turn ignition switch OFF.
2. Disconnect AC 120V outlet main switch connector.
3. Check continuity between terminals 1 and 2 of AC 120V outlet main switch.

AC 120 V OUTLET MAIN SWITCH INPUT SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

AC 120V outlet main switch terminals	Condition	Continuity
1 –2	AC 120V outlet main switch ON	Yes
	AC 120V outlet main switch OFF	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace AC 120V outlet main switch. Refer to [PWO-44, "Removal and Installation"](#).

AC 120 V POWER OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

AC 120 V POWER OUTPUT CIRCUIT

Diagnosis Procedure

INFOID:0000000008940738

A

B

C

D

E

F

G

H

I

J

K

L

PWO

N

O

P

Regarding Wiring Diagram information, refer to [PWO-20, "Wiring Diagram"](#).

1. CHECK HARNESS BETWEEN INVERTER UNIT AND AC 120V OUTLETS

1. Turn ignition switch OFF.
2. Disconnect inverter unit connector B16, AC 120V outlet front connector and AC 120V outlet rear connector.
3. Check continuity between inverter unit connector B16 terminals 5, 11 and AC 120V outlet front connector M208 terminals 1, 4.

Inverter unit		AC 120V outlet front		Continuity
Connector	Terminal	Connector	Terminal	
B16	5	M208	1	Yes
	11		4	

4. Check continuity between inverter unit connector B16 terminals 5, 11 and AC 120V outlet rear connector C53 terminals 1, 2.

Inverter unit		AC 120V outlet rear		Continuity
Connector	Terminal	Connector	Terminal	
B16	5	C53	1	Yes
	11		2	

5. Check continuity between inverter unit connector B16 terminals 5, 11 and ground.

Inverter unit		Ground	Continuity
Connector	Terminal		
B16	5	—	No
	11		

6. Check continuity between inverter unit connector B16 terminals 5 and 11.

Inverter unit		Terminal	Continuity
Connector	Terminal		
B16	5	11	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the harness or connectors.

2. CHECK INVERTER UNIT OUTPUT SIGNAL

1. Connect inverter unit connector B16, AC 120V outlet front connector and AC 120V outlet rear connector.
2. Turn ignition switch ON.
3. AC 120V outlet main switch ON (AC 120V outlet main switch 150W indicator ON).
4. Check voltage between inverter unit connector B16 terminals 5 and 11.

CAUTION:

- To measure AC 120V output signal, always use the circuit tester AC range.
- Never allow the probes to contact each other.

AC 120 V POWER OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

Terminals		Condition	Voltage (Approx.)	
(+)	(-)			
Inverter unit connector B16		AC 120V outlet main switch		
Terminal				
5	11	All indicators OFF	0V	
		150W indicator ON	AC 120V	

Is the inspection result normal?

YES >> GO TO 3

NO >> Replace inverter unit. Refer to [PWO-43, "Removal and Installation"](#).

3. CHECK AC 120V OUTLET FRONT VOLTAGE

1. AC 120V outlet main switch ON (AC 120V outlet main switch 150W indicator ON).
2. Check voltage between AC 120V outlet front M208 terminals 1 and 4.

CAUTION:

- To measure AC 120V output signal, always use the circuit tester AC range.
- Never allow the probes to contact each other.

Terminals		Condition	Voltage (Approx.)	
(+)	(-)			
AC 120V outlet front connector M208		AC 120V outlet main switch		
Terminal				
1	4	OFF	0V	
		ON	AC 120V	

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace AC 120V outlet front. Refer to [PWO-45, "Removal and Installation - Front"](#).

4. CHECK AC 120V OUTLET FRONT GROUND CIRCUIT

1. AC 120V outlet main switch OFF.
2. Turn ignition switch OFF.
3. Disconnect AC 120V outlet front connector.
4. Check continuity between AC 120V outlet front connector M208 terminal 3 and ground.

AC 120V outlet front		Ground	Continuity
Connector	Terminal		
M208	3	—	Yes

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair AC 120V outlet front ground circuit.

5. CHECK AC 120V OUTLET REAR VOLTAGE

1. Turn ignition switch ON.
2. AC 120V outlet main switch ON (AC 120V outlet main switch 150W indicator ON).
3. Check voltage between AC 120V outlet rear C53 terminals 1 and 2.

CAUTION:

- To measure AC 120V output signal, always use the circuit tester AC range.
- Never allow the probes to contact each other.

AC 120 V POWER OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
AC 120V outlet rear connector C53		AC 120V outlet main switch	
Terminal			
1	2	OFF	0V
		ON	AC 120V

Is the inspection result normal?

YES >> GO TO 6

NO >> Replace AC 120V outlet rear. Refer to [PWO-45, "Removal and Installation - Front"](#).

6.CHECK AC 120V OUTLET REAR GROUND CIRCUIT

1. AC 120V outlet main switch OFF.
2. Turn ignition switch OFF.
3. Disconnect AC 120V outlet rear connector.
4. Check continuity between AC 120V outlet rear connector C53 terminal 3 and ground.

AC 120V outlet rear		Ground	Continuity
Connector	Terminal		
C53	3	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair AC 120V outlet rear ground circuit.

A

B

C

D

E

F

G

H

I

J

K

L

PWO

N

O

P

AC 120 V OUTLET MAIN SWITCH INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

AC 120 V OUTLET MAIN SWITCH INDICATOR CIRCUIT

Diagnosis Procedure (150W Indicator)

INFOID:0000000008940739

Regarding Wiring Diagram information, refer to [PWO-20, "Wiring Diagram"](#).

1. CHECK POWER SUPPLY FOR AC 120V OUTLET MAIN SWITCH INDICATOR

1. Turn ignition switch ON.
2. Check for voltage between the AC 120V outlet main switch connector M48 terminal 6 and ground.

AC 120V outlet main switch		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M48	6	—	Ignition switch ON	Battery voltage
			Ignition switch OFF	0V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the AC 120V outlet main switch indicator power supply circuit.

2. CHECK AC 120V OUTLET MAIN SWITCH 150W INDICATOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect AC 120V outlet main switch connector and inverter unit connector B16.
3. Check continuity between AC 120V outlet main switch connector M48 terminal 7 and inverter unit connector B16 terminal 7.

AC 120V outlet main switch		Inverter unit		Continuity
Connector	Terminal	Connector	Terminal	
M48	7	B16	7	Yes

Is the inspection result normal?

YES >> Replace AC 120V outlet main switch. Refer to [PWO-44, "Removal and Installation"](#).

NO >> Repair or replace the AC 120V outlet main switch 150W indicator ground circuit.

Diagnosis Procedure (400W Indicator)

INFOID:0000000008940740

Regarding Wiring Diagram information, refer to [PWO-20, "Wiring Diagram"](#).

1. CHECK AC 120V OUTLET MAIN SWITCH INDICATORS

Check AC 120V outlet main switch indicators. Refer to [PWO-39, "Component Inspection \(AC 120V Outlet Main Switch Indicators\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace AC 120V outlet main switch.

2. CHECK POWER SUPPLY FOR AC 120V OUTLET MAIN SWITCH INDICATOR

1. Turn ignition switch ON.
2. Check for voltage between the AC 120V outlet main switch connector M48 terminal 6 and ground.

AC 120V outlet main switch		Ground	Condition	Voltage (Approx.)
Connector	Terminal			

AC 120 V OUTLET MAIN SWITCH INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[AC 120 V OUTLET]

M48	6	—	Ignition switch ON	Battery voltage
			Ignition switch OFF	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the AC 120V outlet main switch indicator power supply circuit.

3. CHECK AC 120V OUTLET MAIN SWITCH 400W INDICATOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect AC 120V outlet main switch connector and inverter unit connector B16.
3. Check continuity between AC 120V outlet main switch connector M48 terminal 3 and inverter unit connector B16 terminal 3.

AC 120V outlet main switch		Inverter unit		Continuity
Connector	Terminal	Connector	Terminal	
M48	3	B16	3	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the AC 120V outlet main switch 400W indicator ground circuit.

4. CHECK P RANGE SWITCH SIGNAL CIRCUIT

1. Disconnect shift lock control unit connector.
2. Check continuity between shift lock control unit connector M81 terminal 2 and inverter unit connector B16 terminal 6.

Shift lock control unit		Inverter unit		Continuity
Connector	Terminal	Connector	Terminal	
M81	2	B16	6	Yes

Is the inspection result normal?

YES >> Replace inverter unit. Refer to [PWO-43, "Removal and Installation"](#).

NO >> Repair or replace the P range switch signal circuit.

Component Inspection (AC 120V Outlet Main Switch Indicators)

INFOID:0000000008940741

1. CHECK AC 120V OUTLET MAIN SWITCH INDICATORS

1. Turn ignition switch OFF.
2. Disconnect AC 120V outlet main switch connector.
3. Apply battery voltage to AC 120V outlet main switch terminal 6 and ground to terminal 7.

AC 120V outlet main switch terminals	Condition	150W indicator
6 – 7	Battery voltage applied to terminal 6 and ground to terminal 7	ON
	Voltage and ground removed	OFF

4. Apply battery voltage to AC 120V outlet main switch terminal 6 and ground to terminal 3.

AC 120V outlet main switch terminals	Condition	400W indicator
6 – 3	Battery voltage applied to terminal 6 and ground to terminal 3	ON
	Voltage and ground removed	OFF

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace AC 120V outlet main switch. Refer to [PWO-44, "Removal and Installation"](#).

SYMPTOM DIAGNOSIS

NO OUTPUT FROM AC 120 V OUTLET

Diagnosis Procedure

INFOID:0000000008940743

1. CHECK FAIL-SAFE ACTIVATION

Check if the symptom is caused by a fail-safe operation. Refer to [PWO-18, "Fail-safe"](#).

Is fail-safe operating?

- YES >> Repair the part causing fail-safe operation.
NO >> GO TO 2.

2. CHECK INVERTER UNIT POWER SUPPLY CIRCUIT

Check inverter unit power supply circuit. Refer to [PWO-29, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3. CHECK AC 120V OUTLET MAIN SWITCH POWER SUPPLY CIRCUIT

Check AC 120V outlet main switch power supply circuit. Refer to [PWO-32, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4. CHECK AC 120V OUTLET MAIN SWITCH INPUT SIGNAL CIRCUIT

Check AC 120V outlet main switch input signal circuit. Refer to [PWO-33, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace the malfunctioning parts.

5. CHECK INVERTER UNIT POWER OUTPUT CIRCUIT

Check inverter unit power output circuit. Refer to [PWO-35, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Refer to [GI-42, "Intermittent Incident"](#).
NO >> Repair or replace the malfunctioning parts.

AC 120 V OUTLET MAIN SWITCH INDICATOR DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

[AC 120 V OUTLET]

AC 120 V OUTLET MAIN SWITCH INDICATOR DOES NOT TURN ON

Diagnosis Procedure

INFOID:0000000008940744

1. CHECK FAIL-SAFE ACTIVATION

Check if the symptom is caused by a fail-safe operation. Refer to [PWO-18, "Fail-safe"](#).

Is fail-safe operating?

- YES >> Repair the part causing fail-safe operation.
NO >> GO TO 2.

2. CHECK INVERTER UNIT POWER SUPPLY CIRCUIT

Check inverter unit power supply circuit. Refer to [PWO-29, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3. CHECK AC 120V OUTLET MAIN SWITCH POWER SUPPLY CIRCUIT

Check AC 120V outlet main switch power supply circuit. Refer to [PWO-32, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4. CHECK AC 120V OUTLET MAIN SWITCH INPUT SIGNAL CIRCUIT

Check AC 120V outlet main switch input signal circuit. Refer to [PWO-33, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace the malfunctioning parts.

5. CHECK AC 120V OUTLET MAIN SWITCH INDICATOR CIRCUIT

Check AC 120V outlet main switch indicator circuit. Refer to [PWO-38, "Diagnosis Procedure \(150W Indicator\)"](#).

Is the inspection result normal?

- YES >> Refer to [GI-42, "Intermittent Incident"](#).
NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

J

K

L

PWO

N

O

P

NORMAL OPERATING CONDITION

<SYMPTOM DIAGNOSIS>

[AC 120 V OUTLET]

NORMAL OPERATING CONDITION

Description

INFOID:0000000008940745

Because of modified sine wave output, the AC 120V outlet may not operate normally for electric appliance of which electric power consumption is 150W or less.

- Electric appliances requiring a large amount of electric power consumption at startup (e.g., CRT-based TV, power tool)
- Measuring instruments for data requiring accuracy (e.g., medical equipment, measuring instrument)
- Microprocessor-controlled appliances (e.g., microprocessor-controlled blanket)

Noise may be caused in radio or TV, depending on an electric appliance.

REMOVAL AND INSTALLATION

INVERTER UNIT

Removal and Installation

INFOID:000000008934221

A

REMOVAL

1. Remove inverter unit fuse.
 2. Remove rear panel. Refer to [INT-14. "Removal and Installation"](#).
- NOTE:**
The inverter unit is located behind the LH seat.
3. Remove the inverter unit bolts.
 4. Disconnect the harness connector from the inverter unit.
 5. Remove the inverter unit.

C

D

E

INSTALLATION

Installation is in the reverse order of removal.

F

G

H

I

J

K

L

PWO

N

O

P

AC 120V OUTLET MAIN SW

Removal and Installation

INFOID:000000008934222

REMOVAL

1. Remove the inverter unit fuse.
2. Remove the cluster lid C. Refer to [IP-14, "Removal and Installation"](#).
3. Release pawls using suitable tool to remove the AC 120V outlet main switch.

INSTALLATION

Installation is in the reverse order of removal.

AC 120 V OUTLET

< REMOVAL AND INSTALLATION >

[AC 120 V OUTLET]

AC 120 V OUTLET

Removal and Installation - Front

INFOID:000000008934223

AC 120V OUTLET FRONT

Removal

1. Remove center console rear finisher. Refer to [IP-20, "Removal and Installation"](#).
2. Release the pawl from the back of the center console rear finisher to remove the AC 120 V outlet.

Installation

Installation is in the reverse order of removal.

Removal and Installation - Rear

INFOID:000000008945792

AC 120V OUTLET (CARGO BED)

Removal

1. Remove the fuse for the AC 120V outlet.
2. Remove the rivets attaching the AC 120V outlet finisher to the cargo bed.
3. Disconnect the harness connector from the AC 120V outlet to remove the AC 120V outlet.

Installation

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

PWO

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[AC 120 V OUTLET]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

AC 120V Power Outlet

INFOID:000000008934224

Rated voltage output	AC 120V (+/- 10%)	
Operating voltage range	DC 11.5V to 15V (Inverter terminal)	
Rated power output	Low power mode	150W
	High power mode	400W
Output over current protection	High power mode	3.7A or more
Input over current protection	Low power mode	13.3A or more
Output frequency	60Hz (+/- 10%)	
Parasitic current	< 1mA	
Max. input current	45A (during continuous power)	
Rated continuous power	400W @ 40°C (104°F) Maximum	
Overheat protection (Thermistor)	100°C (212°F)	