

SECTION **AV**

AUDIO, VISUAL & NAVIGATION SYSTEM

CONTENTS

<b>BASE AUDIO</b>		
<b>BASIC INSPECTION</b> .....	7	
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	7	
Work Flow .....	7	
<b>SYSTEM DESCRIPTION</b> .....	9	
<b>AUDIO SYSTEM</b> .....	9	
System Diagram .....	9	
System Description .....	9	
Component Parts Location .....	10	
Component Description .....	10	
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	12	
<b>POWER SUPPLY AND GROUND CIRCUIT</b> .....	12	
<b>AUDIO UNIT</b> .....	12	
AUDIO UNIT : Diagnosis Procedure .....	12	
<b>FRONT DOOR SPEAKER</b> .....	13	
Description .....	13	
Diagnosis Procedure .....	13	
<b>FRONT TWEETER</b> .....	15	
Description .....	15	
Diagnosis Procedure .....	15	
<b>REAR DOOR SPEAKER</b> .....	17	
Description .....	17	
Diagnosis Procedure .....	17	
<b>REAR DOOR TWEETER</b> .....	19	
Description .....	19	
Diagnosis Procedure .....	19	
<b>ECU DIAGNOSIS INFORMATION</b> .....	21	
<b>AUDIO UNIT</b> .....	21	
Reference Value .....	21	
<b>WIRING DIAGRAM</b> .....	23	
<b>BASE AUDIO SYSTEM</b> .....	23	
Wiring Diagram .....	23	
<b>SYMPTOM DIAGNOSIS</b> .....	31	
<b>AUDIO SYSTEM</b> .....	31	
Symptom Table .....	31	
<b>NORMAL OPERATING CONDITION</b> .....	32	
Description .....	32	
<b>PRECAUTION</b> .....	33	
<b>PRECAUTIONS</b> .....	33	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	33	
Precaution for Work .....	33	
<b>PREPARATION</b> .....	34	
<b>PREPARATION</b> .....	34	
Special Service Tools .....	34	
Commercial Service Tools .....	34	
<b>REMOVAL AND INSTALLATION</b> .....	35	
<b>AUDIO UNIT</b> .....	35	
Removal and Installation .....	35	
<b>FRONT TWEETER</b> .....	36	
Removal and Installation .....	36	
<b>FRONT DOOR SPEAKER</b> .....	37	
Removal and Installation .....	37	
<b>REAR DOOR SPEAKER</b> .....	38	
Removal and Installation .....	38	
<b>AUDIO ANTENNA</b> .....	39	
Location of Antenna .....	39	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV

Removal and Installation .....	39	<b>REAR DOOR TWEETER</b> .....	<b>68</b>
<b>MID AUDIO</b>		Description .....	68
<b>PRECAUTION</b> .....	<b>40</b>	Diagnosis Procedure .....	68
<b>PRECAUTIONS</b> .....	<b>40</b>	<b>SYMPTOM DIAGNOSIS</b> .....	<b>70</b>
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	40	<b>AUDIO SYSTEM</b> .....	<b>70</b>
Precaution for Trouble Diagnosis .....	40	Symptom Table .....	70
Precaution for Work .....	40	<b>NORMAL OPERATING CONDITION</b> .....	<b>72</b>
<b>PREPARATION</b> .....	<b>42</b>	Description .....	72
<b>PREPARATION</b> .....	<b>42</b>	<b>REMOVAL AND INSTALLATION</b> .....	<b>73</b>
Special Service Tools .....	42	<b>AUDIO UNIT</b> .....	<b>73</b>
Commercial Service Tools .....	42	Removal and Installation .....	73
<b>SYSTEM DESCRIPTION</b> .....	<b>43</b>	<b>FRONT TWEETER</b> .....	<b>74</b>
<b>COMPONENT PARTS</b> .....	<b>43</b>	Removal and Installation .....	74
Component Parts Location .....	43	<b>FRONT DOOR SPEAKER</b> .....	<b>75</b>
Component Description .....	43	Removal and Installation .....	75
<b>SYSTEM</b> .....	<b>45</b>	<b>REAR DOOR SPEAKER</b> .....	<b>76</b>
System Diagram .....	45	Removal and Installation .....	76
System Description .....	45	<b>AUDIO ANTENNA</b> .....	<b>77</b>
<b>DIAGNOSIS SYSTEM (AUDIO UNIT)</b> .....	<b>46</b>	Location of Antenna .....	77
Diagnosis Description .....	46	Removal and Installation .....	77
On Board Diagnosis Function .....	46	<b>DISPLAY AUDIO WITHOUT AMPLIFIER</b>	
<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>49</b>	<b>PRECAUTION</b> .....	<b>78</b>
<b>AUDIO UNIT</b> .....	<b>49</b>	<b>PRECAUTIONS</b> .....	<b>78</b>
Reference Value .....	49	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	78
<b>WIRING DIAGRAM</b> .....	<b>51</b>	Precaution for Trouble Diagnosis .....	78
<b>MID AUDIO SYSTEM</b> .....	<b>51</b>	Precaution for Harness Repair .....	78
Wiring Diagram .....	51	Precaution for Work .....	79
<b>BASIC INSPECTION</b> .....	<b>59</b>	<b>PREPARATION</b> .....	<b>80</b>
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	<b>59</b>	<b>PREPARATION</b> .....	<b>80</b>
Work Flow .....	59	Special Service Tools .....	80
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	<b>61</b>	Commercial Service Tools .....	80
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	<b>61</b>	<b>SYSTEM DESCRIPTION</b> .....	<b>81</b>
<b>AUDIO UNIT</b> .....	<b>61</b>	<b>COMPONENT PARTS</b> .....	<b>81</b>
AUDIO UNIT : Diagnosis Procedure .....	61	Component Parts Location .....	81
<b>FRONT DOOR SPEAKER</b> .....	<b>62</b>	Component Description .....	82
Diagnosis Procedure .....	62	<b>SYSTEM</b> .....	<b>83</b>
<b>FRONT TWEETER</b> .....	<b>64</b>	System Diagram .....	83
Diagnosis Procedure .....	64	System Description .....	83
<b>REAR SPEAKER</b> .....	<b>66</b>	<b>DIAGNOSIS SYSTEM (AUDIO UNIT)</b> .....	<b>85</b>
Description .....	66	Description .....	85
Diagnosis Procedure .....	66	On Board Diagnosis Function .....	85
		<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>91</b>

<b>AUDIO UNIT</b> .....	91	Description .....	135
Reference Value .....	91	<b>REMOVAL AND INSTALLATION</b> .....	137
<b>BLUETOOTH® CONTROL UNIT</b> .....	94	<b>AUDIO UNIT</b> .....	137
Reference Value .....	94	Removal and Installation .....	137
<b>WIRING DIAGRAM</b> .....	97	<b>SATELLITE RADIO ANTENNA</b> .....	138
<b>DISPLAY AUDIO WITHOUT AMPLIFIER</b> .....	97	Removal and Installation .....	138
Wiring Diagram .....	97	<b>FRONT TWEETER</b> .....	139
<b>BASIC INSPECTION</b> .....	112	Removal and Installation .....	139
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	112	<b>FRONT DOOR SPEAKER</b> .....	140
Work Flow .....	112	Removal and Installation .....	140
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	114	<b>REAR DOOR SPEAKER</b> .....	141
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ...	114	Removal and Installation .....	141
<b>AUDIO UNIT</b> .....	114	<b>STEERING SWITCH</b> .....	142
AUDIO UNIT : Diagnosis Procedure .....	114	Removal and Installation .....	142
<b>BLUETOOTH® CONTROL UNIT</b> .....	114	<b>AUDIO ANTENNA</b> .....	143
BLUETOOTH® CONTROL UNIT : Diagnosis Pro- cedure .....	114	Location of Antenna .....	143
<b>MICROPHONE</b> .....	115	Removal and Installation .....	143
MICROPHONE : Diagnosis Procedure .....	115	<b>USB CONNECTOR</b> .....	144
<b>FRONT DOOR SPEAKER</b> .....	117	Removal and Installation .....	144
Diagnosis Procedure .....	117	<b>MICROPHONE</b> .....	145
<b>FRONT TWEETER</b> .....	119	Removal and Installation .....	145
Diagnosis Procedure .....	119	<b>TEL ANTENNA</b> .....	146
<b>REAR DOOR SPEAKER</b> .....	121	Removal and Installation .....	146
Description .....	121	<b>BLUETOOTH CONTROL UNIT</b> .....	147
Diagnosis Procedure .....	121	Removal and Installation .....	147
<b>REAR DOOR TWEETER</b> .....	123	<b>REAR VIEW CAMERA</b> .....	148
Description .....	123	Removal and Installation .....	148
Diagnosis Procedure .....	123	<b>DISPLAY AUDIO WITH AMPLIFIER</b>	
<b>REAR VIEW CAMERA IMAGE SIGNAL CIR- CUIT</b> .....	125	<b>PRECAUTION</b> .....	149
Diagnosis Procedure .....	125	<b>PRECAUTIONS</b> .....	149
<b>STEERING SWITCH</b> .....	127	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	149
Diagnosis Procedure .....	127	Precaution for Trouble Diagnosis .....	149
<b>MICROPHONE SIGNAL CIRCUIT</b> .....	129	Precaution for Harness Repair .....	149
Description .....	129	Precaution for Work .....	150
Diagnosis Procedure .....	129	<b>PREPARATION</b> .....	151
<b>USB CONNECTOR</b> .....	131	<b>PREPARATION</b> .....	151
Diagnosis Procedure .....	131	Special Service Tools .....	151
<b>SYMPTOM DIAGNOSIS</b> .....	132	Commercial Service Tools .....	151
<b>AUDIO SYSTEM</b> .....	132	<b>SYSTEM DESCRIPTION</b> .....	152
Symptom Table .....	132	<b>COMPONENT PARTS</b> .....	152
<b>NORMAL OPERATING CONDITION</b> .....	135	Component Parts Location .....	152
		Component Description .....	153

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

<b>SYSTEM</b> .....	154	<b>REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT</b> .....	214
System Diagram .....	154	Diagnosis Procedure .....	214
System Description .....	154	<b>MICROPHONE SIGNAL CIRCUIT</b> .....	216
<b>DIAGNOSIS SYSTEM (AUDIO UNIT)</b> .....	156	Diagnosis Procedure .....	216
Description .....	156	<b>STEERING SWITCH</b> .....	218
On Board Diagnosis Function .....	156	Diagnosis Procedure .....	218
<b>ECU DIAGNOSIS INFORMATION</b> .....	162	<b>USB CONNECTOR</b> .....	220
<b>AUDIO UNIT</b> .....	162	Diagnosis Procedure .....	220
Reference Value .....	162	<b>SYMPTOM DIAGNOSIS</b> .....	221
<b>AUDIO AMP</b> .....	166	<b>AUDIO SYSTEM</b> .....	221
Reference Value .....	166	Symptom Table .....	221
<b>BLUETOOTH® CONTROL UNIT</b> .....	169	<b>NORMAL OPERATING CONDITION</b> .....	226
Reference Value .....	169	Description .....	226
<b>WIRING DIAGRAM</b> .....	172	<b>REMOVAL AND INSTALLATION</b> .....	228
<b>DISPLAY AUDIO WITH AMPLIFIER</b> .....	172	<b>AUDIO UNIT</b> .....	228
Wiring Diagram .....	172	Removal and Installation .....	228
<b>BASIC INSPECTION</b> .....	190	<b>SATELLITE RADIO ANTENNA</b> .....	229
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	190	Removal and Installation .....	229
Work Flow .....	190	<b>FRONT TWEETER</b> .....	230
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	192	Removal and Installation .....	230
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ..	192	<b>CENTER SPEAKER</b> .....	231
<b>AUDIO UNIT</b> .....	192	Removal and Installation .....	231
AUDIO UNIT : Diagnosis Procedure .....	192	<b>FRONT DOOR SPEAKER</b> .....	232
<b>AUDIO AMP</b> .....	192	Removal and Installation .....	232
AUDIO AMP : Diagnosis Procedure .....	193	<b>REAR DOOR SPEAKER</b> .....	233
<b>BLUETOOTH® CONTROL UNIT</b> .....	193	Removal and Installation .....	233
BLUETOOTH® CONTROL UNIT : Diagnosis Procedure .....	193	<b>SUBWOOFER</b> .....	234
<b>FRONT DOOR SPEAKER</b> .....	195	Removal and Installation .....	234
Diagnosis Procedure .....	195	<b>STEERING SWITCH</b> .....	235
<b>FRONT TWEETER</b> .....	198	Removal and Installation .....	235
Diagnosis Procedure .....	198	<b>AUDIO AMP.</b> .....	236
<b>CENTER SPEAKER</b> .....	201	Removal and Installation .....	236
Diagnosis Procedure .....	201	<b>AUDIO ANTENNA</b> .....	237
<b>REAR DOOR SPEAKER</b> .....	204	Location of Antenna .....	237
Diagnosis Procedure .....	204	Removal and Installation .....	237
<b>REAR DOOR TWEETER</b> .....	207	<b>USB CONNECTOR</b> .....	238
Diagnosis Procedure .....	207	Removal and Installation .....	238
<b>SUBWOOFER</b> .....	210	<b>MICROPHONE</b> .....	239
Description .....	210	Removal and Installation .....	239
Diagnosis Procedure .....	210	<b>TEL ANTENNA</b> .....	240
<b>AMP ON SIGNAL CIRCUIT</b> .....	213	Removal and Installation .....	240
Diagnosis Procedure .....	213	<b>BLUETOOTH CONTROL UNIT</b> .....	241

Removal and Installation .....	241	ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT : Description .....	287	A
<b>REAR VIEW CAMERA .....</b>	<b>242</b>	ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT : Work Procedure .....	287	
Removal and Installation .....	242			
<b>NAVIGATION</b>				
<b>PRECAUTION .....</b>	<b>243</b>	<b>CONFIGURATION (AV CONTROL UNIT) .....</b>	<b>287</b>	B
<b>PRECAUTIONS .....</b>	<b>243</b>	CONFIGURATION (AV CONTROL UNIT) : Description .....	288	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	243	CONFIGURATION (AV CONTROL UNIT) : Work Procedure .....	288	C
Precaution for Trouble Diagnosis .....	243	CONFIGURATION (AV CONTROL UNIT) : Configuration List .....	289	D
Precaution for Harness Repair .....	243			
Precaution for Work .....	244	<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>290</b>	
<b>PREPARATION .....</b>	<b>245</b>	<b>U1000 CAN COMM CIRCUIT .....</b>	<b>290</b>	E
<b>PREPARATION .....</b>	<b>245</b>	DTC Logic .....	290	
Special Service Tools .....	245	Diagnosis Procedure .....	290	
Commercial Service Tools .....	245	<b>U1010 CONTROL UNIT (CAN) .....</b>	<b>291</b>	F
<b>SYSTEM DESCRIPTION .....</b>	<b>246</b>	DTC Logic .....	291	
<b>COMPONENT PARTS .....</b>	<b>246</b>	<b>U1217 AV CONTROL UNIT .....</b>	<b>292</b>	G
Component Parts Location .....	246	DTC Logic .....	292	
Component Description .....	247	<b>U1229 AV CONTROL UNIT .....</b>	<b>293</b>	H
<b>SYSTEM .....</b>	<b>249</b>	DTC Logic .....	293	
System Diagram .....	249	<b>U122F AV CONTROL UNIT .....</b>	<b>294</b>	I
System Description .....	249	DTC Logic .....	294	
<b>DIAGNOSIS SYSTEM (AV CONTROL UNIT)..</b>	<b>253</b>	<b>U1244 GPS ANTENNA .....</b>	<b>295</b>	J
Description .....	253	DTC Logic .....	295	
On Board Diagnosis Function .....	253	Diagnosis Procedure .....	295	
CONSULT Function .....	254	<b>U1258 SATELLITE RADIO ANTENNA .....</b>	<b>296</b>	K
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>255</b>	DTC Logic .....	296	
<b>AV CONTROL UNIT .....</b>	<b>255</b>	Diagnosis Procedure .....	296	
Reference Value .....	255	<b>U1263 USB .....</b>	<b>297</b>	L
DTC Index .....	258	DTC Logic .....	297	
<b>AUDIO AMP .....</b>	<b>259</b>	Diagnosis Procedure .....	297	
Reference Value .....	259	<b>U1265 AUDIO AMP. ....</b>	<b>298</b>	M
<b>DVD PLAYER .....</b>	<b>262</b>	DTC Logic .....	298	
Reference Value .....	262	Diagnosis Procedure .....	298	
<b>WIRING DIAGRAM .....</b>	<b>264</b>	<b>U12AA CONFIGURATION ERROR .....</b>	<b>299</b>	AV
<b>NAVIGATION SYSTEM .....</b>	<b>264</b>	DTC Logic .....	299	
Wiring Diagram .....	264	Diagnosis Procedure .....	299	
<b>BASIC INSPECTION .....</b>	<b>285</b>	<b>U12AB ANTENNA .....</b>	<b>300</b>	O
<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	<b>285</b>	DTC Logic .....	300	
Work Flow .....	285	Diagnosis Procedure .....	300	
<b>INSPECTION AND ADJUSTMENT .....</b>	<b>287</b>	<b>U12AC AV CONTROL UNIT .....</b>	<b>301</b>	P
<b>ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT .....</b>	<b>287</b>	DTC Logic .....	301	
		<b>U12AD AV CONTROL UNIT .....</b>	<b>302</b>	
		DTC Logic .....	302	
		<b>U12AE AV CONTROL UNIT .....</b>	<b>303</b>	
		DTC Logic .....	303	

<b>U12AF AV CONTROL UNIT</b> .....	<b>304</b>	<b>SYMPTOM DIAGNOSIS</b> .....	<b>338</b>
DTC Logic .....	304	<b>MULTI AV SYSTEM</b> .....	<b>338</b>
<b>U12B0 POWER SUPPLY VOLTAGE</b> .....	<b>305</b>	Symptom Table .....	338
DTC Logic .....	305	<b>NORMAL OPERATING CONDITION</b> .....	<b>344</b>
Diagnosis Procedure .....	305	Description .....	344
<b>U12B1 POWER SUPPLY VOLTAGE</b> .....	<b>306</b>	<b>REMOVAL AND INSTALLATION</b> .....	<b>353</b>
DTC Logic .....	306	<b>AV CONTROL UNIT</b> .....	<b>353</b>
Diagnosis Procedure .....	306	Removal and Installation .....	353
<b>U1310 AV CONTROL UNIT</b> .....	<b>307</b>	<b>FRONT TWEETER</b> .....	<b>354</b>
DTC Logic .....	307	Removal and Installation .....	354
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ..	<b>308</b>	<b>CENTER SPEAKER</b> .....	<b>355</b>
<b>AV CONTROL UNIT</b> .....	<b>308</b>	Removal and Installation .....	355
AV CONTROL UNIT : Diagnosis Procedure .....	308	<b>FRONT DOOR SPEAKER</b> .....	<b>356</b>
<b>AUDIO AMP.</b> .....	<b>308</b>	Removal and Installation .....	356
AUDIO AMP. : Diagnosis Procedure .....	308	<b>REAR DOOR SPEAKER</b> .....	<b>357</b>
<b>DVD PLAYER</b> .....	<b>309</b>	Removal and Installation .....	357
DVD PLAYER : Diagnosis Procedure .....	309	<b>SUBWOOFER</b> .....	<b>358</b>
<b>VIDEO MONITOR</b> .....	<b>310</b>	Removal and Installation .....	358
VIDEO MONITOR : Diagnosis Procedure .....	310	<b>STEERING SWITCH</b> .....	<b>359</b>
<b>FRONT DOOR SPEAKER</b> .....	<b>312</b>	Removal and Installation .....	359
Diagnosis Procedure .....	312	<b>AUDIO AMP.</b> .....	<b>360</b>
<b>FRONT TWEETER</b> .....	<b>315</b>	Removal and Installation .....	360
Diagnosis Procedure .....	315	<b>AUDIO ANTENNA</b> .....	<b>361</b>
<b>CENTER SPEAKER</b> .....	<b>318</b>	Location of Antenna .....	361
Diagnosis Procedure .....	318	Removal and Installation .....	361
<b>REAR DOOR SPEAKER</b> .....	<b>321</b>	<b>AUXILIARY INPUT JACK</b> .....	<b>362</b>
Diagnosis Procedure .....	321	Removal and Installation .....	362
<b>REAR DOOR TWEETER</b> .....	<b>324</b>	<b>USB CONNECTOR</b> .....	<b>363</b>
Diagnosis Procedure .....	324	Removal and Installation .....	363
<b>SUBWOOFER</b> .....	<b>327</b>	<b>SATELLITE RADIO ANTENNA</b> .....	<b>364</b>
Description .....	327	Removal and Installation .....	364
Diagnosis Procedure .....	327	<b>GPS ANTENNA</b> .....	<b>365</b>
<b>AMP ON SIGNAL CIRCUIT</b> .....	<b>330</b>	Removal and Installation .....	365
Diagnosis Procedure .....	330	<b>MICROPHONE</b> .....	<b>366</b>
<b>REAR VIEW CAMERA IMAGE SIGNAL CIR-</b>		Removal and Installation .....	366
<b>CUIT</b> .....	<b>331</b>	<b>REAR VIEW CAMERA</b> .....	<b>367</b>
Diagnosis Procedure .....	331	Removal and Installation .....	367
<b>MICROPHONE SIGNAL CIRCUIT</b> .....	<b>333</b>	<b>REAR CONTROL SWITCH</b> .....	<b>368</b>
Diagnosis Procedure .....	333	Removal and Installation .....	368
<b>STEERING SWITCH</b> .....	<b>335</b>	<b>DVD ENTERTAINMENT SYSTEM</b> .....	<b>369</b>
Diagnosis Procedure .....	335	Removal and Installation .....	369
<b>USB CONNECTOR</b> .....	<b>337</b>		
Diagnosis Procedure .....	337		


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000009876435

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

##### 2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3.

##### 3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[BASE AUDIO]

---

Is malfunctioning part detected?

YES >> GO TO 4.

NO >> GO TO 2.

### 4.REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5.

### 5.FINAL CHECK

---

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Has the symptom been repaired?

YES >> Inspection End.


NO >> GO TO 2.



# SYSTEM DESCRIPTION

## AUDIO SYSTEM

### System Diagram



### System Description

INFOID:000000009876437

#### AUDIO SYSTEM

The audio systems consists of the following components

- Audio unit
- Rod antenna
- Front door speakers
- Front tweeters
- Rear door speakers
- Rear door tweeters (crew cab)

When the audio system is on, radio signals are received by the rod antenna. The audio unit then sends audio signals to the front door speakers, front tweeters, rear door speakers and rear door tweeters (crew cab). Refer to Owner's Manual for audio system operating instructions.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P


# AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BASE AUDIO]

## Component Parts Location

INFOID:000000009876438



AWNIA2764ZZ

- |  |   |   |
|--|---|---|
| 1. Front tweeter LH M109                             | 2. Audio unit M168                                    | 3. Front tweeter RH M111                              |
| 4. Front door speaker<br>LH D12<br>RH D112           | 5. Rear door speaker (crew cab)<br>LH D207<br>RH D307 | 6. Rear door tweeter (crew cab)<br>LH D208<br>RH D308 |
| 7. Rear door speaker (king cab)<br>LH B76<br>RH B159 |   |   |

## Component Description

INFOID:000000009876439

Part name	Description
Audio unit	Controls audio system functions
Front door speakers	<ul style="list-style-type: none"> <li>Outputs audio signal from audio unit</li> <li>Outputs high, mid and low range sounds</li> </ul>
Front tweeters	<ul style="list-style-type: none"> <li>Outputs audio signal from audio unit</li> <li>Outputs high range sounds</li> </ul>

# AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BASE AUDIO]

Part name	Description
Rear door speakers	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit</li><li>• Outputs high, mid and low range sounds</li></ul>
Rear door tweeters (crew cab)	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit</li><li>• Outputs high range sounds</li></ul>

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

**DTC/CIRCUIT DIAGNOSIS**

**POWER SUPPLY AND GROUND CIRCUIT  
AUDIO UNIT**

**AUDIO UNIT : Diagnosis Procedure**

INFOID:000000009876440

Regarding Wiring Diagram information, refer to [AV-23, "Wiring Diagram"](#).

**1.CHECK FUSES**

Check that the following fuses of the audio unit are not are not blown.

Unit	Terminals	Signal name	Fuse No.
Audio unit	19	Battery power	31
	7	Ignition switch ACC or ON	4

Are the fuses OK?


YES >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

**2.POWER SUPPLY CIRCUIT CHECK**

1. Disconnect audio unit connector M168.
2. Check voltage between the audio unit connector M168 ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M168	7	Ground	0V	Battery voltage	Battery voltage
	19	Ground	Battery voltage	Battery voltage	Battery voltage



Are the voltage results as specified?

YES >> Inspection end.

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

**3.GROUND CIRCUIT CHECK**

Inspect audio unit case ground.

Does case ground pass inspection?

YES >> Inspection end.

NO >> Repair audio unit case ground.

# FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

## FRONT DOOR SPEAKER

### Description

INFOID:000000009876441

The audio unit sends audio signals to the front door speakers using the front door speaker circuits.

### Diagnosis Procedure

INFOID:000000009876442

Regarding Wiring Diagram information, refer to [AV-23, "Wiring Diagram"](#).

### 1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2.HARNES CHECK

1. Disconnect audio unit connector M168 and suspect front door speaker connector.
2. Check continuity between audio unit harness connector M168 (A) terminal and suspect front door speaker harness connector (B) terminal.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M168	2	D12	1	Yes
	3		2	
	11	D112	1	
	12		2	

3. Check continuity between audio unit harness connector M168 (A) terminal and ground.


A		—	Continuity
Connector	Terminal		
M168	2	Ground	No
	3		
	11		
	12		

Are continuity results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3.FRONT SPEAKER SIGNAL CHECK




# FRONT DOOR SPEAKER

[BASE AUDIO]


## < DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector M168 and front door speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M168 terminals with CONSULT or oscilloscope.

Con- nector	(+)		(-)		Condition	Reference signal
	Terminal	Terminal	Terminal	Terminal		
M168	2	3	11	12	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	11	12				

Is the audio signal voltage as specified?

- YES >> Replace front door speaker. Refer to [AV-37, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-35, "Removal and Installation"](#).



# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

## FRONT TWEETER

### Description

INFOID:000000009876443

The audio unit sends audio signals to the front tweeters using the front tweeter circuits.

### Diagnosis Procedure

INFOID:000000009876444

Regarding Wiring Diagram information, refer to [AV-23, "Wiring Diagram"](#).

## 1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

## 2.HARNES CHECK

1. Disconnect audio unit connector M168 and suspect front tweeter connector.
2. Check continuity between audio unit harness connector M168 (A) and suspect front tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M168	2	M109	1	Yes
	3		2	
	11	M111	1	
	12		2	

3. Check continuity between audio unit harness connector M168 (A) and ground.


A		—	Continuity
Connector	Terminal		
M168	2	Ground	No
	3		
	11		
	12		

Are the continuity results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

## 3.FRONT TWEETER SIGNAL CHECK




# FRONT TWEETER

## < DTC/CIRCUIT DIAGNOSIS >


[BASE AUDIO]

1. Connect audio unit connector M168 and front tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M168 terminals with CONSULT or oscilloscope.

Con- nector	(+)		(-)		Condition	Reference signal
	Terminal	Terminal	Terminal	Terminal		
M168	2	3	11	12	Receive audio signal	 <p style="text-align: center; font-size: small;">SK1A0177E</p>
	11	12				

Is the audio signal voltage as specified?

- YES >> Replace the suspect front tweeter. Refer to [AV-36, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-35, "Removal and Installation"](#).





# REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

## REAR DOOR SPEAKER

### Description

INFOID:000000009876445

The audio unit sends audio signals to the rear door speakers using the rear door speaker circuits.

### Diagnosis Procedure

INFOID:000000009876446

Regarding Wiring Diagram information, refer to [AV-23, "Wiring Diagram"](#).

## 1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

## 2.HARNES CHECK

1. Disconnect audio unit connector M168 and suspect rear door speaker connector.
2. Check continuity between audio unit harness connector M168 (A) and suspect rear door speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M168	4	D207 (crew cab) B76 (king cab)	1	Yes
	5		2	
	13	D307 (crew cab) B159 (king cab)	1	
	14		2	

3. Check continuity between audio unit harness connector M168 (A) and ground.


A		—	Continuity
Connector	Terminal		
M168	4	Ground	No
	5		
	13		
	14		

Are the continuity results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

## 3.REAR DOOR SPEAKER SIGNAL CHECK




# REAR DOOR SPEAKER

[BASE AUDIO]

## < DTC/CIRCUIT DIAGNOSIS >


1. Connect audio unit connector and rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M168 terminals with CONSULT or oscilloscope.

(+)		(-)		Condition	Reference signal
Connector	Terminal	Terminal	Terminal		
M168	4	5	14	Receive audio signal	
	13	14			

SKIA0177E

Is the audio signal voltage as specified?

- YES >> Replace the suspect rear door speaker. Refer to [AV-38. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-35. "Removal and Installation"](#).



# REAR DOOR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

## REAR DOOR TWEETER

### Description

INFOID:000000009876447

The audio unit sends audio signals to the rear door tweeters using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000009876448

Regarding Wiring Diagram information, refer to [AV-23, "Wiring Diagram"](#).

### 1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2.HARNES CHECK

1. Disconnect audio unit connector M168 and suspect rear door tweeter connector.
2. Check continuity between audio unit harness connector M168 (A) and suspect rear door tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M168	4	D208	1	Yes
	5		2	
	13	D308	1	
	14		2	

3. Check continuity between audio unit harness connector M168 (A) and ground.


A		—	Continuity
Connector	Terminal		
M168	4	Ground	No
	5		
	13		
	14		

Are the continuity results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3.REAR DOOR TWEETER SIGNAL CHECK




# REAR DOOR TWEETER

[BASE AUDIO]


## < DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector and rear door tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M168 terminals with CONSULT or oscilloscope.

Connector	(+) Terminal		(-) Terminal		Condition	Reference signal
	4	5	13	14		
M168	4	5	13	14	Receive audio signal	 <p style="text-align: right; font-size: small;">SK1A0177E</p>

Is the audio signal voltage as specified?

- YES >> Replace the suspect rear door tweeter. Refer to [AV-38, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-35, "Removal and Installation"](#).



# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[BASE AUDIO]


## ECU DIAGNOSIS INFORMATION

### AUDIO UNIT




Reference Value

INFOID:000000009876449

#### TERMINAL LAYOUT




#### PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
2 (L/W)	3 (L/R)	Sound signal front door speaker and front tweeter LH (if equipped)	Output	Ignition switch ON	Audio output	
4 (SB)	5 (B/Y)	Sound signal rear door speaker and rear tweeter LH (if equipped)	Output	Ignition switch ON	Audio output	
7 (V)	Ground	ACC power supply	Input	Ignition switch ACC or ON	—	Battery voltage
9 (R/L)	8 (BR)	Illumination	Input	Ignition switch ACC or ON	Exterior lights ON	Battery voltage
11 (W/B)	12 (L/B)	Sound signal front door speaker and front tweeter RH (if equipped)	Output	Ignition switch ON	Voice output	

# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[BASE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
13 (O/L)	14 (R/L)	Sound signal rear door speaker and rear tweeter RH (if equipped)	Output	Ignition switch ON	Voice output	
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage

# BASE AUDIO SYSTEM

< WIRING DIAGRAM >


[BASE AUDIO]

## WIRING DIAGRAM

### BASE AUDIO SYSTEM

#### Wiring Diagram

INFOID:000000009876450



#### BASE AUDIO SYSTEM

CC : CREW CAB  
KC : KING CAB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV


BASE AUDIO SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	4P	Color of Wire	V	Signal Name	-
--------------	----	---------------	---	-------------	---

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	10	Color of Wire	L/R	Signal Name	-
	11		L/W		-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	7G	Color of Wire	Y	Signal Name	-
--------------	----	---------------	---	-------------	---

ABNIA3960GB




# BASE AUDIO SYSTEM

< WIRING DIAGRAM >


[BASE AUDIO]

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	-
5	W/B	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



11J	12J	13J	14J	15J	16J	17J	18J	19J	20J	21J
22J	23J	24J	25J	26J	27J	28J	29J	30J		
31J	32J	33J	34J	35J	36J	37J	38J	39J	40J	41J
42J	43J	44J	45J	46J	47J	48J	49J	50J		
51J	52J	53J	54J	55J	56J	57J	58J	59J	60J	61J
62J	63J	64J	65J	66J	67J	68J	69J	70J		
71J	72J	73J	74J	75J	76J	77J	78J	79J	80J	81J
82J	83J	84J	85J	86J	87J	88J	89J	90J		
91J	92J	93J	94J	95J						
96J	97J	98J	99J	100J						


Terminal No.	Color of Wire	Signal Name
1J	B/Y	-
7J	SB	-

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



11A	12A	13A	14A	15A	16A	17A	18A	19A	20A	21A
22A	23A	24A	25A	26A	27A	28A	29A	30A		
31A	32A	33A	34A	35A	36A	37A	38A	39A	40A	41A
42A	43A	44A	45A	46A	47A	48A	49A	50A		
51A	52A	53A	54A	55A	56A	57A	58A	59A	60A	61A
62A	63A	64A	65A	66A	67A	68A	69A	70A		
71A	72A	73A	74A	75A	76A	77A	78A	79A	80A	81A
82A	83A	84A	85A	86A	87A	88A	89A	90A		
91A	92A	93A	94A	95A						
96A	97A	98A	99A	100A						

Terminal No.	Color of Wire	Signal Name
3A	O/L	-
4A	R/L	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

ABNIA3961GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# BASE AUDIO SYSTEM


< WIRING DIAGRAM >

[BASE AUDIO]

Terminal No.	Color of Wire	Signal Name
16	-	-
17	-	-
18	-	-
19	Y	-
20	-	-


Terminal No.	Color of Wire	Signal Name
5	B/Y	-
6	-	-
7	V	-
8	BR	-
9	R/L	-
10	-	-
11	W/B	-
12	L/B	-
13	O/L	-
14	R/L	-
15	-	-

Connector No.	M168
Connector Name	AUDIO UNIT (WITH BASE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	-	-
2	L/W	-
3	L/R	-
4	SB	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7G	Y	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABNIA3962GB

# BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]


Connector No.	B76
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-(WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	Y	-(WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
1J	Y	-(KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
1J	B/Y	-(EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
7J	L	-(KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
7J	SB	-(EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	-
15	O/L	-

ABNIA6307GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]


Connector No.	B159
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	– (WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	R/L	–

Terminal No.	Color of Wire	Signal Name
3A	L	– (KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
3A	O/L	– (EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
4A	R/L	–

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	–
5	W/B	–

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	L/R	–
11	L/W	–

ABNIA6308GB

# BASE AUDIO SYSTEM

< WIRING DIAGRAM >


[BASE AUDIO]

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-(WITHOUT NAVI OR MID AUDIO SYSTEM)
2	B/Y	-(WITHOUT NAVI OR MID AUDIO SYSTEM)

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	B/Y	-(WITHOUT NAVI OR MID AUDIO SYSTEM)
15	SB	-(WITHOUT NAVI OR MID AUDIO SYSTEM)

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/L	-(WITHOUT NAVI OR MID AUDIO SYSTEM)
2	R/L	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	-
15	O/L	-(WITHOUT NAVI OR MID AUDIO SYSTEM)

Connector No.	D208
Connector Name	REAR DOOR TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	B/Y	-

ABNIA6309GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]

Connector No.	D308
Connector Name	REAR DOOR TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	O/L	-
2	R/L	-

ABNIA3966GB

# AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

## SYMPTOM DIAGNOSIS

### AUDIO SYSTEM

#### Symptom Table

INFOID:000000009876451

#### AUDIO SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> <li>Audio unit power and ground circuit</li> <li>Audio unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-12</a></li> <li><a href="#">AV-35</a></li> </ul>
All speakers do not sound	<ul style="list-style-type: none"> <li>Speaker circuit shorted to ground</li> <li>Audio unit power and ground circuit</li> <li>Audio unit</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-23</a></li> <li><a href="#">AV-12</a></li> <li><a href="#">AV-35</a></li> </ul>
One or several speakers do not sound	<ul style="list-style-type: none"> <li>Front door speaker</li> <li>Front tweeter</li> <li>Rear door tweeter (crew cab)</li> <li>Rear door speaker</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-13</a></li> <li><a href="#">AV-15</a></li> <li><a href="#">AV-19</a></li> <li><a href="#">AV-17</a></li> </ul>
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

#### CD

Symptom	Possible cause	Reference page
CD cannot be inserted.	Audio unit	<a href="#">AV-35</a>
CD cannot be ejected.		
The CD cannot be played.		
The sound skips, stops suddenly, or is distorted.		

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000009876452

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

### NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

#### NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

#### Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> <li>• Ignition components</li> </ul>
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> <li>• Fuel pump condenser</li> </ul>
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> <li>• Relay malfunction, audio unit malfunction</li> </ul>
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> <li>• Motor case ground</li> <li>• Motor</li> </ul>
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> <li>• Rear defogger coil malfunction</li> <li>• Open circuit in printed heater</li> <li>• Poor ground of antenna feeder line</li> </ul>
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> <li>• Ground wire of body parts</li> <li>• Ground due to improper part installation</li> <li>• Wiring connections or a short circuit</li> </ul>



PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010159250

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000009876454

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# PREPARATION

< PREPARATION >

[BASE AUDIO]

## PREPARATION


### PREPARATION

#### Special Service Tools

INFOID:000000010159255

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components




AWJIA0483ZZ

#### Commercial Service Tools

INFOID:000000009876456

Tool name	Description
Power tool	Loosening nuts, screws and bolts



PHB1407E

## REMOVAL AND INSTALLATION

### AUDIO UNIT


#### Removal and Installation

INFOID:000000009876457

#### AUDIO UNIT

##### Removal

1. Remove the cluster lid C. Refer to [JP-15. "Removal and Installation"](#).
2. Remove the audio unit screws (A), using power tool.
3. Remove the audio unit.
  - a. Pull out the audio unit (1) out of the instrument panel.
  - b. Disconnect the audio unit harness connectors.



##### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P


## FRONT TWEETER

### Removal and Installation

INFOID:000000009876458

#### REMOVAL

1. Remove front tweeter speaker grille, using a suitable tool.
2. Remove the front tweeter clips (A).
3. Disconnect the front tweeter harness connector.
4. Remove the front tweeter (1).



#### Installation

Installation is in the reverse order of removal.

# FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BASE AUDIO]


## FRONT DOOR SPEAKER

### Removal and Installation

INFOID:000000009876459

#### REMOVAL

1. Remove the front door finisher. Refer to [INT-10, "Removal and Installation"](#).
2. Remove the front door speaker screws.
3. Disconnect the front door speaker harness connector.
4. Remove the front door speaker.



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BASE AUDIO]

## REAR DOOR SPEAKER


### Removal and Installation

INFOID:000000009876460

### REAR DOOR SPEAKER

#### Removal

1. Remove the rear door finisher. Refer to [INT-10. "Removal and Installation"](#) (Crew Cab) or [INT-10. "Removal and Installation"](#) (King Cab).
2. Remove the rear door speaker.
  - a. Remove the rear door speaker screws.
  - b. Disconnect the rear door speaker harness connector.




#### Installation

Installation is in the reverse order of removal.

### REAR DOOR TWEETER

#### Removal

1. Remove the rear door finisher. Refer to [INT-10. "Removal and Installation"](#).
2. Remove the rear door tweeter.
  - a. Remove the rear door tweeter screws.
  - b. Disconnect the rear door tweeter harness connector.



#### Installation

Installation is in the reverse order of removal.


# AUDIO ANTENNA

< REMOVAL AND INSTALLATION >

[BASE AUDIO]

## AUDIO ANTENNA

### Location of Antenna



1. Antenna
2. Main feeder cable

### Removal and Installation

INFOID:000000009876462

#### REMOVAL

1. Remove audio antenna rod.
2. Remove audio antenna rubber seal.
3. Remove fender protector RH. Refer to [EXT-24. "Removal and Installation"](#).
4. Remove audio antenna assembly bolts.
5. Disconnect the audio antenna feeder from the audio antenna assembly.
6. Remove audio antenna assembly from the vehicle.

#### INSTALLATION

- Installation is in the reverse order of removal.
- Tighten audio antenna rod to specification.

**Audio antenna rod : 3.5 N·m (0.36 kg·m, 31 in·lb)**

#### CAUTION:

**Always properly tighten the audio antenna rod during installation or the audio antenna rod may bend or break during vehicle operation.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010159251

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for Trouble Diagnosis

INFOID:000000009876464

#### AV COMMUNICATION SYSTEM

- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

#### Precaution for Work

INFOID:000000009876466

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.



# PRECAUTIONS

[MID AUDIO]

< PRECAUTION >

---

- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# PREPARATION

< PREPARATION >

[MID AUDIO]

## PREPARATION


### PREPARATION

#### Special Service Tools

INFOID:000000010159260

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components




AWJIA0483ZZ

#### Commercial Service Tools

INFOID:000000009876468

Tool name	Description
Power tool	Loosening nuts, screws and bolts



PIIB1407E

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[MID AUDIO]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000009876469



AWNTA2765ZZ

- |  |   |   |
|--|---|---|
| 1. Front tweeter LH M109                             | 2. Audio unit M163, M164                              | 3. Front tweeter RH M111                              |
| 4. Front door speaker<br>LH D12<br>RH D112           | 5. Rear door speaker (crew cab)<br>LH D207<br>RH D307 | 6. Rear door tweeter (crew cab)<br>LH D208<br>RH D308 |
| 7. Rear door speaker (king cab)<br>LH B76<br>RH B159 |   |   |

#### Component Description

INFOID:000000009876470

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

## COMPONENT PARTS


< SYSTEM DESCRIPTION >

[MID AUDIO]

Part name	Description
Audio unit	<ul style="list-style-type: none"><li>• Controls audio system functions.</li></ul>
Front door speakers	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit.</li><li>• Outputs high, mid and low range sounds</li></ul>
Front tweeters	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit</li><li>• Outputs high range sounds.</li></ul>
Rear door speakers	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit.</li><li>• Outputs high, mid and low range sounds.</li></ul>
Rear door tweeters (crew cab)	<ul style="list-style-type: none"><li>• Outputs audio signal from audio unit.</li><li>• Outputs high range sounds.</li></ul>
Rod antenna	AM/FM signal is received and transmitted to the audio unit.

## SYSTEM

### System Diagram



INFOID:000000009876471

### System Description

INFOID:000000009876472

#### AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Front door speakers
- Front tweeters
- Rear speakers
- Rear tweeters (crew cab)
- Rod antenna

When the audio system is on, radio signals are received by the rod antenna. The audio unit then sends audio signals to the front door speakers, front tweeters, rear door speakers and rear tweeters (crew cab).

Refer to Owner's Manual for audio system operating instructions.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[MID AUDIO]

## DIAGNOSIS SYSTEM (AUDIO UNIT)

### Diagnosis Description

INFOID:000000009876473

The audio unit on board diagnosis performs the functions listed in the table below:

Mode	Description
Hardware/Software Versions	Hardware and software versions are available for: <ul style="list-style-type: none"> <li>• audio unit.</li> <li>• combination meter</li> </ul> EEPROM version and EQ pin info are also available for the audio unit.
Speaker Channel Check	The connection of the speakers to the audio unit can be confirmed.
Communication Diagnosis	The AV communication (M-CAN) message history can be monitored.


### On Board Diagnosis Function

INFOID:000000009876474


#### METHOD OF STARTING

Hardware/Software Versions and Speaker Channel Check

1. Turn the ignition ON.
2. Turn the audio system OFF.
3. While pressing the preset 1 button, turn the volume control dial clockwise or counterclockwise 30 clicks or more.



4. Initially, all display segments will be illuminated.



5. To exit hardware/software versions and speaker channel check, turn the ignition OFF.

Communication Diagnosis


1. Turn the ignition ON.
2. Turn the audio system OFF.

# DIAGNOSIS SYSTEM (AUDIO UNIT)


[MID AUDIO]

## < SYSTEM DESCRIPTION >

- While pressing the preset 6 button, turn the volume control dial clockwise or counterclockwise 30 clicks or more.



- Initially, the communication diagnosis mode is displayed.




- To exit communication diagnosis, turn the ignition OFF.

## SELF DIAGNOSIS MODE

### Hardware/Software Versions

- Press the DISP button to enter versions display, and the audio head unit software version is displayed.



- With each additional press of the DISP button, the following information is available:

- HARD V##### (hardware version)
  - EEP V##### (EEPROM version)
  - MeterS V##### (combination meter software version)
  - MeterH V##### (combination meter hardware version)
  - @@@@ EQ1-4 # (EQ pin info)
- If an EQ error is present, INVALID EQ is displayed
- BTSOFT ##### (internal Bluetooth® module software version)
  - BTHARD ##### (internal Bluetooth® module hardware version)
  - BTCONF #####00 (internal Bluetooth® module configuration)

- Hold the DISP button down to return to all display segments screen.

### Speaker Channel Check

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV


O  
P

# DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[MID AUDIO]


1. Press the RPT/DRM button to enter speaker channel check, and the front left tweeter (front speaker LH) is displayed.



2. With each additional press of the RPT/DRM button, the following information is available:
  - FR RIGHT TWEETER (front speaker RH)
  - FR RIGHT (front door speaker RH)
  - RR RIGHT (rear speaker RH)
  - RR LEFT (rear speaker LH)
  - FR LEFT (front door speaker LH)
3. Hold the RPT/DRM button down to return to all display segments screen.

## Communication Diagnosis

1. Press the DISP button, and the M-CAN message transmission error history screen is displayed.



2. Press the DISP button again, and the METER \$ \$ n n (CMF message reception error history from M-CAN METER) screen is displayed.
3. Press the DISP button again, and the TROUBLE DEL. (deletion of M-CAN message communication history) screen is displayed. To retain the M-CAN message communication history and return to the communication diagnosis mode screen, press the DISP button.
4. To proceed to the M-CAN message communication history deletion screen, press the SEEK/TRACK  $\Delta$  button. The REC DEL-NO? (selection of M-CAN message communication history deletion) screen is displayed. To cancel M-CAN message communication history deletion, wait 6 seconds and you will be returned to the TROUBLE DEL. (deletion of M-CAN message communication history) screen. To proceed with M-CAN message communication history deletion, press the SEEK/TRACK  $\Delta$  button again.
5. The REC DEL-YES?@ (selection of M-CAN message communication history deletion) screen is displayed. To cancel M-CAN message communication history deletion, press the SEEK/TRACK  $\nabla$  button and you will be returned to the REC DEL-NO? (selection of M-CAN message communication history deletion) screen. To proceed with M-CAN message communication history deletion, wait 6 seconds and the communication history deletion will be executed. After the communication history deletion has been executed, you will be returned to the TROUBLE DEL. (deletion of M-CAN message communication history) screen. To return to the communication diagnosis mode screen, press the DISP button.



# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[MID AUDIO]


## ECU DIAGNOSIS INFORMATION

### AUDIO UNIT

Reference Value

INFOID:000000009876475

### TERMINAL LAYOUT





### PHYSICAL VALUES

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
2 (L/W)	3 (L/R)	Audio sound signal front LH	Output	Ignition switch ON	Receive audio sig- nal	 SKIA0177E
4 (SB)	5 (B/Y)	Audio sound signal rear LH	Output	Ignition switch ON	Receive audio sig- nal	 SKIA0177E
7 (V)	Ground	ACC signal	Input	Ignition switch ON	-	Battery voltage
8 (BR)	Ground	Illumination control signal	Input	Ignition switch ON	Illumination control switch is operated by lighting switch in 1st position.	Changes between 0 and 12V
9 (R/L)	Ground	Illumination signal	Input	OFF	Lighting switch is in 1st position.	Battery voltage
					Lighting switch is OFF.	0V
11 (W/B)	12 (L/B)	Audio sound signal front RH	Output	Ignition switch ON	Receive audio sig- nal	 SKIA0177E

# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[MID AUDIO]


Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
13 (O/L)	14 (R/L)	Audio sound signal rear RH	Output	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
18 (W/R)	Ground	Vehicle speed sig- nal (8-pulse)	Input	Ignition switch ON	When vehicle speed is approx. 40 km/h (25 mph)	 <p style="text-align: right; font-size: small;">PKIA1935E</p>
19 (Y)	Ground	Battery power	Input	-	-	Battery voltage
20 (Y)	-	Ground	-	-	-	0V
21 (B)	Ground	Eq1 port1	-	Ignition switch ON	-	0V
22 (B)	Ground	Eq2 port2	-	Ignition switch ON	-	0V
24 (B)	Ground	Eq4 port4	-	Ignition switch ON	-	0V

# WIRING DIAGRAM

## MID AUDIO SYSTEM

### Wiring Diagram

INFOID:000000009876476



: CREW CAB  
 : KING CAB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV


MID AUDIO SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	4P	Color of Wire	V	Signal Name	-
--------------	----	---------------	---	-------------	---

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	10	Color of Wire	L/R	Signal Name	-
Terminal No.	11	Color of Wire	L/W	Signal Name	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	29	Color of Wire	W/R	Signal Name	SPEED OUT
--------------	----	---------------	-----	-------------	-----------

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABNIA4013GB

# MID AUDIO SYSTEM

< WIRING DIAGRAM >



[MID AUDIO]

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
2	L/B	-
5	W/B	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1J	B/Y	-
7J	SB	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3A	O/L	-
4A	R/L	-

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

ABNIA4014GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]


Terminal No.	Color of Wire	Signal Name
7	V	ACC
8	BR	ILL CONT
9	R/L	LIGHT SW
10	-	-
11	W/B	FR SP RH+
12	L/B	RR SP RH-
13	O/L	RR SP RH+
14	R/L	RR SP RH-
15	-	-
16	-	-
17	-	-
18	W/R	SPEED SIG SSV
19	Y	BACK UP
20	B	GND

Connector No.	M163
Connector Name	AUDIO UNIT (WITH MID AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	L/W	FR SP LH+
3	L/R	FR SP LH-
4	SB	FR SP LH+
5	B/Y	RR SP LH-
6	-	-

Connector No.	M162
Connector Name	JOINT CONNECTOR-M10
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
11	B	-
12	B	-
13	B	-
14	B	-
15	B	-

Terminal No.	Color of Wire	Signal Name
34	-	-
35	-	-
36	-	-

Terminal No.	Color of Wire	Signal Name
23	-	-
24	B	EQ4 PORT4
25	-	-
26	-	-
27	-	-
28	-	-
29	-	-
30	-	-
31	-	-
32	-	-
33	-	-

Connector No.	M164
Connector Name	AUDIO UNIT (WITH MID AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
21	B	EQ1 PORT1
22	B	EQ2 PORT2

ABNIA6310GB


# MID AUDIO SYSTEM

< WIRING DIAGRAM >


[MID AUDIO]




Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	B/Y	-
15	SB	-



Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7G	Y	-

Terminal No.	Color of Wire	Signal Name
1J	Y	- (KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
1J	B/Y	- (EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
7J	L	- (KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
7J	SB	- (EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
7G	Y	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

ABNIA4016GB

# MID AUDIO SYSTEM

< WIRING DIAGRAM >


[MID AUDIO]

Connector No.	B76
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	– (WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	Y	– (WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	–
15	O/L	–

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3A	L	– (KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
3A	O/L	– (EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
4A	R/L	–

Connector No.	B159
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	– (WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	R/L	–

ABNIA6311GB




# MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	L/B	-
5	W/B	-

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	L/R	-
11	L/W	-

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-(WITH NAVI OR MID AUDIO SYSTEM)
2	Y	-(WITH NAVI OR MID AUDIO SYSTEM)

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	Y	-(WITH NAVI OR MID AUDIO SYSTEM)
15	L	-(WITH NAVI OR MID AUDIO SYSTEM)

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

ABNIA6312GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# MID AUDIO SYSTEM

< WIRING DIAGRAM >


[MID AUDIO]

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-(WITH NAVI OR MID AUDIO SYSTEM)
2	R/L	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	-
15	L	-(WITH NAVI OR MID AUDIO SYSTEM)

Connector No.	D208
Connector Name	REAR DOOR TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	B/Y	-

Connector No.	D308
Connector Name	REAR DOOR TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	O/L	-
2	R/L	-

ABNIA6313GB


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000009876477

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

##### 2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

##### 3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O

P

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[MID AUDIO]

---

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

### 4.REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

### 5.FINAL CHECK

---

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Has the symptom been repaired?

YES >> Inspection End.

NO >> GO TO 2

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

#### AUDIO UNIT : Diagnosis Procedure

INFOID:000000009876478

Regarding Wiring Diagram information, refer to [AV-51, "Wiring Diagram"](#).

#### 1. CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
7	ACC power supply	4 (10A)
19	Battery power supply	31 (20A)

#### Are the fuses blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M164.
3. Check voltage between audio unit connector M164 and ground.

Audio unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M164	7	—	Ignition switch: ON	Battery voltage
	19		Ignition switch: OFF	

#### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P



# FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

## FRONT DOOR SPEAKER

### Diagnosis Procedure

INFOID:000000009876479

Regarding Wiring Diagram information, refer to [AV-51. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

### 2. CHECK FRONT DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M164 and suspect front door speaker connector.
2. Check continuity between audio unit connector M164 and suspect front door speaker connector.

Audio unit		Front door speaker		Continuity
Connector	Terminal	Connector	Terminal	
M164	2	D12 (LH)	1	Yes
	3		2	
	11	D112 (RH)	1	
	12		2	

3. Check continuity between audio unit connector M164 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M164	2	—	No
	3		
	11		
	12		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

### 3. CHECK FRONT DOOR SPEAKER SIGNAL


1. Connect audio unit connector M164 and suspect front door speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between audio unit connector M164 and ground.

Audio unit connector M85		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

# FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

2	3	Audio signal output	
11	12		

Is the inspection result normal?

- YES >> Replace front door speaker. Refer to [AV-140. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-137. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

## FRONT TWEETER

### Diagnosis Procedure

INFOID:000000009876480

Regarding Wiring Diagram information, refer to [AV-51. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

### 2. CHECK FRONT TWEETER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M164 and suspect front tweeter connector.
2. Check continuity between audio unit connector M164 and suspect front tweeter connector.

Audio unit		Front tweeter		Continuity
Connector	Terminal	Connector	Terminal	
M164	2	M109 (LH)	1	Yes
	3		2	
	11	M111 (RH)	1	
	12		2	

3. Check continuity between audio unit connector M164 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M164	2	—	No
	3		
	11		
	12		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

### 3. CHECK FRONT TWEETER SIGNAL

1. Connect audio unit connector M164 and suspect front tweeter connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between audio unit connector M164 and ground.


Audio unit connector		Condition	Reference value
(+)	(-)		
Terminal	Terminal		



# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

2	3	Audio signal output	
11	12		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

Is the inspection result normal?

- YES >> Replace front tweeter. Refer to [AV-74. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-73. "Removal and Installation"](#).

AV

O  
P

# REAR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

## REAR SPEAKER

### Description

INFOID:000000009876481

The audio unit sends audio signals to the rear door speakers using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000009876482

Regarding Wiring Diagram information, refer to [AV-51, "Wiring Diagram"](#).

## 1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

## 2.HARNES CHECK

1. Disconnect audio unit connector M164 and suspect speaker connector.
2. Check continuity between audio unit harness connectors M164 and suspect speaker harness connector.

Audio unit		Rear speakers		Continuity
Connector	Terminal	Connector	Terminal	
M164	4	D207 (crew cab) B76 (king cab)	1	Yes
	5		2	
	13	D307 (crew cab) B159 (king cab)	1	
	14		2	

3. Check continuity between audio unit harness connectors M164 and ground.

Connector	Terminal	-	Continuity
M164	4	Ground	No
	5		
	13		
	14		

Are the continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.


## 3.REAR DOOR SPEAKER SIGNAL CHECK

1. Connect audio unit connectors and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connectors M164 terminals with CONSULT or oscilloscope.

# REAR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M164	4	5	Receive audio signal	
	13	14		

Are audio signal voltage readings as specified?

- YES >> Replace suspect speaker. Refer to [AV-76. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-73. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# REAR DOOR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

## REAR DOOR TWEETER

### Description

INFOID:000000009876483

The audio unit sends audio signals to the rear door tweeters using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000009876484

Regarding Wiring Diagram information, refer to [AV-51, "Wiring Diagram"](#).

## 1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

## 2.HARNES CHECK

1. Disconnect audio unit connector M164 and suspect rear door tweeter connector.
2. Check continuity between audio unit harness connectors M164 and suspect rear door tweeter harness connector.

Audio unit		Rear door tweeters		Continuity
Connector	Terminal	Connector	Terminal	
M164	4	D208	1	Yes
	5		2	
	13	D308	1	
	14		2	

3. Check continuity between audio unit harness connectors M164 and ground.

Connector	Terminal	-	Continuity
M164	4	Ground	No
	5		
	13		
	14		

Are the continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.


## 3.REAR DOOR TWEETER SIGNAL CHECK

1. Connect audio unit connectors and suspect rear door tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connectors M164 terminals with CONSULT or oscilloscope.

# REAR DOOR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M164	4	5	Receive audio signal	
	13	14		

Are audio signal voltage readings as specified?

- YES >> Replace suspect rear door tweeter. Refer to [AV-76. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-73. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## SYMPTOM DIAGNOSIS

### AUDIO SYSTEM

#### Symptom Table

INFOID:000000009876485

#### RELATED TO AUDIO

Symptoms	Check items	Probable malfunction location
The disk cannot be removed.	Audio unit	Malfunction in audio unit. Refer to <a href="#">AV-46. "On Board Diagnosis Function"</a> .
No sound comes out or the level of the sound is low.	No sound from all speakers.	<ul style="list-style-type: none"> <li>• Speaker circuit shorted to ground. Refer to <a href="#">AV-51. "Wiring Diagram"</a>.</li> <li>• Audio unit power supply and ground circuits malfunction. Refer to <a href="#">AV-61. "AUDIO UNIT : Diagnosis Procedure"</a>.</li> </ul>
	Only a certain speaker (front door speaker LH, front door speaker RH, front speaker LH, front speaker RH, rear speaker LH, rear speaker RH) does not output sound.	<ul style="list-style-type: none"> <li>• Poor connector connection of speaker.</li> <li>• Sound signal circuit malfunction between audio unit and speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-62. "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-64. "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-66. "Diagnosis Procedure"</a> (rear speaker).</li> <li>- <a href="#">AV-68. "Diagnosis Procedure"</a> (rear door tweeter)</li> </ul> </li> <li>• Malfunction in speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-75. "Removal and Installation"</a> (front door speaker).</li> <li>- <a href="#">AV-74. "Removal and Installation"</a> (front tweeter).</li> <li>- <a href="#">AV-76. "Removal and Installation"</a> (rear speaker).</li> <li>- <a href="#">AV-76. "Removal and Installation"</a> (rear door tweeter)</li> </ul> </li> <li>• Malfunction in audio unit. Refer to <a href="#">AV-46. "On Board Diagnosis Function"</a>.</li> </ul>

# AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[MID AUDIO]

Symptoms	Check items	Probable malfunction location
Noise is mixed with audio.	Noise comes out from all speakers.	Malfunction in audio unit. Refer to <a href="#">AV-46. "On Board Diagnosis Function"</a> .
	Noise comes out only from a certain speaker (front door speaker LH, front door speaker RH, front speaker LH, front speaker RH, rear speaker LH, rear speaker RH).	<ul style="list-style-type: none"> <li>• Poor connector connection of speaker.</li> <li>• Sound signal circuit malfunction between audio unit and speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-62. "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-64. "Diagnosis Procedure"</a> (front speaker).</li> <li>- <a href="#">AV-64. "Diagnosis Procedure"</a> (rear speaker).</li> <li>- <a href="#">AV-68. "Diagnosis Procedure"</a> (rear tweeter).</li> </ul> </li> <li>• Malfunction in speaker.</li> <li>• Poor Installation of speaker (e.g. backlash and looseness). Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-75. "Removal and Installation"</a> (front door speaker).</li> <li>- <a href="#">AV-74. "Removal and Installation"</a> (front tweeter).</li> <li>- <a href="#">AV-76. "Removal and Installation"</a> (rear speaker).</li> <li>- <a href="#">AV-76. "Removal and Installation"</a> (rear tweeter).</li> </ul> </li> <li>• Malfunction in audio unit. Refer to <a href="#">AV-46. "On Board Diagnosis Function"</a>.</li> </ul>
	Noise is mixed with radio only (when the vehicle hits a bump or while driving over bad roads)	Poor connector connection of antenna.
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[MID AUDIO]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000009876486

#### RELATED TO NOISE

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

#### NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

#### Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	• Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		• Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	• Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	• Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		• Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		• Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit



# REMOVAL AND INSTALLATION

## AUDIO UNIT


### Removal and Installation

INFOID:000000009876487

#### AUDIO UNIT

##### Removal

1. Remove the cluster lid C. Refer to [JP-15. "Removal and Installation"](#).
2. Remove the audio unit screws (A), using power tool.
3. Remove the audio unit.
  - a. Pull out the audio unit (1) out of the instrument panel.
  - b. Disconnect the audio unit harness connectors.



##### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# FRONT TWEETER

< REMOVAL AND INSTALLATION >

[MID AUDIO]


## FRONT TWEETER

### Removal and Installation

INFOID:000000009876488

#### REMOVAL

1. Remove front tweeter speaker grille, using a suitable tool.
2. Remove the front tweeter clips (A).
3. Disconnect the front tweeter harness connector.
4. Remove the front tweeter (1).



#### Installation

Installation is in the reverse order of removal.

# FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[MID AUDIO]


## FRONT DOOR SPEAKER

### Removal and Installation

INFOID:000000009876489

#### REMOVAL

1. Remove the front door finisher. Refer to [INT-10. "Removal and Installation"](#).
2. Remove the front door speaker screws.
3. Disconnect the front door speaker harness connector.
4. Remove the front door speaker.



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[MID AUDIO]

## REAR DOOR SPEAKER


### Removal and Installation

INFOID:000000009876490

### REAR DOOR SPEAKER

#### Removal

1. Remove the rear door finisher. Refer to [INT-10. "Removal and Installation"](#) (Crew Cab) or [INT-10. "Removal and Installation"](#) (King Cab).
2. Remove the rear door speaker.
  - a. Remove the rear door speaker screws.
  - b. Disconnect the rear door speaker harness connector.




#### Installation

Installation is in the reverse order of removal.

### REAR DOOR TWEETER

#### Removal

1. Remove the rear door finisher. Refer to [INT-10. "Removal and Installation"](#).
2. Remove the rear door tweeter.
  - a. Remove the rear door tweeter screws.
  - b. Disconnect the rear door tweeter harness connector.



#### Installation

Installation is in the reverse order of removal.

# AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[MID AUDIO]

## AUDIO ANTENNA

### Location of Antenna

INFOID:000000009876491



ALNIA0824GB

1. Antenna
2. Main feeder cable

### Removal and Installation

INFOID:000000009876492

#### REMOVAL

1. Remove audio antenna rod.
2. Remove audio antenna rubber seal.
3. Remove fender protector RH. Refer to [EXT-24. "Removal and Installation"](#).
4. Remove audio antenna assembly bolts.
5. Disconnect the audio antenna feeder from the audio antenna assembly.
6. Remove audio antenna assembly from the vehicle.

#### INSTALLATION

- Installation is in the reverse order of removal.
- Tighten audio antenna rod to specification.

**Audio antenna rod : 3.5 N·m (0.36 kg·m, 31 in-lb)**

#### CAUTION:

**Always properly tighten the audio antenna rod during installation or the audio antenna rod may bend or break during vehicle operation.**

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# PRECAUTIONS

< PRECAUTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010585909

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for Trouble Diagnosis

INFOID:000000009876494

#### AV COMMUNICATION SYSTEM


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

#### Precaution for Harness Repair

INFOID:000000009876495

#### AV COMMUNICATION SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]




PK1A0306E

## PRECAUTIONS

[DISPLAY AUDIO WITHOUT AMPLIFIER]

### < PRECAUTION >

- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



### Precaution for Work

INFOID:000000009876496

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# PREPARATION

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< PREPARATION >


## PREPARATION

### PREPARATION

#### Special Service Tools


INFOID:000000010159261

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set  AWJIA0483ZZ	Removing trim components

#### Commercial Service Tools

INFOID:000000009876498

Tool name	Description
Power tool  PIIB1407E	Loosening nuts, screws and bolts



# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000009876499



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# COMPONENT PARTS

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< SYSTEM DESCRIPTION >

- |   |   |   |
|---|---|---|
| 1. Front tweeter LH M109                              | 2. Steering wheel audio control switches              | 3. Microphone R109                                    |
| 4. Audio unit M165, M166, M167, M189                  | 5. Front tweeter RH M111                              | 6. USB Interface M214                                 |
| 7. Front door speaker<br>LH D12<br>RH D112            | 8. Rear door tweeter (crew cab)<br>LH D208<br>RH D308 | 9. Rear door speaker (crew cab)<br>LH D207<br>RH D307 |
| 10. Rear door speaker (king cab)<br>LH B76<br>RH B159 | 11. Rear view camera T2                               | 12. Bluetooth® control unit B142, B143,<br>B144       |

## Component Description

INFOID:000000009876500

Part name	Description
Audio unit	<ul style="list-style-type: none"> <li>Controls audio, hands-free phone, USB connection, AUX IN connection, satellite radio and rear view camera functions.</li> <li>Display unit is built in to audio unit.</li> </ul>
Front door speakers	Outputs high, mid and low range audio signals from audio unit.
Front speakers	
Rear speakers	
Front tweeters	<ul style="list-style-type: none"> <li>Outputs audio signal from audio unit.</li> <li>Outputs high range sounds.</li> </ul>
Rear tweeters	
Steering switches	<ul style="list-style-type: none"> <li>Operations for audio, hands-free phone and voice recognition are possible.</li> <li>Steering switch signal is output to combination meter.</li> <li>Combination meter outputs steering switch signal to audio unit.</li> </ul>
Microphone	<ul style="list-style-type: none"> <li>Used for hands-free phone operations.</li> <li>Microphone signal is transmitted to audio unit.</li> <li>Power is supplied from audio unit.</li> </ul>
USB interface	USB sound and data input signals are transmitted to audio unit.
Rear view camera	<ul style="list-style-type: none"> <li>Outputs image of vehicle rear to audio unit.</li> <li>Power is supplied from audio unit.</li> </ul>
Satellite antenna	Satellite radio signal is received and transmitted to audio unit.
Rod antenna	AM/FM signal is received and transmitted to the audio unit.


# SYSTEM

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## SYSTEM

### System Diagram



### System Description

INFOID:000000009876502

#### AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Front door speakers
- Front tweeters
- Rear speakers
- Rear tweeters
- Steering switches
- Microphone
- USB interface
- Rear view camera
- Rod antenna

When the audio system is on, AM/FM signals received by the rod antenna and sent to the audio unit. The audio unit then sends audio signals to the front door speakers, front tweeters, rear speakers and rear tweeters.

Refer to Owner's Manual for audio system operating instructions.

#### HANDS-FREE PHONE SYSTEM

System Operation

##### NOTE:

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth<sup>®</sup> telephone system.

The Bluetooth<sup>®</sup> telephone system allows users who have a Bluetooth<sup>®</sup> cellular telephone to make a wireless connection between their cellular telephone and the audio unit. Hands-free cellular telephone calls can be sent and received. Some Bluetooth<sup>®</sup> cellular telephones may not be recognized by the audio unit. When a cellular telephone or the audio unit is replaced, the telephone must be paired with the audio unit. Different cellular telephones may have different pairing procedures, refer to the cellular telephone operating manual.

Refer to the Owner's Manual for Bluetooth<sup>®</sup> telephone system operating instructions.

Audio unit

When the ignition switch is turned to ACC or ON, the audio unit will power up. During power up, the audio unit is initialized and performs various self-checks. Initialization may take up to 20 seconds.

Steering Switches

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## SYSTEM

### < SYSTEM DESCRIPTION >

### [DISPLAY AUDIO WITHOUT AMPLIFIER]

When buttons on the steering switches are pushed, the resistance in steering switches circuits change, depending on which button is pushed.

The following functions can be performed using the steering switches:

- Initiate self-diagnosis of the Bluetooth<sup>®</sup> telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls
- Record memos

#### Microphone

The microphone is located in the roof console assembly. The microphone sends a signal to the audio unit.

#### REAR VIEW CAMERA SYSTEM

- The audio unit supplies power to the rear view camera when the reverse signal is received from the TCM.
- The rear view camera transmits rear view camera images to the audio unit when power is supplied from the audio unit.
- The audio unit combines a warning message and fixed guide lines with an image received from the rear view camera to display a rear view camera image on the screen.

# DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (AUDIO UNIT)

### Description

INFOID:000000009876503

The audio unit on board diagnosis performs the functions listed in the table below:


Mode		Description
Self Diagnosis		<ul style="list-style-type: none"> <li>• Audio unit diagnosis.</li> <li>• Diagnoses the connections across system components.</li> </ul>
Confirmation/ Adjustment	Display Diagnosis	The following check functions are available: color tone check by color bar display and white display, light and shade check by gray scale display.
	Vehicle Signals	Diagnosis of signals can be performed for vehicle speed, lights, reverse, EQ pin, destination and camera type.
	Speaker Test	The connection of a speaker can be confirmed by test tone.
	Error History	The system malfunction and the frequency when occurring in the past are displayed. When the malfunctioning item is selected, the time and place that the selected malfunction last occurred are displayed.
	Camera System	Guiding line position that overlaps rear view camera image can be adjusted.
	AV COMM Diagnosis	The communication condition of each unit of display audio system can be monitored.
	Delete Unit Connection Log	Erase the connection history of unit and error history.
	Initialize Setting	Initializes the audio unit memory.

### On Board Diagnosis Function


INFOID:000000009876504

#### METHOD OF STARTING

1. Turn the ignition ON.
2. Turn the audio system OFF.
3. While pressing the preset 1 button, turn the volume control dial clockwise or counterclockwise for 40 clicks or more. When self-diagnosis mode begins, a short beep will be heard. Shifting from current screen to previous screen is performed by pressing BACK button.



4. The trouble diagnosis initial screen is displayed, and Self Diagnosis or Confirmation/Adjustment can be selected.



#### SELF DIAGNOSIS MODE

##### Audio Unit Self Diagnosis

1. Select Self Diagnosis.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## < SYSTEM DESCRIPTION >


- Self diagnosis screen is displayed. The bar graph visible in center of screen indicates progress of self diagnosis.
- Diagnosis results are displayed after the self diagnosis is completed. The unit names and the connection lines are color coded according to the diagnostic results.



Diagnosis results	Unit	Connection line
Normal	Green	Green
Connection malfunction	Gray	Yellow
Unit malfunction <sup>1</sup>	Red	Green

1: Control unit (audio unit) is displayed in red.

- Replace audio unit if Self Diagnosis did not run because control unit malfunction is indicated. The symptom is audio unit internal error. Refer to [AV-137, "Removal and Installation"](#).
  - If multiple errors occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > gray.
- Comments of self diagnosis results can be viewed in the diagnosis result screen.



## Audio Unit Self Diagnosis Results

Only Unit Part Is Displayed In Red		
Screen switch	Description	Possible cause
Control unit	Malfunction is detected in audio unit power supply and ground circuits.	<ul style="list-style-type: none"> <li>Audio unit power supply or ground circuits. Refer to <a href="#">AV-114, "AUDIO UNIT : Diagnosis Procedure"</a>.</li> <li>If no malfunction is detected in audio unit power supply and ground circuits, replace audio unit. Refer <a href="#">AV-137, "Removal and Installation"</a>.</li> </ul>

A Connecting Cable Between Units Is Displayed In Yellow		
Area with yellow connection lines	Description	Possible cause
Control unit ↔ Meter	When one of the following is detected: <ul style="list-style-type: none"> <li>malfunction is detected in combination meter power supply and ground circuits.</li> <li>malfunction is detected in AV communication circuits between audio unit and combination meter.</li> </ul>	<ul style="list-style-type: none"> <li>Combination meter power supply or ground circuits.</li> <li>AV communication circuits between audio unit and combination meter.</li> </ul>


# DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITHOUT AMPLIFIER]


## < SYSTEM DESCRIPTION >

### Audio Unit Confirmation/Adjustment

1. Select Confirmation/Adjustment.
2. Select each switch on the Confirmation/Adjustment screen to display the relevant trouble diagnosis screen. Press the BACK switch to return to the initial Confirmation/Adjustment screen.




### Display Diagnosis



### Vehicle Signals

A comparison check can be made of each actual vehicle signal and the signals recognized by the system.



### Speaker Test

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

# DIAGNOSIS SYSTEM (AUDIO UNIT)

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

### < SYSTEM DESCRIPTION >

Select Speaker Test to display the Speaker Diagnosis screen. Press Start to generate a test tone in a speaker. Press Start again to generate a test tone in the next speaker. Press End to stop the test tones.



### Error History

The self diagnosis results are judged depending on whether any error occurs from when Self Diagnosis is selected until the self diagnosis results are displayed.

However, the diagnosis results are judged normal if an error has occurred before the ignition switch is turned ON and then no error has occurred until the self diagnosis start. Check the Error Record to detect any error that may have occurred before the self diagnosis start because of this situation.

The frequency of occurrence is displayed in a count up manner. The actual count up method differs depending on the error item.


### Count up method A

- The counter is set to 40 if an error occurs. 1 is subtracted from the counter if the condition is normal at a next ignition ON cycle.
- The counter lower limit is 1. The counter can be reset (no error record display) with the Delete log switch.

### Count up method B

- The counter increases by 1 if an error occurs when ignition switch is ON. The counter will not decrease even if the condition is normal at the next ignition ON cycle.
- The counter upper limit is 50. Any counts exceeding 50 are ignored. The counter can be reset (no error record display) with the Delete log switch.

Display type of occurrence frequency	Error history display item
Count up method A	AV communication line, control unit (AV)
Count up method B	Other than the above



### Error item

Some error items may be displayed simultaneously according to the cause. If some error items are displayed simultaneously, the detection of the cause can be performed by the combination of display items



# DIAGNOSIS SYSTEM (AUDIO UNIT)


[DISPLAY AUDIO WITHOUT AMPLIFIER]

< SYSTEM DESCRIPTION >

Error item	Description	Possible cause
CONTROL UNIT (AV)	AV communication circuit initial diagnosis malfunction is detected.	Replace the audio unit if the malfunction occurs constantly. Refer to <a href="#">AV-137, "Removal and Installation"</a>
AV COMM CIRCUIT	When one of the following is detected: <ul style="list-style-type: none"> <li>malfunction is detected in combination meter power supply and ground circuits.</li> <li>malfunction is detected in AV communication circuits between audio unit and combination meter.</li> </ul>	<ul style="list-style-type: none"> <li>Combination meter power supply or ground circuits.</li> <li>AV communication circuits between audio unit and combination meter.</li> </ul>


## Camera System

This mode is used to adjust the guide line display position of the rear view camera.



## AV COMM Diagnosis

- Displays the communication status between audio unit (master unit) and each unit.
- The error counter displays OK if any malfunction was not detected in the past and displays 0 if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if Reset is pressed.




Items	Status (Current)	Counter (Past)
C Rx(Meter-ITM)	OK / ???	OK / 0 – 39
C Tx(ITM-TW SW)	OK / ???	OK / 0 – 39
C Rx(STW SW-ITM)	OK / ???	OK / 0 – 39

### NOTE:

“???” indicates UNKWN.

## Delete Unit Connection Log

Deletes any unit connection records and error records from the audio unit memory (clears the records of the unit that has been removed).



## Initialize Settings


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< SYSTEM DESCRIPTION >

Deletes data stored from the audio unit.



# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


## ECU DIAGNOSIS INFORMATION

### AUDIO UNIT

Reference Value

INFOID:000000009876505

### TERMINAL LAYOUT






### PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
2 (L/W)	3 (L/R)	Sound signal front speaker LH	Output	ON	Sound output	<p>SKIB3609E</p>
4 (SB)	5 (B/Y)	Sound signal rear speaker LH	Output	ON	Sound output	<p>SKIB3609E</p>
6 (V)	Ground	STRG SW A	Input	ON	Press SEEK DOWN switch. Press SEEK UP switch. Press  switch. Except for above.	0.7 V 1.3 V 2.0 V 3.3 V
7 (V)	Ground	ACC power supply	Input	ACC	—	Battery voltage
8 (BR)	9 (R/L)	Illumination control signal	Input	ON	Headlamps ON	Battery voltage
11 (W/B)	12 (L/B)	Sound signal front speaker RH	Output	ON	Sound output	<p>SKIB3609E</p>

# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
13 (O/L)	14 (R/L)	Sound signal rear speaker RH	Output	ON	Sound output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
15 (R/B)	-	STRG SW ground	Output	-	-	-
16 (G/O)	Ground	STRG SW B	Input	ON	Press SOURCE switch.	0 V
					Press  switch.	0.7 V
					Press VOL UP switch.	1.3 V
					Press VOL DOWN switch	2.0 V
					Except for above.	3.3 V
18 (W/R)	Ground	Vehicle speed signal	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	 <p style="text-align: right; font-size: small;">JSNIA0012GB</p>
19 (Y)	Ground	Battery power supply	Input	OFF	-	Battery voltage
23 (W)	Ground	Camera power supply	Output	ON	When camera image is displayed	6.0 V
					Except for above	0 V
24 (R)	25 (G)	Telephone audio in	-	-	-	0 V
26	-	Telephone shield	-	-	-	-
28 (W/L)	-	M-CAN A+	-	-	-	-
29 (Y/L)	-	M-CAN A-	-	-	-	-
30	-	Multimedia CAN shield	-	-	-	-
31 (B/P)	-	M-CAN B+	-	-	-	-
32 (L/W)	-	M-CAN B-	-	-	-	-
33 (B)	Ground	RV_CAM_GND	-	-	-	-
34 (W)	Ground	RV_CAM_SIG	Output	Ignition switch ACC	Shift selector is in R position	6.0V

# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
35 (R)	Ground	Rear view camera video in (+)	Input	Ignition switch ON	With rear view camera ON	
36	—	Shield	—	—	—	—
41 (Y)	Ground	Telephone ON signal	Input	ON	—	—
44 (G)	—	Camera DET	—	—	—	—
45 (B)	—	EQ 1 Port 1	—	—	—	—
46 (B)	—	EQ 2 Port 2	—	—	—	—
47 (B)	—	EQ 3 Port 3	—	—	—	—
48 (B)	—	EQ4 Port 4	—	—	—	—
50 (G/W)	Ground	Reverse signal	Input	Ignition switch ON	R position	Battery voltage
					Other than R position	0 V
53 (W)	—	V BUS signal	—	—	—	—
54 (G)	—	USB ground	—	—	—	—
55 (L)	—	USB D+	—	—	—	—
56 (R)	—	USB D-	—	—	—	—
57	—	Shield	—	—	—	—
58 (B)	—	Satellite antenna signal	—	—	—	—
59 (B)	—	Shield	—	—	—	—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# BLUETOOTH® CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

## BLUETOOTH® CONTROL UNIT

Reference Value

INFOID:00000009876506

### TERMINAL LAYOUT







### PHYSICAL VALUES

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ output			
1 (Y)	Ground	Battery power	Input	-	-	Battery voltage
2 (V)	Ground	ACC power	Input	Ignition switch ACC/ON	-	Battery voltage
3 (G/R)	Ground	IGN power	Input	Ignition switch ON/ START	-	Battery voltage
4 (B/W)	Ground	Ground	-	Ignition switch ON	-	0V
6	-	MIC Shield	-	-	-	-
7 (B)	8 (R/L)	MIC in signal	Input	-	-	-
9 (G)	10 (R)	Audio out	Output	Ignition switch ACC/ON	Bluetooth® control unit sends audio signal	<p>SKIB3609E</p>
11 (Y)	-	Mute control	Output	-	-	-
12 (R/G)	Ground	Ladder in 1	Input	ACC/ON	Press SEEK DOWN switch.	0.7 V
					Press SEEK UP switch.	1.3 V
					Pressing switch.	2.0 V
					Except for above.	3.3 V

# BLUETOOTH® CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal (wire color)		Description		Condition	Reference value (Approx.)	
+	-	Signal name	Input/ output			
13 (G/W)	Ground	Ladder in 2	Input	ACC/ON	Press SOURCE switch.	0 V
					Press  switch.	0.7 V
					Press VOL UP switch.	1.3 V
					Press VOL DOWN switch	2 V
					Except for above.	3.3 V
14 (Y/R)	-	Ladder in ground	Input	-	-	
15 (GR)	-	LED ind 1	-	-	-	
17 (V)	Ground	Ladder out 1	Output	ACC/ON	Press SEEK DOWN switch.	0.7 V
					Press SEEK UP switch.	1.3 V
					Pressing  switch.	2.0 V
					Except for above.	3.3 V
18 (G/O)	Ground	Ladder out 2	Output	ACC/ON	Press SOURCE switch.	0 V
					Press  switch.	0.7 V
					Press VOL UP switch.	1.3 V
					Press VOL DOWN switch	2 V
					Except for above.	3.3 V
19 (R/B)	Ground	Ladder out ground	Output	-	-	
21 (B)	Ground	Cont 1	-	-	0V	
22 (B)	Ground	Cont 3	-	-	0V	
27 (B)	Ground	Cont 4	-	-	0V	
28 (W/R)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is approx. 40 km/h (25 MPH)	 <p style="text-align: right; font-size: small;">PKIA1935E</p>
29 (R/W)	Ground	Microphone power	Output	Ignition switch ON	-	5V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# BLUETOOTH® CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ output			
33 (B)	-	Bluetooth® anten- na	-	-	-	—
34 (B)	-	Bluetooth® anten- na	-	-	-	—
35 (B)	-	M-CAN (+)	-	-	-	—
36 (P)	-	M-CAN (-)	-	-	-	—
37	-	Shield	-	-	-	—






# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABNWA2328GB


# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >

### DISPLAY AUDIO CONNECTORS WITHOUT AMPLIFIER

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/W	— (WITHOUT NAVI)
5	R/L	— (WITHOUT NAVI)
6	SHIELD	—
12	B	— (WITHOUT NAVI)

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4P	V	—

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	L/R	—
11	L/W	—

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
29	W/R	SPEED OUT

Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24	R/G	— (WITHOUT NAVI)
25	G/W	— (WITHOUT NAVI)
31	Y/R	— (WITHOUT NAVI)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV


# DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


Terminal No.	Color of Wire	Signal Name
44A	G	-
47A	Y	-
48A	R/W	-
49A	R/L	-
50A	B	-
60A	G/W	-
69A	Y/R	-
70A	R/G	-
98A	Y	-
99A	V	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3A	O/L	-
4A	R/L	-
31A	W/R	-
32A	G/R	-
34A	SHIELD	-
35A	P	-
36A	B	-
38A	R/B	-
39A	G/O	-
40A	V	-
41A	SHIELD	-
42A	SHIELD	-
43A	R	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7G	Y	-
11G	G	-
13G	B	-
14G	SHIELD	-
23G	R	-
24G	W	-
27G	G/W	-
64G	R	-
94G	G/W	-
95G	G	-
98G	W/B	-

ABNIA6345GB


# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
1J	B/Y	-
7J	SB	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1Q	G/R	-

Connector No.	M101
Connector Name	JOINT CONNECTOR-M03
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	G/R	-
7	G/R	-
18	V	-
19	V	-
20	V	-

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	-
5	W/B	-

Connector No.	M73
Connector Name	BACK-UP LAMP RELAY
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
2	R	-
3	G	-
5	G/W	-
6	W/B	-
7	Y/R	-

ABNIA3969GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	M102
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
15	B	-
16	R	-
18	BR	-

Connector No.	M162
Connector Name	JOINT CONNECTOR-M10
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
11	B	-
12	B	-
13	B	-
14	B	-
15	B	-
16	B	-

Connector No.	M115
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
2	W	-
3	G	-
4	R	-
6	L	-


ABNIA6346GB

# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >


Connector No.	M166
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
53	W	V BUS
54	G	USB GND
55	L	USB D +
56	R	USB D -
57	SHIELD	SHIELD

Terminal No.	Color of Wire	Signal Name
7	V	ACC
8	BR	ILL (-)
9	R/L	ILL (+), LIGHT SW
10	-	-
11	W/B	FR SP RH+
12	L/B	FR SP RH-
13	O/L	RR SP RH+
14	R/L	RR SP RH-
15	R/B	STRG SW GND
16	G/O	STRG SW B
17	-	-
18	W/R	SPEED SIG SSV
19	Y	BAT
20	B	GND

Connector No.	M165
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	-	-
2	L/W	FR SP LH+
3	L/R	FR SP LH-
4	SB	RR SP LH+
5	B/Y	RR SP LH-
6	V	STRG SW A

Terminal No.	Color of Wire	Signal Name
42	-	-
43	-	-
44	G	CAMERA DET
45	B	EQ1 PORT 1
46	B	EQ2 PORT 2
47	B	EQ3 PORT 3
48	B	EQ4 PORT 4
49	-	-
50	GW	REVERSE SGN
51	-	-
52	-	-

Terminal No.	Color of Wire	Signal Name
28	W/L	MCAN A+
29	Y/L	MCAN A-
30	SHIELD	MULTIMEDIA CAN SHIELD
31	B/P	MCAN B+
32	L/W	MCAN B-
33	B	GND
34	W	CAMERA ON
35	R	COMP+
36	SHIELD	COMP-
37	-	-
38	-	-
39	-	-
40	-	-
41	Y	TEL ON

Connector No.	M167
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	-	-
22	-	-
23	-	-
24	R	TEL I/F -
25	G	TEL I/F +
26	SHIELD	TEL SHIELD
27	-	-

ABN1A6347GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector No.	M189
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
58	B	SAT ANT
59	B	SAT SHIELD

Connector No.	M213
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
2	W	-
3	G	-
4	R	-
6	L	-

Connector No.	M214
Connector Name	USB INTERFACE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-
3	R	-
4	W	-
5	SHIELD	-

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	R	-

Connector No.	E41
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24C	SHIELD	-
25C	W	-
27C	G	-
28C	B	-
29C	R	-

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	G	REVERSE LAMP

ABNIA6355GB




# DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal No.	Color of Wire	Signal Name
7G	Y	-
11G	G	-
13G	B	-
14G	SHIELD	-
23G	R	-
24G	W	-
27G	G/W	-
64G	R	-
94G	G/W	-
95G	G	-
98G	W/B	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
27	W/B	T TOW REV LAMP

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY




Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	O	REV LAMP RLY

Connector No.	F9
Connector Name	A/T ASSEMBLY (FLOOR SHIFT)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
7	R	-

ABNIA6348GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >


Connector No.	C8
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	SHIELD	-
5	G	-
6	B	-


Terminal No.	Color of Wire	Signal Name
24C	SHIELD	-
25C	W	-
27C	G	-
28C	B	-
29C	R	-

Connector No.	C1
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1J	B/Y	- (EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
7J	SB	- (EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	B/Y	-
15	SB	-


ABNIA6349GB

# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	-
15	O/L	-


Connector No.	B76
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-(EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	B/Y	-(EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
6	SHIELD	MIC SHIELD
7	B	MIC IN+
8	R/L	MIC IN-
9	G	AUDIO OUT+
10	R	AUDIO OUT-
11	Y	MUTE CONTROL
12	R/G	LADDER IN 1
13	G/W	LADDER IN 2
14	Y/R	LADDER IN GND
15	-	-
16	-	-
17	V	LADDER OUT 1

Connector No.	B142
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	BATT
2	V	ACC
3	G/R	IGN
4	B/W	GND
5	-	-

Terminal No.	Color of Wire	Signal Name
18	G/O	LADDER OUT 2
19	R/B	LADDER OUT GND
20	-	-
21	B	CONT 2
22	-	-
23	-	-
24	-	-
25	-	-
26	-	-
27	B	CONT 6
28	W/R	SPEED SIGNAL
29	R/W	MIC POWER
30	-	-
31	-	-
32	-	-

ABNIA6350GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV


# DISPLAY AUDIO WITHOUT AMPLIFIER

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
35	B	MCAN + 1
36	P	MCAN - 1
37	SHIELD	MCAN SHIELD 1
38	-	-
39	-	-
40	-	-
41	-	-
42	-	-

Connector No.	B144
Connector Name	BLUETOOTH CONTROL® UNIT
Connector Color	WHITE



Connector No.	B143
Connector Name	BLUETOOTH CONTROL® UNIT
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
33	B	BT ANTENNA
34	SHIELD	BT ANTENNA SHIELD

Terminal No.	Color of Wire	Signal Name
47A	Y	-
48A	R/W	-
49A	R/L	-
50A	B	-
60A	G/W	-
69A	Y/R	-
70A	R/G	-
98A	Y	-
99A	V	-

Terminal No.	Color of Wire	Signal Name
3A	O/L	-(EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
4A	R/L	-
31A	W/R	-
32A	G/R	-
34A	SHIELD	-
35A	P	-
36A	B	-
38A	R/B	-
39A	G/O	-
40A	V	-
41A	SHIELD	-
42A	SHIELD	-
43A	R	-
44A	G	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABNIA6351GB

# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >

Connector No.	T2
Connector Name	REAR VIEW CAMERA
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	B	-
6	SHIELD	-

Connector No.	T1
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	SHIELD	-
5	G	-
6	B	-

Connector No.	B159
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/L	-(EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	R/L	-

Connector No.	R107
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-
4	B	-

Connector No.	R9
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/L	-(WITHOUT NAVI)
2	R/W	-
4	B	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/W	-(WITHOUT NAVI)
5	R/L	-(WITHOUT NAVI)
6	SHIELD	-
12	B	-(WITHOUT NAVI)

ABNIA6352GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]


< WIRING DIAGRAM >

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	L/R	-
11	L/W	-

Connector No.	R109
Connector Name	MICROPHONE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R/L	-
4	R/W	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	B/Y	- (WITHOUT NAVI OR MID AUDIO SYSTEM)
15	SB	- (WITHOUT NAVI OR MID AUDIO SYSTEM)

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	-
5	W/B	-


ABNIA6353GB

# DISPLAY AUDIO WITHOUT AMPLIFIER

## [DISPLAY AUDIO WITHOUT AMPLIFIER]

< WIRING DIAGRAM >

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	-
15	O/L	-(WITHOUT NAVI OR MID AUDIO SYSTEM)

Connector No.	D208
Connector Name	REAR DOOR TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	B/Y	-

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-(WITHOUT NAVI OR MID AUDIO SYSTEM)
2	B/Y	-(WITHOUT NAVI OR MID AUDIO SYSTEM)

Connector No.	D308
Connector Name	REAR DOOR TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	O/L	-
2	R/L	-

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/L	-(WITHOUT NAVI OR MID AUDIO SYSTEM)
2	R/L	-

ABNIA6354GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000009876508

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

##### 2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3.

##### 3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.



# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Is malfunctioning part detected?

YES >> GO TO 4.

NO >> GO TO 2.

## 4.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5.

## 5.FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

#### AUDIO UNIT : Diagnosis Procedure

INFOID:000000009876509

Regarding Wiring Diagram information, refer to [AV-97, "Wiring Diagram"](#).

#### 1. CHECK FUSES

Check that the following fuses of the audio unit are not are not blown.

Unit	Terminals	Signal name	Fuse No.
Audio unit	7	Battery power	4 (10A)
	19	Ignition switch ACC or ON	31 (20A)

##### Is the fuse blown?

YES >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

#### 2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect audio unit connector M165.
2. Check voltage between the audio unit connector M165 and ground.

(+) Connector		Terminal	(-)	OFF	ACC	ON
M165	7	Ground	0V	Battery voltage	Battery voltage	
	19	Ground	Battery voltage	Battery voltage	Battery voltage	

##### Is the inspection result normal?

YES >> GO TO 3.

NO >> • Check connector housing for disconnected or loose terminals.  
• Repair harness or connector.

#### 3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Check continuity between the audio unit connector M165, M167 and ground.

Connector	Terminal	—	Continuity
M167	45 (Mexico)	Ground	Yes
	46 (Crew cab)		
	47 (Mexico or King cab)		
	48 (King cab)		
M165	20		

##### Is the inspection result normal?

YES >> Inspection End.

NO >> Repair audio unit ground.

## BLUETOOTH® CONTROL UNIT

#### BLUETOOTH® CONTROL UNIT : Diagnosis Procedure

INFOID:000000009876510

Regarding Wiring Diagram information, refer to [AV-97, "Wiring Diagram"](#).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## 1. CHECK FUSE

Check that the following fuses for the Bluetooth® control unit are not blown.

Unit	Terminal	Signal name	Fuse No.
Bluetooth® control unit	1	Battery power	31 (20A)
	2	Ignition switch ACC or ON	4 (10A)
	3	Ignition switch ON or START	12 (10A)

Is the fuse blown?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

## 2. CHECK POWER SUPPLY CIRCUIT

Check voltage between Bluetooth® control unit harness connector B142 and ground.

Connector	Terminal	Ignition switch position	Value (Approx.)
B142	1	OFF	Battery voltage
	2	ACC	
	3	ON	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between Bluetooth® control unit and fuse.

## 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector.
3. Check continuity between Bluetooth® control unit harness connector B142 and ground.

Connector	Terminal	—	Continuity
B142	4	Ground	Yes
	21		
	27		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair harness or connector.

## MICROPHONE

### MICROPHONE : Diagnosis Procedure

INFOID:000000009876511

AV

Regarding Wiring Diagram information, refer to [AV-97, "Wiring Diagram"](#).

## 1. CHECK POWER SUPPLY CIRCUIT (MICROPHONE SIDE)

1. Turn ignition switch ON.
2. Check voltage between microphone harness connector R109 and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
R109	4	Ground	5V

Is the inspection result normal?

# POWER SUPPLY AND GROUND CIRCUIT

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.  
NO >> GO TO 2.

## 2.CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

1. Turn ignition switch OFF.
2. Disconnect microphone and Bluetooth® control unit harness connectors.
3. Check continuity between microphone harness connector R109 and Bluetooth® control unit harness connector B142.

Microphone		Bluetooth® control unit		Continuity
Connector	Terminal	Connector	Terminal	
R109	4	B142	29	Yes

4. Check continuity between microphone harness connector R109 terminal 4 and ground.

Microphone		—	Continuity
Connector	Terminal		
R109	4	Ground	No

Is the inspection result normal?

- YES >> Replace the Bluetooth® control unit. Refer to [AV-147, "Removal and Installation"](#).  
NO >> Repair harness or connector.

## 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect microphone harness connector R109 and Bluetooth® control unit harness connector B142.
3. Check continuity between microphone harness connector R109 and Bluetooth® control unit harness connector B142.

Microphone		Bluetooth® control unit		Continuity
Connector	Terminal	Connector	Terminal	
R109	2	B142	8	Yes

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair harness or connector.

# FRONT DOOR SPEAKER

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< DTC/CIRCUIT DIAGNOSIS >

## FRONT DOOR SPEAKER

### Diagnosis Procedure

INFOID:000000009876512

Regarding Wiring Diagram information, refer to [AV-97. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

### 2. CHECK FRONT DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M43 and suspect front door speaker connector.
2. Check continuity between audio unit connector M165 and suspect front door speaker connector.

Audio unit		Front door speaker		Continuity
Connector	Terminal	Connector	Terminal	
M165	2	D12 (LH)	1	Yes
	3		2	
	11	D112 (RH)	1	
	12		2	

3. Check continuity between audio unit connector M165 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M165	2	—	No
	3		
	11		
	12		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

### 3. CHECK FRONT DOOR SPEAKER SIGNAL


1. Connect audio unit connector M165 and suspect front door speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between audio unit connector M165 and ground.

Audio unit connector M43		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

# FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

2	3		
11	12	Audio signal output	

Is the inspection result normal?

- YES >> Replace front door speaker. Refer to [AV-140. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-137. "Removal and Installation"](#).

# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## FRONT TWEETER

### Diagnosis Procedure

INFOID:000000009876513

Regarding Wiring Diagram information, refer to [AV-97. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

### 2. CHECK FRONT TWEETER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M165 and suspect front tweeter connector.
2. Check continuity between audio unit connector M165 and suspect front tweeter connector.

Audio unit		Front tweeter		Continuity
Connector	Terminal	Connector	Terminal	
M165	2	M109 (LH)	1	Yes
	3		2	
	11	M111 (RH)	1	
	12		2	

3. Check continuity between audio unit connector M165 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M165	2	—	No
	3		
	11		
	12		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

### 3. CHECK FRONT TWEETER SIGNAL


1. Connect audio unit connector M165 and suspect front tweeter connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between audio unit connector M165 and ground.

Audio unit connector		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

2	3		
11	12	Audio signal output	

Is the inspection result normal?

- YES >> Replace front tweeter. Refer to [AV-139. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-137. "Removal and Installation"](#).



# REAR DOOR SPEAKER

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< DTC/CIRCUIT DIAGNOSIS >

## REAR DOOR SPEAKER

### Description

INFOID:000000009876514

The audio unit sends audio signals to the rear door speakers using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000009876515

Regarding Wiring Diagram information, refer to [AV-97, "Wiring Diagram"](#).

## 1. CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

## 2. HARNESS CHECK

1. Disconnect audio unit connector M165 and suspect rear door speaker connector.
2. Check continuity between audio unit harness connectors M165 and suspect rear door speaker harness connector.

Audio unit		Rear speakers		Continuity
Connector	Terminal	Connector	Terminal	
M165	4	D207 (crew cab) B76 (king cab)	1	Yes
	5		2	
	13	D307 (crew cab) B159 (king cab)	1	
	14		2	

3. Check continuity between audio unit harness connectors M165 and ground.

Connector	Terminal	-	Continuity
M165	4	Ground	No
	5		
	13		
	14		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

## 3. REAR DOOR SPEAKER SIGNAL CHECK

1. Connect audio unit connectors and suspect rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connectors M166 terminals with CONSULT or oscilloscope.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M165	4	5	Receive audio signal	
	13	14		

SK1A0177E

Is the inspection result normal?

- YES >> Replace suspect rear door speaker. Refer to [AV-141, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-137, "Removal and Installation"](#).

# REAR DOOR TWEETER

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< DTC/CIRCUIT DIAGNOSIS >

## REAR DOOR TWEETER

### Description

INFOID:000000009876516

The audio unit sends audio signals to the rear door tweeters using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000009876517

Regarding Wiring Diagram information, refer to [AV-97, "Wiring Diagram"](#).

### 1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2.HARNES CHECK

1. Disconnect audio unit connector M166 and suspect rear door tweeter connector.
2. Check continuity between audio unit harness connectors M165 and suspect rear door tweeter harness connector.

Audio unit		Rear tweeters		Continuity
Connector	Terminal	Connector	Terminal	
M165	4	D208	1	Yes
	5		2	
	13	D308	1	
	14		2	

3. Check continuity between audio unit harness connectors M165 and ground.

Connector	Terminal	-	Continuity
M166	4	Ground	No
	5		
	13		
	14		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3.REAR DOOR TWEETER SIGNAL CHECK

1. Connect audio unit connectors and suspect rear door tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connectors M165 terminals with CONSULT or oscilloscope.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## REAR DOOR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M166	4	5	Receive audio signal	
	13	14		

SKIA0177E

Is the inspection result normal?

- YES >> Replace suspect rear door tweeter. Refer to [AV-141. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-137. "Removal and Installation"](#).

# REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:00000009876518

Regarding Wiring Diagram information, refer to [AV-97. "Wiring Diagram"](#).

### 1. CHECK REVERSE INPUT SIGNAL

1. Turn ignition switch ON.
2. Shift the selector lever to R (reverse).
3. Check voltage between audio unit connector M167 and ground.

Audio unit		Ground	Condition	Voltage (Approx.)
(+)		(-)		
Connector	Terminal			
M167	50	—	Selector lever in R (reverse)	Battery Voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK CAMERA POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M167 and rear view camera connector.
3. Check continuity between audio unit connector M167 and rear view camera connector T2.

Audio unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M167	34	T2	1	Yes

4. Check continuity between audio unit connector M167 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M167	34		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

### 3. CHECK CAMERA POWER SUPPLY VOLTAGE

1. Connect audio unit connector M167 and rear view camera connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R (reverse).
4. Check voltage between audio unit connector M167 and ground.

Audio unit		Ground	Condition	Voltage (Approx.)
(+)		(-)		
Connector	Terminal			
M167	34	—	Selector lever is in "R".	6.0 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace audio unit. Refer to [AV-137. "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## 4. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M167 and rear view camera connector.
3. Check continuity between audio unit connector M167 and rear view camera connector T2.

Audio unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M167	35	T2	3	Yes

4. Check continuity between audio unit connector M167 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M167	35		No

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Repair or replace harness or connectors.

## 5. CHECK CAMERA GROUND CIRCUIT CONTINUITY

Check continuity between audio unit connector M167 and rear view camera connector T2.


Audio unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M167	33	T2	4	Yes

Is the inspection result normal?

- YES >> GO TO 6.  
 NO >> Repair or replace harness or connectors.

## 6. CHECK CAMERA IMAGE SIGNAL

1. Connect audio unit connector M167 and rear view camera connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R (reverse).
4. Check signal between audio unit connector M167 and ground.

Audio unit		Ground	Condition	Reference value
(+)		(-)		
Connector	Terminal			
M167	35	—	Camera image displayed.	 <p style="font-size: small; text-align: right;">SKIB2251J</p>

Is the inspection result normal?

- YES >> Replace audio unit. Refer to [AV-137, "Removal and Installation"](#).  
 NO >> Replace rear view camera.

# STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## STEERING SWITCH

### Diagnosis Procedure

INFOID:000000009876519

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Disconnect combination switch connector M102.
2. Check resistance between combination switch connector terminals.

Terminal	Signal name	Condition	Resistance (Ω) (Approx.)
16	18	Volume (down) Depress  switch.	1
		Volume (up) Depress  switch.	121
		Phone end Depress  switch.	321
15	18	Source Depress SOURCE switch.	1
		Seek (up) Depress  switch.	121
		Seek (down) Depress  switch.	321
		Phone/Send Depress  switch.	723

Do the steering wheel audio control switches check OK?

YES >> GO TO 2.

NO >> Replace steering wheel audio control switch. Refer to [AV-142. "Removal and Installation"](#).

### 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector B142 and combination switch connector M30.
3. Check continuity between Bluetooth® control unit harness connector B142 and combination switch harness connector M30.

Bluetooth® control unit		Combination switch		Continuity
Connector	Terminal	Connector	Terminal	
B142	12	M30	24	Yes
	14		31	
	13		25	

4. Check continuity between Bluetooth® control unit connector B142 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B142	12	Ground	No
	13		
	14		

Are the continuity results as specified?

YES >> GO TO 3.

NO >> Repair harness.

# STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## 3. SPIRAL CABLE CHECK

Check continuity between combination switch harness connectors M30 and M102.

Combination switch				Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	15	Yes
	31		18	
	25		16	

Does the spiral cable check OK?

YES >> Inspection End.

NO >> Replace spiral cable. Refer to [SR-13, "Removal and Installation"](#).



# MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## MICROPHONE SIGNAL CIRCUIT

### Description

INFOID:000000009876520

Voice signals are transmitted from the microphone to the Bluetooth® control unit using the microphone signal circuits.

### Diagnosis Procedure

INFOID:000000009876521

Regarding Wiring Diagram information, refer to [AV-97, "Wiring Diagram"](#).

### 1. CHECK HARNESS BETWEEN BLUETOOTH® CONTROL UNIT AND MICROPHONE

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector and microphone connector.
3. Check continuity between Bluetooth® control unit harness connector B142 and microphone harness connector R109.

Bluetooth® control unit		Microphone		Continuity
Connector	Terminal	Connector	Terminal	
B142	7	R109	1	Yes
	8		2	
	29		4	

4. Check continuity between Bluetooth® control unit harness connector B142 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B142	7	Ground	No
	8		
	29		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

### 2. CHECK MICROPHONE POWER SUPPLY

1. Connect Bluetooth® control unit connector and microphone connector.
2. Turn ignition switch ON.
3. Check voltage between microphone harness connector R109 terminal 4 and ground.

(+) Terminal		(-) Terminal	Value (Approx.)
Connector	Terminal		
R109	4	Ground	5V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace Bluetooth® control unit. Refer to [AV-147, "Removal and Installation"](#).


### 3. CHECK MICROPHONE SIGNAL

Check signal between Bluetooth® control unit harness connector B142 with CONSULT or and oscilloscope.

# MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector	(+)	(-)	Reference signal
	Terminal	Terminal	
B142	7	8	<p>While speaking into MIC</p>  <p>SKIB3609E</p>

Is the inspection result normal?

- YES >> Replace Bluetooth<sup>®</sup> control unit. Refer to [AV-147. "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-145. "Removal and Installation"](#).

# USB CONNECTOR

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## USB CONNECTOR

### Diagnosis Procedure

INFOID:000000009876522

Regarding Wiring Diagram information, refer to [AV-97. "Wiring Diagram"](#).

#### 1. CHECK USB INTERFACE HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M166 and USB interface connector M214.
3. Check continuity between audio unit connector M166 and USB interface connector M214.

Audio unit		USB interface		Continuity
Connector	Terminal	Connector	Terminal	
M166	53	M214	4	Yes
	54		1	
	55		2	
	56		3	
	57		5	

4. Check continuity between audio unit connector M166 and ground.

Audio unit		—	Continuity
Connector	Terminal		
M166	53	Ground	No
	55		

Is the inspection result normal?

- YES >> Replace the USB interface. Refer to [AV-144. "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# AUDIO SYSTEM

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### AUDIO SYSTEM

#### Symptom Table

INFOID:000000009876523

#### RELATED TO AUDIO

Symptoms	Check items	Probable malfunction location
The disk cannot be removed.	Audio unit	Malfunction in audio unit. Refer to <a href="#">AV-85. "On Board Diagnosis Function"</a> .
No sound comes out or the level of the sound is low.	No sound from all speakers.	<ul style="list-style-type: none"> <li>• Speaker circuit shorted to ground. Refer to <a href="#">AV-97. "Wiring Diagram"</a>.</li> <li>• Audio unit power supply and ground circuits malfunction. Refer to <a href="#">AV-114. "AUDIO UNIT : Diagnosis Procedure"</a>.</li> </ul>
	Only a certain speaker (front door speaker LH, front door speaker RH, front speaker LH, front speaker RH, rear speaker LH, rear speaker RH) does not output sound.	<ul style="list-style-type: none"> <li>• Poor connector connection of speaker.</li> <li>• Sound signal circuit malfunction between audio unit and speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-117. "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-119. "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-121. "Diagnosis Procedure"</a> (rear speaker).</li> <li>- <a href="#">AV-123. "Diagnosis Procedure"</a> (rear tweeter)</li> </ul> </li> <li>• Malfunction in speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-140. "Removal and Installation"</a> (front door speaker).</li> <li>- <a href="#">AV-139. "Removal and Installation"</a> (front tweeter).</li> <li>- <a href="#">AV-141. "Removal and Installation"</a> (rear speaker).</li> <li>- <a href="#">AV-141. "Removal and Installation"</a> (rear tweeter)</li> </ul> </li> <li>• Malfunction in audio unit. Refer to <a href="#">AV-85. "On Board Diagnosis Function"</a>.</li> </ul>

# AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Symptoms	Check items	Probable malfunction location
Noise is mixed with audio.	Noise comes out from all speakers.	Malfunction in audio unit. Refer to <a href="#">AV-85. "On Board Diagnosis Function"</a> .
	Noise comes out only from a certain speaker (front door speaker LH, front door speaker RH, front speaker LH, front speaker RH, rear speaker LH, rear speaker RH).	<ul style="list-style-type: none"> <li>• Poor connector connection of speaker.</li> <li>• Sound signal circuit malfunction between audio unit and speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-117. "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-119. "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-121. "Diagnosis Procedure"</a> (rear speaker).</li> <li>- <a href="#">AV-123. "Diagnosis Procedure"</a> (rear tweeter)</li> </ul> </li> <li>• Malfunction in speaker.</li> <li>• Poor Installation of speaker (e.g. backlash and looseness). Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-140. "Removal and Installation"</a> (front door speaker).</li> <li>- <a href="#">AV-139. "Removal and Installation"</a> (front tweeter).</li> <li>- <a href="#">AV-141. "Removal and Installation"</a> (rear speaker).</li> <li>- <a href="#">AV-141. "Removal and Installation"</a> (rear tweeter)</li> </ul> </li> <li>• Malfunction in audio unit. Refer to <a href="#">AV-85. "On Board Diagnosis Function"</a>.</li> </ul>
	Noise is mixed with radio only (when the vehicle hits a bump or while driving over bad roads)	Poor connector connection of antenna.
No radio reception or poor reception.	<ul style="list-style-type: none"> <li>• Other audio sounds are normal.</li> <li>• Any radio station cannot be received or poor reception is caused even after moving to a service area with good reception (e.g. a place with clear view and no obstacles generating external noises).</li> </ul>	<ul style="list-style-type: none"> <li>• Poor connector connection of antenna.</li> </ul>
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

## RELATED TO HANDS-FREE PHONE

- Before performing diagnosis, confirm that the cellular phone being used by the customer is compatible with the vehicle.
- It is possible that a malfunction is occurring due to a version change of the phone even though the phone is a compatible type. This can be confirmed by changing the cellular phone to another compatible type, and check that it operates normally. It is important to determine whether the cause of the malfunction is the vehicle or the cellular phone.

### Check Compatibility

1. Make sure the customer's Bluetooth® related concern is understood.
2. Verify the customer's concern.

**NOTE:**

The customer's phone may be required, depending upon their concern.

3. Write down the customer's phone brand, model and service provider.

**NOTE:**

It is necessary to know the service provider. On occasion, a given phone may be on the approved list with one provider, but may not be on the approved list with other providers.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P












AV

## AUDIO SYSTEM

[DISPLAY AUDIO WITHOUT AMPLIFIER]

### < SYMPTOM DIAGNOSIS >

4. Go to "www.nissanusa.com/bluetooth".
  - a. Using the website's search engine, find out if the customer's phone is on the approved list.
  - b. If the customer's phone is NOT on the approved list:  
Stop diagnosis here. The customer needs to obtain a Bluetooth® phone that is on the approved list before any further action.
  - c. If the feature related to the customer's concern shows as "N" (not compatible):  
Stop diagnosis here. If the customer still wants the feature to function, they will need to get an approved phone showing the feature as "Y" (compatible) in the "Basic Features".
  - d. If the feature related to the customer's concern shows as "Y" (compatible):  
Perform diagnosis as per the following table.

Symptoms	Check items	Probable malfunction location
Does not recognize cellular phone connection (no connection is displayed on the display at the guide).	Repeat the registration of cellular phone.	
Hands-free phone cannot be established.	<ul style="list-style-type: none"> <li>• Hands-free phone operation can be made, but the communication cannot be established.</li> <li>• Hands-free phone operation can be performed, however, voice between each other cannot be heard during the conversation.</li> </ul>	Malfunction in audio unit. Replace audio unit. Refer to <a href="#">AV-137, "Removal and Installation"</a> .
The other party's voice cannot be heard by hands-free phone.	Check the "microphone speaker" in Inspection & Adjustment Mode if sound is heard.	
Originating sound is not heard by the other party with hands-free phone communication.	Sound operation function is normal.	
	Sound operation function does not work.	Microphone signal circuit malfunction. Refer to <a href="#">AV-129, "Diagnosis Procedure"</a> .
The system cannot be operated.	<ul style="list-style-type: none"> <li>• The voice recognition can be controlled.</li> <li>• Steering switch's , , , and  switch works, but   does not work.</li> </ul>	Steering switch malfunction. Replace steering switch. Refer to <a href="#">AV-142, "Removal and Installation"</a> .
	Steering switch's  ,  ,  ,  , and  switches do not work.	Steering switch signal circuit malfunction. Refer to <a href="#">AV-127, "Diagnosis Procedure"</a> .
	All steering switches do not work.	Steering switch ground circuit malfunction. Refer to <a href="#">AV-127, "Diagnosis Procedure"</a> .

### RELATED TO REAR VIEW CAMERA

Symptoms	Check items	Probable malfunction location
Rear view camera is inoperative.	Reverse signal circuit malfunction.	Reverse signal circuit malfunction between BCM and audio unit. Refer to <a href="#">AV-125, "Diagnosis Procedure"</a> .
	Camera image signal circuit malfunction.	Camera image signal circuit malfunction between rear view camera and audio unit. Refer to <a href="#">AV-125, "Diagnosis Procedure"</a> .
	Rear view camera malfunction.	Replace rear view camera.

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000009876524

#### RELATED TO NOISE

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

#### NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

#### Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> <li>• Ignition components</li> </ul>
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> <li>• Fuel pump condenser</li> </ul>
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> <li>• Relay malfunction, audio unit malfunction</li> </ul>
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> <li>• Motor case ground</li> <li>• Motor</li> </ul>
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> <li>• Rear defogger coil malfunction</li> <li>• Open circuit in printed heater</li> <li>• Poor ground of antenna feeder line</li> </ul>
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> <li>• Ground wire of body parts</li> <li>• Ground due to improper part installation</li> <li>• Wiring connections or a short circuit</li> </ul>

#### RELATED TO HANDS-FREE PHONE

Symptom	Cause and Counter measure
Does not recognize cellular phone connection (No connection is displayed on the display at the guide).	<p>Some Bluetooth<sup>®</sup> enabled cellular phones may not be recognized by the in-vehicle phone module.</p> <p>Refer to "RELATED TO HANDS-FREE PHONE (Check Compatibility)" in <a href="#">AV-132. "Symptom Table"</a>.</p>
Cannot use hands-free phone.	<p>Customer will not be able to use a hands-free phone under the following conditions:</p> <ul style="list-style-type: none"> <li>• The vehicle is outside of the telephone service area.</li> <li>• The vehicle is in an area where it is difficult to receive radio waves; such as in a tunnel, in an underground parking garage, near a tall building or in a mountainous area.</li> <li>• The cellular phone is locked to prevent it from being dialed.</li> </ul> <p><b>NOTE:</b></p> <p>While a cellular phone is connected through the Bluetooth<sup>®</sup> wireless connection, the battery power of the cellular phone may discharge quicker than usual. The Bluetooth<sup>®</sup> Hands-Free Phone System cannot charge cellular phones.</p>

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Symptom	Cause and Counter measure
The other party's voice cannot be heard by hands-free phone.	When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
Poor sound quality.	Do not place the cellular phone in an area surrounded by metal or far away from the in-vehicle phone module to prevent tone quality degradation and wireless connection disruption.



## REMOVAL AND INSTALLATION

### AUDIO UNIT

#### Removal and Installation

INFOID:000000009876525

#### AUDIO UNIT

##### Removal

1. Disconnect the battery negative terminal. Refer to [PG-79, "Removal and Installation"](#).
2. Remove the cluster lid C. Refer to [IP-15, "Removal and Installation"](#).
3. Remove the audio unit.
  - a. Remove the audio unit screws using power tool.
  - b. Pull the audio unit out from the instrument panel.
  - c. Disconnect the harness connectors from the audio unit.

##### Installation

Installation is in the reverse order of removal.

#### AV SWITCH

##### Removal

1. Disconnect battery negative terminal. Refer to [PG-79, "Removal and Installation"](#).
2. Remove the cluster lid C. Refer to [IP-15, "Removal and Installation"](#).
3. Remove the AV switch screws.
4. Carefully remove the AV switch.

##### Installation

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# SATELLITE RADIO ANTENNA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## SATELLITE RADIO ANTENNA


### Removal and Installation

INFOID:000000010159256

### SATELLITE RADIO ANTENNA

#### Removal

1. Lower the headliner. Refer to [INT-21. "Removal and Installation"](#).
2. Disconnect the satellite radio antenna connector.
3. Remove the satellite radio antenna nut.
4. Remove the satellite radio antenna.



LK1A0679E

#### Installation

Installation is in the reverse order of removal.

# FRONT TWEETER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


## FRONT TWEETER

### Removal and Installation

INFOID:000000009876526

#### REMOVAL

1. Remove front tweeter speaker grille, using a suitable tool.
2. Remove the front tweeter clips (A).
3. Disconnect the front tweeter harness connector.
4. Remove the front tweeter (1).



#### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


## FRONT DOOR SPEAKER

### Removal and Installation

INFOID:000000009876527

#### REMOVAL

1. Remove the front door finisher. Refer to [INT-10, "Removal and Installation"](#).
2. Remove the front door speaker screws.
3. Disconnect the front door speaker harness connector.
4. Remove the front door speaker.



#### INSTALLATION

Installation is in the reverse order of removal.

# REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## REAR DOOR SPEAKER


### Removal and Installation

INFOID:000000009876528

### REAR DOOR SPEAKER

#### Removal

1. Remove the rear door finisher. Refer to [INT-10, "Removal and Installation"](#) (Crew Cab) or [INT-10, "Removal and Installation"](#) (King Cab).
2. Remove the rear door speaker.
  - a. Remove the rear door speaker screws.
  - b. Disconnect the rear door speaker harness connector.




#### Installation

Installation is in the reverse order of removal.

### REAR DOOR TWEETER

#### Removal

1. Remove the rear door finisher. Refer to [INT-10, "Removal and Installation"](#).
2. Remove the rear door tweeter.
  - a. Remove the rear door tweeter screws.
  - b. Disconnect the rear door tweeter harness connector.



#### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# STEERING SWITCH


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## STEERING SWITCH

### Removal and Installation

INFOID:000000010159258



1. Steering wheel audio control switches 2. Steering wheel

### STEERING WHEEL AUDIO CONTROL SWITCHES

#### Removal

1. Remove the steering wheel. Refer to [ST-22. "Removal and Installation"](#).
2. Remove the steering wheel rear cover screws and the steering wheel rear cover.
3. Remove the steering wheel switch assembly screws and the steering wheel switches.

#### Installation

Installation is in the reverse order of removal.

# AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## AUDIO ANTENNA

### Location of Antenna

INFOID:000000009876530



1. Antenna

2. Main feeder cable

### Removal and Installation

INFOID:000000009876531

#### REMOVAL

1. Remove audio antenna rod.
2. Remove audio antenna rubber seal.
3. Remove fender protector RH. Refer to [EXT-24. "Removal and Installation"](#).
4. Remove audio antenna assembly bolts.
5. Disconnect the audio antenna feeder from the audio antenna assembly.
6. Remove audio antenna assembly from the vehicle.

#### INSTALLATION

Installation is in the reverse order of removal.  
• Tighten audio antenna rod to specification.

**Audio antenna rod : 3.5 N·m (0.36 kg-m, 31 in-lb)**

#### CAUTION:

**Always properly tighten the audio antenna rod during installation or the audio antenna rod may bend or break during vehicle operation.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## USB CONNECTOR

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

---

### USB CONNECTOR

#### Removal and Installation

INFOID:000000009876532

#### REMOVAL

1. Remove the center console assembly. Refer to [IP-20. "Removal and Installation"](#).
2. Push the pawl from the back of the center console to remove the USB interface.

#### INSTALLATION

Installation is in the reverse order of removal.



# MICROPHONE

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


## MICROPHONE

### Removal and Installation

INFOID:000000009876533

#### REMOVAL

1. Remove the front roof console finisher. Refer to [INT-21](#), "[Removal and Installation](#)".
2. Remove the Bluetooth microphone (1)
  - a. Disconnect the Bluetooth microphone harness connector (A).
  - b. Detach the Bluetooth microphone (1) from the front roof console finisher.



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

## TEL ANTENNA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

---

### TEL ANTENNA

#### Removal and Installation

INFOID:000000009876534

The Bluetooth antenna and the Bluetooth control unit are serviced as an assembly. Refer to [AV-147, "Removal and Installation"](#).

# BLUETOOTH CONTROL UNIT

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

## BLUETOOTH CONTROL UNIT


### Removal and Installation

INFOID:000000009876535

#### REMOVAL

1. Disconnect the negative battery terminal.
2. Slide the front RH seat forward.
3. Remove the Bluetooth control unit kick shield screws and the Bluetooth control unit kick shield.
4. Remove the Bluetooth control unit (1).
  - a. Remove the Bluetooth control unit screws (A).
  - b. Disconnect the harness connectors from the Bluetooth control unit.

↔: Front



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

## REAR VIEW CAMERA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

---

### REAR VIEW CAMERA

#### Removal and Installation

INFOID:000000009876536

#### REMOVAL

1. Remove the tail gate handle. Refer to [DLK-137, "Exploded View"](#).
2. Remove the rear view camera screws and the rear view camera from the tail gate handle.

#### INSTALLATION

Installation is in the reverse order of removal.

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010159253

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Trouble Diagnosis

INFOID:000000009876538

AV COMMUNICATION SYSTEM


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

Precaution for Harness Repair

INFOID:000000009876539

AV COMMUNICATION SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

## PRECAUTIONS

< PRECAUTION >

[DISPLAY AUDIO WITH AMPLIFIER]

- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



### Precaution for Work

INFOID:000000009876540

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

# PREPARATION

< PREPARATION >

[DISPLAY AUDIO WITH AMPLIFIER]


## PREPARATION

### PREPARATION

#### Special Service Tools


INFOID:000000010159262

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set  AWJIA0483ZZ	Removing trim components

#### Commercial Service Tools

INFOID:0000000009876542

Tool name	Description
Power tool  PIIB1407E	Loosening nuts, screws and bolts

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[DISPLAY AUDIO WITH AMPLIFIER]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000009876543




AWNIA2767ZZ



# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]



A  
B  
C  
D  
E  
F  
G  
H  
I

- |  |  |   |
|--|--|---|
| 1. Front tweeter LH M109                               | 2. Steering wheel audio control switches   | 3. Center speaker M110                                |
| 4. Microphone R109                                     | 5. Audio unit M171, M172, M175, M188       | 6. Front tweeter RH M111                              |
| 7. USB Interface M214                                  | 8. Front door speaker<br>LH D12<br>RH D112 | 9. Rear door tweeter (crew cab)<br>LH D208<br>RH D308 |
| 10. Rear door speaker (crew cab)<br>LH D207<br>RH D307 | 11. Subwoofer B72                          | 12. Audio amp. M112, M113                             |
| 13. Rear door speaker (king cab)<br>LH B76<br>RH B159  | 14. Rear view camera T2                    | 15. Bluetooth® control unit B142, B143,<br>B144       |

## Component Description

INFOID:000000009876544


Part name	Description
Audio unit	<ul style="list-style-type: none"> <li>Controls audio, hands-free phone, USB connection, AUX IN connection, satellite radio and rear view camera functions.</li> <li>Display unit is built in to audio unit.</li> </ul>
Audio amp.	Receives audio signals from audio unit and outputs audio signals to each speaker.
Front speakers	Outputs high, mid and low range audio signals from audio amp.
Center speaker	
Front door speakers	
Rear door speakers	
Rear speakers	
Steering switches	<ul style="list-style-type: none"> <li>Operations for audio, hands-free phone and voice recognition are possible.</li> <li>Steering switch signal is output to combination meter.</li> <li>Combination meter outputs steering switch signal to audio unit.</li> </ul>
Microphone	<ul style="list-style-type: none"> <li>Used for hands-free phone operations.</li> <li>Microphone signal is transmitted to audio unit.</li> <li>Power is supplied from audio unit.</li> </ul>
USB interface	USB sound and data input signals are transmitted to audio unit.
Rear view camera	<ul style="list-style-type: none"> <li>Outputs image of vehicle rear to audio unit.</li> <li>Power is supplied from audio unit.</li> </ul>
Satellite antenna	Satellite radio signal is received and transmitted to audio unit.
Antenna amp.	<ul style="list-style-type: none"> <li>AM/FM signal received by window antenna is amplified and transmitted to audio unit.</li> <li>Power is supplied from audio unit.</li> </ul>
Window antenna	AM/FM signal is received and transmitted to antenna amp.

J  
K  
L  
M  
AV  
O  
P

## SYSTEM

### System Diagram

INFOID:000000009876545



AWNIA2776GB

### System Description

INFOID:000000009876546

#### AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Audio amp.
- Front speakers
- Center speaker
- Front door speakers
- Rear door speakers
- Rear speakers
- Steering switches
- Microphone
- USB interface
- Rear view camera
- satellite antenna
- Antenna amp.
- Window antenna

When the audio system is on, AM/FM signals received by the window antenna are amplified by the antenna amp. and sent to the audio unit. The audio unit then sends audio signals to the audio amp. The audio amp. then sends audio signals to the front speakers, center speaker, front door speakers, rear door speakers and rear speakers.

Refer to Owner's Manual for audio system operating instructions.

#### HANDS-FREE PHONE SYSTEM

##### System Operation

**NOTE:**

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth® telephone system.

The Bluetooth® telephone system allows users who have a Bluetooth® cellular telephone to make a wireless connection between their cellular telephone and the audio unit. Hands-free cellular telephone calls can be sent and received. Some Bluetooth® cellular telephones may not be recognized by the audio unit. When a cellular telephone or the audio unit is replaced, the telephone must be paired with the audio unit. Different cellular telephones may have different pairing procedures, refer to the cellular telephone operating manual.

Refer to the Owner's Manual for Bluetooth® telephone system operating instructions.

Audio unit

# SYSTEM

## < SYSTEM DESCRIPTION >

## [DISPLAY AUDIO WITH AMPLIFIER]

When the ignition switch is turned to ACC or ON, the audio unit will power up. During power up, the audio unit is initialized and performs various self-checks. Initialization may take up to 20 seconds.

A

### Steering Switches

When buttons on the steering switches are pushed, the resistance in steering switches circuits change, depending on which button is pushed.

B

The following functions can be performed using the steering switches:

- Initiate self-diagnosis of the Bluetooth<sup>®</sup> telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls
- Record memos

C

D

### Microphone

The microphone is located in the roof console assembly. The microphone sends a signal to the audio unit.

### REAR VIEW CAMERA SYSTEM

E

- The audio unit supplies power to the rear view camera when the reverse signal is received.
- The rear view camera transmits rear view camera images to the audio unit when power is supplied from the audio unit.
- The audio unit combines a warning message and fixed guide lines with an image received from the rear view camera to display a rear view camera image on the screen.

F

G

H

I

J

K

L

M

AV

O

P

# DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

## DIAGNOSIS SYSTEM (AUDIO UNIT)

### Description

INFOID:000000009876547

The audio unit on board diagnosis performs the functions listed in the table below:


Mode		Description
Self Diagnosis		<ul style="list-style-type: none"> <li>• Audio unit diagnosis.</li> <li>• Diagnoses the connections across system components.</li> </ul>
Confirmation/ Adjustment	Display Diagnosis	The following check functions are available: color tone check by color bar display and white display, light and shade check by gray scale display.
	Vehicle Signals	Diagnosis of signals can be performed for vehicle speed, lights, reverse, EQ pin, destination and camera type.
	Speaker Test	The connection of a speaker can be confirmed by test tone.
	Error History	The system malfunction and the frequency when occurring in the past are displayed. When the malfunctioning item is selected, the time and place that the selected malfunction last occurred are displayed.
	Camera System	Guiding line position that overlaps rear view camera image can be adjusted.
	AV COMM Diagnosis	The communication condition of each unit of display audio system can be monitored.
	Delete Unit Connection Log	Erase the connection history of unit and error history.
	Initialize Setting	Initializes the audio unit memory.

### On Board Diagnosis Function


INFOID:000000009876548

#### METHOD OF STARTING

1. Turn the ignition ON.
2. Turn the audio system OFF.
3. While pressing the preset 1 button, turn the volume control dial clockwise or counterclockwise for 40 clicks or more. When self-diagnosis mode begins, a short beep will be heard. Shifting from current screen to previous screen is performed by pressing BACK button.



4. The trouble diagnosis initial screen is displayed, and Self Diagnosis or Confirmation/Adjustment can be selected.



#### SELF DIAGNOSIS MODE

##### Audio Unit Self Diagnosis


1. Select Self Diagnosis.

# DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITH AMPLIFIER]

< SYSTEM DESCRIPTION >

- Self diagnosis screen is displayed. The bar graph visible in center of screen indicates progress of self diagnosis.
- Diagnosis results are displayed after the self diagnosis is completed. The unit names and the connection lines are color coded according to the diagnostic results.




Diagnosis results	Unit	Connection line
Normal	Green	Green
Connection malfunction	Gray	Yellow
Unit malfunction <sup>1</sup>	Red	Green

1: Control unit (audio unit) is displayed in red.

- Replace audio unit if Self Diagnosis did not run because control unit malfunction is indicated. The symptom is audio unit internal error. Refer to [AV-228, "Removal and Installation"](#).
- If multiple errors occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > gray.

- Comments of self diagnosis results can be viewed in the diagnosis result screen.



## Audio Unit Self Diagnosis Results

Only Unit Part Is Displayed In Red		
Screen switch	Description	Possible cause
Control unit	Malfunction is detected in audio unit power supply and ground circuits.	<ul style="list-style-type: none"> <li>Audio unit power supply or ground circuits. Refer to <a href="#">AV-192, "AUDIO UNIT : Diagnosis Procedure"</a>.</li> <li>If no malfunction is detected in audio unit power supply and ground circuits, replace audio unit. Refer to <a href="#">AV-228, "Removal and Installation"</a>.</li> </ul>

A Connecting Cable Between Units Is Displayed In Yellow		
Area with yellow connection lines	Description	Possible cause
Control unit ↔ Meter	When one of the following is detected: <ul style="list-style-type: none"> <li>malfunction is detected in combination meter power supply and ground circuits.</li> <li>malfunction is detected in AV communication circuits between audio unit and combination meter.</li> </ul>	<ul style="list-style-type: none"> <li>Combination meter power supply or ground circuits. Refer to <a href="#">MWI-33, "COMBINATION METER : Diagnosis Procedure"</a>.</li> <li>AV communication circuits between audio unit and combination meter.</li> </ul>


# DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITH AMPLIFIER]


## < SYSTEM DESCRIPTION >

### Audio Unit Confirmation/Adjustment

1. Select Confirmation/Adjustment.
2. Select each switch on the Confirmation/Adjustment screen to display the relevant trouble diagnosis screen. Press the BACK switch to return to the initial Confirmation/Adjustment screen.




### Display Diagnosis



### Vehicle Signals

A comparison check can be made of each actual vehicle signal and the signals recognized by the system.




### Speaker Test

# DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITH AMPLIFIER]

## < SYSTEM DESCRIPTION >

Select Speaker Test to display the Speaker Diagnosis screen. Press Start to generate a test tone in a speaker. Press Start again to generate a test tone in the next speaker. Press End to stop the test tones.



### Error History

The self diagnosis results are judged depending on whether any error occurs from when Self Diagnosis is selected until the self diagnosis results are displayed.

However, the diagnosis results are judged normal if an error has occurred before the ignition switch is turned ON and then no error has occurred until the self diagnosis start. Check the Error Record to detect any error that may have occurred before the self diagnosis start because of this situation.

The frequency of occurrence is displayed in a count up manner. The actual count up method differs depending on the error item.


#### Count up method A

- The counter is set to 40 if an error occurs. 1 is subtracted from the counter if the condition is normal at a next ignition ON cycle.
- The counter lower limit is 1. The counter can be reset (no error record display) with the Delete log switch.

#### Count up method B

- The counter increases by 1 if an error occurs when ignition switch is ON. The counter will not decrease even if the condition is normal at the next ignition ON cycle.
- The counter upper limit is 50. Any counts exceeding 50 are ignored. The counter can be reset (no error record display) with the Delete log switch.

Display type of occurrence frequency	Error history display item
Count up method A	AV communication line, control unit (AV)
Count up method B	Other than the above



### Error item

Some error items may be displayed simultaneously according to the cause. If some error items are displayed simultaneously, the detection of the cause can be performed by the combination of display items

# DIAGNOSIS SYSTEM (AUDIO UNIT)


< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

Error item	Description	Possible cause
CONTROL UNIT (AV)	AV communication circuit initial diagnosis malfunction is detected.	Replace the audio unit if the malfunction occurs constantly. Refer to <a href="#">AV-228, "Removal and Installation"</a> .
AV COMM CIRCUIT	When one of the following is detected: <ul style="list-style-type: none"> <li>malfunction is detected in combination meter power supply and ground circuits.</li> <li>malfunction is detected in AV communication circuits between audio unit and combination meter.</li> </ul>	<ul style="list-style-type: none"> <li>Combination meter power supply or ground circuits. Refer to <a href="#">MWI-33, "COMBINATION METER : Diagnosis Procedure"</a>.</li> <li>AV communication circuits between audio unit and combination meter.</li> </ul>

## Camera System

This mode is used to adjust the guide line display position of the rear view camera.




## AV COMM Diagnosis

- Displays the communication status between audio unit (master unit) and each unit.
- The error counter displays OK if any malfunction was not detected in the past and displays 0 if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if Reset is pressed.

Items	Status (Current)	Counter (Past)
C Rx(Meter-ITM)	OK / ???	OK / 0 - 39
C Tx(ITM-TW SW)	OK / ???	OK / 0 - 39
C Rx(STW SW-ITM)	OK / ???	OK / 0 - 39


### NOTE:

"???" indicates UNKWN.



## Delete Unit Connection Log

Deletes any unit connection records and error records from the audio unit memory (clears the records of the unit that has been removed).



## Initialize Settings




# DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

Deletes data stored from the audio unit.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]


## ECU DIAGNOSIS INFORMATION

### AUDIO UNIT

Reference Value

INFOID:000000009876549

### TERMINAL LAYOUT










### PHYSICAL VALUES

Terminal (Wire color)		Description	Input/ Output	Condition		Reference value (Approx.)
+	-			Ignition switch	Operation	
1 (G/W)	Ground	Amp. ON signal	Output	ACC	—	Battery voltage
2 (Y)	3 (BR)	Sound signal front speaker LH	Output	ON	Sound output	 SKIB3609E
4 (BR)	5 (B/R)	Sound signal rear speaker LH	Output	ON	Sound output	 SKIB3609E
6 (V)	15 (R/B)	Steering switch signal A	Input	Ignition switch ON	Keep pressing SOURCE switch.	0 V
					Keep pressing MENU UP switch.	1.0 V
					Keep pressing MENU DOWN switch.	2.0 V
					Keep pressing  switch	3.0 V
					Keep pressing ENTER switch.	4.0 V
					Except for above.	5.0 V
7 (V)	Ground	ACC power supply	Input	ACC	—	Battery voltage
9 (R/L)	8 (BR)	Illumination control signal	Input	ON	Headlamps ON	Battery voltage

# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]


Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
11 (W)	12 (B)	Sound signal front speaker RH	Output	ON	Sound output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
13 (L)	14 (B/W)	Sound signal rear speaker RH	Output	ON	Sound output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
16 (G/O)	15 (R/B)	Steering switch signal B	Input	Ignition switch ON	Keep pressing VOL DOWN switch.	0 V
					Keep pressing VOL UP switch.	1.0 V
					Keep pressing  switch.	2.0 V
					Keep pressing  switch.	3.0 V
					Except for above.	5.0 V
18 (W/R)	Ground	Vehicle speed signal	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	 <p style="text-align: right; font-size: small;">JSNIA0012GB</p>
19 (Y)	Ground	Battery power supply	Input	OFF	—	Battery voltage
20 (B)	Ground	Ground	—	ON	—	0 V
24 (R)	—	TEL I/F —	Input	ON	—	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
25 (G)	—	TEL I/F +	Input	ON	—	 <p style="text-align: right; font-size: small;">SKIB3609E</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (Wire color)		Description	Condition			Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
26	Shield	TEL shield	—	—	—	0 V
28 (W/L)	—	M-CAN (A+)	Input/ Output	—	—	—
29 (Y/L)	—	M-CAN (A-)	Input/ Output	—	—	—
30	Shield	Multimedia CAN shield	—	—	—	—
31 (B/P)	—	M-CAN (B+)	Input/ Output	—	—	—
32 (L/W)	—	M-CAN (B-)	Input/ Output	—	—	—
33 (B)	Ground	Ground	—	ON	—	0 V
34 (W)	—	Camera ON	Input/ Output	—	—	—
35 (R)	Ground	Rear view camera video in (+)	Input	Ignition switch ON	With rear view camera ON	
36	Shield	Comp -	Input/ Output	—	—	—
41 (Y)	Ground	Tel ON	—	ON	—	0 V
44 (G)	Ground	Camera det	—	ON	—	0 V
45 (B)	Ground	EQ2 port 2	—	ON	—	0 V
46 (B)	Ground	EQ2 port 2	—	ON	—	0 V
47 (B)	Ground	EQ3 port 3	—	ON	—	0 V
48 (B)	Ground	EQ4 port 4	—	ON	—	0 V
50 (G/W)	Ground	Reverse signal	Input	ON	Selector lever in R (re- verse)	Battery voltage
					Selector lever in any position other than R (reverse)	0 V
53 (W)	—	V BUS signal	—	—	—	—
54 (G)	—	USB ground	—	—	—	—
55 (L)	—	USB D+ signal	—	—	—	—
56 (R)	—	USB D- signal	—	—	—	—
57	—	Shield	—	—	—	—

# AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
58 (B)	—	Satellite antenna signall	—	—	—	—
59 (B)	—	Shield	—	—	—	—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# AUDIO AMP

< ECU DIAGNOSIS INFORMATION >


[DISPLAY AUDIO WITH AMPLIFIER]

## AUDIO AMP

Reference Value

INFOID:000000009876550

### TERMINAL LAYOUT









### PHYSICAL VALUES

Terminal (wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
1 (Y)	Ground	Battery	Input	-	-	Battery voltage
2 (W)	18 (B)	Subwoofer	Output	Ignition switch ON	Receive audio sig- nal	 SKIA0177E
3 (BR/W)	19 (BR)	Subwoofer	Output	Ignition switch ON	Receive audio sig- nal	 SKIA0177E
4 (B)	Ground	Ground	-	Ignition switch ON	-	-
9 (G/W)	Ground	Amp. ON signal	Input	Ignition switch ON	-	More than 6.5V
10 (L/W)	26 (L/B)	Center speaker	Output	Ignition switch ON	Receive audio sig- nal	 SKIA0177E

# AUDIO AMP

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]





Terminal (wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
11 (SB)	27 (B/Y)	Rear door speaker LH and rear door tweeter LH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
12 (O/L)	28 (R/L)	Rear door speaker RH and rear door tweeter RH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
13 (W/B)	29 (L/B)	Front door tweeter RH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
14 (L/W)	30 (L/R)	Front tweeter LH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
15 (L/W)	31 (L/R)	Front door speaker LH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
16 (W/B)	32 (L/B)	Front door speaker RH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
17 (Y/G)	Ground	Battery	Input	-	-	Battery voltage
20 (B)	Ground	Ground	-	Ignition switch ON	-	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AUDIO AMP

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
21 (W)	5 (B)	Audio sound sig- nal front RH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
22 (Y)	6 (BR)	Audio sound sig- nal front LH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
23 (L)	7 (B/W)	Audio sound sig- nal rear RH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
24 (BR)	8 (B/R)	Audio sound sig- nal rear LH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>



# BLUETOOTH® CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[DISPLAY AUDIO WITH AMPLIFIER]

## BLUETOOTH® CONTROL UNIT

Reference Value

INFOID:000000009876551

### TERMINAL LAYOUT




### PHYSICAL VALUES

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/output			
1 (Y)	Ground	Battery power	Input	-	-	Battery voltage
2 (V)	Ground	ACC power	Input	Ignition switch ACC/ON	-	Battery voltage
3 (G/R)	Ground	IGN power	Input	Ignition switch ON/ START	-	Battery voltage
4 (B/W)	Ground	Ground	-	Ignition switch ON	-	0V
6	-	MIC Shield	-	-	-	-
7 (B)	8 (R/L)	MIC in signal	Input	-	-	-
9 (G)	10 (R)	Audio out	Output	Ignition switch ACC/ON	Bluetooth® control unit sends audio signal	<p style="text-align: right; font-size: small;">SKIB3609E</p>
11 (Y)	-	Mute control	Output	-	-	-
12 (R/G)	Ground	Ladder in 1	Input	ACC/ON	Press SEEK DOWN switch.	0.7 V
					Press SEEK UP switch.	1.3 V
					Pressing  switch.	2.0 V
					Except for above.	3.3 V

# BLUETOOTH® CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/out-put			
13 (G/W)	Ground	Ladder in 2	Input	ACC/ON	Press SOURCE switch.	0 V
					Press  switch.	0.7 V
					Press VOL UP switch.	1.3 V
					Press VOL DOWN switch	2 V
					Except for above.	3.3 V
14 (Y/R)	-	Ladder in ground	Input	-	-	-
17 (V)	Ground	Ladder out 1	Output	ACC/ON	Press SEEK DOWN switch.	0.7 V
					Press SEEK UP switch.	1.3 V
					Pressing  switch.	2.0 V
					Except for above.	3.3 V
18 (G/O)	Ground	Ladder out 2	Output	ACC/ON	Press SOURCE switch.	0 V
					Press  switch.	0.7 V
					Press VOL UP switch.	1.3 V
					Press VOL DOWN switch	2 V
					Except for above.	3.3 V
19 (R/B)	Ground	Ladder out ground	Output	-	-	-
21 (B)	Ground	Cont 1	-	-	-	0V
22 (B)	Ground	Cont 3	-	-	-	0V
27 (B)	Ground	Cont 4	-	-	-	0V
28 (W/R)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is approx. 40 km/h (25 MPH)	
29 (R/W)	Ground	Microphone power	Output	Ignition switch ON	-	5V
33 (B)	-	Bluetooth® antenna	-	-	-	-
34	Shield	Bluetooth® antenna	-	-	-	-
35 (B)	-	M-CAN (+)	-	-	-	-

PKIA1935E

# BLUETOOTH® CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/out- put			
36 (P)	-	M-CAN (-)	-	-	-	—
37	-	Shield	-	-	-	—

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# DISPLAY AUDIO WITH AMPLIFIER

[DISPLAY AUDIO WITH AMPLIFIER]


< WIRING DIAGRAM >

## WIRING DIAGRAM

### DISPLAY AUDIO WITH AMPLIFIER

#### Wiring Diagram

INFOID:000000009876552




\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PA SECTION.

ABNWA2324GB

# DISPLAY AUDIO WITH AMPLIFIER

[DISPLAY AUDIO WITH AMPLIFIER]

< WIRING DIAGRAM >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

- ◁ CC ▷ : CREW CAB
- ◁ KC ▷ : KING CAB
- ◁ KM ▷ : FOR MEXICO OR KING CAB



ABNWA2326GB


# DISPLAY AUDIO WITH AMPLIFIER

[DISPLAY AUDIO WITH AMPLIFIER]

< WIRING DIAGRAM >

## DISPLAY AUDIO CONNECTORS WITH AMPLIFIER

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R/W	– (WITHOUT NAVI)
5	R/L	– (WITHOUT NAVI)
6	SHIELD	–
12	B	– (WITHOUT NAVI)

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4P	V	–
16P	Y/G	–

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	L/R	–
11	L/W	–

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
29	W/R	SPEED OUT

Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24	R/G	– (WITHOUT NAVI)
25	G/W	– (WITHOUT NAVI)
31	Y/R	– (WITHOUT NAVI)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]


Terminal No.	Color of Wire	Signal Name
43A	R	-
44A	G	-
47A	Y	-
48A	R/W	-
49A	R/L	-
50A	B	-
60A	G/W	-
69A	Y/R	-
70A	R/G	-
98A	Y	-
99A	V	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3A	O/L	-
4A	R/L	-
31A	W/R	-
32A	G/R	-
34A	SHIELD	-
35A	P	-
36A	B	-
38A	R/B	-
39A	G/O	-
40A	V	-
41A	SHIELD	-
42A	SHIELD	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7G	Y	-
11G	G	-
13G	B	-
14G	SHIELD	-
23G	R	-
24G	W	-
27G	G/W	-
64G	R	-
94G	G/W	-
95G	G	-
98G	W/B	-

ABNIA6332GB




# DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITH AMPLIFIER]

Terminal No.	Color of Wire	Signal Name
1J	B/Y	-
7J	SB	-
92J	BR	-
93J	B	-
94J	W	-
96J	BR/W	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1Q	G/R	-

Connector No.	M101
Connector Name	JOINT CONNECTOR-M03
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	G/R	-
7	G/R	-
18	V	-
19	V	-
20	V	-

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	-
5	W/B	-

Connector No.	M73
Connector Name	BACK-UP LAMP RELAY
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
2	R	-
3	G	-
5	G/W	-
6	W/B	-
7	Y/R	-

ABNIA6333GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector No.	M110
Connector Name	CENTER SPEAKER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/B	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	M102
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
15	B	-
16	R	-
18	BR	-

Connector No.	M112
Connector Name	AUDIO AMP.
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	BAT
2	W	WOOFER 1+
3	BR/W	WOOFER 2+
4	B	GND
17	Y/G	BAT
18	B	WOOFER 1-
19	BR	WOOFER 2-
20	B	GND

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

ABNIA6334GB

# DISPLAY AUDIO WITH AMPLIFIER


[DISPLAY AUDIO WITH AMPLIFIER]

< WIRING DIAGRAM >


Terminal No.	Color of Wire	Signal Name
29	L/B	FR RH TW-
30	L/R	FR LH TW-
31	L/R	FR LH OUT-
32	L/B	FR RH OUT-

Terminal No.	Color of Wire	Signal Name
13	W/B	FR RH TW+
14	L/W	FR LH TW+
15	L/W	FR LH OUT+
16	W/B	FR RH OUT+
21	W	FR RH IN+
22	Y	FR LH IN+
23	L	RR RH IN+
24	BR	RR LH IN+
25	-	-
26	L/B	CIR OUT-
27	B/Y	RR LH OUT
28	R/L	RR RH OUT-

Connector No.	M113
Connector Name	AUDIO AMP.
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	B	FR RH IN-
6	BR	FR LH IN-
7	B/W	RR RH IN-
8	B/R	RR LH IN-
9	G/W	AMP ON
10	L/W	CIR OUT+
11	SB	RR LH OUT+
12	O/L	RR RH OUT+



Connector No.	M115
Connector Name	WIRE TO WIRE
Connector Color	GRAY

Connector No.	M162
Connector Name	JOINT CONNECTOR-M10
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
2	W	-
3	G	-
4	R	-
6	L	-

Terminal No.	Color of Wire	Signal Name
2	SHIELD	-
11	B	-
12	B	-
13	B	-
14	B	-
15	B	-
16	B	-

ABNIA6335GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# DISPLAY AUDIO WITH AMPLIFIER

## [DISPLAY AUDIO WITH AMPLIFIER]

< WIRING DIAGRAM >


Connector No.	M171
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/W	AMP ON
2	Y	FR SP LH+
3	BR	FR SP LH-
4	BR	RR SP LH+
5	B/R	RR SP LH-
6	V	STRG SW A
7	V	ACC


Terminal No.	Color of Wire	Signal Name
8	BR	ILL (-)
9	R/L	ILL (+), LIGHT SW
10	-	-
11	W	FR SP RH+
12	B	FR SP RH-
13	L	RR SP RH+
14	B/W	RR SP RH-
15	R/B	STRG SW GND
16	G/O	STRG SW B
17	-	-
18	W/R	SPEED SIG SSV
19	Y	BAT
20	B	GND

Connector No.	M172
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
53	W	V BUS
54	G	USB GND
55	L	USB D +
56	R	USB D -
57	SHIELD	SHIELD

Connector No.	M175
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	-	-
22	-	-
23	-	-
24	R	TEL I/F -
25	G	TEL I/F +
26	SHIELD	TEL SHIELD
27	-	-
28	W/L	MCAN A+

Terminal No.	Color of Wire	Signal Name
29	Y/L	MCAN A-
30	SHIELD	MULTIMEDIA CAN SHIELD
31	B/P	MCAN B+
32	L/W	MCAN B-
33	B	GND
34	W	CAMERA ON
35	R	COMP+
36	SHIELD	COMP-
37	-	-
38	-	-
39	-	-
40	-	-
41	Y	TEL ON
42	-	-
43	-	-
44	G	CAMERA DET

Terminal No.	Color of Wire	Signal Name
45	B	EQ2 PORT 2
46	B	EQ2 PORT 2
47	B	EQ3 PORT 3
48	B	EQ4 PORT 4
49	-	-
50	G/W	REVERSE SGN
51	-	-
52	-	-


ABNIA6336GB

# DISPLAY AUDIO WITH AMPLIFIER

## [DISPLAY AUDIO WITH AMPLIFIER]


< WIRING DIAGRAM >

Connector No.	M214
Connector Name	USB INTERFACE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-
3	R	-
4	W	-
5	SHIELD	-

Connector No.	M213
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
2	W	-
3	G	-
4	R	-
6	L	-


Connector No.	M188
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
58	B	SAT ANT
59	B	SAT SHIELD

Terminal No.	Color of Wire	Signal Name
24C	SHIELD	-
25C	W	-
27C	G	-
28C	B	-
29C	R	-

Connector No.	E41
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	R	-

ABNIA6337GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



AV

# DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >



[DISPLAY AUDIO WITH AMPLIFIER]

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	27	Color of Wire	W/B	Signal Name	T TOW REV LAMP
--------------	----	---------------	-----	-------------	----------------

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE

Terminal No.	16	Color of Wire	G	Signal Name	REVERSE LAMP
--------------	----	---------------	---	-------------	--------------


Connector No.	F9
Connector Name	AT ASSEMBLY (FLOOR SHIFT)
Connector Color	GREEN

Terminal No.	7	Color of Wire	R	Signal Name	-
--------------	---	---------------	---	-------------	---

Terminal No.	Color of Wire	Signal Name
7G	Y	-
11G	G	-
13G	B	-
14G	SHIELD	-
23G	R	-
24G	W	-
27G	G/W	-
64G	R	-
94G	G/W	-
95G	G	-
98G	W/B	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABNIA6338GB

# DISPLAY AUDIO WITH AMPLIFIER

[DISPLAY AUDIO WITH AMPLIFIER]



< WIRING DIAGRAM >

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY

Terminal No.	Color of Wire	Signal Name
7	O	REV LAMP RLY

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
13	R	-



Connector No.	C8
Connector Name	WIRE TO WIRE
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	SHIELD	-
5	G	-
6	B	-

Terminal No.	Color of Wire	Signal Name
24C	SHIELD	-
25C	W	-
27C	G	-
28C	B	-
29C	R	-

Connector No.	C1
Connector Name	WIRE TO WIRE
Connector Color	GRAY

AANIA2357GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV


# DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITH AMPLIFIER]

Terminal No.	Color of Wire	Signal Name
1J	B/Y	– (EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
7J	SB	– (EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
92J	BR	–
93J	B	–
94J	W	–
96J	BR/W	–

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	B/Y	–
15	SB	–

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	–
15	O/L	–

Connector No.	B76
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	– (EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	B/Y	– (EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)

Connector No.	B72
Connector Name	SUBWOOFER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	–
2	B	–
3	BR/W	–
4	BR	–

ABNIA6339GB



# DISPLAY AUDIO WITH AMPLIFIER


## [DISPLAY AUDIO WITH AMPLIFIER]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
20	-	-
21	B	CONT 2
22	B	CONT 3
23	-	-
24	-	-
25	-	-
26	-	-
27	B	CONT 6
28	W/R	SPEED SIGNAL
29	R/W	MIC POWER
30	-	-
31	-	-
32	-	-


Terminal No.	Color of Wire	Signal Name
7	B	MIC IN+
8	R/L	MIC IN-
9	G	AUDIO OUT+
10	R	AUDIO OUT-
11	Y	MUTE CONTROL
12	R/G	LADDER IN 1
13	G/W	LADDER IN 2
14	Y/R	LADDER IN GND
15	-	-
16	-	-
17	V	LADDER OUT 1
18	G/O	LADDER OUT 2
19	R/B	LADDER OUT GND

Connector No.	B142
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	BATT
2	V	ACC
3	G/R	IGN
4	B/W	GND
5	-	-
6	SHIELD	MIC SHIELD

Connector No.	B144
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
35	B	MCAN + 1
36	P	MCAN - 1
37	SHIELD	MCAN SHIELD 1
38	-	-
39	-	-
40	-	-
41	-	-
42	-	-

Connector No.	B143
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
33	B	BT ANTENNA
34	SHIELD	BT ANTENNA SHIELD

AANIA2389GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3A	O/L	-(EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
4A	R/L	-
31A	W/R	-
32A	G/R	-
34A	SHIELD	-
35A	P	-
36A	B	-
38A	R/B	-
39A	G/O	-
40A	V	-
41A	SHIELD	-

Terminal No.	Color of Wire	Signal Name
42A	SHIELD	-
43A	R	-
44A	G	-
47A	Y	-
48A	R/W	-
49A	R/L	-
50A	B	-
60A	G/W	-
69A	Y/R	-
70A	R/G	-
98A	Y	-
99A	V	-

Connector No.	B159
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/L	-(EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	R/L	-

Connector No.	T1
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	SHIELD	-
5	G	-
6	B	-

Connector No.	T2
Connector Name	REAR VIEW CAMERA
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	B	-
6	SHIELD	-

# DISPLAY AUDIO WITH AMPLIFIER

[DISPLAY AUDIO WITH AMPLIFIER]


< WIRING DIAGRAM >

Connector No.	R107
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-
4	B	-

Connector No.	R9
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/L	-(WITHOUT NAVI)
2	R/W	-
4	B	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R/W	-(WITHOUT NAVI)
5	R/L	-(WITHOUT NAVI)
6	SHIELD	-
12	B	-(WITHOUT NAVI)

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	L/R	-
11	L/W	-

Connector No.	R109
Connector Name	MICROPHONE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R/L	-
4	R/W	-

ABNIA6341GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# DISPLAY AUDIO WITH AMPLIFIER

[DISPLAY AUDIO WITH AMPLIFIER]

< WIRING DIAGRAM >

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	B/Y	– (WITHOUT NAVI OR MID AUDIO SYSTEM)
15	SB	– (WITHOUT NAVI OR MID AUDIO SYSTEM)

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W/B	–
2	L/B	–

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	–
5	W/B	–

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	–
15	O/L	– (WITHOUT NAVI OR MID AUDIO SYSTEM)

Connector No.	D208
Connector Name	REAR DOOR TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	SB	–
2	B/Y	–

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	– (WITHOUT NAVI OR MID AUDIO SYSTEM)
2	B/Y	– (WITHOUT NAVI OR MID AUDIO SYSTEM)

ABNIA6342GB

# DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

Connector No.	D308
Connector Name	REAR DOOR TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	O/L	-
2	R/L	-

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/L	- (WITHOUT NAVI OR MID AUDIO SYSTEM)
2	R/L	-

ABNIA6343GB


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000009876553

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

##### 2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

##### 3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[DISPLAY AUDIO WITH AMPLIFIER]

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

## 4.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

## 5.FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

#### AUDIO UNIT : Diagnosis Procedure

INFOID:000000009876554

Regarding Wiring Diagram information, refer to [AV-172, "Wiring Diagram"](#).

#### 1. CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
7	ACC power supply	4 (10A)
19	Battery power supply	31 (20A)

##### Are the fuses blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M171.
3. Check voltage between audio unit connector M171 and ground.

Audio unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M171	7	—	Ignition switch: ON	Battery voltage
	19		Ignition switch: OFF	

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

#### 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connectors M171 and M175.
3. Check continuity between audio unit connectors and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M171	20	—	Yes
M175	45 (Crew cab)		
	46 (King cab)		
	47 (King cab or Mexico)		
	48 (King cab)		

##### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

#### AUDIO AMP



# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## AUDIO AMP : Diagnosis Procedure

INFOID:00000009876555

Regarding Wiring Diagram information, refer to [AV-172, "Wiring Diagram"](#).

### 1.CHECK FUSE

Check that the audio amp. fuses are not blown.

Unit	Terminal	Signal name	Fuse No.
Audio amp.	1	Battery power	31
	17		17

Are the fuses OK?


YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio amp. connector.
3. Check voltage between audio amp. harness connector M112 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
M112	1	Ground	Battery voltage
	17		



Is battery voltage present?


YES >> GO TO 3.

NO >> Check harness between audio amp. and fuse.

### 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio amp. connector.
3. Check continuity between audio amp. harness connector M112 and ground.

Connector	Terminal	—	Continuity
M112	4	Ground	Yes
	20		



Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.

## BLUETOOTH® CONTROL UNIT

### BLUETOOTH® CONTROL UNIT : Diagnosis Procedure

INFOID:00000009876556

Regarding Wiring Diagram information, refer to [AV-172, "Wiring Diagram"](#).

### 1.CHECK FUSE

Check that the following fuses for the Bluetooth® control unit are not blown.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Unit	Terminal	Signal name	Fuse No.
Bluetooth® control unit	1	Battery power	31
	2	Ignition switch ACC or ON	4
	3	Ignition switch ON or START	12

**Is inspection result OK?**


YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

## 2.CHECK POWER SUPPLY CIRCUIT

Check voltage between Bluetooth® control unit harness connector B142 and ground.

Connector	Terminal	Ignition switch position	Value (Approx.)
B142	1	OFF	Battery voltage
	2	ACC	
	3	ON	



**Is battery voltage present as specified?**

YES >> GO TO 3.

NO >> Check harness between Bluetooth® control unit and fuse.

## 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector.
3. Check continuity between Bluetooth® control unit harness connector B142 and ground.

Connector	Terminal	—	Continuity
B142	4	Ground	Yes
	21		
	22		
	27		

**Are continuity results as specified?**

YES >> Inspection End.

NO >> Repair harness or connector.

# FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## FRONT DOOR SPEAKER

### Diagnosis Procedure

INFOID:000000009876557

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2. SPEAKER HARNESS CHECK

1. Disconnect audio amp. connector M113 and suspect front door speaker connector.
2. Check continuity between audio amp. harness connector M113 (A) and suspect front door speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M113	15	D12	1	Yes
	31		2	
	16	D112	1	
	32		2	

3. Check continuity between audio amp. harness connector M113 (A) and ground.


A		—	Continuity
Connector	Terminal		
M113	15	Ground	No
	31		
	16		
	32		

Are continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. FRONT DOOR SPEAKER SIGNAL CHECK



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P


# FRONT DOOR SPEAKER

## < DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

1. Connect audio amp. connector M113 and suspect front door speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connector M113 terminals with CONSULT or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
M113	15	31	Receive audio signal	
	16	32		



Is audio signal voltage as specified?

YES >> Replace suspect front door speaker. Refer to [AV-232](#).  
"Removal and Installation".

NO >> GO TO 4.

### 4. PRE-AMP HARNESS CHECK

1. Disconnect audio unit connector M171 and audio amp. connector M113.
2. Check continuity between audio unit harness connector M171 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M171	3	M113	6	Yes
	2		22	
	12		5	
	11		21	

3. Check continuity between audio unit harness connector M171 and ground.

Connector	Terminal	—	Continuity
M171	3	Ground	No
	2		
	12		
	11		

Are continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.


### 5. PRE-AMP SIGNAL CHECK

1. Connect audio unit connector and audio amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M171 terminals with CONSULT or oscilloscope.

# FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M171	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

YES >> Replace audio amp. Refer to [AV-236. "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-228. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## FRONT TWEETER

### Diagnosis Procedure

INFOID:000000009876558

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2. HARNESS CHECK

1. Disconnect audio amp. connector M113 and suspect front tweeter connector.
2. Check continuity between audio amp. harness connector M113 (A) and suspect front tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M113	14	M109	1	Yes
	30		2	
	13	M111	1	
	29		2	

3. Check continuity between audio amp. harness connector M113 (A) and ground.


A		—	Continuity
Connector	Terminal		
M113	14	Ground	No
	30		
	13		
	29		

Are continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. FRONT TWEETER SIGNAL CHECK




ALNIA0722GB

# FRONT TWEETER

## < DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

1. Connect audio amp. connector M113 and suspect front tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connector M113 terminals with CONSULT or oscilloscope.



Connector	Terminal		Condition	Reference signal
	(+)	(-)		
M113	14	30	Receive audio signal	
	13	29		

Is audio signal voltage as specified?

YES >> Replace suspect front tweeter. Refer to [AV-230](#).  
["Removal and Installation"](#).

NO >> GO TO 4.

### 4. PRE-AMP HARNESS CHECK

1. Disconnect audio unit connector M171 and audio amp. connector M113.
2. Check continuity between audio unit harness connector M171 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M171	3	M113	6	Yes
	2		22	
	12		5	
	11		21	

3. Check continuity between audio unit harness connector M171 and ground.

Connector	Terminal	—	Continuity
M171	3	Ground	No
	2		
	12		
	11		

Are continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

### 5. PRE-AMP SIGNAL CHECK

1. Connect audio unit connector and audio amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M171 terminals with CONSULT or oscilloscope.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M171	2	3	Receive audio signal	
	11	12		

SK1A0177E

Are the audio signal voltage readings as specified?

- YES >> Replace audio amp. Refer to [AV-236, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-228, "Removal and Installation"](#).



# CENTER SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## CENTER SPEAKER

### Diagnosis Procedure

INFOID:000000009876559

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2. CENTER SPEAKER HARNESS CHECK

1. Disconnect audio amp. connector M113 and center speaker connector M110.
2. Check continuity between audio amp. harness connector M113 (A) and center speaker harness connector M110 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M113	10	M110	1	Yes
	26		2	

3. Check continuity between audio amp. harness connector M113 (A) and ground.

A		—	Continuity
Connector	Terminal		
M113	10	Ground	No
	26		



Are continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. CENTER SPEAKER SIGNAL CHECK

1. Connect audio amp. connector M113 and center speaker connector M110.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connector M113 terminals with CONSULT or oscilloscope.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# CENTER SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M113	10	26	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>

Is the audio signal voltage reading as specified?

- YES >> Replace center speaker. Refer to [AV-231, "Removal and Installation"](#).  
 NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect audio unit connector M171 and audio amp. connector M113.
2. Check continuity between audio unit harness connector M171 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M171	3	M113	6	Yes
	2		22	
	12		5	
	11		21	

3. Check continuity between audio unit harness connector M171 and ground.


Connector	Terminal	—	Continuity
M171	3	Ground	No
	2		
	12		
	11		

Are continuity test results as specified?

- YES >> GO TO 5.  
 NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

## 5. PRE-AMP SIGNAL CHECK

1. Connect audio unit connector and audio amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M171 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M171	2	3	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	11	12		

Are the audio signal voltage readings as specified?

## CENTER SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

---

YES >> Replace audio amp. Refer to [AV-236, "Removal and Installation"](#).  
NO >> Replace audio unit. Refer to [AV-228, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## REAR DOOR SPEAKER

### Diagnosis Procedure

INFOID:00000009876560

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2. SPEAKER HARNESS CHECK

1. Disconnect audio amp. connectors M113 and suspect rear door speaker connector.
2. Check continuity between audio amp. harness connectors M113 (A) and suspect rear door speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M113	11	D207 (crew cab) B76 (king cab)	1	Yes
	27		2	
	12	D307 (crew cab) B159 (king cab)	1	
	28		2	

3. Check continuity between audio amp. harness connectors M113 (A) and ground.


Connector	Terminal	-	Continuity
M113	11	Ground	No
	27		
	12		
	28		

Are the continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. SPEAKER SIGNAL CHECK



# REAR DOOR SPEAKER


## < DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

1. Connect audio amp. connectors and suspect rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connectors M113 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M113	11	27	Receive audio signal	
	12	28		

SKIA0177E



Are audio signal voltage readings as specified?

YES >> Replace suspect rear door speaker. Refer to [AV-233](#), "[Removal and Installation](#)".

NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect audio unit connector M171 and audio amp. connector M113.
2. Check continuity between audio unit harness connector M171 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M171	5	M113	8	Yes
	4		24	
	14		7	
	13		23	

3. Check continuity between audio unit harness connector M171 and ground.

Connector	Terminal	—	Continuity
M171	5	Ground	No
	4		
	14		
	13		

Are the continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 5. PRE-AMP SIGNAL CHECK

1. Connect audio unit connector M171 and audio amp. connector M113.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M171 terminals with CONSULT or oscilloscope.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M171	4	5	Receive audio signal	
	13	14		

Is the audio signal voltage reading as specified?

- YES >> Replace audio amp. Refer to [AV-236, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-228, "Removal and Installation"](#).

# REAR DOOR TWEETER

[DISPLAY AUDIO WITH AMPLIFIER]

< DTC/CIRCUIT DIAGNOSIS >

## REAR DOOR TWEETER

### Diagnosis Procedure

INFOID:000000009876561

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2. TWEETER HARNESS CHECK

1. Disconnect audio amp. connectors M113 and suspect rear door tweeter connector.
2. Check continuity between audio amp. harness connectors M113 (A) and suspect rear door tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M113	11	D208	1	Yes
	27		2	
	12	D308	1	
	28		2	

3. Check continuity between audio amp. harness connectors M113 (A) and ground.


A		-	Continuity
Connector	Terminal		
M113	11	Ground	No
	27		
	12		
	28		

Are the continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. TWEETER SIGNAL CHECK




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P


# REAR DOOR TWEETER

## < DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

1. Connect audio amp. connectors and suspect rear door tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connectors M113 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M113	11	27	Receive audio signal	 <small>SKIA0177E</small>
	12	28		



Are audio signal voltage readings as specified?

YES >> Replace suspect rear door tweeter. Refer to [AV-233](#), "[Removal and Installation](#)".

NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect audio unit connector M171 and audio amp. connector M113.
2. Check continuity between audio unit harness connector M171 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M171	5	M113	8	Yes
	4		24	
	14		7	
	13		23	

3. Check continuity between audio unit harness connector M171 and ground.

Connector	Terminal	—	Continuity
M171	5	Ground	No
	4		
	14		
	13		

Are the continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 5. PRE-AMP SIGNAL CHECK


1. Connect audio unit connector M171 and audio amp. connector M113.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M171 terminals with CONSULT or oscilloscope.



# REAR DOOR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M171	4	5	Receive audio signal	 <p style="text-align: center; font-size: small;">SKIA0177E</p>
	13	14		

Is the audio signal voltage reading as specified?

YES >> Replace audio amp. Refer to [AV-236. "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-228. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## SUBWOOFER

### Description

INFOID:000000009876562

The audio unit sends audio signals to the audio amp. The audio amp. amplifies the audio signals before sending them to the subwoofer using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000009876563

Regarding Wiring Diagram information, refer to [AV-172, "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and subwoofer connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?


YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2. SUBWOOFER HARNESS CHECK

1. Disconnect audio amp. connector M112 and subwoofer connector B72.
2. Check continuity between audio amp. harness connector M112 (A) and subwoofer harness connector B72 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M112	2	B72	1	Yes
	3		3	
	18		2	
	19		4	



3. Check continuity between audio amp. harness connector M112 (A) and ground.

A		—	Continuity
Connector	Terminal		
M112	2	Ground	No
	3		
	18		
	19		

Are the continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.


### 3. SUBWOOFER SIGNAL CHECK


# SUBWOOFER

## < DTC/CIRCUIT DIAGNOSIS >

## [DISPLAY AUDIO WITH AMPLIFIER]

1. Connect audio amp. connector M112 and subwoofer connector B72.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connector M112 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M112	2	18	Receive audio signal	 <small>SKIA0177E</small>
	3	19		



Is the audio signal voltage as specified?

YES >> Replace subwoofer. Refer to [AV-234, "Removal and Installation"](#).

NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect audio unit connector M171 and audio amp. connector M113.
2. Check continuity between audio unit harness connector M171 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M171	5	M113	8	Yes
	4		24	
	14		7	
	13		23	

3. Check continuity between audio unit harness connector M171 and ground.

Connector	Terminal	—	Continuity
M171	5	Ground	No
	4		
	14		
	13		

Are the continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 5. PRE-AMP SIGNAL CHECK

1. Connect audio unit connector M171 and audio amp. connector M113.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector M171 terminals with CONSULT or oscilloscope.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M171	4	5	Receive audio signal	
	13	14		

Is the audio signal voltage reading as specified?

- YES >> Replace audio amp. Refer to [AV-236, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-228, "Removal and Installation"](#).

# AMP ON SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## AMP ON SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:000000009876564

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).


### 1. CHECK AMP ON SIGNAL

1. Turn audio system ON.
2. Check voltage between audio amp. harness connector M113 terminal 9 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
M113	9	Ground	More than 6.5V

Is inspection result normal?

- YES >> Inspection End.  
NO >> GO TO 2.



### 2. CHECK AMP ON SIGNAL (AUDIO UNIT)

Check voltage between audio unit harness connector M171 terminal 1 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
M171	1	Ground	More than 6.5V

Is inspection result normal?

- YES >> Repair harness or connector.  
NO >> Replace audio unit. Refer to [AV-228. "Removal and Installation"](#).

# REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:00000009876565

Regarding Wiring Diagram information, refer to [AV-172, "Wiring Diagram"](#).

### 1. CHECK REVERSE INPUT SIGNAL

1. Turn ignition switch ON.
2. Shift the selector lever to R (reverse).
3. Check voltage between audio unit connector M175 and ground.

Audio unit		Ground	Condition	Voltage (Approx.)
(+)		(-)		
Connector	Terminal			
M175	50	—	Selector lever in R (reverse)	Battery Voltage

Is inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK CAMERA POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M175 and rear view camera connector.
3. Check continuity between audio unit connector M175 and rear view camera connector T2.

Audio unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M175	34	T2	1	Yes

4. Check continuity between audio unit connector M44 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M175	34		No

Is inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

### 3. CHECK CAMERA POWER SUPPLY VOLTAGE

1. Connect audio unit connector M175 and rear view camera connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R (reverse).
4. Check voltage between audio unit connector M175 and ground.

Audio unit		Ground	Condition	Voltage (Approx.)
(+)		(-)		
Connector	Terminal			
M175	34	—	Selector lever is in "R".	6.0 V

Is inspection result normal?

YES >> GO TO 4.

NO >> Replace audio unit. Refer to [AV-228, "Removal and Installation"](#).

# REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

[DISPLAY AUDIO WITH AMPLIFIER]

< DTC/CIRCUIT DIAGNOSIS >

## 4. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M175 and rear view camera connector.
3. Check continuity between audio unit connector M175 and rear view camera connector T2.

Audio unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M175	35	T2	3	Yes

4. Check continuity between audio unit connector M175 terminal 35 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M175	35		No

Is inspection result normal?

- YES >> GO TO 5.  
 NO >> Repair or replace harness or connectors.

## 5. CHECK CAMERA GROUND CIRCUIT CONTINUITY

Check continuity between audio unit connector M175 and rear view camera connector T2.


Audio unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M175	33	T2	4	Yes

Is inspection result normal?

- YES >> GO TO 6.  
 NO >> Repair or replace harness or connectors.

## 6. CHECK CAMERA IMAGE SIGNAL

1. Connect audio unit connector M175 and rear view camera connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R (reverse).
4. Check signal between audio unit connector M175 and ground.

Audio unit		Ground	Condition	Reference value
(+)		(-)		
Connector	Terminal			
M175	35	—	Camera image displayed.	 <p>SKIB2251J</p>

Is inspection result normal?

- YES >> Replace audio unit. Refer to [AV-228, "Removal and Installation"](#).  
 NO >> Replace rear view camera. Refer to [AV-242, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## MICROPHONE SIGNAL CIRCUIT

### Diagnosis Procedure


INFOID:00000009876566

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CHECK HARNESS BETWEEN BLUETOOTH® CONTROL UNIT AND MICROPHONE

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector and microphone connector.
3. Check continuity between Bluetooth® control unit harness connector B142 (A) and microphone harness connector R109 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B142	7	R109	1	Yes
	8		2	
	29		4	



4. Check continuity between Bluetooth® control unit harness connector B142 (A) and ground.

A		—	Continuity
Connector	Terminal		
B142	7	Ground	No
	8		
	29		

Are the continuity test results as specified?

YES >> GO TO 2.

NO >> Repair harness or connector.

### 2. CHECK MICROPHONE POWER SUPPLY

1. Connect Bluetooth® control unit connector and microphone connector.
2. Turn ignition switch ON.
3. Check voltage between microphone harness connector R109 terminal 4 and ground.


(+)		(-)	Voltage (approx.)
Connector	Terminal		
R109	4	Ground	5V

Is voltage reading approx. 5 volts?

YES >> GO TO 3.

NO >> Replace Bluetooth® control unit. Refer to [AV-241. "Removal and Installation"](#).

### 3. CHECK MICROPHONE SIGNAL







# MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Check signal between Bluetooth® control unit harness connector B142 terminals 7 and 8 with CONSULT or and oscilloscope.

Connector	(+)	(-)	Reference signal
	Terminal	Terminal	
B142	7	8	<p>While speaking into MIC</p>  <p>SK1B3609E</p>



Are voltage readings as specified?

- YES >> Replace Bluetooth® control unit. Refer to [AV-241, "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-239, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## STEERING SWITCH







### Diagnosis Procedure

INFOID:000000009876567

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Disconnect combination switch connector M102.
2. Check resistance between combination switch connector terminals.

Terminal	Signal name	Condition	Resistance (Ω) (Approx.)	
16	18	Volume (down)	Depress  switch.	1
		Volume (up)	Depress  switch.	121
		Phone end	Depress  switch.	321
15	18	Source	Depress SOURCE switch.	1
		Seek (up)	Depress  switch.	121
		Seek (down)	Depress  switch.	321
		Phone/Send	Depress  switch.	723

Do the steering wheel audio control switches check OK?

YES >> GO TO 2.

NO >> Replace steering wheel audio control switch. Refer to [AV-235. "Removal and Installation"](#).

### 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector B142 and combination switch connector M30.
3. Check continuity between Bluetooth® control unit harness connector B142 and combination switch harness connector M30.

Bluetooth® control unit		Combination switch		Continuity
Connector	Terminal	Connector	Terminal	
B142	12	M30	24	Yes
	14		31	
	13		25	

4. Check continuity between Bluetooth® control unit connector B142 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B142	12	Ground	No
	13		
	14		

Are the continuity results as specified?

YES >> GO TO 3.

NO >> Repair harness.

# STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## 3. SPIRAL CABLE CHECK

Check continuity between combination switch harness connectors M30 and M102.

Combination switch				Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	15	Yes
	31		18	
	25		16	

Does the spiral cable check OK?

YES >> Inspection End.

NO >> Replace spiral cable. Refer to [SR-13, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# USB CONNECTOR

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## USB CONNECTOR

### Diagnosis Procedure

INFOID:000000009876568

Regarding Wiring Diagram information, refer to [AV-172, "Wiring Diagram"](#).

#### 1. CHECK USB INTERFACE HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M172 and USB interface connector M214.
3. Check continuity between audio unit connector M172 and USB interface connector M214.

Audio unit		USB interface		Continuity
Connector	Terminal	Connector	Terminal	
M172	53	M214	4	Yes
	54		1	
	55		2	
	56		3	
	57		5	

4. Check continuity between audio unit connector M172 and ground.

Audio unit		—	Continuity
Connector	Terminal		
M172	53	Ground	No
	55		

Is the inspection result normal?

- YES >> Replace the USB interface. Refer to [AV-238, "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

# SYMPTOM DIAGNOSIS

## AUDIO SYSTEM

### Symptom Table

INFOID:000000009876569

#### RELATED TO AUDIO

Symptoms	Check items	Probable malfunction location
The disk cannot be removed.	Audio unit	Malfunction in audio unit. Refer to <a href="#">AV-156. "On Board Diagnosis Function"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Symptoms	Check items	Probable malfunction location
	No sound from all speakers.	<ul style="list-style-type: none"> <li>• Speaker circuit shorted to ground. Refer to <a href="#">AV-172, "Wiring Diagram"</a>.</li> <li>• Audio amp. ON signal circuit malfunction. Refer to <a href="#">AV-213, "Diagnosis Procedure"</a>.</li> <li>• Audio amp. power supply and ground circuits malfunction. Refer to <a href="#">AV-193, "AUDIO AMP : Diagnosis Procedure"</a>.</li> </ul>
No sound comes out or the level of the sound is low.	Only a certain speaker (front door speaker LH, front door speaker RH, front speaker LH, front speaker RH, center speaker, rear door speaker LH, rear door speaker RH, rear speaker LH, rear speaker RH) does not output sound.	<ul style="list-style-type: none"> <li>• Poor connector connection of speaker.</li> <li>• Sound signal circuit malfunction between audio unit and audio amp. Refer to:               <ul style="list-style-type: none"> <li>- <a href="#">AV-195, "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-198, "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-201, "Diagnosis Procedure"</a> (center speaker).</li> <li>- <a href="#">AV-204, "Diagnosis Procedure"</a> (rear door speaker).</li> <li>- <a href="#">AV-207, "Diagnosis Procedure"</a> (rear door tweeter).</li> </ul> </li> <li>• Sound signal circuit malfunction between audio amp. and speaker. Refer to:               <ul style="list-style-type: none"> <li>- <a href="#">AV-195, "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-198, "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-201, "Diagnosis Procedure"</a> (center speaker).</li> <li>- <a href="#">AV-204, "Diagnosis Procedure"</a> (rear door speaker).</li> <li>- <a href="#">AV-207, "Diagnosis Procedure"</a> (rear door tweeter).</li> </ul> </li> <li>• Malfunction in speaker. Refer to:               <ul style="list-style-type: none"> <li>- <a href="#">AV-232, "Removal and Installation"</a> (front door speaker).</li> <li>- <a href="#">AV-230, "Removal and Installation"</a> (front tweeter).</li> <li>- <a href="#">AV-231, "Removal and Installation"</a> (center speaker).</li> <li>- <a href="#">AV-233, "Removal and Installation"</a> (rear door speaker).</li> <li>- <a href="#">AV-233, "Removal and Installation"</a> (rear door tweeter).</li> </ul> </li> <li>• Malfunction in audio unit. Refer to <a href="#">AV-156, "On Board Diagnosis Function"</a>.</li> <li>• Malfunction in audio amp. Replace audio amp. Refer to <a href="#">AV-236, "Removal and Installation"</a>.</li> </ul>

# AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Symptoms	Check items	Probable malfunction location	
	Noise comes out from all speakers.	<ul style="list-style-type: none"> <li>• Malfunction in audio unit. Refer to <a href="#">AV-156. "On Board Diagnosis Function"</a>.</li> <li>• Malfunction in audio amp. Replace audio amp. Refer to <a href="#">AV-236. "Removal and Installation"</a>.</li> </ul>	A B
	Noise is mixed with audio.	<ul style="list-style-type: none"> <li>• Poor connector connection of speaker.</li> <li>• Sound signal circuit malfunction between audio unit and audio amp. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-195. "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-198. "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-201. "Diagnosis Procedure"</a> (center speaker).</li> <li>- <a href="#">AV-204. "Diagnosis Procedure"</a> (rear door speaker).</li> <li>- <a href="#">AV-207. "Diagnosis Procedure"</a> (rear door tweeter).</li> </ul> </li> <li>• Sound signal circuit malfunction between audio amp. and speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-195. "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-198. "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-201. "Diagnosis Procedure"</a> (center speaker).</li> <li>- <a href="#">AV-204. "Diagnosis Procedure"</a> (rear door speaker).</li> <li>- <a href="#">AV-207. "Diagnosis Procedure"</a> (rear door tweeter).</li> </ul> </li> <li>• Malfunction in speaker.</li> <li>• Poor Installation of speaker (e.g. backlash and looseness). Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-232. "Removal and Installation"</a> (front door speaker).</li> <li>- <a href="#">AV-230. "Removal and Installation"</a> (front tweeter).</li> <li>- <a href="#">AV-231. "Removal and Installation"</a> (center speaker).</li> <li>- <a href="#">AV-233. "Removal and Installation"</a> (rear door speaker).</li> <li>- <a href="#">AV-233. "Removal and Installation"</a> (rear door tweeter).</li> </ul> </li> <li>• Malfunction in audio unit. Refer to <a href="#">AV-156. "On Board Diagnosis Function"</a>.</li> <li>• Malfunction in audio amp. Replace audio amp. Refer to <a href="#">AV-236. "Removal and Installation"</a>.</li> </ul>	C D E F G H I J K L M
	Noise is mixed with radio only (when the vehicle hits a bump or while driving over bad roads)	Poor connector connection of antenna or antenna feeder. Refer to <a href="#">AV-237. "Location of Antenna"</a> .	N O P
No radio reception or poor reception.	<ul style="list-style-type: none"> <li>• Other audio sounds are normal.</li> <li>• Any radio station cannot be received or poor reception is caused even after moving to a service area with good reception (e.g. a place with clear view and no obstacles generating external noises).</li> </ul>	<ul style="list-style-type: none"> <li>• Antenna amp. ON signal circuit malfunction. Refer to <a href="#">AV-162. "Reference Value"</a>.</li> <li>• Poor connector connection of antenna or antenna feeder. Refer to <a href="#">AV-237. "Location of Antenna"</a>.</li> </ul>	AV

# AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Symptoms	Check items	Probable malfunction location
No satellite radio reception.	Satellite radio antenna malfunction.	<ul style="list-style-type: none"> <li>• Poor continuity in antenna feeder.</li> <li>• Poor connector connection of antenna or antenna feeder.</li> <li>• Loose satellite radio antenna mounting nut. Refer to <a href="#">AV-237, "Location of Antenna"</a>.</li> </ul>
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

## RELATED TO HANDS-FREE PHONE

- Before performing diagnosis, confirm that the cellular phone being used by the customer is compatible with the vehicle.
- It is possible that a malfunction is occurring due to a version change of the phone even though the phone is a compatible type. This can be confirmed by changing the cellular phone to another compatible type, and check that it operates normally. It is important to determine whether the cause of the malfunction is the vehicle or the cellular phone.

### Check Compatibility

1. Make sure the customer's Bluetooth® related concern is understood.
2. Verify the customer's concern.  
**NOTE:**  
The customer's phone may be required, depending upon their concern.
3. Write down the customer's phone brand, model and service provider.  
**NOTE:**  
It is necessary to know the service provider. On occasion, a given phone may be on the approved list with one provider, but may not be on the approved list with other providers.
4. Go to "www.nissanusa.com/bluetooth/".
  - a. Using the website's search engine, find out if the customer's phone is on the approved list.
  - b. If the customer's phone is NOT on the approved list:  
Stop diagnosis here. The customer needs to obtain a Bluetooth® phone that is on the approved list before any further action.
  - c. If the feature related to the customer's concern shows as "N" (not compatible):  
Stop diagnosis here. If the customer still wants the feature to function, they will need to get an approved phone showing the feature as "Y" (compatible) in the "Basic Features".
  - d. If the feature related to the customer's concern shows as "Y" (compatible):  
Perform diagnosis as per the following table.









Symptoms	Check items	Probable malfunction location
Does not recognize cellular phone connection (no connection is displayed on the display at the guide).	Repeat the registration of cellular phone.	
Hands-free phone cannot be established.	<ul style="list-style-type: none"> <li>• Hands-free phone operation can be made, but the communication cannot be established.</li> <li>• Hands-free phone operation can be performed, however, voice between each other cannot be heard during the conversation.</li> </ul>	Malfunction in audio unit. Replace audio unit. Refer to <a href="#">AV-228, "Removal and Installation"</a> .
The other party's voice cannot be heard by hands-free phone.	Check the "microphone speaker" in Inspection & Adjustment Mode if sound is heard.	
Originating sound is not heard by the other party with hands-free phone communication.	Sound operation function is normal.	
	Sound operation function does not work.	Microphone signal circuit malfunction. Refer to <a href="#">AV-216, "Diagnosis Procedure"</a> .



# AUDIO SYSTEM

## < SYMPTOM DIAGNOSIS >

## [DISPLAY AUDIO WITH AMPLIFIER]

Symptoms	Check items	Probable malfunction location
The system cannot be operated.	<ul style="list-style-type: none"> <li>• The voice recognition can be controlled.</li> <li>• Steering switch's , , and  switch works, but  does not work.</li> </ul>	Steering switch malfunction. Replace steering switch. Refer to <a href="#">AV-235. "Removal and Installation"</a> .
	Steering switch's  ,  ,  , and  switches do not work.	Steering switch signal circuit malfunction. Refer to <a href="#">AV-218. "Diagnosis Procedure"</a> .
	All steering switches do not work.	Steering switch ground circuit malfunction. Refer to <a href="#">AV-218. "Diagnosis Procedure"</a> .

## RELATED TO REAR VIEW CAMERA

Symptoms	Check items	Probable malfunction location
Rear view camera is inoperative.	Reverse signal circuit malfunction.	Reverse signal circuit malfunction between BCM and audio unit. Refer to <a href="#">AV-214. "Diagnosis Procedure"</a> .
	Camera image signal circuit malfunction.	Camera image signal circuit malfunction between rear view camera and audio unit. Refer to <a href="#">AV-214. "Diagnosis Procedure"</a> .
	Rear view camera malfunction.	Replace rear view camera. Refer to <a href="#">AV-242. "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000009876570

#### RELATED TO NOISE

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

**NOTE:**

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

#### Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> <li>• Ignition components</li> </ul>
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> <li>• Fuel pump condenser</li> </ul>
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> <li>• Relay malfunction, audio unit malfunction</li> </ul>
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> <li>• Motor case ground</li> <li>• Motor</li> </ul>
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> <li>• Rear defogger coil malfunction</li> <li>• Open circuit in printed heater</li> <li>• Poor ground of antenna feeder line</li> </ul>
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> <li>• Ground wire of body parts</li> <li>• Ground due to improper part installation</li> <li>• Wiring connections or a short circuit</li> </ul>

#### RELATED TO HANDS-FREE PHONE

Symptom	Cause and Counter measure
Does not recognize cellular phone connection (No connection is displayed on the display at the guide).	<p>Some Bluetooth® enabled cellular phones may not be recognized by the in-vehicle phone module.</p> <p>Refer to "RELATED TO HANDS-FREE PHONE (Check Compatibility)" in <a href="#">AV-221, "Symptom Table"</a>.</p>
Cannot use hands-free phone.	<p>Customer will not be able to use a hands-free phone under the following conditions:</p> <ul style="list-style-type: none"> <li>• The vehicle is outside of the telephone service area.</li> <li>• The vehicle is in an area where it is difficult to receive radio waves; such as in a tunnel, in an underground parking garage, near a tall building or in a mountainous area.</li> <li>• The cellular phone is locked to prevent it from being dialed.</li> </ul> <p><b>NOTE:</b></p> <p>While a cellular phone is connected through the Bluetooth® wireless connection, the battery power of the cellular phone may discharge quicker than usual. The Bluetooth® Hands-Free Phone System cannot charge cellular phones.</p>

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Symptom	Cause and Counter measure
The other party's voice cannot be heard by hands-free phone.	When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
Poor sound quality.	Do not place the cellular phone in an area surrounded by metal or far away from the in-vehicle phone module to prevent tone quality degradation and wireless connection disruption.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## REMOVAL AND INSTALLATION

### AUDIO UNIT

#### Removal and Installation

INFOID:000000009876571

#### AUDIO UNIT

##### Removal

1. Disconnect the battery negative terminal. Refer to [PG-79. "Removal and Installation"](#).
2. Remove the cluster lid C. Refer to [IP-15. "Removal and Installation"](#).
3. Remove the audio unit.
  - a. Remove the audio unit screws using power tool.
  - b. Pull the audio unit out from the instrument panel.
  - c. Disconnect the harness connectors from the audio unit.

##### Installation

Installation is in the reverse order of removal.

#### AV SWITCH

##### Removal

1. Disconnect battery negative terminal. Refer to [PG-79. "Removal and Installation"](#).
2. Remove the cluster lid C. Refer to [IP-15. "Removal and Installation"](#).
3. Remove the AV switch screws.
4. Carefully remove the AV switch.

##### Installation

Installation is in the reverse order of removal.

# SATELLITE RADIO ANTENNA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

## SATELLITE RADIO ANTENNA


### Removal and Installation

INFOID:000000010159257

### SATELLITE RADIO ANTENNA

#### Removal

1. Lower the headliner. Refer to [INT-21, "Removal and Installation"](#).
2. Disconnect the satellite radio antenna connector.
3. Remove the satellite radio antenna nut.
4. Remove the satellite radio antenna.



#### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## FRONT TWEETER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]


### FRONT TWEETER

#### Removal and Installation

INFOID:000000009876572

#### REMOVAL

1. Remove front tweeter speaker grille, using a suitable tool.
2. Remove the front tweeter clips (A).
3. Disconnect the front tweeter harness connector.
4. Remove the front tweeter (1).



#### Installation

Installation is in the reverse order of removal.

# CENTER SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

## CENTER SPEAKER


### Removal and Installation

INFOID:000000009876573

### CENTER SPEAKER

#### Removal

1. Remove the center console. Refer to [IP-20, "Removal and Installation"](#).
2. Remove the cluster lid D. Refer to [IP-15, "Removal and Installation"](#).
3. Remove the center speaker screws.
4. Disconnect the center speaker harness connector.
5. Remove the center speaker.



#### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]


### FRONT DOOR SPEAKER

#### Removal and Installation

INFOID:000000009876574

#### REMOVAL

1. Remove the front door finisher. Refer to [INT-10, "Removal and Installation"](#).
2. Remove the front door speaker screws.
3. Disconnect the front door speaker harness connector.
4. Remove the front door speaker.



#### INSTALLATION

Installation is in the reverse order of removal.



# REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

## REAR DOOR SPEAKER


### Removal and Installation

INFOID:000000009876575

### REAR DOOR SPEAKER

#### Removal

1. Remove the rear door finisher. Refer to [INT-10, "Removal and Installation"](#) (Crew Cab) or [INT-10, "Removal and Installation"](#) (King Cab).
2. Remove the rear door speaker.
  - a. Remove the rear door speaker screws.
  - b. Disconnect the rear door speaker harness connector.




#### Installation

Installation is in the reverse order of removal.

### REAR DOOR TWEETER

#### Removal

1. Remove the rear door finisher. Refer to [INT-10, "Removal and Installation"](#).
2. Remove the rear door tweeter.
  - a. Remove the rear door tweeter screws.
  - b. Disconnect the rear door tweeter harness connector.



#### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

# SUBWOOFER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

## SUBWOOFER


### Removal and Installation

INFOID:000000009876576

### SUBWOOFER

#### Removal

1. Remove the LH front seat. Refer to [SE-34, "Removal and Installation - Front Seat Assembly"](#).
2. Disconnect the subwoofer harness connector (B).
  - ⇐: Front
3. Remove the subwoofer bolts (A).
4. Remove the subwoofer (1).



#### Installation

Installation is in the reverse order of removal.

# STEERING SWITCH


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

## STEERING SWITCH

### Removal and Installation

INFOID:000000010159266



1. Steering wheel audio control switches 2. Steering wheel

### STEERING WHEEL AUDIO CONTROL SWITCHES

#### Removal

1. Remove the steering wheel. Refer to [ST-22. "Removal and Installation"](#).
2. Remove the steering wheel rear cover screws and the steering wheel rear cover.
3. Remove the steering wheel switch assembly screws and the steering wheel switches.

#### Installation

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# AUDIO AMP.

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]


## AUDIO AMP.

### Removal and Installation


INFOID:00000009876578

#### REMOVAL

1. Remove the accelerator pedal. Refer to [ACC-3, "Removal and Installation"](#).
2. Remove the BCM. Refer to [BCS-52, "Removal and Installation"](#).
3. Remove the audio amp.
  - a. Disconnect the audio amp. harness connectors.
  - b. Remove the audio amp bracket screws and slide the audio amp and bracket assembly down.



4. Remove the audio amp. screws (A) and separate the audio amp. (1) from the bracket.



#### INSTALLATION

Installation is in the reverse order of removal.

# AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

## AUDIO ANTENNA

### Location of Antenna

INFOID:000000009876579



1. Antenna

2. Main feeder cable

### Removal and Installation

INFOID:000000009876580

#### REMOVAL

1. Remove audio antenna rod.
2. Remove audio antenna rubber seal.
3. Remove fender protector RH. Refer to [EXT-24. "Removal and Installation"](#).
4. Remove audio antenna assembly bolts.
5. Disconnect the audio antenna feeder from the audio antenna assembly.
6. Remove audio antenna assembly from the vehicle.

#### INSTALLATION

Installation is in the reverse order of removal.  
• Tighten audio antenna rod to specification.

**Audio antenna rod : 3.5 N·m (0.36 kg-m, 31 in-lb)**

#### CAUTION:

**Always properly tighten the audio antenna rod during installation or the audio antenna rod may bend or break during vehicle operation.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## USB CONNECTOR

### Removal and Installation

INFOID:000000009876581

#### REMOVAL

1. Remove the center console assembly. Refer to [IP-20. "Removal and Installation"](#).
2. Push the pawl from the back of the center console to remove the USB interface.

#### INSTALLATION

Installation is in the reverse order of removal.

# MICROPHONE

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]


## MICROPHONE

### Removal and Installation

INFOID:000000009876582

#### REMOVAL

1. Remove the front roof console finisher. Refer to [INT-21](#), "[Removal and Installation](#)".
2. Remove the Bluetooth microphone (1)
  - a. Disconnect the Bluetooth microphone harness connector (A).
  - b. Detach the Bluetooth microphone (1) from the front roof console finisher.



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

## TEL ANTENNA

### Removal and Installation

INFOID:000000009876583

The Bluetooth antenna and the Bluetooth control unit are serviced as an assembly. Refer to [AV-241, "Removal and Installation"](#).



# BLUETOOTH CONTROL UNIT

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

## BLUETOOTH CONTROL UNIT


### Removal and Installation

INFOID:000000009876584

#### REMOVAL

1. Disconnect the negative battery terminal.
2. Slide the front RH seat forward.
3. Remove the Bluetooth control unit kick shield screws and the Bluetooth control unit kick shield.
4. Remove the Bluetooth control unit (1).
  - a. Remove the Bluetooth control unit screws (A).
  - b. Disconnect the harness connectors from the Bluetooth control unit.

↔: Front



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

## REAR VIEW CAMERA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

---

### REAR VIEW CAMERA

#### Removal and Installation

INFOID:000000009876585

#### REMOVAL

1. Remove the tail gate handle. Refer to [DLK-137, "Exploded View"](#).
2. Remove the rear view camera screws and the rear view camera from the tail gate handle.

#### INSTALLATION

Installation is in the reverse order of removal.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010159254

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Trouble Diagnosis

INFOID:000000009876587

AV COMMUNICATION SYSTEM


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

Precaution for Harness Repair

INFOID:000000009876588

AV COMMUNICATION SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV

# PRECAUTIONS

< PRECAUTION >

[NAVIGATION]

- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



## Precaution for Work

INFOID:000000009876589

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

# PREPARATION

< PREPARATION >

[NAVIGATION]


## PREPARATION

### PREPARATION

#### Special Service Tools


INFOID:000000010159263

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set  AWJIA0483ZZ	Removing trim components

#### Commercial Service Tools

INFOID:000000009876591

Tool name	Description
Power tool  PHB1407E	Loosening nuts, screws and bolts

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[NAVIGATION]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000009876592




AWNIA2768ZZ

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[NAVIGATION]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

- |  |  |   |
|--|--|---|
| 1. Front tweeter LH M109                               | 2. Steering wheel audio control switches               | 3. Center speaker M110                                |
| 4. Microphone  | 5. AV control unit M42, M43, M45, M184, M185           | 6. Front tweeter RH M111                              |
| 7. USB interface M124                                  | 8. Auxiliary input jacks                               | 9. Front door speaker<br>LH D12<br>RH D112            |
| 10. Rear door tweeter (crew cab)<br>LH D208<br>RH D308 | 11. Rear door speaker (crew cab)<br>LH D207<br>RH D307 | 12. Rear door speaker (king cab)<br>LH B76<br>RH B159 |
| 13. Subwoofer B72                                      | 14. Audio amp M112, M113                               | 15. Rear view camera T2                               |
| 16. Rear control assembly (if equipped)<br>R204        | 17. Video monitor (if equipped) R202                   | 18. DVD player (if equipped) M205, M206               |

## Component Description

INFOID:000000009876593

Part name	Description
AV control unit	<ul style="list-style-type: none"> <li>• Operation of navigation and audio systems are integrated.</li> <li>• Includes the audio, hands-free phone, navigation, satellite radio, rear view monitor, USB connection and AUX IN connection functions.</li> <li>• Map data can be loaded from SD-card inserted in SD-card slot.</li> <li>• Audio signals are output to audio amp.</li> <li>• Inputs illumination signals required for display dimming control.</li> <li>• Inputs signals for driving status recognition (vehicle speed and reverse).</li> <li>• Touch panel functions can be operated by touching display directly.</li> </ul>
Map SD-card	A collection of Map data.
Audio amp.	Receives audio signals from AV control unit and outputs audio signals to each speaker.
Front tweeters	Outputs high, mid and low range audio signals from audio amp.
Center speaker	
Front door speakers	
Rear door speakers	
Rear door tweeters	
Steering switches	<ul style="list-style-type: none"> <li>• Operations for audio, hands-free phone and voice recognition are possible.</li> <li>• Steering switch signal is output to combination meter.</li> <li>• Combination meter outputs steering switch signal to AV control unit.</li> </ul>
Microphone	<ul style="list-style-type: none"> <li>• Used for hands-free phone operations.</li> <li>• Microphone signal is transmitted to AV control unit.</li> <li>• Power is supplied from AV control unit.</li> </ul>
USB interface	USB sound and data input signals are transmitted to AV control unit.

AV

## COMPONENT PARTS

< SYSTEM DESCRIPTION >


[NAVIGATION]

Part name	Description
Rear view camera	<ul style="list-style-type: none"><li>• Outputs image of vehicle rear to AV control unit.</li><li>• Power is supplied from AV control unit.</li></ul>
Satellite antenna	Satellite radio signal is received and transmitted to AV control unit.
GPS antenna	GPS signal is received and transmitted to AV control unit.
Antenna amp.	<ul style="list-style-type: none"><li>• AM/FM signal received by window antenna is amplified and transmitted to AV control unit.</li><li>• Power is supplied from AV control unit.</li></ul>
Window antenna	AM/FM signal is received and transmitted to antenna amp.
DVD player	<ul style="list-style-type: none"><li>• Outputs DVD video to video monitor.</li><li>• Outputs DVD audio to AV control unit via AUX JACK.</li></ul>
Video monitor	Receives and displays the DVD video signal.
Rear control assembly	<ul style="list-style-type: none"><li>• Audio and DVD functions can be operated.</li><li>• Switch signal is output to the DVD player.</li><li>• Receives audio signal from DVD player for headphones.</li></ul>



SYSTEM

System Diagram



INFOID:000000009876594

System Description

INFOID:000000009876595

Refer to Owner's Manual for navigation and audio system operating instructions. Audio function and display are built into AV control unit.

This navigation has the following functions.

- Map data on SD-card
- Full support for playback of music from iPod® and USB device
- High resolution color 5 inch display with touch panel function
- FM/AM twin digital tuner
- USB mass storage connection
- Satellite radio
- Hands-free phone system

iPod® is a trademark of Apple inc., registered in the U.S. and other countries.

NAVIGATION SYSTEM FUNCTION

Description

- The navigation system can be operated by control panel of the AV control unit and display (touch panel) of the AV control unit.
- Guide sound during the operation of the navigation system is output from AV control unit to front speakers.
- AV control unit calculates the vehicle location based on the signals from GYRO (angle speed sensor), vehicle sensor, and GPS satellite, as well as the map data from map SD-card. The vehicle location is displayed on the AV control unit.

POSITION DETECTION PRINCIPLE

The navigation system periodically calculates the vehicle's current position according to the following three signals:

- Travel distance of the vehicle as determined by the vehicle speed sensor

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# SYSTEM

## < SYSTEM DESCRIPTION >


## [NAVIGATION]

- Turning angle of the vehicle as determined by the gyroscope (angular velocity sensor)
- Direction of vehicle travel as determined by the GPS antenna (GPS information)

The current position of the vehicle is then identified by comparing the calculated vehicle position with map data read from the map SD-card (map-matching), and indicated on the screen as a vehicle mark. More accurate data is judged and used by comparing vehicle position detection results found by the GPS with the result by map-matching.

The current vehicle position will be calculated by detecting the distance the vehicle moved from the previous calculation point and its direction.

- Travel distance  
Travel distance calculations are based on the vehicle speed sensor input signal. Therefore, the calculation may become incorrect as the tires wear down. To prevent this, an automatic distance correction function has been adopted.
- Travel direction  
Change in the travel direction of the vehicle is calculated by a gyroscope (angular velocity sensor) and a GPS antenna (GPS information). They have both advantages and disadvantages.



Type	Advantage	Disadvantage
Gyroscope (angular velocity sensor)	Can detect the vehicle's turning angle quite accurately.	Direction errors may accumulate when vehicle is driven for long distances without stopping.
GPS antenna (GPS information)	Can detect the vehicle's travel direction (North/South/East/West).	Correct direction cannot be detected when vehicle speed is low.


More accurate traveling direction is detected because priorities are set for the signals from these two devices according to the situation.

### MAP-MATCHING

Map-matching compares a current location detected by the method in the "Location Detection Principle" with a road map data from map SD-card.


#### NOTE:

The road map data is based on data stored in the map SD-card.



The vehicle position may not be corrected under the following circumstances and after driving for a certain time when GPS information is difficult to receive. In this case, the vehicle mark on the display must be corrected manually.

- In map-matching, alternative routes to reach the destination will be shown and prioritized, after the road on which the vehicle is currently driven has been judged and the vehicle mark has been repositioned. Alternative routes will be shown in different order of priority, and the incorrect road can be avoided if there is an error in distance and/or direction. Routes are of the same priority if two roads are running in parallel. Therefore, the vehicle mark may appear on either of them alternately, depending on maneuvering of the steering wheel and configuration of the road.




# SYSTEM

## < SYSTEM DESCRIPTION >

## [NAVIGATION]


- Map-matching does not function correctly when a road on which the vehicle is driving is new and not recorded in the map SD-card, or when road pattern stored in the map data and the actual road pattern are different due to repair. The map-matching function may find another road and position the vehicle mark on it when driving on a road not present in the map. Then, the vehicle mark may change to it when the correct road is detected.
- Effective range for comparing the vehicle position and travel direction calculated by the distance and direction with the road data read from the map SD-card is limited. Therefore, correction by map-matching is not possible when there is an excessive gap between current vehicle position and the position on the map.



### GPS (Global Positioning System)

GPS (Global Positioning System) is developed for and is controlled by the US Department of Defense. The system utilizes GPS satellites (NAVSTAR), transmitting out radio waves while flying on an orbit around the earth at an altitude of approximately 21,000 km (13,049 mile).

The receiver calculates the travel position in three dimensions (latitude/longitude/altitude) according to the time lag of the radio waves that four or more GPS satellites transmit (three-dimensional positioning). The GPS receiver calculates the travel position in two dimensions (latitude/longitude) with the previous altitude data if the GPS receiver receives only three radio waves (two-dimensional positioning). GPS position correction is not performed while stopping the vehicle.



Accuracy of the GPS will deteriorate under the following conditions:

- In two-dimensional positioning, GPS accuracy will deteriorate when altitude of the vehicle position changes.
- The position of GPS satellite affects GPS detection precision. The position detection may not be precisely performed.
- The position detection is not performed if GPS receiver does not receive radio waves from GPS satellites. (Inside a tunnel, parking in a building, under an elevated highway etc.) GPS receiver may not receive radio waves from GPS satellites if any object is placed on the GPS antenna.

### NOTE:

- The detection result has an error of approximately 10 m (32.81 ft) even with a high-precision three dimensional positioning.
- There may be cases when the accuracy is lowered and radio waves are stopped intentionally because the GPS satellite signal is controlled by the US trace control center.

### SATELLITE RADIO FUNCTION

- Satellite radio function is built into AV control unit.
- Sound signal (satellite radio) is received by satellite antenna and transmitted to AV control unit. AV control unit outputs sound signal to each speaker.

### AUXILIARY INPUT FUNCTION

- Sound can be output from an external device by connecting a device with USB connector and AUX jack.
- AUX sound signals are transmitted to each speaker via AV control unit.

### REAR VIEW MONITOR FUNCTION

#### Camera Image Operation Principle

- The ITS control unit supplies power to the rear view camera when receiving a reverse signal.
- The rear view camera transmits camera images to the ITS control unit when power is supplied from the ITS control unit.
- The ITS control unit transmits camera images to the AV control unit.
- The AV control unit combines a warning message and fixed guide lines with an image received from the ITS control unit to display a rear view camera image on the screen.

### USB CONNECTION FUNCTION

- iPod® or music files in USB memory can be played.

A  
B  
C  
D  
E  
F  
G  
H

I  
J  
K

L

M

AV

O

P

- Sound signals are transmitted from USB connector and AUX jack to the AV control unit and output to each speaker and tweeter.
- iPod® is recharged when connected to USB connector and AUX jack.

**NOTE:**

Use the enclosed USB harness when connecting iPod® to USB connector and AUX jack.

iPod® is a trademark of Apple inc., registered in the U.S. and other countries.

## SPEED SENSITIVE VOLUME SYSTEM

- Volume level of this system goes up and down automatically in proportion to the vehicle speed.
- The control level can be selected by the customer.

## HANDS-FREE PHONE SYSTEM

- Bluetooth® control is built into AV control unit.
- The connection between cellular phone and AV control unit is performed with Bluetooth® communication.
- The voice guidance signal is input from the AV control unit and output to the front speakers when operating the cellular phone.

### When A Call Is Originated

- Spoken voice sound output from the microphone (microphone signal) is input to AV control unit.
- AV control unit outputs to cellular phone with Bluetooth® communication as a TEL voice signal.
- Voice sound is then heard at the other party.

### When Receiving A Call

- Voice sound is input to own cellular phone from the other party.
- TEL voice signal is input to AV control unit by establishing Bluetooth® communication from cellular phone, and the signal is output to front speakers.

## DVD PLAYER SYSTEM

The DVD entertainment system consists of the following components

- DVD player
- Video monitor
- Rear control assembly

When the DVD entertainment system is on, video signals are sent from the DVD player to the video monitor. Audio signals are sent to the AV control unit via AUX JACK. Audio signals can be directed through the wireless infrared headphones or through the audio amp. to the vehicle speakers. Refer to the Owner's Manual for complete DVD entertainment system operating instructions.

# DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[NAVIGATION]

## DIAGNOSIS SYSTEM (AV CONTROL UNIT)

### Description

INFOID:000000009876596

The AV control unit on board diagnosis performs the functions listed in the table below:

Mode	Item	Content	
Version	—	Version data of the AV control unit is displayed.	
User Configuration	Touch Display Calibration	Allows correction of the position detection accuracy of the touch panel.	
Radio	FM monitor	Monitors the dynamic values of the current tuner	
	AM monitor		
	XM monitor	Version data is displayed.	
	XM functions	<ul style="list-style-type: none"> <li>• Clear XM Chipset NVM</li> <li>• Reset All XM Settings</li> <li>• Clear IGS</li> <li>• XM CBM Debug Mode</li> <li>• External Diag Mode</li> </ul> Current status is displayed.	
System State	Running System Status	<ul style="list-style-type: none"> <li>• SD card slot Access</li> <li>• Power Supply</li> <li>• Speed Signal</li> <li>• Direction Signal</li> <li>• Illumination Signal</li> <li>• GPS Antenna</li> <li>• GPS Tracking</li> <li>• Satellites Visible</li> <li>• Satellites Tracked</li> <li>• BTHFU Status</li> <li>• Radio Antenna</li> <li>• USB Device</li> <li>• iPod® firmware version</li> <li>• Steering wheel key</li> </ul> The current system status is displayed.	
	Speaker Test 4kHz	—	This activates a sequence of test tone outputs to the audio circuits one after the other for 1 second.
	Speaker Test 100Hz		
		Display-Test	—
Self Test	<ul style="list-style-type: none"> <li>• SD Card Access</li> <li>• Radio Antenna</li> <li>• GPS Antenna</li> <li>• XM Antenna</li> </ul>	—	A system self test is executed and the results are stored into the error memory.

Perform CONSULT diagnosis if the AV control unit on board diagnosis does not start or the screen does not display anything.

### On Board Diagnosis Function

INFOID:000000009876597

#### METHOD OF STARTING


1. Turn the ignition ON.
2. Turn the audio system OFF.

# DIAGNOSIS SYSTEM (AV CONTROL UNIT)


< SYSTEM DESCRIPTION >

[NAVIGATION]

- While pressing the MENU button, turn the TUNE-SCROLL dial counterclockwise 3 or more clicks, then clockwise 3 or more clicks, then counterclockwise 3 or more clicks. When self diagnosis mode begins, a short beep will be heard. Shifting from current screen to previous screen is performed by pressing BACK button.



- The trouble diagnosis initial screen is displayed, and Version, User Config, Radio, System State or Self Test can be selected.



## CONSULT Function

INFOID:000000009876598

### CONSULT FUNCTIONS

CONSULT performs the following functions via communication with the AV control unit.

Direct Diagnostic Mode	Description
Ecu Identification	The AV control unit part number is displayed.
Self Diagnostic Result	The AV control unit self diagnostic results are displayed.
Data Monitor	The AV control unit input/output data is displayed in real time.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing AV control unit.</li> </ul>
CAN Diag Support Mntr	<ul style="list-style-type: none"> <li>The result of transmit/receive diagnosis of AV communication is displayed.</li> <li>The result of transmit/receive diagnosis of CAN communication is displayed.</li> </ul>

### ECU IDENTIFICATION

The part number of AV control unit is displayed.

### SELF DIAGNOSTIC RESULT

Refer to [AV-258. "DTC Index"](#).

### DATA MONITOR

Monitor Item [Unit]	Description
VHCL SPD SIG [On/Off]	Indicates vehicle speed signal received from combination meter on CAN communication line.
ILLUM SIG [On/Off]	Indicates condition of illumination signal for the AV control unit.
IGN SIG [On/Off]	Indicates condition of ignition signal.
REV SIG [On/Off]	Indicates condition of reverse signal received from BCM.

### CONFIGURATION

Refer to [AV-288. "CONFIGURATION \(AV CONTROL UNIT\) : Description"](#).

### CAN DIAG SUPPORT MNTR

Refer to [LAN-10. "CAN Diagnostic Support Monitor"](#).

# AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]


## ECU DIAGNOSIS INFORMATION

### AV CONTROL UNIT

Reference Value

INFOID:000000009876599

#### TERMINAL LAYOUT



#### PHYSICAL VALUES

Terminal (Wire color)		Description	Condition		Reference value (Approx.)	
+	-	Signal name	Input/ Output	Ignition switch		
1 (G/W)	Ground	Amp. ON signal	Output	ACC	—	
2 (Y)	3 (BR)	Sound signal front speaker LH	Output	ON	Sound output	 SKIB3609E
4 (BR)	5 (B/R)	Sound signal rear speaker LH	Output	ON	Sound output	 SKIB3609E
6 (R)	15 (L)	Steering switch signal A	Input	Ignition switch ON	Press and hold SOURCE switch.	0V
					Press and hold $\Delta$ switch.	1.0V
					Press and hold $\nabla$ switch.	2.0V
					Press and hold  switch.	3.0V
					Except for above.	5.0V







A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]



Terminal (Wire color)		Description	Input/ Output	Condition		Reference value (Approx.)
+	-			Signal name	Ignition switch	
7 (V)	Ground	ACC power supply	Input	ACC	—	Battery voltage
8 (L)	—	CAN (H)	Input/ Output	—	—	—
9 (R/L)	44 (BR)	Illumination control signal	Input	ON	Headlamps ON	Battery voltage
10	—	Shield	—	—	—	—
11 (W)	12 (B)	Sound signal front speaker RH	Output	ON	Sound output	 SKIB3609E
13 (L)	14 (B/W)	Sound signal rear speaker RH	Output	ON	Sound output	 SKIB3609E
16 (G)	15 (L)	Steering switch signal B	Input	Ignition switch ON	Press and hold  switch	0V
					Press and hold  switch	1.0V
					Press and hold  switch	2.0V
					Except for above	5.0V
17 (P)	—	CAN (L)	Input/ Output	—	—	—
18 (W/R)	Ground	Vehicle speed signal	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	 JSNIA0012GB
19 (Y)	Ground	Battery power supply	Input	OFF	—	Battery voltage
20 (B)	Ground	Ground	—	ON	—	0 V
23 <sup>1</sup> (SB)	—	MR output	—	—	—	—
23 <sup>2</sup> (R/L)	—	MR output	—	—	—	—



# AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
28 (G/W)	Ground	Reverse signal	Input	ON	Selector lever in R (reverse)	Battery voltage
					Selector lever in any position other than R (reverse)	0 V
30 (W)	—	Audio L	Input	—	—	—
31 (R)	—	Audio ground	—	—	—	—
32 (B)	—	Audio R	Input	—	—	—
33 (B)	Ground	Rear view camera video signal ground	—	ON	—	0 V
34 (W)	—	Rear view camera ON	—	—	—	—
36 (R)	35 (Shield)	Camera image signal	Input	ON	When camera image is displayed	 <p style="text-align: right; font-size: small;">SKIB2251J</p>
37 (G/R)	Ground	Ignition power supply	Input	ON or START	—	Battery voltage
42 (W)	Ground	Microphone power supply	Output	ON	—	5.0 V
43 (B)	41 (Shield)	Microphone signal	Input	ON	While speaking into microphone.	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
45 (G)	—	USB ground	—	—	—	—
46 (R)	—	USB D- signal	—	—	—	—
47 (L)	—	USB D+ signal	—	—	—	—
48 (W)	—	V BUS signal	—	—	—	—
49	—	Shield	—	—	—	—
50 (B)	—	GPS antenna signal	—	—	—	—
51 (B)	—	Shield	—	—	—	—
52 (B)	—	Satellite antenna signal	—	—	—	—
53 (B)	—	Shield	—	—	—	—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]

<sup>1</sup>: without rear entertainment system

<sup>2</sup>: with rear entertainment system

## DTC Index

INFOID:000000009876600

CONSULT Display	Reference Page
U1000: CAN COMM CIRCUIT	<a href="#">AV-290, "DTC Logic"</a>
U1010: CONTROL UNIT (CAN)	<a href="#">AV-291, "DTC Logic"</a>
U1217: BLUETOOTH MODULE	<a href="#">AV-292, "DTC Logic"</a>
U1229: iPod CERTIFICATION	<a href="#">AV-293, "DTC Logic"</a>
U122F: Digital broadcasting connection error	<a href="#">AV-294, "DTC Logic"</a>
U1244: GPS ANTENNA CONN	<a href="#">AV-295, "DTC Logic"</a>
U1258: XM ANTENNA CONN	<a href="#">AV-296, "DTC Logic"</a>
U1263: USB OVERCURRENT	<a href="#">AV-297, "DTC Logic"</a>
U1265: AMP ON TERMINAL	<a href="#">AV-298, "DTC Logic"</a>
U12AA: Configuration Error	<a href="#">AV-299, "DTC Logic"</a>
U12AB: FM Antenna error	<a href="#">AV-300, "DTC Logic"</a>
U12AC: Display Temperature too High	<a href="#">AV-301, "DTC Logic"</a>
U12AD: ECU Temperature too High	<a href="#">AV-302, "DTC Logic"</a>
U12AE: Internal Amplifier temperature Warning	<a href="#">AV-303, "DTC Logic"</a>
U12AF: CD Mechanism Temperature Warning	<a href="#">AV-304, "DTC Logic"</a>
U12B0: Supply Voltage Goes below 9V > 20s	<a href="#">AV-305, "DTC Logic"</a>
U12B1: Supply Voltage Goes High > 16V for 20s	<a href="#">AV-306, "DTC Logic"</a>
U1310: CONTROL UNIT (AV)	<a href="#">AV-307, "DTC Logic"</a>

# AUDIO AMP

< ECU DIAGNOSIS INFORMATION >


[NAVIGATION]

## AUDIO AMP

Reference Value

INFOID:000000009876601

### TERMINAL LAYOUT



### PHYSICAL VALUES







Terminal (wire color)		Item	Signal input/output	Condition		Reference value (Approx.)
+	-					
1 (Y)	Ground	Battery	Input	-	-	Battery voltage
2 (W)	18 (B)	Subwoofer	Output	Ignition switch ON	Receive audio signal	 SKIA0177E
3 (BR/W)	19 (BR)	Subwoofer	Output	Ignition switch ON	Receive audio signal	 SKIA0177E
4 (B)	Ground	Ground	-	Ignition switch ON	-	-
9 (G/W)	Ground	Amp. ON signal	Input	Ignition switch ON	-	More than 6.5V
10 (L/W)	26 (L/B)	Center speaker	Output	Ignition switch ON	Receive audio signal	 SKIA0177E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AUDIO AMP

< ECU DIAGNOSIS INFORMATION >





[NAVIGATION]

Terminal (wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
11 (SB)	27 (B/Y)	Rear door speaker LH and rear door tweeter LH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
12 (O/L)	28 (R/L)	Rear door speaker RH and rear door tweeter RH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
13 (W/B)	29 (L/B)	Front door tweeter RH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
14 (L/W)	30 (L/R)	Front tweeter LH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
15 (L/W)	31 (L/R)	Front door speaker LH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
16 (W/B)	32 (L/B)	Front door speaker RH	Output	Ignition switch ON	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
17 (Y/G)	Ground	Battery	Input	-	-	Battery voltage
20 (B)	Ground	Ground	-	Ignition switch ON	-	-

# AUDIO AMP

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]

Terminal (wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
21 (W)	5 (B)	Audio sound sig- nal front RH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
22 (Y)	6 (BR)	Audio sound sig- nal front LH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
23 (L)	7 (B/W)	Audio sound sig- nal rear RH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
24 (BR)	8 (B/R)	Audio sound sig- nal rear LH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# DVD PLAYER


< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]

## DVD PLAYER

### Reference Value

INFOID:000000010621046



### PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (B)	2 (W)	DVD audio signal LH	Output	Ignition switch ON	With operation of the DVD player	 SKIB3609E
3 (R)	4 (G)	DVD audio signal RH	Output	Ignition switch ON	With DVD player operation	 SKIB3609E
9 (S/B)	Ground	Audio ON	Output	Ignition switch ON	With DVD player operation	Battery voltage
10 (BR)	Ground	Illumination control	Input	Ignition switch ON	With lighting switch in 1st or 2nd position	Varies between 0 and Battery voltage
11 (S/B)	Ground	Family entertainment sys- tem enable	Input	Ignition switch ON	With DVD player operation	Battery voltage
12 (R/L)	Ground	Illumination power	Input	Ignition switch ON	With lighting switch in 1st or 2nd position	Battery voltage
15 (V)	Ground	ACC power	Input	Ignition switch ACC or ON	—	Battery voltage
16 (Y)	Ground	Battery power	Input	—	—	Battery voltage

# DVD PLAYER

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
17 (R)	Ground	Common	—	Ignition switch ON	—	0V
18 (B)	Ground	DVD audio signal L	Output	—	—	—
19 (B/W)	Ground	Ground	—	Ignition switch ON	—	0V
20 (W)	Ground	DVD audio signal R	Output	—	—	—
21 (G/Y)	Ground	Switch power	Output	Ignition switch ON	With DVD player operation	5V
22 (B)	Ground	Ground	—	Ignition switch ON	—	0V
23 (B/W)	Ground	VTR (+)	Output	Ignition switch ON	With DVD player operation	—
24 (L)	Ground	VTR (-)	Output	Ignition switch ON	With DVD player operation	—
26	—	Shield	—	—	—	—
27 (B/Y)	Ground	Ground	—	Ignition switch ON	—	0V
28 (Y)	—	Data receive	Input	—	—	—
29 (BR)	—	Data transmit	Output	—	—	—
31 (SB)	Ground	Battery power	Output	—	—	Battery voltage
32 (BR)	Ground	Battery power	Output	—	—	Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# WIRING DIAGRAM

## NAVIGATION SYSTEM

### Wiring Diagram

INFOID:000000009876602



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.


ABNWA2319GB



# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABNWA2320GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]

CC : CREW CAB  
 KC : KING CAB  
 RD : WITH REAR ENTERTAINMENT SYSTEM




ABNWA2321GB

# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

ABNWA2322GB


## NAVIGATION SYSTEM CONNECTORS

Connector No.	M2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	– (WITH NAVI)
5	W	– (WITH NAVI)
12	SHIELD	– (WITH NAVI)

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4P	V	–
16P	Y/G	–

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	L/R	–
11	L/W	–

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
29	W/R	SPEED OUT


Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
24	R	– (WITH NAVI)
25	G	– (WITH NAVI)
31	L	– (WITH NAVI)

Terminal No.	Color of Wire	Signal Name
86A	SHIELD	-
87A	G	-
88A	R	-
89A	W	-
90A	B	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3A	O/L	-
4A	R/L	-
72A	SHIELD	-
73A	L	-
74A	B/W	-
75A	R	-
78A	Y	-
79A	BR	-
80A	SHIELD	-
81A	B/Y	-
82A	B/W	-
83A	G/Y	-
84A	BR	-
85A	SB	-

Terminal No.	Color of Wire	Signal Name
7G	Y	-
13G	B	-
14G	SHIELD	-
23G	R	-
24G	W	-
27G	G/W	-
64G	R	-
94G	G/W	-
95G	G	-
98G	W/B	-

ABNIA6315GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV


# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]

Terminal No.	Color of Wire	Signal Name
1J	B/Y	-
7J	SB	-
92J	BR	-
93J	B	-
94J	W	-
96J	BR/W	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1Q	G/R	-

Terminal No.	Color of Wire	Signal Name
6	R	STRG SW A
7	V	ACC
8	L	CAN-H
9	R/L	ILL (+), LIGHT SW
10	SHIELD	PRE AMP SHIELD
11	W	FR SP RH+
12	B	FR SP RH-
13	L	RR SP RH+
14	B/W	RR SP RH-
15	L	STRG SW GND
16	G	STRG SW B
17	P	CAN-L
18	W/R	SPEED SIG
19	Y	BAT
20	B	GND

Connector No.	M43
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/W	AMP ON
2	Y	FR SP LH+
3	BR	FR SP LH-
4	BR	RR SP LH+
5	B/R	RR SP LH-

Connector No.	M42
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
45	W	V BUS
46	G	USD GND
47	L	USB D +
48	R	USB D -
49	SHIELD	SHIELD


ABNIA6316GB

# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]


Connector No.	M45
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	-	-
22	-	-
23	SB	MR OUTPUT (WITHOUT REAR ENTERTAINMENT SYSTEM)
23	R/L	MR OUTPUT (WITH REAR ENTERTAINMENT SYSTEM)
24	-	-
25	-	-
26	-	-
27	-	-
28	G/W	REVERSE SIGNAL

Terminal No.	Color of Wire	Signal Name
29	-	-
30	W	AUDIO L
31	R	AUDIO GND
32	B	AUDIO R
33	B	GND
34	W	CAMERA ON
35	SHIELD	COMP-
36	R	COMP+
37	G/R	IGN
38	-	-
39	-	-
40	-	-
41	SHIELD	MIC GND
42	W	MIC VCC
43	B	MIC SIGNAL
44	BR	ILL (-)

Connector No.	M56
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-
9	SHIELD	-
12	B	-
13	W	-
14	B	-

Connector No.	M73
Connector Name	BACK-UP LAMP RELAY
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	G	-
2	R	-
3	G	-
5	G/W	-
6	W/B	-
7	Y/R	-

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/B	-
5	W/B	-

Connector No.	M101
Connector Name	JOINT CONNECTOR-M03
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	G/R	-
8	G/R	-
18	V	-
19	V	-
20	V	-

ABNIA6317GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]

Connector No.	M110
Connector Name	CENTER SPEAKER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/B	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	M102
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
15	B	-
16	R	-
18	BR	-

Connector No.	M112
Connector Name	AUDIO AMP.
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	BAT
2	W	WOOFER 1+
3	BR/W	WOOFER 2+
4	B	GND
17	Y/G	BAT
18	B	WOOFER 1-
19	BR	WOOFER 2-
20	B	GND

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

ABNIA6318GB




# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]


Connector No.	M115
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
2	W	-
3	G	-
4	R	-
6	L	-

Terminal No.	Color of Wire	Signal Name
13	W/B	FR RH TW+
14	L/W	FR LH TW+
15	L/W	FR LH OUT+
16	W/B	FR RH OUT+
21	W	FR RH IN+
22	Y	FR LH IN+
23	L	RR RH IN+
24	BR	RR LH IN+
25	-	-
26	L/B	CIR OUT-
27	B/Y	RR LH OUT-
28	R/L	RR RH OUT-
29	L/B	FR RH TW-
30	L/R	FR LH TW-
31	L/R	FR LH OUT-
32	L/B	FR RH OUT-

Connector No.	M113
Connector Name	AUDIO AMP.
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	B	FR RH IN-
6	BR	FR LH IN-
7	B/W	RR RH IN-
8	B/R	RR LH IN-
9	G/W	AMP ON
10	L/W	CIR OUT+
11	SB	RR LH OUT+
12	O/L	RR RH OUT+

Connector No.	M185
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM)
Connector Color	-




Terminal No.	Color of Wire	Signal Name
52	B	SAT ANT
53	B	SAT SHIELD

Connector No.	M184
Connector Name	AV CONTROL UNIT (WITH NAVIGATION SYSTEM)
Connector Color	-



Terminal No.	Color of Wire	Signal Name
50	B	GPS ANT
51	B	GPS SHIELD

Connector No.	M162
Connector Name	JOINT CONNECTOR-M10
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
3	SHIELD	-
4	SHIELD	-
5	SHIELD	-
6	SHIELD	-
7	SHIELD	-
11	B	-
12	B	-
17	SHIELD	-

ABNIA6319GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AV

# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]


Connector No.	M201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	-
9	SHIELD	-
12	B	-
13	W	-
14	B	-

Terminal No.	Color of Wire	Signal Name
17	SHIELD	-
18	Y	-
19	BR	-
20	L	-
21	B/W	-
22	G/Y	-
23	BR	-
24	SB	-


Connector No.	M195
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	Y	-
3	G	-
4	R	-
5	W	-
6	B	-
7	SHIELD	-
8	V	-
9	SHIELD	-
14	B/Y	-
15	B/W	-

Terminal No.	Color of Wire	Signal Name
6	-	-
7	-	-
8	-	-
9	S/B	AUDIO ON
10	BR	ILL-
11	S/B	FES ENABLE
12	R/L	LIGHTING SW
13	-	-
14	-	-
15	V	ACC
16	Y	B+

Connector No.	M205
Connector Name	DVD PLAYER
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	B	FES L+ OUTPUT
2	W	FES L- OUTPUT
3	R	FES R+ OUTPUT
4	G	FES R- OUTPUT
5	-	-


ABNIA6320GB

# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]


Connector No.	M211
Connector Name	AUX JACK (WITH REAR ENTERTAINMENT SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
3	R	-
5	B	-
6	W	-

Terminal No.	Color of Wire	Signal Name
27	B/Y	GND
28	Y	DATA RX
29	BR	DATA TX
30	-	-
31	SB	+B
32	BR	+B

Connector No.	M206
Connector Name	DVD PLAYER
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
17	R	FES OUTPUT COMMON
18	B	FES L+ OUTPUT
19	B/W	GND
20	W	FES R+ OUTPUT
21	G/Y	SW POWER +5V
22	B	GND
23	B/W	VTR+
24	L	VTR-
25	-	-
26	SHIELD	VTR SHIELD

Connector No.	M214
Connector Name	USB INTERFACE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-
3	R	-
4	W	-
5	SHIELD	-

Connector No.	M213
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
2	W	-
3	G	-
4	R	-
6	L	-

Connector No.	M212
Connector Name	AUX JACK (WITHOUT REAR ENTERTAINMENT SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
4	W	-

ABNIA6321GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]


Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	R	-


Terminal No.	Color of Wire	Signal Name
17	SHIELD	-
18	Y	-
19	BR	-
20	L	-
21	B/W	-
22	G/Y	-
23	BR	-
24	SB	-

Connector No.	M215
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	Y	-
3	G	-
4	R	-
5	W	-
6	B	-
7	SHIELD	-
8	V	-
9	SHIELD	-
14	B/Y	-
15	B/W	-


Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	G	REVERSE LAMP

Terminal No.	Color of Wire	Signal Name
24C	SHIELD	-
25C	W	-
28C	B	-
29C	R	-

Connector No.	E41
Connector Name	WIRE TO WIRE
Connector Color	GRAY



ABNIA6322GB


# NAVIGATION SYSTEM

< WIRING DIAGRAM >


[NAVIGATION]

Terminal No.	Color of Wire	Signal Name
7G	Y	-
13G	B	-
14G	SHIELD	-
23G	R	-
24G	W	-
27G	G/W	-
64G	R	-
94G	G/W	-
95G	G	-
98G	W/B	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
27	W/B	T TOW REV LAMP

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
7	O	REV LAMP RLY

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	R	-

Connector No.	F9
Connector Name	A/T ASSEMBLY (FLOOR SHIFT)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
7	R	-

ABNIA6323GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]


Connector No.	C8
Connector Name	WIRE TO WIRE
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	SHIELD	-
6	B	-

Terminal No.	Color of Wire	Signal Name
24C	SHIELD	-
25C	W	-
28C	B	-
29C	R	-


Connector No.	C1
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	B/Y	-
15	SB	-

ABNIA6324GB

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
14	R/L	-
15	O/L	-

Connector No.	B76
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-(EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	B/Y	-(EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)


Connector No.	B72
Connector Name	SUBWOOFER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	BR/W	-
4	BR	-

Terminal No.	Color of Wire	Signal Name
17	B	-
18	L	-
19	G	-
20	L	-
21	W	-
22	G/Y	-
23	BR	-
24	SB	-

Connector No.	B146
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
3	G	-
4	R	-
7	SHIELD	-
14	B/Y	-
15	B/W	-
16	W	-

ABNIA6325GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# NAVIGATION SYSTEM


< WIRING DIAGRAM >

[NAVIGATION]

Terminal No.	Color of Wire	Signal Name
87A	G	-
88A	R	-
89A	W	-
90A	B	-

Terminal No.	Color of Wire	Signal Name
3A	O/L	-(EXCEPT FOR KING CAB WITH BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
4A	R/L	-
72A	SHIELD	-
73A	L	-
74A	B/W	-
75A	R	-
78A	L	-
79A	G	-
80A	SHIELD	-
81A	B/Y	-
82A	W	-
83A	G/Y	-
84A	BR	-
85A	SB	-
86A	SHIELD	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	T2
Connector Name	REAR VIEW CAMERA
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	B	-
6	SHIELD	-

Connector No.	T1
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
3	R	-
4	SHIELD	-
6	B	-

Connector No.	B159
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O/L	-(EXCEPT BASE AUDIO SYSTEM OR MID AUDIO SYSTEM)
2	R/L	-

ABNIA6326GB



# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]

Connector No.	R107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-
4	B	-

Connector No.	R9
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-(WITH NAVI)
2	R/W	-
4	B	-


Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-(WITH NAVI)
5	R/W	-(WITH NAVI)
12	SHIELD	-(WITH NAVI)

Terminal No.	Color of Wire	Signal Name
19	G	-
20	L	-
21	W	-
22	G/Y	-
23	BR	-
24	SB	-

Connector No.	R201
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
3	G	-
4	R	-
7	SHIELD	-
14	B/Y	-
15	B/W	-
16	W	-
17	B	-
18	L	-

Connector No.	R109
Connector Name	MICROPHONE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R/L	-
4	R/W	-


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]


Connector No.	R204
Connector Name	REAR CONTROL ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	G	-
4	R	-
8	GY	-
13	R	-
15	B	-


Terminal No.	Color of Wire	Signal Name
11	SB	FILTERED BATT
12	BR	FILTERED BATT

Connector No.	R202
Connector Name	VIDEO MONITOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B/W	GND
2	B/Y	GND
3	B	ID
4	-	-
5	G	DATA RX
6	L	DATA TX
7	W	VIDEO IN+
8	L	VIDEO IN-
9	-	-
10	GY	SW POWER +5V

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	L/B	-
5	W/B	-

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	L/R	-
11	L/W	-

ABNIA6328GB

# NAVIGATION SYSTEM

< WIRING DIAGRAM >


[NAVIGATION]

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	– (WITH NAVI OR MID AUDIO SYSTEM)
2	Y	– (WITH NAVI OR MID AUDIO SYSTEM)

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	Y	– (WITH NAVI OR MID AUDIO SYSTEM)
15	L	– (WITH NAVI OR MID AUDIO SYSTEM)

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W/B	–
2	L/B	–

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	– (WITH NAVI OR MID AUDIO SYSTEM)
2	R/L	–

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
14	R/L	–
15	L	– (WITH NAVI OR MID AUDIO SYSTEM)

Connector No.	D208
Connector Name	REAR DOOR TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	SB	–
2	B/Y	–

ABNIA6329GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

Connector No.	D308
Connector Name	REAR DOOR TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	O/L	-
2	R/L	-

ABNIA6330GB


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000009876603

#### OVERALL SEQUENCE



#### DETAILED FLOW

### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

### 2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected. Refer to [AV-338, "Symptom Table"](#).

>> GO TO 3

### 3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[NAVIGATION]

---

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

## 4. REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

## 5. FINAL CHECK

---

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2

## INSPECTION AND ADJUSTMENT

## ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT

## ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT : Description

INFOID:000000009876604

## BEFORE REPLACEMENT

When replacing AV control unit, save or print current vehicle specification with CONSULT configuration before replacement.

**NOTE:**

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing AV control unit.

## AFTER REPLACEMENT

**CAUTION:**

When replacing AV control unit, you must perform "After Replace ECU" with CONSULT.

- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.

## ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT : Work Procedure

INFOID:000000009876605

## 1. SAVING VEHICLE SPECIFICATION

## ④-CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

**NOTE:**

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing AV control unit.

>> GO TO 2.

## 2. REPLACE AV CONTROL UNIT

Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).

>> GO TO 3.

## 3. WRITING VEHICLE SPECIFICATION

## ④CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [AV-288, "CONFIGURATION \(AV CONTROL UNIT\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [AV-288, "CONFIGURATION \(AV CONTROL UNIT\) : Work Procedure"](#).

>> GO TO 4.

## 4. OPERATION CHECK

Check that the operation of the AV control unit and camera images (fixed guide lines) are normal.

>> Work End.

## CONFIGURATION (AV CONTROL UNIT)

## CONFIGURATION (AV CONTROL UNIT) : Description

INFOID:000000009876606

Vehicle specification needs to be written with CONSULT because it is not written after replacing AV control unit.

Configuration has three functions as follows:

Function	Description
"Before Replace ECU"	<ul style="list-style-type: none"> <li>• Reads the vehicle configuration of current AV control unit.</li> <li>• Saves the read vehicle configuration.</li> </ul>
"After Replace ECU"	Writes the vehicle configuration with manual selection.
"Select Saved Data List"	Writes the vehicle configuration with saved data.

**CAUTION:**

- When replacing AV control unit, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new AV control unit.

## CONFIGURATION (AV CONTROL UNIT) : Work Procedure

INFOID:000000009876607

**1. WRITING MODE SELECTION****CONSULT**

Select "Reprogramming, Configuration" of AV control unit.

When writing saved data >> GO TO 2.

When writing manually >> GO TO 3.

**2. PERFORM "SAVED DATA LIST"****CONSULT**

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

**3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"****CONSULT**

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [AV-289. "CONFIGURATION \(AV CONTROL UNIT\) : Configuration List"](#).
3. Confirm and/or change setting value for each item.

**CAUTION:**

**Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.**

4. Select "Next".

**CAUTION:**

**Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new AV control unit is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.**

5. When "Completed", select "End".

>> GO TO 4.

**4. OPERATION CHECK**

Confirm that each function controlled by AV control unit operates normally.



# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[NAVIGATION]

>> Work End.

## CONFIGURATION (AV CONTROL UNIT) : Configuration List

INFOID:000000009876608

### CAUTION:

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

MANUAL SETTING ITEM	
Items	Setting value
SOUND SYSTEM	BASE ⇔ BOSE
CAMERA SYSTEM	NONE/AVM ⇔ REAR CAMERA

⇔: Items which confirm vehicle specifications

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### DTC Logic

INFOID:000000009876609

#### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1000]	AV control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system.

#### Diagnosis Procedure

INFOID:000000009876610

### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Perform Self Diagnostic Result for MULTI AV.

#### Is CAN COMM CIRCUIT displayed?

- YES >> Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).
- NO >> Refer to [GI-42, "Intermittent Incident"](#).

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U1010 CONTROL UNIT (CAN)

### DTC Logic

INFOID:000000009876611

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CONTROL UNIT (CAN) [U1010]	Error during CAN controller hardware initialization (VCAN).	Replace the AV control unit if the malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# U1217 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U1217 AV CONTROL UNIT

### DTC Logic

INFOID:000000009876612

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
BLUETOOTH MODULE [U1217]	Connection failure to the internal Bluetooth <sup>®</sup> sub unit is detected.	Replace AV control unit if malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .

# U1229 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U1229 AV CONTROL UNIT

### DTC Logic

INFOID:000000009876613

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
iPod CERTIFICATION [U1229]	iPod authentication chip error.	Replace AV control unit if malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U122F AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U122F AV CONTROL UNIT

### DTC Logic

INFOID:000000009876614

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Digital broadcasting connection error [U122F]	Communication error with digital audio broadcast module internal to AV control unit.	Replace AV control unit if malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .

# U1244 GPS ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U1244 GPS ANTENNA

### DTC Logic

INFOID:000000009876615

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
GPS ANTENNA CONN [U1244]	Open or short to ground is detected in GPS antenna connection.	<ul style="list-style-type: none"><li>• GPS antenna disconnection.</li><li>• Open or short to ground in GPS antenna signal circuit.</li></ul>

### Diagnosis Procedure

INFOID:000000009876616

Regarding Wiring Diagram information, refer to [AV-264, "Wiring Diagram"](#).

### 1. GPS ANTENNA INSPECTION

Visually inspect the GPS antenna and antenna feeder. Refer to [AV-364, "Removal and Installation"](#).

Is inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning components.

### 2. CHECK AV CONTROL UNIT VOLTAGE

1. Disconnect AV control unit connector M184.
2. Turn ignition switch ON.
3. Check voltage between AV control unit terminal 50 and ground.

AV control unit terminal	Ground	Voltage
(+)	(-)	
50	—	5.0 V

Is inspection result normal?

YES >> Replace GPS antenna. Refer to [AV-364, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# U1258 SATELLITE RADIO ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U1258 SATELLITE RADIO ANTENNA

### DTC Logic

INFOID:000000009876617

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
XM ANTENNA CONN [U1258]	Open or short to ground is detected in satellite antenna connection.	<ul style="list-style-type: none"><li>Satellite antenna disconnection.</li><li>Open or short to ground in satellite antenna signal circuit.</li></ul>

### Diagnosis Procedure

INFOID:000000009876618

Regarding Wiring Diagram information, refer to [AV-264, "Wiring Diagram"](#).

### 1. SATELLITE ANTENNA INSPECTION

Visually inspect the satellite antenna and antenna feeder. Refer to [AV-364, "Removal and Installation"](#).

Is inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning components.

### 2. CHECK AV CONTROL UNIT VOLTAGE

1. Disconnect AV control unit connector M185.
2. Turn ignition switch ON.
3. Check voltage between AV control unit terminal 52 and ground.

AV control unit terminal	Ground	Voltage
(+)	(-)	
52	—	5.0 V

Is inspection result normal?

YES >> Replace satellite radio antenna. Refer to [AV-364, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).



U1263 USB

DTC Logic

INFOID:000000009876619

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
USB OVERCURRENT [U1263]	Overcurrent in USB harness is detected.	<ul style="list-style-type: none"> <li>Device connected to USB interface.</li> <li>Harness between the AV control unit and USB interface.</li> </ul>

DTC CONFIRMATION PROCEDURE

1. PERFORM SELF DIAGNOSTIC RESULT

- If there is a device connected to the USB interface, disconnect it.
- Turn ignition switch ON and wait for 2 seconds or more.
- Perform Self Diagnostic Result for MULTI AV.

Is DTC U1263 displayed?

- YES >> Refer to [AV-297, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009876620

1. CHECK USB INTERFACE HARNESS

Visually inspect USB interface harness. Refer to [AV-363, "Removal and Installation"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace USB interface harness. Refer to [AV-363, "Removal and Installation"](#).

2. CHECK USB INTERFACE HARNESS

Check USB interface harness. Refer to [AV-337, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).
- NO >> Replace USB interface harness. Refer to [AV-363, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U1265 AUDIO AMP.

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U1265 AUDIO AMP.

### DTC Logic

INFOID:000000009876621

CONSULT Display	DTC Detection Condition	Possible Cause
AMP ON TERMINAL [U1265]	Open or short to ground is detected in audio amp. ON signal circuit.	Open or short to ground in audio amp. ON signal circuit.

### Diagnosis Procedure

INFOID:000000009876622

Regarding Wiring Diagram information, refer to [AV-264, "Wiring Diagram"](#).

#### 1. CHECK CONTINUITY BETWEEN AV CONTROL UNIT AND AUDIO AMP.

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M43 and audio amp. connector M113.
3. Check continuity between AV control unit connector M43 and audio amp. connector M113.

AV control unit		Audio amp.		Continuity
Connector	Terminal	Connector	Terminal	
M43	1	M113	9	Yes

4. Check continuity between AV control unit connector M43 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M43	1	—	No

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness or connectors.

#### 2. CHECK AV CONTROL UNIT VOLTAGE

1. Connect AV control unit connector M43.
2. Turn ignition switch ON.
3. Check voltage between AV control unit connector M43 and ground.

AV control unit		Ground	Voltage (Approx.)
(+)			
Connector	Terminal	(-)	
M43	1	—	Battery voltage

Is the inspection result normal?

- YES >> Replace audio amp. Refer to [AV-360, "Removal and Installation"](#).  
NO >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).

# U12AA CONFIGURATION ERROR

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U12AA CONFIGURATION ERROR

### DTC Logic

INFOID:000000009876623

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Configuration Error [U12AA]	AV control unit is not properly configured or configuration is corrupt.	Configuration data needs to be written. Refer to <a href="#">AV-288, "CONFIGURATION (AV CONTROL UNIT) : Work Procedure"</a> .

### Diagnosis Procedure

INFOID:000000009876624

#### 1.PERFORM CONFIGURATION

When U12AA is detected, configuration data must be written.

>> Write configuration data with CONSULT. Refer to [AV-288, "CONFIGURATION \(AV CONTROL UNIT\) : Work Procedure"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U12AB ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U12AB ANTENNA

### DTC Logic

INFOID:000000009876625

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
FM Antenna error [U12AB]	Open or short to ground is detected in rod antenna connection.	<ul style="list-style-type: none"><li>• Rod antenna disconnection.</li><li>• Open or short to ground in antenna feeder.</li></ul>

### Diagnosis Procedure

INFOID:000000009876626

Regarding Wiring Diagram information, refer to [AV-264, "Wiring Diagram"](#).

### 1. ROD ANTENNA INSPECTION

Visually inspect the rod antenna and antenna feeder. Refer to [AV-361, "Location of Antenna"](#).

Is inspection result normal?

- YES >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).  
NO >> Repair or replace malfunctioning components.

# U12AC AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U12AC AV CONTROL UNIT

### DTC Logic

INFOID:000000009876627

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Display Temperature too High [U12AC]	Display temperature has exceeded maximum temperature. Display is switched OFF to avoid irreversible damage.	Replace AV control unit if malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U12AD AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U12AD AV CONTROL UNIT

### DTC Logic

INFOID:000000009876628

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
ECU Temperature too High [U12AD]	AV control unit temperature has exceeded maximum temperature.	Replace AV control unit if malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .

# U12AE AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U12AE AV CONTROL UNIT

### DTC Logic

INFOID:000000009876629

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Internal Amplifier temperature Warning [U12AE]	Internal amplifier temperature has exceeded maximum temperature.	Replace AV control unit if malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# U12AF AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U12AF AV CONTROL UNIT

### DTC Logic

INFOID:000000009876630

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CD Mechanism Temperature Warning [U12AF]	CD drive temperature has exceeded maximum temperature. CD drive is switched OFF to avoid irreversible damage.	Replace AV control unit if malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .



# U12B0 POWER SUPPLY VOLTAGE

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U12B0 POWER SUPPLY VOLTAGE

### DTC Logic

INFOID:000000009876631

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Supply Voltage Goes below 9V > 20s [U12B0]	AV control unit supply voltage exceeds lower limits.	<ul style="list-style-type: none"><li>Charging system malfunction.</li><li>AV control unit power supply or ground circuits.</li></ul>

### Diagnosis Procedure

INFOID:000000009876632

#### 1. CHECK CHARGING SYSTEM

Check the vehicle charging system. Refer to [CHG-4, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-7, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning components.

#### 2. CHECK AV CONTROL UNIT POWER SUPPLY AND GROUND CIRCUITS

Perform the AV control unit power supply and ground circuit diagnosis procedure. Refer to [AV-308, "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace the AV control unit. Refer to [AV-353, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# U12B1 POWER SUPPLY VOLTAGE

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U12B1 POWER SUPPLY VOLTAGE

### DTC Logic

INFOID:000000009876633

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Supply Voltage Goes High > 16V for 20s [U12B1]	AV control unit supply voltage exceeds upper limits.	Charging system malfunction.

### Diagnosis Procedure

INFOID:000000009876634

#### 1. CHECK CHARGING SYSTEM

Check the vehicle charging system. Refer to [CHG-4, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-7, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).

Is the inspection result normal?

- YES >> Replace the AV control unit. Refer to [AV-353, "Removal and Installation"](#).
- NO >> Repair or replace the malfunctioning components.

# U1310 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## U1310 AV CONTROL UNIT

### DTC Logic

INFOID:000000009876635

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CONTROL UNIT (AV) [U1310]	Error during CAN controller hardware initialization (MCAN).	Replace AV control unit if malfunction occurs constantly. Refer to <a href="#">AV-353, "Removal and Installation"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## POWER SUPPLY AND GROUND CIRCUIT

### AV CONTROL UNIT

#### AV CONTROL UNIT : Diagnosis Procedure

INFOID:000000009876636

Regarding Wiring Diagram information, refer to [AV-264. "Wiring Diagram"](#).

### 1.CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
7	ACC power supply	4 (10A)
19	Battery power supply	31 (20A)
37	Ignition power supply	12 (10A)

Are the fuses blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect AV control unit connectors M43 and M45.
3. Check voltage between AV control unit connector M43, M45 and ground.

AV control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M43	19	—	Ignition switch: OFF	Battery voltage
	7		Ignition switch: ON	
M45	37			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

### 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between AV control unit connector M43 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M43	20	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

### AUDIO AMP.

#### AUDIO AMP. : Diagnosis Procedure

INFOID:000000009876637

Regarding Wiring Diagram information, refer to [AV-264. "Wiring Diagram"](#).

### 1.CHECK FUSE

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Check that the audio amp. fuses are not blown.

Unit	Terminal	Signal name	Fuse No.
Audio amp.	1	Battery power	31
	17		17

**Are the fuses OK?**


YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

## 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio amp. connector.
3. Check voltage between audio amp. harness connector M112 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
M112	1	Ground	Battery voltage
	17		



**Is battery voltage present?**


YES >> GO TO 3.

NO >> Check harness between audio amp. and fuse.

## 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio amp. connector.
3. Check continuity between audio amp. harness connector M112 and ground.

Connector	Terminal	—	Continuity
M112	4	Ground	Yes
	20		



**Does continuity exist?**

YES >> Inspection End.

NO >> Repair harness or connector.

## DVD PLAYER

### DVD PLAYER : Diagnosis Procedure

INFOID:000000010621044

Regarding Wiring Diagram information, refer to [AV-264, "Wiring Diagram"](#).

## 1.CHECK FUSE

Check that the following fuses for the DVD player are not blown.

Unit	Terminal	Signal name	Fuse No.
DVD player	16	Battery power	31
	15	Ignition switch ACC or ON	4

**Is the fuse OK?**

YES >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

# POWER SUPPLY AND GROUND CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## 2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect DVD player connector M205.
2. Check voltage between the DVD player connector M205 and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M205	16	Ground	Battery voltage	Battery voltage	Battery voltage
	15		0V	Battery voltage	Battery voltage



Are the voltage results as specified?

YES >> GO TO 3.

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 3. GROUND CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect DVD player connector M206.
3. Check continuity between DVD player harness connector M206 terminal 22 and ground.

Connector	Terminal	—	Continuity
M206	22	Ground	Yes

Are the continuity results as specified?

YES >> Inspection End.

NO >> Repair harness or connector.



## VIDEO MONITOR

### VIDEO MONITOR : Diagnosis Procedure

INFOID:000000010621045

Regarding Wiring Diagram information, refer to [AV-264, "Wiring Diagram"](#).

## 1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch to ACC.
2. Check voltage between video monitor harness connector R202 and ground.


(+)		(-)	Value (Approx.)
Connector	Terminal		
R202	11	Ground	12V
	12		

Does specified voltage exist?

YES >> GO TO 3.

NO >> GO TO 2.

## 2. CHECK POWER SUPPLY CIRCUIT




# POWER SUPPLY AND GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

1. Turn ignition switch OFF.
2. Disconnect the video monitor connector R202 and the DVD player connector M206.
3. Check continuity between the video monitor harness connector R202 (A) and the DVD player connector M206 (B).



A		B		Continuity
Connector	Terminal	Connector	Terminal	
R202	11	M206	31	Yes
	12		32	

4. Check continuity between video monitor harness connector R202 (A) and ground.

A		—	Continuity
Connector	Terminal		
R202	11	Ground	No
	12		


### Are continuity test results as specified?

YES >> Refer to [AV-309. "DVD PLAYER : Diagnosis Procedure"](#).

NO >> Repair harness or connector.

## 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect video monitor connector.
3. Check continuity between video monitor harness connector R202 and ground.



Connector	Terminal	—	Continuity
R202	3	Ground	Yes

### Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.

# FRONT DOOR SPEAKER

[NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

## FRONT DOOR SPEAKER

### Diagnosis Procedure

INFOID:000000009876638

Regarding Wiring Diagram information, refer to [AV-264. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2. SPEAKER HARNESS CHECK

1. Disconnect audio amp. connector M113 and suspect front door speaker connector.
2. Check continuity between audio amp. harness connector M113 and suspect front door speaker harness connector.

Connector	Terminal	Connector	Terminal	Continuity
M113	15	D12	1	Yes
	31		2	
	16	D112	1	
	32		2	

3. Check continuity between audio amp. harness connector M113 and ground.

Connector	Terminal	—	Continuity
M113	15	Ground	No
	31		
	16		
	32		

Are continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. FRONT DOOR SPEAKER SIGNAL CHECK

1. Connect audio amp. connector M113 and suspect front door speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connector M113 terminals with CONSULT or oscilloscope.



# FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
M113	15	31	Receive audio signal	
	16	32		

Is audio signal voltage as specified?

YES >> Replace suspect front door speaker. Refer to [AV-232, "Removal and Installation"](#).

NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect AV control unit connector M43 and audio amp. connector M113.
2. Check continuity between AV control unit harness connector M43 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M43	3	M113	6	Yes
	2		22	
	12		5	
	11		21	

3. Check continuity between AV control unit harness connector M43 and ground.

Connector	Terminal	—	Continuity
M43	3	Ground	No
	2		
	12		
	11		

Are continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.

## 5. PRE-AMP SIGNAL CHECK


1. Connect AV control unit connector and audio amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M43 terminals with CONSULT or oscilloscope.

AV

# FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace audio amp. Refer to [AV-360, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).

FRONT TWEETER

Diagnosis Procedure

INFOID:000000009876639

Regarding Wiring Diagram information, refer to [AV-264. "Wiring Diagram"](#).

1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

2. HARNESS CHECK

1. Disconnect audio amp. connector M113 and suspect front tweeter connector.
2. Check continuity between audio amp. harness connector M113 and suspect front tweeter harness connector.

Connector	Terminal	Connector	Terminal	Continuity
M113	14	M109	1	Yes
	30		2	
	13	M111	1	
	29		2	

3. Check continuity between audio amp. harness connector M113 and ground.

Connector	Terminal	—	Continuity
M113	14	Ground	No
	30		
	13		
	29		

Are continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. FRONT TWEETER SIGNAL CHECK


1. Connect audio amp. connector M113 and suspect front tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connector M113 terminals with CONSULT or oscilloscope.

AV

# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
M113	14	30	Receive audio signal	
	13	29		

Is audio signal voltage as specified?

- YES >> Replace suspect front tweeter. Refer to [AV-354, "Removal and Installation"](#).  
 NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect AV control unit connector M43 and audio amp. connector M113.
2. Check continuity between AV control unit harness connector M43 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M43	3	M113	6	Yes
	2		22	
	12		5	
	11		21	

3. Check continuity between AV control unit harness connector M43 and ground.

Connector	Terminal	—	Continuity
M43	3	Ground	No
	2		
	12		
	11		

Are continuity test results as specified?

- YES >> GO TO 5.  
 NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.


## 5. PRE-AMP SIGNAL CHECK

1. Connect AV control unit connector and audio amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M43 terminals with CONSULT or oscilloscope.

# FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace audio amp. Refer to [AV-360, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# CENTER SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## CENTER SPEAKER

### Diagnosis Procedure

INFOID:000000009876640

Regarding Wiring Diagram information, refer to [AV-264. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2. CENTER SPEAKER HARNESS CHECK

1. Disconnect audio amp. connector M113 and center speaker connector M110.
2. Check continuity between audio amp. harness connector M113 (A) and center speaker harness connector M110 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M113	10	M110	1	Yes
	26		2	

3. Check continuity between audio amp. harness connector M113 (A) and ground.

A		—	Continuity
Connector	Terminal		
M113	10	Ground	No
	26		



Are continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. CENTER SPEAKER SIGNAL CHECK

1. Connect audio amp. connector M113 and center speaker connector M110.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connector M113 terminals with CONSULT or oscilloscope.



# CENTER SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M113	10	26	Receive audio signal	

Is the audio signal voltage reading as specified?

- YES >> Replace center speaker. Refer to [AV-355. "Removal and Installation"](#).
- NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect AV control unit connector M43 and audio amp. connector M113.
2. Check continuity between AV control unit harness connector M43 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M43	3	M113	6	Yes
	2		22	
	12		5	
	11		21	

3. Check continuity between AV control unit harness connector M43 and ground.

Connector	Terminal	—	Continuity
M43	3	Ground	No
	2		
	12		
	11		

Are continuity test results as specified?

- YES >> GO TO 5.
- NO >>
  - Check connector housings for disconnected or loose terminals.
  - Repair harness or connector.

## 5. PRE-AMP SIGNAL CHECK

1. Connect AV control unit connector and audio amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M43 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	2	3	Receive audio signal	
	11	12		

AV

## CENTER SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

---

Are the audio signal voltage readings as specified?

YES >> Replace audio amp. Refer to [AV-360, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).



# REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## REAR DOOR SPEAKER

### Diagnosis Procedure

INFOID:000000009876641

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CONNECTOR CHECK

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.


### 2. SPEAKER HARNESS CHECK

1. Disconnect audio amp. connectors M113 and suspect rear door speaker connector.
2. Check continuity between audio amp. harness connectors M113 (A) and suspect rear door speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M113	11	D207 (crew cab) B76 (king cab)	1	Yes
	27		2	
	12	D307 (crew cab) B159 (king cab)	1	
	28		2	

3. Check continuity between audio amp. harness connectors M113 (A) and ground.

Connector	Terminal	-	Continuity
M113	11	Ground	No
	27		
	12		
	28		



Are the continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. SPEAKER SIGNAL CHECK

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


AV


# REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

1. Connect audio amp. connectors and suspect rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connectors M113 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M113	11	27	Receive audio signal	
	12	28		



Are audio signal voltage readings as specified?

YES >> Replace suspect rear door speaker. Refer to [AV-233](#), "[Removal and Installation](#)".

NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect AV control unit connector M43 and audio amp. connector M113.
2. Check continuity between AV control unit harness connector M43 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M43	5	M113	8	Yes
	4		24	
	14		7	
	13		23	

3. Check continuity between AV control unit harness connector M43 and ground.

Connector	Terminal	—	Continuity
M43	5	Ground	No
	4		
	14		
	13		

Are the continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.  
• Repair harness or connector.


## 5. PRE-AMP SIGNAL CHECK

1. Connect AV control unit connector M43 and audio amp. connector M113.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M43 terminals with CONSULT or oscilloscope.

# REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	4	5	Receive audio signal	
	13	14		

SKIA0177E

Is the audio signal voltage reading as specified?

- YES >> Replace audio amp. Refer to [AV-360, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

REAR DOOR TWEETER

Diagnosis Procedure

INFOID:000000009876642

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

**1. CONNECTOR CHECK**

Check the audio amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Repair the terminal and connector.

**2. TWEETER HARNESS CHECK**

1. Disconnect audio amp. connectors M113 and suspect rear door tweeter connector.
2. Check continuity between audio amp. harness connectors M113 and suspect rear door tweeter harness connector.

Connector	Terminal	Connector	Terminal	Continuity
M113	11	D208	1	Yes
	27		2	
	12	D308	1	
	28		2	

3. Check continuity between audio amp. harness connectors M113 and ground.

Connector	Terminal	-	Continuity
M113	11	Ground	No
	27		
	12		
	28		

Are the continuity test results as specified?

- YES >> GO TO 3.
- NO >> Repair harness or connector.


**3. TWEETER SIGNAL CHECK**

1. Connect audio amp. connectors and suspect rear door tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connectors M113 terminals with CONSULT or oscilloscope.

# REAR DOOR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M113	11	27	Receive audio signal	
	12	28		

SKIA0177E

Are audio signal voltage readings as specified?

- YES >> Replace suspect rear door tweeter. Refer to [AV-357, "Removal and Installation"](#).  
 NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect AV control unit connector M43 and audio amp. connector M113.
2. Check continuity between AV control unit harness connector M43 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M43	5	M113	8	Yes
	4		24	
	14		7	
	13		23	

3. Check continuity between AV control unit harness connector M43 and ground.


Connector	Terminal	—	Continuity
M43	5	Ground	No
	4		
	14		
	13		

Are the continuity test results as specified?

- YES >> GO TO 5.  
 NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

## 5. PRE-AMP SIGNAL CHECK

1. Connect AV control unit connector M43 and audio amp. connector M113.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M43 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	4	5	Receive audio signal	
	13	14		

SKIA0177E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

## REAR DOOR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

---

Is the audio signal voltage reading as specified?

YES >> Replace audio amp. Refer to [AV-360](#). "Removal and Installation".

NO >> Replace AV control unit. Refer to [AV-353](#). "Removal and Installation".

# SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## SUBWOOFER

### Description

INFOID:000000009876643

The AV control unit sends audio signals to the audio amp. The audio amp. amplifies the audio signals before sending them to the subwoofer using the audio signal circuits.

### Diagnosis Procedure

INFOID:000000009876644

Regarding Wiring Diagram information, refer to [AV-264, "Wiring Diagram"](#).

### 1.CONNECTOR CHECK

Check the audio amp. and subwoofer connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminal and connector.

### 2.SUBWOOFER HARNESS CHECK

1. Disconnect audio amp. connector M112 and subwoofer connector B72.
2. Check continuity between audio amp. harness connector M112 and subwoofer harness connector B72.

Connector	Terminal	Connector	Terminal	Continuity
M112	2	B72	1	Yes
	3		3	
	18		2	
	19		4	

3. Check continuity between audio amp. harness connector M112 and ground.

A		—	Continuity
Connector	Terminal		
M112	2	Ground	No
	3		
	18		
	19		

Are the continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3.SUBWOOFER SIGNAL CHECK

1. Connect audio amp. connector M112 and subwoofer connector B72.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio amp. harness connector M112 terminals with CONSULT or oscilloscope.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M112	2	18	Receive audio signal	
	3	19		

SKIA0177E

Is the audio signal voltage as specified?

- YES >> Replace subwoofer. Refer to [AV-358. "Removal and Installation"](#).  
 NO >> GO TO 4.

## 4. PRE-AMP HARNESS CHECK

1. Disconnect AV control unit connector M43 and audio amp. connector M113.
2. Check continuity between AV control unit harness connector M43 and audio amp. harness connector M113.

Connector	Terminal	Connector	Terminal	Continuity
M43	5	M113	8	Yes
	4		24	
	14		7	
	13		23	

3. Check continuity between AV control unit harness connector M43 and ground.


Connector	Terminal	—	Continuity
M43	5	Ground	No
	4		
	14		
	13		

Are the continuity test results as specified?

- YES >> GO TO 5.  
 NO >> • Check connector housings for disconnected or loose terminals.  
 • Repair harness or connector.

## 5. PRE-AMP SIGNAL CHECK

1. Connect AV control unit connector M43 and audio amp. connector M113.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M43 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M43	4	5	Receive audio signal	
	13	14		

SKIA0177E



# SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Is the audio signal voltage reading as specified?

YES >> Replace audio amp. Refer to [AV-360. "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-353. "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

# AMP ON SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## AMP ON SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:000000009876645

Regarding Wiring Diagram information, refer to [AV-264, "Wiring Diagram"](#).

#### 1. CHECK AMP ON SIGNAL

1. Turn audio system ON.
2. Check voltage between audio amp. harness connector M113 terminal 9 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
M113	9	Ground	More than 6.5V

Is inspection result normal?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK AMP ON SIGNAL (AV CONTROL UNIT)

Check voltage between AV control unit harness connector M43 terminal 1 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
M43	1	Ground	More than 6.5V

Is inspection result normal?

- YES >> Repair harness or connector.  
NO >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).

# REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:00000009876646

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

### 1. CHECK REVERSE INPUT SIGNAL

1. Turn ignition switch ON.
2. Shift the selector lever to R (reverse).
3. Check voltage between AV control unit connector M45 and ground.

AV control unit		Ground	Condition	Voltage (Approx.)
(+)		(-)		
Connector	Terminal			
M45	28	—	Selector lever in R (reverse)	Battery Voltage

Is inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK CAMERA POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M45 and rear view camera connector T2.
3. Check continuity between AV control unit connector M45 and rear view camera connector T2.

AV control unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M45	34	T2	1	Yes

4. Check continuity between AV control unit connector M45 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M45	34		No

Is inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

### 3. CHECK CAMERA POWER SUPPLY VOLTAGE

1. Connect AV control unit connector M45 and rear view camera connector T2.
2. Turn ignition switch ON.
3. Shift the selector lever to R (reverse).
4. Check voltage between AV control unit connector M45 and ground.

AV control unit		Ground	Condition	Voltage (Approx.)
(+)		(-)		
Connector	Terminal			
M45	34	—	Selector lever is in "R".	6.0 V

Is inspection result normal?

YES >> GO TO 4.

NO >> Replace AV control unit. Refer to [AV-353. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
P

AV

# REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## 4. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M45 and rear view camera connector.
3. Check continuity between AV control unit connector M45 and rear view camera connector T2.

AV control unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M45	36	T2	3	Yes

4. Check continuity between AV control unit connector M45 terminal 36 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M45	36		No

Is inspection result normal?

- YES >> GO TO 5.  
 NO >> Repair or replace harness or connectors.

## 5. CHECK CAMERA GROUND CIRCUIT CONTINUITY

Check continuity between AV control unit connector M45 and rear view camera connector T2.


AV control unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M45	33	T2	4	Yes

Is inspection result normal?

- YES >> GO TO 6.  
 NO >> Repair or replace harness or connectors.

## 6. CHECK CAMERA IMAGE SIGNAL

1. Connect AV control unit connector M45 and rear view camera connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R (reverse).
4. Check signal between AV control unit connector M45 and ground.

AV control unit		Ground	Condition	Reference value
(+)		(-)		
Connector	Terminal			
M45	36	—	Camera image displayed.	 <p style="text-align: right; font-size: small;">SKIB2251J</p>

Is inspection result normal?

- YES >> Replace AV control unit. Refer to [AV-353, "Removal and Installation"](#).  
 NO >> Replace rear view camera. Refer to [AV-367, "Removal and Installation"](#).

# MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## MICROPHONE SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:000000009876647

Regarding Wiring Diagram information, refer to [AV-264. "Wiring Diagram"](#).

### 1. CHECK MICROPHONE SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M45 and microphone connector R109.
3. Check continuity between AV control unit connector M45 and microphone connector R109.

AV control unit		Microphone		Continuity
Connector	Terminal	Connector	Terminal	
M45	41	R109	2	Yes
	42		4	
	43		1	

4. Check continuity between AV control unit connector M45 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M45	41	—	No
	42		
	43		

Is inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness or connectors.

### 2. CHECK MICROPHONE VCC VOLTAGE

1. Connect AV control unit connector M45.
2. Turn ignition switch ON.
3. Check voltage between terminals of AV control unit connector M45.

AV control unit connector		Voltage (Approx.)
(+)	(-)	
Terminal	Terminal	
42	41	5.0 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace AV control unit. Refer to [AV-353. "Removal and Installation"](#).

### 3. CHECK MICROPHONE SIGNAL


1. Connect microphone connector.
2. Check signal between terminals of AV control unit connector M45.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

AV control unit connector		Condition	Reference value
(+)	(-)		
Terminal	Terminal		
42	43	Speak into microphone.	 <p>(V)</p> <p>1</p> <p>0</p> <p>-1</p> <p>2ms</p> <p>SKIB3609E</p>

Is the inspection result normal?

- YES >> Replace AV control unit. Refer to [AV-353. "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-366. "Removal and Installation"](#).

# STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

## STEERING SWITCH







### Diagnosis Procedure

INFOID:000000009876648

Regarding Wiring Diagram information, refer to [AV-264. "Wiring Diagram"](#).

### 1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Disconnect combination switch connector M102.
2. Check resistance between combination switch connector terminals.

Terminal	Signal name	Condition	Resistance (Ω) (Approx.)	
16	18	Volume (down)	Depress  switch.	1
		Volume (up)	Depress  switch.	121
		Phone end	Depress  switch.	321
15	18	Source	Depress SOURCE switch.	1
		Seek (up)	Depress  switch.	121
		Seek (down)	Depress  switch.	321
		Phone/Send	Depress  switch.	723

Do the steering wheel audio control switches check OK?

YES >> GO TO 2.

NO >> Replace steering wheel audio control switch. Refer to [AV-359. "Removal and Installation"](#).

### 2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M43 and combination switch connector M30.
3. Check continuity between AV control unit harness connector M43 and combination switch harness connector M30.

AV control unit		Combination switch		Continuity
Connector	Terminal	Connector	Terminal	
M43	6	M30	24	Yes
	15		31	
	16		25	

4. Check continuity between AV control unit connector M43 and ground.

AV control unit		—	Continuity
Connector	Terminal		
M43	6	Ground	No
	15		
	16		

Are the continuity results as specified?

YES >> GO TO 3.

NO >> Repair harness.

### 3. SPIRAL CABLE CHECK

# STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Check continuity between combination switch harness connectors M30 and M102.

Combination switch				Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	15	Yes
	31		18	
	25		16	

Does the spiral cable check OK?

YES >> Inspection End.

NO >> Replace spiral cable. Refer to [SR-13, "Removal and Installation"](#).



## USB CONNECTOR

### Diagnosis Procedure

INFOID:000000009876649

Regarding Wiring Diagram information, refer to [AV-172. "Wiring Diagram"](#).

#### 1. CHECK USB INTERFACE HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M42 and USB interface connector M124.
3. Check continuity between AV control unit connector M42 and USB interface connector M124.

AV control unit		USB interface		Continuity
Connector	Terminal	Connector	Terminal	
M42	48	M124	3	Yes
	45		4	
	47		2	
	46		1	
	49		5	

4. Check continuity between AV control unit connector M42 and ground.

AV control unit		—	Continuity
Connector	Terminal		
M42	48	Ground	No
	47		

Is the inspection result normal?

- YES >> Replace the USB interface. Refer to [AV-363. "Removal and Installation"](#).  
 NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# SYMPTOM DIAGNOSIS

## MULTI AV SYSTEM

### Symptom Table

INFOID:000000009876650

#### RELATED TO AUDIO

Symptoms	Check items	Probable malfunction location
The disk cannot be removed.	AV control unit	Malfunction in AV control unit. Refer to <a href="#">AV-253. "On Board Diagnosis Function"</a> .

# MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptoms	Check items	Probable malfunction location
<p>No sound comes out or the level of the sound is low.</p>	<p>No sound from all speakers.</p>	<ul style="list-style-type: none"> <li>• Speaker circuit shorted to ground. Refer to <a href="#">AV-264, "Wiring Diagram"</a>.</li> <li>• Amp ON signal circuit malfunction. Refer to <a href="#">AV-330, "Diagnosis Procedure"</a>.</li> <li>• Audio amp. power supply and ground circuits malfunction. Refer to <a href="#">AV-308, "AUDIO AMP. : Diagnosis Procedure"</a>.</li> </ul>
	<p>Only a certain speaker (front door speaker LH, front door speaker RH, front speaker LH, front speaker RH, center speaker, rear door speaker LH, rear door speaker RH, rear speaker LH, rear speaker RH) does not output sound.</p>	<ul style="list-style-type: none"> <li>• Poor connector connection of speaker.</li> <li>• Sound signal circuit malfunction between AV control unit and audio amp. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-312, "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-315, "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-318, "Diagnosis Procedure"</a> (center speaker).</li> <li>- <a href="#">AV-321, "Diagnosis Procedure"</a> (rear door speaker).</li> <li>- <a href="#">AV-324, "Diagnosis Procedure"</a> (rear door tweeter).</li> <li>- <a href="#">AV-327, "Diagnosis Procedure"</a> (sub-woofer).</li> </ul> </li> <li>• Sound signal circuit malfunction between audio amp. and speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-312, "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-315, "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-318, "Diagnosis Procedure"</a> (center speaker).</li> <li>- <a href="#">AV-321, "Diagnosis Procedure"</a> (rear door speaker).</li> <li>- <a href="#">AV-324, "Diagnosis Procedure"</a> (rear door tweeter).</li> <li>- <a href="#">AV-327, "Diagnosis Procedure"</a> (sub-woofer).</li> </ul> </li> <li>• Malfunction in speaker. Refer to:                             <ul style="list-style-type: none"> <li>- <a href="#">AV-356, "Removal and Installation"</a> (front door speaker).</li> <li>- <a href="#">AV-354, "Removal and Installation"</a> (front tweeter).</li> <li>- <a href="#">AV-355, "Removal and Installation"</a> (center speaker).</li> <li>- <a href="#">AV-357, "Removal and Installation"</a> (rear door speaker).</li> <li>- <a href="#">AV-357, "Removal and Installation"</a> (rear door tweeter).</li> <li>- <a href="#">AV-358, "Removal and Installation"</a> (sub-woofer).</li> </ul> </li> <li>• Malfunction in AV control unit. Refer to <a href="#">AV-253, "On Board Diagnosis Function"</a>.</li> <li>• Malfunction in audio amp. Replace Audio amp. Refer to <a href="#">AV-360, "Removal and Installation"</a>.</li> </ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptoms	Check items	Probable malfunction location
	Noise comes out from all speakers.	<ul style="list-style-type: none"> <li>• Malfunction in AV control unit. Refer to <a href="#">AV-253. "On Board Diagnosis Function"</a>.</li> <li>• Malfunction in audio amp. Replace audio amp. Refer to <a href="#">AV-360. "Removal and Installation"</a>.</li> </ul>
Noise is mixed with audio.	Noise comes out only from a certain speaker (front door speaker LH, front door speaker RH, front speaker LH, front speaker RH, center speaker, rear door speaker LH, rear door speaker RH, rear speaker LH, rear speaker RH).	<ul style="list-style-type: none"> <li>• Poor connector connection of speaker.</li> <li>• Sound signal circuit malfunction between AV control unit and audio amp. Refer to:               <ul style="list-style-type: none"> <li>- <a href="#">AV-312. "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-315. "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-318. "Diagnosis Procedure"</a> (center speaker).</li> <li>- <a href="#">AV-321. "Diagnosis Procedure"</a> (rear door speaker).</li> <li>- <a href="#">AV-324. "Diagnosis Procedure"</a> (rear door tweeter).</li> <li>- <a href="#">AV-327. "Diagnosis Procedure"</a> (sub-woofer).</li> </ul> </li> <li>• Sound signal circuit malfunction between audio amp. and speaker. Refer to:               <ul style="list-style-type: none"> <li>- <a href="#">AV-312. "Diagnosis Procedure"</a> (front door speaker).</li> <li>- <a href="#">AV-315. "Diagnosis Procedure"</a> (front tweeter).</li> <li>- <a href="#">AV-318. "Diagnosis Procedure"</a> (center speaker).</li> <li>- <a href="#">AV-321. "Diagnosis Procedure"</a> (rear door speaker).</li> <li>- <a href="#">AV-324. "Diagnosis Procedure"</a> (rear door tweeter).</li> <li>- <a href="#">AV-327. "Diagnosis Procedure"</a> (sub-woofer).</li> </ul> </li> <li>• Malfunction in speaker.</li> <li>• Poor Installation of speaker (e.g. backlash and looseness). Refer to:               <ul style="list-style-type: none"> <li>- <a href="#">AV-356. "Removal and Installation"</a> (front door speaker).</li> <li>- <a href="#">AV-354. "Removal and Installation"</a> (front tweeter).</li> <li>- <a href="#">AV-355. "Removal and Installation"</a> (center speaker).</li> <li>- <a href="#">AV-357. "Removal and Installation"</a> (rear door speaker).</li> <li>- <a href="#">AV-357. "Removal and Installation"</a> (rear door tweeter).</li> <li>- <a href="#">AV-358. "Removal and Installation"</a> (sub-woofer).</li> </ul> </li> <li>• Malfunction in AV control unit. Refer to <a href="#">AV-253. "On Board Diagnosis Function"</a>.</li> <li>• Malfunction in audio amp. Replace audio amp. Refer to <a href="#">AV-360. "Removal and Installation"</a>.</li> </ul>
	Noise is mixed with radio only (when the vehicle hits a bump or while driving over bad roads)	Poor connector connection of antenna or antenna feeder. Refer to <a href="#">AV-361. "Location of Antenna"</a> .

# MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptoms	Check items	Probable malfunction location
No radio reception or poor reception.	<ul style="list-style-type: none"> <li>Other audio sounds are normal.</li> <li>Any radio station cannot be received or poor reception is caused even after moving to a service area with good reception (e.g. a place with clear view and no obstacles generating external noises).</li> </ul>	<ul style="list-style-type: none"> <li>Antenna amp. ON signal circuit malfunction. Refer to <a href="#">AV-255, "Reference Value"</a>.</li> <li>Poor connector connection of antenna or antenna feeder. Refer to <a href="#">AV-361, "Location of Antenna"</a>.</li> </ul>
No satellite radio reception.	<p>There is malfunction in the CONSULT self diagnosis result.</p> <p>Refer to <a href="#">AV-254, "CONSULT Function"</a>.</p>	<ul style="list-style-type: none"> <li>Malfunction in antenna, antenna feeder or AV control unit. Perform DTC diagnosis. Refer to <a href="#">AV-296, "Diagnosis Procedure"</a>.</li> <li>Poor continuity in antenna feeder.</li> <li>Poor connector connection of antenna or antenna feeder. Refer to <a href="#">AV-296, "Diagnosis Procedure"</a>.</li> </ul>
	<p>There is no malfunction in the CONSULT self diagnosis result.</p> <p>Refer to <a href="#">AV-254, "CONSULT Function"</a>.</p>	<ul style="list-style-type: none"> <li>Poor continuity in antenna feeder.</li> <li>Poor connector connection of antenna or antenna feeder.</li> <li>Loose satellite radio antenna mounting nut. Refer to <a href="#">AV-361, "Location of Antenna"</a>.</li> </ul>
Buzz/rattle sound from speaker	<p>The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.</p>	<p>Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.</p>

## RELATED TO HANDS-FREE PHONE

- Before performing diagnosis, confirm that the cellular phone being used by the customer is compatible with the vehicle.
- It is possible that a malfunction is occurring due to a version change of the phone even though the phone is a compatible type. This can be confirmed by changing the cellular phone to another compatible type, and check that it operates normally. It is important to determine whether the cause of the malfunction is the vehicle or the cellular phone.

### Check Compatibility

- Make sure the customer's Bluetooth® related concern is understood.
- Verify the customer's concern.
 

**NOTE:**  
The customer's phone may be required, depending upon their concern.
- Write down the customer's phone brand, model and service provider.
 

**NOTE:**  
It is necessary to know the service provider. On occasion, a given phone may be on the approved list with one provider, but may not be on the approved list with other providers.
- Go to "www.nissanusa.com/bluetooth/".
  - Using the website's search engine, find out if the customer's phone is on the approved list.
  - If the customer's phone is NOT on the approved list:
 

Stop diagnosis here. The customer needs to obtain a Bluetooth® phone that is on the approved list before any further action.
  - If the feature related to the customer's concern shows as "N" (not compatible):
 











Stop diagnosis here. If the customer still wants the feature to function, they will need to get an approved phone showing the feature as "Y" (compatible) in the "Basic Features".
  - If the feature related to the customer's concern shows as "Y" (compatible):
 

Perform diagnosis as per the following table.

# MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptoms	Check items	Probable malfunction location
Does not recognize cellular phone connection (no connection is displayed on the display at the guide).	Repeat the registration of cellular phone.	Malfunction in AV control unit. Replace AV control unit. Refer to <a href="#">AV-353, "Removal and Installation"</a> .
Hands-free phone cannot be established.	<ul style="list-style-type: none"> <li>Hands-free phone operation can be made, but the communication cannot be established.</li> <li>Hands-free phone operation can be performed, however, voice between each other cannot be heard during the conversation.</li> </ul>	
The other party's voice cannot be heard by hands-free phone.	Check the "microphone speaker" in Inspection & Adjustment Mode if sound is heard.	
Originating sound is not heard by the other party with hands-free phone communication.	Sound operation function is normal.	Microphone signal circuit malfunction. Refer to <a href="#">AV-333, "Diagnosis Procedure"</a> .
	Sound operation function does not work.	
The system cannot be operated.	<ul style="list-style-type: none"> <li>The voice recognition can be controlled.</li> <li>Steering switch's , , , and  switch works, but   does not work.</li> </ul>	Steering switch malfunction. Replace steering switch. Refer to <a href="#">AV-359, "Removal and Installation"</a> .
	Steering switch's  ,  ,  , and  switches do not work.	Steering switch signal circuit malfunction. Refer to <a href="#">AV-335, "Diagnosis Procedure"</a> .
	All steering switches do not work.	Steering switch ground circuit malfunction. Refer to <a href="#">AV-335, "Diagnosis Procedure"</a> .

## RELATED TO NAVIGATION

Symptoms	Check items	Probable malfunction location
Navigation system is inoperative.	Navigation malfunction.	<ul style="list-style-type: none"> <li>Malfunction in SD card.</li> <li>Malfunction in AV control unit. Refer to <a href="#">AV-253, "On Board Diagnosis Function"</a>.</li> </ul>
	Steering switches malfunction.	Steering switch signal circuit malfunction. Refer to <a href="#">AV-335, "Diagnosis Procedure"</a> .
	Voice activated control malfunction.	Microphone signal circuit malfunction. Refer to <a href="#">AV-333, "Diagnosis Procedure"</a> . Steering switch signal circuit malfunction. Refer to <a href="#">AV-335, "Diagnosis Procedure"</a> .

## RELATED TO REAR VIEW CAMERA

Symptoms	Check items	Probable malfunction location
Rear view camera is inoperative.	Reverse signal circuit malfunction.	Reverse signal circuit malfunction between BCM and AV control unit. Refer to <a href="#">AV-331, "Diagnosis Procedure"</a> .
	Camera image signal circuit malfunction.	Camera image signal circuit malfunction between rear view camera and AV control unit. Refer to <a href="#">AV-331, "Diagnosis Procedure"</a> .
	Rear view camera malfunction.	Replace rear view camera. Refer to <a href="#">AV-367, "Removal and Installation"</a> .

## DVD PLAYER

# MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptom	Possible cause	Reference page
DVD player inoperative	<ul style="list-style-type: none"> <li>DVD player power and ground circuit</li> <li>DVD player</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-309</a></li> <li><a href="#">AV-369</a></li> </ul>
No sound when playing a DVD	<ul style="list-style-type: none"> <li>Audio signal circuits</li> <li>AV control unit</li> <li>DVD player</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-255</a></li> <li><a href="#">AV-255</a></li> <li><a href="#">AV-369</a></li> </ul>
Video monitor is inoperative/does not display properly	<ul style="list-style-type: none"> <li>Power supply and ground circuits</li> <li>Video out circuit</li> <li>DVD player</li> <li>Video monitor</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-310</a></li> <li><a href="#">AV-262</a></li> <li><a href="#">AV-369</a></li> <li><a href="#">AV-369</a></li> </ul>
Rear control assembly is inoperative/does not operate properly	<ul style="list-style-type: none"> <li>DVD player</li> <li>Rear control assembly</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-369</a></li> <li><a href="#">AV-368</a></li> </ul>
Headphones inoperative	<ul style="list-style-type: none"> <li>Headphone batteries</li> <li>Headphone audio signal circuits from AV control unit</li> <li>AV control unit</li> <li>Rear control assembly</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">AV-255</a></li> <li><a href="#">AV-353</a></li> <li><a href="#">AV-368</a></li> </ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000009876651

#### RELATED TO NOISE

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

#### NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

#### Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> <li>• Ignition components</li> </ul>
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> <li>• Fuel pump condenser</li> </ul>
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> <li>• Relay malfunction, AV control unit malfunction</li> </ul>
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> <li>• Motor case ground</li> <li>• Motor</li> </ul>
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> <li>• Rear defogger coil malfunction</li> <li>• Open circuit in printed heater</li> <li>• Poor ground of antenna feeder line</li> </ul>
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> <li>• Ground wire of body parts</li> <li>• Ground due to improper part installation</li> <li>• Wiring connections or a short circuit</li> </ul>

#### RELATED TO HANDS-FREE PHONE

Symptom	Cause and Counter measure
Does not recognize cellular phone connection (No connection is displayed on the display at the guide).	<p>Some Bluetooth<sup>®</sup> enabled cellular phones may not be recognized by the in-vehicle phone module.</p> <p>Refer to "RELATED TO HANDS-FREE PHONE (Check Compatibility)" in <a href="#">AV-338, "Symptom Table"</a>.</p>
Cannot use hands-free phone.	<p>Customer will not be able to use a hands-free phone under the following conditions:</p> <ul style="list-style-type: none"> <li>• The vehicle is outside of the telephone service area.</li> <li>• The vehicle is in an area where it is difficult to receive radio waves; such as in a tunnel, in an underground parking garage, near a tall building or in a mountainous area.</li> <li>• The cellular phone is locked to prevent it from being dialed.</li> </ul> <p><b>NOTE:</b></p> <p>While a cellular phone is connected through the Bluetooth<sup>®</sup> wireless connection, the battery power of the cellular phone may discharge quicker than usual. The Bluetooth<sup>®</sup> Hands-Free Phone System cannot charge cellular phones.</p>



# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptom	Cause and Counter measure
The other party's voice cannot be heard by hands-free phone.	When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
Poor sound quality.	Do not place the cellular phone in an area surrounded by metal or far away from the in-vehicle phone module to prevent tone quality degradation and wireless connection disruption.

## RELATED TO NAVIGATION

### Basic Operation

Symptom	Cause	Remedy
No image is shown.	Display brightness adjustment is set fully to DARK side.	Adjust the display brightness.
No guide sound is heard. Audio guide volume is too low or too high.	Volume control is set to OFF, MIN or MAX.	Adjust the audio guide volume.
	Audio guidance is not available while the vehicle is driving on a dark pink route.	System is not malfunctioning.
Screen is too dark. Motion of the image is too slow.	Temperature inside the vehicle is low.	Wait until the temperature inside the vehicle reaches the proper temperature.
Small black or bright spots appear on the screen.	Symptom peculiar to a liquid crystal display (display unit).	System is not malfunctioning.

### Vehicle Mark

Symptom	Cause	Remedy
Map screen and BIRDVIEW™ Name of the place vary with the screen.	Some thinning of the character data is done to prevent the display becoming to complex. In some cases and in some locations, the display contents may differ. The same place name, street name, etc. may not be displayed every time on account of the data processing.	System is not malfunctioning.
Vehicle mark is not positioned correctly.	Vehicle is transferred by ferry or by towing after its ignition switch is turned to OFF.	Drive the vehicle for a while in the GPS satellite signal receiving condition.
Screen will not switch to nighttime mode after the lighting switch is turned ON.	The daytime screen is selected by the "SWITCH SCREENS" when the last time the screen dimming setting is done. Switching between daytime/nighttime screen may be inhibited by the automatic illumination adjustment function.	Perform screen dimming and select the nighttime screen by "SWITCH SCREENS".
Map screen will not scroll in accordance with the vehicle travel.	Current location is not displayed.	Press "MAP" button to display the current location.
Vehicle mark will not be shown.	Current location is not displayed.	Press "MAP" button to display the current location.
Accuracy indicator (GPS satellite mark) on the map screen stays gray.	GPS satellite signal is intercepted because the vehicle is in or behind a building.	Move the vehicle out to an open space.
	GPS satellite signal cannot be received because an obstacle is placed on top of the instrument panel.	Do not place anything on top of the meter display (instrument panel).
	GPS satellites are not visible from current location.	Wait until GPS satellites are visible by moving the vehicle.

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptom	Cause	Remedy
Vehicle location accuracy is low.	Accuracy indicator (GPS satellite mark) on the map screen stays gray.	Current location is not determined.
	Vehicle speed setting by the vehicle speed pulse has been deviated (advanced or retarded) from the actual vehicle speed because tire chain is fitted or the system has been used on another vehicle.	Drive the vehicle for a while [for approx. 30 minutes at approx. 30 km/h (19 MPH)] and the deviation will be automatically adjusted. If advancement or retard still occur, perform the distance adjustment by CONFIRMATION/ADJUSTMENT mode of diagnosis function.
	Map data has error or omission. (Vehicle mark is always deviated to the same position.)	As a rule, an updated map DVD-ROM will be released once a year.

### Destination, Passing Points and Menu Items Cannot be Selected/Set

Symptom	Cause	Remedy
Destination cannot be set.	Destination to be set is on an expressway.	Set the destination on an ordinary road.
Passing point is not searched when re-searching the route.	The vehicle has already passed the passing point, or the system judged so.	To include the passing points that have been passed into the route again, set the route again.
Route information will not be displayed.	Route searching has not been done.	Set the destination and perform route searching.
	Vehicle mark is not on the recommended route.	Drive on the recommended route.
	Route guide is turned OFF.	Turn route guide ON.
	Route information is not available on the dark pink route.	System is not malfunctioning.
After the route searching, no guide sign will appear as the vehicle goes near the entrance/exit to the toll road.	Vehicle mark is not on the recommended route. (On the display, only guide signs related to the recommended route will be shown.)	Drive on the recommended route.
Automatic route searching is not possible.	Vehicle is driving on a highway (gray route), or no recommended route is available.	Drive on a road to be searched. Or re-search the route manually. In this case, however, the whole route will be searched.
Performed automatic detour search (or detour search). However, the result is the same as that of the previous search.	Performed search with every conditions considered. However, the result is the same as that of the previous search.	System is not malfunctioning.
Passing points cannot be set.	More than five passing points were set.	Passing points can be set up to five. To stop at more than five points, perform sharing in several steps.
When setting the route, the starting point cannot be selected.	The current vehicle location is always set as the starting point of a route.	System is not malfunctioning.
Some menu items cannot be selected.	The vehicle is being driven.	Stop the vehicle at a safe place and then operate the system.

### Voice Guide

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptom	Cause	Remedy	A
Voice guide will not operate.	Note: Voice guide is only available at intersections that satisfy certain conditions (indicated by ● on the map). Therefore, guidance may not be given even when the route on the map changes direction.	System is not malfunctioning.	B
	The vehicle is not on the recommended route.	Return to the recommended route or re-search the route.	C
	Voice guide is turned OFF.	Turn voice guide ON.	D
	Route guide is turned OFF.	Turn route guide ON.	E
Voice guide does not match the actual road pattern.	Voice guide may vary with the direction to which the vehicle is turn and the connection of the road to other roads.	Drive in conformity to the actual traffic rules.	F

## Route Search

Symptom	Cause	Remedy	G
No route is shown.	No road to be searched is found around the destination.	Find wider road (orange road or wider) nearby and reset the destination and passing points onto it. Take care of the traveling direction when there are separate up and down roads.	H
	Starting point and the destination are too close.	Set the destination at more distant point.	I
	Conditional traffic regulation (day of the week/ time of the day) is set at the area around the current location or the destination.	Turn the time-regulating search conditions OFF. Turn "Avoid regulation time" in the search conditions OFF.	J
Indicated route is intermittent.	In some areas, highways (gray routes) are not used for the search <sup>(Note)</sup> . Therefore, the route to the current location or the passing points may be intermittent.	System is not malfunctioning.	K
When the vehicle has passed the recommended route, it is deleted from the screen.	A recommended route is controlled by each section. When the vehicle has passed the passing point 1, then the map data from the starting point up to the passing point 1 will be deleted. (The data may remain undeleted in some area.)	System is not malfunctioning.	L
Detouring route is recommended.	In some areas, highways (gray routes) are not used for the search. (Note). Therefore, detour route may be recommended.	Set the route closer to the basic route (gray route).	M
	A detour route may be shown when some traffic regulation (one-way traffic, etc.) is set at the area around the starting point or the destination.	Slightly move the starting point or the destination, or set the passing point on the route of your choice.	N
	In the area where highways (gray routes) are used for the search, left turn has priority around the current location and the destination (passing points). For this reason, the recommended route may be detouring.	System is not malfunctioning.	O
Landmarks on the map do not match the actual ones.	This can be happen due to omission or error in the map data.	As a rule, an updated map DVD-ROM will be released once a year. Wait until the latest map has become available.	P
Recommended route is far from the starting point, passing points, and destination.	Starting point, passing points, and destination of the route guide were set far from the desired points because route searching data around these area were not stored.	Reset the destination onto the road nearby. If this road is one of the highways (gray routes), an ordinary road nearby may be displayed as the recommended route.	Q

**NOTE:**

Except for the ordinance-designated cities. (Malfunctioning areas may be changed in the updated map disc.)


### Examples of Current-Location Mark Displacement

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]







Vehicle's travel amount is calculated by reading its travel distance and turning angle. Therefore, if the vehicle is driven in the following manner, an error will occur in the vehicle's current location display. If correct location has not been restored after driving the vehicle for a while, perform location correction.



# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]





Cause (condition) –: While driving    ooo: Display	Driving condition	Remarks (correction, etc.)
Y-intersections  <small>ELK0192D</small>	At a Y intersection or similar gradual division of roads, an error in the direction of travel deduced by the sensor may result in the current-location mark appearing on the wrong road.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
Spiral roads  <small>ELK0193D</small>	When driving on a large, continuous spiral road (such as loop bridge), turning angle error is accumulated and the vehicle mark may deviate from the correct location.	
Straight roads  <small>ELK0194D</small>	When driving on a long, straight road and slow curve without stopping, map-matching does not work effectively enough and distance errors may accumulate. As a result, the vehicle mark may deviate from the correct location when the vehicle is turned at a corner.	
Zigzag roads  <small>ELK0195D</small>	When driving on a zigzag road, the map may be matched to other roads in the similar direction nearby at every turn, and the vehicle mark may deviate from the correct location.	
Roads laid out in a grid pattern  <small>ELK0196D</small>	When driving where roads are laid out in a grid pattern, or where many roads are running in the similar direction nearby, the map may be matched to them by mistake and the vehicle mark may deviate from the correct location.	
Parallel roads  <small>ELK0197D</small>	When two roads are running in parallel (such as highway and sideway), the map may be matched to the other road by mistake and the vehicle mark may deviate from the correct location.	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >



[NAVIGATION]

	Cause (condition)    -: While driving    ooo: Display	Driving condition	Remarks (correction, etc.)
Place	In a parking lot  SEL709V	When driving in a parking lot, or other location where there are no roads on the map, matching may place the vehicle mark on a nearby road. When the vehicle returns to the road, the vehicle mark may have deviated from the correct location. When driving in circle or turning the steering wheel repeatedly, direction errors accumulate, and the vehicle mark may deviate from the correct location.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
	Turntable  SEL710V	When the ignition switch is OFF, the navigation system cannot get the signal from the gyroscope (angular speed sensor). Therefore, the displayed direction may be wrong and the correct road may not be easily returned to after rotating the vehicle on a turntable with the ignition OFF.	
	Slippery roads	On snow, wet roads, gravel, or other roads where tires may slip easily, accumulated mileage errors may cause the vehicle mark to deviate from the correct road.	
	Slopes	When parking in sloped garages, when travelling on banked roads, or in other cases where the vehicle turns when tilted, an error in the turning angle will occur, and the vehicle mark may deviate from the road.	
Map data	Road not displayed on the map screen  SEL699V	When driving on new roads or other roads not displayed on the map screen, map matching does not function correctly and matches the location to a nearby road. When the vehicle returns to a road which is on the map, the vehicle mark may deviate from the correct road.	
	Different road pattern (Changed due to repair)  ELK0201D	If the road pattern stored in the map data and the actual road pattern are different, map matching does not function correctly and matches the location to a nearby road. The vehicle mark may deviate from the correct road.	
Vehicle	Use of tire chains	When tire chains are used, the mileage is not correctly detected, and the vehicle mark may deviate from the correct road.	Drive the vehicle for a while. If the distance still deviates, adjust it by using the distance adjustment function. (If the tire chain is removed, recover the original value.)

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Cause (condition) –: While driving    ooo: Display	Driving condition	Remarks (correction, etc.)
Precautions for driving	Just after the engine is started	If the vehicle is driven just after the engine is started when the gyroscope (angular speed sensor) correction is not completed, the vehicle can lose its direction and may have deviated from the correct location.  Wait for a short while before driving after starting the engine.
	Continuous driving without stopping	When driving long distances without stopping, direction errors may accumulate, and the current-location mark may deviate from the correct road.  Stop and adjust the orientation.
	Abusive driving	Spinning the wheels or engaging in other kinds of abusive driving may result in the system being unable perform correct detection, and may cause the vehicle mark to deviate from the correct road.  If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
How to correct location	Position correction accuracy 	If the accuracy of location settings is poor, accuracy may be reduced when the correct road cannot be found, particularly in places where there are many roads.  Enter in the road displayed on the screen with an accuracy of approx. 1mm. Caution: Whenever possible, use detailed map for the correction.
	Direction when location is corrected 	If the accuracy of location settings during correction is poor, accuracy may be reduced afterwards.  Perform direction correction.

### Location Correction by Map-Matching is Slow

- The map-matching function needs to refer to the data of the surrounding area. It is necessary to drive some distance for the function to work.
- Because map-matching operates on this principle, when there are many roads running in similar directions in the surrounding area, no matching determination may be made. The location may not be corrected until some special feature is found.

### Name of Road is Not Displayed

The current road name may not be displayed if there are no road names displayed on the map screen.

### Contents of Display Differ for Birdview™ and the (Flat) Map Screen

Difference of the BIRDVIEW™ screen from the flat map screen are as follows.

- The current place name displays names which are primarily in the direction of vehicle travel.
- The amount of time before the vehicle travel or turn angle is updated on the screen is longer than for the (flat) map display.
- The conditions for display of place names, roads, and other data are different for nearby areas and for more distant areas.
- Some thinning of the character data is done to prevent the display becoming too complex. In some cases and in some locations, the display contents may differ.
- The same place name, street name, etc. may be displayed multiple times.

### Vehicle Mark Shows a Position Which is Completely Wrong

In the following cases, the vehicle mark may appear on completely different position in the map depending on the GPS satellite signal receiving conditions. In this case, perform location correction and direction correction.

- When location correction has not been done
- If the receiving conditions of the GPS satellite signal is poor, if the vehicle mark becomes out of place, it may move to a completely different location and not come back if location correction is not done. The position will be corrected if the GPS signal can be received.
- When the vehicle has traveled by ferry, or when the vehicle has been being towed

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

- Because calculation of the current location cannot be done when traveling with the ignition off, for example when traveling by ferry or when being towed, the location before travel is displayed. If the precise location can be detected with GPS, the location will be corrected.

### Vehicle Mark Jumps

In the following cases, the vehicle mark may appear to jump as a result of automatic correction of the current location.

- When map matching has been done
- If the current location and the vehicle mark are different when map matching is done, the vehicle mark may seem to jump. At this time, the location may be “corrected” to the wrong road or to a location which is not on a road.
- When GPS location correction has been done
- If the current location and the vehicle mark are different when the location is corrected using GPS measurements, the vehicle mark may seem to jump. At this time, the location may be “corrected” to a location which is not on a road.

### Vehicle Mark is in a River or Sea

The navigation system moves the vehicle mark with no distinction between land and rivers or sea. If the vehicle mark is somehow out of place, it may appear that the vehicle is driving in a river or the sea.

### Vehicle Mark Automatically Rotates

The system wrongly memorizes the rotating status as stopping when the ignition switch is turned ON with the turntable rotating. That causes the vehicle mark to rotate when the vehicle is stopped.

### When Driving on Same Road, Sometimes Vehicle Mark is in Right Place and Sometimes it is in Wrong Place

The conditions of the GPS antenna (GPS data) and gyroscope (angular speed sensor) change gradually. Depending on the road traveled and the operation of the steering wheel, the location detection results will be different. Therefore, even on a road on which the location has never been wrong, conditions may cause the vehicle mark to deviate.



## REMOVAL AND INSTALLATION

### AV CONTROL UNIT

#### Removal and Installation

INFOID:000000009876652

#### REMOVAL

**CAUTION:**

**Before replacing AV control unit, perform "READ CONFIGURATION" to save current vehicle specification. Refer to [AV-288, "CONFIGURATION \(AV CONTROL UNIT\) : Description"](#).**

1. Disconnect the battery negative terminal. Refer to [PG-79, "Removal and Installation"](#).
2. Remove the cluster lid C. Refer to [IP-15, "Removal and Installation"](#).
3. Remove the AV control unit.
  - a. Remove the AV control unit screws using power tool.
  - b. Pull the AV control unit out from the instrument panel.
  - c. Disconnect the harness connectors from the AV control unit.

#### INSTALLATION

**CAUTION:**

**• When replacing AV control unit, perform "WRITE CONFIGURATION". Refer to [AV-288, "CONFIGURATION \(AV CONTROL UNIT\) : Description"](#).**

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

AV

O  
P

## FRONT TWEETER


### Removal and Installation

INFOID:000000009876653

### FRONT TWEETER

#### Removal

1. Remove the front tweeter grille. Refer to [IP-11, "Removal and Installation"](#).
2. Remove the front tweeter clips (A).
3. Disconnect the front tweeter harness connector.
4. Remove the front tweeter (1).



#### Installation

Installation is in the reverse order of removal.

# CENTER SPEAKER

< REMOVAL AND INSTALLATION >

[NAVIGATION]

## CENTER SPEAKER


### Removal and Installation

INFOID:000000009876654

#### CENTER SPEAKER

##### Removal

1. Remove the center console. Refer to [IP-20, "Removal and Installation"](#).
2. Remove the cluster lid D. Refer to [IP-15, "Removal and Installation"](#).
3. Remove the center speaker screws.
4. Disconnect the center speaker harness connector.
5. Remove the center speaker.



##### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[NAVIGATION]

## FRONT DOOR SPEAKER


### Removal and Installation

INFOID:000000009876655

### FRONT DOOR SPEAKER

#### Removal

1. Remove the front door finisher. Refer to [INT-10, "Removal and Installation"](#).
2. Remove the four front door speaker screws.
3. Disconnect the front door speaker harness connector.
4. Remove the front door speaker.



#### Installation

Installation is in the reverse order of removal.

# REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[NAVIGATION]

## REAR DOOR SPEAKER


### Removal and Installation

INFOID:000000009876656

#### REAR DOOR SPEAKER

##### Removal

1. Remove the rear door finisher. Refer to [INT-10, "Removal and Installation"](#) (Crew Cab) or [INT-10, "Removal and Installation"](#) - King Cab.
2. Remove the three rear door speaker screws.
3. Disconnect the rear door speaker harness connector.
4. Remove the rear door speaker.




##### Installation

Installation is in the reverse order of removal.

#### REAR DOOR TWEETER

##### Removal

1. Remove the rear door finisher. Refer to [INT-10, "Removal and Installation"](#).
2. Remove the rear door tweeter screws.
3. Remove the rear door tweeter.
4. Disconnect the rear door tweeter harness connector.



##### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# SUBWOOFER

< REMOVAL AND INSTALLATION >

[NAVIGATION]

## SUBWOOFER


### Removal and Installation

INFOID:000000009876657

#### SUBWOOFER

##### Removal

1. Remove the LH front seat. Refer to [SE-34, "Removal and Installation - Front Seat Assembly"](#).
2. Disconnect the subwoofer harness connector (B).
  - ⇐: Vehicle front
3. Remove the subwoofer bolts (A).
4. Remove the subwoofer (1).



##### Installation

Installation is in the reverse order of removal.

# STEERING SWITCH


< REMOVAL AND INSTALLATION >

[NAVIGATION]

## STEERING SWITCH

### Removal and Installation

INFOID:000000010159267



1. Steering wheel audio control switches 2. Steering wheel

### STEERING WHEEL AUDIO CONTROL SWITCHES

#### Removal

1. Remove the steering wheel. Refer to [ST-22. "Removal and Installation"](#).
2. Remove the steering wheel rear cover screws and the steering wheel rear cover.
3. Remove the steering wheel switch assembly screws and the steering wheel switches.

#### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

# AUDIO AMP.

< REMOVAL AND INSTALLATION >

[NAVIGATION]


## AUDIO AMP.

### Removal and Installation


INFOID:00000009876659

#### REMOVAL

1. Remove the accelerator pedal. Refer to [ACC-3, "Removal and Installation"](#).
2. Remove the BCM. Refer to [BCS-52, "Removal and Installation"](#).
3. Remove the audio amp.
  - a. Disconnect the audio amp. harness connectors.
  - b. Remove the audio amp bracket screws and slide the audio amp and bracket assembly down.



4. Remove the audio amp. screws (A) and separate the audio amp. (1) from the bracket.



#### INSTALLATION

Installation is in the reverse order of removal.



# AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[NAVIGATION]

## AUDIO ANTENNA

### Location of Antenna

INFOID:000000009876660



- |               |   |                             |
|---------------|---|-----------------------------|
| 1. Antenna    | 2. Satellite antenna (if equipped, factory installed) | 3. Satellite antenna feeder |
| 4. Connectors | 5. Satellite radio tuner                              | 6. Main feeder cable        |

### Removal and Installation

INFOID:000000009876661

#### REMOVAL

1. Remove audio antenna rod.
2. Remove audio antenna rubber seal.
3. Remove fender protector RH. Refer to [EXT-24. "Removal and Installation"](#).
4. Remove audio antenna assembly bolts.
5. Disconnect the audio antenna feeder from the audio antenna assembly.
6. Remove audio antenna assembly from the vehicle.

#### INSTALLATION

- Installation is in the reverse order of removal.
- Tighten audio antenna rod to specification.

**Audio antenna rod : 3.5 N·m (0.36 kg-m, 31 in-lb)**

#### CAUTION:

**Always properly tighten the audio antenna rod during installation or the audio antenna rod may bend or break during vehicle operation.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P

## AUXILIARY INPUT JACK

< REMOVAL AND INSTALLATION >

[NAVIGATION]

---

### AUXILIARY INPUT JACK

#### Removal and Installation

INFOID:00000000987662

#### REMOVAL

1. Remove the center console. Refer to [IP-20. "Removal and Installation"](#).
2. Remove the auxiliary input jack.

#### INSTALLATION

Installation is in the reverse order of removal.

## USB CONNECTOR

### Removal and Installation

INFOID:000000009876663

#### REMOVAL

1. Remove the center console assembly. Refer to [IP-20. "Removal and Installation"](#).
2. Push the pawl from the back of the center console to remove the USB interface.

#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

AV

# SATELLITE RADIO ANTENNA

< REMOVAL AND INSTALLATION >

[NAVIGATION]

## SATELLITE RADIO ANTENNA


### Removal and Installation

INFOID:000000009876664

### SATELLITE RADIO ANTENNA

#### Removal

1. Lower the headliner. Refer to [INT-21. "Removal and Installation"](#).
2. Disconnect the satellite radio antenna connector.
3. Remove the satellite radio antenna nut.
4. Remove the satellite radio antenna.



#### Installation

Installation is in the reverse order of removal.


## GPS ANTENNA

### Removal and Installation


INFOID:000000010159259

#### REMOVAL

1. Remove cluster lid C. Refer to [IP-14. "Removal and Installation"](#).
2. Disconnect center speaker.
3. Remove defroster grille. Refer to [VTL-25. "Removal and Installation"](#).
4. Disconnect GPS antenna connector.



5. Remove the GPS antenna.



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P


## MICROPHONE

### Removal and Installation

INFOID:00000000987665

#### REMOVAL

1. Remove the front roof console finisher. Refer to [INT-21](#), "[Removal and Installation](#)".
2. Remove the Bluetooth microphone (1)
  - a. Disconnect the Bluetooth microphone harness connector (A).
  - b. Detach the Bluetooth microphone (1) from the front roof console finisher.



#### INSTALLATION

Installation is in the reverse order of removal.

## REAR VIEW CAMERA

### Removal and Installation

INFOID:00000000987666

#### REMOVAL

1. Remove the tail gate handle. Refer to [DLK-137, "Exploded View"](#).
2. Remove the rear view camera screws and the rear view camera from the tail gate handle.

#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AV

# REAR CONTROL SWITCH

< REMOVAL AND INSTALLATION >

[NAVIGATION]

## REAR CONTROL SWITCH


### Removal and Installation

INFOID:000000010621851

#### REAR AUDIO REMOTE CONTROL UNIT

##### Removal

1. Carefully remove the rear control switch from the rear roof console assembly using a suitable tool.
2. Disconnect the harness connector from rear control switch and remove.



##### Installation

Installation is in the reverse order of removal.



## DVD ENTERTAINMENT SYSTEM


### Removal and Installation

INFOID:000000010621852

#### DVD PLAYER

##### Removal

1. Disconnect the battery negative terminal. Refer to [PG-79, "Removal and Installation"](#).
2. Remove the center console bin. Refer to [IP-19, "Exploded View"](#).
3. Remove the DVD player screws.



4. Remove the DVD player.


##### Installation

Installation is in reverse order of removal.


#### VIDEO MONITOR

##### Removal

1. Remove the rear roof console assembly. Refer to [INT-21, "Removal and Installation"](#).
2. Disconnect the harness connector from video monitor.
3. Remove the video housing screws.



4. Remove the video monitor and housing.
5. Remove the video monitor hinge screws and remove the video monitor.



##### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
AV  
O  
P