

SECTION **PWC**

POWER WINDOW CONTROL SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

CONTENTS

| | |
|---|---|
| <p>BASIC INSPECTION 4</p> <p>DIAGNOSIS AND REPAIR WORKFLOW 4</p> <p style="padding-left: 20px;">Work Flow4</p> <p>SYSTEM DESCRIPTION 6</p> <p>POWER WINDOW SYSTEM 6</p> <p style="padding-left: 20px;">System Diagram6</p> <p style="padding-left: 20px;">System Description6</p> <p style="padding-left: 20px;">Component Parts Location8</p> <p style="padding-left: 20px;">Component Description9</p> <p>DIAGNOSIS SYSTEM (BCM)10</p> <p>COMMON ITEM10</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) 10</p> <p>RETAINED PWR10</p> <p style="padding-left: 20px;">RETAINED PWR : CONSULT Function (BCM - RETAINED PWR) 11</p> <p>DTC/CIRCUIT DIAGNOSIS12</p> <p>POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)12</p> <p>POWER WINDOW MAIN SWITCH12</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Description.... 12</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Component Function Check 12</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Diagnosis Procedure 12</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Component Inspection 15</p> <p>FRONT POWER WINDOW SWITCH16</p> <p style="padding-left: 20px;">FRONT POWER WINDOW SWITCH : Description 16</p> <p style="padding-left: 20px;">FRONT POWER WINDOW SWITCH : Component Function Check 16</p> | <p style="padding-left: 20px;">FRONT POWER WINDOW SWITCH : Diagnosis Procedure16</p> <p>REAR POWER WINDOW SWITCH18</p> <p style="padding-left: 20px;">REAR POWER WINDOW SWITCH : Description...18</p> <p style="padding-left: 20px;">REAR POWER WINDOW SWITCH : Component Function Check 18</p> <p style="padding-left: 20px;">REAR POWER WINDOW SWITCH : Diagnosis Procedure 18</p> <p style="padding-left: 20px;">REAR POWER WINDOW SWITCH : Component Inspection20</p> <p>POWER SUPPLY AND GROUND CIRCUIT CHECK (KING CAB)21</p> <p>POWER WINDOW MAIN SWITCH21</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Description21</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Component Function Check21</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Diagnosis Procedure21</p> <p>FRONT POWER WINDOW SWITCH22</p> <p style="padding-left: 20px;">FRONT POWER WINDOW SWITCH : Description22</p> <p style="padding-left: 20px;">FRONT POWER WINDOW SWITCH : Component Function Check22</p> <p style="padding-left: 20px;">FRONT POWER WINDOW SWITCH : Diagnosis Procedure23</p> <p>POWER WINDOW MOTOR25</p> <p>DRIVER SIDE25</p> <p style="padding-left: 20px;">DRIVER SIDE : Description25</p> <p style="padding-left: 20px;">DRIVER SIDE : Component Function Check25</p> <p style="padding-left: 20px;">DRIVER SIDE : Diagnosis Procedure25</p> <p style="padding-left: 20px;">DRIVER SIDE : Component Inspection26</p> <p>PASSENGER SIDE26</p> <p style="padding-left: 20px;">PASSENGER SIDE : Description26</p> <p style="padding-left: 20px;">PASSENGER SIDE : Component Function Check26</p> |
|---|---|

PWC

| | | | |
|---|-----------|--|-----------|
| PASSENGER SIDE : Diagnosis Procedure | 26 | FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (KING CAB) | 51 |
| PASSENGER SIDE : Component Inspection | 27 | Description | 51 |
| REAR LH | 28 | Component Function Check | 51 |
| REAR LH : Description | 28 | Diagnosis Procedure | 51 |
| REAR LH : Component Function Check | 28 | POWER WINDOW SERIAL LINK | 54 |
| REAR LH : Diagnosis Procedure | 28 | POWER WINDOW MAIN SWITCH | 54 |
| REAR LH : Component Inspection | 29 | POWER WINDOW MAIN SWITCH : Description ... | 54 |
| REAR RH | 29 | POWER WINDOW MAIN SWITCH : Component Function Check | 54 |
| REAR RH : Description | 29 | POWER WINDOW MAIN SWITCH : Diagnosis Procedure | 54 |
| REAR RH : Component Function Check | 29 | FRONT POWER WINDOW SWITCH | 55 |
| REAR RH : Diagnosis Procedure | 30 | FRONT POWER WINDOW SWITCH : Description | 55 |
| REAR RH : Component Inspection | 31 | FRONT POWER WINDOW SWITCH : Component Function Check | 56 |
| ENCODER CIRCUIT CHECK FRONT (CREW CAB) | 32 | FRONT POWER WINDOW SWITCH : Diagnosis Procedure | 56 |
| DRIVER SIDE | 32 | POWER WINDOW LOCK SWITCH | 58 |
| DRIVER SIDE : Description | 32 | Description | 58 |
| DRIVER SIDE : Component Function Check | 32 | Component Function Check | 58 |
| DRIVER SIDE : Diagnosis Procedure | 32 | REAR POWER DROP GLASS CIRCUIT CHECK | 59 |
| PASSENGER SIDE | 34 | Rear Power Drop Glass Circuit Inspection | 59 |
| PASSENGER SIDE : Description | 34 | REAR POWER DROP GLASS DOWN RELAY CHECK | 60 |
| PASSENGER SIDE : Component Function Check | 34 | Rear Power Drop Glass Down Relay Check | 60 |
| PASSENGER SIDE : Diagnosis Procedure | 34 | REAR POWER DROP GLASS UP RELAY CHECK | 62 |
| ENCODER CIRCUIT CHECK FRONT (KING CAB) | 38 | Rear Power Drop Glass Up Relay Check | 62 |
| DRIVER SIDE | 38 | ECU DIAGNOSIS INFORMATION | 64 |
| DRIVER SIDE : Description | 38 | BCM (BODY CONTROL MODULE) | 64 |
| DRIVER SIDE : Component Function Check | 38 | Reference Value | 64 |
| DRIVER SIDE : Diagnosis Procedure | 38 | Terminal Layout | 67 |
| PASSENGER SIDE | 40 | Physical Values | 67 |
| PASSENGER SIDE : Description | 40 | Fail Safe | 72 |
| PASSENGER SIDE : Component Function Check | 40 | DTC Inspection Priority Chart | 72 |
| PASSENGER SIDE : Diagnosis Procedure | 40 | DTC Index | 73 |
| DOOR SWITCH | 44 | POWER WINDOW MAIN SWITCH | 75 |
| CREW CAB | 44 | Reference Value (Crew Cab) | 75 |
| CREW CAB : Description | 44 | Reference Value (King Cab) | 76 |
| CREW CAB : Component Function Check | 44 | Fail Safe | 78 |
| CREW CAB : Diagnosis Procedure | 44 | FRONT POWER WINDOW SWITCH | 79 |
| KING CAB | 45 | Reference Value | 79 |
| KING CAB : Description | 45 | Fail Safe | 80 |
| KING CAB : Component Function Check | 45 | WIRING DIAGRAM | 81 |
| KING CAB : Diagnosis Procedure | 46 | POWER WINDOW SYSTEM | 81 |
| FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (CREW CAB) ... | 48 | Wiring Diagram - King Cab | 81 |
| Description | 48 | | |
| Component Function Check | 48 | | |
| Diagnosis Procedure | 48 | | |

| | | | | |
|--|------------|--|------------|------------|
| Wiring Diagram - Crew Cab | 88 | Diagnosis Procedure | 108 | |
| SYMPTOM DIAGNOSIS | 99 | DOES NOT OPERATE BY KEY CYLINDER SWITCH | 109 | A |
| NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH | 99 | Diagnosis Procedure | 109 | B |
| Diagnosis Procedure | 99 | KEYLESS POWER WINDOW DOWN DOES NOT OPERATE | 110 | C |
| DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE | 100 | Diagnosis Procedure | 110 | |
| Diagnosis Procedure | 100 | POWER WINDOW LOCK SWITCH DOES NOT FUNCTION | 111 | D |
| FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE | 101 | Diagnosis Procedure | 111 | |
| Diagnosis Procedure | 101 | REAR POWER DROP GLASS DOES NOT OPERATE | 112 | E |
| REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE | 102 | Diagnosis Procedure | 112 | |
| Diagnosis Procedure | 102 | PRECAUTION | 113 | F |
| REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE | 103 | PRECAUTIONS | 113 | |
| Diagnosis Procedure | 103 | Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 113 | G |
| ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE) | 104 | Precaution for Work | 113 | |
| Diagnosis Procedure | 104 | PREPARATION | 114 | H |
| ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE) | 105 | PREPARATION | 114 | |
| Diagnosis Procedure | 105 | Special Service Tool | 114 | I |
| AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE) | 106 | REMOVAL AND INSTALLATION | 115 | J |
| Diagnosis Procedure | 106 | POWER WINDOW MAIN SWITCH | 115 | |
| AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE) | 107 | Removal and Installation | 115 | |
| Diagnosis Procedure | 107 | FRONT POWER WINDOW SWITCH | 116 | PWC |
| POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY .. 108 | | Removal and Installation | 116 | |
| | | REAR POWER WINDOW SWITCH | 117 | L |
| | | Removal and Installation - Rear Door Switch | 117 | |
| | | Removal and Installation - Power Drop Glass Switch | 117 | M |
| | | | | N |
| | | | | O |
| | | | | P |

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000011560257

WORK FLOW



AWKIA0058GB

DETAILED FLOW

1. CUSTOMER INFORMATION

Interview the customer to obtain detailed information about the symptom.

>> GO TO 2

2. PRELIMINARY CHECK

Perform preliminary check. Refer to [PWC-6. "System Diagram"](#).

>> GO TO 3

3. SELF-DIAGNOSIS

Perform self-diagnosis. Refer to [BCS-45. "DTC Index"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

>> GO TO 4

4. SYMPTOM

Check for symptoms. Refer to [PWC-99. "Diagnosis Procedure"](#).

>> GO TO 5

5. MALFUNCTIONING PARTS

Repair or replace the applicable parts.

>> GO TO 6

6. SYSTEM OPERATION

Check system operation.

>> GO TO 7

7. SELF-DIAGNOSIS

Perform self-diagnosis. Refer to [BCS-45. "DTC Index"](#).

Are any DTCs indicated?

YES >> GO TO 5

NO >> Inspection End.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

POWER WINDOW SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

POWER WINDOW SYSTEM

System Diagram

INFOID:000000011560258

FRONT WINDOW ANTI-PINCH SYSTEM



System Description

INFOID:000000011560259

POWER WINDOW MAIN SWITCH INPUT/OUTPUT SIGNAL CHART

| Item | Input signal to main power window and door lock/unlock switch | Main power window and door lock/unlock switch function | Actuator |
|---|---|--|--------------------------|
| Key cylinder switch | LOCK/UNLOCK signal (more than 1.5 seconds over) | Power window control | Front power window motor |
| Encoder | Encoder pulse signal | | |
| Main power window and door lock/unlock switch | Front power window motor LH UP/DOWN signal | | |
| Power window and door lock/unlock switch RH | Front power window motor RH UP/DOWN signal | | |
| BCM | RAP signal | | |
| Rear power window switch (Crew Cab) | Rear power window motor UP/DOWN signal | | Rear power window motor |

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH INPUT/OUTPUT SIGNAL CHART

POWER WINDOW SYSTEM

< SYSTEM DESCRIPTION >

| Item | Input signal to front power window switch | Front power window switch function | Actuator |
|---|--|------------------------------------|-----------------------------|
| Power window and door lock/unlock switch RH | Front power window motor RH UP/DOWN signal | Power window control | Front power window motor RH |
| Encoder | Encoder pulse signal | | |
| BCM | RAP signal | | |

POWER WINDOW OPERATION

- Power window system is operable during the retained power operation timer after turning ignition switch ON and OFF.
- Main power window and door lock/unlock switch can open/close all windows.
- Power window and door lock unlock switch RH & rear power window switches LH and RH can open/close the corresponding windows.

REAR POWER DROP GLASS OPERATION (IF EQUIPPED)

- Rear power drop glass system is operable during the retained power operation timer after turning ignition switch ON and OFF.
- Rear power drop glass switch can open/close the rear power drop glass.

POWER WINDOW AUTO-OPERATION (FRONT LH & RH)

- AUTO UP/DOWN operation can be performed when main power window and door lock/unlock switch & power window and door lock/unlock switch RH turns to AUTO.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.

RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF.

Retained power function cancel conditions

- Front door CLOSE (door switch OFF)→OPEN (door switch ON).
- When ignition switch is ON.
- When timer time passes. (45 seconds)

POWER WINDOW LOCK

Ground circuit inside main power window and door lock/unlock switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the main power window and door lock/unlock switch.

ANTI-PINCH OPERATION (FRONT LH & RH)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm (5.91 in) or 2 seconds when detected.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window switch controls to lower the window glass for 150 mm (5.91 in) or 2 seconds after it detects encoder pulse signal frequency change.

OPERATION CONDITION

- When all door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed).

NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

KEY CYLINDER SWITCH OPERATION

POWER WINDOW SYSTEM

< SYSTEM DESCRIPTION >

Hold the door key cylinder to the LOCK or UNLOCK direction for more than 1 second to OPEN or CLOSE front power windows when ignition switch is OFF. In addition, it stops when key position is moved to NEUTRAL when operating.

OPERATION CONDITION

- Ignition switch OFF.
- Hold door key cylinder to LOCK position for more than 1 second to perform CLOSE operation of the door glass.
- Hold door key cylinder to UNLOCK position for more than 1 second to perform OPEN operation of the door glass.

KEYLESS POWER WINDOW DOWN OPERATION (FRONT LH & RH)

Front power windows open when the unlock button on keyfob is activated and kept pressed for more than 3^(NOTE) seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed:

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.

NOTE:

Keyless power window down operation mode can be changed by "PW DOWN SET" mode in "WORK SUPPORT". Refer to [BCS-21. "MULTI REMOTE ENT : CONSULT Function \(BCM - MULTI REMOTE ENT\)"](#).


NOTE:

Use CONSULT to change settings.

MODE1 (3sec)/MODE2 (OFF)/MODE3 (5sec)

Component Parts Location

INFOID:000000011560260



AWKIA1326ZZ

POWER WINDOW SYSTEM

< SYSTEM DESCRIPTION >

- | | | | |
|---|--|--|----------------------------|
| <p>1. A. Main power window and door lock/unlock switch D7, D8 (Crew Cab), D15 (King Cab) Power window and door lock/unlock switch RH D105 B. Front door switch LH B8, RH B108 C. Front power window motor LH D9, RH D104 D. Front door lock assembly LH (key cylinder switch) D14</p> | <p>2. A. Rear power window switch LH D203, RH D303 (Crew Cab) B. Rear power window motor LH D204, RH D304 (Crew Cab)</p> | <p>3. A. Steering column (view with instrument panel removed) B. BCM M18, M19, M20</p> | <p>A</p> <p>B</p> <p>C</p> |
| <p>4. Rear power drop glass switch R103 (Crew Cab)</p> | <p>5. Rear power drop glass up relay M154 (Crew Cab) Rear power drop glass down relay M155 (Crew Cab)</p> | <p>6. Rear power drop glass motor B80 (view with rear finisher removed) (Crew Cab)</p> | <p>D</p> <p>E</p> |

Component Description

INFOID:000000011560261

POWER WINDOW SYSTEM

| Component | Function |
|---|--|
| BCM | <ul style="list-style-type: none"> Supplies power supply to power window switch. Controls retained power. |
| Main power window and door lock/unlock switch | <ul style="list-style-type: none"> Directly controls all power window motor of all doors. Controls anti-pinch operation of front power window LH. |
| Power window and door lock/unlock switch RH | <ul style="list-style-type: none"> Controls front power window motor RH. Controls anti-pinch operation of front power window RH. |
| Rear power window switch (Crew Cab) | <ul style="list-style-type: none"> Controls rear power window motors LH and RH. |
| Rear power drop glass switch (Crew Cab) | <ul style="list-style-type: none"> Controls rear power drop glass motor. |
| Front power window motor LH | <ul style="list-style-type: none"> Integrates the ENCODER POWER and WINDOW MOTOR. Starts operating with signals from main power window and door lock/unlock switch. Transmits power window motor rotation as a pulse signal to main power window and door lock/unlock switch. |
| Front power window motor RH | Starts operating with signals from main power window and door lock/unlock switch & power window and door lock/unlock switch RH. |
| Rear power window motor (Crew Cab) | Starts operating with signals from main power window and door lock/unlock switch & rear power window switch. |
| Rear power drop glass motor (Crew Cab) | Starts operating with signal from rear power drop glass switch. |
| Front door lock assembly LH (key cylinder switch) | Transmits operation condition of key cylinder switch to power window main switch. |
| Front door switch LH or RH | Detects door open/close condition and transmits to BCM. |

PWC

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011885399

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM:

| Direct Diagnostic Mode | Description |
|------------------------|--|
| Ecu Identification | The BCM part number is displayed. |
| Self Diagnostic Result | The BCM self diagnostic results are displayed. |
| Data Monitor | The BCM input/output data is displayed in real time. |
| Active Test | The BCM activates outputs to test components. |
| Work support | The settings for BCM functions can be changed. |
| Configuration | <ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM. |
| CAN Diag Support Mntr | The result of transmit/receive diagnosis of CAN communication is displayed. |

SYSTEM APPLICATION

BCM can perform the following functions:

| System | Sub System | Direct Diagnostic Mode | | | | | | |
|--------------------------------------|----------------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
| | | Ecu Identification | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN Diag Support Mntr |
| Door lock | DOOR LOCK | | | x | x | x | | |
| Rear window defogger | REAR DEFOGGER | | | x | x | | | |
| Warning chime | BUZZER | | | x | x | | | |
| Interior room lamp timer | INT LAMP | | | x | x | x | | |
| Remote keyless entry system | MULTI REMOTE ENT | | | x | x | x | | |
| Exterior lamp | HEADLAMP | | | x | x | x | | |
| Wiper and washer | WIPER | | | x | x | x | | |
| Turn signal and hazard warning lamps | FLASHER | | | x | x | | | |
| Air conditioner | AIR CONDITIONER | | | x | | | | |
| Combination switch | COMB SW | | | x | | | | |
| BCM | BCM | x | x | | | x | x | x |
| Immobilizer | IMMU | | x | x | x | | | |
| Interior room lamp battery saver | BATTERY SAVER | | | x | x | x | | |
| Vehicle security system | THEFT ALM | | | x | x | x | | |
| RAP system | RETAINED PWR | | | x | x | x | | |
| Signal buffer system | SIGNAL BUFFER | | | x | x | | | |
| TPMS | AIR PRESSURE MONITOR | | x | x | x | x | | |
| Panic alarm system | PANIC ALARM | | | | x | | | |

RETAINED PWR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000011885400

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------|---|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |

ACTIVE TEST

| Test Item | Description |
|--------------|---|
| RETAINED PWR | This test is able to check retained power operation [Off/On]. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------|---------|-------------|
| RETAINED PWR SET | MODE3 | 2 min |
| | MODE2 | OFF |
| | MODE1* | 45 sec |

*: Initial setting

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000011560264

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000011560265

Main Power Window And Door Lock/Unlock Switch

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Does power window motor operate with main power window and door lock/unlock switch operation?

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.
 NO >> Refer to [PWC-12, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure


INFOID:000000011560266

Regarding Wiring Diagram information, refer to [PWC-88, "Wiring Diagram - Crew Cab"](#).

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors (A and B) and ground.

| Terminal | | Voltage (V) (Approx.) |
|---|----------|---------------------------|
| (+) | (-) | |
| Main power window and door lock/unlock switch connector | Terminal | |
| D7 (A) | 10 | Ground Battery voltage |
| D8 (B) | 19 | |




Is the measurement value within the specification?

- YES >> GO TO 3
 NO >> GO TO 2

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and main power window and door lock/unlock switch.
3. Check continuity between BCM connector (A) and main power window and door lock/unlock switch connectors (B and C).

| BCM connector | Terminal | Main power window and door lock/unlock switch connector | Terminal | Continuity |
|---------------|----------|---|----------|------------|
| M20 (A) | 68 | D7 (B) | 10 | Yes |
| | 69 | D8 (C) | 19 | |



POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between BCM connector (A) and ground.

| BCM connector | Terminal | Ground | Continuity |
|---------------|----------|--------|------------|
| M20 (A) | 68 | | |
| | 69 | | |

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D8 | 17 | | |

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115. "Removal and Installation"](#).
 NO >> Repair or replace harness.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector and ground.




| Terminals | | (-) | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| (+) BCM connector | | | |
| BCM connector | Terminal | Ground | Battery voltage |
| M20 | 68 | | |
| | 69 | | |

Is the measurement value within the specification?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5
 YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6
 NO >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).

5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

Check voltage between main power window and door lock/unlock switch connector and ground.



A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

| Terminal | | Window condition | Voltage (V) (Approx.) |
|---|----------|------------------|-----------------------|
| (+) | (-) | | |
| Main power window and door lock/unlock switch connector | Terminal | | |
| D7 | 1 | UP | Battery voltage |
| | | DOWN | 0 |
| | 3 | UP | 0 |
| | | DOWN | Battery voltage |

Is the measurement value within the specification?


YES >> GO TO 7

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-115. "Removal and Installation"](#).

6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

Check voltage between main power window and door lock/unlock switch connector and ground.

| Terminal | | Window condition | Voltage (V) (Approx.) |
|---|----------|------------------|-----------------------|
| (+) | (-) | | |
| Main power window and door lock/unlock switch connector | Terminal | | |
| D7 | 7 | UP | Battery voltage |
| | | DOWN | 0 |
| | 5 | UP | 0 |
| | | DOWN | Battery voltage |



Is the measurement value within the specification?


YES >> GO TO 8

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-115. "Removal and Installation"](#).

7. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

- Turn ignition switch OFF.
- Disconnect rear power window switch LH.
- Check continuity between main power window and door lock/unlock switch connector and rear power window switch LH connector.

| Main power window and door lock/unlock switch connector | Terminal | Rear power window switch LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D7 (A) | 1 | D203 (B) | 2 | Yes |
| | 3 | | 3 | |



- Check continuity between main power window and door lock/unlock switch connector and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D7 (A) | 1 | Ground | No |
| | 3 | | |

POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)


< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 9
- NO >> Repair or replace harness.

8. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector and rear power window switch RH connector.



| Main power window and door lock/unlock switch connector | Terminal | Rear power window switch RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D7 (A) | 5 | D303 (B) | 3 | Yes |
| | 7 | | 2 | |

4. Check continuity between main power window and door lock/unlock switch connector and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D7 (A) | 5 | Ground | No |
| | 7 | | |

Is the inspection result normal?

- YES >> GO TO 9
- NO >> Repair or replace harness.

9. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.
Refer to [PWC-15. "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-115. "Removal and Installation"](#).


POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:000000011560267

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

1. Check main power window and door lock/unlock switch.

| Terminal | Main power window and door lock/unlock switch condition | Continuity |
|----------|---|------------|
| 10 | Rear LH | UP |
| 10 | Rear RH | |
| 1 | Rear LH | NEUTRAL |
| 5 | Rear RH | |
| 10 | Rear LH | DOWN |
| 10 | Rear RH | |




POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >


2. Check continuity between main power window and door lock/unlock switch (power window lock switch). (Lock operation).

| Terminal | Main power window and door lock/unlock switch condition | Continuity |
|----------|---|------------|
| 3 | Rear LH | UP |
| 5 | Rear RH | |
| 1 | Rear LH | NEUTRAL |
| 3 | Rear RH | |
| 5 | Rear LH | DOWN |
| 7 | Rear RH | |



3. Check continuity between main power window and door lock/unlock switch (power window lock switch). (Unlock operation).

| Terminal | Main power window and door lock/unlock switch condition | Continuity |
|----------|---|------------|
| 3 | Rear LH | UP |
| 5 | Rear RH | |
| 1 | Rear LH | NEUTRAL |
| 3 | Rear RH | |
| 5 | Rear LH | DOWN |
| 7 | Rear RH | |



Is the inspection result normal?

YES >> Main power window and door lock/unlock switch is OK.

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-115. "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000011560268

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000011560269

Power Window And Door Lock/Unlock Switch RH

1. CHECK FRONT POWER WINDOW MOTOR RH FUNCTION

Does front power window motor RH operate with power window and door lock/unlock switch RH operation?

Is the inspection result normal?

YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.

NO >> Refer to [PWC-16. "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000011560270

Regarding Wiring Diagram information, refer to [PWC-88. "Wiring Diagram - Crew Cab"](#).


POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch ON.
- Check voltage between power window and door lock/unlock switch RH connector and ground.

| Terminal (+) | | Terminal (-) | Voltage (V) (Approx.) |
|---|----------|--------------|-----------------------|
| Power window and door lock/unlock switch RH connector | Terminal | | |
| D105 | 10 | Ground | Battery voltage |




Is the measurement value within the specification?

- YES >> GO TO 3
 NO >> GO TO 2

2. CHECK HARNESS CONTINUITY

- Turn ignition switch OFF.
- Disconnect BCM and power window and door lock/unlock switch RH.
- Check continuity between BCM connector (A) and power window and door lock/unlock switch RH connector (B).

| BCM connector | Terminal | Power window and door lock/unlock switch RH connector | Terminal | Continuity |
|---------------|----------|---|----------|------------|
| M20 (A) | 69 | D105 (B) | 10 | Yes |



- Check continuity between BCM connector (A) and ground.

| BCM connector | Terminal | Ground | Continuity |
|---------------|----------|--------|------------|
| M20 (A) | 69 | | No |


Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect power window and door lock/unlock switch RH.
- Check continuity between power window and door lock/unlock switch RH connector and ground.

| Power window and door lock/unlock switch RH | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D105 | 11 | | Yes |



Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH.
 Refer to [PWC-116, "Removal and Installation"](#).
 NO >> Repair or replace harness.

4. CHECK BCM OUTPUT SIGNAL

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


PWC

POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector and ground.

| Terminals | | (-) | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| (+) BCM connector | | | |
| BCM connector | Terminal | | |
| M20 | 69 | Ground | Battery voltage |



Is the measurement value within the specification?

YES >> Replace power window and door lock/unlock switch RH.
Refer to [PWC-116, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-56, "Removal and Installation"](#).

REAR POWER WINDOW SWITCH

REAR POWER WINDOW SWITCH : Description

INFOID:000000011560271

- BCM supplies power.
- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.

REAR POWER WINDOW SWITCH : Component Function Check

INFOID:000000011560272

Rear Power Window Switch

1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Does rear power window motor operate with rear power window switch operation?

Is the inspection result normal?

YES >> Rear power window switch power supply and ground circuit are OK.

NO >> Refer to [PWC-18, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

REAR POWER WINDOW SWITCH : Diagnosis Procedure


INFOID:000000011560273

Regarding Wiring Diagram information, refer to [PWC-88, "Wiring Diagram - Crew Cab"](#).

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear power window switch connector and ground.

| Terminal | | (-) | Condition | Voltage (V) (Approx.) |
|--|----------|-----|--------------------|--------------------------|
| (+) Rear power window switch connector | | | | |
| Rear power window switch connector | Terminal | | | |
| LH | D203 | 1 | Ignition switch ON | Battery voltage |
| RH | D303 | | | |



Is the measurement value within the specification?

YES >> GO TO 2 (Rear power window switch LH)

YES >> GO TO 3 (Rear power window switch RH)


NO >> GO TO 4

2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and rear power window switch LH connector (B).



| Main power window and door lock/unlock switch connector | Terminal | Rear power window switch LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D7 (A) | 1 | D203 (B) | 2 | Yes |
| | 3 | | 3 | |

4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D7 (A) | 1 | Ground | No |
| | 3 | | |


Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> Repair or replace harness.

3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and rear power window switch RH connector (B).



| Main power window and door lock/unlock switch connector | Terminal | Rear power window switch RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D7 (A) | 5 | D303 (B) | 3 | Yes |
| | 7 | | 2 | |

4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D7 (A) | 5 | Ground | No |
| | 7 | | |

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> Repair or replace harness.

4. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and rear power window switch.
3. Check continuity between BCM connector and rear power window switch connector.

| BCM connector | Terminal | Rear power window switch connector | Terminal | Continuity |
|---------------|----------|------------------------------------|----------|------------|
| M20 | 68 | LH | D203 | Yes |
| | | RH | D303 | |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between BCM connector and ground.

| BCM connector | Terminal | Ground | Continuity |
|---------------|----------|--------|------------|
| M20 | 68 | | No |

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair or replace harness.

5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-20. "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> Replace rear power window switch. Refer to [PWC-117. "Removal and Installation - Rear Door Switch"](#).

REAR POWER WINDOW SWITCH : Component Inspection


INFOID:000000011560274

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

| Terminal | Power window switch condition | Continuity |
|----------|-------------------------------|------------|
| 1 5 | DOWN | Yes |
| 3 4 | | |
| 3 4 | NEUTRAL | |
| 5 2 | | |
| 1 4 | UP | |
| 5 2 | | |



Is the inspection result normal?

YES >> Rear power window switch is OK.

NO >> Replace rear power window switch. Refer to [PWC-117. "Removal and Installation - Rear Door Switch"](#).

POWER SUPPLY AND GROUND CIRCUIT CHECK (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT CHECK (KING CAB)

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000011560275

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000011560276

Main Power Window And Door Lock/Unlock Switch

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Does power window motor operate with main power window and door lock/unlock switch operation?

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.
 NO >> Refer to [PWC-21, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure


INFOID:000000011560277

Regarding Wiring Diagram information, refer to [PWC-81, "Wiring Diagram - King Cab"](#).

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connector and ground.

| Terminal (+) | | Terminal (-) | Voltage (V) (Approx.) |
|---|----------|--------------|-----------------------|
| Main power window and door lock/unlock switch connector | Terminal | | |
| D15 | 1 | Ground | Battery voltage |
| | 10 | | |




Is the measurement value within the specification?

- YES >> GO TO 3
 NO >> GO TO 2

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and main power window and door lock/unlock switch.
3. Check continuity between BCM connector (A) and main power window and door lock/unlock switch connector (B).

| BCM connector | Terminal | Main power window and door lock/unlock switch connector | Terminal | Continuity |
|---------------|----------|---|----------|------------|
| M20 (A) | 68 | D15 (B) | 10 | Yes |
| | 69 | | 1 | |



4. Check continuity between BCM connector (A) and ground.

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT CHECK (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

| BCM connector | Terminal | Ground | Continuity |
|---------------|----------|--------|------------|
| M20 (A) | 68 | | Ground |
| | 69 | | |

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.


3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect main power window and door lock/unlock switch.
- Check continuity between main power window and door lock/unlock switch connector and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D15 | 15 | | Ground |

Is the inspection result normal?


- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115. "Removal and Installation"](#).
 NO >> Repair or replace harness.



4. CHECK BCM OUTPUT SIGNAL

- Connect BCM.
- Turn ignition switch ON.
- Check voltage between BCM connector and ground.

| Terminals | | Voltage (V) (Approx.) |
|---------------|----------|--------------------------|
| (+) | (-) | |
| BCM connector | Terminal | Ground |
| M20 | 68 | |
| | 69 | Battery voltage |



Is the measurement value within the specification?

- YES >> GO TO 5
 NO >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).

5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).
 NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-115. "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000011560278

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000011560279

Power Window And Door Lock/Unlock Switch RH

1. CHECK FRONT POWER WINDOW MOTOR RH FUNCTION

Does front power window motor RH operate with power window and door lock/unlock switch RH operation?

POWER SUPPLY AND GROUND CIRCUIT CHECK (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.
- NO >> Refer to [PWC-23. "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure


INFOID:0000000011560280

Regarding Wiring Diagram information, refer to [PWC-81. "Wiring Diagram - King Cab"](#).

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between power window and door lock/unlock switch RH connector and ground.

| Terminal (+) | | Terminal (-) | Voltage (V) (Approx.) |
|---|----------|--------------|--------------------------|
| Power window and door lock/unlock switch RH connector | Terminal | | |
| D105 | 10 | Ground | Battery voltage |




Is the measurement value within the specification?

- YES >> GO TO 3
- NO >> GO TO 2

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and power window and door lock/unlock switch RH.
3. Check continuity between BCM connector (A) and power window and door lock/unlock switch RH connector (B).

| BCM connector | Terminal | Power window and door lock/unlock switch RH connector | Terminal | Continuity |
|---------------|----------|---|----------|------------|
| M20 (A) | 69 | D105 (B) | 10 | Yes |



4. Check continuity between BCM connector (A) and ground.

| BCM connector | Terminal | Ground | Continuity |
|---------------|----------|--------|------------|
| M20 (A) | 69 | | No |

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT CHECK (KING CAB)


< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector and ground.

| Power window and door lock/unlock switch RH | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D105 | 11 | | Yes |

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH.
Refer to [PWC-116, "Removal and Installation"](#).
- NO >> Repair or replace harness.




4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector and ground.

| Terminals | | (-) | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| (+) BCM connector | | | |
| BCM connector | Terminal | | |
| M20 | 69 | Ground | Battery voltage |

Is the measurement value within the specification?

- YES >> Replace power window and door lock/unlock switch RH.
Refer to [PWC-116, "Removal and Installation"](#).
- NO >> Replace BCM. Refer to [BCS-56, "Removal and Installation"](#).



POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000011560281

Door glass moves UP/DOWN by receiving the signal from power window main switch.

DRIVER SIDE : Component Function Check

INFOID:000000011560282

1. CHECK POWER WINDOW MOTOR CIRCUIT

Does front power window motor LH operate with operating main power window and door lock/unlock switch?
Is the inspection result normal?

- YES >> Front power window motor LH is OK.
- NO >> Refer to [PWC-25, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure


INFOID:000000011560283

Regarding Wiring Diagram information, refer to [PWC-88, "Wiring Diagram - Crew Cab"](#) or [PWC-81, "Wiring Diagram - King Cab"](#).

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Disconnect front power window motor LH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor LH connector and ground.

| Terminal (+) | | Terminal (-) | Main power window and door lock/unlock switch condition | Voltage (V) (Approx.) |
|---------------------------------|----------|--------------|---|-----------------------|
| Power window motor LH connector | Terminal | | | |
| D9 | 2 | Ground | UP | Battery voltage |
| | | | DOWN | 0 |
| | 1 | | UP | 0 |
| | | | DOWN | Battery voltage |




Is the measurement value within the specification?

- YES >> GO TO 2
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-115, "Removal and Installation"](#).

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor connector LH (B).

| Main power window and door lock/unlock switch connector | Terminal | Front power window motor LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D7 (A) (Crew Cab) | 8 | D9 (B) | 2 | Yes |
| D15 (A) (King Cab) | 11 | | 1 | |



POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D7 (A) (Crew Cab) D15 (A) (King Cab) | 8 | | |
| | 11 | | |

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK POWER WINDOW MOTOR

Check front power window motor LH.

Refer to [PWC-26, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace power window motor LH. Refer to [GW-18, "Removal and Installation"](#).

DRIVER SIDE : Component Inspection

INFOID:000000011560284

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR LH

Does motor operate by connecting the battery voltage directly to power window motor?

| Terminal | | Motor condition |
|----------|-----|-----------------|
| (+) | (-) | |
| 1 | 2 | DOWN |
| 2 | 1 | UP |

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000011560285

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

PASSENGER SIDE : Component Function Check

INFOID:000000011560286

1. CHECK POWER WINDOW MOTOR CIRCUIT

Does power window motor operate with operating main power window and door lock/unlock switch or power window and door lock/unlock switch RH?

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Refer to [PWC-26, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000011560287

Regarding Wiring Diagram information, refer to [PWC-88, "Wiring Diagram - Crew Cab"](#) or [PWC-81, "Wiring Diagram - King Cab"](#).


1. CHECK FRONT POWER WINDOW SWITCH RH OUTPUT SIGNAL

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect front power window motor RH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor RH connector and ground.

| Terminal (+) | | Terminal (-) | Front power window motor RH condition | Voltage (V) (Approx.) |
|---------------------------------------|----------|--------------|---------------------------------------|-----------------------|
| Front power window motor RH connector | Terminal | | | |
| D104 | 2 | Ground | UP | Battery voltage |
| | | | DOWN | 0 |
| | 1 | | UP | 0 |
| | | | DOWN | Battery voltage |



Is the measurement value within the specification?


YES >> GO TO 2

NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-116, "Removal and Installation"](#).

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).

| Power window and door lock/unlock switch RH connector | Terminal | Front power window motor RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D105 (A) | 8 | D104 (B) | 2 | Yes |
| | 9 | | 1 | |



4. Check continuity between power window and door lock/unlock switch RH connector (A) and ground.

| Power window and door lock/unlock switch RH connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D105 (A) | 8 | Ground | No |
| | 9 | | |

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-27, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> Replace front power window motor RH. Refer to [GW-18, "Removal and Installation"](#).

PASSENGER SIDE : Component Inspection

INFOID:000000011560288

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR RH

Does motor operate by connecting the battery voltage directly to front power window motor RH?

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| Terminal | | Motor condition |
|----------|-----|-----------------|
| (+) | (-) | |
| 1 | 2 | DOWN |
| 2 | 1 | UP |

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Replace front power window motor RH. Refer to [GW-18, "Removal and Installation"](#).

REAR LH

REAR LH : Description

INFOID:000000011560289

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch LH.

REAR LH : Component Function Check

INFOID:000000011560290

1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

Does rear power window motor LH operate with main power window and door lock/unlock switch or rear power window switch LH?

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-28, "REAR LH : Diagnosis Procedure"](#)

REAR LH : Diagnosis Procedure

INFOID:000000011560291

Regarding Wiring Diagram information, refer to [PWC-88, "Wiring Diagram - Crew Cab"](#).

1. CHECK REAR POWER WINDOW SWITCH OUTPUT SIGNAL

1. Disconnect rear power window motor LH.
2. Turn ignition switch ON.
3. Check voltage between rear power window motor LH connector and ground.


| Terminal | | Window condition | Voltage (V) (Approx.) |
|--|-----|------------------|-----------------------|
| (+) | (-) | | |
| Rear power window motor LH connector D204 | 1 | UP | Battery voltage |
| | | DOWN | 0 |
| | 2 | UP | 0 |
| | | DOWN | Battery voltage |

Is the measurement value within the specification?

YES >> GO TO 2

NO >> Check rear power window switch LH. Refer to [PWC-18, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

2. CHECK HARNESS CONTINUITY



POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector (A) and rear power window motor LH connector (B).

| Rear power window switch LH connector | Terminal | Rear power window motor LH connector | Terminal | Continuity |
|---------------------------------------|----------|--------------------------------------|----------|------------|
| D203 (A) | 5 | D204 (B) | 2 | Yes |
| | 4 | | 1 | |

4. Check continuity between rear power window switch LH connector (A) and ground.

| Rear power window switch LH connector | Terminal | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| D203 (A) | 5 | Ground | No |
| | 4 | | |

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.

3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.
 Refer to [PWC-29, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).
 NO >> Replace rear power window motor LH. Refer to [GW-22, "Rear Door Glass Regulator Assembly"](#).

REAR LH : Component Inspection

INFOID:000000011560292

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR LH

Does motor operate by connecting the battery voltage directly to rear power window motor LH?

| Terminal | | Motor condition |
|----------|-----|-----------------|
| (+) | (-) | |
| 2 | 1 | DOWN |
| 1 | 2 | UP |

Is the inspection result normal?

- YES >> Rear power window motor LH is OK.
 NO >> Replace rear power window motor LH. Refer to [GW-22, "Rear Door Glass Regulator Assembly"](#).

REAR RH

REAR RH : Description

INFOID:000000011560293

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.


REAR RH : Component Function Check

INFOID:000000011560294

1. CHECK REAR POWER WINDOW MOTOR RH CIRCUIT

Does rear power window motor RH operate with operating main power window and door lock/unlock switch or rear power window switch RH?

Is the inspection result normal?



POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Rear power window motor RH is OK.
 NO >> Refer to [PWC-30, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure


INFOID:000000011560295

Regarding Wiring Diagram information, refer to [PWC-88, "Wiring Diagram - Crew Cab"](#).

1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Disconnect rear power window motor RH.
2. Turn ignition switch ON.
3. Check voltage between rear power window motor RH connector and ground.

| Terminal (+) | | Terminal (-) | Rear power window switch RH condition | Voltage (V) (Approx.) |
|--------------------------------------|----------|--------------|---------------------------------------|-----------------------|
| Rear power window motor RH connector | Terminal | | | |
| D304 | 1 | Ground | UP | Battery voltage |
| | | | DOWN | 0 |
| | 2 | | UP | 0 |
| | | | DOWN | Battery voltage |




Is the measurement value within the specification?

- YES >> GO TO 2
 NO >> Check rear power window switch RH. Refer to [PWC-18, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between rear power window switch RH connector (A) and rear power window motor RH connector (B).

| Rear power window switch RH connector | Terminal | Rear power window motor RH connector | Terminal | Continuity |
|---------------------------------------|----------|--------------------------------------|----------|------------|
| D303 (A) | 5 | D304 (B) | 2 | Yes |
| | 4 | | 1 | |



4. Check continuity between rear power window switch RH connector (A) and ground.

| Rear power window switch RH connector | Terminal | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| D303 (A) | 5 | Ground | No |
| | 4 | | |

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness.

3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.
 Refer to [PWC-31, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).
NO >> Replace rear power window motor RH. Refer to [GW-22. "Rear Door Glass Regulator Assembly"](#).

REAR RH : Component Inspection

INFOID:000000011560296

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR RH

Does motor operate by connecting the battery voltage directly to rear power window motor RH?

| Terminal | | Motor condition |
|----------|-----|-----------------|
| (+) | (-) | |
| 2 | 1 | DOWN |
| 1 | 2 | UP |

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.
NO >> Replace rear power window motor RH. Refer to [GW-22. "Rear Door Glass Regulator Assembly"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ENCODER CIRCUIT CHECK FRONT (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

ENCODER CIRCUIT CHECK FRONT (CREW CAB)

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000011560297

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

DRIVER SIDE : Component Function Check

INFOID:000000011560298

1. CHECK ENCODER OPERATION

Does front door glass LH perform AUTO open/close operation normally when operating main power window and door lock/unlock switch?

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-32, "DRIVER SIDE : Diagnosis Procedure"](#)

DRIVER SIDE : Diagnosis Procedure



INFOID:000000011560299

Regarding Wiring Diagram information, refer to [PWC-88, "Wiring Diagram - Crew Cab"](#).

1. CHECK ENCODER OPERATION

1. Turn ignition switch ON.
2. Check signal between main power window and door lock/unlock switch connector and ground with oscilloscope.

| Terminals | | Signal (Reference value) |
|---|----------|-----------------------------|
| (+) | (-) | |
| Main power window and door lock/unlock switch connector | Terminal | Ground |
| D7 | 9 | |
| | 13 | Refer to following signal |



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

NO >> GO TO 2


2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY

ENCODER CIRCUIT CHECK FRONT (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect front power window motor LH.
2. Check voltage between front power window motor LH connector and ground.

| Terminal (+) | | Terminal (-) | Voltage (V) (Approx.) |
|---------------------------------------|----------|--------------|--------------------------|
| Front power window motor LH connector | Terminal | | |
| D9 | 4 | Ground | 10 |




Is the measurement value within the specification?

- YES >> GO TO 4
NO >> GO TO 3

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

| Main power window and door lock/unlock switch connector | Terminal | Front power window motor LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D7 (A) | 15 | D9 (B) | 4 | Yes |



4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D7 (A) | 15 | | No |


Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115, "Removal and Installation"](#).
NO >> Repair or replace harness.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front power window motor LH connector and ground.

| Front power window motor LH connector | Terminal | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| D9 | 6 | | Yes |



Is the inspection result normal?

- YES >> GO TO 6
NO >> GO TO 5

5. CHECK HARNESS CONTINUITY 2

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ENCODER CIRCUIT CHECK FRONT (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector and front power window motor LH connector.

| Main power window and door lock/unlock switch connector | Terminal | Front power window motor LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D7 | 2 | D9 | 6 | Yes |

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115, "Removal and Installation"](#).

NO >> Repair or replace harness.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

| Main power window and door lock/unlock switch connector | Terminal | Front power window motor LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D7 (A) | 9 | D9 (B) | 5 | Yes |
| | 13 | | 3 | |

3. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D7 (A) | 9 | Ground | No |
| | 13 | | |

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#).

NO >> Repair or replace harness.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000011560300

Detects condition of the front power window motor RH operation and transmits to power window and door lock/unlock switch RH as pulse signal.

PASSENGER SIDE : Component Function Check

INFOID:000000011560301

1. CHECK ENCODER OPERATION

Does front door glass RH perform AUTO open/close operation normally when operating power window and door lock/unlock switch RH?

Is the inspection result normal?



YES >> Encoder operation is OK.

NO >> Refer to [PWC-34, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000011560302

Regarding Wiring Diagram information, refer to [PWC-88, "Wiring Diagram - Crew Cab"](#).





ENCODER CIRCUIT CHECK FRONT (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between power window and door lock/unlock switch RH connector and ground with oscilloscope.

| Terminals | | Signal (Reference value) |
|---|----------|-----------------------------|
| (+) | (-) | |
| Power window and door lock/unlock switch RH connector | Terminal | Ground |
| D105 | 12 15 | |
| | | Refer to following signal |




Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).
 NO >> GO TO 2

2. CHECK FRONT POWER WINDOW MOTOR RH POWER SUPPLY

1. Disconnect front power window motor RH.
2. Check voltage between front power window motor RH connector and ground.

| Terminal | | Voltage (V) (Approx.) |
|---------------------------------------|----------|--------------------------|
| (+) | (-) | |
| Front power window motor RH connector | Terminal | 10 |
| D104 | 4 | |




Is the measurement value within the specification?

- YES >> GO TO 4
 NO >> GO TO 3

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).

| Power window and door lock/unlock switch RH connector | Terminal | Front power window motor RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D105 (A) | 4 | D104 (B) | 4 | Yes |



4. Check continuity between power window and door lock/unlock switch RH connector (A) and ground.

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

ENCODER CIRCUIT CHECK FRONT (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

| Power window and door lock/unlock switch RH connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D105 (A) | 4 | | No |

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-116. "Removal and Installation"](#).

NO >> Repair or replace harness.

4. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between front power window motor RH connector and ground.

| Front power window motor RH connector | Terminal | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| D104 | 6 | | Yes |

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 5

5. CHECK HARNESS CONTINUITY 2

- Disconnect power window and door lock/unlock switch RH.
- Check continuity between power window and door lock/unlock switch RH connector and front power window motor RH connector.

| Power window and door lock/unlock switch RH connector | Terminal | Front power window motor RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D105 | 3 | D104 | 6 | Yes |

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-116. "Removal and Installation"](#).

NO >> Repair or replace harness.




6. CHECK HARNESS CONTINUITY 3

- Disconnect power window and door lock/unlock switch RH.
- Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).

| Power window and door lock/unlock switch RH connector | Terminal | Front power window motor RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D105 (A) | 12 | D104 (B) | 3 | Yes |
| | 15 | | 5 | |

- Check continuity between power window and door lock/unlock switch RH connector (A) and ground.

| Power window and door lock/unlock switch RH connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D105 (A) | 12 | | No |
| | 15 | | |



ENCODER CIRCUIT CHECK FRONT (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace front power window motor RH. Refer to [GW-18, "Removal and Installation"](#).

NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

ENCODER CIRCUIT CHECK FRONT (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

ENCODER CIRCUIT CHECK FRONT (KING CAB)

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000011560303

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

DRIVER SIDE : Component Function Check

INFOID:000000011560304

1. CHECK ENCODER OPERATION

Does front door glass LH perform AUTO open/close operation normally when operating main power window and door lock/unlock switch?

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-38. "DRIVER SIDE : Diagnosis Procedure"](#)

DRIVER SIDE : Diagnosis Procedure



INFOID:000000011560305

Regarding Wiring Diagram information, refer to [PWC-81. "Wiring Diagram - King Cab"](#).

1. CHECK ENCODER OPERATION

1. Turn ignition switch ON.
2. Check signal between main power window and door lock/unlock switch connector and ground with oscilloscope.

| Terminals | | Signal (Reference value) |
|---|----------|-----------------------------|
| (+) | (-) | |
| Main power window and door lock/unlock switch connector | Terminal | Ground |
| D15 | 9 | |
| | 13 | Refer to following signal |



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> GO TO 2


2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY

ENCODER CIRCUIT CHECK FRONT (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect front power window motor LH.
2. Check voltage between front power window motor LH connector and ground.

| Terminal (+) | | Terminal (-) | Voltage (V) (Approx.) |
|---------------------------------------|----------|--------------|--------------------------|
| Front power window motor LH connector | Terminal | | |
| D9 | 4 | Ground | 10 |




Is the measurement value within the specification?

- YES >> GO TO 4
NO >> GO TO 3

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

| Main power window and door lock/unlock switch connector | Terminal | Front power window motor LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D15 (A) | 5 | D9 (B) | 4 | Yes |



4. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D15 (A) | 5 | | No |

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115, "Removal and Installation"](#).
NO >> Repair or replace harness.

4. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between front power window motor LH connector and ground.

| Front power window motor LH connector | Terminal | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| D9 | 6 | | Yes |

Is the inspection result normal?

- YES >> GO TO 6
NO >> GO TO 5

5. CHECK HARNESS CONTINUITY 2



ENCODER CIRCUIT CHECK FRONT (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector and front power window motor LH connector.

| Main power window and door lock/unlock switch connector | Terminal | Front power window motor LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D15 | 14 | D9 | 6 | Yes |

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115, "Removal and Installation"](#).

NO >> Repair or replace harness.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector (A) and front power window motor LH connector (B).

| Main power window and door lock/unlock switch connector | Terminal | Front power window motor LH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D15 (A) | 9 | D9 (B) | 5 | Yes |
| | 13 | | 3 | |

3. Check continuity between main power window and door lock/unlock switch connector (A) and ground.

| Main power window and door lock/unlock switch connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D15 (A) | 9 | Ground | No |
| | 13 | | |

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#).

NO >> Repair or replace harness.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000011560306

Detects condition of the front power window motor RH operation and transmits to power window and door lock/unlock switch RH as pulse signal.

PASSENGER SIDE : Component Function Check

INFOID:000000011560307

1. CHECK ENCODER OPERATION

Does front door glass RH perform AUTO open/close operation normally when operating power window and door lock/unlock switch RH?

Is the inspection result normal?



YES >> Encoder operation is OK.

NO >> Refer to [PWC-40, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000011560308

Regarding Wiring Diagram information, refer to [PWC-81, "Wiring Diagram - King Cab"](#).





ENCODER CIRCUIT CHECK FRONT (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

1. CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between power window and door lock/unlock switch RH connector and ground with oscilloscope.

| Terminals | | Signal (Reference value) |
|---|----------|-----------------------------|
| (+) | (-) | |
| Power window and door lock/unlock switch RH connector | Terminal | Ground |
| D105 | 12 15 | |
| | | Refer to following signal |




Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).
 NO >> GO TO 2

2. CHECK FRONT POWER WINDOW MOTOR RH POWER SUPPLY

1. Disconnect front power window motor RH.
2. Check voltage between front power window motor RH connector and ground.

| Terminal | | Voltage (V) (Approx.) |
|---------------------------------------|----------|--------------------------|
| (+) | (-) | |
| Front power window motor RH connector | Terminal | 10 |
| D104 | 4 | |




Is the measurement value within the specification?

- YES >> GO TO 4
 NO >> GO TO 3

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).

| Power window and door lock/unlock switch RH connector | Terminal | Front power window motor RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D105 (A) | 4 | D104 (B) | 4 | Yes |



4. Check continuity between power window and door lock/unlock switch RH connector (A) and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PWC

ENCODER CIRCUIT CHECK FRONT (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

| Power window and door lock/unlock switch RH connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D105 (A) | 4 | | No |

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-116. "Removal and Installation"](#).

NO >> Repair or replace harness.

4. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Check continuity between front power window motor RH connector and ground.

| Front power window motor RH connector | Terminal | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| D104 | 6 | | Yes |

Is the inspection result normal?

YES >> GO TO 6

NO >> GO TO 5

5. CHECK HARNESS CONTINUITY 2

- Disconnect power window and door lock/unlock switch RH.
- Check continuity between power window and door lock/unlock switch RH connector and front power window motor RH connector.

| Power window and door lock/unlock switch RH connector | Terminal | Front power window motor RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D105 | 3 | D104 | 6 | Yes |

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-116. "Removal and Installation"](#).

NO >> Repair or replace harness.




6. CHECK HARNESS CONTINUITY 3

- Disconnect power window and door lock/unlock switch RH.
- Check continuity between power window and door lock/unlock switch RH connector (A) and front power window motor RH connector (B).

| Power window and door lock/unlock switch RH connector | Terminal | Front power window motor RH connector | Terminal | Continuity |
|---|----------|---------------------------------------|----------|------------|
| D105 (A) | 12 | D104 (B) | 3 | Yes |
| | 15 | | 5 | |

- Check continuity between power window and door lock/unlock switch RH connector (A) and ground.

| Power window and door lock/unlock switch RH connector | Terminal | Ground | Continuity |
|---|----------|--------|------------|
| D105 (A) | 12 | | No |
| | 15 | | |



ENCODER CIRCUIT CHECK FRONT (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace front power window motor RH. Refer to [GW-18, "Removal and Installation"](#).

NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR SWITCH

CREW CAB

CREW CAB : Description

INFOID:0000000011885420

Detects door open/close condition.

CREW CAB : Component Function Check

INFOID:0000000011885421

1. CHECK FUNCTION

With CONSULT

Check door switches in data monitor mode with CONSULT.

| Monitor item | Condition |
|--------------|------------------------|
| DOOR SW-DR | CLOSE → OPEN: OFF → ON |
| DOOR SW-AS | |
| DOOR SW-RL | |
| DOOR SW-RR | |

Is the inspection result normal?

YES >> Door switch is OK.

NO >> Refer to [PWC-44, "CREW CAB : Diagnosis Procedure"](#).

CREW CAB : Diagnosis Procedure

INFOID:0000000011885422

Regarding Wiring Diagram information, refer to [DLK-85, "Wiring Diagram - Crew Cab"](#).

1. CHECK DOOR SWITCHES INPUT SIGNAL

With CONSULT

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR") in DATA MONITOR mode with CONSULT. Refer to [BCS-19, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

- When doors are open:

DOOR SW-DR :ON
DOOR SW-AS :ON
DOOR SW-RL :ON
DOOR SW-RR :ON

- When doors are closed:

DOOR SW-DR :OFF
DOOR SW-AS :OFF
DOOR SW-RL :OFF
DOOR SW-RR :OFF


Without CONSULT

Check voltage between BCM connector M18 or M19 terminals 12, 13, 47, 48 and ground.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Connector | Item | Terminals | | Condition | Voltage (V) (Approx.) |
|-----------|----------------------|-----------|--------|---------------------|---------------------------|
| | | (+) | (-) | | |
| M19 | Front door switch LH | 47 | Ground | Open ↓ Closed | 0 ↓ Battery voltage |
| | Rear door switch LH | 48 | | | |
| M18 | Front door switch RH | 12 | | | |
| | Rear door switch RH | 13 | | | |



Is the inspection result normal?

- YES >> Door switch circuit is OK.
- NO >> GO TO 2


2.CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (Front LH), B108 (Front RH), B18 (Rear LH), B116 (Rear RH) terminal 2 and BCM connector M18, M19 terminals 12, 13, 47 and 48.

- 2 - 47 :Continuity should exist
- 2 - 12 :Continuity should exist
- 2 - 48 :Continuity should exist
- 2 - 13 :Continuity should exist

4. Check continuity between door switch connector B8 (Front LH), B108 (Front RH), B18 (Rear LH), B116 (Rear RH) terminal 2 and ground.

- 2 - Ground :Continuity should not exist



Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.

3.CHECK DOOR SWITCHES

Check continuity between door switch terminal 2 and exposed metal of switch while pressing and releasing switch.

| | Terminals | Condition | Continuity |
|------------------------------|------------|-----------|------------|
| Door switch (front and rear) | 2 - Ground | Released | Yes |
| | | Pressed | No |

Is the inspection result normal?

- YES >> Check door switch case ground condition.
- NO >> Replace door switch.


KING CAB

KING CAB : Description

Detects door open/close condition.

KING CAB : Component Function Check

1.CHECK FUNCTION



INFOID:000000011885423

INFOID:000000011885424

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

④ With CONSULT

Check door switches in data monitor mode with CONSULT.

| Monitor item | Condition |
|--------------|------------------------|
| DOOR SW-DR | CLOSE → OPEN: OFF → ON |
| DOOR SW-AS | |

Is the inspection result normal?

YES >> Door switch is OK.

NO >> Refer to [PWC-46. "KING CAB : Diagnosis Procedure"](#).

KING CAB : Diagnosis Procedure

INFOID:000000011885425

Regarding Wiring Diagram information, refer to [DLK-77. "Wiring Diagram - King Cab"](#).

1. CHECK DOOR SWITCHES INPUT SIGNAL

④ With CONSULT

Check door switches ("DOOR SW-DR", "DOOR SW-AS") in DATA MONITOR mode with CONSULT. Refer to [BCS-19. "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

• When doors are open:

DOOR SW-DR :ON

DOOR SW-AS :ON

• When doors are closed:


DOOR SW-DR :OFF

DOOR SW-AS :OFF

⊗ Without CONSULT

Check voltage between BCM connector M18 or M19 terminals 12, 47 and ground.

| Connector | Item | Terminals | | Condition | Voltage (V) (Approx.) |
|-----------|------------------|-----------|--------|-----------|--------------------------|
| | | (+) | (-) | | |
| M19 | Door switches LH | 47 | Ground | Open | 0 |
| M18 | Door switches RH | 12 | | Closed | Battery voltage |



Is the inspection result normal?

YES >> Door switch circuit is OK.

NO >> GO TO 2

2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (Front LH), B108 (Front RH) terminal 2, B73 (Rear upper LH), B156 (Rear upper RH), B74 (Rear lower LH), B157 (Rear lower RH) terminal 1 and BCM connector M18, M19 terminals 12, and 47.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

- 2 - 47 :Continuity should exist
- 2 - 12 :Continuity should exist
- 1 - 47 :Continuity should exist
- 1 - 12 :Continuity should exist

4. Check continuity between door switch connector B8 (Front LH), B108 (Front RH) terminal 2, B73 (Rear upper LH), B156 (Rear upper RH), B74 (Rear lower LH), B157 (Rear lower RH) terminal 1 and ground.

- 2 - Ground :Continuity should not exist
- 1 - Ground :Continuity should not exist

Is the inspection result normal?

- YES >> GO TO 3
- NO >> Repair or replace harness.



3.CHECK DOOR SWITCHES

Check continuity between door switch terminals.

| Item | Terminals | Condition | Continuity |
|--------------------------------------|-----------|-----------|------------|
| Door switches (front) | 2 - 3 | Open | Yes |
| | | Closed | No |
| Door switches (rear upper and lower) | 1 - 2 | Open | Yes |
| | | Closed | No |

Is the inspection result normal?

- YES >> Repair or replace harness.
- NO >> Replace door switch.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (CREW CAB)

Description

INFOID:000000011885428

The main power window and door lock/unlock switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signal.

Component Function Check

INFOID:000000011885429

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check "KEY CYL LK-SW" AND "KEY CYL UN-SW" in DATA MONITOR mode for "POWER DOOR LOCK SYSTEM" with CONSULT.

| Monitor item | Condition |
|---------------|------------------------|
| KEY CYL LK-SW | Lock : ON |
| | Neutral / Unlock : OFF |
| KEY CYL UN-SW | Unlock : ON |
| | Neutral / Lock : OFF |

Is the inspection result normal?

- YES >> Key cylinder switch is OK.
- NO >> Refer to [PWC-48, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011885430

Regarding Wiring Diagram information, refer to [DLK-85, "Wiring Diagram - Crew Cab"](#).

1. CHECK DOOR KEY CYLINDER SWITCH LH

④ With CONSULT

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW") and ("KEY CYL UN-SW") in DATA MONITOR mode with CONSULT. Refer to [BCS-19, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

- When key inserted in front key cylinder is turned to LOCK:

KEY CYL LK-SW : ON

- When key inserted in front key cylinder is turned to UNLOCK:

KEY CYL UN-SW : ON


⊗ Without CONSULT

Check voltage between main power window and door lock/unlock switch connector D7 terminals 4, 6 and ground.

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

| Connector | Terminals | | Condition | Voltage (V) (Approx.) |
|-----------|-----------|--------|----------------|--------------------------|
| | (+) | (-) | | |
| D7 | 4 | Ground | Neutral/Unlock | 5 |
| | | | Lock | 0 |
| | 6 | | Neutral/Lock | 5 |
| | | | Unlock | 0 |



Is the inspection result normal?


YES >> Front door lock assembly LH (key cylinder switch) signal is OK.

NO >> GO TO 2

2. CHECK DOOR KEY CYLINDER SWITCH LH GROUND HARNESS

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly LH (key cylinder switch).
3. Check continuity between front door lock assembly LH (key cylinder switch) connector D14 terminal 5 and body ground.

| Connector | Terminals | Continuity |
|-----------|------------|------------|
| D14 | 5 – Ground | Yes |



Is the inspection result normal?


YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DOOR KEY CYLINDER SWITCH LH

Check continuity between front door lock assembly LH (key cylinder switch) terminals.

| Terminals | Condition | Continuity |
|-----------|-------------------------------------|------------|
| 1 – 5 | Key is turned to UNLOCK or neutral. | No |
| | Key is turned to LOCK. | Yes |
| 5 – 6 | Key is turned to LOCK or neutral. | No |
| | Key is turned to UNLOCK. | Yes |



Is the inspection result normal?

YES >> GO TO 4

NO >> Replace front door lock assembly LH (key cylinder switch). Refer to [DLK-130, "Removal and Installation"](#).

4. CHECK DOOR KEY CYLINDER HARNESS


1. Disconnect main power window and door lock/unlock switch.

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (CREW CAB)

< DTC/CIRCUIT DIAGNOSIS >

- Check continuity between main power window and door lock/unlock switch connector (A) D7 terminals 4, 6 and front door lock assembly LH (key cylinder switch) connector (B) D14 terminals 1, 6 and body ground.

| Connector | Terminals | Connector | Terminals | Continuity |
|-----------|-----------|-----------|-----------|------------|
| A: D7 | 4 | B: D14 | 1 | Yes |
| | 6 | | 6 | Yes |
| | 4, 6 | Ground | | No |



Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch.
- NO >> Repair or replace harness.

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (KING CAB)

Description

INFOID:0000000011885431

The main power window and door lock/unlock switch detects condition of the door key cylinder switch and transmits to BCM as the LOCK or UNLOCK signal.

Component Function Check

INFOID:0000000011885432

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Check "KEY CYL LK-SW" AND "KEY CYL UN-SW" in DATA MONITOR mode for "POWER DOOR LOCK SYSTEM" with CONSULT.

| Monitor item | Condition |
|---------------|------------------------|
| KEY CYL LK-SW | Lock : ON |
| | Neutral / Unlock : OFF |
| KEY CYL UN-SW | Unlock : ON |
| | Neutral / Lock : OFF |

Is the inspection result normal?

- YES >> Key cylinder switch is OK.
- NO >> Refer to [PWC-51, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011885433

Regarding Wiring Diagram information, refer to [DLK-77, "Wiring Diagram - King Cab"](#).

1. CHECK DOOR KEY CYLINDER SWITCH LH

With CONSULT

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW") and ("KEY CYL UN-SW) in DATA MONITOR mode with CONSULT. Refer to [BCS-19, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

- When key inserted in front key cylinder is turned to LOCK:

KEY CYL LK-SW : ON

- When key inserted in front key cylinder is turned to UNLOCK:

KEY CYL UN-SW : ON

Without CONSULT

Check voltage between main power window and door lock/unlock switch connector D15 terminals 6, 7 and ground.


A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

| Connector | Terminals | | Condition | Voltage (V) (Approx.) |
|-----------|-----------|--------|----------------|--------------------------|
| | (+) | (-) | | |
| D15 | 6 | Ground | Neutral/Unlock | 5 |
| | | | Lock | 0 |
| | 7 | | Neutral/Lock | 5 |
| | | | Unlock | 0 |



Is the inspection result normal?


YES >> Front door lock assembly LH (key cylinder switch) signal is OK.

NO >> GO TO 2

2. CHECK DOOR KEY CYLINDER SWITCH LH GROUND HARNESS

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly LH (key cylinder switch).
3. Check continuity between front door lock assembly LH (key cylinder switch) connector D14 terminal 5 and body ground.

| Connector | Terminals | Continuity |
|-----------|------------|------------|
| D14 | 5 – Ground | Yes |



Is the inspection result normal?


YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DOOR KEY CYLINDER SWITCH LH

Check continuity between front door lock assembly LH (key cylinder switch) terminals.

| Terminals | Condition | Continuity |
|-----------|-------------------------------------|------------|
| 1 – 5 | Key is turned to UNLOCK or neutral. | No |
| | Key is turned to LOCK. | Yes |
| 5 – 6 | Key is turned to LOCK or neutral. | No |
| | Key is turned to UNLOCK. | Yes |



Is the inspection result normal?

YES >> GO TO 4

NO >> Replace front door lock assembly LH (key cylinder switch). Refer to [DLK-130, "Removal and Installation"](#).

4. CHECK DOOR KEY CYLINDER HARNESS


1. Disconnect main power window and door lock/unlock switch.

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK (KING CAB)

< DTC/CIRCUIT DIAGNOSIS >

- Check continuity between main power window and door lock/unlock switch connector (A) D15 terminals 6, 7 and front door lock assembly LH (key cylinder switch) connector (B) D14 terminals 1, 6 and body ground.

| Connector | Terminals | Connector | Terminals | Continuity |
|-----------|-----------|-----------|-----------|------------|
| A: D15 | 6 | B: D14 | 1 | Yes |
| | 7 | | 6 | Yes |
| | 6, 7 | Ground | | No |



Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch.
- NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW SERIAL LINK

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000011560323

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Power window lock switch signal
- Retained power operation signal

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000011560324

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-19. "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

| Monitor item | Condition |
|---------------|--------------|
| CDL LOCK SW | LOCK : ON |
| | UNLOCK : OFF |
| CDL UNLOCK SW | LOCK : OFF |
| | UNLOCK : ON |

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-54. "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).


POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000011560325

Regarding Wiring Diagram information, refer to [PWC-88. "Wiring Diagram - Crew Cab"](#) or [PWC-81. "Wiring Diagram - King Cab"](#).

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Remove ignition key and close front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".



POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

| Terminal (+) | | Terminal (-) | Signal (Reference value) |
|---------------|----------|--------------|---|
| BCM connector | Terminal | | |
| M18 | 22 | Ground | <p>(V) 15 10 5 0</p> <p>200 ms</p> <p>P11A2344E</p> |

Is the inspection result normal?

- YES >> Power window serial link is OK.
NO >> GO TO 2

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM and main power window and door lock/unlock switch.
- Check continuity between BCM connector (A) and main power window and door lock/unlock switch connector (B) (Crew Cab) or (C) (King Cab).


| BCM connector | Terminal | Main power window and door lock/unlock switch connector | Terminal | Continuity |
|---------------|----------|---|----------|------------|
| M18 (A) | 22 | D7 (B) | 14 | Yes |
| | | D15 (C) | 12 | |

- Check continuity between BCM connector (A) and ground.

| BCM connector | Terminal | Ground | Continuity |
|---------------|----------|--------|------------|
| M18 (A) | 22 | | No |

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115, "Removal and Installation"](#).
NO >> Repair or replace harness.



FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000011560326

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Retained power operation signal
- Power window lock switch signal

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000011560327

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-19. "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

| Monitor item | Condition |
|---------------|--------------|
| CDL LOCK SW | LOCK : ON |
| | UNLOCK : OFF |
| CDL UNLOCK SW | LOCK : OFF |
| | UNLOCK : ON |

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-56. "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).


FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000011560328

Regarding Wiring Diagram information, refer to [PWC-88. "Wiring Diagram - Crew Cab"](#) or [PWC-81. "Wiring Diagram - King Cab"](#).

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

1. Remove ignition key, and close the front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".



| Terminal (+) | | Terminal (-) | Signal (Reference value) |
|---------------|----------|--------------|--------------------------|
| BCM connector | Terminal | | |
| M18 | 22 | Ground | <p>P11A2344E</p> |

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> GO TO 2


2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check continuity between BCM connector (A) and power window and door lock/unlock switch RH connector (B).

| BCM connector | Terminal | Power window and door lock/unlock switch RH connector | Terminal | Continuity |
|---------------|----------|---|----------|------------|
| M18 (A) | 22 | D105 (B) | 16 | Yes |



4. Check continuity between BCM connector (A) and ground.

| BCM connector | Terminal | Ground | Continuity |
|---------------|----------|--------|------------|
| M18 (A) | 22 | | No |

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115. "Removal and Installation"](#).
- NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW LOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW LOCK SWITCH

Description

INFOID:000000011560329

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

Component Function Check

INFOID:000000011560330

1. CHECK POWER WINDOW LOCK SIGNAL

Exchanges for a normal main power window and door lock/unlock switch, and operation is checked.

Does power window lock operate?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-115, "Removal and Installation"](#).
- NO >> Check condition of harness and connector.

REAR POWER DROP GLASS CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

REAR POWER DROP GLASS CIRCUIT CHECK

Rear Power Drop Glass Circuit Inspection

INFOID:000000011560331

Regarding Wiring Diagram information, refer to [PWC-88. "Wiring Diagram - Crew Cab"](#).

1. CHECK REAR POWER DROP GLASS SWITCH OPERATION

1. Turn ignition switch OFF.
2. Disconnect rear power drop glass switch.
3. Check continuity between rear power drop glass switch terminals 1, 3 and 5.

| Terminal | Condition | Continuity |
|----------|---|------------|
| 3 | 5 Rear power drop glass switch is pressed DOWN | Yes |
| | 1 Rear power drop glass switch is pressed UP | Yes |

Is the inspection result normal?

YES >> GO TO 2

NO >> Replace rear power drop glass switch. Refer to [PWC-117. "Removal and Installation - Power Drop Glass Switch"](#).

2. CHECK REAR POWER DROP GLASS SWITCH GROUND CIRCUIT HARNESS CONTINUITY

Check continuity between rear power drop glass switch connector R103 terminal 3 and ground.

3 - Ground : Continuity should exist.

Is the inspection result normal?


YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK REAR POWER DROP GLASS SIGNAL

1. Connect rear power drop glass switch.
2. Disconnect rear power drop glass motor.
3. Turn ignition switch ON.
4. Check voltage between rear power drop glass motor connector B80 terminals 1, 4 and ground.

| Connector | Terminals | | Condition | Voltage (V) (Approx.) |
|-----------|-----------|--------|-----------|--------------------------|
| | (+) | (-) | | |
| B80 | 1 | Ground | Up | Battery voltage |
| | | | Down | 0 |
| | 4 | | Up | 0 |
| | | | Down | Battery voltage |



Is the inspection result normal?

YES >> Replace rear power drop glass motor. Refer to [GW-13. "Removal and Installation"](#).

NO >> Repair or replace harness.

REAR POWER DROP GLASS DOWN RELAY CHECK

< DTC/CIRCUIT DIAGNOSIS >

REAR POWER DROP GLASS DOWN RELAY CHECK

Rear Power Drop Glass Down Relay Check


INFOID:000000011560332

Regarding Wiring Diagram information, refer to [PWC-88. "Wiring Diagram - Crew Cab"](#).

1. CHECK REAR POWER DROP GLASS DOWN RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power drop glass down relay.
3. Turn ignition switch ON.
4. Check voltage between rear power drop glass down relay connector and ground.

| Connector | Terminals | | Voltage (V) (Approx.) |
|-----------|-----------|--------|--------------------------|
| | (+) | (-) | |
| M155 | 1 | Ground | Battery voltage |
| | 5 | | |




Is the inspection result normal?

- YES >> GO TO 2
 NO >> Repair or replace harness.

2. CHECK REAR POWER DROP GLASS DOWN RELAY

Check continuity between rear power drop glass down relay terminals 3 and 4, 3 and 5.

| Terminal | Condition | Continuity | |
|----------|-----------|---|-----|
| 3 | 4 | 12V direct current supply between terminals 1 and 2 | No |
| | | No current supply | Yes |
| | 5 | 12V direct current supply between terminals 1 and 2 | Yes |
| | | No current supply | No |



Is the inspection result normal?

- YES >> GO TO 3
 NO >> Replace rear power drop glass down relay.


3. CHECK REAR POWER DROP GLASS DOWN RELAY GROUND CIRCUIT

Check continuity between rear power drop glass down relay connector M155 terminal 4 and ground.

4 - Ground : Continuity should exist.

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.



4. CHECK REAR POWER DROP GLASS DOWN RELAY CIRCUIT

REAR POWER DROP GLASS DOWN RELAY CHECK

< DTC/CIRCUIT DIAGNOSIS >


1. Disconnect rear power drop glass switch.
2. Check continuity between rear power drop glass down relay connector M155 terminal 2 and rear power drop glass switch connector R103 terminal 5.

2 - 5

: Continuity should exist.

Is the inspection result normal?

- YES >> Replace rear power drop glass switch. Refer to [PWC-117. "Removal and Installation - Power Drop Glass Switch"](#).
- NO >> Repair or replace harness.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR POWER DROP GLASS UP RELAY CHECK

< DTC/CIRCUIT DIAGNOSIS >

REAR POWER DROP GLASS UP RELAY CHECK

Rear Power Drop Glass Up Relay Check


INFOID:000000011560333

Regarding Wiring Diagram information, refer to [PWC-88. "Wiring Diagram - Crew Cab"](#).

1. CHECK REAR POWER DROP GLASS UP RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power drop glass up relay.
3. Turn ignition switch ON.
4. Check voltage between rear power drop glass up relay connector and ground.

| Connector | Terminals | | Voltage (V) (Approx.) |
|-----------|-----------|--------|--------------------------|
| | (+) | (-) | |
| M154 | 1 | Ground | Battery voltage |
| | 5 | | |




Is the inspection result normal?

- YES >> GO TO 2
 NO >> Repair or replace harness.

2. CHECK REAR POWER DROP GLASS UP RELAY

Check continuity between rear power drop glass down relay terminals 3 and 4, 3 and 5.

| Terminal | Condition | Continuity |
|----------|---|------------|
| 3 | 12V direct current supply between terminals 1 and 2 | No |
| | No current supply | Yes |
| 5 | 12V direct current supply between terminals 1 and 2 | Yes |
| | No current supply | No |



Is the inspection result normal?

- YES >> GO TO 3
 NO >> Replace rear power drop glass up relay.


3. CHECK REAR POWER DROP GLASS UP RELAY GROUND CIRCUIT

Check continuity between rear power drop glass up relay connector M154 terminal 4 and ground.

4 - Ground : Continuity should exist.

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair or replace harness.



4. CHECK REAR POWER DROP GLASS UP RELAY CIRCUIT

REAR POWER DROP GLASS UP RELAY CHECK

< DTC/CIRCUIT DIAGNOSIS >


1. Disconnect rear power drop glass switch.
2. Check continuity between rear power drop glass up relay connector M154 terminal 2 and rear power drop glass switch connector R103 terminal 1.

2 - 1

: Continuity should exist.

Is the inspection result normal?

- YES >> Replace rear power drop glass switch. Refer to [PWC-117. "Removal and Installation - Power Drop Glass Switch"](#).
- NO >> Repair or replace harness.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000011885434

NOTE:

The Signal Tech II Tool [- (J-50190)] can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information:

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Test remote keyless entry keyfob relative signal strength

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | Value/Status |
|---------------|--|-------------------------------|
| ACC ON SW | Ignition switch OFF or ON | Off |
| | Ignition switch ACC | On |
| AIR COND SW | A/C switch OFF | Off |
| | A/C switch ON | On |
| AIR PRESS FL | Front left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS FR | Front right tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RL | Rear left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RR | Rear right tire air pressure value | kPa, kg/cm ² , psi |
| AUTO LIGHT SW | Lighting switch OFF | Off |
| | Lighting switch AUTO | On |
| BRAKE SW | Brake pedal released | Off |
| | Brake pedal applied | On |
| BUCKLE SW | Seat belt buckle unfastened | Off |
| | Seat belt buckle fastened | On |
| BUZZER | Buzzer in combination meter OFF | Off |
| | Buzzer in combination meter ON | On |
| CARGO LAMP SW | Cargo lamp switch OFF | Off |
| | Cargo lamp switch ON | On |
| CDL LOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the LOCK side | On |
| CDL UNLOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the UNLOCK side | On |
| DOOR SW-AS | Front door RH closed | Off |
| | Front door RH opened | On |
| DOOR SW-DR | Front door LH closed | Off |
| | Front door LH opened | On |
| DOOR SW-RL | Rear door LH closed | Off |
| | Rear door LH opened | On |
| DOOR SW-RR | Rear door RH closed | Off |
| | Rear door RH opened | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|---------------|---|--------------|-----|
| FAN ON SIG | Blower motor fan switch OFF | Off | A |
| | Blower motor fan switch ON | On | |
| FR FOG SW | Front fog lamp switch OFF | Off | B |
| | Front fog lamp switch ON | On | |
| FR WASHER SW | Front washer switch OFF | Off | C |
| | Front washer switch ON | On | |
| FR WIPER LOW | Front wiper switch OFF | Off | |
| | Front wiper switch LO | On | D |
| FR WIPER HI | Front wiper switch OFF | Off | |
| | Front wiper switch HI | On | |
| FR WIPER INT | Front wiper switch OFF | Off | E |
| | Front wiper switch INT | On | |
| FR WIPER STOP | Any position other than front wiper stop position | Off | F |
| | Front wiper stop position | On | |
| HAZARD SW | When hazard switch is not pressed | Off | |
| | When hazard switch is pressed | On | G |
| HEAD LAMP SW1 | Headlamp switch OFF | Off | |
| | Headlamp switch 1st | On | H |
| HEAD LAMP SW2 | Headlamp switch OFF | Off | |
| | Headlamp switch 1st | On | |
| HI BEAM SW | High beam switch OFF | Off | I |
| | High beam switch HI | On | |
| ID REGST FL1 | ID registration of front left tire incomplete | YET | J |
| | ID registration of front left tire complete | DONE | |
| ID REGST FR1 | ID registration of front right tire incomplete | YET | |
| | ID registration of front right tire complete | DONE | PWC |
| ID REGST RL1 | ID registration of rear left tire incomplete | YET | |
| | ID registration of rear left tire complete | DONE | |
| ID REGST RR1 | ID registration of rear right tire incomplete | YET | L |
| | ID registration of rear right tire complete | DONE | |
| IGN ON SW | Ignition switch OFF or ACC | Off | M |
| | Ignition switch ON | On | |
| IGN SW CAN | Ignition switch OFF or ACC | Off | |
| | Ignition switch ON | On | N |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 7 | 1 - 7 | |
| KEY CYL LK-SW | Door key cylinder LOCK position | Off | O |
| | Door key cylinder other than LOCK position | On | |
| KEY CYL UN-SW | Door key cylinder UNLOCK position | Off | |
| | Door key cylinder other than UNLOCK position | On | P |
| KEY ON SW | Mechanical key is removed from key cylinder | Off | |
| | Mechanical key is inserted to key cylinder | On | |
| KEYLESS LOCK | LOCK button of key fob is not pressed | Off | |
| | LOCK button of key fob is pressed | On | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


| Monitor Item | Condition | Value/Status |
|----------------|--|-----------------------------------|
| KEYLESS PANIC | PANIC button of key fob is not pressed | Off |
| | PANIC button of key fob is pressed | On |
| KEYLESS UNLOCK | UNLOCK button of key fob is not pressed | Off |
| | UNLOCK button of key fob is pressed | On |
| LIGHT SW 1ST | Lighting switch OFF | Off |
| | Lighting switch 1st | On |
| OIL PRESS SW | <ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running | Off |
| | Ignition switch ON | On |
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5V |
| | Dark outside of the vehicle | Close to 0V |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| REAR DEF SW | Rear window defogger switch OFF | Off |
| | Rear window defogger switch ON | On |
| TURN SIGNAL L | Turn signal switch OFF | Off |
| | Turn signal switch LH | On |
| TURN SIGNAL R | Turn signal switch OFF | Off |
| | Turn signal switch RH | On |
| VEHICLE SPEED | While driving | Equivalent to speedometer reading |
| WARNING LAMP | Low tire pressure warning lamp in combination meter OFF | Off |
| | Low tire pressure warning lamp in combination meter ON | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal Layout

INFOID:000000011885435



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC





Physical Values

AWMIA15422Z

INFOID:000000011885436

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|---|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 1 | BR/W | Key ring output | Output | OFF | ON (driver door open) | 0V |
| | | | | | OFF (driver door closed) | Battery voltage |
| 2 | SB | Combination switch input 5 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 3 | G/Y | Combination switch input 4 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 4 | Y | Combination switch input 3 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 5 | G/B | Combination switch input 2 | Input | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 6 | V | Combination switch input 1 | | | | |
| 9 | R/G | Brake switch | Input | ON | Brake pedal depressed | Battery voltage |
| | | | | | Brake pedal released | 0V |
| 11 | O | Ignition switch (ACC or ON) | Input | ACC or ON | Ignition switch ACC or ON | Battery voltage |
| 12 | R/L | Front door switch RH (All) | Input | OFF | ON (open) | 0V |
| | | Rear door switch lower RH (King Cab) | | | OFF (closed) | Battery voltage |
| | | Rear door switch upper RH (King Cab) | | | | |
| 13 | GR | Rear door switch RH (Crew Cab) | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 15 | L/W | Tire pressure warning check connector | Input | OFF | — | 5V |
| 18 | P | Remote keyless entry receiver and optical sensor (ground) | Output | OFF | — | 0V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|--|---------------------|---------------------|---|--|
| | | | | Ignition switch | Operation or condition | |
| 19 | V/W | Remote keyless entry receiver (power supply) | Output | OFF | Ignition switch OFF | |
| 20 | G/W | Remote keyless entry receiver (signal) | Input | OFF | Stand-by (keyfob buttons released) | |
| | | | | | When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed) | |
| 21 | G | NATS antenna amp. | Input | OFF → ON | Ignition switch (OFF → ON) | Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage. |
| 22 | G | BUS | — | — | Ignition switch ON or power window timer operates | |
| 23 | G/O | Security indicator lamp | Output | OFF | Goes OFF → illuminates (Every 2.4 seconds) | Battery voltage → 0V |
| 25 | BR | NATS antenna amp. | Input | OFF → ON | Ignition switch (OFF → ON) | Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage. |
| 27 | W/R | Compressor ON signal | Input | ON | A/C switch OFF | 5V |
| | | | | | A/C switch ON | 0V |
| 28 | L/R | Front blower monitor | Input | ON | Front blower motor OFF | Battery voltage |
| | | | | | Front blower motor ON | 0V |
| 29 | W/B | Hazard switch | Input | OFF | ON | 0V |
| | | | | | OFF | 5V |
| 31 | P/L | Cargo lamp switch | Input | OFF | Cargo lamp switch ON | 0 |
| | | | | | Cargo lamp switch OFF | Battery voltage |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|--------------------------------------|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 32 | R/G | Combination switch output 5 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 33 | R/Y | Combination switch output 4 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 34 | L | Combination switch output 3 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5291E</p> |
| 35 | O/B | Combination switch output 2 | Output | ON | Lighting, turn, wiper OFF Wiper dial position 4 |  <p style="text-align: right; font-size: small;">SKIA5292E</p> |
| 36 | R/W | Combination switch output 1 | | | | |
| 37 | B/R | Key switch and key lock solenoid | Input | OFF | Key inserted | Battery voltage |
| | | | | | Key removed | 0V |
| 38 | W/L | Ignition switch (ON) | Input | ON | — | Battery voltage |
| 39 | L | CAN-H | — | — | — | — |
| 40 | P | CAN-L | — | — | — | — |
| 41 | Y/B | Rear defogger switch | Input | ON | Rear defogger switch ON | 0V |
| | | | | | Rear defogger switch OFF | 5V |
| 47 | SB | Front door switch LH (All) | Input | OFF | ON (open) | 0V |
| | | Rear door switch lower LH (King Cab) | | | | |
| | | Rear door switch upper LH (King Cab) | | | | |
| 48 | R/Y | Rear door switch LH (Crew Cab) | Input | OFF | ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 50 | R/Y | Cargo bed lamp control | Output | OFF | Cargo lamp switch (ON) | 0V |
| | | | | | Cargo lamp switch (OFF) | Battery voltage |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|---|---------------------|---------------------|--|---|
| | | | | Ignition switch | Operation or condition | |
| 51 | Y/B | Trailer turn signal (right) | Output | ON | Turn right ON | <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 52 | G/B | Trailer turn signal (left) | Output | ON | Turn left ON | <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 56 | R/G | Battery saver output | Output | OFF | 15 minutes after ignition switch is turned OFF | 0V |
| | | | | ON | — | Battery voltage |
| 57 | Y/R | Battery power supply | Input | OFF | — | Battery voltage |
| 58 | W/R | Optical sensor | Input | ON | When optical sensor is illuminated | 3.1V or more |
| | | | | | When optical sensor is not illuminated | 0.6V or less |
| 59 | G | Front door lock assembly LH actuator (unlock) | Output | OFF | OFF (neutral) | 0V |
| | | | | | ON (unlock) | Battery voltage |
| 60 | G/B | Turn signal (left) | Output | ON | Turn left ON | <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 61 | G/Y | Turn signal (right) | Output | ON | Turn right ON | <p style="text-align: right; font-size: small;">SKIA3009J</p> |
| 63 | L | Interior room/map lamp | Output | OFF | Any door switch ON (open) | 0V |
| | | | | | OFF (closed) | Battery voltage |
| 65 | V | All door lock actuators (lock) | Output | OFF | OFF (neutral) | 0V |
| | | | | | ON (lock) | Battery voltage |
| 66 | G/Y | Front door lock actuator RH and rear door lock actuators LH/RH (unlock) | Output | OFF | OFF (neutral) | 0V |
| | | | | | ON (unlock) | Battery voltage |
| 67 | B | Ground | Input | ON | — | 0V |

A
B
C
D
E
F
G
H
I
J

PWC

L
M
N
O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal | Wire color | Signal name | Signal input/output | Measuring condition | | Reference value or waveform (Approx.) |
|----------|------------|---------------------------------|---------------------|---------------------|---|---------------------------------------|
| | | | | Ignition switch | Operation or condition | |
| 68 | W/L | Power window power supply (RAP) | Output | — | Ignition switch ON | Battery voltage |
| | | | | | Within 45 seconds after ignition switch OFF | Battery voltage |
| | | | | | More than 45 seconds after ignition switch OFF | 0V |
| | | | | | When front door LH or RH is open or power window timer operates | 0V |
| 69 | W/R | Power window power supply | Output | — | — | Battery voltage |
| 70 | W/B | Battery power supply | Input | OFF | — | Battery voltage |

Fail Safe

INFOID:000000011885437

Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|-------------------------|---|
| U1000: CAN COMM CIRCUIT | Inhibit engine cranking | When the BCM re-establishes communication with the other modules. |

DTC Inspection Priority Chart

INFOID:000000011885438

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart:

| Priority | DTC |
|----------|---|
| 1 | <ul style="list-style-type: none"> U1000: CAN COMM CIRCUIT |
| 2 | <ul style="list-style-type: none"> B2190: NATS ANTENNA AMP B2191: DIFFERENCE OF KEY B2192: ID DISCORD BCM-ECM B2193: CHAIN OF BCM-ECM |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Priority | DTC | A |
|----------|--|----------------------------|
| 3 | <ul style="list-style-type: none"> • C1729: VHCL SPEED SIG ERR • C1735: IGNITION SIGNAL | B |
| 4 | <ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL | C D E F G H |

DTC Index

INFOID:000000011885439

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

PWC

| CONSULT display | Fail-safe | Tire pressure monitor warning lamp ON | Reference page | L |
|--|-----------|---------------------------------------|------------------------|---|
| No DTC is detected. further testing may be required. | — | — | — | M |
| U1000: CAN COMM CIRCUIT | — | — | BCS-30 | N |
| B2190: NATS ANTENA AMP | — | — | SEC-18 | O |
| B2191: DIFFERENCE OF KEY | — | — | SEC-21 | P |
| B2192: ID DISCORD BCM-ECM | — | — | SEC-22 | |
| B2193: CHAIN OF BCM-ECM | — | — | SEC-24 | |
| C1708: [NO DATA] FL | — | — | WT-15 | |
| C1709: [NO DATA] FR | — | — | WT-15 | |
| C1710: [NO DATA] RR | — | — | WT-15 | |
| C1711: [NO DATA] RL | — | — | WT-15 | |
| C1712: [CHECKSUM ERR] FL | — | — | WT-17 | |
| C1713: [CHECKSUM ERR] FR | — | — | WT-17 | |
| C1714: [CHECKSUM ERR] RR | — | — | WT-17 | |
| C1715: [CHECKSUM ERR] RL | — | — | WT-17 | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Tire pressure monitor warning lamp ON | Reference page |
|---------------------------|-----------|---------------------------------------|-----------------------|
| C1716: [PRESSDATA ERR] FL | — | — | WT-19 |
| C1717: [PRESSDATA ERR] FR | — | — | WT-19 |
| C1718: [PRESSDATA ERR] RR | — | — | WT-19 |
| C1719: [PRESSDATA ERR] RL | — | — | WT-19 |
| C1720: [CODE ERR] FL | — | — | WT-17 |
| C1721: [CODE ERR] FR | — | — | WT-17 |
| C1722: [CODE ERR] RR | — | — | WT-17 |
| C1723: [CODE ERR] RL | — | — | WT-17 |
| C1724: [BATT VOLT LOW] FL | — | — | WT-17 |
| C1725: [BATT VOLT LOW] FR | — | — | WT-17 |
| C1726: [BATT VOLT LOW] RR | — | — | WT-17 |
| C1727: [BATT VOLT LOW] RL | — | — | WT-17 |
| C1729: VHCL SPEED SIG ERR | — | — | WT-21 |
| C1735: IGNITION SIGNAL | — | — | WT-23 |

POWER WINDOW MAIN SWITCH


< ECU DIAGNOSIS INFORMATION >

POWER WINDOW MAIN SWITCH

Reference Value (Crew Cab)

INFOID:000000011560340

TERMINAL LAYOUT



PHYSICAL VALUES



MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

| Terminal No. (Wire color) | | Description | | Condition | Voltage [V] (Approx.) |
|------------------------------|--------|---|------------------|---|--------------------------|
| + | - | Signal name | Input/ Output | | |
| 1 (R/Y) | Ground | Rear power window motor LH UP signal | Output | When rear LH switch in power window main switch is operated UP. | Battery voltage |
| 2 (W/B) | Ground | Encoder ground | — | — | 0 |
| 3 (R/B) | Ground | Rear power window motor LH DOWN signal | Output | When rear LH switch in power window main switch is operated DOWN. | Battery voltage |
| 4 (L) | Ground | Door key cylinder switch LH LOCK signal | Input | Key position (Neutral → Locked) | 5 → 0 |
| 5 (L) | Ground | Rear power window motor RH DOWN signal | Output | When rear RH switch in power window main switch is operated DOWN. | Battery voltage |
| 6 (R) | Ground | Door key cylinder switch LH UNLOCK signal | Input | Key position (Neutral → Unlocked) | 5 → 0 |
| 7 (R) | Ground | Rear power window motor RH UP signal | Output | When rear RH switch in power window main switch is operated UP. | Battery voltage |
| 8 (G/R) | 11 | Front door power window mo- tor LH UP signal | Output | When front LH switch in power window main switch is operated UP. | Battery voltage |
| 9 (O) | 2 | Encoder pulse signal 2 | Input | When power window mo- tor operates. | |

JMKIA0070GB

POWER WINDOW MAIN SWITCH


< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Voltage [V] (Approx.) |
|------------------------------|--------|--|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 10 (W/L) | Ground | RAP signal | Input | IGN SW ON | Battery voltage |
| | | | | Within 45 second after ignition switch is turned to OFF. | Battery voltage |
| | | | | When front LH or RH door is opened during retained power operation. | 0 |
| 11 (G/W) | 8 | Front door power window motor LH DOWN signal | Output | When front LH switch in power window main switch is operated DOWN. | Battery voltage |
| 13 (G/Y) | 2 | Encoder pulse signal 1 | Input | When power window motor operates. |  <small>JMKIA0070GB</small> |
| 14 (LG/W) | Ground | Power window serial link | Input/ Output | IGN SW ON or power window timer operating. |  <small>PIIA2344E</small> |
| 15 (BR) | Ground | Encoder power supply | Output | When ignition switch ON or power window timer operates. | 10 |
| 17 (B) | Ground | Ground | — | — | 0 |
| 19 (W/R) | Ground | Battery power supply | Input | — | Battery voltage |

Reference Value (King Cab)

INFOID:000000011560341

TERMINAL LAYOUT






PHYSICAL VALUES

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Voltage [V] (Approx.) |
|------------------------------|--------|--|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 1 (W/R) | Ground | Battery power supply | Input | — | Battery voltage |
| 5 (BR) | Ground | Encoder power supply | Output | When ignition switch ON or power window timer operates | 10 |
| 6 (L) | Ground | Door key cylinder switch LH LOCK signal | Input | Key position (Neutral → Locked) | 5 → 0 |
| 7 (R) | Ground | Door key cylinder switch LH UNLOCK signal | Input | Key position (Neutral → Unlocked) | 5 → 0 |
| 8 (G/R) | 11 | Front door power window motor LH UP signal | Output | When front LH switch in power window main switch is operated UP. | Battery voltage |
| 9 (O) | 3 | Encoder pulse signal 2 | Input | When power window motor operates. |  <small>JMKIA0070GB</small> |
| 10 (W/L) | Ground | RAP signal | Input | IGN SW ON | Battery voltage |
| | | | | Within 45 second after ignition switch is turned to OFF. | Battery voltage |
| | | | | When front LH or RH door is opened during retained power operation. | 0 |
| 11 (G/W) | 8 | Front door power window motor LH DOWN signal | Output | When front LH switch in power window main switch is operated DOWN. | Battery voltage |
| 12 (LG/W) | Ground | Power window serial link | Input/ Output | IGN SW ON or power window timer operating. |  <small>PIIA2344E</small> |
| 13 (G/Y) | 3 | Encoder pulse signal 1 | Input | When power window motor operates. |  <small>JMKIA0070GB</small> |
| 14 (W/B) | Ground | Encoder ground | — | — | 0 |
| 15 (B) | Ground | Ground | — | — | 0 |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

Fail Safe

INFOID:000000011560342

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

| Error | Error condition |
|---|--|
| Pulse sensor malfunction | When only one side of pulse signal is being detected for more than the specified value. |
| Both pulse sensors malfunction | When both pulse signals have not been detected for more than the specified value during glass open/close operation. |
| Pulse direction malfunction | When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction. |
| Glass recognition position malfunction 1 | When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value. |
| Glass recognition position malfunction 2 | When it detects pulse count more than the value of glass full stroke during glass open/close operation. |
| Malfunction of not yet updated closed position of glass | When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes). |

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

FRONT POWER WINDOW SWITCH


< ECU DIAGNOSIS INFORMATION >

FRONT POWER WINDOW SWITCH

Reference Value

INFOID:000000011560343

TERMINAL LAYOUT



PHYSICAL VALUES



POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

| Terminal No. (Wire color) | | Description | | Condition | Voltage [V] (Approx.) |
|------------------------------|--------|--------------------------------|------------------|--|--------------------------|
| + | - | Signal name | Input/ Output | | |
| 3 (W/B) | Ground | Encoder ground | — | — | 0 |
| 4 (G/R) | Ground | Encoder power supply | Output | When ignition switch ON or power window timer operates | 10 |
| 8 (L) | 9 | Power window motor UP signal | Output | When power window motor is UP at operated. | Battery voltage |
| 9 (G) | 8 | Power window motor DOWN signal | Output | When power window motor is DOWN at operated. | Battery voltage |
| 10 (W/R) | Ground | Battery power supply | Input | — | Battery voltage |
| 11 (B) | Ground | Ground | — | — | 0 |
| 12 (G/Y) | 3 | Encoder pulse signal 1 | Input | When power window motor operates. | |

JMKIA0070GB

FRONT POWER WINDOW SWITCH

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Voltage [V] (Approx.) |
|------------------------------|--------|--------------------------|------------------|--|---|
| + | - | Signal name | Input/ Output | | |
| 15 (G/W) | 3 | Encoder pulse signal 2 | Input | When power window motor operates. |  |
| 16 (LG/W) | Ground | Power window serial link | Input/ Output | IGN SW ON or power window timer operating. |  |

Fail Safe

INFOID:0000000011560344

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

| Error | Error condition |
|---|--|
| Pulse sensor malfunction | When only one side of pulse signal is being detected for more than the specified value. |
| Both pulse sensors malfunction | When both pulse signals have not been detected for more than the specified value during glass open/close operation. |
| Pulse direction malfunction | When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction. |
| Glass recognition position malfunction 1 | When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value. |
| Glass recognition position malfunction 2 | When it detects pulse count more than the value of glass full stroke during glass open/close operation. |
| Malfunction of not yet updated closed position of glass | When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes). |

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

POWER WINDOW SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

POWER WINDOW SYSTEM

Wiring Diagram - King Cab

INFOID:000000011560345



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

AAKWA1165GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM - KING CAB CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M8 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |

| | | | | | | |
|----|----|----|----|----|----|----|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 |
| 9 | 8 | | | | | |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5 | W/R | - |
| 6 | SHIELD | - |
| 8 | G | - |
| 9 | W/L | - |
| 14 | B | - |

| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | | | |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 67 | B | GND (POWER) |
| 68 | W/L | POWER WINDOW POWER SUPPLY (LINKED TO RAP) |
| 69 | W/R | POWER WINDOW POWER SUPPLY (BAT) |
| 70 | W/B | BAT (F/L) |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |




| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------------|
| 11 | O | ACC SW |
| 12 | R/L | DOOR SW (AS) |
| 22 | G | ANTI-PINCH SERIAL LINK (RX, TX) |
| 38 | W/L | IGN SW |



| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |

| | | | | |
|---|---|---|---|----|
| 1 | 2 | 3 | 4 | 5 |
| 6 | 7 | 8 | 9 | 10 |



| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 |
| 50 | 51 | 52 | 53 | 54 | 55 | | | |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 47 | SB | DOOR SW (DR) |

| | | | | | |
|--------------|-----|---------------|-----|-------------|---|
| Terminal No. | 96G | Color of Wire | W/B | Signal Name | - |
| Terminal No. | 99G | Color of Wire | W/L | Signal Name | - |

POWER WINDOW SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|------------------|
| Connector No. | M60 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6T | O | - |

| | |
|-----------------|--------------|
| Connector No. | M40 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 30J | SB | - |

| | |
|-----------------|--------------|
| Connector No. | M36 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 21A | R/L | - |

| | |
|-----------------|---------------------|
| Connector No. | M192 |
| Connector Name | JOINT CONNECTOR-M02 |
| Connector Color | GREEN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | - |
| 4 | O | - |

| | |
|-----------------|--------------|
| Connector No. | M75 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/R | - |
| 3 | B | - |
| 6 | SHIELD | - |
| 7 | G | - |

ABKIA4086GB


A B C D E F G H I J L M N O P



POWER WINDOW SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 96G | W/B | - |
| 99G | L/W | - |

| | |
|-----------------|----------------------|
| Connector No. | B8 |
| Connector Name | FRONT DOOR SWITCH LH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | - |
| 3 | B | - |

| | |
|-----------------|--------------|
| Connector No. | B69 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 30J | SB | - |

| | |
|-----------------|---------------------------|
| Connector No. | B73 |
| Connector Name | REAR DOOR SWITCH UPPER LH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | B | - |

| | |
|-----------------|---------------------------|
| Connector No. | B74 |
| Connector Name | REAR DOOR SWITCH LOWER LH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | B | - |

| | |
|-----------------|----------------------|
| Connector No. | B108 |
| Connector Name | FRONT DOOR SWITCH RH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | R/L | - |
| 3 | B | - |

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|---------------------------|
| Connector No. | B156 |
| Connector Name | REAR DOOR SWITCH UPPER RH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | - |
| 2 | B | - |

| | | |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 21A | R/L | - |

| | |
|-----------------|--------------|
| Connector No. | B149 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|-----------------------------|
| Connector No. | D9 |
| Connector Name | FRONT POWER WINDOW MOTOR LH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G/W | - |
| 2 | G/R | - |
| 3 | G/Y | - |
| 4 | BR | - |
| 5 | O | - |
| 6 | W/B | - |

| | |
|-----------------|--------------|
| Connector No. | D2 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5 | W/R | - |
| 6 | SHIELD | - |
| 8 | LG/W | - |
| 9 | W/L | - |
| 14 | B | - |

| | |
|-----------------|---------------------------|
| Connector No. | B157 |
| Connector Name | REAR DOOR SWITCH LOWER RH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/L | - |
| 2 | B | - |

ABKIA4088GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 6 | L | KEY CYLINDER LOCK |
| 7 | R | KEY CYLINDER UNLOCK |
| 8 | G/R | UP (DR) |
| 9 | O | LIMIT SW |
| 10 | W/L | IGN |
| 11 | G/W | DN (DR) |
| 12 | LG/W | COMMUNICATION |
| 13 | G/Y | ENCODER PULSE |
| 14 | W/B | ENCODER GND |
| 15 | B | GND |
| 16 | - | - |

| | |
|-----------------|--|
| Connector No. | D15 |
| Connector Name | MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (KING CAB) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 1 | W/R | BAT |
| 2 | - | - |
| 3 | - | - |
| 4 | - | - |
| 5 | BR | ENCODER POWER SUPPLY |

| | |
|-----------------|-----------------------------|
| Connector No. | D14 |
| Connector Name | FRONT DOOR LOCK ASSEMBLY LH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 5 | B | - |
| 6 | R | - |

| | |
|-----------------|-----------------------------|
| Connector No. | D104 |
| Connector Name | FRONT POWER WINDOW MOTOR RH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | L | - |
| 3 | G/Y | - |
| 4 | G/R | - |
| 5 | G/W | - |
| 6 | W/B | - |

| | |
|-----------------|--------------|
| Connector No. | D101 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/R | - |
| 3 | B | - |
| 6 | SHIELD | - |
| 7 | LG/W | - |

ABKIA5871GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------|
| 8 | L | UP |
| 9 | G | DOWN |
| 10 | W/R | BAT |
| 11 | B | GND |
| 12 | G/Y | ENCODER PULSE |
| 13 | - | - |
| 14 | - | - |
| 15 | G/W | LIMIT SW |
| 16 | LG/W | COMMUNICATION |

| | |
|-----------------|---|
| Connector No. | D105 |
| Connector Name | POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH |
| Connector Color | WHITE |

| | | | | | | |
|---|---|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| | | | | | | 15 |
| | | | | | | 16 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 1 | - | - |
| 2 | - | - |
| 3 | W/B | ENCODER GND |
| 4 | G/R | ENCODER POWER SUPPLY |
| 5 | - | - |
| 6 | - | - |
| 7 | - | - |

ABKIA5872GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

Wiring Diagram - Crew Cab


INFOID:000000011560346



AAKWA1166GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PWC


ABKWA2566GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM - CREW CAB CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | | | | |
|----|----|----|----|----|----|----|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | | |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | - |
| 2 | LW | - |
| 3 | G | - |


| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|----|----|
| 7P | 6P | 5P | 4P | 3P | 2P | 1P | | |
| 16P | 15P | 14P | 13P | 12P | 11P | 10P | 9P | 8P |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5P | O/L | - |

| | |
|-----------------|--------------|
| Connector No. | M8 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | | | | | | | | |
|----|----|----|----|----|----|----|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | | |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/B | - |
| 2 | R/Y | - |
| 3 | L | - |
| 4 | R | - |
| 5 | W/R | - |
| 6 | SHIELD | - |
| 8 | G | - |
| 9 | W/L | - |
| 14 | B | - |

| | |
|-----------------|---------------------------|
| Connector No. | M18 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------------|
| 11 | O | ACC SW |
| 12 | R/L | DOOR SW (AS) |
| 22 | G | ANTI-PINCH SERIAL LINK (RX, TX) |
| 38 | W/L | IGN SW |

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | WHITE |



| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 |
| 50 | 51 | 52 | 53 | 54 | 55 | | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 47 | SB | DOOR SW (DR) |

| | |
|-----------------|---------------------------|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK |




| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 67 | B | GND (POWER) |
| 68 | W/L | POWER WINDOW POWER SUPPLY (LINKED TO RAF) |
| 69 | W/R | POWER WINDOW POWER SUPPLY (BAT) |
| 70 | W/B | BAT (F/L) |

POWER WINDOW SYSTEM

< WIRING DIAGRAM >



| | |
|-----------------|--------------|
| Connector No. | M40 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |

| | |
|-----------------|--------------|
| Connector No. | M36 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |

| | |
|-----------------|--------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|-------------------|
| Connector No. | M82 |
| Connector Name | CIRCUIT BREAKER-2 |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L/B | - |
| 2 | W/B | - |

| | |
|-----------------|--------------|
| Connector No. | M75 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/R | - |
| 3 | B | - |
| 6 | SHIELD | - |
| 7 | G | - |

| | |
|-----------------|------------------|
| Connector No. | M60 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6T | O | - |

| | |
|-----------------|---------------------|
| Connector No. | M192 |
| Connector Name | JOINT CONNECTOR-M02 |
| Connector Color | GREEN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | - |
| 4 | O | - |
| 6 | O/L | - |
| 8 | O/L | - |
| 9 | O/L | - |

| | |
|-----------------|----------------------------------|
| Connector No. | M155 |
| Connector Name | REAR POWER DROP GLASS DOWN RELAY |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/L | - |
| 2 | L/W | - |
| 3 | B/R | - |
| 4 | B | - |
| 5 | L/B | - |

| | |
|-----------------|--------------------------------|
| Connector No. | M154 |
| Connector Name | REAR POWER DROP GLASS UP RELAY |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/L | - |
| 2 | G | - |
| 3 | L/Y | - |
| 4 | B | - |
| 5 | L/B | - |

ABKIA4092GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|--------------|
| Connector No. | B6 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | O/L | - |
| 11 | B | - |
| 16 | W/L | - |
| 17 | R/B | - |
| 18 | R/Y | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 96G | W/B | - |
| 99G | L/W | - |

| | |
|-----------------|--------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|----------------------|
| Connector No. | B8 |
| Connector Name | FRONT DOOR SWITCH LH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | SB | - |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|--------------------------------|
| Connector No. | B80 |
| Connector Name | REAR POWER DROP GLASS MOTOR |
| Connector Color | GRAY |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L/Y | - |
| 4 | B/R | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2J | R/Y | - |
| 3J | R/B | - |
| 4J | W/L | - |
| 16J | O/L | - |
| 30J | SB | - |
| 97J | L/Y | - |
| 98J | B/R | - |

| | |
|-----------------|--------------|
| Connector No. | B69 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | |
|-----------------|----------------------|
| Connector No. | B108 |
| Connector Name | FRONT DOOR SWITCH RH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | R/L | - |

| | |
|-----------------|--------------|
| Connector No. | B106 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | O/L | - |
| 11 | B | - |
| 16 | W/L | - |
| 17 | L | - |
| 18 | R | - |

ABKIA4094GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


| | |
|-----------------|--------------|
| Connector No. | R1 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | - |
| 2 | L/W | - |
| 3 | G | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 16A | O/L | - |
| 21A | R/L | - |
| 94A | W/L | - |
| 95A | L | - |
| 97A | R | - |

| | |
|-----------------|--------------|
| Connector No. | B149 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| | |
|-----------------|------------------------------|
| Connector No. | R103 |
| Connector Name | REAR POWER DROP GLASS SWITCH |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 3 | B | - |
| 5 | L/W | - |

| | |
|-----------------|--------------|
| Connector No. | R101 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | G | - |
| 7 | L/W | - |
| 14 | B | - |

| | |
|-----------------|--------------|
| Connector No. | R6 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6 | G | - |
| 7 | L/W | - |
| 14 | B | - |

ABKIA4095GB


A B C D E F G H I J L M N O P

PWC

POWER WINDOW SYSTEM


< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | D2 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R/B | - |
| 2 | R/Y | - |
| 3 | L | - |
| 4 | R | - |
| 5 | W/R | - |
| 6 | SHIELD | - |
| 8 | LG/W | - |
| 9 | W/L | - |
| 14 | B | - |


| | |
|-----------------|--|
| Connector No. | D7 |
| Connector Name | MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (CREW CAB) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 1 | R/Y | UP (RL) |
| 2 | W/B | ENCODER GND |
| 3 | R/B | DOWN (RL) |
| 4 | L | KEY CYLINDER LOCK |
| 5 | L | DOWN (RR) |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 6 | R | KEY CYLINDER UNLOCK |
| 7 | R | UP (RR) |
| 8 | G/R | UP (DR) |
| 9 | O | LIMIT SW |
| 10 | W/L | IGN |
| 11 | G/W | DN (DR) |
| 12 | - | - |
| 13 | G/Y | ENCODER PULSE |
| 14 | LG/W | COMMUNICATION |
| 15 | BR | ENCODER POWER SUPPLY |
| 16 | - | - |

| | |
|-----------------|--|
| Connector No. | D8 |
| Connector Name | MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (CREW CAB) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 17 | B | GND |
| 18 | - | - |
| 19 | W/R | BAT |

| | |
|-----------------|-----------------------------|
| Connector No. | D9 |
| Connector Name | FRONT POWER WINDOW MOTOR LH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G/W | - |
| 2 | G/R | - |
| 3 | G/Y | - |
| 4 | BR | - |
| 5 | O | - |
| 6 | W/B | - |

| | |
|-----------------|-----------------------------|
| Connector No. | D14 |
| Connector Name | FRONT DOOR LOCK ASSEMBLY LH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | - |
| 5 | B | - |
| 6 | R | - |

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | D101 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/R | - |
| 3 | B | - |
| 6 | SHIELD | - |
| 7 | LG/W | - |

| | |
|-----------------|-----------------------------|
| Connector No. | D104 |
| Connector Name | FRONT POWER WINDOW MOTOR RH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | L | - |
| 3 | G/Y | - |
| 4 | G/R | - |
| 5 | G/W | - |
| 6 | W/B | - |


| | |
|-----------------|---|
| Connector No. | D105 |
| Connector Name | POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 1 | - | - |
| 2 | - | - |
| 3 | W/B | ENCODER GND |
| 4 | G/R | ENCODER POWER SUPPLY |
| 5 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------|
| 6 | - | - |
| 7 | - | - |
| 8 | L | UP |
| 9 | G | DOWN |
| 10 | W/R | BAT |
| 11 | B | GND |
| 12 | G/Y | ENCODER PULSE |
| 13 | - | - |
| 14 | - | - |
| 15 | G/W | LIMIT SW |
| 16 | LG/W | COMMUNICATION |

| | |
|-----------------|--------------|
| Connector No. | D201 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | O/L | - |
| 11 | B | - |
| 16 | W/L | - |
| 17 | R/B | - |
| 18 | R/Y | - |

ABKIA5868GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

| | |
|-----------------|--------------|
| Connector No. | D301 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | O/L | - |
| 11 | B | - |
| 16 | W/L | - |
| 17 | L | - |
| 18 | R | - |

| | |
|-----------------|----------------------------|
| Connector No. | D204 |
| Connector Name | REAR POWER WINDOW MOTOR LH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | L | - |

| | |
|-----------------|-----------------------------|
| Connector No. | D203 |
| Connector Name | REAR POWER WINDOW SWITCH LH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/L | - |
| 2 | R/Y | - |
| 3 | R/B | - |
| 4 | G | - |
| 5 | L | - |
| 6 | O/L | - |
| 7 | B | - |

| | |
|-----------------|----------------------------|
| Connector No. | D304 |
| Connector Name | REAR POWER WINDOW MOTOR RH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y/B | - |
| 2 | BR | - |

| | |
|-----------------|-----------------------------|
| Connector No. | D303 |
| Connector Name | REAR POWER WINDOW SWITCH RH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/L | - |
| 2 | R | - |
| 3 | L | - |
| 4 | Y/B | - |
| 5 | BR | - |
| 6 | O/L | - |
| 7 | B | - |

ABKIA4098GB

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

Diagnosis Procedure

INFOID:000000011560347

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-31, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window switch main power supply and ground circuit.

Refer to [PWC-12, "POWER WINDOW MAIN SWITCH : Component Function Check"](#) (Crew Cab) or [PWC-21, "POWER WINDOW MAIN SWITCH : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace the malfunctioning parts.

3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH SERIAL CIRCUIT

Check main power window and door lock/unlock switch serial circuit.

Refer to [PWC-12, "POWER WINDOW MAIN SWITCH : Component Function Check"](#) (Crew Cab) or [PWC-21, "POWER WINDOW MAIN SWITCH : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace the malfunctioning parts.

4. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.

Refer to [PWC-12, "POWER WINDOW MAIN SWITCH : Component Function Check"](#) (Crew Cab) or [PWC-21, "POWER WINDOW MAIN SWITCH : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011560348

1. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-25, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011560349

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-16, "FRONT POWER WINDOW SWITCH : Component Function Check"](#) (Crew Cab) or [PWC-22, "FRONT POWER WINDOW SWITCH : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

2. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH SERIAL LINK CIRCUIT

Check power window and door lock/unlock switch RH serial link circuit.

Refer to [PWC-56, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace the malfunctioning parts.

3. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-26, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011560350

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH.

Refer to [PWC-18, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-28, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011560351

1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-18, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-29, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000011560352

1. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-32. "DRIVER SIDE : Component Function Check"](#) (Crew Cab) or [PWC-38. "DRIVER SIDE : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:0000000011560353

1. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-34. "PASSENGER SIDE : Component Function Check"](#) (Crew Cab) or [PWC-40. "PASSENGER SIDE : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000011560354

1. RESET LIMIT SWITCH

Refer to [GW-18, "Removal and Installation"](#).

Does automatic function operate normally?

YES >> Inspection End.
NO >> GO TO 2.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-32, "DRIVER SIDE : Component Function Check"](#) (Crew Cab) or [PWC-38, "DRIVER SIDE : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> Inspection End.
NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000011560355

1. RESET LIMIT SWITCH

Refer to [GW-18, "Removal and Installation"](#).

Does automatic function operate normally?

YES >> Inspection End.

NO >> GO TO 2.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-34, "PASSENGER SIDE : Component Function Check"](#) (Crew Cab) or [PWC-40, "PASSENGER SIDE : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000011560356

1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [DLK-26, "KING CAB : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

DOES NOT OPERATE BY KEY CYLINDER SWITCH

< SYMPTOM DIAGNOSIS >

DOES NOT OPERATE BY KEY CYLINDER SWITCH

Diagnosis Procedure

INFOID:000000011560357

1. CHECK FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH)

Check front door lock assembly LH (key cylinder switch).

Refer to [DLK-38. "CREW CAB : Component Function Check"](#) (Crew Cab) or [DLK-36. "KING CAB : Component Function Check"](#) (King Cab).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011560358

1. CHECK KEYFOB FUNCTION

Check keyfob function.

Refer to [BCS-21. "MULTI REMOTE ENT : CONSULT Function \(BCM - MULTI REMOTE ENT\)"](#) with remote keyless entry system.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000011560359

1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-115. "Removal and Installation"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-44. "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR POWER DROP GLASS DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR POWER DROP GLASS DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011560360

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.
Refer to [BCS-31, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2
NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER DROP GLASS SWITCH

Check rear power drop glass switch.
Refer to [PWC-59, "Rear Power Drop Glass Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3
NO >> Repair or replace the malfunctioning parts.

3. CHECK REAR POWER DROP GLASS MOTOR CIRCUIT

Check rear power drop glass motor circuit.
Refer to [PWC-59, "Rear Power Drop Glass Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4
NO >> Repair or replace the malfunctioning parts.

4. CHECK REAR POWER DROP GLASS RELAYS

Check rear power drop glass relays.
Refer to [PWC-60, "Rear Power Drop Glass Down Relay Check"](#) and [PWC-62, "Rear Power Drop Glass Up Relay Check"](#).

Is the inspection result normal?

YES >> Inspection End.
NO >> Check intermittent incident. Refer to [GI-44, "Intermittent Incident"](#).

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011560361

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000011560362

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

PREPARATION

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000011560363

The actual shape of the tools may differ from those illustrated here.

| Tool number (TechMate No.) Tool name | Description |
|--|--------------------------|
| — (J-46534) Trim Tool Set | Removing trim components |



AWJIA0483ZZ

POWER WINDOW MAIN SWITCH

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION


POWER WINDOW MAIN SWITCH

Removal and Installation

INFOID:000000011560364

REMOVAL

1. Remove the power window main switch finisher and power window main switch (2) from the door finisher LH using a suitable tool.
 - Disconnect the power window switch harness connector.
2. Release the tabs using a suitable tool and remove the main power window switch..
○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J

PWC

L
M
N
O
P

FRONT POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

FRONT POWER WINDOW SWITCH


Removal and Installation

INFOID:000000011560365

REMOVAL

1. Remove the front power window switch finisher (2) and front power window switch (1) from the front door finisher RH using a suitable tool.
 - Disconnect the front power window switch harness connector.
2. Release the tabs using a suitable tool (A) and remove the front power window switch.

○: Pawl



ALKIA38512Z

INSTALLATION

Installation is in the reverse order of removal.

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >


REAR POWER WINDOW SWITCH

Removal and Installation - Rear Door Switch

INFOID:0000000011560366

REMOVAL

1. Remove the rear door switch finisher (1) and rear door switch (2) from the rear door finisher using a suitable tool.
 - Disconnect the rear door switch harness connector.
2. Release the tabs using suitable tool (A) and remove the switch (2).



INSTALLATION


Installation is in the reverse order of removal.

Removal and Installation - Power Drop Glass Switch

INFOID:0000000011560367

REMOVAL

1. Release the pawls and remove the overhead console switch finisher (1) from overhead console using a suitable tool (A).
○: Pawl
2. Release the tabs and remove power drop glass switch from the overhead console switch finisher (1) using suitable tool (A).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P