

SECTION FSU

FRONT SUSPENSION

A
B
C
D

FSU

CONTENTS

SERVICE INFORMATION	2	Wheel Alignment Inspection	7
PRECAUTIONS	2	Component	10
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	Removal and Installation	11
Precaution Necessary for Steering Wheel Rotation After Battery Disconnect	2		
Precaution for Procedure without Cowl Top Cover....	3		
General Precautions	3		
PREPARATION	4		
Special Service Tool	4		
Commercial Service Tool	5		
NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING	6		
NVH Troubleshooting Chart	6		
FRONT SUSPENSION ASSEMBLY	7		
On-Vehicle Inspection and Service	7		
COIL SPRING AND STRUT	12		
Removal and Installation	12		
Disposal	12		
Disassembly and Assembly	13		
TRANSVERSE LINK	15		
Removal and Installation	15		
STABILIZER BAR	16		
Removal and Installation	16		
SERVICE DATA AND SPECIFICATIONS (SDS)	17		
Wheel Alignment (Unladen*)	17		
Ball Joint	18		
Wheelarch Height (Unladen*)	19		

F
G
H
I
J
K
L
M
N
O
P

PRECAUTIONS

< SERVICE INFORMATION >

SERVICE INFORMATION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000005397054

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:0000000005397055

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

PRECAUTIONS

< SERVICE INFORMATION >


5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-III.

A

Precaution for Procedure without Cowl Top Cover

INFOID:000000005397056

When performing the procedure after removing cowl top cover, cover the lower end of windshield.



B

C

D

FSU

F

General Precautions

INFOID:000000005397057

- When installing rubber bushings, the final tightening must be carried out under unladen conditions with tires on ground. Oil might shorten the life of rubber bushings. Be sure to wipe off any spilled oil.
- Unladen conditions mean that fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.
- After servicing suspension parts, be sure to check wheel alignment.
- Self-lock nuts are not reusable. Always use new ones when installing.

G

H

I

J

K

L

M

N

O

P

PREPARATION

< SERVICE INFORMATION >






PREPARATION

Special Service Tool

INFOID:0000000005397058

The actual shapes of Kent-Moore tools may differ from those of special tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV991040S0 (—) CCK gauge attachment 1. Plate 2. Guide bolt 3. Nut 4. Spring 5. Center plate 6. KV99104020 Adapter A a: 72 mm (2.83 in) dia. 7. KV99104030 Adapter B b: 65 mm (2.56 in) dia. 8. KV99104040 Adapter C c: 57 mm (2.24 in) dia. 9. KV99104050 Adapter D d: 53.4 mm (2.102 in) dia.	Measuring wheel alignment
ST35652000 (—) Strut attachment	Disassembling and assembling strut
HT72520000 (J-25730-A) Ball joint remover	Removing steering outer socket
— (J-49286-1) Drift and pull gauge	Measuring drift and pull
— (J-44372) Pull gauge	Measuring steering wheel turning force and ball joint swinging force



PREPARATION

< SERVICE INFORMATION >

Commercial Service Tool

INFOID:000000005397059

A

Tool name	Description
Spring compressor	Removing and installing coil spring
Power tool	Removing nuts, bolts and screws

B

C

D

FSU

F

G

H

I

J

K



L

M

N

O

P



NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SERVICE INFORMATION >

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000005397060

Use chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		FSU-10	FSU-13	FSU-10	FSU-10	FSU-19	FSU-10	FSU-17	FSU-16	FAX-5."NVH Troubleshooting Chart"	FSU-6."NVH Troubleshooting Chart"	WT-5."NVH Troubleshooting Chart"	WT-5."NVH Troubleshooting Chart"	FAX-5."NVH Troubleshooting Chart"	BR-5."NVH Troubleshooting Chart"	PS-5."NVH Troubleshooting Chart"
	Possible cause and SUSPECTED PARTS	Improper installation, looseness	Strut deformation, damage or deflection	Bushing or mounting deterioration	Parts interference	Spring fatigue	Suspension looseness	Incorrect wheel alignment	Stabilizer bar fatigue	FRONT AXLE	FRONT SUSPENSION	TIRES	ROAD WHEEL	DRIVE SHAFT	BRAKES	STEERING
Symptom	Noise	x	x	x	x	x	x			x	x	x	x	x	x	x
	Shake	x	x	x	x		x			x	x	x	x	x	x	x
	Vibration	x	x	x	x	x				x	x	x		x		x
	Shimmy	x	x	x	x			x		x	x	x	x	x	x	x
	Shudder	x	x	x						x	x	x	x	x	x	x
	Poor quality ride or handling	x	x	x	x	x		x	x	x	x	x				

x: Applicable

FRONT SUSPENSION ASSEMBLY

< SERVICE INFORMATION >

FRONT SUSPENSION ASSEMBLY

On-Vehicle Inspection and Service

INFOID:0000000005397061

Make sure the mounting conditions (looseness, back lash) of each component and component conditions (wear, damage) are normal.

INSPECTION OF LOWER BALL JOINT END PLAY

1. Set front wheels in a straight-ahead position. Do not depress brake pedal.
2. Place an iron bar or similar tool between transverse link and steering knuckle.
3. Measure axial end play by prying it up and down.

Axial end play : 0 mm (0 in)

CAUTION:

Be careful not to damage ball joint boot. Do not damage the installation position by applying excessive force.

FSU

STRUT INSPECTION

Check for oil leakage, damage and replace as necessary.

Wheel Alignment Inspection

INFOID:0000000005397062

PRELIMINARY INSPECTION

WARNING:

Always adjust the alignment with the vehicle on a flat surface.

NOTE:

If alignment is out of specification, inspect and replace any damaged or worn rear suspension parts before making any adjustments.

1. Check and adjust the wheel alignment with the vehicle under unladen conditions. "Unladen conditions" means that the fuel, coolant, and lubricant are full; and that the spare tire, jack, hand tools and mats are in their designated positions.
2. Check the tires for incorrect air pressure and excessive wear.
3. Check the wheels for run out and damage. Refer to [WT-6, "Inspection"](#).
4. Check the wheel bearing axial end play. Refer to [FAX-6, "On-Vehicle Inspection and Service"](#).
5. Check the shock absorbers for leaks or damage.
6. Check each mounting point of the suspension components for any excessive looseness or damage.
7. Check each link, arm, and the suspension member for any damage.
8. Check the vehicle height. Refer to [FSU-19, "Wheelarch Height \(Unladen*\)"](#).

GENERAL INFORMATION AND RECOMMENDATIONS

1. A Four-Wheel Thrust Alignment should be performed.
 - This type of alignment is recommended for any NISSAN vehicle.
 - The four-wheel "thrust" process helps ensure that the vehicle is properly aligned and the steering wheel is centered.
 - The alignment machine itself should be capable of accepting any NISSAN vehicle.
 - The alignment machine should be checked to ensure that it is level.
2. Make sure the alignment machine is properly calibrated.
 - Your alignment machine should be regularly calibrated in order to give correct information.
 - Check with the manufacturer of your specific alignment machine for their recommended Service/Calibration Schedule.

THE ALIGNMENT PROCESS

IMPORTANT: Use only the alignment specifications listed in this Service Manual. Refer to [FSU-17, "Wheel Alignment \(Unladen*\)"](#).

1. When displaying the alignment settings, many alignment machines use "indicators": (Green/red, plus or minus, Go/No Go). **Do NOT use these indicators.**
 - The alignment specifications programmed into your alignment machine that operate these indicators may not be correct.

FRONT SUSPENSION ASSEMBLY

< SERVICE INFORMATION >

- This may result in an ERROR.
2. Some newer alignment machines are equipped with an optional “Rolling Compensation” method to “compensate” the sensors (alignment targets or head units). **Do NOT use this “Rolling Compensation” method.**
 - Use the “Jacking Compensation” method. After installing the alignment targets or head units, raise the vehicle and rotate the wheels 1/2 turn both ways.
 - See Instructions in the alignment machine you are using for more information.

CAMBER, CASTER AND KINGPIN INCLINATION ANGLES INSPECTION


- Camber, caster, kingpin inclination angles cannot be adjusted.
- Before inspection, mount front wheels onto turning radius gauge. Mount rear wheels onto a stand that has same height so vehicle will remain horizontal.

Using a CCK Gauge

Install the CCK gauge attachment [SST: KV991040S0] with the following procedure on wheel, then measure wheel alignment.

Tool number : KV991040S0 (—)

1. Remove three wheel nuts, and install the guide bolts to hub bolt.
2. Screw the adapter into the plate until it contacts the plate tightly.
3. Screw the center plate into the plate.
4. Insert the plate assembly on the guide bolt. Put the spring in, and then evenly screw the three guide bolt nuts. When fastening the guide nuts, do not completely compress the spring.




5. Place the dent of alignment gauge onto the projection of the center plate and tightly contact them to measure.

Camber, caster, kingpin inclination angles:

Refer to FSU-17, "Wheel Alignment (Unladen*)".

CAUTION:

- If camber, caster, or kingpin inclination angle is outside the specification, check front suspension parts for wear and damage. Replace suspect parts if a malfunction is detected.
- Kingpin inclination angle is reference value, no inspection is required.



TOE-IN INSPECTION

Measure toe-in using the following procedure.

WARNING:


- Always perform the following procedure on a flat surface.
- Make sure that no person is in front of vehicle before pushing it.

1. Bounce the front of vehicle up and down to stabilize the vehicle height (posture).
2. Push vehicle straight ahead about 5 m (16 ft).

FRONT SUSPENSION ASSEMBLY

< SERVICE INFORMATION >

3. Put a mark on base line of the tread (rear side) of both tires at the same height of hub center. These are measuring points.




4. Measure distance (A) from rear side.
5. Push vehicle slowly ahead to rotate wheels 180 degrees (1/2 turn).

CAUTION:

If wheels have rotated more than 180 degrees (1/2 turn), try the above procedure again from the beginning. Never push vehicle backward.

6. Measure distance (B) from front side.



7. Use the formula below to calculate total toe-in.

$$\text{Total toe-in} = A - B$$

For total toe-in specification, refer to [FSU-17, "Wheel Alignment \(Unladen*\)"](#).

- If the total toe-in is outside the specification, adjust toe-in by varying the length of between steering outer socket and inner socket.


FRONT SUSPENSION ASSEMBLY

< SERVICE INFORMATION >

Component

INFOID:000000005397063

SEC. 400•401•406



AWEIA0134GB

- | | | |
|-----------------------------|---------------------------|------------------------------|
| 1. Strut mounting insulator | 2. Strut mounting bearing | 3. Coil spring |
| 4. Bound bumper | 5. Strut | 6. Steering knuckle |
| 7. Stabilizer clamp | 8. Stabilizer bushing | 9. Stabilizer connecting rod |
| 10. Transverse link | 11. Stabilizer bar | 12. Upper link (left) |

FRONT SUSPENSION ASSEMBLY

< SERVICE INFORMATION >


- | | | |
|------------------------|-----------------------------|-----------------|
| 13. Upper link (right) | 14. Front suspension member | 15. Member stay |
| 16. Cap | Front | |

Removal and Installation

INFOID:000000005397064


REMOVAL

1. Separate intermediate shaft from steering gear pinion shaft. Refer to [PS-9, "Removal and Installation"](#).
2. Remove front tires from vehicle using a power tool.
3. Remove wheel sensor from steering knuckle. Refer to [BRC-34](#).
CAUTION:
Do not pull on wheel sensor harness.
4. Remove the nut on the upper side of stabilizer connecting rod (1) with a power tool, and then remove stabilizer connecting rod (1) from strut assembly.



5. Loosen steering outer socket (1) nut.
6. Remove steering outer socket (1) from steering knuckle (2) so as not to damage ball joint boot (3) using Tool.
CAUTION:
Temporarily tighten the nut to prevent damage to threads and to prevent the Tool from suddenly coming off.

Tool number : HT72520000 (J-25730-A)



7. Remove rear torque rod. Refer to [EM-191, "Component"](#).
8. Remove transverse link ball joint nut and bolt. Then, remove transverse link from steering knuckle.
9. Set jack under front suspension member.
10. Remove upper side bolts of upper link.
11. Remove the bolts of member stay, and then remove member stay from vehicle.
12. Gradually lower a jack to remove front suspension assembly.

INSTALLATION

Installation is in the reverse order of removal.

- For tightening torque, refer to [FSU-10, "Component"](#).
- Perform final tightening of each of parts (rubber bushing), under unladen conditions, which were removed when removing front suspension assembly. Check wheel alignment. Refer to [FSU-7, "Wheel Alignment Inspection"](#).
- Check wheel sensor harness for proper connection. Refer to [BRC-34](#).

COIL SPRING AND STRUT

< SERVICE INFORMATION >

COIL SPRING AND STRUT

Removal and Installation

INFOID:0000000005397065


REMOVAL

1. Remove cowl top panel. Refer to [EI-22, "Removal and Installation"](#).
2. Remove front tires using power tool.
3. Remove harness of wheel sensor from strut assembly. Refer to [BRC-34, "Removal and Installation"](#).

CAUTION:

Do not pull on wheel sensor harness.


4. Remove brake hose lock plate. Refer to [BR-12, "Rear Brake Tube and Hose"](#).
5. Remove the nut on the upper side of stabilizer connecting rod using power tool, and then remove stabilizer connecting rod from strut assembly.
6. Remove nuts and bolts, and then remove steering knuckle from strut assembly. Refer to [FSU-10, "Component"](#).
7. Remove the strut mounting insulator bolts, then remove strut assembly.



INSTALLATION

Installation is in the reverse order of removal.

- For tightening torque, refer to [FSU-10, "Component"](#).
- Perform final tightening of bolts and nuts at the strut assembly lower side (rubber bushing) under unladen conditions with tires on level ground. Check wheel alignment. Refer to [FSU-7, "Wheel Alignment Inspection"](#).
- Check wheel sensor harness for proper connection. Refer to [BRC-34](#).
- Attach strut mounting insulator as shown.



Disposal

INFOID:0000000005719809


1. Set strut assembly horizontally with the piston rod fully extended.
2. Drill 2 – 3 mm (0.08 – 0.12 in) hole at the position (●) from top as shown in the figure to release gas gradually.

CAUTION:

- Wear eye protection (safety glasses).
- Wear gloves.
- Be careful with metal chips or oil blown out by the compressed gas.

NOTE:

- Drill vertically in this direction (←).
- Directly to the outer tube avoiding brackets.
- The gas is clear, colorless, odorless, and harmless.



COIL SPRING AND STRUT

< SERVICE INFORMATION >

A : 20 – 30 mm (0.79 – 1.18 in)

3. Position the drilled hole downward and drain oil by moving the piston rod several times.

CAUTION:

Dispose of drained oil according to the law and local regulations.

Disassembly and Assembly

INFOID:000000005397066

DISASSEMBLY

CAUTION:


Do not damage strut piston rod when removing components from strut assembly.

1. Install Tool (A) to strut and secure it in a vise.

Tool number : ST35652000 (—)

CAUTION:

When installing the strut attachment to strut, wrap a shop cloth around strut to protect it from damage.



2. Using a spring compressor (commercial service tool), compress coil spring between strut mounting bearing and spring lower seat (on strut) until coil spring is free.

CAUTION:

Be sure the spring compressor is securely attached to the coil spring before compressing coil spring.

3. Make sure coil spring with spring compressor between strut mounting bearing and spring lower seat (strut) is free. Then remove piston rod lock nut while securing the piston rod tip so that piston rod does not turn.


4. Remove strut mounting insulator, strut mounting bearing, and bound bumper from strut.

5. Remove coil spring with spring compressor, and then gradually release a spring compressor.

CAUTION:

Loosen while making sure coil spring attachment position does not move.

6. Remove the strut attachment from strut.



SEIA0297E

INSPECTION AFTER DISASSEMBLY

Strut Inspection

Check the following:

- Strut for deformation, cracks or damage, and replace it if necessary.
- Piston rod for damage, uneven wear or distortion, and replace it if necessary.
- For oil leakage, and replace it if necessary.

Strut Mounting Insulator and Rubber Parts Inspection

Check strut mounting insulator for cracks and rubber parts for wear. Replace it if malfunction is detected.

Coil Spring Inspection

Check coil spring for cracks, wear or damage, and replace it if necessary.

ASSEMBLY

CAUTION:

Do not damage strut piston rod when installing components to strut.

COIL SPRING AND STRUT


< SERVICE INFORMATION >

1. Install the Tool (A) to strut and secure it in a vise.

Tool number : ST35652000 (-)


CAUTION:

When installing the strut attachment to strut, wrap a shop cloth around strut to protect it from damage.



WEIA0180E

2. Compress coil spring using a spring compressor (commercial service tool), and install it onto strut.



SEIA0297E


CAUTION:

- Face tube side of coil spring downward. Align the lower end to spring lower seat as shown.
- Be sure spring compressor is securely attached to coil spring. Compress coil spring.

3. Apply soapy water to bound bumper. Insert bound bumper into strut mounting insulator.

CAUTION:

Do not use machine oil.



MEIA0016E


4. Attach strut mounting bearing and strut mounting insulator.
 - Installation position of strut mounting insulator as shown.

5. Secure piston rod tip so that piston rod does not turn, then tighten piston rod lock nut to specified torque.

6. Gradually release a spring compressor, and remove coil spring.

CAUTION:
Loosen while making sure coil spring attachment position does not move.

7. Remove the strut attachment from strut.



MEIA0014E

TRANSVERSE LINK

< SERVICE INFORMATION >

TRANSVERSE LINK

Removal and Installation

INFOID:000000005397067


REMOVAL

1. Remove front tires using power tool.
2. Remove transverse link ball joint nut and bolt. Then, remove transverse link from steering knuckle.
3. Remove transverse link nuts and bolts, then remove transverse link from front suspension member.

NOTE:

When removing LH transverse link it may be necessary to lower the suspension member in order to remove bolts to avoid contact with the transaxle.

- a. Set jack under front suspension member.
 - b. Loosen RH upper link bolts, LH upper link bolt (front suspension member side), front suspension member bolts (left/right). Lower the front suspension member in order to remove transverse link bolts.
4. Remove transverse link.



INSPECTION AFTER REMOVAL

Visual Inspection

Check the following:

- Transverse link and bushing for deformation, cracks or damage. Replace it if necessary.
- Ball joint boot for cracks or other damage, and also for grease leakage. Replace it if necessary.

Ball Joint Inspection

Manually move ball stud to confirm it moves smoothly with no binding.

Swing Torque Inspection

NOTE:

Before measurement, move ball stud at least ten times by hand to check for smooth movement.

- Hook Tool at the cutout on ball stud. Confirm spring balance measurement value is within specifications when ball stud begins moving.


Tool number : — (J-44372)

Swing torque

: 0.5 - 4.9 N·m (0.06 - 0.49 kg-m, 5 - 43 in-lb)

Spring balance measurement

: 15.4 - 150.8 N (1.6 - 15.4 kg-f, 3.5 - 40 lb-f)



- If it is outside the specified range, replace transverse link assembly.

Axial End Play Inspection

- Move tip of ball stud in axial direction to check for looseness.

Axial end play : 0 mm (0 in)

- If it is outside the specified range, replace transverse link assembly.

INSTALLATION

Installation is in the reverse order of removal.

- For tightening torque, refer to [FSU-10, "Component"](#).
- Perform final tightening of bolts and at the front suspension member installation position (rubber bushing) under unladen conditions with tires on level ground. Check wheel alignment. Refer to [FSU-7, "Wheel Alignment Inspection"](#).

STABILIZER BAR

< SERVICE INFORMATION >

STABILIZER BAR

Removal and Installation


INFOID:0000000005397068

REMOVAL

1. Separate intermediate shaft from steering gear pinion shaft. Refer to [PS-9, "Removal and Installation"](#) .
2. Remove front tires using power tool.
3. Remove the nut on the lower side of stabilizer connecting rod using power tool, and then remove stabilizer connecting rod from stabilizer bar.
4. If necessary remove stabilize connecting rod upper nut using power tool. Separate stabilizer connecting rod and strut.
5. Loose steering outer socket (1) nut.
6. Remove steering outer socket (1) from steering knuckle (2) so as not to damage ball joint boot (3) using the Tool.

CAUTION:

Temporarily tighten the nut to prevent damage to threads and to prevent the ball joint remover (suitable tool) from suddenly coming off.




Tool number : HT72520000 (J-25730-A)


7. Remove rear torque rod. Refer to [EM-191, "Component"](#) .
8. Set jack under front suspension member.
9. Remove the bolts of member stay, and then remove member stay.
10. Gradually lower front suspension member in order to remove stabilizer bolts.

CAUTION:

Be careful not to lower it too far. (Do not over load the links.)



11. Remove the bolts of stabilizer clamp, and then remove stabilizer clamp and stabilizer bushing.
12. Remove stabilizer bar.



INSPECTION AFTER REMOVAL

Check stabilizer bar, stabilizer connecting rod, stabilizer bushing, and stabilizer clamp for deformation, cracks, and damage. Replace it if necessary.

INSTALLATION

Installation is in the reverse order of removal.

- For tightening torques, refer to [FSU-10, "Component"](#) .

SERVICE DATA AND SPECIFICATIONS (SDS)


< SERVICE INFORMATION >

SERVICE DATA AND SPECIFICATIONS (SDS)

Wheel Alignment (Unladen*)

INFOID:0000000005397069

Market	United States and Canada		
Tire size	P185/65R15, P195/55R16		
Camber Degree minute (Decimal degree)	RH	Minimum	- 0° 55' (- 0.92°)
		Nominal	- 0° 10' (- 0.17°)
		Maximum	0° 35' (0.58°)
	LH	Minimum	- 0° 55' (- 0.92°)
		Nominal	- 0° 10' (- 0.17°)
		Maximum	0° 35' (0.58°)
Caster Degree minute (Decimal degree)	Left or right difference (LH - RH)	Minimum	-0° 33' (-0.55°)
		Nominal	0° 0' (0°)
		Maximum	0° 33' (0.55°)
	RH	Minimum	4° 05' (4.08°)
		Nominal	4° 50' (4.83°)
		Maximum	5° 35' (5.58°)
Kingpin inclination Degree minute (Decimal degree)	LH	Minimum	3° 55' (3.92°)
		Nominal	4° 40' (4.67°)
		Maximum	5° 25' (5.42°)
	Left or right difference (LH - RH)	Minimum	-0° 45' (-0.75°)
		Nominal	-0° 12' (-0.20°)
		Maximum	0° 21' (0.35°)
Total toe-in Distance (mm) Angle (degree minute second)	Minimum	9° 10' (9.17°)	
	Nominal	9° 55' (9.92°)	
	Maximum	10° 40' (10.67°)	




Total toe-in	Distance (A - B)	Minimum	0 mm (0 in)
		Nominal	1 mm (0.04 in)
		Maximum	2 mm (0.08 in)
	Angle (left or right, each side) Degree minute second (Decimal degree)	Minimum	0° 0' 0" (0°)
		Nominal	0° 2' 42" (0.05°)
		Maximum	0° 5' 24" (0.09°)

*: Fuel, engine coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE INFORMATION >

Market	United States and Canada		
Tire size	P185/65R14		
Camber Degree minute (Decimal degree)	RH	Minimum	- 0° 50' (- 0.83°)
		Nominal	- 0° 5' (- 0.08°)
		Maximum	0° 40' (0.67°)
	LH	Minimum	- 0° 50' (- 0.83°)
		Nominal	- 0° 5' (- 0.08°)
		Maximum	0° 40' (0.67°)
Caster Degree minute (Decimal degree)	Left or right difference (LH - RH)	Minimum	-0° 33' (-0.55°)
		Nominal	-0° 0' (-0°)
		Maximum	0° 33' (0.55°)
	RH	Minimum	3° 45' (3.75°)
		Nominal	4° 30' (4.50°)
		Maximum	5° 15' (5.25°)
	LH	Minimum	3° 35' (3.58°)
		Nominal	4° 20' (4.33°)
		Maximum	5° 5' (5.08°)
Kingpin inclination Degree minute (Decimal degree)	Left or right difference (LH - RH)	Minimum	-0° 45' (-0.75°)
		Nominal	-0° 12' (-0.20°)
		Maximum	0° 21' (0.35°)
		Minimum	9° 5' (9.08°)
		Nominal	9° 50' (9.83°)
		Maximum	10° 35' (10.58°)



Total toe-in	Distance (A - B)	Minimum	0 mm (0 in)
		Nominal	1 mm (0.04 in)
		Maximum	2 mm (0.08 in)
	Angle (left or right, each side) Degree minute (Decimal degree)	Minimum	0° 0' 0" (0°)
		Nominal	0° 2' 42" (0.05°)
		Maximum	0° 5' 24" (0.09°)

*: Fuel, engine coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

Ball Joint

INFOID:0000000005397070


Swing torque	0.5 - 4.9 N·m (0.06 - 0.49 kg-m, 5 - 43 in-lb)
Measurement on spring balance	15.4 - 150.8 N (1.6 - 15.4 kg-f, 3.5 - 40 lb-f)
Axial end play	0 mm (0 in)

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE INFORMATION >

Wheelarch Height (Unladen*)

INFOID:000000005397071



LEIA0085E

Tire size	P185/65R14	P185/65R15		P195/55R16
Market	United States and Canada	United States	Canada	United States
Front (H_f)	677 (26.65)	685 mm (26.97 in)	685 (26.97)	686 (27.01)
Rear (H_r)	681 (26.81)	682 mm (26.85 in)	683 (26.89)	683 (26.89)

*: Fuel, engine coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

A

B

C

D

FSU

F

G

H

I

J

K

L

M

N

O

P