

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SECTION EC

ENGINE CONTROL SYSTEM

CONTENTS

HR16DE

| | | |
|--|----|--|
| PRECAUTION | | |
| PRECAUTIONS | | |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 8 | |
| Precaution for Procedure without Cowl Top Cover..... | 8 | |
| On Board Diagnostic (OBD) System of Engine and CVT | 8 | |
| General Precautions | 9 | |
| PREPARATION | 12 | |
| PREPARATION | 12 | |
| Special Service Tools | 12 | |
| Commercial Service Tools | 12 | |
| SYSTEM DESCRIPTION | 14 | |
| COMPONENT PARTS | 14 | |
| ENGINE CONTROL SYSTEM | 14 | |
| ENGINE CONTROL SYSTEM : | | |
| Component Parts Location | 14 | |
| ENGINE CONTROL SYSTEM : Component Description | 17 | |
| Accelerator Pedal Position Sensor | 18 | |
| Air Fuel Ratio Sensor 1 | 19 | |
| Air Fuel Ratio Sensor 1 Heater | 19 | |
| Camshaft Position Sensor | 19 | |
| Clutch Pedal Position Switch | 20 | |
| Cooling Fan | 20 | |
| Crankshaft Position Sensor | 20 | |
| ECM | 20 | |
| Electric Throttle Control Actuator | 21 | |
| Engine Coolant Temperature Sensor | 21 | |
| Engine Oil Pressure Sensor | 21 | |
| Engine Oil Temperature Sensor | 21 | |
| EVAP Canister Purge Volume Control Solenoid Valve | 22 | |
| EVAP Canister Vent Control Valve | 22 | |
| EVAP Control System Pressure Sensor | 22 | |
| Exhaust Valve Timing Control Solenoid Valve | 23 | |
| Fuel Injector | 23 | |
| Fuel Pump | 23 | |
| Heated Oxygen Sensor 2 | 24 | |
| Heated Oxygen Sensor 2 Heater | 24 | |
| Ignition Coil With Power Transistor | 24 | |
| Intake Air Temperature Sensor | 24 | |
| Intake Valve Timing Control Solenoid Valve | 25 | |
| Knock Sensor | 25 | |
| Battery Current Sensor (With Battery Temperature Sensor) | 25 | |
| Malfunction Indicator Lamp (MIL) | 26 | |
| Mass Air Flow Sensor | 26 | |
| Oil Pressure Warning Lamp | 26 | |
| Refrigerant Pressure Sensor | 27 | |
| Stop Lamp Switch & ASCD Brake Switch | 27 | |
| Throttle Control Motor | 27 | |
| Throttle Control Motor Relay | 27 | |
| Throttle Position Sensor | 27 | |
| ASCD Steering Switch | 27 | |
| STRUCTURE AND OPERATION | 28 | |
| Positive Crankcase Ventilation | 28 | |
| On Board Refueling Vapor Recovery (ORVR) | 29 | |
| SYSTEM | 30 | |
| ENGINE CONTROL SYSTEM | 30 | |
| ENGINE CONTROL SYSTEM : System Diagram..... | 30 | |
| ENGINE CONTROL SYSTEM : System Description | 31 | |
| MULTIPOINT FUEL INJECTION SYSTEM | 31 | |
| MULTIPOINT FUEL INJECTION SYSTEM : | | |
| System Diagram | 32 | |
| MULTIPOINT FUEL INJECTION SYSTEM : System Description | 32 | |
| ELECTRIC IGNITION SYSTEM | 35 | |

| | | |
|--|--|------------|
| ELECTRIC IGNITION SYSTEM : | GST (Generic Scan Tool) | 49 |
| System Diagram | DIAGNOSIS SYSTEM (ECM) | 50 |
| ELECTRIC IGNITION SYSTEM : System De- scription | DIAGNOSIS DESCRIPTION | 50 |
| | DIAGNOSIS DESCRIPTION : 1st Trip Detection Logic and Two Trip Detection Logic | 50 |
| AIR CONDITIONING CUT CONTROL | DIAGNOSIS DESCRIPTION : DTC and Freeze Frame Data | 50 |
| AIR CONDITIONING CUT CONTROL : System Diagram | DIAGNOSIS DESCRIPTION : Counter System | 51 |
| AIR CONDITIONING CUT CONTROL : System Description | DIAGNOSIS DESCRIPTION : Driving Pattern | 54 |
| | DIAGNOSIS DESCRIPTION : System Readiness Test (SRT) Code | 55 |
| CAN COMMUNICATION | DIAGNOSIS DESCRIPTION : Permanent Diag- nostic Trouble Code (Permanent DTC) | 56 |
| CAN COMMUNICATION : System Description | DIAGNOSIS DESCRIPTION : Malfunction Indica- tor Lamp (MIL) | 57 |
| | On Board Diagnosis Function | 57 |
| COOLING FAN CONTROL | CONSULT Function | 60 |
| COOLING FAN CONTROL : System Diagram | ECU DIAGNOSIS INFORMATION | 70 |
| COOLING FAN CONTROL : System Description... | ECM | 70 |
| | Reference Value | 70 |
| EVAPORATIVE EMISSION SYSTEM | Fail Safe | 82 |
| EVAPORATIVE EMISSION SYSTEM : System Diagram | DTC Inspection Priority Chart | 84 |
| EVAPORATIVE EMISSION SYSTEM : System Description | DTC Index | 86 |
| | Test Value and Test Limit | 89 |
| INTAKE VALVE TIMING CONTROL | WIRING DIAGRAM | 97 |
| INTAKE VALVE TIMING CONTROL : System Di- agram | ENGINE CONTROL SYSTEM | 97 |
| INTAKE VALVE TIMING CONTROL : System De- scription | Wiring Diagram | 97 |
| | BASIC INSPECTION | 118 |
| EXHAUST VALVE TIMING CONTROL | DIAGNOSIS AND REPAIR WORKFLOW | 118 |
| EXHAUST VALVE TIMING CONTROL : System Diagram | Work Flow | 118 |
| EXHAUST VALVE TIMING CONTROL : System Description | Diagnostic Work Sheet | 121 |
| | ADDITIONAL SERVICE WHEN REPLACING | |
| ENGINE PROTECTION CONTROL AT LOW EN- GINE OIL PRESSURE | ECM | 123 |
| ENGINE PROTECTION CONTROL AT LOW EN- GINE OIL PRESSURE : System Diagram | Description | 123 |
| ENGINE PROTECTION CONTROL AT LOW EN- GINE OIL PRESSURE : System Description | Work Procedure | 123 |
| | VIN REGISTRATION | 125 |
| FUEL FILLER CAP WARNING SYSTEM | Description | 125 |
| FUEL FILLER CAP WARNING SYSTEM : | Work Procedure | 125 |
| System Diagram | ACCELERATOR PEDAL RELEASED POSI- TION LEARNING | 126 |
| FUEL FILLER CAP WARNING SYSTEM : System Description | Description | 126 |
| | Work Procedure | 126 |
| AUTOMATIC SPEED CONTROL DEVICE (ASCD).. | THROTTLE VALVE CLOSED POSITION LEARNING | 127 |
| AUTOMATIC SPEED CONTROL DEVICE (AS- CD) : System Diagram | Description | 127 |
| AUTOMATIC SPEED CONTROL DEVICE (AS- CD) : System Description | Work Procedure | 127 |
| | IDLE AIR VOLUME LEARNING | 128 |
| OPERATION | Description | 128 |
| AUTOMATIC SPEED CONTROL DEVICE (ASCD).. | Work Procedure | 128 |
| AUTOMATIC SPEED CONTROL DEVICE (AS- CD) : Switch Name and Function | | |
| | | |
| ON BOARD DIAGNOSTIC (OBD) SYSTEM | | |
| Diagnosis Description | | |

| | | | | |
|--|------------|--|------------|----|
| MIXTURE RATIO SELF-LEARNING VALUE CLEAR | 130 | Diagnosis Procedure | 171 | |
| Description | 130 | Component Inspection | 172 | A |
| Work Procedure | 130 | | | |
| BASIC INSPECTION | 131 | P0037, P0038 HO2S2 HEATER | 174 | |
| Work Procedure | 131 | DTC Logic | 174 | EC |
| | | Diagnosis Procedure | 174 | |
| | | Component Inspection | 175 | |
| FUEL PRESSURE CHECK | 135 | P0075 IVT CONTROL SOLENOID VALVE | 177 | C |
| Work Procedure | 135 | DTC Logic | 177 | |
| | | Diagnosis Procedure | 177 | |
| | | Component Inspection | 178 | D |
| HOW TO SET SRT CODE | 137 | P0078 EVT CONTROL SOLENOID VALVE ... | 179 | |
| Description | 137 | DTC Logic | 179 | E |
| SRT Set Driving Pattern | 138 | Diagnosis Procedure | 179 | |
| Work Procedure | 140 | Component Inspection | 180 | |
| HOW TO ERASE PERMANENT DTC | 143 | P0101 MAF SENSOR | 182 | F |
| Description | 143 | DTC Logic | 182 | |
| Work Procedure (Group A) | 144 | Diagnosis Procedure | 182 | |
| Work Procedure (Group B) | 146 | Component Inspection | 184 | G |
| DTC/CIRCUIT DIAGNOSIS | 149 | P0102, P0103 MAF SENSOR | 187 | |
| | | DTC Logic | 187 | H |
| TROUBLE DIAGNOSIS - SPECIFICATION VALUE | 149 | Diagnosis Procedure | 187 | |
| Description | 149 | Component Inspection | 189 | |
| Component Function Check | 149 | | | |
| Diagnosis Procedure | 150 | P0111 IAT SENSOR | 192 | I |
| POWER SUPPLY AND GROUND CIRCUIT ... | 157 | DTC Logic | 192 | |
| Diagnosis Procedure | 157 | Component Function Check | 193 | J |
| | | Diagnosis Procedure | 193 | |
| U0101 CAN COMM CIRCUIT | 160 | Component Inspection | 193 | |
| Description | 160 | P0112, P0113 IAT SENSOR | 194 | K |
| DTC Logic | 160 | DTC Logic | 194 | |
| Diagnosis Procedure | 160 | Diagnosis Procedure | 194 | |
| | | Component Inspection | 195 | |
| U0284 ACTIVE GRILLE SHUTTER | 161 | P0116 ECT SENSOR | 196 | L |
| DTC Logic | 161 | DTC Logic | 196 | |
| Diagnosis Procedure | 161 | Component Function Check | 197 | M |
| | | Diagnosis Procedure | 197 | |
| U1001 CAN COMM CIRCUIT | 162 | Component Inspection | 197 | |
| Description | 162 | P0117, P0118 ECT SENSOR | 198 | N |
| DTC Logic | 162 | DTC Logic | 198 | |
| Diagnosis Procedure | 162 | Diagnosis Procedure | 198 | |
| | | Component Inspection | 199 | |
| U1040 ENG COMM CIRCUIT | 163 | P0122, P0123 TP SENSOR | 200 | O |
| DTC Logic | 163 | DTC Logic | 200 | |
| Diagnosis Procedure | 163 | Diagnosis Procedure | 200 | |
| | | Component Inspection | 201 | P |
| P0011 IVT CONTROL | 164 | P0125 ECT SENSOR | 203 | |
| DTC Logic | 164 | DTC Logic | 203 | |
| Diagnosis Procedure | 165 | Diagnosis Procedure | 203 | |
| Component Inspection | 166 | Component Inspection | 204 | |
| P0014 EVT CONTROL | 168 | P0127 IAT SENSOR | 205 | |
| DTC Logic | 168 | DTC Logic | 205 | |
| Diagnosis Procedure | 169 | | | |
| Component Inspection | 170 | | | |
| P0031, P0032 A/F SENSOR 1 HEATER | 171 | | | |
| DTC Logic | 171 | | | |

| | | | |
|---|------------|---|------------|
| Diagnosis Procedure | 205 | DTC Logic | 257 |
| Component Inspection | 206 | Diagnosis Procedure | 257 |
| P0128 THERMOSTAT FUNCTION | 207 | Component Inspection | 258 |
| DTC Logic | 207 | P0196 EOT SENSOR | 259 |
| Diagnosis Procedure | 208 | DTC Logic | 259 |
| Component Inspection | 209 | Component Function Check | 261 |
| P0130 A/F SENSOR 1 | 210 | Diagnosis Procedure | 261 |
| DTC Logic | 210 | Component Inspection | 261 |
| Component Function Check | 211 | P0197, P0198 EOT SENSOR | 262 |
| Diagnosis Procedure | 211 | DTC Logic | 262 |
| P0131 A/F SENSOR 1 | 214 | Diagnosis Procedure | 262 |
| DTC Logic | 214 | Component Inspection | 263 |
| Diagnosis Procedure | 215 | P0222, P0223 TP SENSOR | 264 |
| P0132 A/F SENSOR 1 | 217 | DTC Logic | 264 |
| DTC Logic | 217 | Diagnosis Procedure | 264 |
| Diagnosis Procedure | 218 | Component Inspection | 265 |
| P0137 HO2S2 | 220 | P0300, P0301, P0302, P0303, P0304 MIS- FIRE | 267 |
| DTC Logic | 220 | DTC Logic | 267 |
| Component Function Check | 221 | Diagnosis Procedure | 268 |
| Diagnosis Procedure | 222 | P0327, P0328 KS | 273 |
| Component Inspection | 223 | DTC Logic | 273 |
| P0138 HO2S2 | 226 | Diagnosis Procedure | 273 |
| DTC Logic | 226 | Component Inspection | 274 |
| Component Function Check | 227 | P0335 CKP SENSOR (POS) | 275 |
| Diagnosis Procedure | 228 | DTC Logic | 275 |
| Component Inspection | 231 | Diagnosis Procedure | 275 |
| P0139 HO2S2 | 234 | Component Inspection | 277 |
| DTC Logic | 234 | P0340 CMP SENSOR (PHASE) | 279 |
| Component Function Check | 235 | DTC Logic | 279 |
| Diagnosis Procedure | 236 | Diagnosis Procedure | 279 |
| Component Inspection | 237 | Component Inspection | 281 |
| P014C, P014D, P015A, P015B, A/F SENSOR 1 | 240 | P0420 THREE WAY CATALYST FUNCTION.. | 282 |
| DTC Logic | 240 | DTC Logic | 282 |
| Diagnosis Procedure | 242 | Component Function Check | 283 |
| P0171 FUEL INJECTION SYSTEM FUNC- TION | 245 | Diagnosis Procedure | 284 |
| DTC Logic | 245 | P0441 EVAP CONTROL SYSTEM | 287 |
| Diagnosis Procedure | 246 | DTC Logic | 287 |
| P0172 FUEL INJECTION SYSTEM FUNC- TION | 249 | Component Function Check | 288 |
| DTC Logic | 249 | Diagnosis Procedure | 289 |
| Diagnosis Procedure | 250 | P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | 292 |
| P0181 FTT SENSOR | 253 | DTC Logic | 292 |
| DTC Logic | 253 | Diagnosis Procedure | 293 |
| Component Function Check | 254 | Component Inspection | 295 |
| Diagnosis Procedure | 255 | P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE | 297 |
| Component Inspection | 256 | DTC Logic | 297 |
| P0182, P0183 FTT SENSOR | 257 | Diagnosis Procedure | 297 |
| | | Component Inspection | 298 |

| | | | | | | |
|---|------------|--|------------|--|------------|----|
| P0447 EVAP CANISTER VENT CONTROL VALVE | 300 | DTC Logic | 300 | DTC Logic | 332 | A |
| DTC Logic | 300 | Diagnosis Procedure | 300 | Diagnosis Procedure | 332 | |
| Diagnosis Procedure | 300 | | | | | |
| Component Inspection | 301 | | | | | |
| P0448 EVAP CANISTER VENT CONTROL VALVE | 304 | P050A, P050B, P050E COLD START CONTROL | 334 | Description | 334 | EC |
| DTC Logic | 304 | DTC Logic | 334 | DTC Logic | 334 | |
| Diagnosis Procedure | 304 | Diagnosis Procedure | 335 | Diagnosis Procedure | 335 | C |
| Component Inspection | 306 | | | Component Inspection | 337 | |
| P0451 EVAP CONTROL SYSTEM PRES-SURE SENSOR | 308 | P0520 EOP SENSOR | 336 | DTC Logic | 336 | D |
| DTC Logic | 308 | DTC Logic | 336 | Diagnosis Procedure | 336 | |
| Diagnosis Procedure | 309 | Diagnosis Procedure | 336 | Component Inspection | 337 | |
| Component Inspection | 310 | | | | | |
| P0452 EVAP CONTROL SYSTEM PRES-SURE SENSOR | 312 | P0524 ENGINE OIL PRESSURE | 338 | DTC Logic | 338 | E |
| DTC Logic | 312 | DTC Logic | 338 | Diagnosis Procedure | 339 | |
| Diagnosis Procedure | 312 | Diagnosis Procedure | 339 | Component Inspection | 340 | |
| Component Inspection | 314 | | | | | |
| P0453 EVAP CONTROL SYSTEM PRES-SURE SENSOR | 315 | P059F ACTIVE GRILLE SHUTTER | 341 | DTC Logic | 341 | F |
| DTC Logic | 315 | DTC Logic | 341 | Diagnosis Procedure | 343 | |
| Diagnosis Procedure | 315 | Diagnosis Procedure | 343 | Component Inspection (Active Grille Shutter) | 345 | G |
| Component Inspection | 318 | Component Inspection (Active Grille Shutter Relay) | 346 | Component Inspection (Active Grille Shutter Relay) | 346 | |
| P0456 EVAP CONTROL SYSTEM | 319 | | | | | H |
| DTC Logic | 319 | P0603 ECM POWER SUPPLY | 347 | Description | 347 | |
| Diagnosis Procedure | 320 | Description | 347 | DTC Logic | 347 | I |
| Component Inspection | 324 | DTC Logic | 347 | Diagnosis Procedure | 347 | |
| P0460 FUEL LEVEL SENSOR | 325 | Diagnosis Procedure | 347 | | | |
| DTC Logic | 325 | P0605 ECM | 349 | P0607 ECM | 351 | K |
| Diagnosis Procedure | 325 | DTC Logic | 349 | DTC Logic | 351 | |
| | | Diagnosis Procedure | 349 | Diagnosis Procedure | 351 | |
| P0461 FUEL LEVEL SENSOR | 326 | | | P0643 SENSOR POWER SUPPLY | 352 | L |
| DTC Logic | 326 | P0607 ECM | 351 | DTC Logic | 352 | |
| Component Function Check | 326 | DTC Logic | 351 | Diagnosis Procedure | 352 | |
| Diagnosis Procedure | 327 | Diagnosis Procedure | 351 | | | |
| P0462, P0463 FUEL LEVEL SENSOR | 328 | | | P0850 PNP SWITCH | 354 | M |
| DTC Logic | 328 | Description | 354 | Description | 354 | |
| Diagnosis Procedure | 328 | DTC Logic | 354 | DTC Logic | 354 | |
| | | Component Function Check | 355 | Component Function Check | 355 | N |
| P0500 VSS | 329 | Diagnosis Procedure | 355 | Diagnosis Procedure | 355 | |
| Description | 329 | | | P1078 EVT CONTROL POSITION SENSOR | 357 | O |
| DTC Logic | 329 | P1078 EVT CONTROL POSITION SENSOR | 357 | DTC Logic | 357 | |
| Component Function Check | 330 | DTC Logic | 357 | Diagnosis Procedure | 357 | |
| Diagnosis Procedure | 330 | Diagnosis Procedure | 357 | Component Inspection | 359 | |
| P0506 ISC SYSTEM | 331 | Component Inspection | 359 | | | P |
| Description | 331 | P1148 CLOSED LOOP CONTROL | 360 | P1148 CLOSED LOOP CONTROL | 360 | |
| DTC Logic | 331 | DTC Logic | 360 | DTC Logic | 360 | |
| Diagnosis Procedure | 331 | Diagnosis Procedure | 360 | Diagnosis Procedure | 360 | |
| P0507 ISC SYSTEM | 332 | | | P117A AIR FUEL RATIO | 361 | |
| Description | 332 | P117A AIR FUEL RATIO | 361 | DTC Logic | 361 | |
| | | DTC Logic | 361 | Diagnosis Procedure | 362 | |
| | | Diagnosis Procedure | 362 | | | |

| | | | |
|--|------------|--|------------|
| P1212 TCS COMMUNICATION LINE | 366 | Description | 393 |
| Description | 366 | DTC Logic | 393 |
| DTC Logic | 366 | Diagnosis Procedure | 393 |
| Diagnosis Procedure | 366 | | |
| P1217 ENGINE OVER TEMPERATURE | 367 | P1805 BRAKE SWITCH | 395 |
| DTC Logic | 367 | DTC Logic | 395 |
| Component Function Check | 367 | Diagnosis Procedure | 395 |
| Diagnosis Procedure | 368 | Component Inspection | 396 |
| P1225 TP SENSOR | 370 | P2096, P2097 A/F SENSOR 1 | 397 |
| DTC Logic | 370 | DTC Logic | 397 |
| Diagnosis Procedure | 370 | Diagnosis Procedure | 397 |
| P1226 TP SENSOR | 371 | P2100, P2103 THROTTLE CONTROL MO- | |
| DTC Logic | 371 | TOR RELAY | 401 |
| Diagnosis Procedure | 371 | DTC Logic | 401 |
| | | Diagnosis Procedure | 401 |
| P1550 BATTERY CURRENT SENSOR | 372 | P2101 ELECTRIC THROTTLE CONTROL | |
| DTC Logic | 372 | FUNCTION | 404 |
| Diagnosis Procedure | 372 | DTC Logic | 404 |
| Component Inspection | 373 | Diagnosis Procedure | 404 |
| | | Component Inspection | 407 |
| P1551, P1552 BATTERY CURRENT SEN- | | P2118 THROTTLE CONTROL MOTOR | 408 |
| SOR | 374 | DTC Logic | 408 |
| DTC Logic | 374 | Diagnosis Procedure | 408 |
| Diagnosis Procedure | 374 | Component Inspection | 409 |
| Component Inspection | 375 | | |
| P1553 BATTERY CURRENT SENSOR | 376 | P2119 ELECTRIC THROTTLE CONTROL | |
| DTC Logic | 376 | ACTUATOR | 410 |
| Diagnosis Procedure | 376 | DTC Logic | 410 |
| Component Inspection | 377 | Diagnosis Procedure | 410 |
| P1554 BATTERY CURRENT SENSOR | 378 | P2122, P2123 APP SENSOR | 412 |
| DTC Logic | 378 | DTC Logic | 412 |
| Component Function Check | 378 | Diagnosis Procedure | 412 |
| Diagnosis Procedure | 379 | Component Inspection | 413 |
| Component Inspection | 380 | | |
| P1564 ASCD STEERING SWITCH | 381 | P2127, P2128 APP SENSOR | 415 |
| DTC Logic | 381 | DTC Logic | 415 |
| Diagnosis Procedure | 381 | Diagnosis Procedure | 415 |
| Component Inspection | 383 | Component Inspection | 417 |
| P1572 ASCD BRAKE SWITCH | 384 | P2135 TP SENSOR | 418 |
| DTC Logic | 384 | DTC Logic | 418 |
| Diagnosis Procedure | 385 | Diagnosis Procedure | 418 |
| Component Inspection (ASCD Brake Switch) | 387 | Component Inspection | 419 |
| Component Inspection (Stop Lamp Switch) | 387 | | |
| P1574 ASCD VEHICLE SPEED SENSOR | 389 | P2138 APP SENSOR | 421 |
| Description | 389 | DTC Logic | 421 |
| DTC Logic | 389 | Diagnosis Procedure | 421 |
| Diagnosis Procedure | 389 | Component Inspection | 423 |
| P1715 INPUT SPEED SENSOR | 391 | ASCD BRAKE SWITCH | 425 |
| Description | 391 | Component Function Check | 425 |
| DTC Logic | 391 | Diagnosis Procedure | 425 |
| Diagnosis Procedure | 391 | Component Inspection (ASCD Brake Switch) | 426 |
| P1720 VSS | 393 | CLUTCH PEDAL POSITION SWITCH | 427 |
| | | Component Function Check | 427 |

| | | | | |
|--|------------|--|------------|-----------|
| Diagnosis Procedure | 427 | REFRIGERANT PRESSURE SENSOR | 450 | A |
| Component Inspection (Clutch Pedal Position Switch) | 428 | Component Function Check | 450 | |
| COOLING FAN | 429 | Diagnosis Procedure | 450 | |
| Component Function Check | 429 | SYMPTOM DIAGNOSIS | 452 | EC |
| Diagnosis Procedure | 429 | ENGINE CONTROL SYSTEM SYMPTOMS ... | 452 | |
| Component Inspection (Cooling Fan Motor) | 431 | Symptom Table | 452 | C |
| Component Inspection (Cooling Fan Relay) | 431 | NORMAL OPERATING CONDITION | 458 | |
| ELECTRICAL LOAD SIGNAL | 432 | Description | 458 | D |
| Description | 432 | PERIODIC MAINTENANCE | 459 | |
| Component Function Check | 432 | IDLE SPEED | 459 | E |
| Diagnosis Procedure | 432 | Inspection | 459 | |
| Diagnosis Procedure | 432 | IGNITION TIMING | 460 | F |
| Component Inspection | 435 | Inspection | 460 | |
| FUEL INJECTOR | 434 | EVAPORATIVE EMISSION SYSTEM | 461 | G |
| Component Function Check | 434 | Inspection | 461 | |
| Diagnosis Procedure | 434 | EVAP LEAK CHECK | 462 | H |
| Component Inspection | 435 | Inspection | 462 | |
| FUEL PUMP | 436 | POSITIVE CRANKCASE VENTILATION | 464 | I |
| Component Function Check | 436 | Inspection | 464 | |
| Diagnosis Procedure | 436 | REMOVAL AND INSTALLATION | 465 | J |
| Component Inspection | 438 | ECM | 465 | |
| IGNITION SIGNAL | 439 | Exploded View | 465 | K |
| Component Function Check | 439 | Removal and Installation | 465 | |
| Diagnosis Procedure | 439 | SERVICE DATA AND SPECIFICATIONS (SDS) | 466 | L |
| Component Inspection (Ignition Coil with Power Transistor) | 442 | SERVICE DATA AND SPECIFICATIONS (SDS) | 466 | |
| Component Inspection (Condenser) | 443 | Idle Speed | 466 | M |
| MALFUNCTION INDICATOR LAMP | 444 | Ignition Timing | 466 | |
| Component Function Check | 444 | Calculated Load Value | 466 | N |
| Diagnosis Procedure | 444 | Mass Air Flow Sensor | 466 | |
| ON BOARD REFUELING VAPOR RECOVERY (ORVR) | 445 | | | P |
| Component Function Check | 445 | | | |
| Diagnosis Procedure | 445 | | | |
| Component Inspection (Refueling EVAP vapor cut valve) | 447 | | | |
| Component Inspection (Drain filter) | 449 | | | |

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009760534

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000009020566

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



On Board Diagnostic (OBD) System of Engine and CVT

INFOID:000000009020567

The ECM has an on board diagnostic system. It will light up the malfunction indicator (MI) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the negative battery cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-53, "Description"](#).

PRECAUTIONS

[HR16DE]


< PRECAUTION >

- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MI to light up due to the malfunction of the fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission control module) before returning the vehicle to the customer.


General Precautions

INFOID:000000009020568


- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned OFF.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.



- Do not disassemble ECM.
- If a battery cable is disconnected, the memory will return to the ECM value.
The ECM will now start to self-control at its initial value. So, engine operation can vary slightly in this case. However, this is not an indication of a malfunction. Do not replace parts because of a slight variation.
- If the battery is disconnected, the following emission-related diagnostic information will be lost within 24 hours.
 - Diagnostic trouble codes
 - 1st trip diagnostic trouble codes
 - Freeze frame data
 - 1st trip freeze frame data
 - System readiness test (SRT) codes
 - Test values



- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.




PRECAUTIONS


[HR16DE]

< PRECAUTION >


- Before replacing ECM, perform ECM Terminals and Reference Value inspection and make sure ECM functions properly. Refer to **EC-70, "Reference Value"**.
- Handle mass air flow sensor carefully to avoid damage.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious incidents.
- Do not shock or jar the camshaft position sensor (PHASE), crankshaft position sensor (POS).



- After performing each TROUBLE DIAGNOSIS, perform DTC CONFIRMATION PROCEDURE or Component Function Check. The DTC should not be displayed in the DTC Confirmation Procedure if the repair is completed. The Component Function Check should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.



- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.

PRECAUTIONS


[HR16DE]

< PRECAUTION >

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
 - Keep the antenna as far as possible from the electronic control units.
 - Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - Be sure to ground the radio to vehicle body.



A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

PREPARATION

< PREPARATION >

[HR16DE]

PREPARATION





PREPARATION

Special Service Tools

INFOID:000000009020569

NOTE:

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|--|--|
| (J-44321) Fuel pressure gauge kit  <p style="text-align: center;">LEC642</p> | Checks fuel pressure |
| (J-44321-6) Fuel pressure adapter  <p style="text-align: center;">LBIA0376E</p> | Connects fuel pressure gauge to quick connector type fuel lines. |
| KV10118400 Fuel tube adapter  <p style="text-align: center;">PBIB3043E</p> | Measuring fuel pressure |
| KV10120000 Fuel tube adapter  <p style="text-align: center;">JSBIA0410ZZ</p> | |

Commercial Service Tools


INFOID:000000009020570

PREPARATION


< PREPARATION >

[HR16DE]

| Tool name (Kent-Moore No.) | Description | |
|---|---|--------------|
| Leak detector i.e.: (J-41416) | Locates the EVAP leak | A EC C |
| EVAP service port adapter i.e.: (J-41413-OBD) | Applies positive pressure through EVAP service port | D E |
| Fuel filler cap adapter i.e.: (MLR-8382) | Checks fuel tank vacuum relief valve opening pressure | F G H |
| Socket wrench | Removes and installs engine coolant temperature sensor | I J |
| Oxygen sensor thread cleaner i.e.: (J-43897-18), (J-43897-12) | Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below. a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor | K L M |
| Anti-seize lubricant i.e.: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907) | Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads. | N O P |




S-NT703




S-NT704



S-NT815



S-NT705



AEM488



S-NT779

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HR16DE]


SYSTEM DESCRIPTION

COMPONENT PARTS

ENGINE CONTROL SYSTEM

ENGINE CONTROL SYSTEM : Component Parts Location

INFOID:000000009020571




ALBIA1071ZZ

- | | | |
|---|--|--|
| 1. Battery current sensor | 2. ECM | 3. IPDM E/R Refer to PCS-5, "Component Parts Location" (with I-Key), PCS-34, "Component Parts Location" (without I-Key) |
| 4. Mass air flow sensor (with intake air temperature sensor) | 5. Electric throttle control actuator (with built in throttle position sensor and throttle control motor) | 6. EVAP canister purge volume control solenoid valve |
| 7. Cooling fan motor | 8. Refrigerant pressure sensor Refer to HA-11, "Component Parts Location" | |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HR16DE]




- | | | |
|--|--|--|
| 1. Ignition coil No.4 (with power transistor) | 2. Ignition coil No.3 (with power transistor) | 3. Ignition coil No.2 (with power transistor) |
| 4. Ignition coil No.1 (with power transistor) | 5. PCV valve | 6. Intake valve timing control solenoid valve |
| 7. Engine oil pressure sensor | 8. Engine oil temperature sensor | 9. Knock sensor |
| 10. Engine coolant temperature sensor | 11. Camshaft position sensor | 12. Exhaust valve timing control position sensor |
| 13. Exhaust valve timing control solenoid valve | 14. Fuel injector No.1 (Front) | 15. Fuel injector No.1 (Rear) |
| 16. Fuel injector No.2 (Front) | 17. Fuel injector No.2 (Rear) | 18. Fuel injector No.3 (Front) |
| 19. Fuel injector No.3 (Rear) | 20. Fuel injector No.4 (Front) | 21. Fuel injector No.4 (Rear) |
| 22. Crankshaft position sensor | | |
| A. Engine front right side | B. Left view of the engine | C. Engine rear right side |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HR16DE]



JSBIA0565ZZ


1. A/F sensor 1

2. Heated oxygen sensor 2

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HR16DE]



- | | | |
|-------------------------------------|--|---|
| 1. ASCD steering switch | 2. Active grille shutter | 3. Fuel level sensor unit and fuel pump |
| 4. Fuel tank temperature sensor | 5. EVAP control system pressure sensor | 6. EVAP canister |
| 7. EVAP canister vent control valve | 8. ASCD brake switch | 9. Stop lamp switch |
| 10. Clutch pedal position switch | 11. Accelerator pedal position sensor | |
| A. Fuel tank | B. Rear under body | C. Periphery of pedals |

ENGINE CONTROL SYSTEM : Component Description

INFOID:000000009020572

| Component | Reference |
|------------------------------------|---|
| ECM | EC-20, "ECM" |
| A/F sensor 1 | EC-19, "Air Fuel Ratio Sensor 1" |
| A/F sensor 1 heater | EC-19, "Air Fuel Ratio Sensor 1 Heater" |
| Accelerator pedal position sensor | EC-18, "Accelerator Pedal Position Sensor" |
| Cooling fan motor | EC-20, "Cooling Fan" |
| Crankshaft position sensor | EC-20, "Crankshaft Position Sensor" |
| Electric throttle control actuator | EC-21, "Electric Throttle Control Actuator" |
| Engine coolant temperature sensor | EC-21, "Engine Coolant Temperature Sensor" |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HR16DE]

| Component | Reference |
|---|--|
| Engine oil pressure sensor | EC-21, "Engine Oil Pressure Sensor" |
| Engine oil temperature sensor | EC-21, "Engine Oil Temperature Sensor" |
| EVAP canister purge volume control solenoid valve | EC-22, "EVAP Canister Purge Volume Control Solenoid Valve" |
| EVAP canister vent control valve | EC-22, "EVAP Canister Vent Control Valve" |
| EVAP control system pressure sensor | EC-22, "EVAP Control System Pressure Sensor" |
| Exhaust valve timing control position sensor | EC-19, "Camshaft Position Sensor" |
| Exhaust valve timing control solenoid valve | EC-23, "Exhaust Valve Timing Control Solenoid Valve" |
| Fuel injector | EC-23, "Fuel Injector" |
| Fuel pump | EC-23, "Fuel Pump" |
| Heated oxygen sensor 2 | EC-24, "Heated Oxygen Sensor 2" |
| Heated oxygen sensor 2 heater | EC-24, "Heated Oxygen Sensor 2 Heater" |
| Ignition coil (with power transistor) | EC-24, "Ignition Coil With Power Transistor" |
| Intake air temperature sensor | EC-24, "Intake Air Temperature Sensor" |
| Camshaft position sensor | EC-19, "Camshaft Position Sensor" |
| Intake valve timing control solenoid valve | EC-25, "Intake Valve Timing Control Solenoid Valve" |
| Knock sensor | EC-25, "Knock Sensor" |
| Mass air flow sensor | EC-26, "Mass Air Flow Sensor" |
| PCV valve | EC-28, "Positive Crankcase Ventilation" |
| Refrigerant pressure sensor | EC-27, "Refrigerant Pressure Sensor" |
| Stop lamp switch | EC-27, "Stop Lamp Switch & ASCD Brake Switch" |
| Throttle control motor | EC-27, "Throttle Control Motor" |
| Throttle control motor relay | EC-27, "Throttle Control Motor Relay" |
| Throttle position sensor | EC-27, "Throttle Position Sensor" |
| ASCD steering switch | EC-27, "ASCD Steering Switch" |
| ASCD brake switch | EC-27, "Stop Lamp Switch & ASCD Brake Switch" |
| Clutch pedal position switch | EC-20, "Clutch Pedal Position Switch" |
| Active grille shutter | EXT-10, "ACTIVE GRILLE SHUTTER SYSTEM : Active grille shutter" |


Accelerator Pedal Position Sensor

INFOID:000000009020573

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometer which transform the accelerator pedal position into output voltage, and emit the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



PBIB1741E

COMPONENT PARTS


< SYSTEM DESCRIPTION >

[HR16DE]


Air Fuel Ratio Sensor 1

INFOID:000000009020574

The air fuel ratio (A/F) sensor 1 is a planar one-cell limit current sensor. The sensor element of the A/F sensor 1 is composed an electrode layer, which transports ions. It has a heater in the element. The sensor is capable of precise measurement $\lambda = 1$, but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide λ range. The exhaust gas components diffuse through the diffusion layer at the sensor cell. An electrode layer is applied voltage, and this current relative oxygen density in lean. Also this current relative hydrocarbon density in rich.



Therefore, the A/F sensor 1 is able to indicate air fuel ratio by this electrode layer of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of about 800°C (1,472°F).



Air Fuel Ratio Sensor 1 Heater

INFOID:000000009020575

SYSTEM DESCRIPTION


| Sensor | Input Signal to ECM | ECM function | Actuator |
|--|----------------------|---|---|
| Camshaft position sensor (PHASE) Crankshaft position sensor (POS) | Engine speed | Air fuel ratio (A/F) sensor 1 heater control | Air fuel ratio (A/F) sensor 1 heater |
| Mass air flow sensor | Amount of intake air | | |

The ECM performs ON/OFF duty control of the A/F sensor 1 heater corresponding to the engine operating condition to keep the temperature of A/F sensor 1 element within the specified range.

Camshaft Position Sensor

INFOID:000000009020576

The camshaft position sensor senses the protrusion of camshaft to identify a particular cylinder. The camshaft position sensor senses the piston position. When the crankshaft position sensor system becomes inoperative, the camshaft position sensor provides various controls of engine parts instead, utilizing timing of cylinder identification signals. The sensor consists of a permanent magnet and Hall IC. When engine is running, the high and low parts of the teeth cause the gap with the sensor to change. The changing gap causes the magnetic field near the sensor to change. Due to the changing magnetic field, the voltage from the sensor changes.




COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HR16DE]

ECM receives the signals as shown in the figure.



Clutch Pedal Position Switch

INFOID:000000009762888

When the clutch pedal is depressed, the clutch pedal position switch turns OFF and the clutch pedal position switch signal is sent to the ECM. The ECM judges the clutch pedal conditions via the signal (ON or OFF).

Cooling Fan


INFOID:000000009020577

Cooling fan operates at low and high speed when the current flows in the cooling fan motor. Refer to [EC-38, "COOLING FAN CONTROL : System Description"](#) for cooling fan operation.


Crankshaft Position Sensor

INFOID:000000009020578

The crankshaft position sensor is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at end of the crankshaft. It detects the fluctuation of the engine revolution. The sensor consists of a permanent magnet and Hall IC. When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change. The changing gap causes the magnetic field near the sensor to change. Due to the changing magnetic field, the voltage from the sensor changes. The ECM receives the voltage signal and detects the fluctuation of the engine revolution.




ECM receives the signals as shown in the figure.



ECM

INFOID:000000009020579

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HR16DE]

Electric Throttle Control Actuator


INFOID:000000009020580

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle valve in response to driving conditions via the throttle control motor.

Engine Coolant Temperature Sensor

INFOID:000000009020581


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

| Engine coolant temperature [°C (°F)] | Voltage* (V) | Resistance (kΩ) |
|--------------------------------------|--------------|-----------------|
| -10 (14) | 4.4 | 7.0 - 11.4 |
| 20 (68) | 3.5 | 2.10 - 2.90 |
| 50 (122) | 2.2 | 0.68 - 1.00 |
| 90 (194) | 0.9 | 0.236 - 0.260 |


*: These data are reference values and are measured between ECM terminals.



Engine Oil Pressure Sensor

INFOID:000000009020582


The engine oil pressure (EOP) sensor is detects engine oil pressure and transmits a voltage signal to the ECM.



Engine Oil Temperature Sensor

INFOID:000000009020583


The engine oil temperature sensor is used to detect the engine oil temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine oil temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

| Engine oil temperature [°C (°F)] | Voltage* (V) | Resistance (kΩ) |
|----------------------------------|--------------|-----------------|
| -10 (14) | 4.4 | 7.0 - 11.4 |
| 20 (68) | 3.5 | 2.10 - 2.90 |
| 50 (122) | 2.2 | 0.68 - 1.00 |
| 90 (194) | 0.9 | 0.236 - 0.260 |
| 110 (230) | 0.6 | 0.143 - 0.153 |


*: These data are reference values and are measured between ECM terminals.



EVAP Canister Purge Volume Control Solenoid Valve

INFOID:000000009020584

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



EVAP Canister Vent Control Valve


INFOID:000000009020585

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid valve responds to signals from the ECM. When the ECM sends an ON signal, the coil in the solenoid valve is energized. A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative emission control system components.

This solenoid valve is used only for diagnosis, and usually remains opened.


When the vent is closed, under normal purge conditions, the evaporative emission control system is depressurized and allows "EVAP Control System" diagnosis.



EVAP Control System Pressure Sensor

INFOID:000000009020586

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases.



COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HR16DE]

Exhaust Valve Timing Control Solenoid Valve

INFOID:000000009020587


Exhaust valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The exhaust valve timing control solenoid valve changes the oil amount and direction of flow through exhaust valve timing control unit or stops oil flow.

The longer pulse width retards valve angle.

The shorter pulse width advances valve angle.

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the exhaust valve angle at the control position.




JSBIA0652ZZ

Fuel Injector

INFOID:000000009020588

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the fuel injector circuit, the coil in the fuel injector is energized. The energized coil pulls the ball valve back and allows fuel to flow through the fuel injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



JSBIA0742ZZ

Fuel Pump

INFOID:000000009020589

| Sensor | Input signal to ECM | ECM function | Actuator |
|--|---------------------|-------------------|-----------------------------------|
| Crankshaft position sensor (POS) Camshaft position sensor (PHASE) | Engine speed* | Fuel pump control | Fuel pump relay ↓ Fuel pump |
| Battery | Battery voltage* | | |

*: ECM determines the start signal status by the signals of engine speed and battery voltage.

The ECM activates the fuel pump for a few seconds after the ignition switch is turned ON to improve engine start ability. If the ECM receives a engine speed signal from the crankshaft position sensor (POS) and camshaft position sensor (PHASE), it knows that the engine is rotating, and causes the pump to operate. If the engine speed signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

| Condition | Fuel pump operation |
|----------------------------------|------------------------|
| Ignition switch is turned to ON. | Operates for 1 second. |
| Engine running and cranking | Operates. |
| When engine is stopped | Stops in 1.5 seconds. |
| Except as shown above | Stops. |

COMPONENT PARTS


< SYSTEM DESCRIPTION >

[HR16DE]

Heated Oxygen Sensor 2

INFOID:000000009020590

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas. Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1 V in richer conditions to 0 V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



SEF327R

Heated Oxygen Sensor 2 Heater

INFOID:000000009020591

SYSTEM DESCRIPTION

| Sensor | Input signal to ECM | ECM function | Actuator |
|--|----------------------------|---------------------------------------|-------------------------------|
| Camshaft position sensor (PHASE) Crankshaft position sensor (POS) | Engine speed | Heated oxygen sensor 2 heater control | Heated oxygen sensor 2 heater |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Mass air flow sensor | Amount of intake air | | |

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed, amount of intake air and engine coolant temperature.

OPERATION

| Engine speed | Heated oxygen sensor 2 heater |
|--|-------------------------------|
| Above 3,600 rpm | OFF |
| Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load | ON |

Ignition Coil With Power Transistor

INFOID:000000009020592


The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns ON and OFF the ignition coil primary circuit. This ON/OFF operation induces the proper high voltage in the coil secondary circuit.

Intake Air Temperature Sensor

INFOID:000000009020593

The intake air temperature sensor is built-into mass air flow sensor (1). The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



PBIA9559J

COMPONENT PARTS


[HR16DE]

< SYSTEM DESCRIPTION >

<Reference data>

| Intake air temperature [°C (°F)] | Voltage* (V) | Resistance (kΩ) |
|----------------------------------|--------------|-----------------|
| 25 (77) | 3.3 | 1.800 - 2.200 |
| 80 (176) | 1.2 | 0.283 - 0.359 |

*: These data are reference values and are measured between ECM terminals.



INFOID:000000009020594

Intake Valve Timing Control Solenoid Valve


Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.


When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.



INFOID:000000009020595

Knock Sensor

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.



INFOID:000000009696918

Battery Current Sensor (With Battery Temperature Sensor)


OUTLINE

The power generation voltage variable control enables fuel consumption to be decreased by reducing the engine load which is caused by the power generation of the generator.

Based on sensor signals, ECM judges whether or not the power generation voltage variable control is performed. When performing the power generation voltage variable control, ECM calculates the target power generation voltage based on the sensor signal. And ECM sends the calculated value as the power generation command value to IPDM E/R. For the details of the power generation voltage variable control, refer to [CHG-8, "System Description"](#).

CAUTION:

Never connect the electrical component or the ground wire directly to the battery terminal. The connection causes the malfunction of the power generation voltage variable control, and then the battery discharge may occur.



BATTERY CURRENT SENSOR

The battery current sensor is installed to the battery negative cable. The sensor measures the charging/discharging current of the battery.

COMPONENT PARTS

[HR16DE]

< SYSTEM DESCRIPTION >


BATTERY TEMPERATURE SENSOR

Battery temperature sensor is integrated in battery current sensor. The sensor measures temperature around the battery. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>

| Temperature [°C (°F)] | Voltage* (V) | Resistance (kΩ) |
|-----------------------|--------------|-----------------|
| 25 (77) | 3.333 | 1.9 - 2.1 |
| 90 (194) | 0.969 | 0.222 - 0.258 |


*: These data are reference values and are measured between battery temperature sensor signal terminal and sensor ground.



Malfunction Indicator Lamp (MIL)

INFOID:000000009020596


The MIL is located on the combination meter. The MIL will illuminate when the ignition switch is turned ON without the engine running. This is a bulb check. When the engine is started, the MIL should turn OFF. If MIL remains ON or continues blinking, the on board diagnostic system detects a DTC(s) that affects exhaust gas. For details, refer to [EC-57, "DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp \(MIL\)"](#).



Mass Air Flow Sensor

INFOID:000000009020597


The mass air flow sensor (1) is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. The mass air flow sensor controls the temperature of the hot wire to a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the electric current supplied to hot wire is changed to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.



Oil Pressure Warning Lamp

INFOID:000000009020598

Oil pressure warning lamp is located on the combination meter. It indicates the low pressure of the engine oil and the malfunction of the engine oil pressure system. Combination meter turns the oil pressure warning lamp ON/OFF according to the oil pressure warning lamp signal received from ECM via CAN communication. For details, refer to [EC-43, "ENGINE PROTECTION CONTROL AT LOW ENGINE OIL PRESSURE : System Description"](#).



COMPONENT PARTS


< SYSTEM DESCRIPTION >

[HR16DE]

Refrigerant Pressure Sensor

INFOID:000000009020599

The refrigerant pressure sensor is installed at the condenser of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.



Stop Lamp Switch & ASCD Brake Switch

INFOID:000000009020600

Stop lamp switch and ASCD brake switch are installed to brake pedal bracket. ECM detects the state of the brake pedal by those two types of input (ON/OFF signal).

| Brake pedal | ASCD brake switch | Stop lamp switch |
|-------------|-------------------|------------------|
| Released | ON | OFF |
| Depressed | OFF | ON |

Throttle Control Motor

INFOID:000000009020601

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle valve in response to driving conditions via the throttle control motor.

Throttle Control Motor Relay

INFOID:000000009020602


Power supply for the throttle control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

Throttle Position Sensor

INFOID:000000009020603

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has two sensors. These sensors are a kind of potentiometer which transform the throttle valve position into output voltage, and emit the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and controls the throttle valve in response to driving conditions via the throttle control motor.



ASCD Steering Switch


INFOID:000000009020604

ASCD steering switch has variant values of electrical resistance for each button. ECM reads voltage variation of switch, and determines which button is operated.

STRUCTURE AND OPERATION

Positive Crankcase Ventilation

INFOID:000000009020605



This system returns blow-by gas to the intake manifold.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.


During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.




STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[HR16DE]

On Board Refueling Vapor Recovery (ORVR)

INFOID:000000009020606



From the beginning of refueling, the air and vapor inside the fuel tank go through refueling EVAP vapor cut valve and EVAP/ORVR line to the EVAP canister. The vapor is absorbed by the EVAP canister and the air is released to the atmosphere.

When the refueling has reached the full level of the fuel tank, the refueling EVAP vapor cut valve is closed and refueling is stopped because of auto shut-off. The vapor which was absorbed by the EVAP canister is purged during driving.

WARNING:

When conducting inspections below, be sure to observe the following:


- Put a “CAUTION: FLAMMABLE” sign in workshop.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Be sure to furnish the workshop with a CO₂ fire extinguisher.

CAUTION:

- Before removing fuel line parts, carry out the following procedures:
 - Put drained fuel in an explosion-proof container and put lid on securely.
 - Release fuel pressure from fuel line. Refer to [EC-135, "Work Procedure"](#).
 - Disconnect battery ground cable.
- Always replace O-ring when the fuel gauge retainer is removed.
- Do not kink or twist hose and tube when they are installed.
- Do not tighten hose and clamps excessively to avoid damaging hoses.
- After installation, run engine and check for fuel leaks at connection.
- Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically. Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire.

SYSTEM
ENGINE CONTROL SYSTEM
ENGINE CONTROL SYSTEM : System Diagram

INFOID:000000009020607



JPBIA5483GB

SYSTEM

< SYSTEM DESCRIPTION >

[HR16DE]

ENGINE CONTROL SYSTEM : System Description

INFOID:000000009020608

ECM performs various controls such as fuel injection control and ignition timing control.

| Function | Reference |
|--|--|
| Multiport fuel injection system | EC-32. "MULTIPORT FUEL INJECTION SYSTEM : System Description" |
| Electric ignition system | EC-35. "ELECTRIC IGNITION SYSTEM : System Description" |
| Air conditioning cut control | EC-37. "AIR CONDITIONING CUT CONTROL : System Description" |
| CAN communication | EC-38. "CAN COMMUNICATION : System Description" |
| Cooling fan control | EC-38. "COOLING FAN CONTROL : System Description" |
| Evaporative emission system | EC-40. "EVAPORATIVE EMISSION SYSTEM : System Description" |
| Intake valve timing control | EC-41. "INTAKE VALVE TIMING CONTROL : System Description" |
| Exhaust valve timing control | EC-42. "EXHAUST VALVE TIMING CONTROL : System Description" |
| Engine protection control at low engine oil pressure | EC-43. "ENGINE PROTECTION CONTROL AT LOW ENGINE OIL PRESSURE : System Description" |
| Fuel filler cap warning system | EC-44. "FUEL FILLER CAP WARNING SYSTEM : System Description" |
| Automatic speed control device (ASCD) | EC-45. "AUTOMATIC SPEED CONTROL DEVICE (ASCD) : System Description" |
| Active grille shutter system | EXT-11. "ACTIVE GRILLE SHUTTER SYSTEM : System Description" |

MULTIPORT FUEL INJECTION SYSTEM


SYSTEM

< SYSTEM DESCRIPTION >

[HR16DE]

MULTIPOINT FUEL INJECTION SYSTEM : System Diagram

INFOID:000000009020609



MULTIPOINT FUEL INJECTION SYSTEM : System Description

INFOID:000000009020610

INPUT/OUTPUT SIGNAL CHART

SYSTEM

< SYSTEM DESCRIPTION >

[HR16DE]

| Sensor | Input signal to ECM | ECM function | Actuator |
|--------------------------------------|--|--|---------------|
| Crankshaft position sensor (POS) | Engine speed*4 Piston position | Fuel injection & mixture ratio control | Fuel injector |
| Camshaft position sensor (PHASE) | | | |
| Mass air flow sensor | Amount of intake air | | |
| Intake air temperature sensor | Intake air temperature | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Air fuel ratio (A/F) sensor 1 | Density of oxygen in exhaust gas | | |
| Throttle position sensor | Throttle position | | |
| Accelerator pedal position sensor | Accelerator pedal position | | |
| Park/neutral position (PNP) switch*1 | PNP signal | | |
| Transmission range switch*2 | | | |
| Battery | Battery voltage*4 | | |
| Knock sensor | Engine knocking condition | | |
| Heated oxygen sensor 2*3 | Density of oxygen in exhaust gas | | |
| EPS control unit | EPS operation signal*5 | | |
| Combination meter | Vehicle speed*5 | | |
| BCM | A/C ON signal*5 Blower fan signal*5 | | |

*1: M/T models

*2: CVT models

*3: This sensor is not used to control the engine system under normal conditions.

*4: ECM determines the start signal status by the signals of engine speed and battery voltage.

*5: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from the crankshaft position sensor, camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.

<Fuel increase>


- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever position is changed from N to D (CVT models)
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

< SYSTEM DESCRIPTION >

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for drivability and emission control. The three way catalyst (manifold) can better reduce CO, HC and NOx emissions. This system uses A/F sensor 1 in the exhaust manifold to monitor whether the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about A/F sensor 1, refer to [EC-19. "Air Fuel Ratio Sensor 1"](#). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of A/F sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

- Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of A/F sensor 1 or its circuit
- Insufficient activation of heated sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from N to D (CVT models)
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from A/F sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot wire) and characteristic changes during operation (i.e., fuel injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.


"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes "short-term fuel trim" and "long-term fuel trim".

"Short-term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from A/F sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long-term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the "short-term fuel trim" from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

< SYSTEM DESCRIPTION >

FUEL INJECTION TIMING



Two types of systems are used.

- Sequential Multiport Fuel Injection System
Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.
- Simultaneous Multiport Fuel Injection System
Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.
The four injectors will then receive the signals two times for each engine cycle.
This system is used when the engine is being started and/or if the fail safe system (CPU) is operating.


FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration, operation of the engine at excessively high speeds or operation of the vehicle at excessively high speeds.

ELECTRIC IGNITION SYSTEM

ELECTRIC IGNITION SYSTEM : System Diagram

INFOID:000000009020611



ELECTRIC IGNITION SYSTEM : System Description

INFOID:000000009020612

INPUT/OUTPUT SIGNAL CHART

SYSTEM

< SYSTEM DESCRIPTION >

[HR16DE]

| Sensor | Input signal to ECM | ECM function | Actuator |
|---------------------------------------|-----------------------------------|-------------------------|---------------------------------------|
| Crankshaft position sensor (POS) | Engine speed*3 Piston position | Ignition timing control | Ignition coil (with power transistor) |
| Camshaft position sensor (PHASE) | | | |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Throttle position sensor | Throttle position | | |
| Accelerator pedal position sensor | Accelerator pedal position | | |
| Park/neutral position (PNP) switch *1 | PNP signal | | |
| Transmission range switch *2 | | | |
| Battery | Battery voltage *3 | | |
| Knock sensor | Engine knocking | | |
| Combination meter | Vehicle speed *4 | | |

*1: M/T models

*2: CVT models

*3: ECM determines the start signal status by the signals of engine speed and battery voltage.

*4: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

Firing order: 1 - 3 - 4 - 2

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.


- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

AIR CONDITIONING CUT CONTROL

AIR CONDITIONING CUT CONTROL : System Diagram

INFOID:000000009020613



AIR CONDITIONING CUT CONTROL : System Description

INFOID:000000009020614

INPUT/OUTPUT SIGNAL CHART

| Sensor | Input signal to ECM | ECM function | Actuator |
|--|--|-------------------------------|---|
| Crankshaft position sensor (POS) Camshaft position sensor (PHASE) | Engine speed ^{*1} Piston position | A/C compressor request signal | IPDM E/R ↓ Air conditioner relay ↓ Compressor |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Accelerator pedal position sensor | Accelerator pedal position | | |
| Battery | Battery voltage ^{*1} | | |
| Refrigerant pressure sensor | Refrigerant pressure | | |
| EPS control unit | EPS operation signal ^{*2} | | |
| Combination meter | Vehicle speed signal ^{*2} | | |
| BCM | A/C ON signal ^{*2} Blower fan signal ^{*2} | | |

*1: ECM determines the start signal status by the signals of engine speed and battery voltage.

*2: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used.

Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

< SYSTEM DESCRIPTION >

CAN COMMUNICATION

CAN COMMUNICATION : System Description

INFOID:000000009020615


CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to [LAN-29, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#), about CAN communication for detail.

COOLING FAN CONTROL

COOLING FAN CONTROL : System Diagram

INFOID:000000009020616



COOLING FAN CONTROL : System Description

INFOID:000000009020617

INPUT/OUTPUT SIGNAL CHART

| Sensor | Input signal to ECM | ECM function | Actuator |
|--|--|----------------------------------|--|
| Crankshaft position sensor (POS) Camshaft position sensor (PHASE) | Engine speed*1 Piston position | Cooling fan speed request signal | IPDM E/R ↓ Cooling fan relay ↓ Cooling fan motor |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Refrigerant pressure sensor | Refrigerant pressure | | |
| Battery | Battery voltage*1 | | |
| Combination meter | Vehicle speed*2 | | |
| BCM | A/C ON signal*2 Blower fan signal*2 | | |


*1: The ECM determines the start signal status by the signals of engine speed and battery voltage.

*2: This signal is sent to ECM through CAN communication line.

SYSTEM DESCRIPTION (CVT MODELS)

ECM controls cooling fan speed corresponding to vehicle speed, engine coolant temperature, refrigerant pressure, air conditioner ON signal. Then control system has 3-step control [HIGH/LOW/OFF].

Cooling Fan Operation



Cooling Fan Relay Operation


The ECM controls cooling fan relays through CAN communication line.

| Cooling fan speed | Cooling fan relay | | |
|-------------------|-------------------|-----|-----|
| | 1 | 2 | 3 |
| Stop (OFF) | OFF | OFF | OFF |
| Low (LOW) | ON | OFF | OFF |
| High (HI) | ON | ON | ON |

SYSTEM DESCRIPTION (M/T MODELS)

ECM controls cooling fan speed corresponding to vehicle speed, engine coolant temperature, refrigerant pressure, air conditioner ON signal. Then control system has 2-step control [HIGH/OFF].

Cooling Fan Operation



Cooling Fan Relay Operation


The ECM controls cooling fan relays through CAN communication line.

| Cooling fan speed | Cooling fan relay |
|-------------------|-------------------|
| Stop (OFF) | OFF |
| Operate (HI) | ON |

EVAPORATIVE EMISSION SYSTEM

EVAPORATIVE EMISSION SYSTEM : System Diagram

INFOID:000000009020618



EVAPORATIVE EMISSION SYSTEM : System Description

INFOID:000000009020619

INPUT/OUTPUT SIGNAL CHART

| Sensor | Input signal to ECM | ECM function | Actuator |
|--|--|----------------------------------|---|
| Crankshaft position sensor (POS) Camshaft position sensor (PHASE) | Engine speed*1 Piston position | EVAP canister purge flow control | EVAP canister purge volume control solenoid valve |
| Mass air flow sensor | Amount of intake air | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Air fuel ratio (A/F) sensor 1 | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | | |
| Throttle position sensor | Throttle position | | |
| Accelerator pedal position sensor | Accelerator pedal position | | |
| Battery | Battery voltage*1 | | |
| Fuel tank temperature sensor | Fuel temperature in fuel tank | | |
| EVAP control system pressure sensor | Pressure in purge line | | |
| Combination meter | Vehicle speed*2 | | |

*1: ECM determines the start signal status by the signals of engine speed and battery voltage.


*2: This signal is sent to the ECM through CAN communication line.

SYSTEM

< SYSTEM DESCRIPTION >

[HR16DE]

SYSTEM DESCRIPTION




The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank. The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases. EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating.

INTAKE VALVE TIMING CONTROL

INTAKE VALVE TIMING CONTROL : System Diagram

INFOID:000000009020620



INTAKE VALVE TIMING CONTROL : System Description

INFOID:000000009020621

INPUT/OUTPUT SIGNAL CHART


| Sensor | Input signal to ECM | ECM function | Actuator |
|-----------------------------------|-----------------------------------|-----------------------------|--|
| Crankshaft position sensor (POS) | Engine speed*1 Piston position | Intake valve timing control | Intake valve timing control solenoid valve |
| Camshaft position sensor (PHASE) | | | |
| Engine oil temperature sensor | Engine oil temperature | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Combination meter | Vehicle speed*2 | | |

< SYSTEM DESCRIPTION >

*1: ECM determines the start signal status by the signals of engine speed and battery voltage.

*2: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION




This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, engine oil temperature and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing (IVT) control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

EXHAUST VALVE TIMING CONTROL

EXHAUST VALVE TIMING CONTROL : System Diagram

INFOID:000000009020622



JPBIA4885GB

EXHAUST VALVE TIMING CONTROL : System Description

INFOID:000000009020623

INPUT/OUTPUT SIGNAL CHART


| Sensor | Input signal to ECM | ECM function | Actuator |
|-----------------------------------|-----------------------------------|------------------------------|---|
| Crankshaft position sensor (POS) | Engine speed*1 Piston position | Exhaust valve timing control | Exhaust valve timing control solenoid valve |
| Camshaft position sensor (PHASE) | | | |
| Engine oil temperature sensor | Engine oil temperature | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Combination meter | Vehicle speed*2 | | |

< SYSTEM DESCRIPTION >

*1: ECM determines the start signal status by the signals of engine speed and battery voltage.

*2: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION




This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the exhaust valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, engine oil temperature and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the exhaust valve timing (EVT) control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the exhaust valve to increase engine torque and output in a range of high engine speed.

ENGINE PROTECTION CONTROL AT LOW ENGINE OIL PRESSURE

ENGINE PROTECTION CONTROL AT LOW ENGINE OIL PRESSURE : System Diagram



ENGINE PROTECTION CONTROL AT LOW ENGINE OIL PRESSURE : System Description

INPUT/OUTPUT SIGNAL CHART

| Sensor | Input signal to ECM | ECM function | Actuator |
|----------------------------------|---------------------|---|--|
| Engine oil pressure sensor | Engine pressure | Engine protection control • Oil pressure warning lamp signal | Combination meter • Oil pressure warning lamp |
| Crankshaft position sensor (POS) | Engine speed | | |

SYSTEM DESCRIPTION

- The engine protection control at low engine oil pressure warns the driver of a decrease in engine oil pressure by the oil pressure warning lamp a before the engine becomes damaged.
- When detecting a decrease in engine oil pressure at an engine speed less than 1,000 rpm, ECM transmits an oil pressure warning lamp signal to the combination meter. The combination meter turns ON the oil pressure warning lamp, according to the signal.


| | | |
|---------------------------------|---------------------|---------------------------|
| Decrease in engine oil pressure | Engine speed | Combination meter |
| | | Oil pressure warning lamp |
| Detection | Less than 1,000 rpm | ON* |
| | 1,000 rpm or more | ON |

*: When detecting a normal engine oil pressure, ECM turns OFF the oil pressure warning lamp.

FUEL FILLER CAP WARNING SYSTEM

FUEL FILLER CAP WARNING SYSTEM : System Diagram

INFOID:000000009020626



JSBIA0797GB

FUEL FILLER CAP WARNING SYSTEM : System Description

INFOID:000000009020627

INPUT/OUTPUT SIGNAL CHART

Input

| Unit/Sensor | Input signal to ECM | ECM function |
|-------------------------------------|---------------------------------------|---------------------------------|
| EVAP control system pressure sensor | Pressure in purge line | Fuel filler cap warning control |
| Combination meter | Fuel level | |
| | Fuel filler cap warning reset signal* | |

*: This signal is sent to the ECM via the CAN communication line.

Output

| Unit | Output signal | Actuator |
|------|---|-------------------|
| ECM | Fuel filler cap warning display signal* | Combination meter |

*: This signal is sent to the combination meter via the CAN communication line.

SYSTEM DESCRIPTION

The fuel filler cap warning system alerts the driver to the prevention of the fuel filler being left uncapped and malfunction occurrences after refueling, by turning ON the fuel filler cap warning display on the combination meter.

ECM judges a refueled state, based on a fuel level signal transmitted from the combination meter.

When a very small leak is detected through the EVAP leak diagnosis performed after judging the refueled state, ECM transmits a fuel filler cap warning display signal (request for display ON) to the combination meter via CAN communication.

When receiving the signal, the combination meter turns ON the fuel filler cap warning display.

CAUTION:

Check fuel filler cap installation condition when the fuel filler cap warning display turns ON.

Reset Operation

< SYSTEM DESCRIPTION >

The fuel filler cap warning lamp tunes OFF, according to any condition listed below:

- Reset operation is performed by operating the meter control switch on the combination meter. Refer to [MWI-13. "Switch Name and Function"](#).
- When the reset operation is performed, the combination meter transmits a fuel filler cap warning reset signal to ECM via CAN communication. ECM transmits a fuel filler cap warning display signal (request for display OFF) to the combination meter via CAN communication. When receiving the signal, the combination meter turns OFF the fuel filler cap warning display.
- EVAP leak diagnosis result is normal.
- Fuel refilled.
- DTC erased by using CONSULT.


NOTE:

MIL turns ON if a malfunction is detected in leak diagnosis results again at the trip after the fuel filler cap warning display turns ON/OFF.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

AUTOMATIC SPEED CONTROL DEVICE (ASCD) : System Diagram

INFOID:000000009020628



AUTOMATIC SPEED CONTROL DEVICE (ASCD) : System Description

INFOID:000000009020629

INPUT/OUTPUT SIGNAL CHART

| Sensor | Input signal to ECM | ECM function | Actuator |
|------------------------------------|---------------------------------|----------------------------|------------------------------------|
| ASCD steering switch | ASCD steering switch operation | ASCD vehicle speed control | Electric throttle control actuator |
| Brake pedal position switch | Brake pedal operation | | |
| Stop lamp switch | | | |
| Clutch pedal position switch | Clutch pedal operation | | |
| Transmission range switch | Gear position | | |
| Park/neutral position (PNP) switch | PNP signal | | |
| Combination meter | Vehicle speed signal* | | |
| TCM | Output shaft revolution signal* | | |

*: This signal is sent to the ECM via the CAN communication line

BASIC ASCD SYSTEM

Automatic Speed Control Device (ASCD) allows a driver to keep vehicle at predetermined constant speed without depressing accelerator pedal. Driver can be set the vehicle speed in the set speed range. ECM controls throttle angle of electric throttle control actuator to regulate engine speed. Operation status of ASCD is indicated in combination meter. If any malfunction occurs in the ASCD system, it automatically deactivates the ASCD control.

SYSTEM

< SYSTEM DESCRIPTION >

[HR16DE]

Refer to [EC-47, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\) : Switch Name and Function"](#) for ASCD operating instructions.

CAUTION:

Always drive vehicle in a safe manner according to traffic conditions and obey all traffic laws.

OPERATION

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


AUTOMATIC SPEED CONTROL DEVICE (ASCD) : Switch Name and Function

INFOID:000000009020630

A

EC

SWITCHES AND INDICATORS



- ① CRUISE indicator
- ② SET indicator
- ③ CANCEL switch
- ④ ACCEL/RES switch
- ⑤ COAST/SET switch
- ⑥ ASCD MAIN switch
- Ⓐ On the combination meter (Information display)
- Ⓑ On the steering wheel

SET SPEED RANGE

ASCD system can be set the following vehicle speed.

| Minimum speed (Approx.) | Maximum speed (Approx.) |
|-------------------------|-------------------------|
| 38 km/h (24 MPH) | 144 km/h (90 MPH) |

SWITCH OPERATION

| Item | Function |
|--------------------------------------|--|
| CANCEL switch | Cancels the cruise control driving. |
| ACCEL/RES switch (ACCELERATE/RESUME) | <ul style="list-style-type: none"> • Resumes the set speed. • Increases speed incrementally during cruise control driving. |
| COAST/SET switch | <ul style="list-style-type: none"> • Sets desired cruise speed. • Decreases speed incrementally during cruise control driving. |
| ASCD MAIN switch | Master switch to activate the ASCD system. |

SET OPERATION

Press MAIN switch. (The CRUISE indicator in combination meter illuminates.)

When vehicle speed reaches a desired speed between approximately 38 km/h (24 MPH) and 144 km/h (90 MPH), press COAST/SET switch.

ACCELERATE OPERATION

If the ACCEL/RES switch is pressed during the cruise control driving, increase the vehicle speed until the switch is released or vehicle speed reaches maximum speed controlled by the system. And then ASCD will keep the new set speed.

CANCEL OPERATION

When any of following conditions exist, cruise operation will be canceled.

- CANCEL switch is pressed
- More than 2 switches at ASCD steering switch are pressed at the same time (Set speed will be cleared)
- Brake pedal is depressed
- Clutch pedal is depressed or gear position is changed to neutral position. (M/T models)
- Selector lever is changed to N, P or R position (CVT models)
- Vehicle speed decreased to 13 km/h (8 MPH) lower than the set speed

C

D

E

F

G

H

I

J

K

L

M

N

O

P

< SYSTEM DESCRIPTION >

- TCS system is operated

When the ECM detects any of the following conditions, the ECM will cancel the cruise operation and inform the driver by blinking indicator lamp.

- Engine coolant temperature is slightly higher than the normal operating temperature, CRUISE indicator may blink slowly.

When the engine coolant temperature decreases to the normal operating temperature, CRUISE indicator will stop blinking and the cruise operation will be able to work by pressing SET/- switch or RES/+ switch.

- Malfunction for some self-diagnoses regarding ASCD control: SET indicator will blink quickly.
- Speed limiter MAIN switch is pressed.(Set speed is cleared.)
- ASCD MAIN switch is pressed.(Set speed is cleared.)

COAST OPERATION

When the COAST/SET switch is pressed during the cruise control driving, decrease vehicle set speed until the switch is released. And then ASCD will keep the new set speed.

RESUME OPERATION

When the ACCEL/RES switch is pressed after cancel operation other than pressing MAIN switch is performed, vehicle speed will return to last set speed. To resume vehicle set speed, vehicle condition must meet following conditions.

- Brake pedal is released
- Clutch pedal is released (M/T models)
- Selector lever is in other than P and N positions (CVT models)
- Vehicle speed is greater than 38 km/h (24 MPH) and less than 144 km/h (90 MPH)

ON BOARD DIAGNOSTIC (OBD) SYSTEM

< SYSTEM DESCRIPTION >

[HR16DE]

ON BOARD DIAGNOSTIC (OBD) SYSTEM

Diagnosis Description

INFOID:000000009020631

This system is an on board diagnostic system that records exhaust emission-related diagnostic information and detects a sensors/actuator-related malfunction. A malfunction is indicated by the malfunction indicator lamp (MIL) and stored in ECU memory as a DTC. The diagnostic information can be obtained with the diagnostic tool (GST: Generic Scan Tool).

GST (Generic Scan Tool)

INFOID:000000009020632

When GST is connected with a data link connector equipped on the vehicle side, it will communicate with the control unit equipped in the vehicle and then enable various kinds of diagnostic tests. Refer to [EC-49. "Diagnosis Description"](#).

NOTE:

Service \$0A is not applied for regions where it is not mandated.

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM (ECM)

DIAGNOSIS DESCRIPTION

DIAGNOSIS DESCRIPTION : 1st Trip Detection Logic and Two Trip Detection Logic

INFOID:000000009020633

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not illuminate at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL illuminates. The MIL illuminates at the same time when the DTC is stored. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to illuminate or blink the MIL, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

×: Applicable —: Not applicable

| Items | MIL | | | | DTC | | 1st trip DTC | |
|---|----------|-------------|----------|-------------|---------------------|---------------------|---------------------|---------------------|
| | 1st trip | | 2nd trip | | 1st trip displaying | 2nd trip displaying | 1st trip displaying | 2nd trip displaying |
| | Blinking | Illuminated | Blinking | Illuminated | | | | |
| Misfire (Possible three way catalyst damage) — DTC: P0300 – P0308 is being detected | × | — | — | — | — | — | × | — |
| Misfire (Possible three way catalyst damage) — DTC: P0300 – P0308 is being detected | — | — | × | — | — | × | — | — |
| One trip detection diagnoses (Refer to EC-86, "DTC Index" .) | — | × | — | — | × | — | — | — |
| Except above | — | — | — | × | — | × | × | — |

DIAGNOSIS DESCRIPTION : DTC and Freeze Frame Data

INFOID:000000009020634

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not recur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is saved in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are saved in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

For malfunctions in which 1st trip DTCs are displayed, refer to [EC-86, "DTC Index"](#). These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT.

1st trip DTC is specified in Service \$07 of SAE J1979/ISO 15031-5. 1st trip DTC detection occurs without illuminating the MIL and therefore does not warn the driver of a malfunction.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in Work Flow procedure Step 2, refer to [EC-118, "Work Flow"](#). Then perform DTC Confirmation Procedure or Component Function Check to try to duplicate the malfunction. If the malfunction is duplicated, the item requires repair.

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, absolute throttle position, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT or GST. The 1st trip freeze frame data can only be displayed on the CONSULT screen.

DIAGNOSIS SYSTEM (ECM)

[HR16DE]

< SYSTEM DESCRIPTION >

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

| Priority | Items | |
|----------|----------------------------|--|
| 1 | Freeze frame data | Misfire — DTC: P0300 – P0308 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175 |
| 2 | | Except the above items |
| 3 | 1st trip freeze frame data | |

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was saved in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased.

DIAGNOSIS DESCRIPTION : Counter System

INFOID:000000009020635

RELATIONSHIP BETWEEN MIL, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on.
- The MIL will turn OFF after the vehicle is driven 3 times (driving pattern B) with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The “TIME” in “SELF-DIAGNOSTIC RESULTS” mode of CONSULT will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in OK for the 2nd trip.

COUNTER SYSTEM CHART


| Items | Fuel Injection System | Misfire | Other |
|-------------------------------------|-----------------------|-------------------|----------------|
| MIL (turns OFF) | 3 (pattern B) | 3 (pattern B) | 3 (pattern B) |
| DTC, Freeze Frame Data (no display) | 80 (pattern C) | 80 (pattern C) | 40 (pattern A) |
| 1st Trip DTC (clear) | 1 (pattern C), *1 | 1 (pattern C), *1 | 1 (pattern B) |
| 1st Trip Freeze Frame Data (clear) | *1, *2 | *1, *2 | 1 (pattern B) |

For details about patterns B and C under “Fuel Injection System” and “Misfire”, see “EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”.

For details about patterns A and B under Other, see “EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”.

- *1: Clear timing is at the moment OK is detected.
- *2: Clear timing is when the same malfunction is detected in the 2nd trip.

Relationship Between MIL, DTC, 1st Trip DTC and Driving Patterns for “Misfire <Exhaust Quality Deterioration>”, “Fuel Injection System”



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will turn OFF after vehicle is driven 3 times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- *6: The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.
- *8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

Explanation for Driving Patterns for “Misfire <Exhaust Quality Deterioration>”, “Fuel Injection System”

Driving Pattern B

Refer to [EC-54. "DIAGNOSIS DESCRIPTION : Driving Pattern"](#).

< SYSTEM DESCRIPTION >

Driving Pattern C

Refer to [EC-54, "DIAGNOSIS DESCRIPTION : Driving Pattern"](#).

Example:


If the stored freeze frame data is as per the following:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 – 1,225 rpm, Calculated load value: 27 – 33%, Engine coolant temperature: more than 70°C (158°F)

Relationship Between MIL, DTC, 1st Trip DTC and Driving Patterns Except For “Misfire <Exhaust Quality Deterioration>”, “Fuel Injection System”



JMBIA1418GB

- | | | |
|---|--|---|
| <p>*1: When the same malfunction is detected in two consecutive trips, MIL will light up.</p> | <p>*2: MIL will turn OFF after vehicle is driven 3 times (pattern B) without any malfunctions.</p> | <p>*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.</p> |
| <p>*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)</p> | <p>*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.</p> | <p>*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.</p> |
| <p>*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.</p> | | |

Explanation for Driving Patterns Except for “Misfire <Exhaust Quality Deterioration>”, “Fuel Injection System”

Driving Pattern A

Refer to [EC-54, "DIAGNOSIS DESCRIPTION : Driving Pattern"](#).

Driving Pattern B

Refer to [EC-54, "DIAGNOSIS DESCRIPTION : Driving Pattern"](#).

DIAGNOSIS DESCRIPTION : Driving Pattern

INFOID:000000009020636

CAUTION:

Always drive at a safe speed.

DRIVING PATTERN A

Driving pattern A means a trip satisfying the following conditions.

- Engine speed reaches 400 rpm or more.
- Engine coolant temperature rises by 20°C (36°F) or more after starting the engine.
- Engine coolant temperature reaches 70°C (158°F) or more.
- The ignition switch is turned from ON to OFF.

NOTE:

- When the same malfunction is detected regardless of driving conditions, reset the counter of driving pattern A.
- When the above conditions are satisfied without detecting the same malfunction, reset the counter of driving pattern A.

DRIVING PATTERN B

Driving pattern B means a trip satisfying the following conditions.

- Engine speed reaches 400 rpm or more.
- Engine coolant temperature reaches 70°C (158°F) or more.
- Vehicle speed of 70 – 120 km/h (44 – 75 MPH) is maintained for 60 seconds or more under the control of closed loop.
- Vehicle speed of 30 – 60 km/h (19 – 37 MPH) is maintained for 10 seconds or more under the control of closed loop.
- Under the closed loop control condition, the following state reaches 12 seconds or more in total: Vehicle speed of 4 km/h (2 MPH) or less with idling condition.
- The state of driving at 10 km/h (7 MPH) or more reaches 10 minutes or more in total.
- A lapse of 22 minutes or more after engine start.

NOTE:

- Drive the vehicle at a constant velocity.
- When the same malfunction is detected regardless of driving conditions, reset the counter of driving pattern B.
- When the above conditions are satisfied without detecting the same malfunction, reset the counter of driving pattern B.

DRIVING PATTERN C

Driving pattern C means operating vehicle as per the following:

The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

DIAGNOSIS SYSTEM (ECM)

< SYSTEM DESCRIPTION >

[HR16DE]

Calculated load value: (Calculated load value in the freeze frame data) x (1±0.1) [%]

Engine coolant temperature condition:

- When the freeze frame data shows lower than 70°C (158°F), engine coolant temperature should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), engine coolant temperature should be higher than or equal to 70°C (158°F).

NOTE:

- When the same malfunction is detected regardless of the above vehicle conditions, reset the counter of driving pattern C.
- When the above conditions are satisfied without detecting the same malfunction, reset the counter of driving pattern C.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

DRIVING PATTERN D

Driving pattern D means a trip satisfying the following conditions.

- The state of driving at 40 km/h (25 MPH) reaches 300 seconds or more in total.
- Idle speed lasts 30 seconds or more.
- A lapse of 600 seconds or more after engine start.

NOTE:

- When the same malfunction is detected regardless of driving conditions, reset the counter of driving pattern D.
- When the above conditions are satisfied without detecting the same malfunction, reset the counter of driving pattern D.

DIAGNOSIS DESCRIPTION : System Readiness Test (SRT) Code

INFOID:000000009020637

System Readiness Test (SRT) code is specified in Service §01 of SAE J1979/ISO 15031-5.

As part of an enhanced emissions test for Inspection & Maintenance (I/M), certain states require the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this Service Manual to set the SRT to "CMPLT".

In most cases the ECM will automatically complete its self-diagnosis cycle during normal usage, and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern; the SRT will indicate "INCMP" for these items.

NOTE:

The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items the vehicle is returned to the customer untested.

NOTE:

If permanent DTC is stored or MIL illuminates during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT"), DTC (No DTCs) and permanent DTC (No permanent DTC) before the inspection.

SRT SET TIMING

SRT is set as "CMPLT" after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

DIAGNOSIS SYSTEM (ECM)

< SYSTEM DESCRIPTION >

[HR16DE]

| Self-diagnosis result | | Example | | | | | | |
|-----------------------|--------|-------------------|----------------|---------|--------------|------------------------|--------|-----|
| | | Diagnosis | Ignition cycle | | | | | |
| | | | ← ON → | OFF | ← ON → | OFF | ← ON → | OFF |
| All OK | Case 1 | P0400 | OK (1) | — (1) | OK (2) | — (2) | | |
| | | P0402 | OK (1) | — (1) | — (1) | OK (2) | | |
| | | P1402 | OK (1) | OK (2) | — (2) | — (2) | | |
| | | SRT of EGR | “CMPLT” | “CMPLT” | “CMPLT” | “CMPLT” | | |
| | Case 2 | P0400 | OK (1) | — (1) | — (1) | — (1) | | |
| | | P0402 | — (0) | — (0) | OK (1) | — (1) | | |
| | | P1402 | OK (1) | OK (2) | — (2) | — (2) | | |
| | | SRT of EGR | “INCMP” | “INCMP” | “CMPLT” | “CMPLT” | | |
| NG exists | Case 3 | P0400 | OK | OK | — | — | | |
| | | P0402 | — | — | — | — | | |
| | | P1402 | NG | — | NG | NG (Consecutive NG) | | |
| | | (1st trip) DTC | 1st trip DTC | — | 1st trip DTC | DTC (= MIL ON) | | |
| | | SRT of EGR | “INCMP” | “INCMP” | “INCMP” | “CMPLT” | | |

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is NG.

—: Self-diagnosis is not carried out.

When all SRT related self-diagnoses show OK results in a single cycle (Ignition OFF-ON-OFF), the SRT will indicate “CMPLT”. → Case 1 above

When all SRT related self-diagnoses show OK results through several different cycles, the SRT will indicate “CMPLT” at the time the respective self-diagnoses have at least one OK result. → Case 2 above

If one or more SRT related self-diagnoses show NG results in 2 consecutive cycles, the SRT will also indicate “CMPLT”. → Case 3 above

The table above shows that the minimum number of cycles for setting SRT as “INCMP” is the number one (1) for each self-diagnosis (Case 1 & 2) or the number two (2) for one of self-diagnoses (Case 3). However, in preparation for the state emissions inspection, it is unnecessary for each self-diagnosis to be executed twice (Case 3) for the following reasons:

- The SRT will indicate “CMPLT” at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires “CMPLT” of the SRT only with OK self-diagnosis results.
- During SRT driving pattern, the 1st trip DTC (NG) is detected prior to “CMPLT” of SRT and the self-diagnosis memory must be erased from the ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate “INCMP”.

NOTE:

SRT can be set as “CMPLT” together with the DTC(s). Therefore, DTC check must always be carried out prior to the state emission inspection even though the SRT indicates “CMPLT”.

DIAGNOSIS DESCRIPTION : Permanent Diagnostic Trouble Code (Permanent DTC)

INFOID:000000009020638

Permanent DTC is defined in SAE J1979/ISO 15031-5 Service \$0A.

ECM stores a DTC issuing a command of turning on MIL as a permanent DTC and keeps storing the DTC as a permanent DTC until ECM judges that there is no presence of malfunction.

Permanent DTCs cannot be erased by using the Erase function of CONSULT or Generic Scan Tool (GST) and by disconnecting the battery to shut off power to ECM. This prevents a vehicle from passing the state emission inspection without repairing a malfunctioning part.

When not passing the state emission inspection due to more than one permanent DTC, permanent DTCs should be erased, referring to this manual.

NOTE:

- The important items in state emission inspection are that MIL is not ON, SRT test items are set, and permanent DTCs are not included.
- Permanent DTCs do not apply for regions that permanent DTCs are not regulated by law.

PERMANENT DTC SET TIMING

The setting timing of permanent DTC is stored in ECM with the lighting of MIL when a DTC is confirmed.

DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp (MIL)

INFOID:000000009020639

When emission-related ECU detects a malfunction in the emission control systems components and/or the powertrain control components (which affect vehicle emissions), it turns on/blinks MIL to inform the driver that a malfunction has been detected.

1. The MIL illuminates when ignition switch is turned ON (engine is not running).


NOTE:

Check the MIL circuit if MIL does not illuminate. Refer to [EC-444, "Diagnosis Procedure"](#).

2. When the engine is started, the MIL should go off.

NOTE:

If MIL continues to illuminate/blink, perform self-diagnoses and inspect/repair accordingly because an emission-related ECU has detected a malfunction in the emission control systems components and/or the powertrain control components (which affect vehicle emissions).



On Board Diagnosis Function

INFOID:000000009020640

ON BOARD DIAGNOSIS ITEM

The on board diagnostic system has the following functions.

| Diagnostic test mode | Function |
|--|---|
| Bulb check | MIL can be checked. |
| SRT status | ECM can read if SRT codes are set. |
| Malfunction warning | If ECM detects a malfunction, it illuminates or blinks MIL to inform the driver that a malfunction has been detected. |
| Self-diagnostic results | DTCs or 1st trip DTCs stored in ECM can be read. |
| Accelerator pedal released position learning | ECM can learn the accelerator pedal released position. Refer to EC-126, "Work Procedure" . |
| Throttle valve closed position learning | ECM can learn the throttle valve closed position. Refer to EC-127, "Work Procedure" . |
| Idle air volume learning | ECM can learn the idle air volume. Refer to EC-128, "Work Procedure" . |
| Mixture ratio self-learning value clear | Mixture ratio self-learning value can be erased. Refer to EC-130, "Work Procedure" . |

BULB CHECK MODE

Description

This function allows damage inspection in the MIL bulb (blown, open circuit, etc.).

Operation Procedure

1. Turn ignition switch ON.
2. The MIL on the instrument panel should stay ON.
If it remains OFF, check MIL circuit. Refer to [EC-444, "Diagnosis Procedure"](#).

SRT STATUS MODE

Description


This function allows to read if ECM has completed the self-diagnoses of major emission control systems and components. For SRT, refer to [EC-55, "DIAGNOSIS DESCRIPTION : System Readiness Test \(SRT\) Code"](#).

Operation Procedure

1. Turn ignition switch ON and wait 20 seconds.
2. SRT status is indicated as shown blow.
 - ECM continues to illuminate MIL if all SRT codes are set.

< SYSTEM DESCRIPTION >

- ECM blinks MIL for about 10 seconds if all SRT codes are not set.



MALFUNCTION WARNING MODE

Description

In this function ECM turns on or blinks MIL when it detects a malfunction in the emission control system components and/or the powertrain control components (which affect vehicle emissions) to inform the driver that a malfunction has been detected.

Operation Procedure

1. Turn ignition switch ON.
2. Check that MIL illuminates.
If it remains OFF, check MIL circuit. Refer to [EC-444, "Diagnosis Procedure"](#).
3. Start engine and let it idle.
 - For two trip detection logic diagnoses, ECM turns on MIL when it detects the same malfunction twice in the two consecutive driving cycles.
 - For 1st trip detection logic diagnoses, ECM turns on MIL when it detects a malfunction in one driving cycle.
 - ECM blinks MIL when it detects a malfunction that may damage the three way catalyst (misfire).

SELF-DIAGNOSTIC RESULTS MODE

Description

This function allows to indicate DTCs or 1st trip DTCs stored in ECM according to the number of times MIL is blinking.

How to Set Self-diagnostic Results Mode

NOTE:

- It is better to count the time accurately with a clock.
 - It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
 - After ignition switch is turned off, ECM is always released from the "self-diagnostic results" mode.
1. Confirm that accelerator pedal is fully released, turn ignition switch ON and wait 3 seconds.
 2. Repeat the following procedure quickly five times within 5 seconds.
 - Fully depress the accelerator pedal.
 - Fully release the accelerator pedal.
 3. Wait 7 seconds, fully depress the accelerator pedal and keep it depressed for approx. 10 seconds until the MIL starts blinking.


NOTE:

Do not release the accelerator pedal for 10 seconds if MIL starts blinking during this period. This blinking is displaying SRT status and is continued for another 10 seconds.

4. Fully release the accelerator pedal.
ECM has entered to "Self-diagnostic results" mode.


NOTE:

Wait until the same DTC (or 1st trip DTC) appears to completely confirm all DTCs.



How to Read Self-diagnostic Results

The DTC and 1st trip DTC are indicated by the number of blinks of the MIL as shown below. The DTC and 1st trip DTC are displayed at the same time. If the MIL does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MIL illuminates in "malfunction warning" mode, it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT or GST. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes per the following.

| | | | | | | | | | | | | | | | | |
|---------|----|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|
| Number | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
| Flashes | 10 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 11 | 12 | 13 | 14 | 15 | 16 |

The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-seconds) - OFF (0.6-seconds) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-seconds ON and 0.3-seconds OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-seconds OFF.

DIAGNOSIS SYSTEM (ECM)

[HR16DE]

< SYSTEM DESCRIPTION >

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC 0000 refers to no malfunction. Refer to [EC-86, "DTC Index"](#).

How to Erase Self-diagnostic Results

By performing this procedure, ECM memory is erased and the following diagnostic information is erased as well.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

NOTE:

Also, if a battery terminal is disconnected, ECM memory is erased and the diagnostic information as listed above is erased. (The amount of time required for erasing may vary from a few seconds to several hours.)

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Set ECM in "self-diagnostic results" mode.
6. The diagnostic information has been erased from the backup memory in the ECM.
Fully depress the accelerator pedal and keep it depressed for more than 10 seconds.
7. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

CONSULT Function

INFOID:000000009020641

FUNCTION

| Diagnostic test mode | Function |
|------------------------|---|
| Self Diagnostic Result | Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.* |
| Data Monitor | Input/Output data in the ECM can be read. |
| Work support | This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit. |
| Active Test | Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECMs and also shifts some parameters in a specified range. |
| ECU Identification | ECM part number can be read. |
| DTC work support | The status of system monitoring tests and the self-diagnosis status/result can be confirmed. |

*: The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

SELF DIAGNOSTIC RESULT MODE

Self Diagnostic Item

Regarding items of DTC and 1st trip DTC, refer to [EC-86, "DTC Index"](#).

How to Read DTC and 1st Trip DTC

DTCs and 1st trip DTCs related to the malfunction are displayed in "self-diag results".

- When ECM detects a 1st trip DTC, "1t" is displayed for "TIME".
- When ECM has detected a current DTC, "0" is displayed for "TIME".
- If "TIME" is neither "0" nor "1t", the DTC occurred in the past and ECM shows the number of times the vehicle has been driven since the last detection of the DTC.

Freeze Frame Data and 1st Trip Freeze Frame Data

DIAGNOSIS SYSTEM (ECM)

< SYSTEM DESCRIPTION >

[HR16DE]

| Freeze frame data item* | Description |
|------------------------------|---|
| Detected DTC | The engine control component part/control system has a trouble code, it is displayed as PXXXX. (Refer to EC-86, "DTC Index" .) |
| FUEL SYS-B1 | <ul style="list-style-type: none"> • "Fuel injection system status" at the moment a malfunction is detected is displayed. • One mode in the following is displayed. Mode2: Open loop due to detected system malfunction Mode3: Open loop due to driving conditions (power enrichment, deceleration enrichment) Mode4: Closed loop - using oxygen sensor(s) as feedback for fuel control Mode5: Open loop - has not yet satisfied condition to go to closed loop |
| FUEL SYS-B2 | |
| CAL/LD VALUE [%] | The calculated load value at the moment a malfunction is detected is displayed. |
| COOLANT TEMP [°C] or [°F] | The engine coolant temperature at the moment a malfunction is detected is displayed. |
| L-FUEL TRM-B1 [%] | <ul style="list-style-type: none"> • "Long-term fuel trim" at the moment a malfunction is detected is displayed. • The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim. |
| L-FUEL TRM-B2 [%] | |
| S-FUEL TRM-B1 [%] | <ul style="list-style-type: none"> • "Short-term fuel trim" at the moment a malfunction is detected is displayed. • The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule. |
| S-FUEL TRM-B2 [%] | |
| ENGINE SPEED [rpm] | The engine speed at the moment a malfunction is detected is displayed. |
| VEHICL SPEED [km/h] or [mph] | The vehicle speed at the moment a malfunction is detected is displayed. |
| ABSOL TH-P/S [%] | The throttle valve opening angle at the moment a malfunction is detected is displayed. |
| B/FUEL SCHDL [msec] | The base fuel schedule at the moment a malfunction is detected is displayed. |
| INT/A TEMP SE [°C] or [°F] | The intake air temperature at the moment a malfunction is detected is displayed. |
| INT MANI PRES [kPa] | These items are displayed but are not applicable to this model. |
| COMBUST CONDITION | |

*: The items are the same as those of 1st trip freeze frame data.

DATA MONITOR MODE

NOTE:

- The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.
- For reference values of the following items, refer to [EC-70, "Reference Value"](#).

Monitored Item

| Monitored item | Unit | Description | Remarks |
|-----------------|--------|---|--|
| IDLE REQUEST* | YES/NO | <ul style="list-style-type: none"> • Displays the idle request status sent from HPCM. - YES: Idle request received - NO: No idle request | |
| MIL ON REQUEST* | YES/NO | <ul style="list-style-type: none"> • Displays the MIL ON request status sent from HPCM. - YES: MIL ON request received - NO: No MIL ON request | |
| ENGINE NO-LOAD* | YES/NO | <ul style="list-style-type: none"> • Displays the clutch 1 disengagement/engagement status sent from HPCM. - YES: Clutch 1 disengaged - NO: Clutch 1 engaged | |
| READY STATE* | YES/NO | <ul style="list-style-type: none"> • Displays the clutch 1 disengagement/engagement status sent from HPCM. - YES: READY state - NO: Not in READY state | |
| ENG SPEED | rpm | Indicates the engine speed computed from the signal of the crankshaft position sensor (POS) and camshaft position sensor (PHASE). | <ul style="list-style-type: none"> • Accuracy becomes poor if engine speed drops below the idle rpm. • If the signal is interrupted while the engine is running, an abnormal value may be indicated. |

DIAGNOSIS SYSTEM (ECM)

[HR16DE]

< SYSTEM DESCRIPTION >

| Monitored item | Unit | Description | Remarks |
|----------------|-------------|---|---|
| MAS A/F SE-B1 | V | The signal voltage of the mass air flow sensor is displayed. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. When engine is running, specification range is indicated in "SPEC". |
| B/FUEL SCHDL | ms | "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. | When engine is running, specification range is indicated in "SPEC". |
| A/F ALPHA-B1 | % | The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. | <ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. When engine is running, specification range is indicated in "SPEC". This data also includes the data for the air-fuel ratio learning control. |
| COOLAN TEMP/S | °C or °F | The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. | When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed. |
| A/F SEN1 (B1) | V | The A/F signal computed from the input signal of the air fuel ratio (A/F) sensor 1 is displayed. | |
| HO2S2 (B1) | V | The signal voltage of the heated oxygen sensor 2 is displayed. | |
| HO2S2 MNTR(B1) | RICH/LEAN | <ul style="list-style-type: none"> Display of heated oxygen sensor 2 signal. - RICH: means the amount of oxygen after three way catalyst is relatively small. - LEAN: means the amount of oxygen after three way catalyst is relatively large. | When the engine is stopped, a certain value is indicated. |
| VHCL SPEED SE | km/h or mph | The vehicle speed computed from the vehicle speed signal sent from combination meter is displayed. | |
| BATTERY VOLT | V | The power supply voltage of ECM is displayed. | |
| ACCEL SEN 1 | V | The accelerator pedal position sensor signal voltage is displayed. | ACCEL SEN 2 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal. |
| ACCEL SEN 2 | | | |
| TP SEN 1-B1 | V | The throttle position sensor signal voltage is displayed. | TP SEN 2-B1 signal is converted by ECM internally. Thus, it differs from ECM terminal voltage signal. |
| TP SEN 2-B1 | | | |
| FUEL T/TMP SE | °C or °F | The fuel temperature (determined by the signal voltage of the fuel tank temperature sensor) is displayed. | |
| EVAP SYS PRES | V | The signal voltage of EVAP control system pressure sensor is displayed. | |
| FUEL LEVEL SE | V | The signal voltage of the fuel level sensor is displayed. | |
| START SIGNAL | ON/OFF | Indicates start signal status [ON/OFF] computed by the ECM according to the signals of engine speed and battery voltage. | After starting the engine, [OFF] is displayed regardless of the starter signal. |
| CLSD THL POS | ON/OFF | Indicates idle position [ON/OFF] computed by ECM according to the accelerator pedal position sensor signal. | |
| AIR COND SIG | ON/OFF | Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. | |
| PW/ST SIGNAL | ON/OFF | [ON/OFF] condition of the power steering system (determined by the signal sent from EPS control unit) is indicated. | |

DIAGNOSIS SYSTEM (ECM)

< SYSTEM DESCRIPTION >

[HR16DE]

| Monitored item | Unit | Description | Remarks |
|----------------|------------|--|--|
| LOAD SIGNAL | ON/OFF | <ul style="list-style-type: none"> Indicates [ON/OFF] condition of the electrical lode signal. - ON: Rear window defogger switch is ON and/or lighting switch is 2nd position. - OFF: Both rear window defogger switch and lighting switch are OFF. | |
| IGNITION SW | ON/OFF | Indicates [ON/OFF] condition from ignition switch signal. | |
| HEATER FAN SW | ON/OFF | Indicates [ON/OFF] condition from the heater fan switch signal. | |
| BRAKE SW | ON/OFF | Indicates [ON/OFF] condition from the stop lamp switch signal. | |
| INJ PULSE-B1 | msec | Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. | When the engine is stopped, a certain computed value is indicated. |
| IGN TIMING | BTDC | Indicates the ignition timing computed by ECM according to the input signals. | When the engine is stopped, a certain value is indicated. |
| CAL/LD VALUE | % | "Calculated load value" indicates the value of the current air flow divided by peak air flow. | |
| MASS AIRFLOW | g/s | Indicates the mass air flow computed by ECM according to the signal voltage of the mass air flow sensor. | |
| PURG VOL C/V | % | <ul style="list-style-type: none"> Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. | |
| INT/V TIM(B1) | °CA | Indicates [°CA] of intake camshaft advance angle. | |
| EXH/V TIM B1 | °CA | Indicates [°CA] of exhaust camshaft retard angle. | |
| INT/V SOL(B1) | % | <ul style="list-style-type: none"> The control value of the intake valve timing control solenoid valve (determined by ECM according to the input signals) is indicated. The advance angle becomes larger as the value increases. | |
| AIR COND RLY | ON/OFF | The air conditioner relay control condition (determined by ECM according to the input signals) is indicated. | |
| FUEL PUMP RLY | ON/OFF | Indicates the fuel pump relay control condition determined by ECM according to the input signals. | |
| VENT CONT/V | ON/OFF | <ul style="list-style-type: none"> The control condition of the EVAP canister vent control valve (determined by ECM according to the input signals) is displayed. - ON: Closed - OFF: Open | |
| THRTL RELAY | ON/OFF | Indicates the throttle control motor relay control condition determined by the ECM according to the input signals. | |
| COOLING FAN | HI/LOW/OFF | <ul style="list-style-type: none"> Indicates the condition of the cooling fan (determined by ECM according to the input signals). - HI: High speed operation - LOW: Low speed operation - OFF: Stop | |
| HO2S2 HTR (B1) | ON/OFF | Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. | |

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

DIAGNOSIS SYSTEM (ECM)

[HR16DE]

< SYSTEM DESCRIPTION >

| Monitored item | Unit | Description | Remarks |
|----------------|-------------|--|---------|
| ALT DUTY SIG | ON/OFF | <ul style="list-style-type: none"> • The control condition of the power generation voltage variable control (determined by ECM according to the input signals) is indicated. - ON: Power generation voltage variable control is active. - OFF: Power generation voltage variable control is inactive. | |
| I/P PULLY SPD | rpm | Indicates the engine speed computed from the input speed sensor signal. | |
| VEHICLE SPEED | km/h or mph | The vehicle speed computed from the vehicle speed signal sent from TCM is displayed. | |
| IDL A/V LEARN | YET/CMPLT | <ul style="list-style-type: none"> • Displays the condition of Idle Air Volume Learning. - YET: Idle air volume learning has not been performed yet. - CMPLT: Idle air volume learning has already been performed successfully. | |
| TRVL AFTER MIL | km or mile | Distance traveled while MI is activated. | |
| ENG OIL TEMP | °C or °F | The engine oil temperature (determined by the signal voltage of the engine oil temperature sensor) is indicated. | |
| A/F S1 HTR(B1) | % | <ul style="list-style-type: none"> • Air fuel ratio (A/F) sensor 1 heater control value computed by ECM according to the input signals. • The current flow to the heater becomes larger as the value increases. | |
| VHCL SPEED SE | km/h or mph | The vehicle speed computed from the vehicle speed signal sent from combination meter is displayed. | |
| SET VHCL SPD | km/h or mph | The preset vehicle speed is displayed. | |
| MAIN SW | ON/OFF | Indicates [ON/OFF] condition from ASCD MAIN switch signal. | |
| CANCEL SW | ON/OFF | Indicates [ON/OFF] condition from CANCEL switch signal. | |
| RESUME/ACC SW | ON/OFF | Indicates [ON/OFF] condition from ACCEL/RES switch signal. | |
| SET SW | ON/OFF | Indicates [ON/OFF] condition from COAST/SET switch signal. | |
| BRAKE SW1 | ON/OFF | Indicates [ON/OFF] condition from ASCD brake switch signal. | |
| BRAKE SW2 | ON/OFF | Indicates [ON/OFF] condition of stop lamp switch signal. | |
| VHCL SPD CUT | NON/CUT | <ul style="list-style-type: none"> • Indicates the vehicle cruise condition. - NON: Vehicle speed is maintained at the ASCD set speed. - CUT: Vehicle speed decreased to excessively low compared with the ASCD set speed, and ASCD operation is cut off. | |
| LO SPEED CUT | NON/CUT | <ul style="list-style-type: none"> • Indicates the vehicle cruise condition. - NON: Vehicle speed is maintained at the ASCD set speed. - CUT: Vehicle speed decreased to excessively low, and ASCD operation is cut off. | |
| AT OD MONITOR | ON/OFF | Indicates [ON/OFF] condition of CVT O/D according to the input signal from the TCM. | |
| AT OD CANCEL | ON/OFF | Indicates [ON/OFF] condition of CVT O/D cancel request signal. | |

DIAGNOSIS SYSTEM (ECM)

< SYSTEM DESCRIPTION >

[HR16DE]

| Monitored item | Unit | Description | Remarks |
|--------------------|--------------|--|---------|
| CRUISE LAMP | ON/OFF | Indicates [ON/OFF] condition of CRUISE lamp determined by the ECM according to the input signals. | A |
| SET LAMP* | ON/OFF | Indicates [ON/OFF] condition of SET lamp determined by the ECM according to the input signals. | EC |
| ALT DUTY | % | Indicates the duty ratio of the power generation command value. The ratio is calculated by ECM based on the battery current sensor signal. | C |
| BAT CUR SEN | mV | The signal voltage of battery current sensor is displayed. | |
| A/F ADJ-B1 | — | Indicates the correction of a factor stored in ECM. The factor is calculated from the difference between the target air-fuel ratio stored in ECM and the air-fuel ratio calculated from A/F sensor 1 signal. | D |
| P/N POSI SW | ON/OFF | Indicates [ON/OFF] condition from the park/neutral position (PNP) signal. | E |
| INT/A TEMP SE | °C or °F | The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated. | F |
| AC PRESS SEN | V | The signal voltage from the refrigerant pressure sensor is displayed. | G |
| CLUTCH P/P SW | ON/OFF | Indicates [ON/OFF] condition clutch pedal position switch signals. | H |
| VTC DTY EX B1 | % | <ul style="list-style-type: none"> • The control value of the exhaust valve timing control solenoid valve (determined by ECM according to the input signals) is indicated. • The advance angle becomes larger as the value increases. | I |
| THRTL STK CNT B1* | — | — | J |
| EVAP LEAK DIAG | YET/CMPLT | <ul style="list-style-type: none"> • Indicates the condition of EVAP leak diagnosis. YET: EVAP leak diagnosis has not been performed yet. CMPLT: EVAP leak diagnosis has been performed successfully. | K |
| EVAP DIAG READY | ON/OFF | <ul style="list-style-type: none"> • Indicates the ready condition of EVAP leak diagnosis. ON: Diagnosis has been ready condition. OFF: Diagnosis has not been ready condition. | L |
| A/F SEN1 DIAG1(B1) | INCMP/CM-PLT | <ul style="list-style-type: none"> • Indicates DTC P015A or P015B self-diagnosis condition. - INCMP: Self-diagnosis is incomplete. - CMPLT: Self-diagnosis is complete. | M |
| A/F SEN1 DIAG2(B1) | INCMP/CM-PLT | <ul style="list-style-type: none"> • Indicates DTC P014C or P014D self-diagnosis condition. - INCMP: Self-diagnosis is incomplete. - CMPLT: Self-diagnosis is complete. | N |
| A/F SEN1 DIAG3(B1) | ABSNT/PRSNT | <ul style="list-style-type: none"> • Indicates DTC P014C, P014D, P015A or P015B self-diagnosis condition. - ABSNT: The vehicle condition is not within the diagnosis range. - PRSNT: The vehicle condition is within the diagnosis range. | O |
| HO2 S2 DIAG2(B1) | INCMP/CM-PLT | <ul style="list-style-type: none"> • Indicates DTC P0139 self-diagnosis (slow response) condition. - INCMP: Self-diagnosis is incomplete. - CMPLT: Self-diagnosis is complete. | P |
| EOP SENSOR | mV | The signal voltage of EOP sensor is displayed. | |

DIAGNOSIS SYSTEM (ECM)

[HR16DE]

< SYSTEM DESCRIPTION >

| Monitored item | Unit | Description | Remarks |
|--------------------------|---------------------------------------|---|---------|
| HO2 S2 DIAG1(B1) | INCMP/CM-PLT | <ul style="list-style-type: none"> • Indicates DTC P0139 self-diagnosis (delayed response) condition. - INCMP: Self-diagnosis is incomplete. - CMPLT: Self-diagnosis is complete. | |
| SYSTEM 1 DIAGNOSIS A B2 | INCMP/CM-PLT | <ul style="list-style-type: none"> • Indicates DTC P117A self-diagnosis condition. - INCMP: Self-diagnosis is incomplete. - CMPLT: Self-diagnosis is complete. | |
| SYSTEM 1 DIAGNOSIS A B1 | INCMP/CM-PLT | <ul style="list-style-type: none"> • Indicates DTC P117B self-diagnosis condition. - INCMP: Self-diagnosis is incomplete. - CMPLT: Self-diagnosis is complete. | |
| A/GRLL SHTR POSITION | F/CLOSE MOVING F/OPEN UNIDTF | <ul style="list-style-type: none"> • Indicates the status of active grille shutter. - F/CLOSE: Active grille shutter is fully closed. - MOVING: Active grille shutter is in motion. - F/OPEN: Active grille shutter is fully opened. - UNIDTF: Unable to specify the shutter position. | |
| A/GRLL SHTR CALIBRATION | INCMP/CM-PLT | <ul style="list-style-type: none"> • Indicates initial position learning status of active grille shutter. - CMPLT: The leaning is complete. - INCOMP: The learning is incomplete. | |
| A/GRLL SHTR CIRCUIT DIAG | OK/NG | <ul style="list-style-type: none"> • Indicates the diagnosis result of active grille shutter circuit. - OK: Normal. - NG: Malfunction detected. | |
| A/GRLL SHTR TEMP DIAG | OK/NG | <ul style="list-style-type: none"> • Indicates the diagnosis result of active grille shutter actuator temperature status. - OK: Normal - NG: Abnormal temperature detected. | |
| A/GRLL SHTR VOLT DIAG | OK/NG | <ul style="list-style-type: none"> • Indicates the diagnosis result of active grille shutter voltage status. - OK: Normal - NG: Abnormal voltage detected. | |
| A/GRLL SHTR OVER RUN | OK/NG | <ul style="list-style-type: none"> • Indicates active grille shutter moves beyond normal moving limit. - OK: Normal - NG: Malfunction detected. | |
| A/GRLL SHTR STUCK | OK/NG | <ul style="list-style-type: none"> • Indicates the diagnosis result of active grille shutter stuck or the operation range less than normal. - OK: Normal - NG: Malfunction detected. | |
| A/GRLL SHTR CALIB DIAG | OK/NG | <ul style="list-style-type: none"> • Indicates the diagnosis result of initial position learning of active grille shutter. - OK: Normal - NG: Deficiency detected. | |

*: The item is indicated, but not used.

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

WORK SUPPORT MODE

Work Item

DIAGNOSIS SYSTEM (ECM)

< SYSTEM DESCRIPTION >

[HR16DE]

| WORK ITEM | CONDITION | USAGE |
|----------------------------|---|---|
| IDLE AIR VOL LEARN | The idle air volume that keeps the engine within the specified range is memorized in ECM. | When learning the idle air volume |
| EVAP SYSTEM CLOSE | Close the EVAP canister vent control valve in order to make EVAP system close under the following conditions. <ul style="list-style-type: none"> • Ignition switch ON • Engine not running • Ambient temperature is above 0°C (32°F) • No vacuum and no high pressure in EVAP system • Fuel tank temperature is more than 0°C (32°F) • Within 10 minutes after starting "EVAP SYSTEM CLOSE" • When trying to execute "EVAP SYSTEM CLOSE" under the condition except above, CONSULT will discontinue it and display appropriate instruction. NOTE: When starting engine, CONSULT may display "Battery voltage is low. Charge battery", even in using charged battery. | When detecting EVAP vapor leak point of EVAP system |
| FUEL PRESSURE RELEASE | Fuel pump will stop by touching "START" during idling. Crank a few times after engine stalls. | When releasing fuel pressure from fuel line |
| TARGET IDLE RPM ADJ* | Idle condition | When setting target idle speed |
| VIN REGISTRATION | In this mode, VIN is registered in ECM. | When registering VIN in ECM |
| SELF-LEARNING CONT | The coefficient of self-learning control mixture ratio returns to the original coefficient. | When clearing mixture ratio self-learning value |
| TARGET IGN TIM ADJ* | Idle condition | When adjusting target ignition timing |
| CLSD THL POS LEARN | Ignition on and engine stopped. | When learning throttle valve closed position |
| SAVING DATA FOR REPLC CPU | In this mode, save data that is in ECM. | When ECM is replaced. |
| WRITING DATA FOR REPLC CPU | In this mode, write data stored by "SAVE DATA FOR CPU REPLC" in work support mode to EC | When ECM is replaced. |

*: This function is not necessary in the usual service procedure.

ACTIVE TEST MODE

Test Item

| TEST ITEM | CONDITION | JUDGMENT | CHECK ITEM (REMEDY) |
|------------------|---|--|--|
| FUEL INJECTION | <ul style="list-style-type: none"> • Engine: Return to the original trouble condition • Change the amount of fuel injection using CONSULT. | If trouble symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> • Harness and connectors • Fuel injector • Air fuel ratio (A/F) sensor 1 |
| ENG COOLANT TEMP | <ul style="list-style-type: none"> • Engine: Return to the original trouble condition • Change the engine coolant temperature using CONSULT. | If trouble symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> • Harness and connectors • Engine coolant temperature sensor • Fuel injector |
| PURG VOL CONT/V | <ul style="list-style-type: none"> • Engine: After warming up, run engine at 1,500 rpm. • Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT. | Engine speed changes according to the opening percent. | <ul style="list-style-type: none"> • Harness and connectors • Solenoid valve |
| FUEL/T TEMP SEN | Change the fuel tank temperature using CONSULT. | | |
| COOLING FAN* | <ul style="list-style-type: none"> • Ignition switch: ON • Turn the cooling fan "LOW", "HI" and "OFF" CONSULT. | Cooling fan moves and stops. | <ul style="list-style-type: none"> • Harness and connectors • IPDM E/R (Cooling fan relay) • Cooling fan motor |
| ALTERNATOR DUTY | <ul style="list-style-type: none"> • Engine: Idle • Change duty ratio using CONSULT. | Battery voltage changes. | <ul style="list-style-type: none"> • Harness and connectors • IPDM E/R • Alternator |

DIAGNOSIS SYSTEM (ECM)

< SYSTEM DESCRIPTION >

[HR16DE]

| TEST ITEM | CONDITION | JUDGMENT | CHECK ITEM (REMEDY) |
|-----------------------|--|---|---|
| FUEL PUMP RELAY | <ul style="list-style-type: none"> Ignition switch: ON Turn the fuel pump relay "ON" and "OFF" using CONSULT and listen to operating sound. | Fuel pump relay makes the operating sound. | <ul style="list-style-type: none"> Harness and connectors Fuel pump relay |
| IGNITION TIMING | <ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT. | If trouble symptom disappears, see CHECK ITEM. | Perform Idle Air Volume Learning. |
| POWER BALANCE | <ul style="list-style-type: none"> Engine: After warming up, idle the engine. A/C switch OFF Shift lever: P or N (CVT), Neutral (M/T) Cut off each fuel injector signal one at a time using CONSULT. | Engine runs rough or dies. | <ul style="list-style-type: none"> Harness and connectors Compression Fuel injector Power transistor Spark plug Ignition coil |
| VENT CONTROL/V | <ul style="list-style-type: none"> Ignition switch: ON Turn solenoid valve ON and OFF with the CONSULT and listen to operating sound. | Solenoid valve makes an operating sound. | <ul style="list-style-type: none"> Harness and connectors EVAP canister vent control solenoid valve |
| INT V/T ASSIGN ANGLE | <ul style="list-style-type: none"> Engine: Return to the original non-standard condition Change intake valve timing using CONSULT. | If malfunctioning symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> Harness and connectors Intake valve timing control solenoid valve |
| EXH V/T ASSIGN ANGLE | <ul style="list-style-type: none"> Engine: Return to the original non-standard condition Change exhaust valve timing using CONSULT. | If malfunctioning symptom disappears, see CHECK ITEM. | <ul style="list-style-type: none"> Harness and connectors Exhaust valve timing control solenoid valve |
| ACTIVE GRILLE SHUTTER | <p>NOTE: Initial position learning is required every time when the ignition switch is turned OFF.</p> <ol style="list-style-type: none"> Engine: Idle speed Touch "CALIBRTN" to perform initial position learning. Touch "OPEN" or "CLOSE" to operate active grille shutter. | Active grille shutter fully opens or fully closes. | <ul style="list-style-type: none"> Harness or connector Active grille shutter actuator Active grille shutter |

*: Leaving cooling fan OFF with CONSULT while engine is running may cause the engine to overheat.

DTC WORK SUPPORT MODE

Test Item

| Test mode | Test item | Corresponding DTC No. | Reference page |
|--------------------|--------------------------|-----------------------|-------------------------------------|
| A/F SEN1 | A/F SEN1 (B1) P1276 | P0130 | EC-210, "DTC Logic" |
| EVAPORATIVE SYSTEM | EVP V/S LEAK P0456/P1456 | P0456 | EC-319, "DTC Logic" |
| | PURG FLOW P0441 | P0441 | EC-287, "DTC Logic" |
| | PURG VOL CN/V P1444 | P0443 | EC-292, "DTC Logic" |
| HO2S2 | HO2S2 (B1) P1146 | P0138 | EC-226, "DTC Logic" |
| | HO2S2 (B1) P1147 | P0137 | EC-220, "DTC Logic" |
| | HO2S2 (B1) P0139 | P0139 | EC-234, "DTC Logic" |

SRT & P-DTC MODE

SRT STATUS Mode

- For items whose SRT codes are set, "CMPLT" is displayed on the CONSULT screen; for items whose SRT codes are not set, "INCMP" is displayed.
- "SRT STATUS" provides the presence or absence of permanent DTCs stored in ECM memory.

< SYSTEM DESCRIPTION >

PERMANENT DTC STATUS Mode

How to display permanent DTC status

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select "PERMANENT DTC STATUS" in "DTC & SRT CONFIRMATION" mode with CONSULT.

NOTE:

Permanent DTCs stored in ECM memory are displayed on the CONSULT screen to show if a driving pattern required for erasing permanent DTCs is complete (CMPLT) or incomplete (INCMP).

CAUTION:

Since the "PERMANENT DTC STATUS" screen displays the previous trip information, repeat the following twice to update the information: "Ignition switch OFF", "Wait for more than 10 seconds" and "Ignition switch ON".

| PERMANENT DTC & SRT CONFIRMATION : PERMANENT DTC STATUS | | |
|--|-------------------|-------------------|
| <p>CAUTION: Turn ignition switch from ON to OFF twice to update the information on the status screen.</p> | | |
| PERMANENT DTC | DRIVING PATTERN B | DRIVING PATTERN D |
| XXXX | INCMP | INCMP |
| XXXX | CMPLT | INCMP |
| XXXX | INCMP | CMPLT |
| XXXX | CMPLT | INCMP |
| XXXX | INCMP | INCMP |
| XXXX | INCMP | INCMP |
| <p>The previous trip information is displayed. </p> | | |

JSBIA0062GB

NOTE:

This mode is not used in regions that permanent DTCs are not regulated by law.

SRT WORK SUPPORT Mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

PERMANENT DTC WORK SUPPORT Mode

This mode enables a technician to drive a vehicle to complete the driving pattern that is required for erasing permanent DTC.

NOTE:

This mode is not used in regions that permanent DTCs are not regulated by law.

ECU DIAGNOSIS INFORMATION

ECM

Reference Value

INFOID:000000009020642

VALUES ON THE DIAGNOSIS TOOL

NOTE:

- The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.
- Numerical values in the following table are reference values.
- These values are input/output values that ECM receives/transmits and may differ from actual operations.
Example: The ignition timing shown by the timing light may differ from the ignition timing displayed on the data monitor.
This occurs because the timing light shows a value calculated by ECM according to signals received from the camshaft position sensor and other sensors related to ignition timing.
- For outlines of following items, refer to [EC-60. "CONSULT Function"](#).

| Monitor Item | Condition | | Values/Status |
|-----------------|--|---------------------------------------|---|
| IDLE REQUEST | NOTE: The item is indicated, but not used. | | |
| MIL ON REQUEST | NOTE: The item is indicated, but not used. | | |
| ENGINE NO-LOAD | NOTE: The item is indicated, but not used. | | |
| READY STATE | NOTE: The item is indicated, but not used. | | |
| ENG SPEED | • Run engine and compare CONSULT value with the tachometer indication. | | Almost the same speed as the tachometer indication. |
| MAS A/F SE-B1 | See EC-149. "Description" . | | |
| B/FUEL SCHDL | See EC-149. "Description" . | | |
| A/F ALPHA-B1 | See EC-149. "Description" . | | |
| COOLAN TEMP/S | • Engine: After warming up | | More than 70°C (158F) |
| A/F SEN1 (B1) | • Engine: After warming up | Maintaining engine speed at 2,000 rpm | Fluctuates around 2.2 V |
| HO2S2 (B1) | • Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. | | 0 - 0.3 V ←→ Approx. 0.6 - 1.0 V |
| HO2S2 MNTR (B1) | - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load | | LEAN ←→ RICH |
| VHCL SPEED SE | • Turn drive wheels and compare CONSULT value with the speedometer indication. | | Almost the same speed as speedometer indication |
| BATTERY VOLT | • Ignition switch: ON (Engine stopped) | | 11 - 14 V |
| ACCEL SEN 1 | • Ignition switch: ON (Engine stopped) | Accelerator pedal: Fully released | 0.6 - 0.9 V |
| | | Accelerator pedal: Fully depressed | 4.0 - 4.8 V |
| ACCEL SEN 2 | • Ignition switch: ON (Engine stopped) | Accelerator pedal: Fully released | 0.6 - 0.9 V |
| | | Accelerator pedal: Fully depressed | 3.9 - 4.8 V |
| TP SEN 1-B1 | • Ignition switch: ON (Engine stopped) • Shift lever: 1st | Accelerator pedal: Fully released | More than 0.36 V |
| | | Accelerator pedal: Fully depressed | Less than 4.75 V |
| TP SEN 2-B1 | • Ignition switch: ON (Engine stopped) • Shift lever: 1st | Accelerator pedal: Fully released | More than 0.36 V |
| | | Accelerator pedal: Fully depressed | Less than 4.75 V |
| FUEL T/TMP SE | • Ignition switch: ON | | Indicates fuel tank temperature |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Monitor Item | Condition | Values/Status | |
|---------------|--|--|-------------------------------|
| EVAP SYS PRES | • Ignition switch: ON | Approx. 1.8 - 4.8 V | |
| FUEL LEVEL SE | • Ignition switch: ON | Depending on fuel level of fuel tank | |
| START SIGNAL | • Ignition switch: ON → START → ON | OFF → ON → OFF | |
| CLSD THL POS | • Ignition switch: ON (Engine stopped) | Accelerator pedal: Fully released | ON |
| | | Accelerator pedal: Slightly depressed | OFF |
| AIR COND SIG | • Engine: After warming up, idle the engine | Air conditioner switch: OFF | OFF |
| | | Air conditioner switch: ON (Compressor operates.) | ON |
| PW/ST SIGNAL | • Engine: After warming up, idle the engine | Steering wheel: Not being turned | OFF |
| | | Steering wheel: Being turned | ON |
| LOAD SIGNAL | • Ignition switch: ON | Rear window defogger switch: ON and/or Lighting switch: 2nd position | ON |
| | | Rear window defogger switch and lighting switch: OFF | OFF |
| IGNITION SW | • Ignition switch: ON → OFF → ON | ON → OFF → ON | |
| HEATER FAN SW | • Engine: After warming up, idle the engine | Heater fan switch: ON | ON |
| | | Heater fan switch: OFF | OFF |
| BRAKE SW | • Ignition switch: ON | Brake pedal: Fully released | OFF |
| | | Brake pedal: Slightly depressed | ON |
| INJ PULSE-B1 | • Engine: After warming up • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Idle | 2.0 - 3.0 msec |
| | | 2,000 rpm | 1.9 - 2.9 msec |
| IGN TIMING | • Engine: After warming up • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Idle | 4°BTDC (CVT) 10°BTDC (M/T) |
| | | 2,000 rpm | 25° - 45°BTDC |
| CAL/LD VALUE | • Engine: After warming up • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Idle | 10% - 35% |
| | | 2,500 rpm | 10% - 35% |
| MASS AIRFLOW | • Engine: After warming up • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Idle | 0.8 - 4.0 g/s |
| | | 2,500 rpm | 2.0 - 10.0 g/s |
| PURG VOL C/V | • Engine: After warming up • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Idle | 0% |
| | | 2,000 rpm | 0% - 50% |
| INT/V TIM(B1) | • Engine: After warming up • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Idle | -5° - 5°CA |
| | | When revving engine up to 2,000rpm Quickly | Approx. 0° - 40°CA |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Monitor Item | Condition | | Values/Status |
|-----------------|---|---|--|
| EXH/V TIM B1 | <ul style="list-style-type: none"> Engine: After warming up Selector lever position: P or N (CVT) or Neutral (M/T) Air conditioner switch: OFF No load | Idle | -5° - 5°C |
| | | When revving engine up to 2,000rpm Quickly | Approx. 0° - 40°C |
| INT/V SOL(B1) | <ul style="list-style-type: none"> Engine: After warming up Selector lever position: P or N (CVT) or Neutral (M/T) Air conditioner switch: OFF No load | Idle | 0% - 2% |
| | | When revving engine up to 2,000rpm Quickly | Approx. 0% - 90% |
| AIR COND RLY | <ul style="list-style-type: none"> Engine: After warming up, idle the engine | Air conditioner switch: OFF | OFF |
| | | Air conditioner switch: ON (Compressor operates.) | ON |
| FUEL PUMP RLY | <ul style="list-style-type: none"> For 1 seconds after turning ignition switch: ON Engine running or cranking | | ON |
| | | <ul style="list-style-type: none"> Except above | OFF |
| VENT CONT/V | <ul style="list-style-type: none"> Ignition switch: ON | | OFF |
| THRTL RELAY | <ul style="list-style-type: none"> Ignition switch: ON | | ON |
| COOLING FAN | <ul style="list-style-type: none"> Engine: After warming up, idle the engine Air conditioner switch: OFF | Engine coolant temperature is 98°C (208°F) or less | OFF |
| | | Engine coolant temperature is between 98°C (208°F) and 99°C (210°F) | LOW |
| | | Engine coolant temperature is 100°C (212°F) or more | HIGH |
| HO2S2 HTR (B1) | <ul style="list-style-type: none"> Engine speed: Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load | | ON |
| ALT DUTY SIG | <ul style="list-style-type: none"> Power generation voltage variable control: Operating Power generation voltage variable control: Not operating | | ON |
| | | | OFF |
| I/P PULLY SPD | <ul style="list-style-type: none"> Vehicle speed: More than 20 km/h (12 MPH) | | Almost the same speed as the tachometer indication |
| VEHICLE SPEED | <ul style="list-style-type: none"> Turn drive wheels and compare CONSULT value with the speedometer indication. | | Almost the same speed as speedometer indication |
| IDL A/V LEARN | <ul style="list-style-type: none"> Engine: running | Idle air volume learning has not been performed yet. | YET |
| | | Idle air volume learning has already been performed successfully. | CMPLT |
| TRVL AFTER MIL | <ul style="list-style-type: none"> Ignition switch: ON | Vehicle has traveled after MI has turned ON. | 0 - 65,535 km (0 - 40,723 miles) |
| ENG OIL TEMP | <ul style="list-style-type: none"> Engine: After warming up | | More than 70°C (158F) |
| A/F S1 HTR (B1) | <ul style="list-style-type: none"> Engine: After warming up, idle the engine (More than 140 seconds after starting engine) | | 4 - 100% |
| VHCL SPEED SE | <ul style="list-style-type: none"> Turn drive wheels and compare CONSULT value with the speedometer indication. | | Almost the same speed as speedometer indication |
| SET VHCL SPD | <ul style="list-style-type: none"> Engine: Running | ASCD: Operating | The preset vehicle speed is displayed |
| MAIN SW | <ul style="list-style-type: none"> Ignition switch: ON | MAIN switch: Pressed | ON |
| | | MAIN switch: Released | OFF |
| CANCEL SW | <ul style="list-style-type: none"> Ignition switch: ON | CANCEL switch: Pressed | ON |
| | | CANCEL switch: Released | OFF |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Monitor Item | Condition | Values/Status |
|----------------------------------|--|--|
| RESUME/ACC SW | • Ignition switch: ON | ACCEL/RES switch: Pressed ON |
| | | ACCEL/RES switch: Released OFF |
| SET SW | • Ignition switch: ON | COAST/SET switch: Pressed ON |
| | | COAST/SET switch: Released OFF |
| BRAKE SW1 (ASCD brake switch) | • Ignition switch: ON | COAST/SET switch: Pressed ON |
| | | COAST/SET switch: Released OFF |
| BRAKE SW2 (Stop lamp switch) | • Ignition switch: ON | Brake pedal: Fully released OFF |
| | | Brake pedal: Slightly depressed ON |
| VHCL SPD CUT | • Ignition switch: ON | NON |
| LO SPEED CUT | • Ignition switch: ON | NON |
| AT OD MONITOR | • Ignition switch: ON | OFF |
| AT OD CANCEL | • Ignition switch: ON | OFF |
| CRUISE LAMP | • Ignition switch: ON | MAIN switch: Pressed at the 1st time → at the 2nd time ON → OFF |
| SET LAMP | NOTE: The item is indicated, but not used. | |
| ALT DUTY | • Engine: Idle | 0 - 80% |
| BAT CUR SEN | • Engine speed: Idle • Battery: Fully charged • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Approx 2,500 - 3,500 mV |
| A/F ADJ-B1 | • Engine running | -0.330 - 0.330 |
| P/N POSI SW | • Ignition switch: ON | Selector lever position: P or N (CVT) or Neutral (M/T) ON |
| | | Shift lever: Except above OFF |
| INT/A TEMP SE | • Ignition switch: ON | Indicates intake air temperature |
| AC PRESS SEN | • Engine: Idle • Both A/C switch and blower fan switch: ON (Compressor operates.) | 1.0 - 4.0 V |
| CLUTCH P/P SW | • Ignition switch: ON | Clutch pedal: Fully released OFF |
| | | Clutch pedal: Fully depressed ON |
| VTC DTY EX B1 | • Engine: After warming up • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Idle 0% - 2% |
| | | 2,000 rpm Approx. 0% - 90% |
| THRTL STK CNT B1 | NOTE: The item is indicated, but not used. | |
| EVAP LEAK DIAG | • Ignition switch: ON | Depending on condition of EVAP leak diagnosis |
| EVAP DIAG READY | • Ignition switch: ON (READY) | Depending on ready condition of EVAP leak diagnosis |
| A/F SEN1 DIAG1(B1) | • DTC P015A and P015B self-diagnosis is incomplete. | INCMP |
| | • DTC P015A and P015B self-diagnosis is complete. | CMPLT |
| A/F SEN1 DIAG2(B1) | • DTC P014C and P014D self-diagnosis is incomplete. | INCMP |
| | • DTC P014C and P014D self-diagnosis is complete. | CMPLT |

ECM


< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Monitor Item | Condition | Values/Status |
|------------------------------|--|--------------------------------------|
| A/F SEN1 DIAG3(B1) | • The vehicle condition is not within the diagnosis range of DTC P014C, P014D, P015A or P015B. | ABSNT |
| | • The vehicle condition is within the diagnosis range of DTC P014C, P014D, P015A or P015B. | PRSNT |
| HO2 S2 DIAG2(B1) | • DTC P0139 self-diagnosis (slow response) is incomplete. | INCOMP |
| | • DTC P0139 self-diagnosis (slow response) is complete. | CMPLT |
| SYSTEM 1 DIAG- NOSIS A B1 | DTC P117A self-diagnosis is incomplete. | INCOMP |
| | DTC P117A self-diagnosis is complete. | CMPLT |
| SYSTEM 1 DIAG- NOSIS B B1 | DTC P117A self-diagnosis is on standby. | ABSENT |
| | DTC P117A self-diagnosis is under diagnosis. | PRSENT |
| EOP SENSOR | • Engine: After warming up • Selector lever position: P or N (CVT) or Neutral (M/T) • Air conditioner switch: OFF • No load | Idle Approx 1,000 - 2,000 mV |
| | | 2,000 rpm Approx 1,500 - 3,500 mV |
| HO2 S2 DIAG1(B1) | • DTC P0139 self-diagnosis (delayed response) is incomplete. | INCOMP |
| | • DTC P0139 self-diagnosis (delayed response) is complete. | CMPLT |
| A/GRLL SHTRR PO- SITION | • Engine RPM: idle speed. • Vehicle speed: 0 km/h (0 MPH). | F/OPEN |
| | • Vehicle speed: 30 km/h (19 MPH) or faster. (Comply the condition of active grille shutter operation). | F/OPEN →MOVING→F/ CLOSE |
| A/GRLL SHTRR CALIBRATION | • Turn ignition switch OFF→ ON • Drive the vehicle at a speed more than 6 km/h (4 MPH) for the first time. | CMPLT |
| | • Turn ignition switch OFF → ON. • When the vehicle speed does not reach 6 km/h (4 MPH). | INCOMP |
| A/GRLL SHTRR CIRCUIT DIAG | • Malfunction of active grill shutter power supply is detected. | NG |
| | • Malfunction of active grill shutter power supply is not detected. | OK |
| A/GRLL SHTRR TEMP DIAG | • Abnormal temperature of active grill shutter actuator is detected. | NG |
| | • Abnormal temperature of active grill shutter actuator is not detected. | OK |
| A/GRLL SHTRR VOLT DIAG | • Abnormal voltage of active grill shutter circuit is detected. | NG |
| | • Abnormal voltage of active grill shutter circuit is not detected. | OK |
| A/GRLL SHTRR OVERRUN | • Active grill shutter does not stop within normal moving limit. | NG |
| | • Active grill shutter stops within normal moving limit | OK |
| A/GRLL SHTRR STUCK | • Detecting the active grille shutter stuck or the operation range less than normal. | NG |
| | • Not detecting the active grille shutter stuck or the operation range less than normal. | OK |
| A/GRLL SHTRR CALIB DIAG | • Malfunction of active grill shutter initial position learning is detected. | NG |
| | • Malfunction of active grill shutter initial position learning is not detected. | OK |

*: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

TERMINAL LAYOUT



PHYSICAL VALUES

NOTE:






- Connect a break-out box and harness adapter between the ECM and ECM harness connector.
- Use extreme care not to touch 2 pins at one time.
- Data is for comparison and may not be exact.
- Specification data are reference values and are measured between each terminals.
- Pulse signal is measured by CONSULT.

| Terminal No. | | Description | | Condition | Value (Approx.) |
|--------------|---------|-------------------------------------|--------------|--|-----------------------------|
| + | - | Signal name | Input/Output | | |
| 1 (L) | 108 (B) | Throttle control motor (Open) | Output | [Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed | 2.6 V★ |
| 2 (L/W) | 108 (B) | Throttle control motor power supply | Input | [Ignition switch: ON] | BATTERY VOLTAGE (11 - 14 V) |
| 3 (G/W) | 108 (B) | A/F sensor 1 heater | Output | [Engine is running] • Warm-up condition • Idle speed (More than 140 seconds after starting engine) | 2.9 - 8.8 V★ |
| 4 (P) | 108 (B) | Throttle control motor (Close) | Output | [Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released | 1.8 V★ |

ECM

< ECU DIAGNOSIS INFORMATION >




[HR16DE]

| Terminal No. | | Description | | Condition | Value (Approx.) |
|--|-------------|---|--------------|--|---|
| + | - | Signal name | Input/Output | | |
| 5 (BR/W) | 59 (L/Y) | Heated oxygen sensor 2 heater | Output | [Engine is running] <ul style="list-style-type: none"> • Engine speed: Below 3,600 rpm after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load | 10 V★  |
| | | | | [Ignition switch: ON] <ul style="list-style-type: none"> • Engine stopped [Engine is running] <ul style="list-style-type: none"> • Engine speed: Above 3,600 rpm | BATTERY VOLTAGE (11 - 14 V) |
| 9 (SB) | 108 (B) | EVAP canister purge volume control solenoid valve | Output | [Engine is running] <ul style="list-style-type: none"> • Idle speed | BATTERY VOLTAGE (11 - 14 V)★  |
| | | | | [Engine is running] <ul style="list-style-type: none"> • Engine speed: About 2,000 rpm (More than 100 seconds after starting engine.) | BATTERY VOLTAGE (11 - 14 V)★  |
| 10 (B) | — | ECM ground | — | — | — |
| 11 (B/Y) | — | ECM ground | — | — | — |
| 12 (L/W) 16 (G) 20 (O/W) 24 (R) | 108 (B) | Fuel injector No. 1 (Rear) | Output | [Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle | BATTERY VOLTAGE (11 - 14 V)★  |
| 25 (R) 29 (G) 30 (O) 31 (L) | | Fuel injector No. 4 (Front) | | [Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Engine speed: 2,000 rpm | BATTERY VOLTAGE (11 - 14 V)★  |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]



| Terminal No. | | Description | | Condition | Value (Approx.) |
|--------------|------------|--|--------------|--|---|
| + | - | Signal name | Input/Output | | |
| 15 (G/W) | 108 (B) | Throttle control motor relay | Output | [Ignition switch: OFF] | BATTERY VOLTAGE (11 - 14 V) |
| | | | | [Ignition switch: ON] | 0 - 1.0 V |
| 17 (V) | 108 (B) | Ignition signal No. 1 | Output | [Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle | 0 - 0.3 V★ |
| 18 (Y/B) | | Ignition signal No. 2 | | |  |
| 21 (W) | | Ignition signal No. 4 | | |  |
| 22 (BR) | | Ignition signal No. 3 | | |  |
| 23 (GR) | 108 (B) | Fuel pump relay | Output | [Ignition switch: ON] • For 1 second after turning ignition switch ON | 0 - 1.0 V |
| | | | | [Ignition switch: ON] • More than 1 second after turning ignition switch ON | BATTERY VOLTAGE (11 - 14 V) |
| 26 (P) | 108 (B) | EVAP canister vent control valve | Output | [Ignition switch: ON] | BATTERY VOLTAGE (11 - 14 V) |
| 32 (P) | 108 (B) | ECM relay (Self shut-off) | Output | [Engine is running] [Ignition switch: OFF] • A few seconds after turning ignition switch OFF | 0 - 1.0 V |
| | | | | [Ignition switch: OFF] • More than a few seconds after turning ignition switch OFF | BATTERY VOLTAGE (11 - 14 V) |
| 33 (W) | 36 (R) | Throttle position sensor 1 | Input | [Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released | More than 0.36 V |
| | | | | [Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed | Less than 4.75 V |
| 34 (B) | 36 (R) | Throttle position sensor 2 | Input | [Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released | Less than 4.75 V |
| | | | | [Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed | More than 0.36 V |
| 36 (R) | — | Sensor ground (Throttle position sensor) | — | — | — |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >



[HR16DE]

| Terminal No. | | Description | | Condition | Value (Approx.) |
|--------------|-------------|---|--------------|--|---|
| + | - | Signal name | Input/Output | | |
| 37 (W) | 40 (L) | Knock sensor | Input | [Engine is running] • Idle speed | 2.5 V |
| 38 (LG/V) | 44 (P) | Engine coolant temperature sensor | Input | [Engine is running] | 0 - 4.8 V Output voltage varies with engine coolant temperature. |
| 39 (L) | 68 (R) | Battery temperature sensor | Input | [Engine is running] • Battery temperature: 25°C (°F) • Idle speed | 3.5 V |
| 40 (L) | — | Sensor ground (Knock sensor shield circuit) | — | — | — |
| 42 (L) | 51 (P) | Fuel tank temperature sensor | Input | [Engine is running] | 0 - 4.8 V Output voltage varies with fuel tank temperature. |
| 43 (SB) | 68 (R) | EVAP control system pressure sensor | Input | [Ignition switch: ON] | 0.5 - 4.6 V |
| 44 (P) | — | Sensor ground (Engine coolant temperature sensor) | — | — | — |
| 45 (G/B) | 52 (LG) | Mass air flow sensor | Input | [Ignition switch ON] • Engine stopped | 0.4 V |
| | | | | [Engine is running] • Warm-up condition • Idle speed | 0.8 - 1.3 V |
| | | | | [Engine is running] • Warm-up condition • Engine is revving from idle to about 4,000 rpm | 0.8 - 1.3 to 2.4 V (Check for linear voltage rise in response to engine being increased to about 4,000 rpm.) |
| 46 (V) | 55 (G/L) | Intake air temperature sensor | Input | [Engine is running] | 0 - 4.8 V Output voltage varies with intake air temperature. |
| 47 (Y) | 60 (L) | Engine oil pressure sensor | Input | [Engine is running] • Warm-up condition • Idle speed | 1.0 - 2.0 V |
| | | | | [Engine is running] • Warm-up condition • Engine speed: 2,000 rpm | 1.5 - 3.5 V |
| 48 (W/R) | 63 (W) | Exhaust valve timing control position sensor | Input | [Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle | 4.3 V★  |
| | | | | [Engine is running] • Engine speed: 2,000 rpm | 4.3 V★  |
| 49 (G/W) | 108 (B) | A/F sensor 1 | Input | [Ignition switch: ON] | 2.2 V |

ECM




< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Terminal No. | | Description | | Condition | Value (Approx.) |
|--------------|----------|---|--------------|---|---|
| + | - | Signal name | Input/Output | | |
| 50 (L/R) | 59 (L/Y) | Heated oxygen sensor 2 | Input | [Engine is running] • Revving engine from idle to 3,000 rpm quickly after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load | 0 - 1.0 V |
| 51 (P) | — | Sensor ground (Fuel tank temperature sensor) | — | — | — |
| 52 (LG) | — | Sensor ground (Mass air flow sensor) | — | — | — |
| 53 (L) | 108 (B) | A/F sensor 1 | Input | [Engine is running] • Warm-up condition • Engine speed: 2,500 rpm | 1.8 V Output voltage varies with air fuel ratio. |
| 54 (BR) | — | Sensor ground (Engine oil temperature sensor) | — | — | — |
| 55 (G/L) | — | Sensor ground (Intake air temperature sensor) | — | — | — |
| 57 (P) | 54 (BR) | Engine oil temperature sensor | Input | [Engine is running] | 0 - 4.8 V Output voltage varies with engine oil temperature. |
| 58 (BR) | 68 (R) | Battery current sensor | Input | [Engine is running] • Battery: Fully charged* • Idle speed | 2.6 - 3.5 V |
| 59 (L/Y) | — | Sensor ground (Heated oxygen sensor 2) | — | — | — |
| 60 (L) | — | Sensor ground (Engine oil pressure sensor) | — | — | — |
| 61 (L/O) | 62 (G) | Crankshaft position sensor | Input | [Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle | 4.0 V★  |
| | | | | [Engine is running] • Engine speed: 2,000 rpm | 4.0 V★  |
| 62 (G) | — | Sensor ground (Crankshaft position sensor) | — | — | — |
| 63 (W) | — | Sensor ground (Camshaft position sensor) | — | — | — |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P


< ECU DIAGNOSIS INFORMATION >

| Terminal No. | | Description | | Condition | Value (Approx.) |
|--------------|------------|--|--------------|--|--|
| + | - | Signal name | Input/Output | | |
| 65 (R/W) | 63 (W) | Camshaft position sensor | Input | [Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle | 4.3 V★  |
| | | | | [Engine is running] • Engine speed is 2,000 rpm | 4.3 V★  |
| 68 (R) | — | Sensor ground (EVAP control system pressure sensor, battery current sensor, battery temperature sensor) | — | — | — |
| 69 (BR) | 108 (B) | Park/Neutral position signal | Input | [Ignition switch: ON] • Shift lever: Neutral | BATTERY VOLTAGE (11 - 14 V) |
| | | | | [Ignition switch: ON] • Shift lever: Except above position | 0 V |
| 70 (L/Y) | — | Engine communication line | Input/Output | — | — |
| 71 (Y) | 68 (R) | Sensor power supply (EVAP control system pressure sensor, battery current sensor, battery temperature sensor) | — | [Ignition switch: ON] | 5 V |
| 72 (W/R) | 36 (R) | Sensor power supply (Throttle position sensor) | — | [Ignition switch: ON] | 5 V |
| 73 (P) | 108 (B) | Intake valve timing control solenoid valve | Output | [Engine is running] • Warm-up condition • Idle speed | BATTERY VOLTAGE (11 - 14 V) |
| | | | | [Engine is running] • Warm-up condition • When revving engine up to 2,000rpm quickly | 7 - 10 V★  |
| 74 (O) | 60 (L) | Sensor power supply (Engine oil pressure sensor) | — | [Ignition switch: ON] | 5 V |
| 75 (O) | 62 (G) | Sensor power supply (Crankshaft position sensor) | — | [Ignition switch: ON] | 5 V |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Terminal No. | | Description | Input/ Output | Condition | Value (Approx.) |
|--------------|------------|--|------------------|---|--|
| + | - | Signal name | | | |
| 77 (P/W) | 108 (B) | Exhaust valve timing control solenoid valve | Output | [Engine is running] • Warm-up condition • Idle speed | BATTERY VOLTAGE (11 - 14 V) |
| | | | | [Engine is running] • Warm-up condition • When revving engine up to 2,000rpm quickly | 7 - 10 V★  |
| 78 (BR) | 63 (W) | Sensor power supply (Camshaft position sensor) | — | [Ignition switch: ON] | 5 V |
| 81 (V) | 108 (B) | Power supply for ECM (Back-up) | Input | [Ignition switch: OFF] | BATTERY VOLTAGE (11 - 14 V) |
| 83 (P) | — | CAN-L | Input/ Output | — | — |
| 84 (L) | — | CAN-H | Input/ Output | — | — |
| 85 (V) | 98 (LG) | Refrigerant pressure sensor | Input | [Engine is running] • Warm-up condition • Both A/C switch and blower fan switch: ON (Compressor operates) | 1.0 - 4.0 V |
| 88 (GR) | — | Data link connector | Input/ Output | — | — |
| 92 (R) | — | Clutch pedal position switch | Input | [Ignition switch: ON] • Clutch pedal: Fully released | 0 V |
| | | | | [Ignition switch: ON] • Clutch pedal: Fully depressed | BATTERY VOLTAGE (11 - 14 V) |
| 93 (L) | 108 (B) | Ignition switch | Input | [Ignition switch: OFF] | 0 V |
| | | | | [Ignition switch: ON] | BATTERY VOLTAGE (11 - 14 V) |
| 94 (Y) | 95 (B) | ASCD steering switch | Input | [Ignition switch: ON] • ASCD steering switch: OFF | 4 V |
| | | | | [Ignition switch: ON] • MAIN switch: Pressed | 0 V |
| | | | | [Ignition switch: ON] • CANCEL switch: Pressed | 1 V |
| | | | | [Ignition switch: ON] • ACCEL/RES switch: Pressed | 3 V |
| | | | | [Ignition switch: ON] • COAST/SET switch: Pressed | 2 V |
| 95 (B) | — | Sensor ground (ASCD steering switch) | — | — | — |
| 98 (LG) | — | Sensor ground (Refrigerant pressure sensor) | — | — | — |
| 99 (LG) | 108 (B) | Stop lamp switch | Input | [Ignition switch: OFF] • Brake pedal: Fully released | 0 V |
| | | | | [Ignition switch: OFF] • Brake pedal: Slightly depressed | BATTERY VOLTAGE (11 - 14 V) |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Terminal No. | | Description | | Condition | Value (Approx.) |
|--------------|---------|---|--------------|---|-----------------------------|
| + | - | Signal name | Input/Output | | |
| 100 (G) | 108 (B) | Brake pedal position switch | Input | [Ignition switch: OFF] • Brake pedal: Fully released | BATTERY VOLTAGE (11 - 14 V) |
| | | | | [Ignition switch: OFF] • Brake pedal: Slightly depressed | 0 V |
| 101 (W) | 98 (LG) | Sensor power supply (Refrigerant pressure sensor) | — | [Ignition switch: ON] | 5 V |
| 102 (BR) | 104 (Y) | Sensor power supply (Accelerator pedal position sensor 2) | — | [Ignition switch: ON] | 5 V |
| 103 (GR) | 104 (Y) | Accelerator pedal position sensor 2 | Input | [Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released | 0.3 - 0.6 V |
| | | | | [Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed | 1.95 - 2.4 V |
| 104 (Y) | — | Sensor ground (Accelerator pedal position sensor 2) | — | — | — |
| 105 (G) | 108 (B) | Power supply for ECM | Input | [Ignition switch: ON] | BATTERY VOLTAGE (11 - 14 V) |
| 106 (V) | 111 (P) | Sensor power supply (Accelerator pedal position sensor 1) | — | [Ignition switch: ON] | 5 V |
| 108 (B) | — | ECM ground | — | — | — |
| 110 (SB) | 111 (P) | Accelerator pedal position sensor 1 | Input | [Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released | 0.6 - 0.9 V |
| | | | | [Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed | 3.9 - 4.7 V |
| 111 (P) | — | Sensor ground (Accelerator pedal position sensor 1) | — | — | — |

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

*: Before measuring the terminal voltage, confirm that the battery is fully charged. Refer to [PG-61, "Work Flow"](#).

Fail Safe

INFOID:000000009020643

NON DTC RELATED ITEM

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Detected items | Engine operating condition in fail-safe mode | Remarks | Reference page |
|-------------------------------|--|--|--|
| Malfunction indicator circuit | Engine speed will not rise more than 2,500 rpm due to the fuel cut | When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system. Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by means of operating fail safe function. The fail safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction. | EC-444, "Component Function Check" |

DTC RELATED ITEM

| DTC No. | Detected items | Engine operating condition in fail safe mode | | | | | | | | |
|---|--|--|-----------|--|---|--------------|---|--------------|-----------------------|--|
| U0101 | CAN communication line | ECM operates active grille shutter to fully-open position. | | | | | | | | |
| U0284 | Active grille shutter | ECM operates active grille shutter to fully-open position. | | | | | | | | |
| U1040 | Engine communication line | ECM operates active grille shutter to fully-open position. | | | | | | | | |
| P0011 | Intake valve timing control | The signal is not energized to the intake valve timing control solenoid valve and the valve control does not function. | | | | | | | | |
| P0014 | Exhaust valve timing control | The signal is not energized to the exhaust valve timing control solenoid valve and the valve control does not function. | | | | | | | | |
| P0101 P0102 P0103 | Mass air flow sensor circuit | Engine speed will not rise more than 2,400 rpm due to the fuel cut. | | | | | | | | |
| P0117 P0118 | Engine coolant temperature sensor circuit | Engine coolant temperature will be determined by ECM based on the following conditions. CONSULT displays the engine coolant temperature decided by ECM. <table border="1" style="width: 100%; margin-top: 5px;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th style="width: 40%;">Engine coolant temperature decided (CONSULT display)</th> </tr> </thead> <tbody> <tr> <td>Just as ignition switch is turned ON or START</td> <td style="text-align: center;">40°C (104°F)</td> </tr> <tr> <td>Approx. 4 minutes or more after engine starting</td> <td style="text-align: center;">80°C (176°F)</td> </tr> <tr> <td>Except as shown above</td> <td style="text-align: center;">40 - 80°C (104 - 176°F) (Depends on the time)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> When the fail safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running. ECM operates active grille shutter to fully-open position. | Condition | Engine coolant temperature decided (CONSULT display) | Just as ignition switch is turned ON or START | 40°C (104°F) | Approx. 4 minutes or more after engine starting | 80°C (176°F) | Except as shown above | 40 - 80°C (104 - 176°F) (Depends on the time) |
| Condition | Engine coolant temperature decided (CONSULT display) | | | | | | | | | |
| Just as ignition switch is turned ON or START | 40°C (104°F) | | | | | | | | | |
| Approx. 4 minutes or more after engine starting | 80°C (176°F) | | | | | | | | | |
| Except as shown above | 40 - 80°C (104 - 176°F) (Depends on the time) | | | | | | | | | |
| P0116 P0125 | Engine coolant temperature sensor | ECM operates active grille shutter to fully-open position. | | | | | | | | |
| P0122 P0123 P0222 P0223 P2135 | Throttle position sensor | ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor. | | | | | | | | |
| P0196 P0197 P0198 | Engine oil temperature sensor | <ul style="list-style-type: none"> Exhaust valve timing control does not function. ECM operates active grille shutter to fully-open position. | | | | | | | | |
| P0500 | Vehicle speed sensor | <ul style="list-style-type: none"> The cooling fan operates (Highest) while engine is running. ECM operates active grille shutter to fully-open position. | | | | | | | | |
| P0524 | Engine oil pressure | <ul style="list-style-type: none"> ECM illuminates oil pressure warning lamp on the combination meter. Engine speed will not rise more than 4,000 rpm due to the fuel cut. Fail-safe is canceled when ignition switch OFF → ON. | | | | | | | | |
| P059F | Active grille shutter | <ul style="list-style-type: none"> When a voltage and temperature related malfunction is detected, the active grille shutter stops at the position of detection. Except for the above case, operates the active grille shutter to fully closed position. | | | | | | | | |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| DTC No. | Detected items | Engine operating condition in fail safe mode | |
|---|------------------------------------|--|-------------------|
| P0605 | ECM | (When ECM calculation function is malfunctioning.) ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring. | |
| P0607 | ECM | ECM operates active grille shutter to fully-open position. | |
| P0643 | Sensor power supply | ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring. | |
| P1720 | Vehicle speed sensor | ECM operates active grille shutter to fully-open position. | |
| P1805 | Brake switch | ECM controls the electric throttle control actuator by regulating the throttle opening to a small range. Therefore, acceleration will be poor. | |
| | | Vehicle condition | Driving condition |
| | | When engine is idling | Normal |
| | | When accelerating | Poor acceleration |
| P2100 P2103 | Throttle control motor relay | ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring. | |
| P2101 | Electric throttle control function | ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring. | |
| P2118 | Throttle control motor | ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring. | |
| P2119 | Electric throttle control actuator | (When electric throttle control actuator does not function properly due to the return spring malfunction:) ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm. | |
| | | (When throttle valve opening angle in fail safe mode is not in specified range:) ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less. | |
| | | (When ECM detects the throttle valve is stuck open:) While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in the Neutral position, and engine speed will not exceed 1,000 rpm or more. | |
| P2122 P2123 P2127 P2128 P2138 | Accelerator pedal position sensor | The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor. | |

DTC Inspection Priority Chart

INFOID:000000009020644

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Priority | Detected items (DTC) | |
|----------|---|---|
| 1 | <ul style="list-style-type: none"> • U0101 U1001 CAN communication line • U0284 Active grille shutter • U1040 Engine communication line • P0101 P0102 P0103 Mass air flow sensor • P0111 P0112 P0113 P0127 Intake air temperature sensor • P0116 P0117 P0118 P0125 Engine coolant temperature sensor • P0122 P0123 P0222 P0223 P1225 P1226 P2135 Throttle position sensor • P0128 Thermostat function • P0181, P0182, P0183 Fuel tank temperature sensor • P0196 P0197 P0198 Engine oil temperature sensor • P0327 P0328 Knock sensor • P0335 Crankshaft position sensor (POS) • P0340 Camshaft position sensor (PHASE) • P0500 Vehicle speed sensor • P0520 Engine oil pressure sensor • P0605 P0607 ECM • P0643 Sensor power supply • P0850 Park/neutral position (PNP) switch • P1550 P1551 P1552 P1553 P1554 Battery current sensor • P1610 - P1615 NATS • P2122 P2123 P2127 P2128 P2138 Accelerator pedal position sensor | <p>A</p> <p>EC</p> <p>C</p> <p>D</p> <p>E</p> <p>F</p> |
| 2 | <ul style="list-style-type: none"> • P0031 P0032 Air fuel ratio (A/F) sensor 1 heater • P0037 P0038 Heated oxygen sensor 2 heater • P0075 Intake valve timing control solenoid valve • P0078 Exhaust valve timing control solenoid valve • P0130 P0131 P0132 P0133 P014C P014D P015A P015B P2096 P2097 Air fuel ratio (A/F) sensor 1 • P0137 P0138 P0139 Heated oxygen sensor 2 • P0441 EVAP control system purge flow monitoring • P0443, P0444, P0445 EVAP canister purge volume control solenoid valve • P0447, P0448 EVAP canister vent control valve • P0451, P0452, P0453 EVAP control system pressure sensor • P0460, P0461, P0462, P0463 Fuel level sensor • P059F Active grille shutter • P0603 ECM • P1078 Exhaust valve timing control position sensor • P1217 Engine over temperature (OVERHEAT) • P1805 Brake switch • P2100 P2103 Throttle control motor relay • P2101 Electric throttle control function • P2118 Throttle control motor | <p>G</p> <p>H</p> <p>I</p> <p>J</p> <p>K</p> |
| 3 | <ul style="list-style-type: none"> • P0011 Intake valve timing control • P0014 Exhaust valve timing control • P0171 P0172 Fuel injection system function • P0300 - P0304 Misfire • P0420 Three way catalyst function • P0456 EVAP control system (VERY SMALL LEAK) • P0506, P0507 Idle speed control system • P050A P050B P050E Cold start control • P0524 Engine oil pressure • P1148 Closed loop control • P117A Air fuel ratio • P1212 TCS communication line • P1564 ASCD steering switch • P1572 ASCD brake switch • P1574 ASCD vehicle speed sensor • P1715 Input speed sensor • P1720 Vehicle speed sensor • P2119 Electric throttle control actuator | <p>L</p> <p>M</p> <p>N</p> <p>O</p> <p>P</p> |

DTC Index

x:Applicable —: Not applicable

| DTC*1 | | Items (CONSULT screen terms) | SRT code | Trip | MIL | Permanent DTC group*4 | Reference page |
|------------------|-------------|---|-------------|------|-----|--------------------------|------------------------|
| CONSULT GST*2 | ECM*3 | | | | | | |
| U0101 | 0101*5 | LOST COMM (TCM) | — | 1 | x | B | EC-162 |
| U0284 | 0284 | LOST COMM (A/GRLL SHTR MDL A) | — | 2 | x | B | EC-161 |
| U1001 | 1001*5 | CAN COMM CIRCUIT | — | 2 | — | — | EC-162 |
| U1040 | 1040 | ENG COMM CIRCUIT | — | 2 | — | — | EC-163 |
| P0000 | 0000 | NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED. | — | — | — | — | — |
| P0011 | 0011 | INT/V TIM CONT-B1 | x | 2 | x | B | EC-164 |
| P0014 | 0014 | EXT/V TIM CONT-B1 | — | 2 | x | B | EC-168 |
| P0031 | 0031 | A/F SEN1 HTR (B1) | — | 2 | x | B | EC-171 |
| P0032 | 0032 | A/F SEN1 HTR (B1) | — | 2 | x | B | EC-171 |
| P0037 | 0037 | HO2S2 HTR (B1) | — | 2 | x | B | EC-174 |
| P0038 | 0038 | HO2S2 HTR (B1) | — | 2 | x | B | EC-174 |
| P0075 | 0075 | INT/V TIM V/CIR-B1 | — | 2 | x | B | EC-177 |
| P0078 | 0078 | EX V/T ACT/CIRC-B1 | — | 2 | x | B | EC-179 |
| P0101 | 0101 | MAF SEN/CIRCUIT-B1 | — | 2 | x | B | EC-182 |
| P0102 | 0102 | MAF SEN/CIRCUIT-B1 | — | 1 | x | B | EC-187 |
| P0103 | 0103 | MAF SEN/CIRCUIT-B1 | — | 1 | x | B | EC-187 |
| P0111 | 0111 | IAT SENSOR 1 B1 | — | 2 | x | A | EC-192 |
| P0112 | 0112 | IAT SEN/CIRCUIT-B1 | — | 2 | x | B | EC-194 |
| P0113 | 0113 | IAT SEN/CIRCUIT-B1 | — | 2 | x | B | EC-194 |
| P0116 | 0116 | ECT SEN/CIRC | — | 2 | x | A | EC-196 |
| P0117 | 0117 | ECT SEN/CIRC | — | 1 | x | B | EC-198 |
| P0118 | 0118 | ECT SEN/CIRC | — | 1 | x | B | EC-198 |
| P0122 | 0122 | TP SEN 2/CIRC-B1 | — | 1 | x | B | EC-200 |
| P0123 | 0123 | TP SEN 2/CIRC-B1 | — | 1 | x | B | EC-200 |
| P0125 | 0125 | ECT SENSOR | — | 2 | x | B | EC-203 |
| P0127 | 0127 | IAT SENSOR-B1 | — | 2 | x | B | EC-205 |
| P0128 | 0128 | THERMSTAT FNCTN | — | 2 | x | A | EC-207 |
| P0130 | 0130 | A/F SENSOR1 (B1) | x | 2 | x | A | EC-210 |
| P0131 | 0131 | A/F SENSOR1 (B1) | — | 2 | x | B | EC-214 |
| P0132 | 0132 | A/F SENSOR1 (B1) | — | 2 | x | B | EC-217 |
| P0137 | 0137 | HO2S2 (B1) | x | 2 | x | A | EC-220 |
| P0138 | 0138 | HO2S2 (B1) | x | 2 | x | A | EC-226 |
| P0139 | 0139 | HO2S2 (B1) | x | 2 | x | A | EC-234 |
| P014C | 014C | A/F SENSOR1 (B1) | x | 2 | x | A | EC-240 |
| P014D | 014D | A/F SENSOR1 (B1) | x | 2 | x | A | EC-240 |
| P015A | 015A | A/F SENSOR1 (B1) | x | 2 | x | A | EC-240 |
| P015B | 015B | A/F SENSOR1 (B1) | x | 2 | x | A | EC-240 |
| P0171 | 0171 | FUEL SYS-LEAN-B1 | — | 2 | x | B | EC-245 |
| P0172 | 0172 | FUEL SYS-RICH-B1 | — | 2 | x | B | EC-249 |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| DTC*1 | | Items (CONSULT screen terms) | SRT code | Trip | MIL | Permanent DTC group*4 | Reference page | |
|------------------|-------|---------------------------------|-------------|--------|--------|--------------------------|------------------------|----|
| CONSULT GST*2 | ECM*3 | | | | | | | |
| P0181 | 0181 | FTT SENSOR | — | 2 | × | A and B | EC-253 | A |
| P0182 | 0182 | FTT SEN/CIRCUIT | — | 2 | × | B | EC-257 | EC |
| P0183 | 0183 | ECT SEN/CIRCUIT | — | 2 | × | B | EC-257 | |
| P0196 | 0196 | EOP SENSOR | — | 2 | × | A and B | EC-259 | C |
| P0197 | 0197 | EOP SEN/CIRC | — | 2 | × | B | EC-262 | |
| P0198 | 0198 | EOP SEN/CIRC | — | 2 | × | B | EC-262 | D |
| P0222 | 0222 | TP SEN 1/CIRC-B1 | — | 1 | × | B | EC-264 | |
| P0223 | 0223 | TP SEN 1/CIRC-B1 | — | 1 | × | B | EC-264 | |
| P0300 | 0300 | MULTI CYL MISFIRE | — | 1 or 2 | × or — | B | EC-267 | E |
| P0301 | 0301 | CYL 1 MISFIRE | — | 1 or 2 | × or — | B | EC-267 | |
| P0302 | 0302 | CYL 2 MISFIRE | — | 1 or 2 | × or — | B | EC-267 | F |
| P0303 | 0303 | CYL 3 MISFIRE | — | 1 or 2 | × or — | B | EC-267 | |
| P0304 | 0304 | CYL 4 MISFIRE | — | 1 or 2 | × or — | B | EC-267 | |
| P0327 | 0327 | KNOCK SEN/CIRC-B1 | — | 2 | — | — | EC-273 | G |
| P0328 | 0328 | KNOCK SEN/CIRC-B1 | — | 2 | — | — | EC-273 | |
| P0335 | 0335 | CKP SEN/CIRCUIT | — | 2 | × | B | EC-275 | H |
| P0340 | 0340 | CMP SEN/CIRC-B1 | — | 2 | × | B | EC-279 | |
| P0420 | 0420 | TW CATALYST SYS-B1 | × | 2 | × | A | EC-282 | I |
| P0441 | 0441 | EVAP PURG FLOW/MON | × | 2 | × | A | EC-287 | |
| P0443 | 0443 | PURG VOLUME CONT/V | — | 2 | × | A | EC-292 | J |
| P0444 | 0444 | PURG VOLUME CONT/V | — | 2 | × | B | EC-297 | |
| P0445 | 0445 | PURG VOLUME CONT/V | — | 2 | × | B | EC-297 | |
| P0447 | 0447 | VENT CONTROL VALVE | — | 2 | × | B | EC-300 | K |
| P0448 | 0448 | VENT CONTROL VALVE | — | 2 | × | B | EC-304 | |
| P0451 | 0451 | EVAP SYS PRES SEN | — | 2 | × | A | EC-308 | L |
| P0452 | 0452 | EVAP SYS PRES SEN | — | 2 | × | B | EC-312 | |
| P0453 | 0453 | EVAP SYS PRES SEN | — | 2 | × | A | EC-315 | |
| P0456 | 0456 | EVAP VERY SML LEAK | ×*8 | 2 | × | A | EC-319 | M |
| P0460 | 0460 | FUEL LEV SEN SLOSH | — | 2 | × | A | EC-325 | |
| P0461 | 0461 | FUEL LEVEL SENSOR | — | 2 | × | B | EC-326 | N |
| P0462 | 0462 | FUEL LEVEL SEN/CIRC | — | 2 | × | B | EC-328 | |
| P0463 | 0463 | FUEL LEVEL SEN/CIRC | — | 2 | × | B | EC-328 | |
| P0500 | 0500 | VEH SPEED SEN/CIRC*6 | — | 2 | × | B | EC-329 | O |
| P0506 | 0506 | ISC SYSTEM | — | 2 | × | B | EC-331 | |
| P0507 | 0507 | ISC SYSTEM | — | 2 | × | B | EC-332 | |
| P050A | 050A | COLD START CONTROL | — | 2 | × | A | EC-334 | P |
| P050B | 050B | COLD START CONTROL | — | 2 | × | A | EC-334 | |
| P050E | 050E | COLD START CONTROL | — | 2 | × | A | EC-334 | |
| P0520 | 0520 | EOP SENSOR/SWITCH | — | 2 | — | — | EC-336 | |
| P0524 | 0524 | ENGINE OIL PRESSURE | — | 1 | — | — | EC-338 | |
| P059F | 059F | ACTIVE GRILLE AIR SHUTTER | — | 2 | × | B | EC-341 | |
| P0603 | 0603 | ECM BACK UP/CIRCUIT*7 | — | 2 | × | B | EC-347 | |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| DTC*1 | | Items (CONSULT screen terms) | SRT code | Trip | MIL | Permanent DTC group*4 | Reference page |
|------------------|-------|---------------------------------|-------------|-------------|-------------|--------------------------|---|
| CONSULT GST*2 | ECM*3 | | | | | | |
| P0605 | 0605 | ECM | — | 1 or 2 | × or — | B | EC-349 |
| P0607 | 0607 | ECM | — | 1*9 2*10 | ×*9 —*10 | B | EC-351 |
| P0643 | 0643 | SENSOR POWER/CIRC | — | 1 | × | B | EC-352 |
| P0850 | 0850 | P-N POS SW/CIRCUIT | — | 2 | × | B | EC-354 |
| P1078 | 1078 | EXH TIM SEN/CIRCUIT | — | 2 | × | B | EC-357 |
| P1148 | 1148 | CLOSED LOOP-B1 | — | 1 | × | A | EC-360 |
| P117A | 117A | AIR FUEL RATIO B1 | — | 2 | × | — | EC-341 |
| P1212 | 1212 | TCS/CIRC | — | 2 | — | — | EC-366 |
| P1217 | 1217 | ENG OVER TEMP | — | 1 | × | B | EC-367 |
| P1225 | 1225 | CTP LEARNING-B1 | — | 2 | — | — | EC-370 |
| P1226 | 1226 | CTP LEARNING-B1 | — | 2 | — | — | EC-371 |
| P1550 | 1550 | BAT CURRENT SENSOR | — | 2 | — | — | EC-372 |
| P1551 | 1551 | BAT CURRENT SENSOR | — | 2 | — | — | EC-374 |
| P1552 | 1552 | BAT CURRENT SENSOR | — | 2 | — | — | EC-374 |
| P1553 | 1553 | BAT CURRENT SENSOR | — | 2 | — | — | EC-376 |
| P1554 | 1554 | BAT CURRENT SENSOR | — | 2 | — | — | EC-378 |
| P1564 | 1564 | ASCD SW | — | 1 | — | — | EC-381 |
| P1572 | 1572 | ASCD BRAKE SW | — | 1 | — | — | EC-384 |
| P1574 | 1574 | ASCD VHL SPD SEN | — | 1 | — | — | EC-389 |
| P1610 | 1610 | LOCK MODE | — | 2 | — | — | SEC-65 (with I-Key system) SEC-166 (without I- Key system) |
| P1611 | 1611 | ID DISCORD, IMMU-ECM | — | 2 | — | — | SEC-66 |
| P1612 | 1612 | CHAIN OF ECM-IMMU | — | 2 | — | — | SEC-67 |
| P1614 | 1614 | NATS ANTENNA ANP. | — | 2 | — | — | SEC-167 |
| P1615 | 1615 | DIFFERENCE OF KEY | — | 2 | — | — | SEC-170 |
| P1715 | 1715 | IN PULY SPEED | — | 2 | — | — | EC-391 |
| P1720 | 1720 | V/SP SEN (A/T OUT) | — | 2 | — | — | EC-393 |
| P1805 | 1805 | BRAKE SW/CIRCUIT | — | 2 | — | — | EC-395 |
| P2096 | 2096 | POST CAT FUEL TRIM SYS B1 | — | 2 | × | — | EC-397 |
| P2097 | 2097 | POST CAT FUEL TRIM SYS B1 | — | 2 | × | — | EC-397 |
| P2100 | 2100 | ETC MOT PWR-B1 | — | 1 | × | B | EC-401 |
| P2101 | 2101 | ETC FNCTN/CIRC-B1 | — | 1 | × | B | EC-404 |
| P2103 | 2103 | ETC MOT PWR | — | 1 | × | B | EC-401 |
| P2118 | 2118 | ETC MOT-B1 | — | 1 | × | B | EC-408 |
| P2119 | 2119 | ETC ACTR-B1 | — | 1 | × | B | EC-410 |
| P2122 | 2122 | APP SEN 1/CIRC | — | 1 | × | B | EC-412 |
| P2123 | 2123 | APP SEN 1/CIRC | — | 1 | × | B | EC-412 |
| P2127 | 2127 | APP SEN 2/CIRC | — | 1 | × | B | EC-415 |
| P2128 | 2128 | APP SEN 2/CIRC | — | 1 | × | B | EC-415 |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| DTC*1 | | Items (CONSULT screen terms) | SRT code | Trip | MIL | Permanent DTC group*4 | Reference page |
|------------------|-------|---------------------------------|-------------|------|-----|--------------------------|------------------------|
| CONSULT GST*2 | ECM*3 | | | | | | |
| P2135 | 2135 | TP SENSOR-B1 | — | 1 | × | B | EC-418 |
| P2138 | 2138 | APP SENSOR | — | 1 | × | B | EC-421 |

- *1: 1st trip DTC No. is the same as DTC No.
- *2: This number is prescribed by SAE J1979/ ISO 15031-5.
- *3: In Diagnostic Test Mode II (Self-diagnostic results), this number is controlled by NISSAN.
- *4: Refer to [EC-143](#), "Description".
- *5: The troubleshooting for this DTC needs CONSULT.
- *6: When the fail-safe operations for both self-diagnoses occur, the MIL illuminates.
- *7: This self-diagnosis is not for ECM power supply circuit, even though "ECM BACK UP/CIRCUIT" is displayed on CONSULT screen.
- *8: SRT code will not be set if the self-diagnostic result is NG.
- *9: CVT models.
- *10: M/T models.

Test Value and Test Limit

INFOID:000000009566184

The following is the information specified in Service \$06 of SAE J1979/ISO 15031-5.
 The test value is a parameter used to determine whether a system/circuit diagnostic test is OK or NG while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.
 These data (test value and test limit) are specified by On Board Monitor ID (OBDMID), Test ID (TID), Unit and Scaling ID and can be displayed on the GST screen.
 The items of the test value and test limit will be displayed with GST screen which items are provided by the ECM. (e.g., if bank 2 is not applied on this vehicle, only the items of bank 1 are displayed)

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Item | OBD-MID | Self-diagnostic test item | DTC | Test value and Test limit (GST display) | | Description |
|------|---------|--|----------------|---|---------------------|---|
| | | | | TID | Unit and Scaling ID | |
| HO2S | 01H | Air fuel ratio (A/F) sensor 1 (Bank 1) | P0131 | 83H | 0BH | Minimum sensor output voltage for test cycle |
| | | | P0131 | 84H | 0BH | Maximum sensor output voltage for test cycle |
| | | | P0130 | 85H | 0BH | Minimum sensor output voltage for test cycle |
| | | | P0130 | 86H | 0BH | Maximum sensor output voltage for test cycle |
| | | | P0133 | 87H | 04H | Response rate: Response ratio (lean to rich) |
| | | | P0133 | 88H | 04H | Response rate: Response ratio (rich to lean) |
| | | | P2A00 or P2096 | 89H | 84H | The amount of shift in air fuel ratio (too lean) |
| | | | P2A00 or P2097 | 8AH | 84H | The amount of shift in air fuel ratio (too rich) |
| | | | P0130 | 8BH | 0BH | Difference in sensor output voltage |
| | | | P0133 | 8CH | 83H | Response gain at the limited frequency |
| | | | P014C | 8DH | 04H | O2 sensor slow response - Rich to lean bank 1 sensor 1 |
| | | | P014C | 8EH | 04H | O2 sensor slow response - Rich to lean bank 1 sensor 1 |
| | | | P014D | 8FH | 84H | O2 sensor slow response - Lean to rich bank 1 sensor 1 |
| | | | P014D | 90H | 84H | O2 sensor slow response - Lean to rich bank 1 sensor 1 |
| | | | P015A | 91H | 01H | O2 sensor delayed response - Rich to lean bank 1 sensor 1 |
| | | | P015A | 92H | 01H | O2 sensor delayed response - Rich to lean bank 1 sensor 1 |
| | | | P015B | 93H | 01H | O2 sensor delayed response - Lean to rich bank 1 sensor 1 |
| | | | P015B | 94H | 01H | O2 sensor delayed response - Lean to rich bank 1 sensor 1 |
| | | | P0133 | 95H | 04H | Response rate: Response ratio (lean to rich) |
| | | | P0133 | 96H | 84H | Response rate: Response ratio (rich to lean) |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Item | OBD-MID | Self-diagnostic test item | DTC | Test value and Test limit (GST display) | | Description |
|------|---------|--|----------------|---|---------------------|---|
| | | | | TID | Unit and Scaling ID | |
| HO2S | 02H | Heated oxygen sensor 2 (Bank 1) | P0138 | 07H | 0CH | Minimum sensor output voltage for test cycle |
| | | | P0137 | 08H | 0CH | Maximum sensor output voltage for test cycle |
| | | | P0138 | 80H | 0CH | Sensor output voltage |
| | | | P0139 | 81H | 0CH | Difference in sensor output voltage |
| | | | P0139 | 82H | 11H | Rear O2 sensor delay response diagnosis |
| | 03H | Heated oxygen sensor 3 (Bank 1) | P0143 | 07H | 0CH | Minimum sensor output voltage for test cycle |
| | | | P0144 | 08H | 0CH | Maximum sensor output voltage for test cycle |
| | | | P0146 | 80H | 0CH | Sensor output voltage |
| | | | P0145 | 81H | 0CH | Difference in sensor output voltage |
| | 05H | Air fuel ratio (A/F) sensor 1 (Bank 2) | P0151 | 83H | 0BH | Minimum sensor output voltage for test cycle |
| | | | P0151 | 84H | 0BH | Maximum sensor output voltage for test cycle |
| | | | P0150 | 85H | 0BH | Minimum sensor output voltage for test cycle |
| | | | P0150 | 86H | 0BH | Maximum sensor output voltage for test cycle |
| | | | P0153 | 87H | 04H | Response rate: Response ratio (lean to rich) |
| | | | P0153 | 88H | 04H | Response rate: Response ratio (rich to lean) |
| | | | P2A03 or P2098 | 89H | 84H | The amount of shift in air fuel ratio (too lean) |
| | | | P2A03 or P2099 | 8AH | 84H | The amount of shift in air fuel ratio (too rich) |
| | | | P0150 | 8BH | 0BH | Difference in sensor output voltage |
| | | | P0153 | 8CH | 83H | Response gain at the limited frequency |
| | | | P014E | 8DH | 04H | O2 sensor slow response - Rich to lean bank 2 sensor 1 |
| | | | P014E | 8EH | 04H | O2 sensor slow response - Rich to lean bank 2 sensor 1 |
| | | | P014F | 8FH | 84H | O2 sensor slow response - Lean to rich bank 2 sensor 1 |
| | | | P014F | 90H | 84H | O2 sensor slow response - Lean to rich bank 2 sensor 1 |
| | | | P015C | 91H | 01H | O2 sensor delayed response - Rich to lean bank 2 sensor 1 |
| | | | P015C | 92H | 01H | O2 sensor delayed response - Rich to lean bank 2 sensor 1 |
| | | | P015D | 93H | 01H | O2 sensor delayed response - Lean to rich bank 2 sensor 1 |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Item | OBD-MID | Self-diagnostic test item | DTC | Test value and Test limit (GST display) | | Description |
|---------------|---------------|--|-------------------------------------|---|---------------------|--|
| | | | | TID | Unit and Scaling ID | |
| HO2S | 05H | Air fuel ratio (A/F) sensor 1 (Bank 2) | P015D | 94H | 01H | O2 sensor delayed response - Lean to rich bank 2 sensor 1 |
| | | | P0153 | 95H | 04H | Response rate: Response ratio (lean to rich) |
| | | | P0153 | 96H | 84H | Response rate: Response ratio (rich to lean) |
| | 06H | Heated oxygen sensor 2 (Bank 2) | P0158 | 07H | 0CH | Minimum sensor output voltage for test cycle |
| | | | P0157 | 08H | 0CH | Maximum sensor output voltage for test cycle |
| | | | P0158 | 80H | 0CH | Sensor output voltage |
| | | | P0159 | 81H | 0CH | Difference in sensor output voltage |
| | | | P0159 | 82H | 11H | Rear O2 sensor delay response diagnosis |
| | 07H | Heated oxygen sensor 3 (Bank2) | P0163 | 07H | 0CH | Minimum sensor output voltage for test cycle |
| | | | P0164 | 08H | 0CH | Maximum sensor output voltage for test cycle |
| | | | P0166 | 80H | 0CH | Sensor output voltage |
| | | | P0165 | 81H | 0CH | Difference in sensor output voltage |
| | CATA- LYST | 21H | Three way catalyst function (Bank1) | P0420 | 80H | 01H |
| P0420 | | | | 82H | 01H | Switching time lag engine exhaust index value |
| P2423 | | | | 83H | 0CH | Difference in 3rd O2 sensor output voltage |
| P2423 | | | | 84H | 84H | O2 storage index in HC trap catalyst |
| 22H | | Three way catalyst function (Bank2) | P0430 | 80H | 01H | O2 storage index |
| | | | P0430 | 82H | 01H | Switching time lag engine exhaust index value |
| | | | P2424 | 83H | 0CH | Difference in 3rd O2 sensor output voltage |
| | | | P2424 | 84H | 84H | O2 storage index in HC trap catalyst |
| EGR SYSTEM | 31H | EGR function | P0400 | 80H | 96H | Low flow faults: EGR temp change rate (short term) |
| | | | P0400 | 81H | 96H | Low flow faults: EGR temp change rate (long term) |
| | | | P0400 | 82H | 96H | Low flow faults: Difference between max EGR temp and EGR temp under idling condition |
| | | | P0400 | 83H | 96H | Low flow faults: Max EGR temp |
| | | | P1402 | 84H | 96H | High Flow Faults: EGR temp increase rate |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Item | OBD-MID | Self-diagnostic test item | DTC | Test value and Test limit (GST display) | | Description |
|-------------|-------------------|--|------------------------------------|---|---|---|
| | | | | TID | Unit and Scaling ID | |
| VVT SYSTEM | 35H | VVT Monitor (Bank1) | P0011 | 80H | 9DH | VTC intake function diagnosis (VTC alignment check diagnosis) |
| | | | P0014 | 81H | 9DH | VTC exhaust function diagnosis (VTC alignment check diagnosis) |
| | | | P0011 | 82H | 9DH | VTC intake function diagnosis (VTC drive failure diagnosis) |
| | | | P0014 | 83H | 9DH | VTC exhaust function diagnosis (VTC drive failure diagnosis) |
| | | | P100A | 84H | 10H | VEL slow response diagnosis |
| | | | P1090 | 85H | 10H | VEL servo system diagnosis |
| | | | P0011 | 86H | 9DH | VTC intake intermediate lock function diagnosis (VTC intermediate position alignment check diagnosis) |
| | | | Advanced: P052A Retarded: P052B | 87H | 9DH | VTC intake intermediate lock system diagnosis (VTC intermediate lock position check diagnosis) |
| | 36H | VVT Monitor (Bank2) | P0021 | 80H | 9DH | VTC intake function diagnosis (VTC alignment check diagnosis) |
| | | | P0024 | 81H | 9DH | VTC exhaust function diagnosis (VTC alignment check diagnosis) |
| | | | P0021 | 82H | 9DH | VTC intake function diagnosis (VTC drive failure diagnosis) |
| | | | P0024 | 83H | 9DH | VTC exhaust function diagnosis (VTC drive failure diagnosis) |
| | | | P100B | 84H | 10H | VEL slow response diagnosis |
| | | | P1093 | 85H | 10H | VEL servo system diagnosis |
| P0021 | | | 86H | 9DH | VTC intake intermediate lock function diagnosis (VTC intermediate position alignment check diagnosis) | |
| | | Advanced: P052C Retarded: P052D | 87H | 9DH | VTC intake intermediate lock system diagnosis (VTC intermediate lock position check diagnosis) | |
| EVAP SYSTEM | 39H | EVAP control system leak (Cap Off) | P0455 | 80H | 0CH | Difference in pressure sensor output voltage before and after pull down |
| | 3BH | EVAP control system leak (Small leak) | P0442 | 80H | 05H | Leak area index (for more than 0.04 inch) |
| | 3CH | EVAP control system leak (Very small leak) | P0456 | 80H | 05H | Leak area index (for more than 0.02 inch) |
| | | | P0456 | 81H | FDH | Maximum internal pressure of EVAP system during monitoring |
| | | | P0456 | 82H | FDH | Internal pressure of EVAP system at the end of monitoring |
| 3DH | Purge flow system | P0441 | 83H | 0CH | Difference in pressure sensor output voltage before and after vent control valve close | |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

| Item | OBD-MID | Self-diagnostic test item | DTC | Test value and Test limit (GST display) | | Description |
|------------------|---------|---|---------------------------------------|---|---------------------|---|
| | | | | TID | Unit and Scaling ID | |
| O2 SENSOR HEATER | 41H | A/F sensor 1 heater (Bank 1) | Low Input: P0031 High Input: P0032 | 81H | 0BH | Converted value of heater electric current to voltage |
| | 42H | Heated oxygen sensor 2 heater (Bank 1) | Low Input: P0037 High Input: P0038 | 80H | 0CH | Converted value of heater electric current to voltage |
| | 43H | Heated oxygen sensor 3 heater (Bank 1) | P0043 | 80H | 0CH | Converted value of heater electric current to voltage |
| | 45H | A/F sensor 1 heater (Bank 2) | Low Input: P0051 High Input: P0052 | 81H | 0BH | Converted value of heater electric current to voltage |
| | 46H | Heated oxygen sensor 2 heater (Bank 2) | Low Input: P0057 High Input: P0058 | 80H | 0CH | Converted value of heater electric current to voltage |
| | 47H | Heated oxygen sensor 3 heater (Bank 2) | P0063 | 80H | 0CH | Converted value of heater electric current to voltage |
| SECONDARY AIR | 71H | Secondary air system | P0411 | 80H | 01H | Secondary air injection system incorrect flow detected |
| | | | Bank1: P0491 Bank2: P0492 | 81H | 01H | Secondary air injection system insufficient flow |
| | | | P2445 | 82H | 01H | Secondary air injection system pump stuck off |
| | | | P2448 | 83H | 01H | Secondary air injection system high airflow |
| | | | Bank1: P2440 Bank2: P2442 | 84H | 01H | Secondary air injection system switching valve stuck open |
| | | | P2440 | 85H | 01H | Secondary air injection system switching valve stuck open |
| | | | P2444 | 86H | 01H | Secondary air injection system pump stuck on |
| FUEL SYSTEM | 81H | Fuel injection system function (Bank 1) | P0171 or P0172 | 80H | 2FH | Long term fuel trim |
| | | | P0171 or P0172 | 81H | 24H | The number of lambda control clamped |
| | | | P117A | 82H | 03H | Cylinder A/F imbalance monitoring |
| | 82H | Fuel injection system function (Bank 2) | P0174 or P0175 | 80H | 2FH | Long term fuel trim |
| | | | P0174 or P0175 | 81H | 24H | The number of lambda control clamped |
| | | | P117B | 82H | 03H | Cylinder A/F imbalance monitoring |

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Item | OBD-MID | Self-diagnostic test item | DTC | Test value and Test limit (GST display) | | Description |
|---------|---------|----------------------------|-------|---|---------------------|--|
| | | | | TID | Unit and Scaling ID | |
| MISFIRE | A1H | Multiple cylinder misfires | P0301 | 80H | 24H | Misfiring counter at 1000 revolution of the first cylinder |
| | | | P0302 | 81H | 24H | Misfiring counter at 1000 revolution of the second cylinder |
| | | | P0303 | 82H | 24H | Misfiring counter at 1000 revolution of the third cylinder |
| | | | P0304 | 83H | 24H | Misfiring counter at 1000 revolution of the fourth cylinder |
| | | | P0305 | 84H | 24H | Misfiring counter at 1000 revolution of the fifth cylinder |
| | | | P0306 | 85H | 24H | Misfiring counter at 1000 revolution of the sixth cylinder |
| | | | P0307 | 86H | 24H | Misfiring counter at 1000 revolution of the seventh cylinder |
| | | | P0308 | 87H | 24H | Misfiring counter at 1000 revolution of the eighth cylinder |
| | | | P0300 | 88H | 24H | Misfiring counter at 1000 revolution of the multiple cylinders |
| | | | P0301 | 89H | 24H | Misfiring counter at 200 revolution of the first cylinder |
| | | | P0302 | 8AH | 24H | Misfiring counter at 200 revolution of the second cylinder |
| | | | P0303 | 8BH | 24H | Misfiring counter at 200 revolution of the third cylinder |
| | | | P0304 | 8CH | 24H | Misfiring counter at 200 revolution of the fourth cylinder |
| | | | P0305 | 8DH | 24H | Misfiring counter at 200 revolution of the fifth cylinder |
| | | | P0306 | 8EH | 24H | Misfiring counter at 200 revolution of the sixth cylinder |
| | | | P0307 | 8FH | 24H | Misfiring counter at 200 revolution of the seventh cylinder |
| | | | P0308 | 90H | 24H | Misfiring counter at 200 revolution of the eighth cylinder |
| | | | P0300 | 91H | 24H | Misfiring counter at 1000 revolution of the single cylinder |
| | | | P0300 | 92H | 24H | Misfiring counter at 200 revolution of the single cylinder |
| | | | P0300 | 93H | 24H | Misfiring counter at 200 revolution of the multiple cylinders |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS INFORMATION >

[HR16DE]

| Item | OBD-MID | Self-diagnostic test item | DTC | Test value and Test limit (GST display) | | Description |
|---------|---------|---------------------------|-------|---|---------------------|--|
| | | | | TID | Unit and Scaling ID | |
| MISFIRE | A2H | No. 1 cylinder misfire | P0301 | 0BH | 24H | EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles |
| | | | P0301 | 0CH | 24H | Misfire counts for last/current driving cycles |
| | A3H | No. 2 cylinder misfire | P0302 | 0BH | 24H | EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles |
| | | | P0302 | 0CH | 24H | Misfire counts for last/current driving cycles |
| | A4H | No. 3 cylinder misfire | P0303 | 0BH | 24H | EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles |
| | | | P0303 | 0CH | 24H | Misfire counts for last/current driving cycles |
| | A5H | No. 4 cylinder misfire | P0304 | 0BH | 24H | EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles |
| | | | P0304 | 0CH | 24H | Misfire counts for last/current driving cycles |
| | A6H | No. 5 cylinder misfire | P0305 | 0BH | 24H | EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles |
| | | | P0305 | 0CH | 24H | Misfire counts for last/current driving cycles |
| | A7H | No. 6 cylinder misfire | P0306 | 0BH | 24H | EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles |
| | | | P0306 | 0CH | 24H | Misfire counts for last/current driving cycles |
| | A8H | No. 7 cylinder misfire | P0307 | 0BH | 24H | EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles |
| | | | P0307 | 0CH | 24H | Misfire counts for last/current driving cycles |
| | A9H | No. 8 cylinder misfire | P0308 | 0BH | 24H | EWMA (Exponential Weighted Moving Average) misfire counts for last 10 driving cycles |
| | | | P0308 | 0CH | 24H | Misfire counts for last/current driving cycles |


< WIRING DIAGRAM >

WIRING DIAGRAM

ENGINE CONTROL SYSTEM

Wiring Diagram

INFOID:000000009020647




ABBWA1074GB

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]




ABBWA1075GB

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]




A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]




ABBWA1077GB

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]




* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABBWA1079GB


ENGINE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|---------------------|
| Connector No. | M5 |
| Connector Name | JOINT CONNECTOR-M03 |
| Connector Color | BROWN |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | - |
| 2 | O | - |
| 6 | P | - |
| 11 | GR | - |
| 13 | GR | - |

| | |
|-----------------|---------------------|
| Connector No. | M8 |
| Connector Name | JOINT CONNECTOR-M02 |
| Connector Color | GREEN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 8 | L | - |
| 9 | L | - |
| 19 | P | - |
| 20 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | M10 |
| Connector Name | JOINT CONNECTOR-M01 |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | L | - |
| 6 | L | - |
| 8 | L | - |
| 13 | P | - |
| 15 | P | - |
| 17 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | M22 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 4 | B/W | - |
| 5 | B/W | - |
| 6 | L | - |
| 7 | GR | - |
| 8 | O | - |
| 14 | P | - |
| 16 | LG | - |

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------|
| 1 | L | CAN-H |
| 2 | P | CAN-L |
| 21 | B | GND (ILL) |
| 22 | B | GND (POWER) |
| 23 | B | GND (CIRCUIT) |
| 27 | R/W | BAT |
| 28 | GR | IGN |

| | |
|-----------------|-----------------------------------|
| Connector No. | M30 |
| Connector Name | COMBINATION SWITCH (SPIRAL CABLE) |
| Connector Color | GRAY |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 25 | Y | - |
| 32 | B | - |

ABBIA1675GB


A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1A | GR | - |
| 19A | GR | - |
| 20A | P | - |
| 21A | L | - |
| 35A | P | - |
| 36A | Y | - |
| 46A | B | - |

| | |
|-----------------|--------------|
| Connector No. | M69 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| | |
|-----------------|---------------------|
| Connector No. | M51 |
| Connector Name | JOINT CONNECTOR-M04 |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | LG | - |
| 11 | LG | - |
| 12 | R/W | - |

| | |
|-----------------|------------------------------|
| Connector No. | E5 |
| Connector Name | COOLING FAN MOTOR (WITH CVT) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |
| 2 | B | - |


| | |
|-----------------|-----------------------------------|
| Connector No. | M88 |
| Connector Name | COMBINATION SWITCH (SPIRAL CABLE) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 13 | R | - |
| 16 | B | - |


ABBIA1676GB

| | |
|-----------------|--------------|
| Connector No. | E7 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1A | GR | - |
| 19A | GR | - |
| 20A | P | - |
| 21A | L | - |
| 35A | Y | - |
| 36A | Y | - |
| 46A | B | - |

| | |
|-----------------|--------------|
| Connector No. | E8 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | GR | - |
| 3 | R | - |
| 10 | R | - |
| 11 | L | - |
| 12 | BR | - |
| 14 | G | - |
| 20 | BR | - |
| 24 | Y | - |

| | |
|-----------------|-----------------------------------|
| Connector No. | E12 |
| Connector Name | ACCELERATOR PEDAL POSITION SENSOR |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | - |
| 2 | P | - |
| 3 | SB | - |
| 4 | V | - |
| 5 | BR | - |
| 6 | GR | - |

| | |
|-----------------|-----------------------------|
| Connector No. | E13 |
| Connector Name | STOP LAMP SWITCH (WITH CVT) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | LG | - |
| 3 | L | - |
| 4 | P | - |

| | |
|-----------------|---------------------|
| Connector No. | E14 |
| Connector Name | JOINT CONNECTOR-E03 |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |
| 4 | P | - |
| 5 | P | - |
| 8 | L | - |
| 11 | L | - |
| 12 | L | - |

ABBIA1677GB


A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]

| | |
|-----------------|-------|
| Connector No. | E16 |
| Connector Name | ECM |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------------------|
| 81 | V | POWER SUPPLY FOR ECM (BACK-UP) |
| 82 | - | - |
| 83 | P | CAN-L |
| 84 | L | CAN-H |
| 85 | V | REFRIGERANT PRESSURE SENSOR |
| 86 | - | - |
| 87 | - | - |
| 88 | GR | DATA LINK CONNECTER |

| | |
|-----------------|-----------------------------|
| Connector No. | E17 |
| Connector Name | REFRIGERANT PRESSURE SENSOR |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | LG | - |
| 2 | V | - |
| 3 | W | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 89 | - | - |
| 90 | - | - |
| 91 | - | - |
| 92 | R | CLUTCH PEDAL POSITION SWITCH |
| 93 | L | IGNITION SWITCH |
| 94 | Y | ASCD STEERING SWITCH |
| 95 | B | SENSOR GROUND (ASCD STEERING SWITCH) |
| 96 | - | - |
| 97 | - | - |
| 98 | LG | SENSOR GROUND (REFRIGERANT PRESSURE SENSOR) |
| 99 | LG | STOP LAMP SWITCH |
| 100 | G | BRAKE PEDAL POSITION SWITCH |
| 101 | W | SENSOR POWER SUPPLY (REFRIGERANT PRESSURE SENSOR) |


| | |
|-----------------|--------------|
| Connector No. | E19 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | GR | - |
| 3 | GR | - |
| 6 | L | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------------------|
| 102 | BR | SENSOR POWER SUPPLY (APP SENSOR 2) |
| 103 | GR | ACCELERATOR PEDAL POSITION SENSOR 2 |
| 104 | Y | SENSOR GROUND (APP SENSOR 2) |
| 105 | G | POWER SUPPLY FOR ECM |
| 106 | V | SENSOR POWER SUPPLY (APP SENSOR 1) |
| 107 | - | - |
| 108 | B | ECM GROUND |
| 109 | - | - |
| 110 | SB | ACCELERATOR PEDAL POSITION SENSOR 1 |
| 111 | P | SENSOR GROUND (APP SENSOR 1) |
| 112 | - | - |

| | |
|-----------------|--------------|
| Connector No. | E21 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | R | - |
| 4 | GR | - |
| 5 | BR | - |
| 10 | Y | - |
| 11 | BR | - |
| 12 | L | - |
| 13 | P | - |
| 14 | G | - |

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >


[HR16DE]

| | |
|-----------------|------------------------------|
| Connector No. | E32 |
| Connector Name | COOLING FAN MOTOR (WITH CVT) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | Y | - |
| 4 | LG | - |

| | |
|-----------------|------------------------------|
| Connector No. | E31 |
| Connector Name | COOLING FAN MOTOR (WITH M/T) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | - |
| 2 | P | - |
| 3 | B | - |
| 4 | LG | - |

| | |
|-----------------|---------------------|
| Connector No. | E22 |
| Connector Name | JOINT CONNECTOR-E02 |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | LG | - |
| 10 | LG | - |

| | |
|-----------------|--|
| Connector No. | E44 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 9 | BR | FUEL PUMP |
| 11 | G | ECM VB |

| | |
|-----------------|--|
| Connector No. | E43 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 5 | Y | MOTOR FAN HI |
| 7 | P | MOTOR FAN LO |

| | |
|-----------------|-----------------------------|
| Connector No. | E36 |
| Connector Name | BRAKE PEDAL POSITION SWITCH |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | - |
| 2 | G | - |

ABBIA1679GB


A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >


[HR16DE]

| | |
|-----------------|--|
| Connector No. | E45 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 19 | B | GND (POWER) |
| 21 | R | AT ECU (WITH CVT) |

| | |
|-----------------|--|
| Connector No. | E46 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 59 | Y | MOTOR FAN RLY GND |
| 60 | B | GND (SIGNAL) |
| 61 | P | CAN-L |
| 62 | L | CAN-H |
| 65 | BR | RELAY IG |

| | |
|-----------------|------------------------------|
| Connector No. | E48 |
| Connector Name | CLUTCH PEDAL POSITION SWITCH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | R | - |
| 4 | B | - |

| | |
|-----------------|--------------|
| Connector No. | E55 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | G | - |
| 3 | V | - |
| 4 | G | - |
| 5 | L | - |
| 6 | GR | - |
| 7 | R | - |
| 8 | B | - |
| 10 | P | - |

| | |
|-----------------|------------------------------|
| Connector No. | E57 |
| Connector Name | STOP LAMP SWITCH (WITH IM/T) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | LG | - |

| | |
|-----------------|-------------------|
| Connector No. | E62 |
| Connector Name | COOLING FAN RELAY |
| Connector Color | BLUE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BR | - |
| 2 | Y | - |
| 3 | B | - |
| 5 | LG | - |

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]

| | |
|-----------------|------------------------------------|
| Connector No. | F7 |
| Connector Name | ELECTRIC THROTTLE CONTROL ACTUATOR |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W | - |
| 2 | W/R | - |
| 3 | B | - |
| 4 | R | - |
| 5 | P | - |
| 6 | L | - |

| | |
|-----------------|-----------------------------------|
| Connector No. | F6 |
| Connector Name | ENGINE COOLANT TEMPERATURE SENSOR |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | LG/V | - |
| 2 | P | - |

| | |
|-----------------|------------------------|
| Connector No. | E63 |
| Connector Name | HEATED OXYGEN SENSOR 2 |
| Connector Color | GRAY |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | R | - |
| 2 | G | - |
| 3 | BR | - |
| 4 | L | - |

| | |
|-----------------|------------------------|
| Connector No. | F9 |
| Connector Name | BATTERY CURRENT SENSOR |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | - |
| 2 | L | - |
| 3 | R | - |
| 4 | BR | - |

| | |
|-----------------|--------------|
| Connector No. | F8 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | L | - |
| 3 | R | - |
| 10 | L/Y | - |
| 11 | L/R | - |
| 12 | BR/W | - |
| 14 | P | - |
| 20 | SB | - |
| 24 | Y | - |

ABBIA1681GB

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM


< WIRING DIAGRAM >

[HR16DE]

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------------------|
| 22 | BR | IGNITION SIGNAL NO. 3 |
| 23 | GR | FUEL PUMP RELAY |
| 24 | R | FUEL INJECTOR NO. 4 (REAR) |
| 25 | R | FUEL INJECTOR NO. 4 (FRONT) |
| 26 | P | EVAP CANISTER VENT CONTROL VALVE |
| 27 | - | - |
| 28 | - | - |
| 29 | G | FUEL INJECTOR NO. 3 (FRONT) |
| 30 | O | FUEL INJECTOR NO. 2 (FRONT) |
| 31 | L | FUEL INJECTOR NO. 1 (FRONT) |
| 32 | P | ECM RELAY (SELF SHUT-OFF) |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 7 | - | - |
| 8 | - | - |
| 9 | SB | EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE |
| 10 | B | ECM GROUND |
| 11 | B/Y | ECM GROUND |
| 12 | L/W | FUEL INJECTOR NO. 1 (REAR) |
| 13 | - | - |
| 14 | - | - |
| 15 | G/W | THROTTLE CONTROL MOTOR RELAY |
| 16 | G | FUEL INJECTOR NO. 3 (REAR) |
| 17 | V | IGNITION SIGNAL NO. 1 |
| 18 | Y/B | IGNITION SIGNAL NO. 2 |
| 19 | - | - |
| 20 | O/W | FUEL INJECTOR NO. 2 (REAR) |
| 21 | W | IGNITION SIGNAL NO. 4 |

| | |
|-----------------|------|
| Connector No. | F10 |
| Connector Name | ECM |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------------------|
| 1 | L | THROTTLE CONTROL MOTOR (OPEN) |
| 2 | L/W | THROTTLE CONTROL MOTOR POWER SUPPLY |
| 3 | G/W | A/F SENSOR 1 HEATER |
| 4 | P | THROTTLE CONTROL MOTOR (CLOSE) |
| 5 | BR/W | HEATED OXYGEN SENSOR 2 HEATER |
| 6 | - | - |

ABBIA1682GB

ENGINE CONTROL SYSTEM


< WIRING DIAGRAM >

[HR16DE]

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 63 | W | SENSOR GROUND (CMP SENSOR / EXHAUST VALVE TIMING POSITION SENSOR) |
| 64 | - | - |
| 65 | R/W | CAMSHAFT POSITION SENSOR |
| 66 | - | - |
| 67 | - | - |
| 68 | R | SENSOR GROUND (BATTERY CURRENT SENSOR) |
| 69 | BR | PARK/NEUTRAL POSITION SIGNAL |
| 70 | L/Y | ENGINE COMMUNICATION LINE |
| 71 | Y | SENSOR POWER SUPPLY (BATTERY CURRENT SENSOR) |
| 72 | W/R | SENSOR POWER SUPPLY (TP SENSOR) |
| 73 | P | INTAKE VALVE TIMING CONTROL SOLENOID VALVE |
| 74 | O | SENSOR POWER SUPPLY (EOP SENSOR) |
| 75 | O | SENSOR POWER SUPPLY (CKP SENSOR) |
| 76 | - | - |
| 77 | P/W | EXHAUST VALVE TIMING CONTROL SOLENOID VALVE |
| 78 | BR | SENSOR POWER SUPPLY (CMP SENSOR / EXHAUST VALVE TIMING POSITION SENSOR) |
| 79 | - | - |
| 80 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 46 | V | INTAKE AIR TEMPERATURE SENSOR |
| 47 | Y | ENGINE OIL PRESSURE SENSOR |
| 48 | W/R | EXHAUST VALVE TIMING CONTROL POSITION SENSOR |
| 49 | G/W | A/F SENSOR 1 |
| 50 | L/R | HEATED OXYGEN SENSOR 2 |
| 51 | P | SENSOR GROUND (FUEL TANK TEMPERATURE SENSOR) |
| 52 | LG | SENSOR GROUND (MAF SENSOR/IAT SENSOR) |
| 53 | L | A/F SENSOR 1 |
| 54 | BR | SENSOR GROUND (EOT SENSOR) |
| 55 | G/L | SENSOR GROUND (IAT SENSOR) |
| 56 | - | - |
| 57 | P | ENGINE OIL TEMPERATURE SENSOR |
| 58 | BR | BATTERY CURRENT SENSOR |
| 59 | L/Y | SENSOR GROUND (HO2S 2) |
| 60 | L | SENSOR GROUND (EOP SENSOR) |
| 61 | L/O | CRANKSHAFT POSITION SENSOR |
| 62 | G | SENSOR GROUND (CKP SENSOR) |

| | |
|-----------------|-------|
| Connector No. | F11 |
| Connector Name | ECM |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------------------|
| 33 | W | THROTTLE POSITION SENSOR 1 |
| 34 | B | THROTTLE POSITION SENSOR 2 |
| 35 | - | - |
| 36 | R | SENSOR GROUND (TP SENSOR) |
| 37 | W | KNOCK SENSOR |
| 38 | LG/V | ENGINE COOLANT TEMPERATURE SENSOR |
| 39 | L | BATTERY TEMPERATURE SENSOR |
| 40 | L | SENSOR GROUND (KNOCK SENSOR) |
| 41 | - | - |
| 42 | L | FUEL TANK TEMPERATURE SENSOR |
| 43 | SB | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 44 | P | SENSOR GROUND (ECT SENSOR) |
| 45 | G/B | MASS AIR FLOW SENSOR |

ABBIA1683GB

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]

| | |
|-----------------|----------------------------------|
| Connector No. | F15 |
| Connector Name | CRANKSHAFT POSITION SENSOR (POS) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | - |
| 2 | G | - |
| 3 | L/O | - |

| | |
|-----------------|--------------|
| Connector No. | F14 |
| Connector Name | KNOCK SENSOR |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W/G | - |
| 2 | L | - |

| | |
|-----------------|-------------------------------|
| Connector No. | F12 |
| Connector Name | AIR FUEL RATIO (A/F) SENSOR 1 |
| Connector Color | BROWN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G/W | - |
| 2 | L | - |
| 3 | G/W | - |
| 4 | L | - |

| | |
|-----------------|-----------------------------|
| Connector No. | F19 |
| Connector Name | FUEL INJECTOR NO. 3 (FRONT) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | G | - |

| | |
|-----------------|-----------------------------|
| Connector No. | F18 |
| Connector Name | FUEL INJECTOR NO. 2 (FRONT) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | O | - |

| | |
|-----------------|-----------------------------|
| Connector No. | F17 |
| Connector Name | FUEL INJECTOR NO. 1 (FRONT) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | L | - |

ABBIA1684GB

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]

| | |
|-----------------|---|
| Connector No. | F22 |
| Connector Name | EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | GW | - |
| 2 | SB | - |

| | |
|-----------------|--------------------------|
| Connector No. | F21 |
| Connector Name | CAMSHAFT POSITION SENSOR |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BR | - |
| 2 | W | - |
| 3 | R/W | - |

| | |
|-----------------|-----------------------------|
| Connector No. | F20 |
| Connector Name | FUEL INJECTOR NO. 4 (FRONT) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | R | - |

| | |
|-----------------|-------------------------------|
| Connector No. | F25 |
| Connector Name | ENGINE OIL TEMPERATURE SENSOR |
| Connector Color | GRAY |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |
| 2 | BR | - |

| | |
|-----------------|------------------------------------|
| Connector No. | F24 |
| Connector Name | PARK/NEUTRAL POSITION (PNP) SWITCH |
| Connector Color | GREEN |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | R | - |
| 3 | BR | - |

| | |
|-----------------|--|
| Connector No. | F23 |
| Connector Name | INTAKE VALVE TIMING CONTROL SOLENOID VALVE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | - |
| 2 | L | - |

ABBIA1685GB

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]

| | |
|-----------------|----------------------------|
| Connector No. | F30 |
| Connector Name | FUEL INJECTOR NO. 4 (REAR) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | R | - |

| | |
|-----------------|----------------------------|
| Connector No. | F29 |
| Connector Name | FUEL INJECTOR NO. 3 (REAR) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | G | - |

| | |
|-----------------|-----------|
| Connector No. | F26 |
| Connector Name | CONDENSER |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | - |
| 2 | B | - |

| | |
|-----------------|--------------|
| Connector No. | F33 |
| Connector Name | WIRE TO WIRE |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | GR | - |
| 3 | GR | - |
| 6 | Y | - |

| | |
|-----------------|---|
| Connector No. | F32 |
| Connector Name | EXHAUST VALVE TIMING CONTROL SOLENOID VALVE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P/W | - |
| 2 | L | - |

| | |
|-----------------|----------------------|
| Connector No. | F31 |
| Connector Name | MASS AIR FLOW SENSOR |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | - | - |
| 2 | G | - |
| 3 | LG | - |
| 4 | G/B | - |
| 5 | V | - |
| 6 | G/L | - |

ABBIA1686GB

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]

| | |
|-----------------|---|
| Connector No. | F36 |
| Connector Name | IGNITION COIL NO. 3 (WITH POWER TRANSISTOR) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BR | - |
| 2 | B | - |
| 3 | Y | - |

| | |
|-----------------|---|
| Connector No. | F35 |
| Connector Name | IGNITION COIL NO. 2 (WITH POWER TRANSISTOR) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y/B | - |
| 2 | B | - |
| 3 | Y | - |

| | |
|-----------------|---|
| Connector No. | F34 |
| Connector Name | IGNITION COIL NO. 1 (WITH POWER TRANSISTOR) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | V | - |
| 2 | B | - |
| 3 | Y | - |

| | |
|-----------------|--|
| Connector No. | F42 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 29 | L/W | ETC |
| 32 | G/W | MOTRLY |
| 34 | Y | IGN COIL |
| 35 | BR | ECM BAT |
| 36 | SB | INJECTOR |
| 39 | L | ENG SOL |

| | |
|-----------------|----------------------------|
| Connector No. | F38 |
| Connector Name | ENGINE OIL PRESSURE SENSOR |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | O | - |
| 2 | Y | - |
| 3 | L | - |

| | |
|-----------------|---|
| Connector No. | F37 |
| Connector Name | IGNITION COIL NO. 4 (WITH POWER TRANSISTOR) |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W | - |
| 2 | B | - |
| 3 | Y | - |

ABBIA1687GB

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >


[HR16DE]

| | |
|-----------------|----------------------------|
| Connector No. | F53 |
| Connector Name | FUEL INJECTOR NO. 1 (REAR) |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | LW | - |

| | |
|-----------------|---------------------------|
| Connector No. | F49 |
| Connector Name | TRANSMISSION RANGE SWITCH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7 | R | CAN-L |
| 10 | BR | CAN-H |

| | |
|-----------------|--|
| Connector No. | F43 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 43 | GR | FPR |
| 47 | R/W | ECM IGNSW |
| 50 | P | SSOFF |

| | |
|-----------------|--|
| Connector No. | F56 |
| Connector Name | EXHAUST VALVE TIMING CONTROL POSITION SENSOR |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BR | - |
| 2 | W | - |
| 3 | W/R | - |

| | |
|-----------------|--------------|
| Connector No. | F55 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2 | G | - |
| 3 | BR | - |
| 4 | G/W | - |
| 5 | R/W | - |
| 6 | R | - |
| 7 | R | - |
| 8 | B | - |
| 10 | P | - |

| | |
|-----------------|----------------------------|
| Connector No. | F54 |
| Connector Name | FUEL INJECTOR NO. 2 (REAR) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | SB | - |
| 2 | O/W | - |


ABBIA1688GB

ENGINE CONTROL SYSTEM

< WIRING DIAGRAM >

[HR16DE]

| | |
|-----------------|--------------|
| Connector No. | B12 |
| Connector Name | WIRE TO WIRE |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3 | GR | - |
| 4 | W | - |
| 5 | G | - |
| 11 | Y | - |
| 10 | V | - |
| 12 | BR | - |
| 13 | SB | - |
| 14 | P | - |

| | |
|-----------------|----------------------------------|
| Connector No. | B5 |
| Connector Name | EVAP CANISTER VENT CONTROL VALVE |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BR | - |
| 2 | SB | - |

| | |
|-----------------|-------------------------------------|
| Connector No. | B3 |
| Connector Name | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | GR | - |
| 2 | Y | - |
| 3 | V | - |

| | |
|-----------------|--------------------------------------|
| Connector No. | B44 |
| Connector Name | FUEL LEVEL SENSOR UNIT AND FUEL PUMP |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 3 | B | - |
| 4 | W | - |
| 5 | P | - |

ABBIA1689GB

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009020648

OVERALL SEQUENCE



*1: Include 1st trip DTC.

*2: Include 1st trip freeze frame data.

JSBIA0123GB

DIAGNOSIS AND REPAIR WORKFLOW

[HR16DE]

< BASIC INSPECTION >

DETAILED FLOW

1. GET INFORMATION FOR SYMPTOM

1. Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the "Diagnostic Work Sheet". (Refer to [EC-121, "Diagnostic Work Sheet"](#).)
2. Ask if the customer requests I/M examination.

Malfunction information, obtained>>GO TO 2.

No malfunction information, but a request for I/M examination>>GO TO 13.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is displayed.
 - Record DTC and freeze frame data. (Print them out with CONSULT or GST.)
 - Erase DTC.
 - ⓐ With CONSULT: "How to Erase DTC and 1st Trip DTC" in [EC-60, "CONSULT Function"](#).
 - ⓑ Without CONSULT: "How to Erase Self-diagnostic Results" in [EC-57, "On Board Diagnosis Function"](#).
 - Study the relationship between the cause detected by DTC and the symptom described by the customer. (Symptom Table is useful. Refer to [EC-452, "Symptom Table"](#).)
3. Check related service bulletins for information.

Is any symptom described and is any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer (except MIL ON).

Also study the normal operation and fail safe related to the symptom. Refer to [EC-458, "Description"](#) and [EC-82, "Fail Safe"](#).

Diagnostic Work Sheet is useful to verify the incident.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail safe related to the symptom. Refer to [EC-458, "Description"](#) and [EC-82, "Fail Safe"](#).

Diagnostic Work Sheet is useful to verify the incident.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the displayed DTC, and then make sure that DTC is detected again.

If two or more DTCs are detected, refer to [EC-84, "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
 - If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 10.

DIAGNOSIS AND REPAIR WORKFLOW

[HR16DE]

< BASIC INSPECTION >

NO >> Check according to [GI-41, "Intermittent Incident"](#).

6. PERFORM BASIC INSPECTION

Perform [EC-131, "Work Procedure"](#).

Do you have CONSULT?

YES >> GO TO 7.

NO >> GO TO 9.

7. PERFORM "SPEC" IN DATA MONITOR MODE

With CONSULT

Make sure that "MAS A/F SE-B1", "B/FUEL SCHDL" and "A/F ALPHA-B1" are within the SP value in "SPEC" of "DATA MONITOR" mode with CONSULT. Refer to [EC-149, "Component Function Check"](#).

Is the measurement value within the SP value?

YES >> GO TO 9.

NO >> GO TO 8.

8. DETECT MALFUNCTIONING PART BY TROUBLE DIAGNOSIS - SPECIFICATION VALUE

Detect malfunctioning part according to [EC-150, "Diagnosis Procedure"](#).

Is malfunctioning part detected?

YES >> GO TO 11.

NO >> GO TO 9.

9. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE

Detect malfunctioning system according to [EC-452, "Symptom Table"](#) based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 10.

10. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

Inspect according to Diagnosis Procedure of the system.

NOTE:

The Diagnosis Procedure in EC section described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnosis Procedure. For details, refer to [GI-44, "Circuit Inspection"](#).

Is malfunctioning part detected?

YES >> GO TO 11.

NO >> Monitor input data from related sensors or check the voltage of related ECM terminals using CONSULT. Refer to [EC-70, "Reference Value"](#).

11. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it.

With CONSULT: "How to Erase DTC and 1st Trip DTC" in [EC-60, "CONSULT Function"](#).

Without CONSULT: "How to Erase Self-diagnostic Results" in [EC-57, "On Board Diagnosis Function"](#).

>> GO TO 12.

12. FINAL CHECK

When DTC was detected in step 2, perform DTC CONFIRMATION PROCEDURE or Component Function Check again, and then make sure that the malfunction have been repaired securely.

When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and make sure that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 10.

YES-2 >> Symptom remains: GO TO 6.

DIAGNOSIS AND REPAIR WORKFLOW

[HR16DE]

< BASIC INSPECTION >

NO-1 >> No request for I/M examination from the customer: Before returning the vehicle to the customer, always erase unnecessary DTC in ECM and TCM (ⓅWith CONSULT: Refer to “How to Erase DTC and 1st Trip DTC” in [EC-60, "CONSULT Function"](#), (Ⓧ)Without CONSULT: Refer to “How to Erase Self-diagnostic Results” in [EC-57, "On Board Diagnosis Function"](#)).

NO-2 >> I/M examination, requested from the customer: GO TO 13.

13. PREPARE FOR I/M EXAMINATION

1. Set SRT codes. Refer to [EC-137, "Description"](#).
2. Erase permanent DTCs. Refer to [EC-143, "Description"](#).

>> INSPECTION END

Diagnostic Work Sheet

INFOID:000000009020649

DESCRIPTION

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about symptoms. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the WORKSHEET SAMPLE below in order to organize all the information for troubleshooting.

Some conditions may cause the MIL to illuminate or blink, and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

ADDITIONAL SERVICE WHEN REPLACING ECM

< BASIC INSPECTION >

[HR16DE]

ADDITIONAL SERVICE WHEN REPLACING ECM

Description

INFOID:000000009020650

When replacing ECM, the following procedure must be performed. (For details, refer to [EC-123, "Work Procedure"](#).)

PROGRAMMING OPERATION

NOTE:

After replacing with a blank ECM, programming is required to write ECM information. Be sure to follow the procedure to perform the programming.

Work Procedure

INFOID:000000009020651

1. CHECK ECM PART NUMBER

Check ECM part number to see whether it is blank ECM or not.

NOTE:

- Part number of blank ECM is 23703 - xxxxxx.
- Check the part number when ordering ECM or with the one included in the label on the container box.

Is the ECM a blank ECM?

YES >> GO TO 2.

NO >> GO TO 4.

2. SAVE ECM PART NUMBER

Read out the part number from the old ECM and save the number, following the programming instructions. Refer to "CONSULT Operation Manual".

NOTE:

- The ECM part number is saved in CONSULT.
- Even when ECM part number is not saved in CONSULT, go to 3.

>> GO TO 3.

3. PERFORM ECM PROGRAMMING

After replacing ECM, perform the ECM programming. Refer to "CONSULT Operation Manual".

NOTE:

- Refer to [EC-465, "Removal and Installation"](#) for replacement of ECM.
- During programming, maintain the following conditions:
 - Ignition switch: ON
 - Electric load: OFF
 - Brake pedal: Not depressed
 - Battery voltage: 12 – 13.5 V (Be sure to check the value of battery voltage by selecting "BATTERY VOLT" in "Data monitor" of CONSULT.)

>> GO TO 4.

4. REPLACE ECM

Replace ECM. Refer to [EC-465, "Removal and Installation"](#).

>> GO TO 5.

5. PERFORM VIN REGISTRATION

Refer to [EC-125, "Work Procedure"](#).

>> GO TO 6.

6. PERFORM INITIALIZATION OF NATS SYSTEM AND REGISTRATION OF ALL NATS IGNITION KEY IDS

Refer to [SEC-63, "ECM : Work Procedure"](#) (with I-Key), [SEC-165, "ECM RE-COMMUNICATING FUNCTION : Special Repair Requirement"](#) (without I-Key).

ADDITIONAL SERVICE WHEN REPLACING ECM

< BASIC INSPECTION >

[HR16DE]

>> GO TO 7.

7. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

Refer to [EC-126. "Work Procedure"](#).

>> GO TO 8.

8. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Refer to [EC-127. "Work Procedure"](#).

>> GO TO 9.

9. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-128. "Work Procedure"](#).

>> END

VIN REGISTRATION

< BASIC INSPECTION >

[HR16DE]

VIN REGISTRATION

Description

INFOID:000000009762590

VIN Registration is an operation to registering VIN in ECM. It must be performed each time ECM is replaced.

NOTE:

Accurate VIN which is registered in ECM may be required for Inspection & Maintenance (I/M).

Work Procedure

INFOID:000000009762591

1. CHECK VIN

Check the VIN of the vehicle and note it. Refer to [GI-34. "Identification Number"](#).

>> GO TO 2.

2. PERFORM VIN REGISTRATION

 With CONSULT

1. Turn ignition switch ON and engine stopped.
2. Select "VIN REGISTRATION" in "WORK SUPPORT" mode of "ENGINE" using CONSULT.
3. Follow the instruction of CONSULT display.

>> END

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ACCELERATOR PEDAL RELEASED POSITION LEARNING

< BASIC INSPECTION >

[HR16DE]

ACCELERATOR PEDAL RELEASED POSITION LEARNING

Description

INFOID:000000009020652

Accelerator Pedal Released Position Learning is a function of ECM to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

Work Procedure

INFOID:000000009020653

1. START

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch ON and wait at least 2 seconds.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON and wait at least 2 seconds.
5. Turn ignition switch OFF and wait at least 10 seconds.

>> END

THROTTLE VALVE CLOSED POSITION LEARNING

< BASIC INSPECTION >

[HR16DE]

THROTTLE VALVE CLOSED POSITION LEARNING

Description

INFOID:000000009020654

Throttle Valve Closed Position Learning is a function of ECM to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected or electric throttle control actuator inside is cleaned.

Work Procedure

INFOID:000000009020655

1. START

Ⓜ WITH CONSULT

1. Turn ignition switch ON.
2. Select "CLSD THL POS LEARN" in "WORK SUPPORT" mode.
3. Follow the instructions on the CONSULT display.
4. Turn ignition switch OFF and wait at least 10 seconds.
Check that throttle valve moves during the above 10 seconds by confirming the operating sound.

ⓧ WITHOUT CONSULT

1. Start the engine.
NOTE:
Engine coolant temperature is 25°C (77°F) or less before engine starts.
2. Warm up the engine.
NOTE:
Raise engine coolant temperature until it reaches 65°C (149°F) or more.
3. Turn ignition switch OFF and wait at least 10 seconds.
Check that throttle valve moves during the above 10 seconds by confirming the operating sound.

>> END

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

IDLE AIR VOLUME LEARNING

Description

INFOID:000000009020656

Idle Air Volume Learning is a function of ECM to learn the idle air volume that keeps each engine idle speed within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

Work Procedure

INFOID:000000009020657

1. PRECONDITIONING

Make sure that all of the following conditions are satisfied.

Learning will be cancelled if any of the following conditions are missed for even a moment.

- Battery voltage: More than 12.9 V (At idle)
- Engine coolant temperature: 70 - 100°C (158 - 212°F)
- Selector lever: P or N (CVT), Neutral (M/T)
- Electric load switch: OFF
(Air conditioner, headlamp, rear window defogger)
- **For vehicles equipped with daytime light systems, perform one of the following procedures before starting engine not to illuminate headlamps.**
 - Apply parking brake
 - Set lighting switch to the 1st position
 - Steering wheel: Neutral (Straight-ahead position) position
 - Vehicle speed: Stopped
 - Transmission: Warmed-up
 - CVT models
 - With CONSULT: Drive vehicle until "FLUID TEMP SE" in "DATA MONITOR" mode of "TRANSMISSION" system indicates less than 0.9 V.
 - Without CONSULT: Drive vehicle for 10 minutes.
 - M/T models
 - Drive vehicle for 10 minutes.

Do you have CONSULT?

- YES >> GO TO 2.
- NO >> GO TO 3.

2. IDLE AIR VOLUME LEARNING

ⓈWith CONSULT

1. Perform ACCELERATOR PEDAL RELEASED POSITION LEARNING. Refer to [EC-126, "Work Procedure"](#).
2. Perform THROTTLE VALVE CLOSED POSITION LEARNING. Refer to [EC-127, "Work Procedure"](#).
3. Start engine and warm it up to normal operating temperature.
4. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode with CONSULT.
5. Touch "START" and wait 20 seconds.

Is "CMPLT" displayed on CONSULT screen?

- YES >> GO TO 4.
- NO >> GO TO 5.

3. IDLE AIR VOLUME LEARNING

ⓧWithout CONSULT

NOTE:


- It is better to count the time accurately with a clock.
 - It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
1. Perform ACCELERATOR PEDAL RELEASED POSITION LEARNING. Refer to [EC-126, "Work Procedure"](#).
 2. Perform THROTTLE VALVE CLOSED POSITION LEARNING. Refer to [EC-127, "Work Procedure"](#).
 3. Start engine and warm it up to normal operating temperature.
 4. Turn ignition switch OFF and wait at least 10 seconds.

IDLE AIR VOLUME LEARNING

[HR16DE]

< BASIC INSPECTION >

5. Confirm that accelerator pedal is fully released, turn ignition switch ON and wait 3 seconds.
6. Repeat the following procedure quickly five times within 5 seconds.
 - Fully depress the accelerator pedal.
 - Fully release the accelerator pedal.
7. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 20 seconds until the MI stops blinking and turned ON.
8. Fully release the accelerator pedal within 3 seconds after the MI turned ON.
9. Start engine and let it idle.
10. Wait 20 seconds.



>> GO TO 4.

4. CHECK IDLE SPEED AND IGNITION TIMING

Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

For specification, refer to [EC-466, "Idle Speed"](#) and [EC-466, "Ignition Timing"](#).

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following

- Check that throttle valve is fully closed.
- Check PCV valve operation.
- Check that downstream of throttle valve is free from air leakage.

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace malfunctioning part.

6. DETECT MALFUNCTIONING PART

Engine component parts and their installation condition are questionable. Check and eliminate the cause of the incident.

It is useful to perform "TROUBLE DIAGNOSIS - SPECIFICATION VALUE". Refer to [EC-149, "Description"](#).

If any of the following conditions occur after the engine has started, eliminate the cause of the incident and perform Idle Air Volume Learning all over again:

- Engine stalls.
- Erroneous idle.

>> INSPECTION END

MIXTURE RATIO SELF-LEARNING VALUE CLEAR

< BASIC INSPECTION >

[HR16DE]

MIXTURE RATIO SELF-LEARNING VALUE CLEAR

Description

INFOID:000000009020658

This describes how to erase the mixture ratio self-learning value. For the actual procedure, follow the instructions in "Diagnosis Procedure".

Work Procedure

INFOID:000000009020659

1. START

With CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT.
3. Clear mixture ratio self-learning value by touching "CLEAR".

With GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF.
3. Disconnect mass air flow sensor harness connector.
4. Restart engine and let it idle for at least 5 seconds.
5. Stop engine and reconnect mass air flow sensor harness connector.
6. Select Service \$03 with GST. Make sure DTC P0102 is detected.
7. Select Service \$04 with GST to erase the DTC P0102.

>> END



BASIC INSPECTION

Work Procedure

INFOID:000000009020660

1.INSPECTION START


1. Check service records for any recent repairs that may indicate a related malfunction, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Wiring harness for improper connections, pinches and cut
 - Vacuum hoses for splits, kinks and improper connections
 - Hoses and ducts for leaks
 - Air cleaner clogging
 - Gasket
3. Confirm that electrical or mechanical loads are not applied.
 - Headlamp switch is OFF.
 - Air conditioner switch is OFF.
 - Rear window defogger switch is OFF.
 - Steering wheel is in the straight-ahead position, etc.
4. Start engine and warm it up until engine coolant temperature indicator points to the middle of gauge. Ensure engine stays below 1,000 rpm.



5. Run engine at about 2,000 rpm for about 2 minutes under no load.
6. Make sure that no DTC is displayed with CONSULT or GST.

Is any DTC detected?

- YES >> GO TO 2.
- NO >> GO TO 3.



2.REPAIR OR REPLACE

Repair or replace components as necessary according to corresponding Diagnostic Procedure.

>> GO TO 3

3.CHECK TARGET IDLE SPEED

1. Run engine at about 2,000 rpm for about 2 minutes under no load.

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BASIC INSPECTION


[HR16DE]

< BASIC INSPECTION >

- Rev engine (2,000 to 3,000 rpm) two or three times under no load, then run engine at idle speed for about 1 minute.
- Check idle speed.
For procedure, refer to [EC-459, "Inspection"](#).
For specification, refer to [EC-466, "Idle Speed"](#).

Is the inspection result normal?

- YES >> GO TO 10.
NO >> GO TO 4.



4.PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

- Stop engine.
- Perform [EC-126, "Work Procedure"](#).

>> GO TO 5.

5.PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-127, "Work Procedure"](#).

>> GO TO 6.

6.PERFORM IDLE AIR VOLUME LEARNING

Perform [EC-128, "Work Procedure"](#).

Is Idle Air Volume Learning carried out successfully?

- YES >> GO TO 7.
NO >> Follow the instruction of IDLE AIR VOLUME LEARNING. Then GO TO 4.

7.CHECK TARGET IDLE SPEED AGAIN

- Start engine and warm it up to normal operating temperature.
- Check idle speed.
For procedure, refer to [EC-459, "Inspection"](#).
For specification, refer to [EC-466, "Idle Speed"](#).

Is the inspection result normal?

- YES >> GO TO 10.
NO >> GO TO 8.

8.DETECT MALFUNCTIONING PART

Check the Following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-279, "DTC Logic"](#).
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-275, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 9.
NO >> Repair or replace. Then GO TO 4.

9.CHECK ECM FUNCTION

- Substitute another known-good ECM to check ECM function. (ECM may be the cause of an incident, but this is a rare case.)
- Perform initialization and registration of all NATS ignition key IDs. Refer to [SEC-165, "ECM RE-COMMUNICATING FUNCTION : Special Repair Requirement"](#).

>> GO TO 4.

10.CHECK IGNITION TIMING


- Run engine at idle.

BASIC INSPECTION

[HR16DE]

< BASIC INSPECTION >

2. Check ignition timing with a timing light.
For procedure, refer to [EC-460, "Inspection"](#).
For specification, refer to [EC-466, "Ignition Timing"](#).
- Timing indicator (1)



Is the inspection result normal?

- YES >> GO TO 19.
NO >> GO TO 11.

11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-126, "Work Procedure"](#).

>> GO TO 12.

12. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-127, "Work Procedure"](#).

>> GO TO 13.

13. PERFORM IDLE AIR VOLUME LEARNING

Perform [EC-128, "Work Procedure"](#).

Is idle air volume learning carried out successfully?

- YES >> GO TO 14.
NO >> Follow the instruction of IDLE AIR VOLUME LEARNING. Then GO TO 4.

14. CHECK TARGET IDLE SPEED AGAIN


1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.
For procedure, refer to [EC-459, "Inspection"](#).
For specification, refer to [EC-466, "Idle Speed"](#).

Is the inspection result normal?

- YES >> GO TO 15.
NO >> GO TO 17.

15. CHECK IGNITION TIMING AGAIN

1. Run engine at idle.
2. Check ignition timing with a timing light.
For procedure, refer to [EC-460, "Inspection"](#).
For specification, refer to [EC-466, "Ignition Timing"](#).
- Timing indicator (1)



Is the inspection result normal?

- YES >> GO TO 19.
NO >> GO TO 16.

16. CHECK TIMING CHAIN INSTALLATION

Check timing chain installation. Refer to [EM-51, "Removal and Installation"](#).

Is the inspection result normal?

- YES >> GO TO 17.
NO >> Repair the timing chain installation. Then GO TO 4.

BASIC INSPECTION

[HR16DE]

< BASIC INSPECTION >

17.DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-279, "DTC Logic"](#).
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-275, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 18.

NO >> Repair or replace. Then GO TO 4.

18.CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of an incident, but this is a rare case.)
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [SEC-165, "ECM RE-COMMUNICATING FUNCTION : Special Repair Requirement"](#).

>> GO TO 4.

19.INSPECTION END

If ECM is replaced during this BASIC INSPECTION procedure, perform [EC-123, "Work Procedure"](#).

>> INSPECTION END

FUEL PRESSURE CHECK

< BASIC INSPECTION >

[HR16DE]

FUEL PRESSURE CHECK

Work Procedure

INFOID:000000009020661

FUEL PRESSURE RELEASE

1. FUEL PRESSURE RELEASE

④ With CONSULT

1. Turn ignition switch ON.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.

⊗ Without CONSULT

1. Remove fuel pump fuse located in IPDM E/R.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch OFF.
5. Reinstall fuel pump fuse after servicing fuel system.

>> INSPECTION END

FUEL PRESSURE CHECK

1. FUEL PRESSURE CHECK

CAUTION:


- Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.
- The fuel hose connection method used when taking fuel pressure check must not be used for other purposes.
- Be careful not to scratch or put debris around connection area when servicing, so that the quick connector maintains seal ability with O-rings inside.
- Do not perform fuel pressure check with electrical systems operating (i.e. lights, rear defogger, A/C, etc.) Fuel pressure gauge may indicate false readings due to varying engine load and changes in manifold vacuum.

NOTE:

Prepare pans or saucers under the disconnected fuel line because the fuel may spill out. The fuel pressure cannot be completely released because this models do not have fuel return system.

1. Release fuel pressure to zero.
2. Prepare fuel hose for fuel pressure check (B) and fuel tube adapter [SST: KV10118400 or KV10120000] (D), then connect fuel pressure gauge (A).

- ⇐ To quick connector
← To fuel tube (engine side)
C : Hose clamp



CAUTION:

- Use suitable fuel hose for fuel pressure check (genuine NISSAN fuel hose without quick connector).
 - To avoid unnecessary force or tension to hose, use moderately long fuel hose for fuel pressure check.
 - Do not use the fuel hose for checking fuel pressure with damage or cracks on it.
 - Use Pressure Gauge to check fuel pressure.
3. Remove fuel hose.

CAUTION:

Do not twist or kink fuel hose because it is plastic hose.

FUEL PRESSURE CHECK

[HR16DE]

< BASIC INSPECTION >

4. Connect fuel hose for fuel pressure check (1) to fuel tube (engine side) with clamp (2) as shown in the figure.

5 : No.2 spool

CAUTION:

- Wipe off oil or dirt from hose insertion part using cloth moistened with gasoline.
- Apply proper amount of gasoline between top of the fuel tube (3) and No.1 spool (4).
- Insert fuel hose for fuel pressure check until it touches the No.1 spool on fuel tube.
- Use NISSAN genuine hose clamp (part number: 16439 N4710 or 16439 40U00).
- When reconnecting fuel line, always use new clamps.
- Use a torque driver to tighten clamps.
- Install hose clamp to the position within 1 - 2 mm (0.04 - 0.08 in).

Tightening torque : 1 - 1.5 N·m (0.1 - 0.15 kg·m, 9 - 13 in·lb)

- Make sure that clamp screw does not contact adjacent parts.

5. Connect fuel tube adapter to quick connector (1).

A : Fuel pressure gauge

6. After connecting fuel hose for fuel pressure check, pull the hose with a force of approximately 98 N (10 kg, 22 lb) to confirm fuel tube does not come off.
7. Turn ignition switch ON and check for fuel leakage.
8. Start engine and check for fuel leakage.
9. Read the indication of fuel pressure gauge.

CAUTION:

- Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
- During fuel pressure check, confirm for fuel leakage from fuel connection every 3 minutes.

At idling : Approximately 350 kPa (3.57 kg/cm², 51 psi)

Is the inspection result normal?



- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK FUEL HOSE AND FUEL TUBE

If result is unsatisfactory, check fuel hoses and fuel tubes for clogging.

Is the inspection result normal?

- YES >> Replace "fuel filter and fuel pump assembly". Refer to [FL-6, "Exploded View"](#).
NO >> Repair or replace.



HOW TO SET SRT CODE

< BASIC INSPECTION >

[HR16DE]

HOW TO SET SRT CODE

Description

INFOID:000000009020662

OUTLINE

In order to set all SRTs, the self-diagnoses as in the “SRT ITEM” table must have been performed at least once. Each diagnosis may require actual driving for a long period of time under various conditions.

SRT ITEM

The table below shows required self-diagnostic items to set the SRT to “CMPLT”.

| SRT item* (CONSULT indication) | Required self-diagnostic items to set the SRT to “CMPLT” | Corresponding DTC No. |
|-----------------------------------|--|--------------------------|
| CATALYST | Three way catalyst function | P0420 |
| EVAP SYSTEM | EVAP control system purge flow monitoring | P0441 |
| | EVAP control system | P0456 |
| HO2S | Heated oxygen sensor 2 | P0137 |
| | Heated oxygen sensor 2 | P0138 |
| | Heated oxygen sensor 2 | P0139 |
| EGR/VVT SYSTEM | Intake valve timing control function | P0011 |

*: Though displayed on the CONSULT screen, “HO2S HTR” is not SRT item.


SRT SERVICE PROCEDURE

If a vehicle has failed the state emissions inspection due to one or more SRT items indicating “INCMP”, review the flowchart diagnostic sequence, referring to the following flowchart.

HOW TO SET SRT CODE

< BASIC INSPECTION >

[HR16DE]



SRT Set Driving Pattern

INFOID:000000009020663


CAUTION:

HOW TO SET SRT CODE

< BASIC INSPECTION >

[HR16DE]

Always drive the vehicle in safe manner according to traffic conditions and obey all traffic laws.



JSBIA3647GB

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Checking the vehicle speed with GST is advised.

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
- "Zone A" is the fastest time where required for the diagnosis under normal conditions*. If the diagnosis is not completed within "Zone A", the diagnosis can still be performed within "Zone B".

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

< BASIC INSPECTION >

- *: Normal conditions
- Sea level
- Flat road
- Ambient air temperature: 20 – 30°C (68 – 86°F)

NOTE:

Diagnosis is performed as quickly as possible under normal conditions. However, under other conditions, diagnosis may also be performed. [For example: ambient air temperature other than 20 – 30°C (68 – 86°F)]

Work Procedure

INFOID:000000009020664

1. CHECK DTC

Check DTC.

Is any DTC detected?

- YES >> Repair malfunction(s) and erase DTC. Refer to [EC-86, "DTC Index"](#).
- NO >> GO TO 2.

2. CHECK SRT STATUS

WITH CONSULT

Select "SRT STATUS" in "DTC & SRT CONFIRMATION" mode of "ENGINE" using CONSULT.

WITHOUT CONSULT

Perform "SRT status" mode with [EC-57, "On Board Diagnosis Function"](#).

WITH GST

Select Service \$01 with GST.

Is SRT code(s) set?

- YES >> GO TO 12.
- NO-1 >> With CONSULT: GO TO 3.
- NO-2 >> Without CONSULT: GO TO 4.

3. DTC CONFIRMATION PROCEDURE

1. Select "SRT WORK SUPPORT" in "DTC & SRT CONFIRMATION" mode with CONSULT.
2. For SRT(s) that is not set, perform the corresponding "DTC CONFIRMATION PROCEDURE" according to the "Performance Priority" in the "SRT ITEM" table. Refer to [EC-55, "DIAGNOSIS DESCRIPTION : System Readiness Test \(SRT\) Code"](#).
3. Check DTC.

Is any DTC detected?

- YES >> Repair malfunction(s) and erase DTC. Refer to [EC-86, "DTC Index"](#).
- NO >> GO TO 11.

4. PERFORM ROAD TEST

- Check the "Performance Priority" in the "SRT ITEM" table. Refer to [EC-55, "DIAGNOSIS DESCRIPTION : System Readiness Test \(SRT\) Code"](#).
- Perform the most efficient SRT set driving pattern to set the SRT properly. Refer to [EC-138, "SRT Set Driving Pattern"](#).

In order to set all SRTs, the SRT set driving pattern must be performed at least once.

>> GO TO 5.

5. PATTERN 1

1. Check the vehicle condition;
 - Engine coolant temperature is –10 to 35°C (14 to 95°F).
 - Fuel tank temperature is more than 0°C (32°F).
2. Start the engine.
3. Keep engine idling until the engine coolant temperature is greater than 70°C (158°F)

NOTE:

ECM terminal voltage is follows;

- Engine coolant temperature
 - –10 to 35°C (14 to 95°F): 3.0 - 4.3 V
 - 70°(158°F): Less than 1.4 V

HOW TO SET SRT CODE

[HR16DE]

< BASIC INSPECTION >

- Fuel tank temperature: Less than 4.1 V
Refer to [EC-70, "Reference Value"](#).

>> GO TO 6.

6.PATTERN 2

- Drive the vehicle. And depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds.
- Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again

NOTE:


- Checking the vehicle speed with GST is advised.
- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

>> GO TO 7.

7.PATTERN 3

- Operate vehicle following the driving pattern shown in the figure.
- Release the accelerator pedal during deceleration of vehicle speed from 90 km/h (56 MPH) to 0 km/h (0 MPH).


>> GO TO 8.



8.PATTERN 4

- Operate vehicle following the driving pattern shown in the figure.
- Drive the vehicle in a proper gear at 60 km/h (38 MPH) and maintain the speed.
- Release the accelerator pedal fully at least 5 seconds.
- Repeat the above two steps at least 5 times.

>> GO TO 9.



9.PATTERN 5

- The accelerator pedal must be held very steady during steady-state driving.
- If the accelerator pedal is moved, the test must be conducted again.

>> GO TO 10.

10.PATTERN 6

- Cool down the engine so that the engine coolant temperature lowers between 15 – 35°C (59 – 95°F).

CAUTION:

Never turn the ignition switch ON while cooling down the engine.

- Engine coolant temperature at engine start is between 15 – 35°C (59 – 95°F) and has lowered 45°C (113°F) or more since the latest engine stop.

>> GO TO 11.

11.CHECK SRT STATUS

HOW TO SET SRT CODE

[HR16DE]

< BASIC INSPECTION >

WITH CONSULT

Select "SRT STATUS" in "DTC & SRT CONFIRMATION" mode of "ENGINE" using CONSULT.

WITHOUT CONSULT

Perform "SRT status" mode with [EC-57, "On Board Diagnosis Function"](#).

WITH GST

Select Service \$01 with GST.

Is SRT(s) set?

YES >> GO TO 12.

NO >> Call TECH LINE or take appropriate action.

12.CHECK PERMANENT DTC

NOTE:

Permanent DTC cannot be checked with a tool other than CONSULT or GST.

WITH CONSULT

Select "SRT STATUS" in "DTC & SRT CONFIRMATION" mode of "ENGINE" using CONSULT.

WITH GST

Select Service \$01 with GST.

Is permanent DTC(s) detected?

YES >> Proceed to [EC-149, "Description"](#).

NO >> END

HOW TO ERASE PERMANENT DTC

< BASIC INSPECTION >

[HR16DE]

HOW TO ERASE PERMANENT DTC


Description

INFOID:000000009020665

OUTLINE

When a DTC is stored in ECM

When a DTC is stored in ECM and MIL is ON, a permanent DTC is erased with MIL shutoff if the same malfunction is not detected after performing the driving pattern for MIL shutoff three times in a row.



*1: When the same malfunction is detected in two consecutive trips, MIL will illuminate.

*2: MIL will turn off after vehicle is driven 3 times (driving pattern B) without any malfunctions.

When a DTC is not stored in ECM

The erasing method depends on a permanent DTC stored in ECM. Refer to the following table.

NOTE:

If the applicable permanent DTC includes multiple groups, perform the procedure of Group B first. If the permanent DTC is not erased, perform the procedure of Group A.

×: Applicable —: Not applicable

| Group * | Perform "DTC CONFIRMATION PROCEDURE" for applicable DTCs. | Driving pattern | | Reference |
|---------|---|-----------------|---|------------------------|
| | | B | D | |
| A | × | — | — | EC-144 |
| B | — | × | × | EC-146 |

*: For group, refer to [EC-86. "DTC Index"](#).

PERMANENT DTC ITEM


For permanent DTC items, MIL turns ON. Refer to [EC-86. "DTC Index"](#).

HOW TO ERASE PERMANENT DTC

< BASIC INSPECTION >


[HR16DE]

PERMANENT DTC SERVICE PROCEDURE



Work Procedure (Group A)

INFOID:000000009020666



HOW TO ERASE PERMANENT DTC

[HR16DE]

< BASIC INSPECTION >

*1: When the same malfunction is detected in two consecutive trips, MIL will illuminate.

A

1. CHECK DTC

EC

Check DTC.

Is any DTC detected?

C

YES >> Repair malfunction(s) and erase DTC. Refer to [EC-57, "On Board Diagnosis Function"](#), [EC-60, "CONSULT Function"](#).

D

NO >> GO TO 2.

2. CHECK PERMANENT DTC

 With CONSULT

E

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select "PERMANENT DTC STATUS" mode with CONSULT.

F

 With GST

G

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select Service \$0A with GST.

H

Is any permanent DTC detected?

YES >> GO TO 3.

I

NO >> END

3. PERFORM DTC CONFIRMATION PROCEDURE

Perform "DTC CONFIRMATION PROCEDURE" for DTCs which are the same as permanent DTCs stored in ECM. Refer to [EC-86, "DTC Index"](#).

J

>> GO TO 4.

4. CHECK PERMANENT DTC

K

 With CONSULT

L

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select "PERMANENT DTC STATUS" mode with CONSULT.

M

 With GST

N

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select Service \$0A with GST.

O

Is any permanent DTC detected?

YES >> GO TO 1.

P

NO >> END


HOW TO ERASE PERMANENT DTC

< BASIC INSPECTION >

[HR16DE]

Work Procedure (Group B)

INFOID:00000009020667



*1: When the same malfunction is detected in two consecutive trips, MIL will illuminate.

*2: After experiencing driving pattern B and D, permanent DTC is erased.

*3: Indication does not change unless the ignition switch is turned from ON to OFF twice even after experiencing driving pattern B or D.

NOTE:

Drive the vehicle according to only driving patterns indicating "INCMP" in driving patterns B and D on the "PERMANENT DTC STATUS" screen.

1. CHECK DTC

Check DTC.

Is any DTC detected?

YES >> Repair malfunction(s) and erase DTC. Refer to [EC-57. "On Board Diagnosis Function"](#), [EC-60. "CONSULT Function"](#).

NO >> GO TO 2.

2. CHECK PERMANENT DTC

Ⓜ With CONSULT

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select "PERMANENT DTC STATUS" mode with CONSULT.

Ⓜ With GST

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

HOW TO ERASE PERMANENT DTC

[HR16DE]

< BASIC INSPECTION >

4. Turn ignition switch ON.
5. Select Service \$0A with GST.

Is any permanent DTC detected?

- YES >> GO TO 3.
NO >> END

3. DRIVE DRIVING PATTERN B

CAUTION:

- Always drive at a safe speed.
- Never erase self-diagnosis results.
- If self-diagnosis results are erased during the trip of driving pattern B or D, the counter of driving pattern B and D is reset.

 With CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Use "PERMANENT DTC WORK SUPPORT" mode with CONSULT to drive the vehicle according to driving pattern B. Refer to [EC-60. "CONSULT Function"](#), [EC-146. "Work Procedure \(Group B\)"](#).

 With GST

1. Start engine and warm it up to normal operating temperature.
2. Drive the vehicle according to driving pattern B. Refer to [EC-146. "Work Procedure \(Group B\)"](#).

>> GO TO 4.

4. CHECK PERMANENT DTC

 With CONSULT

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select "PERMANENT DTC STATUS" mode with CONSULT.

 With GST

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select Service \$0A with GST.

Is any permanent DTC detected?

- YES >> GO TO 5.
NO >> END

5. DRIVE DRIVING PATTERN D


CAUTION:

- Always drive at a safe speed.
- Never erase self-diagnosis results.
- If self-diagnosis results are erased during the trip of driving pattern B or D, the counter of driving pattern B and D is reset.


Drive the vehicle according to driving pattern D. Refer to [EC-146. "Work Procedure \(Group B\)"](#).

>> GO TO 6.

6. CHECK PERMANENT DTC

 With CONSULT

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select "PERMANENT DTC STATUS" mode with CONSULT.

 With GST

1. Turn ignition switch OFF and wait at least 10 seconds.

HOW TO ERASE PERMANENT DTC

[HR16DE]

< BASIC INSPECTION >

2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON.
5. Select Service \$0A with GST.

Is any permanent DTC detected?

YES >> GO TO 1.
NO >> END

DTC/CIRCUIT DIAGNOSIS

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

Description

INFOID:000000009020668

The specification (SP) value indicates the tolerance of the value that is displayed in “SPEC” of “DATA MONITOR” mode of CONSULT during normal operation of the Engine Control System. When the value in “SPEC” of “DATA MONITOR” mode is within the SP value, the Engine Control System is confirmed OK. When the value in “SPEC” of “DATA MONITOR” mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MI.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Component Function Check

INFOID:000000009020669

1. START

Make sure that all of the following conditions are satisfied.

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 98.3 - 104.3 kPa (1.003 - 1.064 kg/cm², 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up
 - CVT models: After the engine is warmed up to normal operating temperature, drive vehicle until “FLUID TEMP SE” (CVT fluid temperature sensor signal) indicates more than 60°C (140°F).
 - M/T models: After the engine is warmed up to normal operating temperature, drive vehicle for 5 minutes.
- Electrical load: Not applied
 - Rear window defogger switch, air conditioner switch, lighting switch are OFF. Steering wheel is straight ahead.
- Engine speed: Idle

>> GO TO 2.

2. PERFORM “SPEC” OF “DATA MONITOR” MODE

With CONSULT

NOTE:

Perform “SPEC” in “DATA MONITOR” mode in maximum scale display.

1. Perform [EC-131, "Work Procedure"](#).
2. Select “B/FUEL SCHDL”, “A/F ALPHA-B1” and “MAS A/F SE-B1” in “SPEC” of “DATA MONITOR” mode with CONSULT.
3. Make sure that monitor items are within the SP value.

Is the inspection result normal?

YES >> END

NO >> Go to [EC-150, "Diagnosis Procedure"](#).

TROUBLE DIAGNOSIS - SPECIFICATION VALUE


< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Diagnosis Procedure

INFOID:000000009020670

OVERALL SEQUENCE




PBIB2318E

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]



PBIB3213E

DETAILED PROCEDURE

1. CHECK "A/F ALPHA-B1"

With CONSULT

1. Start engine.
2. Confirm that the testing conditions are met. Refer to [EC-149, "Component Function Check"](#).
3. Select "A/F ALPHA-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NOTE:

Check "A/F ALPHA-B1" for approximately 1 minute because it may fluctuate. It is NG if the indication is out of the SP value even a little.

Is the measurement value within the SP value?

- YES >> GO TO 17.
- NO-1 >> Less than the SP value: GO TO 2.
- NO-2 >> More than the SP value: GO TO 3.

2.CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

- YES >> GO TO 4.
- NO >> More than the SP value: GO TO 19.

3.CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

- YES >> GO TO 6.
- NO-1 >> More than the SP value: GO TO 6.
- NO-2 >> Less than the SP value: GO TO 25.

4.CHECK "A/F ALPHA-B1"

1. Stop the engine.
2. Disconnect PCV hose, and then plug it.
3. Start engine.
4. Select "A/F ALPHA-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

- YES >> GO TO 5.
- NO >> GO TO 6.

5.CHANGE ENGINE OIL

1. Stop the engine.
2. Change engine oil.

NOTE:

This symptom may occur when a large amount of gasoline is mixed with engine oil because of driving conditions (such as when engine oil temperature does not rise enough since a journey distance is too short during winter). The symptom will not be detected after changing engine oil or changing driving condition.

>> **INSPECTION END**

6.CHECK FUEL PRESSURE

Check fuel pressure. (Refer to [EC-135. "Work Procedure"](#).)

Is the inspection result normal?

- YES >> GO TO 9.
- NO-1 >> Fuel pressure is too high: Replace fuel filter and fuel pump assembly (Refer to [FL-6. "Exploded View"](#)), and then GO TO 8.
- NO-2 >> Fuel pressure is too low: GO TO 7.

7.DETECT MALFUNCTIONING PART

Check fuel hoses and fuel tubes for clogging

Is the inspection result normal?

- YES >> Replace fuel filter and fuel pump assembly (Refer to [FL-6. "Exploded View"](#)), and then GO TO 8.
- NO >> Repair or replace and then GO TO 8.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

8. CHECK "A/F ALPHA-B1"

1. Start engine.
2. Select "A/F ALPHA-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> GO TO 9.

9. PERFORM POWER BALANCE TEST

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Make sure that the each cylinder produces a momentary engine speed drop.

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 10.

10. DETECT MALFUNCTIONING PART

Check the following.

1. Ignition coil and its circuit (Refer to [EC-442, "Component Inspection \(Ignition Coil with Power Transistor\)"](#).)
2. Fuel injector and its circuit (Refer to [EC-435, "Component Inspection"](#).)
3. Intake air leakage
4. Low compression pressure (Refer to [EM-13, "Inspection"](#).)

Is the inspection result normal?

YES >> Replace fuel injector (Refer to [EM-40, "Removal and Installation"](#)), and then GO TO 11.

NO >> Repair or replace malfunctioning part and then GO TO 11.

11. CHECK "A/F ALPHA-B1"

1. Start engine.
2. Select "A/F ALPHA-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> GO TO 12.

12. CHECK A/F SENSOR 1 FUNCTION

Perform all DTC CONFIRMATION PROCEDURE related with A/F sensor 1.

- For DTC P0130, refer to [EC-210, "DTC Logic"](#).
- For DTC P0131, refer to [EC-214, "DTC Logic"](#).
- For DTC P0132, refer to [EC-217, "DTC Logic"](#).
- For DTC P2096, P2097, refer to [EC-397, "DTC Logic"](#).

Is any DTC detected?

YES >> GO TO 15.

NO >> GO TO 13.

13. CHECK A/F SENSOR 1 CIRCUIT

Perform DIAGNOSTIC PROCEDURE according to corresponding DTC.

>> GO TO 14.

14. CHECK "A/F ALPHA-B1"

1. Start engine.
2. Select "A/F ALPHA-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> GO TO 15.

15. DISCONNECT AND RECONNECT ECM HARNESS CONNECTOR

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Stop the engine.
2. Disconnect ECM harness connector.
3. Check pin terminal and connector for damage, and then reconnect it.

>> GO TO 16.

16.CHECK "A/F ALPHA-B1"

1. Start engine.
2. Select "A/F ALPHA-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> Detect malfunctioning part according to [EC-452, "Symptom Table"](#).

17.CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO-1 >> More than the SP value: GO TO 18.

NO-2 >> Less than the SP value: GO TO 25.

18.DETECT MALFUNCTIONING PART

1. Check for the cause of large engine friction. Refer to the following.
 - Engine oil level is too high
 - Engine oil viscosity
 - Belt tension of power steering, alternator, A/C compressor, etc. is excessive
 - Noise from engine
 - Noise from transmission, etc.
2. Check for the cause of insufficient combustion. Refer to the following.
 - Valve clearance malfunction
 - Intake valve timing control function malfunction
 - Camshaft sprocket installation malfunction, etc.

>> Repair or replace malfunctioning part, and then GO TO 30.

19.CHECK INTAKE SYSTEM

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system

Is the inspection result normal?

YES >> GO TO 21.

NO >> Repair or replace malfunctioning part, and then GO TO 20.

20.CHECK "A/F ALPHA-B1", AND "B/FUEL SCHDL"

Select "A/F ALPHA-B1" and "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and make sure that each indication is within the SP value.

Is the measurement value within the SP value?

YES >> **INSPECTION END**

NO >> "B/FUEL SCHDL" is more, "A/F ALPHA-B1" is less than the SP value: GO TO 21.

21.DISCONNECT AND RECONNECT MASS AIR FLOW SENSOR HARNESS CONNECTOR

1. Stop the engine.
2. Disconnect mass air flow sensor harness connector.
3. Check pin terminal and connector for damage and then reconnect it again.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

>> GO TO 22.

22.CHECK "A/F ALPHA-B1"

1. Start engine.
2. Select "A/F ALPHA-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> Detect malfunctioning part of mass air flow sensor circuit and repair it. Refer to [EC-187. "DTC Logic"](#). Then GO TO 29.

NO >> GO TO 23.

23.CHECK "MAS A/F SE-B1"

Select "MAS A/F SE-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> GO TO 24.

NO >> More than the SP value: Replace mass air flow sensor (Refer to [EM-28. "Removal and Installation"](#)), and then GO TO 29.

24.REPLACE ECM

1. Replace ECM. Refer to [EC-465. "Removal and Installation"](#).
2. Perform [EC-123. "Work Procedure"](#).

>> GO TO 29.

25.CHECK INTAKE SYSTEM

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system

Is the inspection result normal?

YES >> GO TO 27.

NO >> Repair or replace malfunctioning part, and then GO TO 26.

26.CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> Less than the SP value: GO TO 27.

27.CHECK "MAS A/F SE-B1"

Select "MAS A/F SE-B1" in "SPEC" of "DATA MONITOR" mode, and make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> GO TO 28.

NO >> Less than the SP value: Replace mass air flow sensor (Refer to [EM-28. "Removal and Installation"](#)), and then GO TO 30.

28.CHECK INTAKE SYSTEM

Check for the cause of air leak after the mass air flow sensor. Refer to the following.

- Disconnection, looseness, and cracks in air duct
- Looseness of oil filler cap
- Disconnection of oil level gauge
- Open stuck, breakage, hose disconnection, or cracks of PCV valve
- Disconnection or cracks of EVAP purge hose, open stuck of EVAP canister purge volume control solenoid valve

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- Malfunctioning seal of rocker cover gasket
- Disconnection, looseness, or cracks of hoses, such as vacuum hose, connecting to intake air system parts
- Malfunctioning seal of intake air system, etc.

>> GO TO 30.

29.CHECK "A/F ALPHA-B1" AND "B/FUEL SCHDL"

Select "A/F ALPHA-B1" and "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and make sure that each indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> Detect malfunctioning part according to [EC-452. "Symptom Table"](#).

30.CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "SPEC" of "DATA MONITOR" mode, and then make sure that the indication is within the SP value.

Is the measurement value within the SP value?

YES >> INSPECTION END

NO >> Detect malfunctioning part according to [EC-452. "Symptom Table"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000009020671

1.CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44. "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2.CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connectors.
2. Check the continuity between ECM harness connector and ground.

| ECM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| F10 | 10 | Ground | Existed |
| | 11 | | |
| E16 | 108 | | |

3. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E55, F55
- Harness for open or short between ECM and ground

>> Repair open circuit or short to power in harness or connectors.

4.CHECK ECM POWER SUPPLY CIRCUIT-I

1. Reconnect ECM harness connectors.
2. Turn ignition switch ON.
3. Check the voltage between ECM harness connector and ground.

| ECM | | Ground | Voltage |
|-----------|----------|--------|-----------------|
| Connector | Terminal | | |
| E16 | 93 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 5.

5.DETECT MALFUNCTIONING PART

Check the following.

- 10 A fuse (No. 55)
- Harness for open or short between ECM and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

6.CHECK ECM POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON and then OFF.

POWER SUPPLY AND GROUND CIRCUIT

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Check the voltage between ECM harness connector and ground.

| ECM | | Ground | Voltage |
|-----------|----------|--------|--|
| Connector | Terminal | | |
| E16 | 105 | Ground | After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop to approximately 0 V. |

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 9.

7. CHECK ECM POWER SUPPLY CIRCUIT-III

1. Turn ignition switch ON.
2. Check the voltage between IPDM E/R harness connector and ground.

| IPDM E/R | | Ground | Voltage |
|-----------|----------|--------|-----------------|
| Connector | Terminal | | |
| F43 | 50 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace IPDM E/R. Refer to [PCS-31. "Removal and Installation"](#)(WITH I-KEY), [PCS-60. "Removal and Installation"](#)(WITHOUT I-KEY).

8. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> INSPECTION END

9. CHECK ECM POWER SUPPLY CIRCUIT-IV

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Check the voltage between ECM harness connector and ground.

| ECM | | Ground | Voltage |
|-----------|----------|--------|-----------------|
| Connector | Terminal | | |
| F10 | 32 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 13.

NO >> GO TO 10.

10. CHECK ECM POWER SUPPLY CIRCUIT-V

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector F43.
3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

| ECM | | IPDM E/R | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F10 | 32 | F43 | 50 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 11.

11. DETECT MALFUNCTIONING PART

Check the following.

POWER SUPPLY AND GROUND CIRCUIT

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- Harness for open or short between ECM and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

12.CHECK 20 A FUSE

1. Disconnect 20 A fuse (No. 53) from IPDM E/R.
2. Check 20 A fuse.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Replace 20 A fuse.

13.CHECK ECM POWER SUPPLY CIRCUIT-VI

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector E44.
3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

| ECM | | IPDM E/R | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E16 | 105 | E44 | 11 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair open circuit or short to ground or short power in harness or connectors.

14.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation"](#)(WITH I-KEY), [PCS-60, "Removal and Installation"](#)(WITHOUT I-KEY).

NO >> Repair or replace harness or connectors.

U0101 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

U0101 CAN COMM CIRCUIT

Description

INFOID:000000009020672

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000009020673

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|--|
| U0101 | LOST COMM (TCM) (Lost communication with TCM) | When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) with TCM for 2 seconds or more. | CAN communication line between TCM and ECM |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 3 seconds.
2. Check DTC.

Is DTC detected?

- YES >> Proceed to [EC-160, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020674

Perform the trouble diagnosis for CAN communication system. Refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U0284 ACTIVE GRILLE SHUTTER

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

U0284 ACTIVE GRILLE SHUTTER

DTC Logic

INFOID:000000009509479

DTC DETECTION LOGIC

NOTE:

If DTC U0284 is displayed with another DTC UXXXX, perform trouble diagnosis for DTC UXXXX first. Refer to [EC-86, "DTC Index"](#).

| DTC | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|-------|--|---|---|
| U0284 | LOST COMM (A/GRLL SHTRR MDL A) (Lost communication with active grille air shutter module A) | When ECM cannot receive the engine communication signal from active grille shutter. | <ul style="list-style-type: none"> • Harness and connectors (Engine communication line is open or circuit shorted.) • Active grille shutter |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If another DTC Confirmation Procedure is conducted just before this procedure, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is 10 V or more with ignition switch ON.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-161, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009509480

1. INSPECTION START

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect active grille shutter harness connector.
4. Check the continuity between ECM harness connector and active grille shutter harness connector.

| + | | - | | Continuity |
|-----------|----------|-----------------------|----------|------------|
| ECM | | Active grille shutter | | |
| Connector | Terminal | Connector | Terminal | |
| F11 | 70 | E303 | 2 | Existed |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace the error-detected parts.

2. CHECK INTERMITTENT INCIDENT

Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace active grille shutter. Refer to [EXT-31, "Removal and Installation"](#).
 NO >> Repair or replace the error-detected parts.

U1001 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

U1001 CAN COMM CIRCUIT

Description

INFOID:000000009020675

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000009020676

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---------------------------|---|---|
| U1001 | CAN communication line | When ECM is not transmitting or receiving CAN communication signal other than OBD (emission related diagnosis) for 2 seconds or more. | Harness or connectors (CAN communication line is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 3 seconds.
2. Check DTC.

Is DTC detected?

- YES >> [EC-162. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020677

Go to [LAN-15. "Trouble Diagnosis Flow Chart"](#).

U1040 ENG COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

U1040 ENG COMM CIRCUIT

DTC Logic

INFOID:000000009735336

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---------------------------|---|--|
| U1040 | Engine communication line | When ECM unable to transmit engine communication signal | <ul style="list-style-type: none">• Harness and connectors (Engine communication line is open or shorted.)• ECM |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If another DTC Confirmation Procedure is conducted just before this procedure, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 10 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-163, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009735339

1. CHECK ACTIVE GRILLE SHUTTER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect active grille shutter harness connector.
4. Check the continuity between ECM harness connector and active grille shutter harness connector.

| + | | - | | Continuity |
|-----------|----------|-----------------------|----------|------------|
| ECM | | Active grille shutter | | |
| Connector | Terminal | Connector | Terminal | |
| F11 | 70 | E303 | 2 | Existed |

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2. CHECK INTERMITTENT INCIDENT

Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace ECM. Refer to [EC-465, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P0011 IVT CONTROL

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

P0011 IVT CONTROL

DTC Logic

INFOID:000000009020678

DTC DETECTION LOGIC

NOTE:

If DTC P0011 is displayed with DTC P0075, first perform the trouble diagnosis for DTC P0075. Refer to [EC-177, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | Detecting condition | Possible cause |
|---------|---|--|---|
| P0011 | Intake valve timing control performance | There is a gap between angle of target and phase-control angle degree. | <ul style="list-style-type: none">• Crankshaft position sensor• Camshaft position sensor• Intake valve timing control solenoid valve• Accumulation of debris to the signal pick-up portion of the camshaft• Timing chain installation• Foreign matter caught in the oil groove for intake valve timing control |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10 V and 16 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE-I

With CONSULT

1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT.
2. Start engine and warm it up to the normal operating temperature.
3. Maintain the following conditions for at least 6 consecutive seconds. Hold the accelerator pedal as steady as possible.

| | |
|---------------|---|
| ENG SPEED | 500 - 2,000 rpm |
| COOLAN TEMP/S | More than 60°C (140°F) |
| Shift lever | P or N position (CVT) Neutral position (M/T) |

4. Let engine idle for 10 seconds.
5. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Go to [EC-165, "Diagnosis Procedure"](#)
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-II

With CONSULT

1. Maintain the following conditions for at least 20 consecutive seconds.

P0011 IVT CONTROL

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| | |
|-------------------------|---|
| ENG SPEED | 1,200 - 3,175 rpm (A constant rotation is maintained.) |
| COOLAN TEMP/S | More than 65°C (149°F) |
| Shift lever | 1st or 2nd position |
| Driving location uphill | Driving vehicle uphill (Increased engine load will help maintain the driving conditions required for this test.) |

CAUTION:

Always drive at a safe speed.

2. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Go to [EC-165, "Diagnosis Procedure"](#)
- NO >> INSPECTION END

Diagnosis Procedure


INFOID:000000009020679

1. CHECK OIL PRESSURE WARNING LAMP

1. Start engine.
2. Check oil pressure warning lamp and confirm it is not illuminated.

Is oil pressure warning lamp illuminated?

- YES >> Go to [LU-7, "Inspection"](#).
- NO >> GO TO 2.



2. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-166, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Replace intake valve timing control solenoid valve. Refer to [EM-60, "Exploded View"](#).

3. CHECK CRANKSHAFT POSITION SENSOR

Refer to [EC-277, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace crankshaft position sensor. Refer to [EM-92, "Exploded View"](#).

4. CHECK CAMSHAFT POSITION SENSOR

Refer to [EC-281, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace camshaft position sensor. Refer to [EM-48, "Exploded View"](#).

5. CHECK CAMSHAFT (INTAKE)

Check the following.

P0011 IVT CONTROL


[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft. Refer to [EM-60, "Removal and Installation"](#).



6. CHECK TIMING CHAIN INSTALLATION

Check service records for any recent repairs that may cause timing chain misaligned.

Are there any service records that may cause timing chain misaligned?

- YES >> Check timing chain installation. Refer to [EM-51, "Removal and Installation"](#).
NO >> GO TO 7.

7. CHECK LUBRICATION CIRCUIT

Perform "Inspection of Camshaft Sprocket (INT) Oil Groove". Refer to [EM-68, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 8.
NO >> Clean lubrication line.

8. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020680

1. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE-I

1. Turn ignition switch OFF.
2. Disconnect intake valve timing control solenoid valve harness connector.
3. Check resistance between intake valve timing control solenoid valve terminals as follows.

| Terminals | Resistance [at 20°C (68°F)] |
|-------------------|--------------------------------------|
| 1 and 2 | 7.0 - 7.7 Ω |
| 1 or 2 and ground | ∞ Ω (Continuity should not exist) |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace intake valve timing control solenoid valve. Refer to [EM-60, "Exploded View"](#).

2. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE-II

1. Remove intake valve timing control solenoid valve. Refer to [EM-60, "Exploded View"](#).
2. Apply 12 V between intake valve timing control solenoid valve terminals 1 and 2, and then interrupt it. Make sure that the plunger moves as shown in the figure.


CAUTION:

Do not apply 12 V continuously for 5 seconds or more. Doing so may result in damage to the coil in intake valve timing control solenoid valve.

NOTE:

Always replace O-ring when intake valve timing control solenoid valve is removed.

Is the inspection result normal?



P0011 IVT CONTROL

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

YES >> INSPECTION END

NO >> Replace intake valve timing control solenoid valve. Refer to [EM-60, "Exploded View"](#).

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

P0014 EVT CONTROL

DTC Logic

INFOID:000000009020681

DTC DETECTION LOGIC

NOTE:

If DTC P0014 is displayed with DTC P0078, first perform trouble diagnosis for DTC P0078. Refer to [EC-179, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|--|
| P0014 | EXH/V TIM CONT-B1 (Exhaust valve timing control performance) | There is a gap between angle of target and phase-control angle degree. | <ul style="list-style-type: none"> • Crankshaft position sensor • Exhaust valve timing control position sensor • Exhaust valve timing control solenoid valve • Accumulation of debris to the signal pick-up portion of the camshaft • Timing chain installation • Foreign matter caught in the oil groove for exhaust valve timing control |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10 V and 16 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE-I

 **With CONSULT**

1. Turn ignition switch ON and select "DATA MONITOR" mode of "ENGINE" using CONSULT.
2. Start engine and warm it up to the normal operating temperature.
3. Maintain the following conditions for at least 6 consecutive seconds. Hold the accelerator pedal as steady as possible.

| | |
|----------------|--|
| ENG SPEED | 1,200 - 2,000 rpm (A constant rotation is maintained.) |
| COOLAN TEMP/S | More than 60°C (140°F) |
| Selector lever | P or N position (CVT) Neutral position (M/T) |

4. Let engine idle for 10 seconds.
5. Check 1st trip DTC.

 **With GST**

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-169, "Diagnosis Procedure"](#)
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-II

 **With CONSULT**

1. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
2. Maintain the following conditions for at least 20 consecutive seconds.

P0014 EVT CONTROL

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| | |
|-------------------------|---|
| ENG SPEED | 1,700 - 2,950 rpm (A constant rotation is maintained.) |
| COOLAN TEMP/S | More than 70°C (158°F) |
| Selector lever | 1st or 2nd position |
| Driving location uphill | Driving vehicle uphill (Increased engine load will help maintain the driving conditions required for this test.) |

CAUTION:

Always drive at a safe speed.

3. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-169, "Diagnosis Procedure"](#)
- NO >> INSPECTION END

Diagnosis Procedure


INFOID:000000009020682

1. CHECK OIL PRESSURE WARNING LAMP

1. Start engine.
2. Check oil pressure warning lamp and confirm it is not illuminated.

Is oil pressure warning lamp illuminated?

- YES >> Check the engine oil level. Refer to [LU-7, "Inspection"](#).
- NO >> GO TO 2.



2. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE

Check the exhaust valve timing control solenoid valve. Refer to [EC-170, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Replace exhaust valve timing control solenoid valve. Refer to [EM-60, "Exploded View"](#).

3. CHECK CRANKSHAFT POSITION SENSOR

Check the crankshaft position sensor. Refer to [EC-277, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace crankshaft position sensor. Refer to [EM-92, "Exploded View"](#).

4. CHECK EXHAUST VALVE TIMING CONTROL POSITION SENSOR

Check the exhaust valve timing control position sensor. Refer to [EC-281, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace exhaust valve timing control position sensor. Refer to [EM-60, "Exploded View"](#).

5. CHECK CAMSHAFT (EXHAUST)

Check the following.

P0014 EVT CONTROL


[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft. Refer to [EM-60. "Removal and Installation"](#).



6. CHECK TIMING CHAIN INSTALLATION

Check service records for any recent repairs that may cause timing chain misaligned.

Are there any service records that may cause timing chain misaligned?

- YES >> Check timing chain installation. Refer to [EM-51. "Removal and Installation"](#).
 NO >> GO TO 7.

7. CHECK LUBRICATION CIRCUIT

Refer to [LU-7. "Inspection"](#), "INSPECTION AFTER INSTALLATION".

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
 NO >> Clean lubrication line.

Component Inspection

INFOID:000000009020683

1. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE-I

1. Turn ignition switch OFF.
2. Disconnect exhaust valve timing control solenoid valve harness connector.
3. Check resistance between exhaust valve timing control solenoid valve terminals as per the following.

| Exhaust valve timing control solenoid valve | | Resistance |
|---|--------|-------------------------------------|
| + | - | |
| Terminal | | |
| 1 | 2 | 7.0 - 7.7 Ω [at 20°C (68°F)] |
| 1 | Ground | $\infty \Omega$ |
| 2 | | (Continuity should not exist) |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace exhaust valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).

2. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE-II

1. Remove exhaust valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).
2. Provide 12 V DC between exhaust valve timing control solenoid valve terminals 1 and 2, and then interrupt it. Check that the plunger moves as shown in the figure.

CAUTION:


Do not apply 12 V DC continuously for 5 seconds or more. Doing so may result in damage to the coil in exhaust valve timing control solenoid valve.

NOTE:

Always replace O-ring when exhaust valve timing control solenoid valve is removed.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace exhaust valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).



P0031, P0032 A/F SENSOR 1 HEATER

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0031, P0032 A/F SENSOR 1 HEATER

DTC Logic

INFOID:000000009020684

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P0031 | Air fuel ratio (A/F) sensor 1 heater control circuit low | The current amperage in the A/F sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the A/F sensor 1 heater.) | <ul style="list-style-type: none"> • Harness or connectors (The A/F sensor 1 heater circuit is open or shorted.) • A/F sensor 1 heater |
| P0032 | Air fuel ratio (A/F) sensor 1 heater control circuit high | The current amperage in the A/F sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the A/F sensor 1 heater.) | <ul style="list-style-type: none"> • Harness or connectors (The A/F sensor 1 heater circuit is shorted.) • A/F sensor 1 heater |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10 V and 16 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for at least 10 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-171, "Diagnosis Procedure"](#).
 NG >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020685

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace ground connection.

2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect air fuel ratio (A/F) sensor 1 harness connector.
2. Turn ignition switch ON.
3. Check the voltage between A/F sensor 1 harness connector and ground.

| A/F sensor 1 | | Ground | Voltage |
|--------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F12 | 4 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 3.

P0031, P0032 A/F SENSOR 1 HEATER

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

3. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F42
- 20A fuse (No. 53)
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

4. CHECK A/F SENSOR 1 HEATER OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 3 | F10 | 3 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK A/F SENSOR 1 HEATER

Refer to [EC-172. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1. Refer to [EM-31. "Exploded View"](#).

CAUTION:

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J-43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Perform [GI-41. "Intermittent Incident"](#).

>> Repair or replace.

Component Inspection

INFOID:000000009020686

1. CHECK AIR FUEL RATIO (A/F) SENSOR 1

1. Turn ignition switch OFF.
2. Disconnect A/F sensor 1 harness connector.
3. Check resistance between A/F sensor 1 terminals as follows.

| Terminal | Resistance |
|------------|---------------------------------------|
| 3 and 4 | 1.98 - 2.66 Ω [at 25°C (77°F)] |
| 3 and 1, 2 | $\infty \Omega$ |
| 4 and 1, 2 | (Continuity should not exist) |

P0031, P0032 A/F SENSOR 1 HEATER

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1. Refer to [EM-31. "Exploded View"](#).

CAUTION:

- Discard any air fuel ratio (A/F) sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new air fuel ratio (A/F) sensor, clean exhaust system threads using Heated Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J-43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

P0037, P0038 HO2S2 HEATER

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0037, P0038 HO2S2 HEATER

DTC Logic

INFOID:000000009020687

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P0037 | HO2 HTR (B1) (Heated oxygen sensor 2 heater control circuit low) | The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.) | <ul style="list-style-type: none">• Harness or connectors (Heated oxygen sensor 2 heater circuit is open or shorted.)• Heated oxygen sensor 2 heater |
| P0038 | HO2 HTR (B1) (Heated oxygen sensor 2 heater control circuit high) | The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.) | <ul style="list-style-type: none">• Harness or connectors (Heated oxygen sensor 2 heater circuit is shorted.)• Heated oxygen sensor 2 heater |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Turn ignition switch ON and select "DATA MONITOR" mode of "ENGINE" using CONSULT.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-174, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020688

1. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 (HO2S2) harness connector.
3. Turn ignition switch ON.
4. Check the voltage between HO2S2 harness connector and ground.

| HO2S2 | | Ground | Voltage |
|-----------|----------|--------|-----------------|
| Connector | Terminal | | |
| E63 | 2 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.

P0037, P0038 HO2S2 HEATER

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace error-detected parts.

2.CHECK HO2S2 OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between HO2S2 harness connector and ECM harness connector.

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 3 | F10 | 5 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK HEATED OXYGEN SENSOR 2 HEATER

Check the heated oxygen sensor 2 heater. Refer to [EC-175, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 4.

4.REPLACE HEATED OXYGEN SENSOR 2

Replace heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

CAUTION:

- Discard any sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved Anti-seize Lubricant (commercial service tool).

>> INSPECTION END

Component Inspection

INFOID:000000009020689

1.CHECK HEATED OXYGEN SENSOR 2 HEATER

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 (HO2S2) harness connector.
3. Check resistance between HO2S2 terminals as per the following.

| Heated oxygen sensor 2 | | Resistance |
|------------------------|---|--|
| + | - | |
| Terminal | | |
| 2 | 3 | 3.4 - 4.4 Ω [at 25°C (77°F)] |
| 1 | 2 | $\infty \Omega$ (Continuity should not exist) |
| | 3 | |
| | 4 | |
| 4 | 1 | |
| | 2 | |
| | 3 | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.REPLACE HEATED OXYGEN SENSOR 2

P0037, P0038 HO2S2 HEATER

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Replace heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

CAUTION:

- Discard any sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved Anti-seize Lubricant (commercial service tool).

>> INSPECTION END

P0075 IVT CONTROL SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0075 IVT CONTROL SOLENOID VALVE

DTC Logic

INFOID:000000009020690

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|--|--|
| P0075 | Intake valve timing control solenoid valve circuit | An improper voltage is sent to the ECM through intake valve timing control solenoid valve. | <ul style="list-style-type: none"> Harness or connectors (Intake valve timing control solenoid valve circuit is open or shorted.) Intake valve timing control solenoid valve |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-177. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020691

1. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake valve timing (IVT) control solenoid valve harness connector.
3. Turn ignition switch ON.
4. Check the voltage between intake valve timing control solenoid valve harness connector and ground.

| IVT control solenoid valve | | Ground | Voltage |
|----------------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F23 | 2 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between intake valve timing control solenoid valve and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.

P0075 IVT CONTROL SOLENOID VALVE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

3. Check the continuity between intake valve timing control solenoid valve harness connector and ECM harness connector.

| IVT control solenoid valve | | ECM | | Continuity |
|----------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F23 | 1 | F11 | 73 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-178. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace intake valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020692

1.CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE-I

1. Turn ignition switch OFF.
2. Disconnect intake valve timing control solenoid valve harness connector.
3. Check resistance between intake valve timing control solenoid valve terminals as follows.

| Terminals | Resistance [at 20°C (68°F)] |
|-------------------|--------------------------------------|
| 1 and 2 | 7.0 - 7.7 Ω |
| 1 or 2 and ground | ∞ Ω (Continuity should not exist) |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace intake valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#)

2.CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE-II

1. Remove intake valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).
2. Apply 12 V between intake valve timing control solenoid valve terminals 1 and 2, and then interrupt it. Make sure that the plunger moves as shown in the figure.

CAUTION:

Do not apply 12 V continuously for 5 seconds or more. Doing so may result in damage to the coil in intake valve timing control solenoid valve.


NOTE:

Always replace O-ring when intake valve timing control solenoid valve is removed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace intake valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).



P0078 EVT CONTROL SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0078 EVT CONTROL SOLENOID VALVE

DTC Logic

INFOID:000000009020693

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P0078 | EX V/T ACT/CIRC-B1 (Exhaust valve timing control solenoid valve circuit) | An improper voltage is sent to the ECM through exhaust valve timing control solenoid valve. | <ul style="list-style-type: none"> Harness or connectors (Exhaust valve timing control solenoid valve circuit is open or shorted.) Exhaust valve timing control solenoid valve |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for 5 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-179. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020694

1. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE POWER SUPPLY

- Turn ignition switch OFF.
- Disconnect exhaust valve timing (EVT) control solenoid valve harness connector.
- Turn ignition switch ON.
- Check the voltage between exhaust valve timing control solenoid valve harness connector and ground.

| EVT control solenoid valve | | Ground | Voltage |
|----------------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F32 | 2 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect IPDM E/R harness connector.
- Check the continuity between EVT control solenoid valve harness connector and IPDM E/R harness connector.

| EVT control solenoid valve | | IPDM E/R | | Continuity |
|----------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F32 | 2 | F42 | 39 | Existed |

- Also check harness for short to ground.

P0078 EVT CONTROL SOLENOID VALVE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit.

NO >> Repair or replace error-detected parts.

3. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVT control solenoid valve harness connector and ECM harness connector.

| EVT control solenoid valve | | ECM | | Continuity |
|----------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F32 | 1 | F11 | 77 | Existed |

4. Also check harness for short to ground and to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE

Check the exhaust valve timing control solenoid valve. Refer to [EC-180. "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO >> Replace exhaust valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).

Component Inspection

INFOID:000000009020695

1. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE-I

1. Turn ignition switch OFF.
2. Disconnect exhaust valve timing control solenoid valve harness connector.
3. Check resistance between exhaust valve timing control solenoid valve terminals as per the following.

| Exhaust valve timing control solenoid valve | | Resistance |
|---|--------|-------------------------------------|
| + | - | |
| Terminal | | |
| 1 | 2 | 7.0 - 7.7 Ω [at 20°C (68°F)] |
| 1 | Ground | $\infty \Omega$ |
| 2 | | (Continuity should not exist) |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace exhaust valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).

2. CHECK EXHAUST VALVE TIMING CONTROL SOLENOID VALVE-II

1. Remove exhaust valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).
2. Provide 12 V DC between exhaust valve timing control solenoid valve terminals 1 and 2, and then interrupt it. Check that the plunger moves as shown in the figure.

CAUTION:


Do not apply 12 V DC continuously for 5 seconds or more. Doing so may result in damage to the coil in exhaust valve timing control solenoid valve.

NOTE:

Always replace O-ring when exhaust valve timing control solenoid valve is removed.

Is the inspection result normal?

YES >> INSPECTION END



P0078 EVT CONTROL SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

NO >> Replace exhaust valve timing control solenoid valve. Refer to [EM-60. "Exploded View"](#).

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

P0101 MAF SENSOR

DTC Logic

INFOID:000000009020696

DTC DETECTION LOGIC

NOTE:

If DTC P0101 is displayed with other DTC, first perform the trouble diagnosis for other DTC.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P0101 | MAF SEN/CIRCUIT-B1 [Mass air flow (MAF) sensor circuit range/performance] | <ul style="list-style-type: none"> • A high voltage from the sensor is sent to ECM under light load driving condition. • A low voltage from the sensor is sent to ECM under heavy load driving condition. | <ul style="list-style-type: none"> • Harness or connectors (MAF sensor circuit is open or shorted.) • Intake air leaks (e.g. poor connection) • MAF sensor • EVAP control system pressure sensor • Intake air temperature sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC CONFIRMATION PROCEDURE has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and warm it up to normal operating temperature.
2. Drive the vehicle for at least 5 seconds under the following conditions:

CAUTION:

Always drive vehicle at safe speed.

| | |
|----------------|--------------------------|
| Selector lever | Suitable position |
| Vehicle speed | 40 km/h (25 MPH) or more |

NOTE:

- The gear must be fixed while driving the vehicle.
- Keep the accelerator pedal as steady as possible during cruising.

3. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-182, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020697

1. CHECK INTAKE SYSTEM

Check the following items to see the installation condition and the connection condition of the joint.

- Air duct
- Vacuum hoses
- Intake air passage between air duct and intake manifold

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Reconnect or replace error-detected parts.

2. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.

P0101 MAF SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace ground connection.

3. CHECK MASS AIR FLOW (MAF) SENSOR POWER SUPPLY CIRCUIT

1. Disconnect MAF sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between MAF sensor harness connector and ground.

| MAF sensor | | Ground | Voltage |
|------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F31 | 2 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E55, F55
- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between MAF sensor harness connector and ECM harness connector.

| MAF sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F31 | 3 | F11 | 52 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between MAF sensor harness connector and ECM harness connector.

| MAF sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F31 | 4 | F11 | 45 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK INTAKE AIR TEMPERATURE SENSOR

Check the intake air temperature sensor. Refer to [EC-193, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.

P0101 MAF SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace MAF sensor (with intake air temperature sensor). Refer to [EM-26. "Removal and Installation"](#).

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Check the EVAP control system pressure sensor. Refer to [EC-310. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19. "Removal and Installation"](#).

9. CHECK MAF SENSOR

Check the MAF sensor. Refer to [EC-184. "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO >> Replace MAF sensor. Refer to [EM-26. "Removal and Installation"](#).

Component Inspection

INFOID:000000009020698

1. CHECK MASS AIR FLOW SENSOR-I

With CONSULT

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Start engine and warm it up to normal operating temperature.
4. Connect CONSULT and select "DATA MONITOR" mode of "ENGINE".
5. Select "MAS A/F SE-B1" and check indication.

| Monitor item | Condition | MAS A/F SE-B1 |
|---------------|--|-------------------------------|
| MAS A/F SE-B1 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Without CONSULT

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Start engine and warm it up to normal operating temperature.
4. Check the voltage between ECM harness connector and ground.

| Connector | ECM | | Condition | Voltage |
|-----------|----------|----|--|-------------------------------|
| | + | - | | |
| | Terminal | | | |
| F11 | 45 | 52 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | | | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | | | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | | | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK FOR THE CAUSE OF UNEVEN AIR FLOW THROUGH MASS AIR FLOW SENSOR

1. Turn ignition switch OFF.
2. Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.
 - Crushed air ducts
 - Malfunctioning seal of air cleaner element

P0101 MAF SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- Uneven dirt of air cleaner element
- Improper specification of intake air system parts

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 3.

3. CHECK MASS AIR FLOW SENSOR-II

☑ With CONSULT

1. Repair or replace malfunctioning part.
2. Start engine and warm it up to normal operating temperature.
3. Connect CONSULT and select "DATA MONITOR" mode of "ENGINE".
4. Select "MAS A/F SE-B1" and check indication.

| Monitor item | Condition | MAS A/F SE-B1 |
|---------------|--|-------------------------------|
| MAS A/F SE-B1 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

☒ Without CONSULT

1. Repair or replace malfunctioning part.
2. Start engine and warm it up to normal operating temperature.
3. Check the voltage between ECM harness connector and ground.

| ECM | | | Condition | Voltage |
|-----------|----|----|--|-------------------------------|
| Connector | + | - | | |
| F11 | 45 | 52 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | | | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | | | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | | | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 4.

4. CHECK MASS AIR FLOW SENSOR-III

☑ With CONSULT

1. Turn ignition switch OFF.
2. Disconnect mass air flow sensor harness connector and reconnect it again.
3. Start engine and warm it up to normal operating temperature.
4. Connect CONSULT and select "DATA MONITOR" mode of "ENGINE".
5. Select "MAS A/F SE-B1" and check indication.

| Monitor item | Condition | MAS A/F SE-B1 |
|---------------|--|-------------------------------|
| MAS A/F SE-B1 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

☒ Without CONSULT

1. Turn ignition switch OFF.

P0101 MAF SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect mass air flow sensor harness connector and reconnect it again.
3. Start engine and warm it up to normal operating temperature.
4. Check the voltage between ECM harness connector and ground.

| ECM | | | Condition | Voltage |
|-----------|----------|----|--|-------------------------------|
| Connector | + | - | | |
| | Terminal | | | |
| F11 | 45 | 52 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | | | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | | | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | | | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Clean or replace mass air flow sensor. Refer to [EM-26. "Removal and Installation"](#).

P0102, P0103 MAF SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0102, P0103 MAF SENSOR

DTC Logic

INFOID:000000009020699

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P0102 | Mass air flow sensor circuit low input | An excessively low voltage from the sensor is sent to ECM. | <ul style="list-style-type: none">• Harness or connectors (The sensor circuit is open or shorted.)• Intake air leakage• Mass air flow sensor |
| P0103 | Mass air flow sensor circuit high input | An excessively high voltage from the sensor is sent to ECM. | <ul style="list-style-type: none">• Harness or connectors (The sensor circuit is open or shorted.)• Mass air flow sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

Which DTC is detected?

- P0102 >> GO TO 2.
- P0103 >> GO TO 3.

2. PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P0102

1. Start engine and wait at least 5 seconds.
2. Check DTC.

Is DTC detected?

- YES >> Go to [EC-187. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

3. PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P0103-I

1. Turn ignition switch ON and wait at least 5 seconds.
2. Check DTC.

Is DTC detected?

- YES >> Go to [EC-187. "Diagnosis Procedure"](#).
- NO >> GO TO 4.

4. PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P0103-II

1. Start engine and wait at least 5 seconds.
2. Check DTC.

Is DTC detected?

- YES >> Go to [EC-187. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020700

1. INSPECTION START

Confirm the detected DTC.

Which DTC is detected?

- P0102 >> GO TO 2.
- P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Reconnect the parts.

3.CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44. "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace ground connection.

4.CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow (MAF) sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between MAF sensor harness connector and ground.

| MAF sensor | | Ground | Voltage |
|------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F31 | 2 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5.CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between MAF sensor harness connector and ECM harness connector.

| MAF sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F31 | 3 | F11 | 52 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair open circuit or short to ground or short to power in harness or connectors.

6.CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between MAF sensor harness connector and ECM harness connector.

| MAF sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F31 | 4 | F11 | 45 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Repair open circuit or short to ground or short to power in harness or connectors.

7.CHECK MASS AIR FLOW SENSOR

Refer to [EC-189. "Component Inspection"](#).

Is the inspection result normal?

P0102, P0103 MAF SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 8.
 NO >> Replace mass air flow sensor. Refer to [EM-26, "Removal and Installation"](#).

8.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020701

1.CHECK MASS AIR FLOW SENSOR-I

With CONSULT

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Start engine and warm it up to normal operating temperature.
4. Connect CONSULT and select "DATA MONITOR" mode.
5. Select "MAS A/F SE-B1" and check indication.

| Monitor item | Condition | MAS A/F SE-B1 |
|---------------|--|-------------------------------|
| MAS A/F SE-B1 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Without CONSULT

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Start engine and warm it up to normal operating temperature.
4. Check the voltage between ECM harness connector and ground.

| ECM | | | Condition | Voltage |
|-----------|------------------------------|----|--|-------------------------------|
| Connector | Terminal | | | |
| | | + | - | |
| F11 | 45 (MAF sensor signal) | 52 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | | | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | | | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | | | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> GO TO 2.

2.CHECK FOR THE CAUSE OF UNEVEN AIR FLOW THROUGH MASS AIR FLOW SENSOR

1. Turn ignition switch OFF.
2. Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.
 - Crushed air ducts
 - Malfunctioning seal of air cleaner element
 - Uneven dirt of air cleaner element
 - Improper specification of intake air system parts

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 3.

3.CHECK MASS AIR FLOW SENSOR-II

P0102, P0103 MAF SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Ⓟ With CONSULT

1. Repair or replace malfunctioning part.
2. Start engine and warm it up to normal operating temperature.
3. Connect CONSULT and select "DATA MONITOR" mode.
4. Select "MAS A/F SE-B1" and check indication.

| Monitor item | Condition | MAS A/F SE-B1 |
|---------------|--|-------------------------------|
| MAS A/F SE-B1 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

ⓧ Without CONSULT

1. Repair or replace malfunctioning part.
2. Start engine and warm it up to normal operating temperature.
3. Check the voltage between ECM harness connector and ground.

| ECM | | | Condition | Voltage |
|-----------|---------------------------|----|--|-------------------------------|
| Connector | Terminal | | | |
| | + | - | | |
| F11 | 45 (MAF sensor signal) | 52 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | | | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | | | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | | | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> GO TO 4.

4. CHECK MASS AIR FLOW SENSOR-III

Ⓟ With CONSULT

1. Turn ignition switch OFF.
2. Disconnect mass air flow sensor harness connector and reconnect it again.
3. Start engine and warm it up to normal operating temperature.
4. Connect CONSULT and select "DATA MONITOR" mode.
5. Select "MAS A/F SE-B1" and check indication.

| Monitor item | Condition | MAS A/F SE-B1 |
|---------------|--|-------------------------------|
| MAS A/F SE-B1 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

ⓧ Without CONSULT

1. Turn ignition switch OFF.
2. Disconnect mass air flow sensor harness connector and reconnect it again.
3. Start engine and warm it up to normal operating temperature.
4. Check the voltage between ECM harness connector and ground.

P0102, P0103 MAF SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECM | | | Condition | Voltage |
|-----------|------------------------------|----|--|-------------------------------|
| Connector | Terminal | | | |
| | + | - | | |
| F11 | 45 (MAF sensor signal) | 52 | Ignition switch ON (Engine stopped.) | Approx. 0.4 V |
| | | | Idle (Engine is warmed-up to normal operating temperature.) | 0.8 - 1.3 V |
| | | | 2,500 rpm (Engine is warmed-up to normal operating temperature.) | 1.4 - 1.9 V |
| | | | Idle to about 4,000 rpm | 0.8 - 1.3 V to Approx. 2.4 V* |

*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Clean or replace mass air flow sensor. Refer to [EM-26, "Removal and Installation"](#).

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P0111 IAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0111 IAT SENSOR

DTC Logic

INFOID:000000009020702

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|--|--|---|
| P0111 | IAT SENSOR 1 B1 [Intake air temperature (IAT) sensor circuit range/performance] | The comparison result of signals transmitted to ECM from each temperature sensor (IAT sensor, ECT sensor, FTT sensor, and EOT sensor) shows that the voltage signal of the IAT sensor is higher/lower than that of other temperature sensors when the engine is started with its cold state. | <ul style="list-style-type: none">• Harness or connectors (High or low resistance in the IAT sensor circuit)• IAT sensor |

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Is it necessary to erase permanent DTC?

- YES >> GO TO 3.
NO >> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-193, "Component Function Check"](#).

NOTE:

Use the component function check to check the overall function of the IAT sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Proceed to [EC-193, "Diagnosis Procedure"](#).

3.PRECONDITIONING

If DTC CONFIRMATION PROCEDURE has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

- Before performing the following procedure, do not add fuel.
- Before performing the following procedure, check that fuel level is between 1/4 and 4/4.
- Before performing the following procedure, confirm that battery voltage is 11 V or more at idle.

>> GO TO 4.

4.PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 60 minutes.
2. Move the vehicle to a cool place.

NOTE:

Cool the vehicle in an environment of ambient air temperature between -10°C (14°F) and 35°C (95°F).

3. Turn ignition switch OFF and soak the vehicle for 12 hours.

CAUTION:

Never turn ignition switch ON during soaking.

NOTE:

The vehicle must be cooled with the hood open.

4. Start engine and let it idle for 5 minutes or more.

CAUTION:

Never turn ignition switch OFF during idling.

5. Check 1st trip DTC.

P0111 IAT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is 1st trip DTC detected?

- YES >> Proceed to [EC-193, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Component Function Check

INFOID:000000009020703

A

EC

1.CHECK INTAKE AIR TEMPERATURE (IAT) SENSOR

1. Turn ignition switch OFF.
2. Disconnect mass air flow sensor harness connector.
3. Check resistance between mass air flow sensor terminals as follows.

C

| Mass air flow sensor | | Condition | Resistance (kΩ) |
|----------------------|---|-----------------------|-----------------------|
| Terminal | | | |
| 5 | 6 | Temperature [°C (°F)] | 25 (77) 1.800 – 2.200 |

D

E

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> Proceed to [EC-193, "Diagnosis Procedure"](#).

F

Diagnosis Procedure

INFOID:000000009020704

1.CHECK INTAKE AIR TEMPERATURE (IAT) SENSOR

G

Check intake air temperature sensor. Refer to [EC-193, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> Replace mass air flow sensor (with intake air temperature sensor). Refer to [EM-26, "Removal and Installation"](#).

H

I

Component Inspection

INFOID:000000009020705

1.CHECK INTAKE AIR TEMPERATURE SENSOR

J

1. Turn ignition switch OFF.
2. Disconnect mass air flow sensor harness connector.
3. Check resistance between mass air flow sensor terminals as per the following.

K

| Mass air flow sensor | | Condition | Resistance (kΩ) |
|----------------------|---|-----------------------|-----------------------|
| Terminals | | | |
| 5 | 6 | Temperature [°C (°F)] | 25 (77) 1.800 - 2.200 |

L

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace mass air flow sensor (with intake air temperature sensor). Refer to [EM-26, "Removal and Installation"](#).

M

N

O

P

P0112, P0113 IAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0112, P0113 IAT SENSOR

DTC Logic

INFOID:000000009020706

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|--|
| P0112 | Intake air temperature sensor circuit low input | An excessively low voltage from the sensor is sent to ECM. | • Harness or connectors (The sensor circuit is open or shorted.) • Intake air temperature sensor |
| P0113 | Intake air temperature sensor circuit high input | An excessively high voltage from the sensor is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-194, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020707

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect mass air flow (MAF) sensor (with intake air temperature sensor) harness connector.
2. Turn ignition switch ON.
3. Check the voltage between mass air flow sensor harness connector and ground.

| MAF sensor | | Ground | Voltage |
|------------|----------|--------|-------------|
| Connector | Terminal | | |
| F31 | 5 | Ground | Approx. 5 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between mass air flow sensor harness connector and ECM harness connector.

P0112, P0113 IAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| MAF sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F31 | 6 | F11 | 55 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-195. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace mass air flow sensor (with intake air temperature sensor). Refer to [EM-26. "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020708

1.CHECK INTAKE AIR TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect mass air flow sensor harness connector.
3. Check resistance between mass air flow sensor terminals as follows.

| Terminals | Condition | Resistance |
|-----------|----------------------------------|------------------|
| 5 and 6 | Temperature [°C (°F)] 25 (77) | 1.800 - 2.200 kΩ |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace mass air flow sensor (with intake air temperature sensor). Refer to [EM-26. "Removal and Installation"](#).

P0116 ECT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

P0116 ECT SENSOR

DTC Logic

INFOID:000000009020709

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|---|
| P0116 | ECT SEN/CIRC [Engine coolant temperature (ECT) sensor circuit range/per- formance] | The comparison result of signals transmitted to ECM from each temperature sensor (IAT sensor, ECT sensor, FTT sensor, and EOT sensor) shows that the voltage signal of the ECT sensor is higher/lower than that of other temperature sensors when the engine is started with its cold state. | <ul style="list-style-type: none">• Harness or connectors (High or low resistance in the ECT sensor circuit)• ECT sensor |

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Is it necessary to erase permanent DTC?

YES >> GO TO 3.

NO >> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-197, "Component Function Check"](#).

NOTE:

Use the component function check to check the overall function of the ECT sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to [EC-197, "Diagnosis Procedure"](#).

3.PRECONDITIONING

If DTC CONFIRMATION PROCEDURE has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

- Before performing the following procedure, do not add fuel.
- Before performing the following procedure, check that fuel level is between 1/4 and 4/4.
- Before performing the following procedure, confirm that battery voltage is 11 V or more at idle.

>> GO TO 4.

4.PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 60 minutes.
2. Move the vehicle to a cool place.

NOTE:

Cool the vehicle in an environment of ambient air temperature between -10°C (14°F) and 35°C (95°F).

3. Turn ignition switch OFF and soak the vehicle for 12 hours.

CAUTION:

Never turn ignition switch ON during soaking.

NOTE:

The vehicle must be cooled with the hood open.

4. Start engine and let it idle for 5 minutes or more.

CAUTION:

Never turn ignition switch OFF during idling.

< DTC/CIRCUIT DIAGNOSIS >

5. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-197, "Diagnosis Procedure"](#).
- NO >> INSPECTION END


Component Function Check

INFOID:000000009020710

1. CHECK ENGINE COOLANT TEMPERATURE (ECT) SENSOR

1. Turn ignition switch OFF.
2. Disconnect ECT sensor harness connector.
3. Remove ECT sensor. Refer to [CO-24, "Exploded View"](#).
4. Check resistance between ECT sensor terminals by heating with hot water as shown in the figure.

| ECT sensor | | Condition | Resistance (kΩ) |
|------------|---|-----------------------|-----------------|
| Terminal | | | |
| 1 | 2 | Temperature [°C (°F)] | 20 (68) |
| | | | 50 (122) |
| | | | 90 (194) |



Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> Proceed to [EC-197, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020711

1. CHECK ENGINE COOLANT TEMPERATURE (ECT) SENSOR

Check ECT sensor. Refer to [EC-197, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> Replace ECT sensor. Refer to [CO-24, "Exploded View"](#).


Component Inspection

INFOID:000000009020712

1. CHECK ENGINE COOLANT TEMPERATURE (ECT) SENSOR

1. Turn ignition switch OFF.
2. Disconnect ECT sensor harness connector.
3. Remove ECT sensor.
4. Check resistance between ECT sensor terminals by heating with hot water as shown in the figure.

| ECT sensor | | Condition | Resistance (kΩ) |
|------------|---|-----------------------|-----------------|
| Terminal | | | |
| 1 | 2 | Temperature [°C (°F)] | 20 (68) |
| | | | 50 (122) |
| | | | 90 (194) |



Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace engine coolant temperature sensor. Refer to [CO-24, "Exploded View"](#).

P0117, P0118 ECT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

P0117, P0118 ECT SENSOR

DTC Logic

INFOID:000000009020713

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|--|
| P0117 | Engine coolant temperature sensor circuit low input | An excessively low voltage from the sensor is sent to ECM. | <ul style="list-style-type: none">• Harness or connectors (The sensor circuit is open or shorted.)• Engine coolant temperature sensor |
| P0118 | Engine coolant temperature sensor circuit high input | An excessively high voltage from the sensor is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 5 seconds.
2. Check DTC.

Is DTC detected?

- YES >> Go to [EC-198, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020714

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

1. Disconnect engine coolant temperature (ECT) sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between ECT sensor harness connector and ground.

| ECT sensor | | Ground | Voltage |
|------------|----------|--------|-------------|
| Connector | Terminal | | |
| F6 | 1 | Ground | Approx. 5 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between ECT sensor harness connector and ECM harness connector.

P0117, P0118 ECT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECT sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F6 | 2 | F11 | 44 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-199. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace engine coolant temperature sensor. Refer to [CO-24. "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020715

1.CHECK ENGINE COOLANT TEMPERATURE SENSOR


1. Turn ignition switch OFF.
2. Disconnect engine coolant temperature sensor harness connector.
3. Remove engine coolant temperature sensor. Refer to [CO-24. "Exploded View"](#)
4. Check resistance between engine coolant temperature sensor terminals by heating with hot water as shown in the figure.

| Terminals | Condition | Resistance | |
|-----------|-----------------------|------------|------------------|
| 1 and 2 | Temperature [°C (°F)] | 20 (68) | 2.10 - 2.90 kΩ |
| | | 50 (122) | 0.68 - 1.00 kΩ |
| | | 90 (194) | 0.236 - 0.260 kΩ |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace engine coolant temperature sensor. Refer to [CO-24. "Exploded View"](#).



P0122, P0123 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0122, P0123 TP SENSOR

DTC Logic

INFOID:000000009020716

DTC DETECTION LOGIC

NOTE:

If DTC P0122 or P0123 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|--|---|
| P0122 | Throttle position sensor 2 circuit low input | An excessively low voltage from the TP sensor 2 is sent to ECM. | <ul style="list-style-type: none"> • Harness or connectors (TP sensor 2 circuit is open or shorted.) • Electric throttle control actuator (TP sensor 2) |
| P0123 | Throttle position sensor 2 circuit high input | An excessively high voltage from the TP sensor 2 is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 1 second.
2. Check DTC.

Is DTC detected?

YES >> Go to [EC-200, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020717

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.
3. Check the voltage between electric throttle control actuator harness connector and ground.

| Electric throttle control actuator | | Ground | Voltage |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| F7 | 2 | Ground | Approx. 5 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

P0122, P0123 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

3. CHECK THROTTLE POSITION SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

| Electric throttle control actuator | | ECM | | Continuity |
|------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F7 | 4 | F11 | 36 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

| Electric throttle control actuator | | ECM | | Continuity |
|------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F7 | 3 | F11 | 34 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-201, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020718

1. CHECK THROTTLE POSITION SENSOR

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Perform [EC-127, "Work Procedure"](#).
4. Turn ignition switch ON.
5. Set selector lever to D (CVT) or 1st (M/T) position.
6. Check the voltage between ECM harness connector and ground.

P0122, P0123 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECM | | | Condition | Voltage |
|-----------|----------------------------|----|-----------------|------------------|
| Connector | Terminal | | | |
| | + | - | | |
| F11 | 33 (TP sensor 1 signal) | 36 | Fully released | More than 0.36 V |
| | | | Fully depressed | Less than 4.75 V |
| | 34 (TP sensor 2 signal) | | Fully released | Less than 4.75 V |
| | | | Fully depressed | More than 0.36 V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

P0125 ECT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0125 ECT SENSOR

DTC Logic

INFOID:000000009020719

DTC DETECTION LOGIC

NOTE:

- If DTC P0125 is displayed with P0116, first perform the trouble diagnosis for DTC P0116. Refer to [EC-196, "DTC Logic"](#).
- If DTC P0125 is displayed with P0117 or P0118, first perform the trouble diagnosis for DTC P0117 or P0118. Refer to [EC-198, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|--|--|---|
| P0125 | ECT SENSOR (Insufficient engine coolant temperature for closed loop fuel control) | <ul style="list-style-type: none">• Voltage sent to ECM from the sensor is not practical, even when some time has passed after starting the engine.• Engine coolant temperature is insufficient for closed loop fuel control. | <ul style="list-style-type: none">• Harness or connectors (High resistance in the circuit)• Engine coolant temperature sensor• Thermostat |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. CHECK ENGINE COOLANT TEMPERATURE SENSOR FUNCTION

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
3. Check "COOLAN TEMP/S".

Ⓜ With GST

Follow the procedure "With CONSULT" above.

Is it above 5°C (41°F)?

- YES >> INSPECTION END
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

1. Start engine and run it for 65 minutes at idle speed.
2. Check 1st trip DTC.

If "COOLAN TEMP/S" indication increases to more than 10°C (50°F) within 65 minutes, stop engine because the test result will be OK.

CAUTION:

Be careful not to overheat engine.

Ⓜ With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-203, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020720

1. CHECK ENGINE COOLANT TEMPERATURE SENSOR

P0125 ECT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Check the engine coolant temperature sensor. Refer to [EC-204. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace engine coolant temperature sensor. Refer to [CO-24. "Exploded View"](#).

2. CHECK THERMOSTAT OPERATION

When the engine is cold [lower than 70°C (158°F)] condition, grasp lower radiator hose and confirm the engine coolant does not flow.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO >> Repair or replace thermostat. Refer to [CO-21. "Exploded View"](#).


Component Inspection

INFOID:000000009020721

1. CHECK ENGINE COOLANT TEMPERATURE (ECT) SENSOR

1. Turn ignition switch OFF.
2. Disconnect ECT sensor harness connector.
3. Remove ECT sensor.
4. Check resistance between ECT sensor terminals by heating with hot water as shown in the figure.

| ECT sensor | | Condition | Resistance (kΩ) | |
|------------|---|-----------------------|-----------------|---------------|
| Terminal | | | | |
| 1 | 2 | Temperature [°C (°F)] | 20 (68) | 2.10 - 2.90 |
| | | | 50 (122) | 0.68 - 1.00 |
| | | | 90 (194) | 0.236 - 0.260 |



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace engine coolant temperature sensor. Refer to [CO-24. "Exploded View"](#).

P0127 IAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0127 IAT SENSOR

DTC Logic

INFOID:000000009020722

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P0127 | IAT SENSOR-B1 (Intake air temperature too high) | Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor. | <ul style="list-style-type: none">• Harness or connectors (Intake air temperature sensor circuit is open or shorted)• Intake air temperature sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Wait until engine coolant temperature is less than 96°C (205°F)
 - Turn ignition switch ON.
 - Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
 - Check the engine coolant temperature.
 - If the engine coolant temperature is not less than 96°C (205°F), turn ignition switch OFF and cool down engine.

NOTE:

Perform the following steps before engine coolant temperature is above 96°C (205°F).

2. Turn ignition switch ON.
3. Select "DATA MONITOR" mode of "ENGINE" using CONSULT
4. Start engine.
5. Hold vehicle speed at more than 70 km/h (43 MPH) for 100 consecutive seconds.

CAUTION:

Always drive vehicle at a safe speed.

6. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-205. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020723

1. CHECK INTAKE AIR TEMPERATURE SENSOR

Check the intake air temperature sensor. Refer to [EC-206. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
NO >> Replace mass air flow sensor (with intake air temperature sensor). Refer to [EM-26. "Removal and Installation"](#).

P0127 IAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Component Inspection

INFOID:000000009020724

1. CHECK INTAKE AIR TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect mass air flow sensor harness connector.
3. Check resistance between mass air flow sensor terminals as per the following.

| Mass air flow sensor | | Condition | | Resistance (kΩ) |
|----------------------|---|-----------------------|---------|-----------------|
| Terminals | | | | |
| 5 | 6 | Temperature [°C (°F)] | 25 (77) | 1.800 - 2.200 |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace mass air flow sensor (with intake air temperature sensor). Refer to [EM-26. "Removal and Installation"](#).

P0128 THERMOSTAT FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0128 THERMOSTAT FUNCTION

DTC Logic

INFOID:000000009020725

DTC DETECTION LOGIC

NOTE:

If DTC P0128 is displayed with DTC P0300, P0301, P0302, P0303 or P0304, first perform the trouble diagnosis for P0300, P0301, P0302, P0303, P0304. Refer to [EC-267, "DTC Logic"](#).

Engine coolant temperature has not risen enough to open the thermostat even though the engine has run long enough.

This is due to a leak in the seal or the thermostat being stuck open.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|---|
| P0128 | THERMSTAT FNCTN [Coolant thermostat (coolant temperature below thermostat regulating temperature)] | The engine coolant temperature does not reach to specified temperature even though the engine has run long enough. | <ul style="list-style-type: none">• Thermostat• Leakage from sealing portion of thermostat• Engine coolant temperature sensor |

DTC CONFIRMATION PROCEDURE

NOTE:

Never refuel before and during the following procedure.


1. PRECONDITIONING-I

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PRECONDITIONING-II

 With CONSULT

1. Turn ignition switch ON.
2. Check the following conditions:

| | |
|---------------------|----------------------|
| Ambient temperature | -10°C (14°F) or more |
| A/C switch | OFF |
| Blower fan switch | OFF |


3. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
4. Check the following conditions:

| | |
|---------------|--|
| COOLAN TEMP/S | -10°C – 52°C (14 – 126°F) (M/T) -10°C – 46°C (14 – 115°F) (CVT) |
|---------------|--|

Is the condition satisfied?

- YES >> GO TO 3.
NO >> 1. Satisfy the condition.
2. GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-I

 With CONSULT

1. Start engine.
2. Drive the vehicle until the following condition is satisfied.

CAUTION:

Always drive vehicle at safe speed.

- **STEP 1**

P0128 THERMOSTAT FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Drive the vehicle under the conditions instructed below until the difference between "COOLAN TEMP/S" and "FUEL T/TMP SE" becomes at least 25°C (45°F).

| | |
|---------------|--|
| COOLAN TEMP/S | 71°C (160°F) or less (M/T) 65°C (149°F) or less (CVT) |
| FUEL T/TMP SE | Less than the value calculated by subtracting 25°C (45°F) from "COOLAN TEMP/S".* |

*: Example

| COOLAN TEMP/S | FUEL T/TMP SE |
|---------------|----------------------|
| 70°C (158°F) | 47°C (117°F) or less |
| 65°C (149°F) | 42°C (108°F) or less |
| 60°C (140°F) | 37°C (99°F) or less |

- STEP 2

Drive the vehicle at 50 km/h (32 MPH) or more with the difference between "COOLAN TEMP/S" and "FUEL T/TMP SE" maintained at 23°C (41°F) or more.

NOTE:

Keep the accelerator pedal as steady as possible during cruising.

- STEP 3

Drive the vehicle at 50 km/h (32 MPH) or more until "COOLAN TEMP/S" increases by 6°C (11°F).

NOTE:


Keep the accelerator pedal as steady as possible during cruising.

Is the condition satisfied?

YES >> GO TO 4.

NO >> GO TO 1.

4.PERFORM DTC CONFIRMATION PROCEDURE-II

 With CONSULT

1. Drive the vehicle until the following condition is satisfied.

| | |
|---------------|--|
| COOLAN TEMP/S | 71°C (160°F) or more (M/T) 65°C (149°F) or more (CVT) |
|---------------|--|

CAUTION:

Always drive vehicle at safe speed.

2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Proceed to [EC-208, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020726

1.CHECK ENGINE COOLANT TEMPERATURE SENSOR

Check the engine coolant temperature sensor. Refer to [EC-209, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace engine coolant temperature sensor. Refer to [CO-24, "Exploded View"](#).

2.CHECK THERMOSTAT

Check the thermostat. Refer to [CO-21, "Removal and Installation"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace thermostat. Refer to [CO-21, "Removal and Installation"](#).

P0128 THERMOSTAT FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]


INFOID:000000009020727

Component Inspection

1. CHECK ENGINE COOLANT TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect engine coolant temperature sensor harness connector.
3. Remove engine coolant temperature sensor. Refer to [CO-24, "Exploded View"](#).
4. Check resistance between engine coolant temperature sensor terminals by heating with hot water as shown in the figure.

| Engine coolant temperature sensor | | Condition | Resistance (kΩ) | |
|-----------------------------------|---|-----------------------|-----------------|---------------|
| Terminal | | | | |
| 1 | 2 | Temperature [°C (°F)] | 20 (68) | 2.10 - 2.90 |
| | | | 50 (122) | 0.68 - 1.00 |
| | | | 90 (194) | 0.236 - 0.260 |



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace engine coolant temperature sensor. Refer to [CO-24, "Exploded View"](#).

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P0130 A/F SENSOR 1

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0130 A/F SENSOR 1

DTC Logic

INFOID:000000009020728

DTC DETECTION LOGIC

To judge malfunctions, the diagnosis checks that the A/F signal computed by ECM from the A/F sensor 1 signal fluctuates according to fuel feedback control.

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible Cause |
|---------|---------------------------------------|--|---|
| P0130 | Air fuel ratio (A/F) sensor 1 circuit | The A/F signal computed by ECM from the A/F sensor 1 signal is constantly approx. 2.2 V. | <ul style="list-style-type: none">• Harness or connectors (The A/F sensor 1 circuit is open or shorted.)• A/F sensor 1 |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

Do you have CONSULT?

- YES >> GO TO 2.
NO >> GO TO 6.

2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Select "ENGINE" using CONSULT.
3. Select "A/F SEN1 (B1)" in "DATA MONITOR" mode.
4. Check "A/F SEN1 (B1)" indication.

Does the indication fluctuate around 2.2 V?

- YES >> GO TO 3.
NO >> Go to [EC-211, "Diagnosis Procedure"](#).

3. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION -I

1. Select "ENGINE" using CONSULT.
2. Select "A/F SEN1 (B1) P1276" (for DTC P0130) of "A/F SEN1" in "DTC WORK SUPPORT" mode.
3. Touch "START".
4. When the following conditions are met, "TESTING" will be displayed on the CONSULT screen.

| | |
|----------------|--|
| ENG SPEED | 1,000 - 3,200 rpm |
| VHCL SPEED SE | More than 40 km/h (25 mph) |
| B/FUEL SCHDL | 1.5 - 9.0 msec |
| Selector lever | D position (CVT models) 5th position (M/T models) |

If "TESTING" is not displayed after 20 seconds, retry from step 2.

CAUTION:

Always drive vehicle at a safe speed.

Is "TESTING" displayed on CONSULT screen?

- YES >> GO TO 4.
NO >> Check A/F sensor 1 function again. GO TO 2.

4. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION -II

Release accelerator pedal fully.

NOTE:

P0130 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Never apply brake when releasing the accelerator pedal.

Which does "TESTING" change to?

COMPLETED>>GO TO 5.

OUT OF CONDITION>>Retry DTC CONFIRMATION PROCEDURE. GO TO 3.

5.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION -III

Touch "SELF-DIAG RESULT".

Which is displayed on CONSULT screen?

OK >> INSPECTION END

NG >> Go to [EC-211, "Diagnosis Procedure"](#).

6.PERFORM COMPONENT FUNCTION CHECK FOR MALFUNCTION

Perform component function check. Refer to [EC-211, "Component Function Check"](#).

NOTE:

Use component function check to check the overall function of the A/F sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to [EC-211, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020729

1.PERFORM COMPONENT FUNCTION CHECK

With GST

1. Start engine and warm it up to normal operating temperature.
2. Drive the vehicle at a speed of 80 km/h (50 MPH) for a few minutes in the suitable gear position.
3. Shift the selector lever to D position (CVT) or 5th position (M/T), then release the accelerator pedal fully until the vehicle speed decreases to 50 km/h (30 MPH).

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

Never apply brake when releasing the accelerator pedal.

4. Repeat steps 2 and 3 for five times.
5. Stop the vehicle and turn ignition switch OFF.
6. Turn ignition switch ON.
7. Turn ignition switch OFF and wait at least 10 seconds.
8. Restart engine.
9. Repeat steps 2 and 3 for five times.
10. Stop the vehicle and connect GST to the vehicle.
11. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to [EC-211, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020730

1.CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2.CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect A/F sensor 1 harness connector.
2. Turn ignition switch ON.
3. Check the voltage between A/F sensor 1 harness connector and ground.

P0130 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| A/F sensor 1 | | Ground | Voltage |
|--------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F12 | 4 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F42
- 20A fuse (No. 53)
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

4. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 1 | F11 | 49 | Existed |
| | 2 | | 53 | |

4. Check the continuity between A/F sensor 1 harness connector and ground or ECM harness connector and ground.

| A/F sensor 1 | | Ground | Continuity |
|--------------|----------|--------|-------------|
| Connector | Terminal | | |
| F12 | 1 | Ground | Not existed |
| | 2 | | |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 49 | Ground | Not existed |
| | 53 | | |

5. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Perform [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace.

6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1. Refer to [EM-31, "Exploded View"](#).

CAUTION:

P0130 A/F SENSOR 1

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J-43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

P0131 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

P0131 A/F SENSOR 1

DTC Logic

INFOID:000000009020731

DTC DETECTION LOGIC

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the A/F sensor 1 signal is not inordinately low.

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible Cause |
|---------|---|--|---|
| P0131 | Air fuel ratio (A/F) sensor 1 circuit low voltage | The A/F signal computed by ECM from the A/F sensor 1 signal is constantly approx. 0 V. | <ul style="list-style-type: none">• Harness or connectors (The A/F sensor 1 circuit is open or shorted.)• A/F sensor 1 |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V at idle.

>> GO TO 2.

2. CHECK A/F SENSOR FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Select "ENGINE" using CONSULT.
3. Select "A/F SEN1 (B1)" in "DATA MONITOR" mode.
4. Check "A/F SEN1 (B1)" indication.

Is the indication constantly approx. 0 V?

YES >> Go to [EC-215. "Diagnosis Procedure"](#).

NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch OFF and wait at least 10 seconds and then restart engine.
2. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.

CAUTION:

Always drive vehicle at a safe speed.

3. Maintain the following conditions for about 20 consecutive seconds.

| | |
|----------------|----------------------------|
| ENG SPEED | 1,000 - 3,200 rpm |
| VHCL SPEED SE | More than 40 km/h (25 mph) |
| B/FUEL SCHDL | 1.5 - 9.0 msec |
| Selector lever | Suitable position |

NOTE:

- Keep the accelerator pedal as steady as possible during cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 1, return to step 1.

4. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to [EC-215. "Diagnosis Procedure"](#).

NO >> INSPECTION END

P0131 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

INFOID:00000009020732

Diagnosis Procedure

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44. "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace ground connection.

2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect A/F sensor 1 harness connector.
2. Turn ignition switch ON.
3. Check the voltage between A/F sensor 1 harness connector and ground.

| A/F sensor 1 | | Ground | Voltage |
|--------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F12 | 4 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F42
- 20A fuse (No. 53)
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

4. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 1 | F11 | 49 | Existed |
| | 2 | | 53 | |

4. Check the continuity between A/F sensor 1 harness connector and ground or ECM harness connector and ground.

| A/F sensor 1 | | Ground | Continuity |
|--------------|----------|--------|-------------|
| Connector | Terminal | | |
| F12 | 1 | Ground | Not existed |
| | 2 | | |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 49 | Ground | Not existed |
| | 53 | | |

5. Also check harness for short to power.

Is the inspection result normal?

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P0131 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Perform [GI-41. "Intermittent Incident"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace.

6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1. Refer to [EM-31. "Exploded View"](#).

CAUTION:

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J-43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

P0132 A/F SENSOR 1

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0132 A/F SENSOR 1

DTC Logic

INFOID:000000009020733

DTC DETECTION LOGIC

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the A/F sensor 1 signal is not inordinately high.

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible Cause |
|---------|--|--|--|
| P0132 | Air fuel ratio (A/F) sensor 1 circuit high voltage | The A/F signal computed by ECM from the A/F sensor 1 signal is constantly approx. 5 V. | <ul style="list-style-type: none"> • Harness or connectors (The A/F sensor 1 circuit is open or shorted.) • A/F sensor 1 |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V at idle.

>> GO TO 2.

2. CHECK A/F SENSOR FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Select "ENGINE" using CONSULT.
3. Select "A/F SEN1 (B1)" in "DATA MONITOR" mode.
4. Check "A/F SEN1 (B1)" indication.

Is the indication constantly approx. 5 V?

YES >> Go to [EC-218. "Diagnosis Procedure"](#).

NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch OFF and wait at least 10 seconds and then restart engine.
2. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.

CAUTION:

Always drive vehicle at a safe speed.

3. Maintain the following conditions for about 20 consecutive seconds.

| | |
|----------------|----------------------------|
| ENG SPEED | 1,000 - 3,200 rpm |
| VHCL SPEED SE | More than 40 km/h (25 mph) |
| B/FUEL SCHDL | 1.5 - 9.0 msec |
| Selector lever | Suitable position |

NOTE:

- Keep the accelerator pedal as steady as possible during the cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 1, return to step 1.

4. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to [EC-218. "Diagnosis Procedure"](#).

NO >> INSPECTION END

P0132 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

INFOID:00000009020734

Diagnosis Procedure

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44. "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect A/F sensor 1 harness connector.
2. Turn ignition switch ON.
3. Check the voltage between A/F sensor 1 harness connector and ground.

| A/F sensor 1 | | Ground | Voltage |
|--------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F12 | 4 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F42
- 20A fuse (No. 53)
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

4. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 1 | F11 | 49 | Existed |
| | 2 | | 53 | |

4. Check the continuity between A/F sensor 1 harness connector and ground or ECM harness connector and ground.

| A/F sensor 1 | | Ground | Continuity |
|--------------|----------|--------|-------------|
| Connector | Terminal | | |
| F12 | 1 | Ground | Not existed |
| | 2 | | |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 49 | Ground | Not existed |
| | 53 | | |

5. Also check harness for short to power.

Is the inspection result normal?

P0132 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Perform [GI-41. "Intermittent Incident"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace.

6. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace malfunctioning air fuel ratio (A/F) sensor 1. Refer to [EM-31. "Exploded View"](#).

CAUTION:

- Discard any A/F sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new A/F sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J-43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P


P0137 HO2S2

DTC Logic

INFOID:000000009020735

DTC DETECTION LOGIC

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst 1 causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during various driving conditions such as fuel-cut.



| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P0137 | Heated oxygen sensor 2 circuit low voltage | The maximum voltage from the sensor does not reach the specified voltage. | <ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted) • Heated oxygen sensor 2 • Fuel pressure • Fuel injector • Intake air leaks |

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

YES >> GO TO 2.

NO >> GO TO 5.

2.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

For better results, perform “DTC WORK SUPPORT” at a temperature of 0 to 30°C (32 to 86°F).

>> GO TO 3.

3.PERFORM DTC CONFIRMATION PROCEDURE

ⓂWith CONSULT

1. Turn ignition switch ON and select “DATA MONITOR” mode of “ENGINE” using CONSULT.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. Make sure that “COOLAN TEMP/S” indicates more than 70°C (158°F).
If not, warm up engine and go to next step when “COOLAN TEMP/S” indication reaches 70°C (158°F).
7. Open engine hood.
8. Select “HO2S2 (B1) P1147” of “HO2S2” in “DTC WORK SUPPORT” mode of “ENGINE” using CONSULT.
9. Follow the instruction of CONSULT.

NOTE:

< DTC/CIRCUIT DIAGNOSIS >

It will take at most 10 minutes until "COMPLETED" is displayed.

10. Touch "SELF-DIAG RESULT".

Which is displayed on CONSULT screen?

- OK >> INSPECTION END
- NG >> Proceed to [EC-222, "Diagnosis Procedure"](#).
- CAN NOT BE DIAGNOSED>>GO TO 4.

4.PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Turn ignition switch OFF and leave the vehicle in a cool place (soak the vehicle).
2. Perform DTC CONFIRMATION PROCEDURE again.

>> GO TO 3.

5.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-221, "Component Function Check"](#).

NOTE:

Use component function check to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Proceed to [EC-222, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020736

1.PERFORM COMPONENT FUNCTION CHECK-I

Without CONSULT

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Restart engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|--|---|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Reving up to 3,600 rpm under no load at least 10 times | The voltage should be above 0.78 V at least once during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK-II

Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|---------------------------------------|---|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Keeping engine at idle for 10 minutes | The voltage should be above 0.78 V at least once during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 3.

3.PERFORM COMPONENT FUNCTION CHECK-III

Check the voltage between ECM harness connector terminals under the following condition.

| ECM | | | Condition | Voltage |
|-----------|---------------|----------|---|---|
| Connector | + | - | | |
| | | Terminal | Terminal | |
| F11 | 50 (HO2S2) | 59 | Coasting from 80 km/h (50 MPH) in D position (CVT), 4th gear position (M/T) | The voltage should be above 0.78 V at least once during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-222. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020737

1.HECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44. "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace ground connection.

2.CLEAR THE MIXTURE RATIO SELF-LEARNING VALUE

1. Clear the mixture ratio self-learning value. Refer to [EC-130. "Work Procedure"](#).
2. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0171 detected? Is it difficult to start engine?

- YES >> Perform trouble diagnosis for DTC P0171. Refer to [EC-245. "DTC Logic"](#).
- NO >> GO TO 3.

3.CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check the continuity between HO2S2 harness connector and ECM harness connector.

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 1 | F11 | 59 | Existed |

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4.CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between HO2S2 harness connector and ECM harness connector.

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 4 | F11 | 50 | Existed |

2. Check the continuity between HO2S2 harness connector ground or ECM harness connector and ground.

| HO2S2 | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| E63 | 4 | Ground | Not existed |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 50 | Ground | Not existed |

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-223, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6. REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#)

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020738

1. INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK HEATED OXYGEN SENSOR 2

 **With CONSULT**

1. Turn ignition switch ON and select "ENGINE" using CONSULT.
2. Select "DATA MONITOR" mode.
3. Start engine and warm it up to the normal operating temperature.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
6. Let engine idle for 1 minute.
7. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT.


A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P0137 HO2S2

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

8. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



Ⓐ: "HO2S2 (B1)" should be above 0.78 V at least once when the "FUEL INJECTION" is +25%.

Ⓑ: "HO2S2 (B1)" should be below 0.18 V at least once when the "FUEL INJECTION" is -25%.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

3. CHECK HEATED OXYGEN SENSOR 2-I

⊗ Without CONSULT

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|---|--|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Revving up to 3,600 rpm under no load at least 10 times | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 4.

4. CHECK HEATED OXYGEN SENSOR 2-II

Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|---------------------------------------|--|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Keeping engine at idle for 10 minutes | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK HEATED OXYGEN SENSOR 2-III

Check the voltage between ECM harness connector terminals under the following condition.

| ECM | | | Condition | Voltage |
|-----------|---------------|----------|---|--|
| Connector | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Coasting from 80 km/h (50 MPH) in D position (CVT), 4th gear position (M/T) | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 6.

6. REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P0138 HO2S2

DTC Logic


INFOID:000000009020739

DTC DETECTION LOGIC

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst 1 causes the longer switching time.


MALFUNCTION A

To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during various driving conditions such as fuel cut.



MALFUNCTION B

To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during various driving conditions such as fuel cut.



| DTC No. | Trouble diagnosis content | DTC detecting condition | | Possible cause |
|---------|---|-------------------------|--|---|
| P0138 | Heated oxygen sensor 2 circuit high voltage | A) | An excessively high voltage from the sensor is sent to ECM. | <ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted) • Heated oxygen sensor 2 |
| | | B) | The minimum voltage from the sensor is not reached to the specified voltage. | <ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted) • Heated oxygen sensor 2 • Fuel pressure • Fuel injector |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING OF DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.

< DTC/CIRCUIT DIAGNOSIS >

3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 2 minutes.
5. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-228, "Diagnosis Procedure"](#).
- NO-1 >> With CONSULT: GO TO 3.
- NO-2 >> Without CONSULT: GO TO 5.

3.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION B**NOTE:**

For better results, perform "DTC WORK SUPPORT" at a temperature of 0 to 30°C (32 to 86°F).

1. Turn ignition switch ON and select "DATA MONITOR" mode of "ENGINE" using CONSULT.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. Make sure that "COOLAN TEMP/S" indication is more than 70°C (158°F).
If not, warm up engine and go to next step when "COOLAN TEMP/S" indication reaches 70°C (158°F).
7. Open engine hood.
8. Select "HO2S2 (B1) P1146" of "HO2S2" in "DTC WORK SUPPORT" mode of "ENGINE" using CONSULT.
9. Follow the instruction of CONSULT.

NOTE:

It will take at most 10 minutes until "COMPLETED" is displayed.

10. Touch "SELF-DIAG RESULT".

Which is displayed on CONSULT

- OK >> INSPECTION END
- NG >> Proceed to [EC-228, "Diagnosis Procedure"](#).
- CAN NOT BE DIAGNOSED>>GO TO 4.

4.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION B AGAIN

1. Turn ignition switch OFF and leave the vehicle in a cool place (soak the vehicle).
2. Perform DTC confirmation procedure again.

>> GO TO 3.

5.PERFORM COMPONENT FUNCTION CHECK FOR MALFUNCTION B

Perform component function check. Refer to [EC-227, "Component Function Check"](#).

NOTE:

Use component function check to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Proceed to [EC-228, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020740

1.PERFORM COMPONENT FUNCTION CHECK-I**⊗ Without CONSULT**

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
6. Let engine idle for 1 minute.
7. Check the voltage between ECM harness connector terminals under the following condition.

| ECM | | | Condition | Voltage |
|-----------|----------------------|----------|---|---|
| Connector | + | - | | |
| | | Terminal | Terminal | |
| F11 | 50 (HO2S2 signal) | 59 | Revving up to 3,600 rpm under no load at least 10 times | The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK-II

Check the voltage between ECM harness connector terminals under the following condition.

| ECM | | | Condition | Voltage |
|-----------|----------------------|----------|---------------------------------------|---|
| Connector | + | - | | |
| | | Terminal | Terminal | |
| F11 | 50 (HO2S2 signal) | 59 | Keeping engine at idle for 10 minutes | The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 3.

3.PERFORM COMPONENT FUNCTION CHECK-III

Check the voltage between ECM harness connector terminals under the following condition.

| ECM | | | Condition | Voltage |
|-----------|----------------------|----------|---|---|
| Connector | + | - | | |
| | | Terminal | Terminal | |
| F11 | 50 (HO2S2 signal) | 59 | Coasting from 80 km/h (50 MPH) in D position (CVT), 4th gear position (M/T) | The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-228, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020741

1.INSPECTION START

Confirm the detected malfunction (A or B). Refer to [EC-226, "DTC Logic"](#).

Which malfunction is detected?

- A >> GO TO 2.
- B >> GO TO 9.

2.CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace ground connection.

3.CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 2 harness connector.
2. Disconnect ECM harness connector.
3. Check the continuity between HO2S2 harness connector and ECM harness connector.

< DTC/CIRCUIT DIAGNOSIS >

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 1 | F11 | 59 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

4.CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between HO2S2 harness connector and ECM harness connector.

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 4 | F11 | 50 | Existed |

2. Check the continuity between HO2S2 harness connector and ground or ECM harness connector and ground.

| HO2S2 | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| E63 | 4 | Ground | Not existed |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 50 | Ground | Not existed |

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

5.CHECK HO2S2 CONNECTOR FOR WATER

Check connectors for water.

Water should not exist.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness or connectors.

6.CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-231, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 7.

7.REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved anti-seize lubricant (commercial service tool).

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

>> INSPECTION END

8. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

9. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> GO TO 10.
 NO >> Repair or replace ground connection.

10. CLEAR THE MIXTURE RATIO SELF-LEARNING VALUE

1. Clear the mixture ratio self-learning value. Refer to [EC-130, "Work Procedure"](#).
2. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0172 detected? Is it difficult to start engine?

- YES >> Perform trouble diagnosis for DTC P0172. Refer to [EC-249, "DTC Logic"](#).
 NO >> GO TO 11.

11. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check the continuity between HO2S2 harness connector and ECM harness connector.

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 1 | F11 | 59 | Existed |

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 12.
 NO >> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between HO2S2 harness connector and ECM harness connector.

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 4 | F11 | 50 | Existed |

2. Check the continuity between HO2S2 harness connector or ECM harness connector and ground.

| HO2S2 | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| E63 | 4 | Ground | Not existed |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 50 | Ground | Not existed |

3. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 13.
- NO >> Repair open circuit, short to ground or short to power in harness or connectors.

13.CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-231, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 15.
- NO >> GO TO 14.

14.REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

15.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020742

1.INSPECTION START

Do you have CONSULT?


Do you have CONSULT?

- YES >> GO TO 2.
- NO >> GO TO 3.

2.CHECK HEATED OXYGEN SENSOR 2

ⓂWith CONSULT

1. Turn ignition switch ON and select "ENGINE" using CONSULT.
2. Select "DATA MONITOR" mode.
3. Start engine and warm it up to the normal operating temperature.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
6. Let engine idle for 1 minute.
7. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT.
8. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



- Ⓜa: "HO2S2 (B1)" should be above 0.78 V at least once when the "FUEL INJECTION" is +25%.
- Ⓜb: "HO2S2 (B1)" should be below 0.18 V at least once when the "FUEL INJECTION" is -25%.

Is the inspection result normal?

< DTC/CIRCUIT DIAGNOSIS >

YES >> INSPECTION END
 NO >> GO TO 6.

3.CHECK HEATED OXYGEN SENSOR 2-I

⊗ Without CONSULT

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|--|--|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Revvng up to 3,600 rpm under no load at least 10 times | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

YES >> INSPECTION END
 NO >> GO TO 4.

4.CHECK HEATED OXYGEN SENSOR 2-II

Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|---------------------------------------|--|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Keeping engine at idle for 10 minutes | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

YES >> INSPECTION END
 NO >> GO TO 5.

5.CHECK HEATED OXYGEN SENSOR 2-III

Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|---|--|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Coasting from 80 km/h (50 MPH) in D position (CVT), 4th gear position (M/T) | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

YES >> INSPECTION END
 NO >> GO TO 6.

6.REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

P0138 HO2S2

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved anti-seize lubricant (commercial service tool).

A

>> INSPECTION END

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P


P0139 HO2S2

DTC Logic

INFOID:00000009020743

DTC DETECTION LOGIC

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel cut.



| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P0139 | Heated oxygen sensor 2 circuit slow response | It takes more time for the sensor to respond between rich and lean than the specified time. | <ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted) • Heated oxygen sensor 2 • Fuel pressure • Fuel injector • Intake air leaks |

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

YES >> GO TO 2.

NO >> GO TO 6.

2.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

For better results, perform "DTC WORK SUPPORT" at a temperature of 0 to 30°C (32 to 86°F).

>> GO TO 3.

3.PERFORM DTC CONFIRMATION PROCEDURE

ⓐWith CONSULT

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
6. Let engine idle for 1 minute.
7. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
8. Make sure that "COOLAN TEMP/S" indicates more than 70°C (158°F).
If not, warm up engine and go to next step when "COOLAN TEMP/S" indication reaches to 70°C (158°F).
9. Open engine hood.
10. Select "HO2S2 (B1) P0139" in "DTC WORK SUPPORT" mode of "ENGINE" using CONSULT.

< DTC/CIRCUIT DIAGNOSIS >

11. Start engine and follow the instruction of CONSULT display.

NOTE:

It will take at most 10 minutes until "COMPLETED" is displayed.

Is "COMPLETED" displayed on CONSULT screen?

YES >> GO TO 5.


NO >> GO TO 4.

4.PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Turn ignition switch OFF and leave the vehicle in a cool place (soak the vehicle).
2. Perform DTC confirmation procedure again.

>> GO TO 3.

5.PERFORM SELF-DIAGNOSIS

 With CONSULT

Perform ECM self-diagnosis.

Is DTC "P0139" detected?

YES >> Proceed to [EC-236, "Diagnosis Procedure"](#).

NO >> INSPECTION END

6.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-235, "Component Function Check"](#).

NOTE:

Use component function check to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to [EC-236, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020744

1.PERFORM COMPONENT FUNCTION CHECK-I

 Without CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Check the voltage between ECM harness connector and ground under the following condition.

| ECM | | Condition | Voltage |
|-----------|----------------------|-----------|--|
| Connector | Terminal | | |
| | | + | - |
| F11 | 50 (HO2S2 signal) | 59 | Reving up to 3,600 rpm under no load at least 10 times A change of voltage should be more than 0.12 V for 1 second during this procedure. |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK-II

Check the voltage between ECM harness connector and ground under the following condition.

| ECM | | | Condition | Voltage |
|-----------|----------------------|----|---|--|
| Connector | Terminal | | | |
| | + | - | | |
| F11 | 50 (HO2S2 signal) | 59 | Keeping engine speed at idle for 10 minutes | A change of voltage should be more than 0.12 V for 1 second during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 3.

3.PERFORM COMPONENT FUNCTION CHECK-III

Check the voltage between ECM harness connector and ground under the following condition.

| ECM | | | Condition | Voltage |
|-----------|----------------------|----|---|--|
| Connector | Terminal | | | |
| | + | - | | |
| F11 | 50 (HO2S2 signal) | 59 | Coasting from 80 km/h (50 MPH) in D position (CVT), 4th gear position (M/T) | A change of voltage should be more than 0.12 V for 1 second during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-236, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020745

1.CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace ground connection.

2.CLEAR THE MIXTURE RATIO SELF-LEARNING VALUE

1. Clear the mixture ratio self-learning value. Refer to [EC-130, "Work Procedure"](#).
2. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0171 or P0172 detected? Is it difficult to start engine?

- YES >> Perform trouble diagnosis for DTC P0171 or P0172. Refer to [EC-245, "DTC Logic"](#) or [EC-249, "DTC Logic"](#).
- NO >> GO TO 3.

3.CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect heated oxygen sensor 2 (HO2S2) harness connector.
3. Disconnect ECM harness connector.
4. Check the continuity between HO2S2 harness connector and ECM harness connector.

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 1 | F11 | 59 | Existed |

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

P0139 HO2S2

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Check the continuity between HO2S2 harness connector and ECM harness connector.

| HO2S2 | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E63 | 4 | F11 | 50 | Existed |

2. Check the continuity between HO2S2 harness connector or ECM harness connector and ground.

| HO2S2 | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| E63 | 4 | Ground | Not existed |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 50 | Ground | Not existed |

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5.CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-237, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020746

1.INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK HEATED OXYGEN SENSOR 2

With CONSULT


1. Turn ignition switch ON and select "ENGINE" using CONSULT.
2. Select "DATA MONITOR" mode.
3. Start engine and warm it up to the normal operating temperature.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
6. Let engine idle for 1 minute.
7. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT.

P0139 HO2S2

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

8. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



Ⓐ: "HO2S2 (B1)" should be above 0.78 V at least once when the "FUEL INJECTION" is +25%.

Ⓑ: "HO2S2 (B1)" should be below 0.18 V at least once when the "FUEL INJECTION" is -25%.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 6.

3. CHECK HEATED OXYGEN SENSOR 2-I

⊗ Without CONSULT

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|--|--|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Reving up to 3,600 rpm under no load at least 10 times | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 4.

4. CHECK HEATED OXYGEN SENSOR 2-II

Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage |
|-----------|---------------|----------|---------------------------------------|--|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Keeping engine at idle for 10 minutes | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK HEATED OXYGEN SENSOR 2-III

Check the voltage between ECM harness connector terminals under the following condition.

| ECM | | | Condition | Voltage |
|-----------|---------------|----------|---|--|
| Connector | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Coasting from 80 km/h (50 MPH) in D position (CVT), 4th gear position (M/T) | The voltage should be above 0.78 V at least once during this procedure. The voltage should be below 0.18 V at least once during this procedure. |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 6.

6. REPLACE HEATED OXYGEN SENSOR 2

Replace malfunctioning heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved anti-seize lubricant (commercial service tool).

>> INSPECTION END

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P014C, P014D, P015A, P015B, A/F SENSOR 1

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P014C, P014D, P015A, P015B, A/F SENSOR 1

DTC Logic

INFOID:000000009020747

DTC DETECTION LOGIC

To judge malfunctions, this diagnosis measures response time of the A/F signal computed by ECM from the A/F sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and the A/F sensor 1 temperature index. Judgment is based on whether the compensated time (the A/F signal cycling time index) is inordinately long or not.

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible Cause |
|---------|---|---|--|
| P014C | Air fuel ratio (A/F) sensor 1 (bank 1) circuit slow response | • The response time of a A/F sensor 1 signal delays more than the specified time computed by ECM. | • Harness or connectors (The A/F sensor 1 circuit is open or shorted.) • A/F sensor 1 |
| P014D | | | |
| P015A | Air fuel ratio (A/F) sensor 1 (bank 1) circuit delayed response | | |
| P015B | | | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

Do you have CONSULT?

- YES >> GO TO 2.
NO >> GO TO 5.

2. PERFORM DTC CONFIRMATION PROCEDURE-1

With CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
6. Let engine idle for 1 minute.
7. Increase the engine speed up to about 3,600 rpm and keep it for 10 seconds.
8. Fully release accelerator pedal and then let engine idle for about 1 minute.
9. Check the items status of "DATA MONITOR" as follows.

NOTE:

If "PRCNT" changed to "ABSNT", refer to [EC-149, "Component Function Check"](#).

| Data monitor item | Status |
|---------------------|--------|
| A/F SEN1 DIAG3 (B1) | PRCNT |

Is "PRCNT" displayed on CONSULT screen?

- YES >> GO TO 4.
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-2

With CONSULT

Perform DTC confirmation procedure-1 again.

Is "PRCNT" displayed on CONSULT screen?

- YES >> GO TO 4.
NO >> Refer to [EC-149, "Component Function Check"](#).

4. PERFORM DTC CONFIRMATION PROCEDURE-2

With CONSULT

1. Wait for about 20 seconds at idle.
2. Check the items status of "DATA MONITOR" as follows.

NOTE:

If "CMPLT" changed to "INCMP", refer to [EC-149, "Component Function Check"](#).

| Data monitor item | Status |
|---------------------|--------|
| A/F SEN1 DIAG1 (B1) | CMPLT |
| A/F SEN1 DIAG2 (B1) | |

Is "CMPLT" displayed on CONSULT screen?

YES >> GO TO 5.

NO >> Refer to [EC-149, "Component Function Check"](#).

5. PERFORM SELF-DIAGNOSIS

With CONSULT

Check the "SELF-DIAG RESULT".

Is any DTC detected?

YES >> Proceed to [EC-242, "Diagnosis Procedure"](#).

NO >> INSPECTION END

6. CHECK AIR-FUEL RATIO SELF-LEARNING VALUE

With GST

1. Start engine and warm it up to normal operating temperature.
2. Select Service \$01 with GST.
3. Calculate the total value of "Short term fuel trim" and "Long term fuel trim" indications.

Is the total percentage within $\pm 15\%$?

YES >> GO TO 8.

NO >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Intake air leaks
- Exhaust gas leaks
- Incorrect fuel pressure
- Lack of fuel
- Fuel injector
- Incorrect PCV hose connection
- PCV valve
- Mass air flow sensor

>> Repair or replace malfunctioning part.

8. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
5. Let engine idle for 1 minute.
6. Increase the engine speed up to about 3,600 rpm and keep it for 10 seconds.
7. Fully release accelerator pedal and then let engine idle for about 1 minute.
8. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Proceed to [EC-242, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

1.CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace ground connection.


2.RETIGHTEN A/F SENSOR 1

Loosen and retighten the A/F sensor 1. Refer to [EM-31, "Exploded View"](#).

>> GO TO 3.

3.CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



Is exhaust gas leak detected?

- YES >> Repair or replace.
 NO >> GO TO 4.

4.CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

- YES >> Repair or replace.
 NO >> GO TO 5.

5.CLEAR THE MIXTURE RATIO SELF-LEARNING VALUE

1. Clear the mixture ratio self-learning value. Refer to [EC-130, "Work Procedure"](#).
2. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0171 or P172 detected? Is it difficult to start engine?

- YES >> Perform trouble diagnosis for DTC P0171 or P0172. Refer to [EC-245, "DTC Logic"](#) or [EC-249, "DTC Logic"](#).
 NO >> GO TO 6.

6.CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect A/F sensor 1 harness connector.
2. Turn ignition switch ON.
3. Check the voltage between A/F sensor 1 harness connector and ground.

| A/F sensor 1 | | Ground | Voltage |
|--------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F12 | 4 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 8.

P014C, P014D, P015A, P015B, A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F42
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

8. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 1 | F11 | 49 | Existed |
| | 2 | | 53 | |

4. Check the continuity between A/F sensor 1 harness connector and ground, or ECM harness connector and ground.

| A/F sensor 1 | | Ground | Continuity |
|--------------|----------|--------|-------------|
| Connector | Terminal | | |
| F12 | 1 | Ground | Not existed |
| | 2 | | |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 49 | Ground | Not existed |
| | 53 | | |

5. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK AIR FUEL RATIO (A/F) SENSOR 1 HEATER

Refer to [EC-172, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> GO TO 13.

10. CHECK MASS AIR FLOW SENSOR

Refer to [EC-184, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 11.

NO >> Replace mass air flow sensor. Refer to [EM-26, "Removal and Installation"](#).

11. CHECK PCV VALVE

Refer to [EC-464, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace PCV valve. Refer to [EM-48, "Exploded View"](#).

P014C, P014D, P015A, P015B, A/F SENSOR 1

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

12. CHECK INTERMITTENT INCIDENT

Perform [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> GO TO 13.

NO >> Repair or replace.

13. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace air fuel ratio (A/F) sensor 1. Refer to [EM-31, "Exploded View"](#).

CAUTION:

- Discard any sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner [commercial service tool (J-43897-18 or J43897-12)] and approved Anti-seize Lubricant (commercial service tool).

>> INSPECTION END

P0171 FUEL INJECTION SYSTEM FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0171 FUEL INJECTION SYSTEM FUNCTION

DTC Logic

INFOID:000000009020749

DTC DETECTION LOGIC

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the A/F sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and lights up the MI (2 trip detection logic).

| Sensor | Input signal to ECM | ECM function | Actuator |
|--------------|--|------------------------|---------------|
| A/F sensor 1 | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | Fuel injection control | Fuel injector |

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--------------------------------|--|---|
| P0171 | Fuel injection system too lean | <ul style="list-style-type: none">Fuel injection system does not operate properly.The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) | <ul style="list-style-type: none">Intake air leaksA/F sensor 1Fuel injectorExhaust gas leaksIncorrect fuel pressureLack of fuelMass air flow sensorIncorrect PCV hose connection |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE-I

- Clear the mixture ratio self-learning value. Refer to [EC-130, "Work Procedure"](#).
- Start engine.

Is it difficult to start engine?

- YES >> GO TO 3.
NO >> GO TO 4.

3. RESTART ENGINE

If it is difficult to start engine, the fuel injection system has a malfunction, too.
Crank engine while depressing accelerator pedal.

NOTE:

When depressing accelerator pedal three-fourths (3/4) or more, the control system may not start the engine. Do not depress accelerator pedal too much.

Does engine start?

- YES >> Go to [EC-246, "Diagnosis Procedure"](#).
NO >> Check exhaust and intake air leak visually.

4. PERFORM DTC CONFIRMATION PROCEDURE-II

- Start engine and let it idle for at least 5 minutes.
- Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-246, "Diagnosis Procedure"](#).

P0171 FUEL INJECTION SYSTEM FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 5.

5. PERFORM DTC CONFIRMATION PROCEDURE-III

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Start engine.
3. Maintain the following conditions for at least 10 consecutive minutes.
Hold the accelerator pedal as steady as possible.

| | |
|---------------|-----------------------------|
| VHCL SPEED SE | 50 – 120 km/h (31 – 75 MPH) |
|---------------|-----------------------------|

CAUTION:

Always drive vehicle at a safe speed.

4. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to [EC-246. "Diagnosis Procedure"](#).


NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020750

1. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



Is exhaust gas leak detected?

YES >> Repair or replace.

NO >> GO TO 2.

2. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

1. Listen for an intake air leak after the mass air flow sensor.
2. Check PCV hose connection.

Intake air leak detected?

YES >> Repair or replace.

NO >> GO TO 3.

3. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect corresponding A/F sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 1 | F11 | 49 | Existed |
| | 2 | | 53 | |

5. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

P0171 FUEL INJECTION SYSTEM FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| A/F sensor 1 | | Ground | Continuity |
|--------------|----------|--------|-------------|
| Connector | Terminal | | |
| F12 | 1 | Ground | Not existed |
| | 2 | | |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 49 | Ground | Not existed |
| | 53 | | |

6. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-135, "Work Procedure"](#).

2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-135, "Work Procedure"](#).

At idling: Approximately 350 kPa (3.57 kg/cm², 51 psi)

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

5. CHECK FUEL HOSES AND FUEL TUBES

Check fuel hoses and fuel tubes for clogging.

Is the inspection result normal?

YES >> Replace "fuel filter and fuel pump assembly". Refer to [FL-6, "Exploded View"](#).

NO >> Repair or replace

6. CHECK MASS AIR FLOW SENSOR

 **With CONSULT**

1. Install all removed parts.

2. Check "MASS AIRFLOW" in "DATA MONITOR" mode with CONSULT.

0.8 - 4.0 g/s : at idling

2.0 - 10.0 g/s : at 2,500 rpm

 **With GST**

1. Install all removed parts.

2. Check mass air flow sensor signal in Service \$01 with GST.

0.8 - 4.0 g/s : at idling


2.0 - 10.0 g/s : at 2,500 rpm

Is the measurement value within the specification?

YES >> GO TO 7.

NO >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or grounds. Refer to [EC-187, "DTC Logic"](#).

7. CHECK FUNCTION OF FUEL INJECTOR

 **With CONSULT**

1. Start engine.

2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.

3. Make sure that each circuit produces a momentary engine speed drop.

P0171 FUEL INJECTION SYSTEM FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

⊗ Without CONSULT


1. Let engine idle.
2. Listen to each fuel injector operating sound.

Clicking noise should be heard.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Perform trouble diagnosis for FUEL INJECTOR. Refer to [EC-434, "Component Function Check"](#).



8. CHECK FUEL INJECTOR


1. Turn ignition switch OFF.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect all fuel injector harness connectors.
4. Remove fuel tube assembly. Refer to [FL-6, "Removal and Installation"](#). Keep fuel hose and all fuel injectors connected to fuel tube.
5. Disconnect all ignition coil harness connectors.
6. Prepare pans or saucers under each fuel injector.
7. Crank engine for about 3 seconds.

Fuel should be sprayed evenly for each fuel injector.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace fuel injectors from which fuel does not spray out. Always replace O-ring with new ones. Refer to [EM-40, "Removal and Installation"](#).



9. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

P0172 FUEL INJECTION SYSTEM FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0172 FUEL INJECTION SYSTEM FUNCTION

DTC Logic

INFOID:000000009020751

DTC DETECTION LOGIC

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the A/F sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and lights up the MI (2 trip detection logic).

| Sensor | Input signal to ECM | ECM function | Actuator |
|--------------|--|------------------------|---------------|
| A/F sensor 1 | Density of oxygen in exhaust gas (Mixture ratio feedback signal) | Fuel injection control | Fuel injector |

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--------------------------------|--|---|
| P0172 | Fuel injection system too rich | <ul style="list-style-type: none">Fuel injection system does not operate properly.The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) | <ul style="list-style-type: none">A/F sensor 1Fuel injectorExhaust gas leaksIncorrect fuel pressureMass air flow sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE-I

- Clear the mixture ratio self-learning value. Refer to [EC-130, "Work Procedure"](#).
- Start engine.

Is it difficult to start engine?

YES >> GO TO 3.

NO >> GO TO 4.

3. RESTART ENGINE

If it is difficult to start engine, the fuel injection system has a malfunction, too.

Crank engine while depressing accelerator pedal.

NOTE:

When depressing accelerator pedal three-fourths (3/4) or more, the control system may not start the engine. Do not depress accelerator pedal too much.

Does engine start?

YES >> Go to [EC-250, "Diagnosis Procedure"](#).

NO >> Remove spark plugs and check for fouling, etc.

4. PERFORM DTC CONFIRMATION PROCEDURE-II

- Start engine and let it idle for at least 5 minutes.
- Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to [EC-250, "Diagnosis Procedure"](#).

NO >> GO TO 5.

5. PERFORM DTC CONFIRMATION PROCEDURE-III

P0172 FUEL INJECTION SYSTEM FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Start engine.
3. Maintain the following conditions for at least 10 consecutive minutes.
Hold the accelerator pedal as steady as possible.

| | |
|---------------|-----------------------------|
| VHCL SPEED SE | 50 – 120 km/h (31 – 75 MPH) |
|---------------|-----------------------------|

CAUTION:

Always drive vehicle at a safe speed.

4. Check 1st trip DTC.

Is 1st trip DTC detected?


- YES >> Go to [EC-250, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020752

1. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before three way catalyst (manifold).



Is exhaust gas leak detected?

- YES >> Repair or replace.
NO >> GO TO 2.

2. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

- YES >> Repair or replace.
NO >> GO TO 3.

3. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect corresponding A/F sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 1 | F11 | 49 | Existed |
| | 2 | | 53 | |

5. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

| A/F sensor 1 | | Ground | Continuity |
|--------------|----------|--------|-------------|
| Connector | Terminal | | |
| F12 | 1 | Ground | Not existed |
| | 2 | | |

P0172 FUEL INJECTION SYSTEM FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 49 | Ground | Not existed |
| | 53 | | |

6. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-135, "Work Procedure"](#).

2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-135, "Work Procedure"](#).

At idling: Approximately 350 kPa (3.57 kg/cm², 51 psi)

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

5. CHECK FUEL HOSES AND FUEL TUBES

Check fuel hoses and fuel tubes for clogging.

Is the inspection result normal?

YES >> Replace "fuel filter and fuel pump assembly". Refer to [FL-6, "Exploded View"](#).

NO >> Repair or replace

6. CHECK MASS AIR FLOW SENSOR

 **With CONSULT**

1. Install all removed parts.

2. Check "MASS AIRFLOW" in "DATA MONITOR" mode with CONSULT.

0.8 - 4.0 g/s : at idling

2.0 - 10.0 g/s : at 2,500 rpm

 **With GST**

1. Install all removed parts.

2. Check mass air flow sensor signal in "Service \$01" with GST.

0.8 - 4.0 g/s : at idling

2.0 - 10.0 g/s : at 2,500 rpm

Is the measurement value within the specification?

YES >> GO TO 7.

NO >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or grounds. Refer to [EC-187, "DTC Logic"](#).

7. CHECK FUNCTION OF FUEL INJECTOR

 **With CONSULT**

1. Start engine.

2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.

3. Make sure that each circuit produces a momentary engine speed drop.

 **Without CONSULT**

1. Let engine idle.

P0172 FUEL INJECTION SYSTEM FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >


2. Listen to each fuel injector operating sound.

Clicking noise should be heard.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Perform trouble diagnosis for FUEL INJECTOR. Refer to [EC-434. "Component Function Check"](#).



8. CHECK FUEL INJECTOR

1. Remove fuel injector assembly. Refer to [EM-40. "Removal and Installation"](#).
Keep fuel hose and all fuel injectors connected to fuel tube.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect all fuel injector harness connectors.
4. Disconnect all ignition coil harness connectors.
5. Prepare pans or saucers under each fuel injectors.
6. Crank engine for about 3 seconds.
Make sure fuel does not drip from fuel injector.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace the fuel injectors from which fuel is dripping. Always replace O-ring with new one. Refer to [EM-40. "Removal and Installation"](#).

9. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> INSPECTION END

P0181 FTT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0181 FTT SENSOR

DTC Logic

INFOID:000000009020753

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | | Possible cause |
|---------|---|-------------------------|--|--|
| P0181 | FTT SENSOR [Fuel tank temperature (FTT) sensor circuit range/performance] | A) | Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signals from ECT sensor and intake air temperature sensor. | <ul style="list-style-type: none"> • Harness or connectors (FTT sensor circuit is open or shorted) • FTT sensor • Combination meter |
| | | B) | The comparison result of signals transmitted to ECM from each temperature sensor (IAT sensor, ECT sensor, EOT sensor, and FTT sensor) shows that the voltage signal of the FTT sensor is higher/lower than that of other temperature sensors when the engine is started with its cold state. | <ul style="list-style-type: none"> • Harness or connectors (High or low resistance in the FTT sensor circuit) • FTT sensor |

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Is it necessary to erase permanent DTC?

- YES >> GO TO 7.
- NO >> GO TO 2.

2.PRECONDITIONING

If DTC CONFIRMATION PROCEDURE has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 3.

3.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A-I

1. Turn ignition switch ON and wait at least 10 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-255, "Diagnosis Procedure"](#).
- NO >> GO TO 4.

4.CHECK ENGINE COOLANT TEMPERATURE

With CONSULT

1. Select "COOLAN TEMP/S" in "DATA MONITOR" of "ENGINE" using CONSULT.
2. Check "COOLAN TEMP/S" value.

With GST

Follow the procedure "With CONSULT" above.

"COOLAN TEMP/S" less than 60°C (140°F)?

- YES >> INSPECTION END
- NO >> GO TO 5.

5.PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A-II

With CONSULT

1. Cool engine down until "COOLAN TEMP/S" is less than 60°C (140°F).

< DTC/CIRCUIT DIAGNOSIS >

2. Wait at least 10 seconds.
3. Check 1st trip DTC.

 With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-255, "Diagnosis Procedure"](#).
 NO >> GO TO 6.

6. PERFORM COMPONENT FUNCTION CHECK (FOR MALFUNCTION B)

Perform component function check. Refer to [EC-254, "Component Function Check"](#).

NOTE:

Use the component function check to check the overall function of the FTT sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Proceed to [EC-255, "Diagnosis Procedure"](#).

7. PRECONDITIONING

If DTC CONFIRMATION PROCEDURE has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

- Before performing the following procedure, do not add fuel.
- Before performing the following procedure, check that fuel level is between 1/4 and 4/4.
- Before performing the following procedure, confirm that battery voltage is 11 V or more at idle.

>> GO TO 8.

8. PERFORM DTC CONFIRMATION PROCEDURE B

1. Start engine and let it idle for 60 minutes.
2. Move the vehicle to a cool place.

NOTE:

Cool the vehicle in an environment of ambient air temperature between -10°C (14°F) and 35°C (95°F).

3. Turn ignition switch OFF and soak the vehicle for 12 hours.

CAUTION:

Never turn ignition switch ON during soaking.

NOTE:

The vehicle must be cooled with the hood open.

4. Start engine and let it idle for 5 minutes or more.

CAUTION:

Never turn ignition switch OFF during idling.

5. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-255, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Component Function Check

INFOID:000000009020754

1. CHECK FUEL TANK TEMPERATURE (FTT) SENSOR


1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Remove fuel level sensor unit. Refer to [FL-6, "Removal and Installation"](#).

P0181 FTT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

4. Check resistance between fuel level sensor unit and fuel pump terminals by heating with hot water as shown in the figure.



| Fuel level sensor unit and fuel pump | | Condition | Resistance (kΩ) |
|--------------------------------------|---|-----------------------|-----------------|
| Terminal | | | |
| 4 | 5 | Temperature [°C (°F)] | 20 (68) |
| | | | 50 (122) |
| | | | 2.3 – 2.7 |
| | | | 0.79 – 0.90 |

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
 NO >> Proceed to [EC-255, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020755

1. INSPECTION START

Confirm the detected malfunction (A or B). Refer to [EC-253, "DTC Logic"](#).

Which malfunction is detected?

- A >> GO TO 2.
 B >> GO TO 6.

2. CHECK DTC WITH COMBINATION METER

Check DTC with combination meter. Refer to [MWI-15, "CONSULT Function"](#).

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Proceed to [MWI-21, "DTC Index"](#)

3. CHECK FUEL TANK TEMPERATURE (FTT) SENSOR POWER

- Turn ignition switch OFF.
- Disconnect fuel level sensor unit and fuel pump harness connector.
- Turn ignition switch ON.
- Check the voltage between fuel level sensor unit and fuel pump harness connector and ground.

| Fuel level sensor unit and fuel pump | | Ground | Voltage (Approx.) |
|--------------------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| B44 | 4 | Ground | 5 V |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 4.

4. CHECK FUEL TANK TEMPERATURE (FTT) SENSOR POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect ECM harness connector.
- Check the continuity between fuel level sensor unit and fuel pump harness connector and ECM harness connector.

| Fuel level sensor unit and fuel pump | | ECM | | Continuity |
|--------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B44 | 4 | F11 | 42 | Existed |

4. Also check harness for short to ground and to power.

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit.
 NO >> Repair or replace error-detected parts.

P0181 FTT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

5. CHECK FTT SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between fuel level sensor unit and fuel pump harness connector and ECM harness connector.

| Fuel level sensor unit and fuel pump | | ECM | | Continuity |
|--------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B44 | 5 | F11 | 51 | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

6. CHECK FUEL TANK TEMPERATURE (FTT) SENSOR

Check the FTT sensor. Refer to [EC-256, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace fuel level sensor unit and fuel pump. Refer to [FL-6, "Removal and Installation"](#).

Component Inspection

INFOID:000000009020756

1. CHECK FUEL TANK TEMPERATURE (FTT) SENSOR


1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Remove fuel level sensor unit. Refer to [FL-6, "Removal and Installation"](#).
4. Check resistance between fuel level sensor unit and fuel pump terminals by heating with hot water as shown in the figure.

| Fuel level sensor unit and fuel pump | | Condition | Resistance (kΩ) |
|--------------------------------------|---|-----------------------|-----------------|
| Terminal | | | |
| 4 | 5 | Temperature [°C (°F)] | 20 (68) |
| | | | 50 (122) |
| | | | 2.3 – 2.7 |
| | | | 0.79 – 0.90 |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit and fuel pump. Refer to [FL-6, "Removal and Installation"](#).



P0182, P0183 FTT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0182, P0183 FTT SENSOR

DTC Logic

INFOID:000000009020757

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P0182 | FTT SEN/CIRCUIT (Fuel tank temperature sensor circuit low input) | An excessively low voltage from the sensor is sent to ECM. | <ul style="list-style-type: none"> • Harness or connectors (The FTT sensor circuit is open or shorted.) • Fuel tank temperature sensor • Combination meter |
| P0183 | FTT SEN/CIRCUIT (Fuel tank temperature sensor circuit high input) | An excessively high voltage from the sensor is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-257. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020758

1. CHECK DTC WITH COMBINATION METER

Refer to [MWI-15. "CONSULT Function"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Proceed to [MWI-21. "DTC Index"](#)

2. CHECK FUEL TANK TEMPERATURE (FTT) SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Turn ignition switch ON.
4. Check the voltage between fuel level sensor unit and fuel pump harness connector and ground.

| Fuel level sensor unit and fuel pump | | Ground | Voltage (Approx.) |
|--------------------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| B44 | 4 | Ground | 5 V |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 3.

3. CHECK FUEL TANK TEMPERATURE (FTT) SENSOR POWER SUPPLY CIRCUIT

P0182, P0183 FTT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between fuel level sensor unit and fuel pump harness connector and ECM harness connector.

| Fuel level sensor unit and fuel pump | | ECM | | Continuity |
|--------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B44 | 4 | F11 | 42 | Existed |

4. Also check harness for short to ground and to power.

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit.
 NO >> Repair or replace error-detected parts.

4.CHECK FUEL TANK TEMPERATURE (FTT) SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between fuel level sensor unit and fuel pump harness connector and ECM harness connector.

| Fuel level sensor unit and fuel pump | | ECM | | Continuity |
|--------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B44 | 5 | F11 | 51 | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace error-detected parts.

5.CHECK FUEL TANK TEMPERATURE (FTT) SENSOR

Check the FTT sensor. Refer to [EC-258. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
 NO >> Replace "fuel level sensor unit and fuel pump". Refer to [FL-6. "Removal and Installation"](#).

Component Inspection

INFOID:000000009020759


1.CHECK FUEL TANK TEMPERATURE (FTT) SENSOR

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Remove fuel level sensor unit. Refer to [FL-6. "Removal and Installation"](#).
4. Check resistance between fuel level sensor unit and fuel pump terminals by heating with hot water as shown in the figure.

| Fuel level sensor unit and fuel pump | | Condition | Resistance (kΩ) |
|--------------------------------------|---|-----------------------|-----------------|
| Terminal | | | |
| 4 | 5 | Temperature [°C (°F)] | 20 (68) |
| | | | 50 (122) |
| | | | 2.3 – 2.7 |
| | | | 0.79 – 0.90 |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace fuel level sensor unit and fuel pump. Refer to [FL-6. "Removal and Installation"](#).



JMBIA0167ZZ

P0196 EOT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0196 EOT SENSOR

DTC Logic

INFOID:000000009020760

DTC DETECTION LOGIC

NOTE:

If DTC P0196 is displayed with DTC P0197 or P0198, first perform the trouble diagnosis for DTC P0197 or P0198. Refer to [EC-262, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | | Possible cause |
|---------|---|-------------------------|--|--|
| P0196 | EOT SENSOR [Engine oil temperature (EOT) sensor circuit range/perfor- mance] | A) | Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signals from EOT sensor and intake air temperature sensor. | <ul style="list-style-type: none"> • Harness or connectors (EOT sensor circuit is open or shorted) • EOT sensor |
| | | B) | The comparison result of signals transmitted to ECM from each temperature sensor (IAT sensor, ECT sensor, FTT sensor, and EOT sensor) shows that the signal voltage of the EOT sensor is higher/lower than that of other temperature sensors when the engine is started with its cold state. | <ul style="list-style-type: none"> • Harness or connectors (High or low resistance in the EOT sensor circuit) • EOT sensor |

DTC CONFIRMATION PROCEDURE

1. INSPECTION START

Is it necessary to erase permanent DTC?

- YES >> GO TO 6.
- NO >> GO TO 2.

2. PRECONDITIONING

If DTC CONFIRMATION PROCEDURE has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is 11 V or more at idle.

>> GO TO 3.


3. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A-I

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and let it idle for 5 minutes and 10 seconds.
6. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-261, "Diagnosis Procedure"](#).
- NO >> GO TO 4.

4. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A-II

 With CONSULT

1. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
2. Check that "COOLAN TEMP/S" indicates above 80°C (176°F).
If it is above 80°C (176°F), go to the following steps.

P0196 EOT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

If it is below 80°C (176°F), warm engine up until "COOLAN TEMP/S" indicates more than 80°C (176°F). Then perform the following steps.

3. Turn ignition switch OFF and soak the vehicle in a cool place.
4. Turn ignition switch ON.

NOTE:

Do not turn ignition switch OFF until step 8.

5. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
6. Check the following.

| | |
|--|--------------------|
| COOLAN TEMP/S | Below 40°C (104°F) |
| INT/A TEMP SE | Below 40°C (104°F) |
| Difference between "COOLAN TEMP/S" and "INT/A TEMP SE" | Within 6°C (11°F) |

If they are within the specified range, perform the following steps.

If they are out of the specified range, soak the vehicle to meet the above conditions. Then perform the following steps.

NOTE:

- **Do not turn ignition switch OFF.**
- **If it is supposed to need a long period of time, do not deplete the battery.**

7. Start engine and let it idle for 5 minutes.
8. Check 1st trip DTC.

 With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-261, "Diagnosis Procedure"](#).
NO >> GO TO 5.

5.PERFORM COMPONENT FUNCTION CHECK (FOR MALFUNCTION B)

Perform component function check. Refer to [EC-261, "Component Function Check"](#).

NOTE:

Use the component function check to check the overall function of the EOT sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Proceed to [EC-261, "Diagnosis Procedure"](#).

6.PRECONDITIONING

If DTC CONFIRMATION PROCEDURE has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

- **Before performing the following procedure, do not add fuel.**
- **Before performing the following procedure, check that fuel level is between 1/4 and 4/4.**
- **Before performing the following procedure, confirm that battery voltage is 11 V or more at idle.**

>> GO TO 7.

7.PERFORM DTC CONFIRMATION PROCEDURE B

1. Start engine and let it idle for 60 minutes.
2. Move the vehicle to a cool place.

NOTE:

Cool the vehicle in an environment of ambient air temperature between -10°C (14°F) and 35°C (95°F).

3. Turn ignition switch OFF and soak the vehicle for 12 hours.

CAUTION:

Never turn ignition switch ON during soaking.

NOTE:

The vehicle must be cooled with the hood open.

< DTC/CIRCUIT DIAGNOSIS >

4. Start engine and let it idle for 5 minutes or more.

CAUTION:

Never turn ignition switch OFF during idling.

5. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Proceed to [EC-261, "Diagnosis Procedure"](#).

NO >> INSPECTION END


Component Function Check

INFOID:000000009020761

1.CHECK ENGINE OIL TEMPERATURE (EOT) SENSOR

1. Turn ignition switch OFF.
2. Disconnect EOT sensor harness connector.
3. Remove EOT sensor. Refer to [EM-92, "Exploded View"](#).
4. Check resistance between EOT sensor terminals by heating with hot water as shown in the figure.

| EOT sensor | | Condition | Resistance (kΩ) | |
|------------|---|-----------------------|-----------------|---------------|
| Terminal | | | | |
| 1 | 2 | Temperature [°C (°F)] | 20 (68) | 2.10 – 2.90 |
| | | | 50 (122) | 0.68 – 1.00 |
| | | | 90 (194) | 0.236 – 0.260 |



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Proceed to [EC-261, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020762

1.CHECK ENGINE OIL TEMPERATURE (EOT) SENSOR

Check EOT sensor. Refer to [EC-261, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace EOT sensor. Refer to [EM-92, "Exploded View"](#).


Component Inspection

INFOID:000000009020763

1.CHECK ENGINE OIL TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect engine oil temperature sensor harness connector.
3. Remove engine oil temperature sensor.
4. Check resistance between engine oil temperature sensor terminals by heating with hot water as shown in the figure.

| Engine oil temperature sensor | | Condition | Resistance (kΩ) | |
|-------------------------------|---|-----------------------|-----------------|---------------|
| Terminal | | | | |
| 1 | 2 | Temperature [°C (°F)] | 20 (68) | 2.10 - 2.90 |
| | | | 50 (122) | 0.68 - 1.00 |
| | | | 90 (194) | 0.236 - 0.260 |



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace engine oil temperature sensor. Refer to [EM-92, "Exploded View"](#).

P0197, P0198 EOT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

P0197, P0198 EOT SENSOR

DTC Logic

INFOID:000000009020764

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC Detecting Condition | Possible Cause |
|---------|---|---|--|
| P0197 | EOT SEN/CIRC (Engine oil temperature sensor circuit low input) | An excessively low voltage from the engine oil temperature sensor is sent to ECM. | • Harness or connectors (EOT sensor circuit is open or shorted.) • Engine oil temperature sensor |
| P0198 | EOT SEN/CIRC (Engine oil temperature sensor circuit high input) | An excessively high voltage from the engine oil temperature sensor is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and wait at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-262, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020765

1. CHECK ENGINE OIL TEMPERATURE SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect engine oil temperature (EOT) sensor harness connector.
3. Turn ignition switch ON.
4. Check the voltage between EOT sensor harness connector and ground.

| EOT sensor | | Ground | Voltage (Approx.) |
|------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F25 | 1 | Ground | 5 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK ENGINE OIL TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EOT sensor harness connector and ECM harness connector.

| EOT sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F25 | 1 | F11 | 57 | Existed |

P0197, P0198 EOT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

4. Also check harness for short to ground.

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit.
- NO >> Repair or replace error-detected parts.

3.CHECK EOT SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EOT sensor harness connector and ECM harness connector.

| EOT sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F25 | 2 | F11 | 54 | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace error-detected parts.

4.CHECK ENGINE OIL TEMPERATURE SENSOR

Check the engine oil temperature sensor. Refer to [EC-263, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> Replace engine oil temperature sensor. Refer to [EM-92, "Exploded View"](#).


Component Inspection

INFOID:000000009020766

1.CHECK ENGINE OIL TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect engine oil temperature sensor harness connector.
3. Remove engine oil temperature sensor. Refer to [EM-92, "Exploded View"](#).
4. Check resistance between engine oil temperature sensor terminals by heating with hot water as shown in the figure.

| Engine oil temperature sensor | | Condition | Resistance (kΩ) | |
|-------------------------------|---|-----------------------|-----------------|---------------|
| + | - | | | |
| Terminal | | | | |
| 1 | 2 | Temperature [°C (°F)] | 20 (68) | 2.10 - 2.90 |
| | | | 50 (122) | 0.68 - 1.00 |
| | | | 90 (194) | 0.236 - 0.260 |



Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace engine oil temperature sensor. Refer to [EM-92, "Exploded View"](#).

P0222, P0223 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0222, P0223 TP SENSOR

DTC Logic

INFOID:000000009020767

DTC DETECTION LOGIC

NOTE:

If DTC P0222 or P0223 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|--|--|
| P0222 | Throttle position sensor 1 circuit low input | An excessively low voltage from the TP sensor 1 is sent to ECM. | <ul style="list-style-type: none">• Harness or connectors (TP sensor 1 circuit is open or shorted.)• Electric throttle control actuator (TP sensor 1) |
| P0223 | Throttle position sensor 1 circuit high input | An excessively high voltage from the TP sensor 1 is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 1 second.
2. Check DTC.

Is DTC detected?

YES >> Go to [EC-264, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020768

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.
3. Check the voltage between electric throttle control actuator harness connector and ground.

| Electric throttle control actuator | | Ground | Voltage |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| F7 | 2 | Ground | Approx. 5 V |

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK THROTTLE POSITION SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.

P0222, P0223 TP SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

3. Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

| Electric throttle control actuator | | ECM | | Continuity |
|------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F7 | 4 | F11 | 36 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

| Electric throttle control actuator | | ECM | | Continuity |
|------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F7 | 1 | F11 | 33 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5.CHECK THROTTLE POSITION SENSOR

Refer to [EC-265, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

7.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020769

1.CHECK THROTTLE POSITION SENSOR

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Perform [EC-127, "Work Procedure"](#).
4. Turn ignition switch ON.
5. Set selector lever to D (CVT) or 1st (M/T) position.
6. Check the voltage between ECM harness connector and ground.

P0222, P0223 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECM | | Condition | Voltage | |
|-----------|----------------------------|-------------------|-----------------|------------------|
| Connector | Terminal | | | |
| | + | | | |
| | - | | | |
| F11 | 33 (TP sensor 1 signal) | Accelerator pedal | Fully released | More than 0.36 V |
| | | | Fully depressed | Less than 4.75 V |
| | 34 (TP sensor 2 signal) | | Fully released | Less than 4.75 V |
| | | | Fully depressed | More than 0.36 V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

P0300, P0301, P0302, P0303, P0304 MISFIRE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0300, P0301, P0302, P0303, P0304 MISFIRE

DTC Logic

INFOID:000000009020770

DTC DETECTION LOGIC

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the crankshaft position (CKP) sensor (POS) signal to vary, ECM can determine that a misfire is occurring.

| Sensor | Input signal to ECM | ECM function |
|----------------------------------|---------------------|-------------------------------|
| Crankshaft position sensor (POS) | Engine speed | On board diagnosis of misfire |

The misfire detection logic consists of the following two conditions.

- One Trip Detection Logic (Three Way Catalyst Damage)**
 On the 1st trip, when a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MI will blink.
 When a misfire condition occurs, the ECM monitors the CKP sensor signal every 200 engine revolutions for a change.
 When the misfire condition decreases to a level that will not damage the TWC, the MI will turn off.
 If another misfire condition occurs that can damage the TWC on a second trip, the MI will blink.
 When the misfire condition decreases to a level that will not damage the TWC, the MI will remain on.
 If another misfire condition occurs that can damage the TWC, the MI will begin to blink again.
- Two Trip Detection Logic (Exhaust quality deterioration)**
 For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MI will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.
 A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|------------------------------------|----------------------------|--|
| P0300 | Multiple cylinder misfire detected | Multiple cylinder misfire. | <ul style="list-style-type: none"> • Improper spark plug • Insufficient compression • Incorrect fuel pressure • The fuel injector circuit is open or shorted • Fuel injector* • Intake air leak • The ignition signal circuit is open or shorted • Lack of fuel • Signal plate • A/F sensor 1 • Incorrect PCV hose connection |
| P0301 | No.1 cylinder misfire detected | No. 1 cylinder misfires. | |
| P0302 | No. 2 cylinder misfire detected | No. 2 cylinder misfires. | |
| P0303 | No. 3 cylinder misfire detected | No. 3 cylinder misfires. | |
| P0304 | No. 4 cylinder misfire detected | No. 4 cylinder misfires. | |

*: DTC is detected even where a malfunction occurs one side of the dual injector.

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE-I

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Restart engine and let it idle for about 35 minutes.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to [EC-268. "Diagnosis Procedure"](#).

P0300, P0301, P0302, P0303, P0304 MISFIRE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-II

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Start engine and drive the vehicle under the similar conditions to (1st trip) Freeze Frame Data for a certain time. Refer to the table below.

Hold the accelerator pedal as steady as possible.

The similar conditions to (1st trip) Freeze Frame Data means the vehicle operation that the following conditions should be satisfied at the same time.

CAUTION:

Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws when driving.

| | |
|--|--|
| Engine speed | Engine speed in the freeze frame data \pm 400 rpm |
| Vehicle speed | Vehicle speed in the freeze frame data \pm 10 km/h (6 MPH) |
| Engine coolant temperature (T) condition | When the freeze frame data shows lower than 70°C (158°F), T should be lower than 70°C (158°F). |
| | When the freeze frame data shows higher than or equal to 70°C (158°F), T should be higher than or equal to 70°C (158°F). |

The time to driving varies according to the engine speed in the freeze frame data.

| Engine speed | Time |
|---------------------|--------------------------|
| Around 1,000 rpm | Approximately 20 minutes |
| Around 2,000 rpm | Approximately 10 minutes |
| More than 3,000 rpm | Approximately 7 minutes |

3. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to [EC-268, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020771

1. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

1. Start engine and run it at idle speed.
2. Listen for the sound of the intake air leak.
3. Check PCV hose connection.

Is intake air leak detected?

YES >> Discover air leak location and repair.

NO >> GO TO 2.

2. CHECK FOR EXHAUST SYSTEM CLOGGING

Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.

Is the inspection result normal?

YES-1 >> With CONSULT: GO TO 3.

YES-2 >> Without CONSULT: GO TO 4.

NO >> Repair or replace it.

3. PERFORM POWER BALANCE TEST

 **With CONSULT**

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.
3. Make sure that each circuit produces a momentary engine speed drop.

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 4.


4. CHECK FUNCTION OF FUEL INJECTOR

1. Start engine and let engine idle.
2. Listen to each fuel injector operating sound.

Clicking noise should be heard.

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Perform trouble diagnosis for FUEL INJECTOR. Refer to [EC-434, "Component Function Check"](#).



5. CHECK FUNCTION OF IGNITION COIL-I

CAUTION:

Do the following procedure in the place where ventilation is good without the combustible.

1. Turn ignition switch OFF.
2. Remove fuel pump fuse in IPDM E/R to release fuel pressure.
NOTE:
 Do not use CONSULT to release fuel pressure, or fuel pressure applies again during the following procedure.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.
6. Remove all ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
7. Remove ignition coil and spark plug of the cylinder to be checked.
8. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
9. Connect spark plug and harness connector to ignition coil.
10. Fix ignition coil using a rope etc. with gap of 13 - 17 mm (0.52 - 0.66 in) between the edge of the spark plug and grounded metal portion as shown in the figure.
11. Crank engine for about 3 seconds, and check whether spark is generated between the spark plug and the grounded metal portion.

Spark should be generated.

CAUTION:

- Do not approach to the spark plug and the ignition coil within 50 cm (19.7 in). Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20 kV or more.
- It might cause to damage the ignition coil if the gap of more than 17 mm (0.66 in) is taken.

NOTE:

When the gap is less than 13 mm (0.52 in), the spark might be generated even if the coil is malfunctioning.

Is the inspection result normal?


- YES >> GO TO 9.
 NO >> GO TO 6.

6. CHECK FUNCTION OF IGNITION COIL-II

1. Turn ignition switch OFF.
2. Disconnect spark plug and connect a known-good spark plug.
3. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded metal portion.

Spark should be generated.

Is the inspection result normal?



< DTC/CIRCUIT DIAGNOSIS >


YES >> GO TO 7.

NO >> Check ignition coil, power transistor and their circuits. Refer to [EC-439, "Component Function Check"](#).**7. CHECK SPARK PLUG**

Check the initial spark plug for fouling, etc.

Is the inspection result normal?YES >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [EM-116, "Spark Plug"](#).

NO >> Repair or clean spark plug. Then GO TO 8.

**8. CHECK FUNCTION OF IGNITION COIL-III**

1. Reconnect the initial spark plugs.

2. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded portion.

Spark should be generated.Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [EM-116, "Spark Plug"](#).**9. CHECK COMPRESSION PRESSURE**Check compression pressure. Refer to [EM-13, "Inspection"](#).Is the inspection result normal?

YES >> GO TO 10.

NO >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

10. CHECK FUEL PRESSURE

1. Install all removed parts.

2. Release fuel pressure to zero. Refer to [EC-135, "Work Procedure"](#).3. Install fuel pressure gauge and check fuel pressure. Refer to [EC-135, "Work Procedure"](#).**At idling: Approximately 350 kPa (3.57 kg/cm², 51 psi)**Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 11.

11. DETECT MALFUNCTIONING PART

Check fuel hoses and fuel tubes for clogging.

Is the inspection result normal?YES >> Replace "fuel filter and fuel pump assembly". Refer to [FL-6, "Removal and Installation"](#).

NO >> Repair or replace.

12. CHECK IGNITION TIMING

Check the following items.

For procedure, refer to [EC-460, "Inspection"](#).For specification, refer to [EC-466, "Ignition Timing"](#).Is the inspection result normal?

YES >> GO TO 13.

NO >> Follow the [EC-131, "Work Procedure"](#).

P0300, P0301, P0302, P0303, P0304 MISFIRE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

13. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect A/F sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 1 | F11 | 49 | Existed |
| | 2 | | 53 | |

5. Check the continuity between A/F sensor 1 harness connector or ECM harness connector and ground.

| A/F sensor 1 | | Ground | Continuity |
|--------------|----------|--------|-------------|
| Connector | Terminal | | |
| F12 | 1 | Ground | Not existed |
| | 2 | | |

| ECM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 49 | Ground | Not existed |
| | 53 | | |

6. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

14. CHECK A/F SENSOR 1 HEATER

Refer to [EC-172. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 15.

NO >> Replace A/F sensor 1. Refer to [EM-31. "Exploded View"](#).

15. CHECK MASS AIR FLOW SENSOR

 **With CONSULT**

Check "MASS AIRFLOW" in "DATA MONITOR" mode with CONSULT.

0.8 - 4.0 g/s : at idling

2.0 - 10.0 g/s : at 2,500 rpm

 **With GST**

Check mass air flow sensor signal in Service \$01 with GST.

0.8 - 4.0 g/s : at idling

2.0 - 10.0 g/s : at 2,500 rpm

Is the measurement value within the specification?

YES >> GO TO 16.

NO >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or ground. Refer to [EC-187. "DTC Logic"](#).

16. CHECK SYMPTOM TABLE

Check items on the rough idle symptom in [EC-452. "Symptom Table"](#).

Is the inspection result normal?

P0300, P0301, P0302, P0303, P0304 MISFIRE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

YES >> GO TO 17.

NO >> Repair or replace.

17.ERASE THE 1ST TRIP DTC

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests.

>> GO TO 18.

18.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

P0327, P0328 KS

DTC Logic

INFOID:000000009020772

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detected condition | Possible cause |
|---------|---------------------------------|---|--|
| P0327 | Knock sensor circuit low input | An excessively low voltage from the sensor is sent to ECM. | <ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Knock sensor |
| P0328 | Knock sensor circuit high input | An excessively high voltage from the sensor is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-273, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020773

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace ground connection.

2. CHECK KNOCK SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect knock sensor harness connector.
2. Disconnect ECM harness connector.
3. Check the continuity between knock sensor harness connector and ECM harness connector.

| Knock sensor | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F14 | 2 | F11 | 40 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between knock sensor harness connector and ECM harness connector.

< DTC/CIRCUIT DIAGNOSIS >

| Knock sensor | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F14 | 1 | F11 | 37 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK KNOCK SENSOR

Refer to [EC-274. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace knock sensor. Refer to [EM-92. "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020774

1.CHECK KNOCK SENSOR

1. Turn ignition switch OFF.
2. Disconnect knock sensor harness connector.
3. Check resistance between knock sensor terminals as follows.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

| Terminals | Resistance [at 20°C (68°F)] |
|-----------|-----------------------------|
| 1 and 2 | Approx. 532 - 588 kΩ |

CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace knock sensor. Refer to [EM-92. "Exploded View"](#).

P0335 CKP SENSOR (POS)

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0335 CKP SENSOR (POS)

DTC Logic

INFOID:000000009020775

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|--|
| P0335 | Crankshaft position sensor (POS) circuit | <ul style="list-style-type: none">The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking.The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running.The crankshaft position sensor (POS) signal is not in the normal pattern during engine running. | <ul style="list-style-type: none">Harness or connectors [Crankshaft position sensor (POS) circuit is open or shorted.] (Battery current sensor circuit is shorted.) (Refrigerant pressure sensor circuit is shorted.) (Accelerator pedal position sensor 2 circuit is shorted.)Crankshaft position sensor (POS)Battery current sensorRefrigerant pressure sensorAccelerator pedal position sensorSignal plate |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V with ignition switch ON.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for at least 5 seconds.
If engine does not start, crank engine for at least 2 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-275, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020776

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK CRANKSHAFT POSITION (CKP) SENSOR (POS) POWER SUPPLY CIRCUIT-I

- Disconnect crankshaft position (CKP) sensor (POS) harness connector.
- Turn ignition switch ON.
- Check the voltage between CKP sensor (POS) harness connector and ground.

P0335 CKP SENSOR (POS)

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| CKP sensor (POS) | | Ground | Voltage |
|------------------|----------|--------|-------------|
| Connector | Terminal | | |
| F15 | 1 | Ground | Approx. 5 V |

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 3.

3. CHECK CRANKSHAFT POSITION (CKP) SENSOR (POS) POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between CKP sensor (POS) harness connector and ECM harness connector.

| CKP sensor (POS) | | ECM | | Continuity |
|------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F15 | 1 | F11 | 75 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit.

4. CHECK SENSOR POWER SUPPLY CIRCUIT

Check harness for short to power and short to ground, between the following terminals.

| ECM | | Sensor | | |
|-----------|----------|-------------------------------------|-----------|----------|
| Connector | Terminal | Name | Connector | Terminal |
| F11 | 75 | CKP sensor (POS) | F15 | 1 |
| E16 | 101 | Refrigerant pressure sensor | E17 | 3 |
| | 102 | Accelerator pedal position sensor 2 | E12 | 5 |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair short to ground or short to power in harness or connectors.

5. CHECK COMPONENTS

Check the following.

- Refrigerant pressure sensor (Refer to [EC-450, "Component Function Check"](#)).
- Accelerator pedal position sensor (Refer to [EC-413, "Component Inspection"](#)).

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace refrigerant pressure sensor. Refer to [HA-30, "REFRIGERANT PRESSURE SENSOR : Removal and Installation"](#).

6. CHECK CKP SENSOR (POS) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check the continuity between CKP sensor (POS) harness connector and ECM harness connector.

| CKP sensor (POS) | | ECM | | Continuity |
|------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F15 | 2 | F11 | 62 | Existed |

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

P0335 CKP SENSOR (POS)

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

7. CHECK CKP SENSOR (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check the continuity between CKP sensor (POS) harness connector and ECM harness connector.

| CKP sensor (POS) | | ECM | | Continuity |
|------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F15 | 3 | F11 | 61 | Existed |

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-277, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace crankshaft position sensor (POS). Refer to [EM-92, "Exploded View"](#).

9. CHECK GEAR TOOTH

Visually check for chipping signal plate gear tooth.

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace the signal plate. Refer to [EM-92, "Exploded View"](#).

10. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020777


1. CHECK CRANKSHAFT POSITION SENSOR (POS)-I

1. Turn ignition switch OFF.
2. Loosen the fixing bolt of the sensor.
3. Disconnect crankshaft position sensor (POS) harness connector.
4. Remove the sensor. Refer to [EM-92, "Exploded View"](#).
5. Visually check the sensor for chipping.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace crankshaft position sensor (POS). Refer to [EM-92, "Exploded View"](#).



2. CHECK CRANKSHAFT POSITION SENSOR (POS)-II

Check resistance between crankshaft position sensor (POS) terminals as follows.

| Terminals (Polarity) | Resistance [at 25°C (77°F)] |
|----------------------|-----------------------------|
|----------------------|-----------------------------|

P0335 CKP SENSOR (POS)

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| | |
|---------------|-------------------------------|
| 1 (+) - 2 (-) | Except 0 or ∞ Ω |
| 1 (+) - 3 (-) | |
| 2 (+) - 3 (-) | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace crankshaft position sensor (POS). Refer to [EM-92. "Exploded View"](#).

P0340 CMP SENSOR (PHASE)

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0340 CMP SENSOR (PHASE)

DTC Logic

INFOID:000000009020778

DTC DETECTION LOGIC

NOTE:

If DTC P0340 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|--|--|
| P0340 | Camshaft position sensor (PHASE) circuit | <ul style="list-style-type: none">The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking.The cylinder No. signal is not sent to ECM during engine running.The cylinder No. signal is not in the normal pattern during engine running. | <ul style="list-style-type: none">Harness or connectors (Camshaft position sensor circuit is open or shorted)Camshaft position sensorIntake camshaftStarter motorStarting system circuitDead (Weak) battery |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V with ignition switch ON.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE-I

- Start engine and let it idle for at least 5 seconds.
If engine does not start, crank engine for at least 2 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-279, "Diagnosis Procedure"](#).
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-II

- Keep engine speed at more than 800 rpm for at least 5 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-279, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020779

1. CHECK STARTING SYSTEM

Turn ignition switch to START position.

Does the engine turn over? Does the starter motor operate?

- YES >> GO TO 2.
NO >> Check starting system.

2. CHECK GROUND CONNECTION

- Turn ignition switch OFF.

P0340 CMP SENSOR (PHASE)

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. Check ground connection E15. Refer to Ground Inspection in [GI-44. "Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace ground connection.

3. CHECK CAMSHAFT POSITION SENSOR (PHASE) POWER SUPPLY CIRCUIT

1. Disconnect camshaft position sensor (PHASE) harness connector.
2. Turn ignition switch ON.
3. Check the voltage between camshaft position sensor (PHASE) harness connector and ground.

| Camshaft position sensor (PHASE) | | Ground | Voltage |
|----------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| F21 | 1 | Ground | Approx. 5 V |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CAMSHAFT POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connectors.
3. Check the continuity between camshaft position sensor (PHASE) harness connector and ECM harness connector.

| Camshaft position sensor (PHASE) | | ECM | | Continuity |
|----------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F21 | 2 | F11 | 63 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CAMSHAFT POSITION SENSOR (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between camshaft position sensor (PHASE) harness connector and ECM harness connector.

| Camshaft position sensor (PHASE) | | ECM | | Continuity |
|----------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F21 | 3 | F11 | 65 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-281. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace camshaft position sensor (PHASE). Refer to [EM-48. "Exploded View"](#).

7. CHECK CAMSHAFT (INT)

Check the following.

P0340 CMP SENSOR (PHASE)

[HR16DE]


< DTC/CIRCUIT DIAGNOSIS >

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

Is the inspection result normal?

YES >> GO TO 8.

NO >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft. Refer to [EM-60, "Removal and Installation"](#).



8.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020780


1.CHECK CAMSHAFT POSITION SENSOR-I

1. Turn ignition switch OFF.
2. Loosen the fixing bolt of the sensor.
3. Disconnect camshaft position sensor harness connector.
4. Remove the sensor. Refer to [EM-48, "Exploded View"](#).
5. Visually check the sensor for chipping.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace camshaft position sensor. Refer to [EM-48, "Exploded View"](#).



2.CHECK CAMSHAFT POSITION SENSOR-II

Check resistance camshaft position sensor terminals as follows.

| Terminals (Polarity) | Resistance [at 25°C (77°F)] |
|----------------------|-----------------------------|
| 1 (+) - 2 (-) | Except 0 or ∞ Ω |
| 1 (+) - 3 (-) | |
| 2 (+) - 3 (-) | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace camshaft position sensor. Refer to [EM-48, "Exploded View"](#).

P0420 THREE WAY CATALYST FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0420 THREE WAY CATALYST FUNCTION

DTC Logic


INFOID:000000009020781

DTC DETECTION LOGIC

The ECM monitors the switching frequency ratio of air fuel ratio (A/F) sensor 1 and heated oxygen sensor 2.

A three way catalyst (manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of air fuel ratio (A/F) sensor 1 and heated oxygen sensor 2 approaches a specified limit value, the three way catalyst (manifold) malfunction is diagnosed.



| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P0420 | Catalyst system efficiency below threshold | <ul style="list-style-type: none"> Three way catalyst (manifold) does not operate properly. Three way catalyst (manifold) does not have enough oxygen storage capacity. | <ul style="list-style-type: none"> Three way catalyst (manifold) Exhaust tube Intake air leaks Fuel injector Fuel injector leaks Spark plug Improper ignition timing |

DTC CONFIRMATION PROCEDURE

1. INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

YES >> GO TO 2.

NO >> GO TO 7.

2. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Do not hold engine speed for more than the specified minutes below.

>> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-I

Ⓟ With CONSULT

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT.
6. Make sure that "COOLAN TEMP/S" indicates more than 70°C (158°F).
If not, warm up engine and go to next step when "COOLAN TEMP/S" indication reaches to 70°C (158°F).
7. Open engine hood.
8. Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT.
9. Rev engine up to 2,000 to 3,000 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely.

P0420 THREE WAY CATALYST FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

10. Check the indication of "CATALYST".

Which is displayed on CONSULT screen?

- CMPLT >> GO TO 6.
- INCMP >> GO TO 4.

4.PERFORM DTC CONFIRMATION PROCEDURE-II

1. Wait 5 seconds at idle.
2. Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).

Does the indication change to "CMPLT"?

- YES >> GO TO 6.
- NO >> GO TO 5.

5.PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Stop engine and cool it down to less than 70°C (158°F).
2. Perform DTC CONFIRMATION PROCEDURE again.

>> GO TO 3.

6.PERFORM DTC CONFIRMATION PROCEDURE-III

Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-284, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

7.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-283, "Component Function Check"](#).

NOTE:

Use component function check to check the overall function of the three way catalyst (manifold). During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-284, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020782

1.PERFORM COMPONENT FUNCTION CHECK

Without CONSULT

1. Start engine and warm it up to the normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Restart engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
4. Let engine idle for 1 minute.
5. Open engine hood.
6. Check the voltage between ECM harness connector terminals under the following condition.

| Connector | ECM | | Condition | Voltage (V) |
|-----------|---------------|----------|---|--|
| | + | - | | |
| | Terminal | Terminal | | |
| F11 | 50 (HO2S2) | 59 | Keeping engine speed at 2500 rpm constant under no load | The voltage fluctuation cycle takes more than 5 seconds. • 1 cycle: 0.6 - 1.0 → 0 - 0.3 → 0.6 - 1.0 |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-284, "Diagnosis Procedure"](#).

P0420 THREE WAY CATALYST FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

INFOID:00000009020783

Diagnosis Procedure

1. CHECK EXHAUST SYSTEM


Visually check exhaust tubes and muffler for dent.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace.

2. CHECK EXHAUST GAS LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust gas leak before the three way catalyst (manifold).



Is exhaust gas leak detected?

- YES >> Repair or replace.
- NO >> GO TO 3.

3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

- YES >> Repair or replace.
- NO >> GO TO 4.

4. CHECK IGNITION TIMING AND IDLE SPEED

Check the following items. Refer to [EC-131, "Work Procedure"](#).

For specification, refer to [EC-466, "Ignition Timing"](#)

For specification, refer to [EC-466, "Idle Speed"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Follow the [EC-131, "Work Procedure"](#).

5. CHECK FUEL INJECTOR

1. Stop engine and then turn ignition switch ON.
2. Check the voltage between ECM harness connector and ground.

| Cylinder | | ECM | | | | Voltage | |
|----------|--------------|-----------|----------|-----------|----------|-----------------|-----------------|
| No. | Front / Rear | + | | - | | | |
| | | Connector | Terminal | Connector | Terminal | | |
| 1 | Front | F10 | 31 | E16 | 108 | Battery voltage | |
| 2 | | | 30 | | | | |
| 3 | | | 29 | | | | |
| 4 | | | 25 | | | | |
| 1 | Rear | F10 | 12 | E16 | 108 | | Battery voltage |
| 2 | | | 20 | | | | |
| 3 | | | 16 | | | | |
| 4 | | | 24 | | | | |

P0420 THREE WAY CATALYST FUNCTION

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Perform [EC-434. "Diagnosis Procedure"](#).

6. CHECK FUNCTION OF IGNITION COIL-I

CAUTION:

Do the following procedure in the place where ventilation is good without the combustible.

1. Turn ignition switch OFF.
2. Remove fuel pump fuse in IPDM E/R to release fuel pressure.

NOTE:

Do not use CONSULT to release fuel pressure, or fuel pressure applies again during the following procedure.

3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch OFF.
6. Remove all ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
7. Remove ignition coil and spark plug of the cylinder to be checked.
8. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
9. Connect spark plug and harness connector to ignition coil.
10. Fix ignition coil using a rope etc. with gap of 13 - 17 mm (0.52 - 0.66 in) between the edge of the spark plug and grounded metal portion as shown in the figure.
11. Crank engine for about 3 seconds, and check whether spark is generated between the spark plug and the grounded metal portion.

Spark should be generated.

CAUTION:

- Do not approach to the spark plug and the ignition coil within 50 cm (19.7 in). Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20 kV or more.
- It might cause to damage the ignition coil if the gap of more than 17 mm (0.66 in) is taken.

NOTE:

When the gap is less than 13 mm (0.52 in), the spark might be generated even if the coil is malfunctioning.

Is the inspection result normal?

- YES >> GO TO 10.
NO >> GO TO 7.

7. CHECK FUNCTION OF IGNITION COIL-II


1. Turn ignition switch OFF.
2. Disconnect spark plug and connect a known-good spark plug.
3. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded metal portion.

Spark should be generated.

Is the inspection result normal?

- YES >> GO TO 8.
NO >> Check ignition coil, power transistor and their circuits. Refer to [EC-439. "Diagnosis Procedure"](#).

8. CHECK SPARK PLUG



P0420 THREE WAY CATALYST FUNCTION


[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Check the initial spark plug for fouling, etc.

Is the inspection result normal?

- YES >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [EM-116. "Spark Plug"](#).
NO >> Repair or clean spark plug. Then GO TO 9



9. CHECK FUNCTION OF IGNITION COIL-III

1. Reconnect the initial spark plugs.
2. Crank engine for about 3 seconds, and recheck whether spark is generated between the spark plug and the grounded portion.

Spark should be generated.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [EM-116. "Spark Plug"](#).

10. CHECK FUEL INJECTOR

1. Turn ignition switch OFF.
2. Remove fuel injector assembly.
Refer to [EM-40. "Removal and Installation"](#).
Keep fuel hose and all fuel injectors connected to fuel tube.
3. Disconnect all ignition coil harness connectors.
4. Reconnect all fuel injector harness connectors disconnected.
5. Turn ignition switch ON.

Does fuel drip from fuel injector?

- YES >> GO TO 11.
NO >> Replace the fuel injector(s) from which fuel is dripping. Refer to [EM-40. "Removal and Installation"](#).

11. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

Is the trouble fixed?

- YES >> INSPECTION END
NO >> Replace three way catalyst assembly. Refer to [EX-5. "Exploded View"](#).

P0441 EVAP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0441 EVAP CONTROL SYSTEM

DTC Logic

INFOID:000000009020784


DTC DETECTION LOGIC

NOTE:

If DTC P0441 is displayed with other DTC such as P2122, P2123, P2127, P2128 or P2138, first perform trouble diagnosis for other DTC.

In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control solenoid valve is open to admit purge flow. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a malfunction is determined.



| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P0441 | EVAP PURG FLOW/MON (EVAP control system incorrect purge flow) | EVAP control system does not operate properly, EVAP control system has a leak between intake manifold and EVAP control system pressure sensor. | <ul style="list-style-type: none"> • EVAP canister purge volume control solenoid valve stuck closed • EVAP control system pressure sensor and the circuit • Loose, disconnected or improper connection of rubber tube • Blocked rubber tube • Cracked EVAP canister • EVAP canister purge volume control solenoid valve circuit • Accelerator pedal position sensor • Blocked purge port • EVAP canister vent control valve |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

Will CONSULT be used?

- YES >> GO TO 2.
NO >> GO TO 5.

P0441 EVAP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

2. PERFORM DTC CONFIRMATION PROCEDURE-I

Ⓜ WITH CONSULT

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and let it idle for at least 70 seconds.
6. Select "PURG FLOW P0441" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode of "ENGINE" using CONSULT.
7. Touch "START".

Is "COMPLETED" displayed on CONSULT screen?

- YES >> GO TO 4.
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-II

When the following conditions are met, "TESTING" will be displayed on the CONSULT screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take at least 35 seconds.)

| | |
|----------------|-----------------------------|
| Selector lever | Suitable position |
| VHCL SPEED SE | 32 - 120 km/h (20 - 75 MPH) |
| ENG SPEED | 500 - 3,800 rpm |
| B/FUEL SCHDL | 1.0 - 10 msec |
| COOLAN TEMP/S | More than 0°C (32°F) |

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "TESTING" does not change for a long time, retry from step 2.

Is "COMPLETED" displayed on CONSULT screen?

- YES >> GO TO 4.
NO >> Perform DTC CONFIRMATION PROCEDURE again. GO TO 2.

4. PERFORM DTC CONFIRMATION PROCEDURE-III

Touch "SELF-DIAG RESULTS".

Which is displayed on CONSULT screen?

- OK >> INSPECTION END
NG >> Proceed to [EC-289, "Diagnosis Procedure"](#).

5. PERFORM COMPONENT FUNCTION CHECK

Ⓜ WITH GST

Perform component function check. Refer to [EC-288, "Component Function Check"](#).

NOTE:

Use component function check to check the overall monitoring function of the EVAP control system purge flow monitoring. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Proceed to [EC-289, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020785

1. PERFORM COMPONENT FUNCTION CHECK

1. Lift up drive wheels.
2. Start engine (VDC switch OFF) and warm it up to normal operating temperature.
3. Turn ignition switch OFF and wait at least 10 seconds.

P0441 EVAP CONTROL SYSTEM

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

4. Start engine and wait at least 70 seconds.
5. Set voltmeter probes to ECM harness connector terminals as per the following.

| ECM | | |
|-----------|----------|----|
| Connector | + | - |
| | Terminal | |
| F11 | 43 | 68 |

6. Check EVAP control system pressure sensor value at idle speed and note it.
7. Establish and maintain the following conditions for at least 1 minute.

| | |
|-----------------------------|-----------------------------------|
| Air conditioner switch | ON |
| Headlamp switch | ON |
| Rear window defogger switch | ON |
| Engine speed | Approx. 3,000 rpm |
| Gear position | Any position other than P, N or R |

8. Verify that EVAP control system pressure sensor value stays 0.1 V less than the value at idle speed (measured at step 6) for at least 1 second.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Proceed to [EC-289, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020786

1.CHECK EVAP CANISTER

1. Turn ignition switch OFF.
2. Check EVAP canister for cracks.

Is the inspection result normal?

- YES-1 >> With CONSULT: GO TO 2.
 YES-2 >> Without CONSULT: GO TO 3.
 NO >> Replace EVAP canister. Refer to [FL-14, "Removal and Installation"](#).

2.CHECK PURGE FLOW

Ⓜ WITH CONSULT

1. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine and let it idle.
3. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
4. Touch "Qd" and "Qu" on CONSULT screen to adjust "PURG VOL CONT/V" opening and check vacuum existence.

| PURG VOL CONT/V | Vacuum |
|-----------------|-------------|
| 100% | Existed |
| 0% | Not existed |

Is the inspection result normal?

- YES >> GO TO 7.
 NO >> GO TO 4.

3.CHECK PURGE FLOW

Ⓧ WITHOUT CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.

P0441 EVAP CONTROL SYSTEM

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

3. Disconnect vacuum hose connected to EVAP canister purge volume control solenoid valve at EVAP service port and install vacuum gauge. For the location of EVAP service port, refer to [FL-14, "Exploded View"](#).
4. Start engine and let it idle.
Never depress accelerator pedal even slightly.
5. Check vacuum gauge indication before 60 seconds pass after starting engine.

Vacuum should not exist.

6. Rev engine up to 2,000 rpm after 100 seconds pass after starting engine.

Vacuum should exist.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 4.

4. CHECK EVAP PURGE LINE


1. Turn ignition switch OFF.
2. Check EVAP purge line for improper connection or disconnection.
Refer to [EC-40, "EVAPORATIVE EMISSION SYSTEM : System Diagram"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair EVAP purge line.

5. CHECK EVAP PURGE HOSE AND PURGE PORT


1. Disconnect purge hoses connected to EVAP service port (A) and EVAP canister purge volume control solenoid valve (B).
2. Blow air into each hose and EVAP purge port (C).



3. Check that air flows freely.

Is the inspection result normal?

- YES-1 >> With CONSULT: GO TO 6.
YES-2 >> Without CONSULT: GO TO 7.
NO >> Repair or clean hoses and/or purge port.



6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓟ WITH CONSULT

1. Start engine.
2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT. Check that engine speed varies according to the valve opening.

Does engine speed vary according to the valve opening?

- YES >> GO TO 8.
NO >> GO TO 7.

P0441 EVAP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Check the EVAP canister purge volume control solenoid valve. Refer to [EC-295, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace EVAP canister purge volume control solenoid valve. Refer to [FL-14, "Exploded View"](#).

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.

2. Check that water is not inside connectors.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

9. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR FUNCTION

Refer to [EC-312, "DTC Logic"](#) for DTC P0452, [EC-315, "DTC Logic"](#) for DTC P0453.

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

10. CHECK RUBBER TUBE FOR CLOGGING

1. Disconnect rubber tube connected to EVAP canister vent control valve.

2. Check the rubber tube for clogging.

Is the inspection result normal?

YES >> GO TO 11.

NO >> Clean the rubber tube using an air blower.

11. CHECK EVAP CANISTER VENT CONTROL VALVE

Check the EVAP canister vent control valve. Refer to [EC-301, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 12.

NO >> Replace EVAP canister vent control valve. Refer to [FL-17, "Removal and Installation"](#).

12. CHECK EVAP PURGE LINE

Inspect EVAP purge line (pipe and rubber tube). Check for evidence of leaks.

Refer to [EC-40, "EVAPORATIVE EMISSION SYSTEM : System Diagram"](#).

Is the inspection result normal?

YES >> GO TO 13.

NO >> Repair or replace malfunctioning part.

13. CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 14.

14. CHECK INTERMITTENT INCIDENT

Perform [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

DTC Logic

INFOID:00000009020791

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | | Possible cause |
|---------|---|-------------------------|--|---|
| P0443 | PURG VOLUME CONT/V (EVAP canister purge volume control solenoid valve) | A | The canister purge flow is detected during the vehicle is stopped while the engine is running, even when EVAP canister purge volume control solenoid valve is completely closed. | <ul style="list-style-type: none">• EVAP control system pressure sensor• EVAP canister purge volume control solenoid valve (The valve is stuck open.)• EVAP canister vent control valve• EVAP canister• Hoses (Hoses are connected incorrectly or clogged.) |
| | | B | The canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control solenoid valve is completely closed. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

- Perform DTC CONFIRMATION PROCEDURE when the fuel is between 1/4 and 3/4 full, and vehicle is placed on flat level surface.
- Always perform test at a temperature of 5 to 60°C (41 to 140°F).
- Cool the vehicle so that engine coolant temperature becomes same level as ambient temperature.

Do you have CONSULT

- YES >> GO TO 2.
NO >> GO TO 4.

2. PERFORM DTC CONFIRMATION PROCEDURE A

Ⓟ With CONSULT

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
3. Check that the following condition are met.
FUEL T/TMP SE: 0 - 35°C (32 - 95°F)
4. Start engine and wait at least 60 seconds.
5. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-293, "Diagnosis Procedure"](#).
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE B

Ⓟ With CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Select "PURG VOL CN/V P1444" of "EVAPORATIVE SYSTEM" in "DTC WORK SUPPORT" mode of "ENGINE" using CONSULT.
5. Touch "START".
6. Start engine and let it idle until "TESTING" on CONSULT changes to "COMPLETED". (It will take approximately 10 seconds.)
If "TESTING" is not displayed after 5 minutes, retry from step 2.
7. Touch "SELF-DIAG RESULT".

P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Which is displayed on CONSULT?

- OK >> INSPECTION END
- NG >> Proceed to [EC-293, "Diagnosis Procedure"](#).

4. PERFORM DTC CONFIRMATION PROCEDURE A

 With GST

1. Turn ignition switch ON.
2. Check the voltage between ECM harness connector and ground.

| ECM | | Ground | Voltage |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| F11 | 43 | Ground | 3.1 - 4.0 V |

3. Start engine and wait at least 60 seconds.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-293, "Diagnosis Procedure"](#).
- NO >> GO TO 5.

5. PERFORM DTC CONFIRMATION PROCEDURE

 With GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and let it idle for at least 20 seconds.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-293, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020792

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch ON.
4. Check the voltage between EVAP canister purge volume control solenoid valve harness connector and ground.

| EVAP canister purge volume control solenoid valve | | Ground | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| F22 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check the continuity between EVAP canister purge volume control solenoid valve harness connector and IPDM E/R harness connector.

| EVAP canister purge volume control solenoid valve | | IPDM E/R | | Continuity |
|---|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F22 | 1 | E44 | 11 | Existed |

P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

4. Also check harness for short to ground.

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit.

NO >> Repair or replace error-detected parts.

3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE GROUND CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect ECM harness connector.

3. Check the continuity between EVAP canister purge volume control solenoid valve harness connector and ECM harness connector.

| EVAP canister purge volume control solenoid valve | | ECM | | Continuity |
|---|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F22 | 2 | F10 | 9 | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.

2. Check connectors for water.

Water should not exist.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Check the EVAP control system pressure sensor. Refer to [EC-295, "Component Inspection"](#).


Is the inspection result normal?

YES-1 >> With CONSULT: GO TO 6.

YES-2 >> Without CONSULT: GO TO 7.

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 With CONSULT

1. Turn ignition switch OFF.

2. Reconnect harness connectors disconnected.

3. Start engine.

4. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT. Check that engine speed varies according to the valve opening.

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 7.

7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Check the EVAP canister purge volume control solenoid valve. Refer to [EC-295, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace EVAP canister purge volume control solenoid valve. Refer to [FL-14, "Exploded View"](#).

8. CHECK RUBBER TUBE FOR CLOGGING

1. Disconnect rubber tube connected to EVAP canister vent control valve.

2. Check the rubber tube for clogging.

P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Is the inspection result normal?

- YES >> GO TO 9.
NO >> Clean the rubber tube using an air blower.

9. CHECK EVAP CANISTER VENT CONTROL VALVE

Check the EVAP canister vent control valve. Refer to [EC-301. "Component Inspection"](#).

Is the inspection result normal?


- YES >> GO TO 10.
NO >> Replace EVAP canister vent control valve. Refer to [FL-17. "Removal and Installation"](#).

10. CHECK IF EVAP CANISTER IS SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve and EVAP control system pressure sensor attached.
2. Check if water will drain from EVAP canister.

Does water drain from the EVAP canister?

- YES >> GO TO 11.
NO >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).



11. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve and EVAP control system pressure sensor attached.

The weight should be less than 1.6 kg (3.5 lb).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
NO >> GO TO 12.

12. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and vehicle frame for clogging or poor connection

>> Repair hose or replace EVAP canister. Refer to [FL-14. "Removal and Installation"](#).

Component Inspection

INFOID:000000009020793

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Ⓜ With CONSULT

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Disconnect EVAP purge hoses connected to EVAP canister purge volume control solenoid valve.
4. Turn ignition switch ON.
5. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.


P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

6. Touch “Qd” and “Qu” on CONSULT screen to adjust “PURG VOL C/V” opening and check air passage continuity of EVAP canister purge volume control solenoid valve as per the following conditions.

| Condition (PURG VOL C/V value) | Air passage continuity between (A) and (B) |
|-----------------------------------|---|
| 100% | Existed |
| 0% | Not existed |



⊗ Without CONSULT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Disconnect EVAP purge hoses connected to EVAP canister purge volume control solenoid valve.
4. Check air passage continuity of EVAP canister purge volume control solenoid valve as per the following conditions.

| Condition | Air passage continuity between (A) and (B) |
|---|---|
| 12 V direct current supply between terminals 1 and 2 | Existed |
| No supply | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace EVAP canister purge volume control solenoid valve. Refer to [FL-14, "Removal and Installation"](#).

P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

DTC Logic

INFOID:000000009020794

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P0444 | EVAP canister purge volume control solenoid valve circuit open | An excessively low voltage signal is sent to ECM through the valve | <ul style="list-style-type: none"> • Harness or connectors (The solenoid valve circuit is open or shorted.) • EVAP canister purge volume control solenoid valve |
| P0445 | EVAP canister purge volume control solenoid valve circuit shorted | An excessively high voltage signal is sent to ECM through the valve | <ul style="list-style-type: none"> • Harness or connectors (The solenoid valve circuit is open or shorted.) • EVAP canister purge volume control solenoid valve |

DTC CONFIRMATION PROCEDURE

1.CONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11 V at idle.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for at least 13 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-297. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020795

1.CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch ON.
4. Check the voltage between EVAP canister purge volume control solenoid valve harness connector and ground.

| EVAP canister purge volume control solenoid valve | | Ground | Voltage |
|---|----------|--------|-----------------|
| Connector | Terminal | | |
| F22 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following.

- Harness connector E55, F55
- Harness for open or short between EVAP canister purge volume control solenoid valve and IPDM E/R
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVAP canister purge volume control solenoid valve harness connector and ECM harness connector.

| EVAP canister purge volume control solenoid valve | | ECM | | Continuity |
|---|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F22 | 2 | F10 | 9 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES-1 >> With CONSULT: GO TO 4.

YES-2 >> Without CONSULT: GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

 **With CONSULT**

1. Reconnect all harness connectors disconnected.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that engine speed varies according to the valve opening.

Does engine speed vary according to the valve opening?

YES >> GO TO 6.

NO >> GO TO 5.

5. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-298, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace EVAP canister purge volume control solenoid valve. Refer to [FL-14, "Removal and Installation"](#).

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020796

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

 **With CONSULT**

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Disconnect EVAP purge hoses connected to EVAP canister purge volume control solenoid valve.
4. Turn ignition switch ON.
5. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT.


P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

6. Touch "Qd" and "Qu" on CONSULT screen to adjust "PURG VOL C/V" opening and check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.


| Condition (PURG VOL C/V value) | Air passage continuity between (A) and (B) |
|-----------------------------------|---|
| 100% | Existed |
| 0% | Not existed |



⊗ Without CONSULT

1. Turn ignition switch OFF.
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Disconnect EVAP purge hoses connected to EVAP canister purge volume control solenoid valve.
4. Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

| Condition | Air passage continuity between (A) and (B) |
|---|---|
| 12 V direct current supply between terminals 1 and 2 | Existed |
| No supply | Not existed |



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace EVAP canister purge volume control solenoid valve. Refer to [FL-14, "Removal and Installation"](#).

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P0447 EVAP CANISTER VENT CONTROL VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0447 EVAP CANISTER VENT CONTROL VALVE

DTC Logic

INFOID:000000009020797

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|--|--|---|
| P0447 | VENT CONTROL VALVE (EVAP canister vent control valve circuit open) | An improper voltage signal is sent to ECM through EVAP canister vent control valve. | <ul style="list-style-type: none">• Harness or connectors (EVAP canister vent control valve circuit is open or shorted.)• EVAP canister vent control valve |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and wait at least 8 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-300, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020798

1. INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

- YES >> GO TO 2.
NO >> GO TO 3.

2. CHECK EVAP CANISTER VENT CONTROL VALVE CIRCUIT

Ⓟ With CONSULT

1. Turn ignition switch OFF and then turn ON.
2. Select "VENT CONTROL/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
3. Touch "ON/OFF" on CONSULT screen.
4. Check for operating sound of the valve.

Clicking sound should be heard.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 3.

3. CHECK EVAP CANISTER VENT CONTROL VALVE POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect EVAP canister vent control valve harness connector.
3. Turn ignition switch ON.

P0447 EVAP CANISTER VENT CONTROL VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

4. Check the voltage between EVAP canister vent control valve harness connector and ground.

| EVAP canister vent control valve | | Ground | Voltage |
|----------------------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| B5 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 4.

4. CHECK EVAP CANISTER VENT CONTROL VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check the continuity between EVAP canister vent control valve harness connector and IPDM E/R harness connector.

| EVAP canister vent control valve | | IPDM E/R | | Continuity |
|----------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B5 | 1 | E42 | 34 | Existed |

4. Also check harness for short to ground.

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit.
NO >> Repair or replace error-detected parts.

5. CHECK EVAP CANISTER VENT CONTROL VALVE OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVAP canister vent control valve harness connector and ECM harness connector.

| EVAP canister vent control valve | | ECM | | Continuity |
|----------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B5 | 2 | F10 | 26 | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace error-detected parts.

6. CHECK RUBBER TUBE FOR CLOGGING

1. Disconnect rubber tube connected to EVAP canister vent control valve.
2. Check the rubber tube for clogging.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Clean the rubber tube using an air blower.

7. CHECK EVAP CANISTER VENT CONTROL VALVE

Check the EVAP canister vent control valve. Refer to [EC-301, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Replace EVAP canister vent control valve. Refer to [FL-17, "Removal and Installation"](#).

Component Inspection

INFOID:000000009020799

1. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Turn ignition switch OFF.

P0447 EVAP CANISTER VENT CONTROL VALVE


[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. Remove EVAP canister vent control valve from EVAP canister.
3. Check portion (A) of EVAP canister vent control valve for being rusted.

Is it rusted?

- YES >> Replace EVAP canister vent control valve. Refer to [FL-17. "Removal and Installation"](#).
- NO >> GO TO 2.



2. CHECK EVAP CANISTER VENT CONTROL VALVE-II

With CONSULT

1. Reconnect harness connectors disconnected.
2. Turn ignition switch ON.
3. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
4. Check air passage continuity and operation delay time.
Make sure new O-ring is installed properly.

| VENT CONT/V condition | Air passage continuity between (A) and (B) |
|-----------------------|--|
| ON | Not existed |
| OFF | Existed |

Operation takes less than 1 second.

Without CONSULT

Check air passage continuity and operation delay time under the following conditions.

Make sure new O-ring is installed properly.

| Condition | Air passage continuity between (A) and (B) |
|--|--|
| 12 V direct current supply between terminals (1) and (2) | Not existed |
| OFF | Existed |

Operation takes less than 1 second.

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Replace EVAP canister vent control valve. Refer to [FL-17. "Removal and Installation"](#).

3. CHECK EVAP CANISTER VENT CONTROL VALVE-III

With CONSULT



1. Clean the air passage [portion (A) to (B)] of EVAP canister vent control valve using an air blower.
2. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
3. Check air passage continuity and operation delay time.
Make sure new O-ring is installed properly.

| VENT CONT/V condition | Air passage continuity between (A) and (B) |
|-----------------------|--|
| ON | Not existed |
| OFF | Existed |

Operation takes less than 1 second.

Without CONSULT

1. Clean the air passage [portion (A) to (B)] of EVAP canister vent control valve using an air blower.
2. Check air passage continuity and operation delay time under the following conditions.



P0447 EVAP CANISTER VENT CONTROL VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Make sure new O-ring is installed properly.

| Condition | Air passage continuity between (A) and (B) |
|--|--|
| 12 V direct current supply between terminals (1) and (2) | Not existed |
| OFF | Existed |

Operation takes less than 1 second.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace EVAP canister vent control valve. Refer to [FL-17, "Removal and Installation"](#).

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

P0448 EVAP CANISTER VENT CONTROL VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0448 EVAP CANISTER VENT CONTROL VALVE

DTC Logic

INFOID:000000009020800

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P0448 | VENT CONTROL VALVE (EVAP canister vent control valve close) | EVAP canister vent control valve remains closed under specified driving conditions. | <ul style="list-style-type: none">• EVAP canister vent control valve• EVAP control system pressure sensor and the circuit• Blocked rubber tube to EVAP canister vent control valve• EVAP canister is saturated with water |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.


2. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Turn ignition switch ON and wait at least 5 seconds.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON and select "DATA MONITOR" mode of "ENGINE" using CONSULT.
4. Start engine and let it idle for at least 1 minute.
5. Repeat next procedures three times.
 - Increase the engine speed up to 3,000 to 3,500 rpm and keep it for 2 minutes and 50 seconds to 3 minutes.

Never exceed 3 minutes.

- Fully released accelerator pedal and keep engine idle for about 5 seconds.
6. Repeat next procedure 20 times.
 - Quickly increase the engine speed up to 4,000 to 4,500 rpm or more and keep it for 25 to 30 seconds.
 - Fully released accelerator pedal and keep engine idle for at least 35 seconds.



7. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT" above.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-304, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020801

1. CHECK RUBBER TUBE

P0448 EVAP CANISTER VENT CONTROL VALVE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect rubber tube connected to EVAP canister vent control valve.
3. Check the rubber tube for clogging.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Clean rubber tube using an air blower.

2.CHECK EVAP CANISTER VENT CONTROL VALVE

Check the EVAP canister vent control valve. Refer to [EC-306, "Component Inspection"](#).

Is the inspection result normal?


- YES >> GO TO 3.
NO >> Replace EVAP canister vent control valve. Refer to [FL-17, "Removal and Installation"](#).

3.CHECK IF EVAP CANISTER IS SATURATED WITH WATER

1. Remove EVAP canister with EVAP canister vent control valve and EVAP control system pressure sensor attached.
2. Check if water will drain from the EVAP canister.

Does water drain from EVAP canister?

- YES >> GO TO 4.
NO >> GO TO 6.



4.CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve and EVAP control system pressure sensor attached.

The weight should be less than 1.6 kg (3.5 lb).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 5.

5.DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and vehicle frame for clogging or poor connection

>> Repair hose or replace EVAP canister. Refer to [FL-14, "Removal and Installation"](#).

6.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR

1. Disconnect EVAP control system pressure sensor harness connector.
2. Check connectors for water.

Water should not exist.

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

7.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Check the EVAP control system pressure sensor. Refer to [EC-310, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

P0448 EVAP CANISTER VENT CONTROL VALVE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

INFOID:00000009020802


Component Inspection

1. CHECK EVAP CANISTER VENT CONTROL VALVE-I

1. Turn ignition switch OFF.
2. Remove EVAP canister vent control valve from EVAP canister.
3. Check portion (A) of EVAP canister vent control valve for being rusted.

Is it rusted?

- YES >> Replace EVAP canister vent control valve. Refer to [FL-17, "Removal and Installation"](#).
- NO >> GO TO 2.



2. CHECK EVAP CANISTER VENT CONTROL VALVE-II

With CONSULT

1. Reconnect harness connectors disconnected.
2. Turn ignition switch ON.
3. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
4. Check air passage continuity and operation delay time.
Make sure new O-ring is installed properly.

| VENT CONT/V condition | Air passage continuity between (A) and (B) |
|-----------------------|--|
| ON | Not existed |
| OFF | Existed |

Operation takes less than 1 second.

Without CONSULT

Check air passage continuity and operation delay time under the following conditions.

Make sure new O-ring is installed properly.

| Condition | Air passage continuity between (A) and (B) |
|--|--|
| 12 V direct current supply between terminals (1) and (2) | Not existed |
| OFF | Existed |

Operation takes less than 1 second.


Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Replace EVAP canister vent control valve. Refer to [FL-17, "Removal and Installation"](#).

3. CHECK EVAP CANISTER VENT CONTROL VALVE-III

With CONSULT

1. Clean the air passage [portion (A) to (B)] of EVAP canister vent control valve using an air blower.
2. Perform "VENT CONTROL/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.



P0448 EVAP CANISTER VENT CONTROL VALVE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

3. Check air passage continuity and operation delay time.
Make sure new O-ring is installed properly.

| VENT CONT/V condition | Air passage continuity between (A) and (B) |
|-----------------------|--|
| ON | Not existed |
| OFF | Existed |

Operation takes less than 1 second.

⊗ Without CONSULT

- Clean the air passage [portion (A) to (B)] of EVAP canister vent control valve using an air blower.
- Check air passage continuity and operation delay time under the following conditions.
Make sure new O-ring is installed properly.


| Condition | Air passage continuity between (A) and (B) |
|--|--|
| 12 V direct current supply between terminals (1) and (2) | Not existed |
| OFF | Existed |

Operation takes less than 1 second.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace EVAP canister vent control valve. Refer to [FL-17. "Removal and Installation"](#).



A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

P0451 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0451 EVAP CONTROL SYSTEM PRESSURE SENSOR

DTC Logic

INFOID:000000009020803

DTC DETECTION LOGIC

NOTE:

If DTC P0451 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|--|--|---|
| P0451 | EVAP SYS PRES SEN (EVAP control system pressure sensor performance) | ECM detects a sloshing signal from the EVAP control system pressure sensor | <ul style="list-style-type: none">• Harness or connectors (EVAP control system pressure sensor circuit is shorted.)• EVAP control system pressure sensor |

DTC CONFIRMATION PROCEDURE

NOTE:

Never remove fuel filler cap during DTC confirmation procedure.

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

With CONSULT>>GO TO 2.

Without CONSULT>>GO TO 5.

2. PERFORM DTC CONFIRMATION PROCEDURE-1

Ⓟ With CONSULT

1. Start engine and let it idle for least 40 seconds.

NOTE:

Do not depress accelerator pedal even slightly.

2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Proceed to [EC-309, "Diagnosis Procedure"](#).

NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE-2

Ⓟ With CONSULT

1. Select "EVAP DIAG READY" in "DATA MONITOR" mode of "ENGINE".
2. Let it idle until "OFF" of "EVAP DIAG READY" changes to "ON".

NOTE:

It will take at most 2 hours until "OFF" of "EVAP DIAG READY" changes to "ON".

3. Turn ignition switch OFF and wait at least 90 minutes.

NOTE:

Never turn ignition switch ON during 90 minutes.

4. Turn ignition switch ON.
5. Select "EVAP LEAK DIAG" in "DATA MONITOR" mode of "ENGINE".
6. Check that "EVAP LEAK DIAG" indication.

Which is displayed on CONSULT?

CMPLT >> GO TO 4.

YET >> 1. Perform DTC CONFIRMATION PROCEDURE again.

2. GO TO 1.

4. PERFORM DTC CONFIRMATION PROCEDURE-3

P0451 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Ⓜ With CONSULT
Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-309, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

5.PERFORM DTC CONFIRMATION PROCEDURE-4

Ⓜ With GST

1. Start engine and let it idle for least 40 seconds.

NOTE:

Do not depress accelerator pedal even slightly.

2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-309, "Diagnosis Procedure"](#).
- NO >> GO TO 6.

6.PERFORM DTC CONFIRMATION PROCEDURE-5

Ⓜ With GST

1. Let it idle for at least 2 hours.
2. Turn ignition switch OFF and wait at least 90 minutes.

NOTE:

Never turn ignition switch ON during 90 minutes.

3. Turn ignition switch ON.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-309, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020804

1.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR FOR WATER

1. Turn ignition switch OFF.
2. Disconnect EVAP control system pressure sensor harness connector.
3. Check sensor harness connector for water.

Water should not exist.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace harness connector.

2.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check the voltage between EVAP control system pressure sensor harness connector and ground.

| EVAP control system pressure sensor | | Ground | Voltage (Approx.) |
|-------------------------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| B3 | 3 | Ground | 5 V |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 3.

3.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

P0451 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 3 | F11 | 71 | Existed |

4. Also check harness for short to ground and to power.

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit.

NO >> Repair or replace error-detected parts

4. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 1 | F11 | 68 | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

5. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR SIGNAL CIRCUIT

1. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 2 | F11 | 43 | Existed |

2. Also check harness for short to ground and to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

6. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Check the EVAP control system pressure sensor. Refer to [EC-310, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

Component Inspection

INFOID:000000009020805

1. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Turn ignition switch OFF.
2. Remove EVAP control system pressure sensor with its harness connector connected from EVAP canister.
Always replace O-ring with a new one.
3. Install a vacuum pump to EVAP control system pressure sensor.
4. Turn ignition switch ON and check output voltage between ECM harness connector and ground under the following conditions.

P0451 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECM | | | Condition [Applied vacuum kPa (kg/cm ² , psi)] | Voltage |
|-----------|----------|----|--|-------------------------------------|
| Connector | + | - | | |
| | Terminal | | | |
| F11 | 43 | 68 | Not applied | 0.5 - 4.6 V |
| | | | -26.7 (-0.272, -3.87) | 2.1 to 2.5 V lower than above value |

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-0.952 kg/cm², -13.53 psi) or pressure over 101.3 kPa (1.033 kg/cm², 14.69 psi).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

DTC Logic

INFOID:000000009020806

DTC DETECTION LOGIC

NOTE:

If DTC P0451 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|--|--|---|
| P0452 | EVAP SYS PRES SEN (EVAP control system pressure sensor low input) | An excessively low voltage from the sensor is sent to ECM. | <ul style="list-style-type: none">• Harness or connectors (EVAP control system pressure sensor circuit is shorted.)• EVAP control system pressure sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
5. Make sure that "FUEL T/TMP SE" indication is more than 0°C (32°F).
6. Start engine and wait at least 20 seconds.
7. Check 1st trip DTC.

Ⓜ With GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes to ECM harness connector terminals as per the following.

| Connector | ECM | | Voltage |
|-----------|-----|----|-----------------|
| | + | - | |
| F11 | 43 | 68 | Less than 4.2 V |

3. Make sure that the voltage is less than 4.2 V.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and wait at least 20 seconds.
6. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-312, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020807

1. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR FOR WATER

P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect EVAP control system pressure sensor harness connector.
3. Check sensor harness connector for water.

Water should not exist.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness connector.

2.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check the voltage between EVAP control system pressure sensor harness connector and ground.

| EVAP control system pressure sensor | | Ground | Voltage (Approx.) |
|-------------------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| B3 | 3 | Ground | 5 V |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 3 | F11 | 71 | Existed |

4. Also check harness for short to ground and to power.

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit.
NO >> Repair or replace error-detected parts

4.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 1 | F11 | 68 | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace error-detected parts.

5.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR SIGNAL CIRCUIT

1. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

P0452 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 2 | F11 | 43 | Existed |

2. Also check harness for short to ground and to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

6. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Check the EVAP control system pressure sensor. Refer to [EC-310. "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19. "Removal and Installation"](#).

Component Inspection

INFOID:000000009020808

1. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Turn ignition switch OFF.
2. Remove EVAP control system pressure sensor with its harness connector connected from EVAP canister.
Always replace O-ring with a new one.
3. Install a vacuum pump to EVAP control system pressure sensor.
4. Turn ignition switch ON and check output voltage between ECM harness connector and ground under the following conditions.

| ECM | | | Condition [Applied vacuum kPa (kg/cm ² , psi)] | Voltage |
|-----------|----|----------|--|-------------------------------------|
| Connector | + | - | | |
| | | Terminal | | |
| F11 | 43 | 68 | Not applied | 0.5 - 4.6 V |
| | | | -26.7 (-0.272, -3.87) | 2.1 to 2.5 V lower than above value |

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-0.952 kg/cm², -13.53 psi) or pressure over 101.3 kPa (1.033 kg/cm², 14.69 psi).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19. "Removal and Installation"](#).

P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

DTC Logic

INFOID:000000009020809

DTC DETECTION LOGIC

NOTE:

If DTC P0451 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P0453 | EVAP SYS PRES SEN (EVAP control system pressure sensor high input) | An excessively high voltage from the sensor is sent to ECM. | <ul style="list-style-type: none">• Harness or connectors (EVAP control system pressure sensor circuit is shorted.)• EVAP control system pressure sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Always perform test at a temperature of 5°C (41°F) or more.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
5. Make sure that "FUEL T/TMP SE" indication is more than 0°C (32°F).
6. Start engine and wait at least 20 seconds.
7. Check 1st trip DTC.

Ⓜ With GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes to ECM harness connector terminals as per the following.

| Connector | ECM | | Voltage |
|-----------|-----|----|-----------------|
| | + | - | |
| F11 | 43 | 68 | Less than 4.2 V |

3. Make sure that the voltage is less than 4.2 V.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Start engine and wait at least 20 seconds.
6. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-315, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020810

1. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR CONNECTOR FOR WATER

P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect EVAP control system pressure sensor harness connector.
3. Check sensor harness connector for water.

Water should not exist.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness connector.

2.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check the voltage between EVAP control system pressure sensor harness connector and ground.

| EVAP control system pressure sensor | | Ground | Voltage (Approx.) |
|-------------------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| B3 | 3 | Ground | 5 V |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 3 | F11 | 71 | Existed |

4. Also check harness for short to ground and to power.

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit.
NO >> Repair or replace error-detected parts

4.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 1 | F11 | 68 | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace error-detected parts.

5.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR SIGNAL CIRCUIT

1. Check the continuity between EVAP control system pressure sensor harness connector and ECM harness connector.

P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| EVAP control system pressure sensor | | ECM | | Continuity |
|-------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B3 | 2 | F11 | 43 | Existed |

2. Also check harness for short to ground and to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

6. CHECK RUBBER TUBE

1. Disconnect rubber tube connected to EVAP canister vent control valve.

2. Check the rubber tube for clogging.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Clean the rubber tube using an air blower, repair or replace rubber tube.

7. CHECK EVAP CANISTER VENT CONTROL VALVE

Refer to [EC-301, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace EVAP canister vent control valve. Refer to [FL-17, "Removal and Installation"](#).

8. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Refer to [EC-318, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

9. CHECK IF EVAP CANISTER IS SATURATED WITH WATER


1. Remove EVAP canister with EVAP canister vent control valve and EVAP control system pressure sensor attached.

2. Check if water will drain from the EVAP canister.

Does water drain from EVAP canister?

YES >> GO TO 10.

NO >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).



10. CHECK EVAP CANISTER

Weigh the EVAP canister with the EVAP canister vent control valve and EVAP control system pressure sensor attached.

The weight should be less than 1.6 kg (3.5 lb).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 11.

11. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and vehicle frame for clogging or poor connection

P0453 EVAP CONTROL SYSTEM PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

>> Repair hose or replace EVAP canister. Refer to [FL-14, "Removal and Installation"](#).

Component Inspection

INFOID:000000009020811

1. CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

1. Turn ignition switch OFF.
2. Remove EVAP control system pressure sensor with its harness connector connected from EVAP canister.
Always replace O-ring with a new one.
3. Install a vacuum pump to EVAP control system pressure sensor.
4. Turn ignition switch ON and check output voltage between ECM harness connector and ground under the following conditions.

| ECM | | | Condition [Applied vacuum kPa (kg/cm ² , psi)] | Voltage |
|-----------|----|----|--|-------------------------------------|
| Connector | + | - | | |
| F11 | 43 | 68 | Not applied | 0.5 - 4.6 V |
| | | | -26.7 (-0.272, -3.87) | 2.1 to 2.5 V lower than above value |

CAUTION:

- Always calibrate the vacuum pump gauge when using it.
- Do not apply below -93.3 kPa (-0.952 kg/cm², -13.53 psi) or pressure over 101.3 kPa (1.033 kg/cm², 14.69 psi).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

P0456 EVAP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0456 EVAP CONTROL SYSTEM


DTC Logic

INFOID:000000009020816

DTC DETECTION LOGIC

This diagnosis detects leaks in the EVAP line between fuel tank and EVAP canister purge volume control solenoid valve, using the negative pressure caused by decrease of fuel temperature in the fuel tank after turning ignition switch OFF.

If ECM judges there are no leaks, the diagnosis will be OK.



| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P0456 | EVAP VERY SML LEAK (Evaporative emission control system leak) | <ul style="list-style-type: none"> • EVAP system has a leak. • EVAP system does not operate properly. | <ul style="list-style-type: none"> • Incorrect fuel tank vacuum relief valve • Incorrect fuel filler cap used • Fuel filler cap remains open or does not close. • Foreign matter caught in fuel filler cap. • Leak is in line between intake manifold and EVAP canister purge volume control solenoid valve. • Foreign matter caught in EVAP canister vent control valve. • EVAP canister or fuel tank leaks • EVAP purge line (pipe and rubber tube) leaks • EVAP purge line rubber tube bent • Loose or disconnected rubber tube • EVAP canister vent control valve and the circuit • EVAP canister purge volume control solenoid valve and the circuit • Fuel tank temperature sensor • O-ring of EVAP canister vent control valve is missing or damaged • EVAP canister is saturated with water • EVAP control system pressure sensor • Refueling EVAP vapor cut valve • ORVR system leaks • Fuel level sensor and the circuit • Foreign matter caught in EVAP canister purge volume control solenoid valve |

CAUTION:

- Use only a genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may illuminate.
- If the fuel filler cap is not tightened properly, the MIL may illuminate.
- Use only a genuine NISSAN rubber tube as a replacement.

DTC CONFIRMATION PROCEDURE

P0456 EVAP CONTROL SYSTEM

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

Do you have CONSULT?

- YES >> GO TO 2.
NO >> GO TO 4.

2. PERFORM DTC CONFIRMATION PROCEDURE-I

ⓑ WITH CONSULT

1. Turn ignition switch ON and select "EVAP DIAG READY" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
2. Start engine and wait at idle until "OFF" of "EVAP DIAG READY" changes to "ON".

NOTE:

It will take at most 2 hours until "OFF" of "EVAP DIAG READY" changes to "ON".

3. Turn ignition switch OFF and wait at least 90 minutes.

NOTE:

Never turn ignition switch ON during 90 minutes.

4. Turn ignition switch ON and select "EVAP LEAK DIAG" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
5. Check that "EVAP LEAK DIAG" indication.

Which is displayed on CONSULT?

- CMPLT >> GO TO 3.
YET >> Perform DTC CONFIRMATION PROCEDURE again. GO TO 1.

3. PERFORM DTC CONFIRMATION PROCEDURE-II

Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-320, "Diagnosis Procedure"](#).
NO >> INSPECTION END.

4. PERFORM DTC CONFIRMATION PROCEDURE

ⓐ WITH GST

1. Start engine and wait engine idle for at least 2 hours.
2. Turn ignition switch OFF and wait at least 90 minutes.

NOTE:

Never turn ignition switch ON during 90 minutes.

3. Turn ignition switch ON.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-320, "Diagnosis Procedure"](#).
NO >> INSPECTION END.

Diagnosis Procedure

INFOID:000000009020817

1. CHECK FUEL FILLER CAP DESIGN

1. Turn ignition switch OFF.

P0456 EVAP CONTROL SYSTEM

[HR16DE]


< DTC/CIRCUIT DIAGNOSIS >

2. Check for genuine NISSAN fuel filler cap design.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace with genuine NISSAN fuel filler cap.



2. CHECK FUEL FILLER CAP INSTALLATION

Check that the cap is tightened properly by rotating the cap clockwise.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Open fuel filler cap, then clean cap and fuel filler neck threads using air blower. Then retighten until rereaching sound is heard.

3. CHECK FUEL FILLER CAP FUNCTION

Check for air releasing sound while opening the fuel filler cap.

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK FUEL TANK VACUUM RELIEF VALVE

Refer to [EC-324. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace fuel filler cap with a genuine one.

5. CHECK FOR EVAP LEAK

Refer to [EC-462. "Inspection"](#).

Is there any leak in EVAP line?

YES >> Repair or replace.

NO >> GO TO 6.

6. CHECK EVAP CANISTER VENT CONTROL VALVE

Check the following.

• EVAP canister vent control valve is installed properly.

Refer to [FL-17. "Exploded View"](#).

• EVAP canister vent control valve.

Refer to [EC-301. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace EVAP canister vent control valve and O-ring. Refer to [FL-17. "Removal and Installation"](#).

7. CHECK IF EVAP CANISTER SATURATED WITH WATER

P0456 EVAP CONTROL SYSTEM


[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Remove EVAP canister (1) with EVAP canister vent control valve (2) and EVAP control system pressure sensor attached.
2. Check if water will drain from the EVAP canister.

Does water drain from EVAP canister?

- YES >> GO TO 8.
NO-1 >> With CONSULT: GO TO 10.
NO-2 >> Without CONSULT: GO TO 11.



8. CHECK EVAP CANISTER

Weigh the EVAP canister assembly with the EVAP canister vent control valve and EVAP control system pressure sensor attached. Refer to [FL-17, "Removal and Installation"](#).

The weight should be less than 1.6 kg (3.5 lb).

Is the inspection result normal?

- YES-1 >> With CONSULT: GO TO 10.
YES-2 >> Without CONSULT: GO TO 11.
NO >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- EVAP canister for damage
- EVAP hose between EVAP canister and vehicle frame for clogging or poor connection

>> Repair hose or replace EVAP canister. Refer to [FL-14, "Removal and Installation"](#).

10. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

With CONSULT

1. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
2. Start engine and let it idle.
3. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
4. Touch "Qu" on CONSULT screen to increase "PURG VOL CONT/V" opening to 100%.
5. Check vacuum hose for vacuum.

Vacuum should exist.

Is the inspection result normal?

- YES >> GO TO 13.
NO >> GO TO 12.

11. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

Without CONSULT

1. Start engine and warm it up to normal operating temperature.
2. Stop engine.
3. Disconnect vacuum hose to EVAP canister purge volume control solenoid valve at EVAP service port.
4. Start engine and let it idle for at least 80 seconds.
5. Check vacuum hose for vacuum when revving engine up to 2,000 rpm.

Vacuum should exist.

Is the inspection result normal?

- YES >> GO TO 13.
NO >> GO TO 12.

12. CHECK VACUUM HOSE

Check vacuum hoses for clogging or disconnection. Refer to [FL-14, "Exploded View"](#).

Is the inspection result normal?

P0456 EVAP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

- YES >> GO TO 13.
NO >> Repair or reconnect the hose.

13.CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Check the EVAP canister purge volume control solenoid valve. Refer to [EC-295, "Component Inspection"](#).
Is the inspection result normal?

- YES >> GO TO 14.
NO >> Replace EVAP canister purge volume control solenoid valve. Refer to [FL-14, "Exploded View"](#).

14.CHECK FUEL TANK TEMPERATURE SENSOR

Check the fuel tank temperature sensor. Refer to [EC-256, "Component Inspection"](#).
Is the inspection result normal?

- YES >> GO TO 15.
NO >> Replace fuel level sensor unit. Refer to [FL-6, "Removal and Installation"](#).

15.CHECK EVAP CONTROL SYSTEM PRESSURE SENSOR

Check the EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).
Is the inspection result normal?

- YES >> GO TO 16.
NO >> Replace EVAP control system pressure sensor. Refer to [FL-19, "Removal and Installation"](#).

16.CHECK EVAP PURGE LINE

Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-40, "EVAPORATIVE EMISSION SYSTEM : System Description"](#).

Is the inspection result normal?

- YES >> GO TO 17.
NO >> Repair or reconnect the hose.

17.CLEAN EVAP PURGE LINE

Clean EVAP purge line (pipe and rubber tube) using air blower.

>> GO TO 18.

18.CHECK EVAP/ORVR LINE

Check EVAP/ORVR line between EVAP canister and fuel tank for clogging, kink, looseness and improper connection. For location, refer to [EC-29, "On Board Refueling Vapor Recovery \(ORVR\)"](#).

Is the inspection result normal?

- YES >> GO TO 19.
NO >> Repair or replace hoses and tubes.

19.CHECK RECIRCULATION LINE

Check recirculation line between fuel filler tube and fuel tank for clogging, kink, cracks, looseness and improper connection.

Is the inspection result normal?

- YES >> GO TO 20.
NO >> Repair or replace hose, tube or fuel filler tube.

20.CHECK REFUELING EVAP VAPOR CUT VALVE

Check the refueling EVAP vapor cut valve. Refer to [EC-447, "Component Inspection \(Refueling EVAP vapor cut valve\)"](#).

Is the inspection result normal?

- YES >> GO TO 21.
NO >> Replace refueling EVAP vapor cut valve with fuel tank. Refer to [FL-10, "Removal and Installation"](#).

21.CHECK FUEL LEVEL SENSOR

Check the fuel level sensor. Refer to [MWI-46, "Component Inspection"](#).

Is the inspection result normal?

P0456 EVAP CONTROL SYSTEM

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >


- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Replace fuel level sensor unit. Refer to [FL-6, "Removal and Installation"](#).

Component Inspection

INFOID:000000009020818

1. CHECK FUEL FILLER CAP

1. Turn ignition switch OFF.
2. Remove fuel filler cap.
3. Wipe clean valve housing.



4. Install fuel filler cap adapter (commercial service tool) to fuel filler cap.
5. Check valve opening pressure and vacuum.

Pressure: 15.3 - 20.0 kPa (0.156 - 0.204 kg/cm², 2.22 - 2.90 psi)

Vacuum: -6.0 to -3.3 kPa (-0.061 to -0.034 kg/cm², -0.87 to -0.48 psi)

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.


2. REPLACE FUEL FILLER CAP

Replace fuel filler cap.

CAUTION:

Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may illuminate.

>> INSPECTION END



P0460 FUEL LEVEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0460 FUEL LEVEL SENSOR

DTC Logic

INFOID:000000009020819

DTC DETECTION LOGIC

NOTE:

- If DTC P0460 is displayed with DTC UXXXX, first perform the trouble diagnosis for DTC UXXXX.
- If DTC P0460 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to [EC-351, "DTC Logic"](#).

When the vehicle is parked, naturally the fuel level in the fuel tank is stable. It means that output signal of the fuel level sensor does not change. If ECM senses sloshing signal from the sensor, fuel level sensor malfunction is detected.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P0460 | FUEL LEV SEN SLOSH (Fuel level sensor circuit noise) | Even though the vehicle is parked, a signal being varied is sent from the fuel level sensor to ECM. | <ul style="list-style-type: none">• Harness or connectors (The CAN communication line is open or shorted)• Harness or connectors (The sensor circuit is open or shorted)• Combination meter• Fuel level sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and wait maximum of 2 consecutive minutes.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-325, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020820

1. CHECK COMBINATION METER FUNCTION

Refer to [MWI-15, "CONSULT Function"](#).

Is the inspection result normal?

- YES >> CHECK INTERMITTENT INCIDENT. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Refer to [MWI-45, "Component Function Check"](#).

P0461 FUEL LEVEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0461 FUEL LEVEL SENSOR

DTC Logic

INFOID:000000009020821

DTC DETECTION LOGIC

NOTE:

- If DTC P0461 is displayed with DTC UXXXX, first perform the trouble diagnosis for DTC UXXXX.
- If DTC P0461 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to [EC-351, "DTC Logic"](#).

Driving long distances naturally affect fuel gauge level.

This diagnosis detects the fuel gauge malfunction of the gauge not moving even after a long distance has been driven.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|--|--|---|
| P0461 | FUEL LEVEL SENSOR (Fuel level sensor circuit range/ performance) | The output signal of the fuel level sensor does not change within the specified range even though the vehicle has been driven a long distance. | <ul style="list-style-type: none">• Harness or connectors (The CAN communication line is open or shorted)• Harness or connectors (The sensor circuit is open or shorted)• Combination meter• Fuel level sensor |

DTC CONFIRMATION PROCEDURE

1. PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-326, "Component Function Check"](#).

Use component function check to check the overall function of the fuel level sensor function. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Proceed to [EC-327, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020822

1. PRECONDITIONING

WARNING:

When performing following procedure, be sure to observe the handling of the fuel. Refer to [GI-24, "General Precautions"](#).

TESTING CONDITION:

Before starting component function check, preparation of draining fuel and refilling fuel is required.

Do you have CONSULT?

- YES >> GO TO 2.
- NO >> GO TO 3.

2. PERFORM COMPONENT FUNCTION CHECK

 With CONSULT

NOTE:

Start from step 10, if it is possible to confirm that the fuel cannot be drained by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) in advance.

1. Prepare a fuel container and a spare hose.
2. Release fuel pressure from fuel line, refer to [EC-135, "Work Procedure"](#).
3. Remove the fuel feed hose on the fuel level sensor unit.
4. Connect a spare fuel hose where the fuel feed hose was removed.
5. Turn ignition switch OFF and wait at least 10 seconds then turn ON.
6. Select "FUEL LEVEL SE" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
7. Check "FUEL LEVEL SE" output voltage and note it.
8. Select "FUEL PUMP RELAY" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
9. Touch "ON" and drain fuel approximately 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) and stop it.

P0461 FUEL LEVEL SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

10. Check "FUEL LEVEL SE" output voltage and note it.
11. Fill fuel into the fuel tank for 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal).
12. Check "FUEL LEVEL SE" output voltage and note it.
13. Confirm whether the voltage changes more than 0.03 V during step 7 to 10 and 10 to 12.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Proceed to [EC-327, "Diagnosis Procedure"](#).

3.PERFORM COMPONENT FUNCTION CHECK

Without CONSULT

NOTE:

Start from step 8, if it is possible to confirm that the fuel cannot be drained by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) in advance.

1. Prepare a fuel container and a spare hose.
2. Release fuel pressure from fuel line. Refer to [EC-135, "Work Procedure"](#).
3. Remove the fuel feed hose on the fuel level sensor unit.
4. Connect a spare fuel hose where the fuel feed hose was removed.
5. Turn ignition switch ON.
6. Drain fuel by 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal) from the fuel tank using proper equipment.
7. Confirm that the fuel gauge indication varies.
8. Fill fuel into the fuel tank for 30 ℓ (7-7/8 US gal, 6-5/8 Imp gal).
9. Confirm that the fuel gauge indication varies.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Proceed to [EC-327, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020823

1.CHECK COMBINATION METER FUNCTION

Refer to [MWI-15, "CONSULT Function"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Refer to [MWI-45, "Component Function Check"](#).

P0462, P0463 FUEL LEVEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0462, P0463 FUEL LEVEL SENSOR

DTC Logic

INFOID:000000009020824

DTC DETECTION LOGIC

NOTE:

- If DTC P0462 or P0463 is displayed with DTC UXXXX, first perform the trouble diagnosis for DTC UXXXX.
- If DTC P0462 or P0463 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to [EC-351, "DTC Logic"](#).

This diagnosis indicates the former, to detect open or short circuit malfunction.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P0462 | FUEL LEVEL SEN/CIRC (Fuel level sensor circuit low input) | An excessively low voltage from the sensor is sent to ECM. | <ul style="list-style-type: none">• Harness or connectors (CAN communication line is open or shorted)• Harness or connectors (Fuel level sensor circuit is open or shorted) |
| P0463 | FUEL LEVEL SEN/CIRC (Fuel level sensor circuit high input) | An excessively high voltage from the sensor is sent to ECM. | <ul style="list-style-type: none">• Combination meter• Fuel level sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 11 V and 16 V at ignition switch ON.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-328, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020825

1. CHECK COMBINATION METER FUNCTION

Refer to [MWI-15, "CONSULT Function"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Refer to [MWI-45, "Component Function Check"](#).

P0500 VSS

Description

INFOID:000000009020826

The vehicle speed signal is sent to the combination meter from the “ABS actuator and electric unit (control unit)” by CAN communication line. The combination meter then sends a signal to the ECM by CAN communication line.

DTC Logic

INFOID:000000009020827

DTC DETECTION LOGIC

NOTE:

- If DTC P0500 is displayed with DTC UXXXX, first perform the trouble diagnosis for DTC UXXXX.
- If DTC P0500 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to [EC-351, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---------------------------|---|--|
| P0500 | Vehicle speed sensor | The almost 0 km/h (0 MPH) of vehicle speed signal is sent to ECM even when vehicle is being driven. | <ul style="list-style-type: none"> • Harness or connectors (The CAN communication line is open or shorted) • Harness or connectors (The vehicle speed signal circuit is open or shorted) • Combination meter • ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

- YES >> GO TO 2.
- NO >> GO TO 5.

2.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 3.

3.CHECK VEHICLE SPEED SENSOR FUNCTION

NOTE:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

 With CONSULT

1. Start engine.
2. Read “VHCL SPEED SE” in “DATA MONITOR” mode with CONSULT. The vehicle speed on CONSULT should exceed 10 km/h (6 mph) when rotating wheels with suitable gear position.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Go to [EC-330, "Diagnosis Procedure"](#).

4.PERFORM DTC CONFIRMATION PROCEDURE

1. Select “DATA MONITOR” mode with CONSULT.
2. Warm engine up to normal operating temperature.
3. Maintain the following conditions for at least 60 consecutive seconds.

CAUTION:

Always drive vehicle at a safe speed.

< DTC/CIRCUIT DIAGNOSIS >

| | |
|---------------|---|
| ENG SPEED | 1,400 - 6,000 rpm (CVT) 1,900 - 6,000 rpm (M/T) |
| COOLAN TEMP/S | More than 70°C (158°F) |
| B/FUEL SCHDL | 6.2 - 31.8 msec (CVT) 4.5 - 31.8 msec (M/T) |
| Shift lever | Except P or N position (CVT) Except Neutral position (M/T) |
| PW/ST SIGNAL | OFF |

4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-330, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

5. PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-330, "Component Function Check"](#).

Use component function check to check the overall function of the vehicle speed signal circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-330, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020828

1. PERFORM COMPONENT FUNCTION CHECK

 **With GST**

1. Lift up drive wheels.
2. Start engine.
3. Read vehicle speed signal in Service \$01 with GST.
The vehicle speed signal on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-330, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020829

1. CHECK DTC WITH ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check DTC with ABS actuator and electric unit (control unit). Refer to [BRC-41, "DTC Index"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace.

2. CHECK DTC WITH COMBINATION METER

Check DTC with combination meter. Refer to [MWI-21, "DTC Index"](#).

>> INSPECTION END

P0506 ISC SYSTEM

Description

INFOID:000000009020830

The ECM controls the engine idle speed to a specified level through the fine adjustment of the air, which is let into the intake manifold, by operating the electric throttle control actuator. The operating of the throttle valve is varied to allow for optimum control of the engine idling speed. The crankshaft position sensor (POS) detects the actual engine speed and sends a signal to the ECM.

The ECM controls the electric throttle control actuator so that the engine speed coincides with the target value memorized in the ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warming up, deceleration, and engine load (air conditioner, power steering and cooling fan operation, etc.).

DTC Logic

INFOID:000000009020831

DTC DETECTION LOGIC

NOTE:

If DTC P0506 is displayed with other DTC, first perform the trouble diagnosis for the other DTC.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P0506 | ISC SYSTEM (Idle speed control system RPM lower than expected) | The idle speed is less than the target idle speed by 100 rpm or more. | <ul style="list-style-type: none"> • Electric throttle control actuator • Intake air leak |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

If the target idle speed is out of the specified value, perform [EC-128, "Work Procedure"](#), before conducting DTC Confirmation Procedure.

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.
- Always perform the test at a temperature above -10°C (14°F).

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and run it for at least 1 minute at idle speed.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-331, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020832

1. CHECK INTAKE AIR LEAK

1. Start engine and let it idle.
2. Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

- YES >> Discover air leak location and repair.
- NO >> Replace ECM. Refer to [EC-465, "Removal and Installation"](#).

P0507 ISC SYSTEM

Description

INFOID:000000009020833

The ECM controls the engine idle speed to a specified level through the fine adjustment of the air, which is let into the intake manifold, by operating the electric throttle control actuator. The operating of the throttle valve is varied to allow for optimum control of the engine idling speed. The crankshaft position sensor (POS) detects the actual engine speed and sends a signal to the ECM.

The ECM controls the electric throttle control actuator so that the engine speed coincides with the target value memorized in the ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warming up, deceleration, and engine load (air conditioner, power steering and cooling fan operation, etc.).

DTC Logic

INFOID:000000009020834

DTC DETECTION LOGIC

NOTE:

If DTC P0507 is displayed with other DTC, first perform the trouble diagnosis for the other DTC.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P0507 | ISC SYSTEM (Idle speed control system RPM higher than expected) | The idle speed is more than the target idle speed by 200 rpm or more. | <ul style="list-style-type: none"> • Electric throttle control actuator • Intake air leak • PCV system |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

If the target idle speed is out of the specified value, perform [EC-128, "Work Procedure"](#), before conducting DTC Confirmation Procedure.

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.
- Always perform the test at a temperature above -10°C (14°F).

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and run it for at least 1 minute at idle speed.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-332, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020835

1. CHECK PCV HOSE CONNECTION

Confirm that PCV hose is connected correctly.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace error-detected parts.

P0507 ISC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

2. CHECK INTAKE AIR LEAK

1. Start engine and let it idle.
2. Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

YES >> Discover air leak location and repair.

NO >> Replace ECM. Refer to [EC-465. "Removal and Installation"](#).

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

P050A, P050B, P050E COLD START CONTROL

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P050A, P050B, P050E COLD START CONTROL

Description

INFOID:000000009020836

ECM controls ignition timing and engine idle speed when engine is started with pre-warming up condition. This control promotes the activation of three way catalyst by heating the catalyst and reduces emissions.

DTC Logic

INFOID:000000009020837

DTC DETECTION LOGIC

NOTE:

If DTC P050A, P050B or P050E is displayed with other DTC, first perform the trouble diagnosis for other DTC.

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P050A | Cold start idle air control system performance | ECM does not control engine idle speed properly when engine is started with pre-warming up condition. | • Lack of intake air volume • Fuel injection system • ECM |
| P050B | Cold start ignition timing performance | ECM does not control ignition timing properly when engine is started with pre-warming up condition. | |
| P050E | Cold start engine exhaust temperature too low | The temperature of the catalyst inlet does not rise to the proper temperature when the engine is started with pre-warming up condition. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE-I

With CONSULT

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Select "DATA MONITOR" mode with CONSULT.
4. Check the indication of "COOLAN TEMP/S".

With GST

Follow the procedure "With CONSULT" above.

Is the value of "COOLAN TEMP/S" between 15°C (59°F) and 36°C (97°F)?

YES >> GO TO 3.

NO-1 [If it is below 15°C (59°F)]>>Warm up the engine until the value of "COOLAN TEMP/S" reaches 15°C (59°F) or more. Retry from step 1.

NO-2 [If it is above 36°C (97°F)]>>Cool engine down to less than 36°C (97°F). Retry from step 1.

3. PERFORM DTC CONFIRMATION PROCEDURE-II

With CONSULT

1. Set the select lever in N range.
2. Start the engine and warm up in idle with the value of "COOLAN TEMP/S" between 15°C (59°F) and 40°C (104°F) for more than 15 seconds.
3. Check 1st trip DTC.

With GST

Follow the procedure "With CONSULT" above.

P050A, P050B, P050E COLD START CONTROL

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Is 1st trip DTC detected?

- YES >> Go to [EC-335, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

A

Diagnosis Procedure

INFOID:000000009020838

EC

1.PERFORM IDLE AIR VOLUME LEARNING

Perform [EC-128, "Work Procedure"](#).

Is Idle Air Volume Learning carried out successfully?

- YES >> GO TO 2.
- NO >> Follow the instruction of Idle Air Volume Learning.

C

D

2.CHECK INTAKE SYSTEM

Check for the cause of intake air volume lacking. Refer to the following.

- Crushed intake air passage
- Intake air passage clogging
- Clogging of throttle body

E

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace malfunctioning part

F

3.CHECK FUEL INJECTION SYSTEM FUNCTION

Perform DTC Confirmation Procedure for DTC P0171. Refer to [EC-245, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Go to [EC-246, "Diagnosis Procedure"](#) for DTC P0171.

H

4.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC Confirmation Procedure.
See [EC-334, "DTC Logic"](#).

I

J

Is the 1st trip DTC P050A, P050B or P050E displayed again?

- YES >> GO TO 5.
- NO >> INSPECTION END

K

5.REPLACE ECM

Replace ECM. Refer to [EC-465, "Removal and Installation"](#).

L

>> INSPECTION END

M

N

O

P

P0520 EOP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0520 EOP SENSOR

DTC Logic

INFOID:000000009020839

DTC DETECTION LOGIC

NOTE:

If DTC P0520 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | Detecting condition | Possible cause |
|---------|---|--|--|
| P0520 | EOP SENSOR/SWITCH [Engine oil pressure sensor circuit] | ECM detects the following status continuously for 5 seconds or more: • A voltage signal transmitted from the engine oil pressure sensor is lower than 0.3 V. • A voltage signal transmitted from the engine oil pressure sensor is higher than 5.02 V. | <ul style="list-style-type: none"> • Harness or connectors (Engine oil pressure sensor circuit is open or shorted.) • Engine oil pressure sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. CHECK ENGINE OIL LEVEL

Check engine oil level. Refer to [LU-7, "Inspection"](#).

Is inspection result normal?

YES >> GO TO 3.

NO >> Check engine oil leak. Refer to [LU-7, "Inspection"](#).

3. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Proceed to [EC-336, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020840

1. CHECK ENGINE OIL PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect engine oil pressure sensor harness connector.
3. Turn ignition switch ON.
4. Check the voltage between engine oil pressure sensor harness connector terminals.

| Engine oil pressure sensor | | Ground | Voltage (Approx.) |
|----------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| F38 | 1 | Ground | 5 V |

Is inspection result normal?

YES >> GO TO 2

NO >> Repair or replace error-detected parts.

P0520 EOP SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK ENGINE OIL PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between engine oil pressure sensor harness connector and ECM harness connector.

| Engine oil pressure sensor | | ECM | | Continuity |
|----------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F38 | 3 | F11 | 60 | Existed |

2. Also check harness for short to ground and short to power.

Is inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3. CHECK ENGINE OIL PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between engine oil pressure sensor harness connector and ECM harness connector.

| Engine oil pressure sensor | | ECM | | Continuity |
|----------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F38 | 2 | F11 | 47 | Existed |

2. Also check harness for short to ground and short to power.

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4. CHECK ENGINE OIL PRESSURE SENSOR

Refer to [EC-337, "Component Inspection"](#).

Is inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace engine oil pressure sensor. Refer to [EM-92, "Exploded View"](#).

Component Inspection

INFOID:000000009020841

1. CHECK ENGINE OIL PRESSURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect engine oil pressure sensor harness connector.
3. Check resistance between engine oil pressure sensor connector terminals.

| Engine oil pressure sensor | | Condition | Resistance (kΩ) |
|----------------------------|---|-----------|-----------------|
| Terminal | | | |
| 1 | 2 | None | 4 – 10 |
| | 3 | | 2 – 8 |
| 2 | 1 | | 4 – 10 |
| | 3 | | 1 – 3 |
| 3 | 1 | | 2 – 8 |
| | 2 | | 1 – 3 |

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace engine oil pressure sensor. Refer to [EM-92, "Exploded View"](#).

P0524 ENGINE OIL PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0524 ENGINE OIL PRESSURE

DTC Logic

INFOID:000000009020842

DTC DETECTION LOGIC

NOTE:

If DTC P0524 is displayed with DTC P0520 or P0075, perform trouble diagnosis for DTC P0520 or P0075 first. Refer to [EC-336, "DTC Logic"](#) or [EC-177, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | Detecting condition | Possible cause |
|---------|--|--|--|
| P0524 | ENGINE OIL PRESSURE (Engine oil pressure too low) | An engine oil pressure sensor signal voltage applied to ECM remains lower than the specified value continuously for 10 seconds or more when the engine speed is 1,000 rpm or more. | <ul style="list-style-type: none">• Decrease in engine oil pressure• Decrease in engine oil level• Engine oil condition• Engine oil pressure sensor• Engine body |

DTC CONFIRMATION PROCEDURE

CAUTION:

If "Diagnosis Procedure" is unfinished, be sure to perform Step 3 and 4.

1. PRECONDITIONING-I

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is 11 V or more at idle.

>> GO TO 2.

2. PRECONDITIONING-II

Is "Diagnosis Procedure" of DTC P0524 finished?

- YES >> GO TO 5.
NO >> GO TO 3.

3. CHECK ENGINE OIL LEVEL

Check engine oil level. Refer to [LU-7, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Proceed to [EC-339, "Diagnosis Procedure"](#)

4. CHECK ENGINE OIL PRESSURE

Ⓟ WITH CONSULT

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
3. Start the engine and check that "EOP SENSOR" changes, according to engine speeds.

| Monitor item | Condition | Value (Approx.) |
|--------------|--|---|
| EOP SENSOR | <ul style="list-style-type: none">• Engine oil temperature: 80°C (176°F)• Selector lever: P or N position (CVT), Neutral position (M/T) | Engine speed: 600 rpm 1,053 mV or more |
| | <ul style="list-style-type: none">• Air conditioner switch: OFF• No load | Engine speed: 2,000 rpm 1,802 mV or more |

Ⓧ Without CONSULT

P0524 ENGINE OIL PRESSURE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Check engine oil level. Refer to [LU-7, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Proceed to [EC-339, "Diagnosis Procedure"](#)

5.PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and warm it up to normal operating temperature.
2. Maintain the following conditions for about 10 consecutive seconds.

| | |
|----------------------------|---|
| Selector lever | P or N position (CVT) Neutral position (M/T) |
| Engine coolant temperature | 70°C (158°F) or more |
| Engine speed | 1,000 rpm or more |

NOTE:

With engine speed set around 4,000 rpm, the phenomenon can be reproduced more easily.

3. Check DTC.

Is 1st trip DTC detected?

YES >> Proceed to [EC-339, "Diagnosis Procedure"](#)

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020843

1.CHECK ENGINE OIL LEVEL

1. Turn ignition switch OFF.
2. Check engine oil level. Refer to [LU-7, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2.CHECK ENGINE OIL PRESSURE

Ⓜ WITH CONSULT

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
3. Start the engine and check that "EOP SENSOR" changes, according to engine speeds.

| Monitor item | Condition | Value (Approx.) |
|--------------|--|--|
| EOP SENSOR | • Engine oil temperature: 80°C (176°F) • Selector lever: P or N position (CVT), Neutral position (M/T) • Air conditioner switch: OFF • No load | Engine speed: 600 rpm 1,053 mV or more |
| | Engine speed: 2,000 rpm 1,802 mV or more | |

ⓧ Without CONSULT

Check engine oil level. Refer to [LU-7, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check oil pressure. Refer to [LU-7, "Inspection"](#).

3.CHECK ENGINE OIL PRESSURE SENSOR

Check engine oil pressure sensor. Refer to [EC-337, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace engine oil pressure sensor. Refer to [EM-92, "Exploded View"](#).

4.CHECK ENGINE OIL LEAKAGE

Check engine oil leakage. Refer to [LU-7, "Inspection"](#).

P0524 ENGINE OIL PRESSURE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

5.CHECK CAUSE OF ENGINE OIL CONSUMPTION

Check the following item.

| Step | Inspection item | Equipment | Standard | Reference |
|------|---|--|--|-----------|
| 1 | PCV valve | EC-464, "Inspection" | | |
| 2 | Exhaust front tube | Visual | <ul style="list-style-type: none">• No blocking• No abnormal sounds | — |
| 3 | Oil pump | Visual | <ul style="list-style-type: none">• No blocking• No damage | — |
| 4 | <ul style="list-style-type: none">• Piston• Piston pin• Piston ring | <ul style="list-style-type: none">• Piston to piston pin oil clearance EM-101, "Inspection"• Piston ring side clearance EM-101, "Inspection"• Piston ring end gap EM-101, "Inspection" | | |
| 5 | Cylinder block | <ul style="list-style-type: none">• Cylinder block top surface distortion EM-101, "Inspection"• Piston to cylinder bore clearance EM-101, "Inspection" | | |

>> Repair or replace error-detected parts.

Component Inspection

INFOID:000000009020844

1.CHECK ENGINE OIL PRESSURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect engine oil pressure sensor harness connector.
3. Check the resistance between engine oil pressure sensor connector terminals.

| Engine oil pressure sensor | | Resistance (kΩ) |
|----------------------------|---|-----------------|
| + | - | |
| Terminal | | |
| 1 | 2 | 4 – 10 |
| | 3 | 2 – 8 |
| 2 | 1 | 4 – 10 |
| | 3 | 1 – 3 |
| 3 | 1 | 2 – 8 |
| | 2 | 1 – 3 |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace engine oil pressure sensor. Refer to [EM-92, "Exploded View"](#).

P059F ACTIVE GRILLE SHUTTER

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P059F ACTIVE GRILLE SHUTTER


DTC Logic

INFOID:000000009509489

DTC DETECTION LOGIC

Active grille shutter normally stops within zone (A) which is defined by zone (B) ($90^{\circ} \pm 20^{\circ}$).

If the active grille shutter stops within zone (C) stuck error is detected, and if the active grille shutter stops at position beyond zone (D) over-run error is detected.



NOTE:

If DTC P059F displayed with DTC UXXXX, P0116, P0117, P0118, P0125, P0196, P0197, P0198, P0500, P0607, or P1720 first perform the trouble diagnosis for DTC UXXXX, P0116, P0117, P0118, P0125, P0196, P0197, P0198, P0500, P0607, or P1720. Refer to [EC-86, "DTC Index"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause | |
|---------|--|--|--|--|
| P059F | ACTIVE GRILLE AIR SHUTTER A (Active grille air shutter A performance/stuck off) | ECM records the DTCs when it receives following diagnosis signals from active grille shutter actuator. | <ul style="list-style-type: none"> Harness or connectors (Active grille shutter circuit is open or shorted.) Active grille shutter | |
| | | A | | Detects the malfunction of initial position learning or operational malfunctions for specified times. |
| | | B | | <ul style="list-style-type: none"> Active grille shutter power supply voltage is lower than 7.5 V for more than 5 seconds consecutively. Active grille shutter power supply voltage is more than 17.5 V for more than 5 seconds consecutively. |
| | | C | | Detects the temperature of active grille shutter actuator is more than 155°C (311°F) for more than 600 seconds for accumulation. |
| | | D | | Detects the temperature of active grille shutter actuator is more than 155°C (311°F) for more than specified times. |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If another DTC Confirmation Procedure is conducted just before this procedure, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 11V and 16V with ignition switch ON.

With CONSULT >>GO TO 2.

Without CONSULT >>GO TO 5.

2. DTC CONFIRMATION PROCEDURE B

P059F ACTIVE GRILLE SHUTTER

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Ⓟ With CONSULT

1. Start the engine and let it idle for 5 seconds or more.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-343. "Diagnosis Procedure"](#).
NO >> GO TO 3.

3. DTC CONFIRMATION PROCEDURE A AND D

Ⓟ With CONSULT

1. Turn ignition switch OFF and wait 10 seconds or more.
2. Turn ignition switch ON.
3. Select "DATA MONITOR" mode of "ENGINE" using CONSULT.
4. Start the engine if the following conditions are met.

| | |
|----------------|--------------------|
| INT/A TEMP SE | 0°C (32°F) or more |
| COOLANT TEMP/S | 0°C (32°F) or more |

5. Select "ACTIVE GRILLE SHUTTER" in "ACTIVE TEST" of "ENGINE" using CONSULT.
6. Touch "CALIBRTN" at least 60 seconds.
7. Check 1st trip DTC.

Is 1st trip DTC is detected?

- YES >> Proceed to [EC-343. "Diagnosis Procedure"](#).
NO >> GO TO 4.

4. DTC CONFIRMATION PROCEDURE C

Ⓟ With CONSULT

1. Drive 10 minutes or more under the status that following conditions are met.

| | |
|---------------|--------------------------|
| VHCL SPEED SE | 40 km/h (25 MPH) or more |
| INT/A TEMP SE | 50°C (122°F) or less |

CAUTION:

Always drive at a safe speed.

NOTE:

Maintain the conditions for 10 minutes or more for accumulation.

2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-343. "Diagnosis Procedure"](#).
NO >> INSPECTION END

5. DTC CONFIRMATION PROCEDURE A, B AND D

1. Start the engine when the following conditions are met.

| | |
|----------------------------|--------------------|
| Intake air temperature | 0°C (32°F) or more |
| Engine coolant temperature | 0°C (32°F) or more |

2. Drive the vehicle at 10 km/h (7 MPH) or more for at least 60 seconds.
3. Check DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-343. "Diagnosis Procedure"](#).
NO >> GO TO 6.

6. DTC CONFIRMATION PROCEDURE C

1. Drive the vehicle for 10 minutes or more with the following conditions.

| | |
|------------------------|--------------------------|
| Vehicle speed | 40 km/h (25 MPH) or more |
| Intake air temperature | 50°C (122°F) or less |

P059F ACTIVE GRILLE SHUTTER

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

CAUTION:

Always drive at a safe speed.

NOTE:

Maintain the conditions for 10 minutes or more for accumulation.

2. Check DTC.

Is 1st trip DTC detected?

YES >> Proceed to [EC-343. "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009509490

1. CHECK ACTIVE GRILLE SHUTTER

1. Turn ignition switch OFF.
2. Check if any foreign objects interferes with active grille shutter.
3. Check the installation condition of active grille shutter.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the error-detected parts.

2. CHECK ACTIVE GRILLE SHUTTER POWER SUPPLY

1. Disconnect active grille shutter harness connector.
2. Check the voltage between active grille shutter harness connector and ground as follows.

| + | | - | Condition | Voltage (Approx.) |
|-----------------------|----------|--------|----------------------|-------------------|
| Active grille shutter | | | | |
| Connector | Terminal | | | |
| E303 | 4 | Ground | Ignition switch: ON | Battery voltage |
| | | | Ignition switch: OFF | 0 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 6.

3. CHECK ACTIVE GRILLE SHUTTER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check the continuity between active grille shutter harness connector and ground.

| + | | - | Continuity |
|-----------------------|----------|--------|------------|
| Active grille shutter | | | |
| Connector | Terminal | | |
| E303 | 1 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the error-detected parts.

4. CHECK ACTIVE GRILLE SHUTTER SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check the continuity between ECM harness connector and active grille shutter harness connector.

| + | | - | | Continuity |
|-----------|----------|-----------------------|----------|------------|
| ECM | | Active grille shutter | | |
| Connector | Terminal | Connector | Terminal | |
| F11 | 70 | E303 | 2 | Existed |

P059F ACTIVE GRILLE SHUTTER

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the error-detected parts.

5.CHECK ACTIVE GRILLE SHUTTER

Check active grille shutter. Refer to [EC-345, "Component Inspection \(Active Grille Shutter\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace active grille shutter. Refer to [EXT-31, "Removal and Installation"](#).

6.CHECK ACTIVE GRILLE SHUTTER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Remove active grille shutter relay.
3. Check the continuity between active grille shutter harness connector and active grille shutter relay harness connector.

| + | | - | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E303 | 4 | E72 | 3 | Existed |

4. Also check harness for short to ground.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the error-detected parts.

7.CHECK ACTIVE GRILLE SHUTTER RELAY POWER SUPPLY CIRCUIT - 1

Check the voltage between active grille shutter harness connector and ground.

| + | | - | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal | | |
| E72 | 5 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 11.

8.CHECK ACTIVE GRILLE SHUTTER RELAY SIGNAL CIRCUIT - 1

1. Check the voltage between active grille shutter harness connector and ground as follows.

| + | | - | Condition | Voltage (Approx.) |
|-----------|----------|--------|----------------------|-------------------|
| Connector | Terminal | | | |
| E72 | 2 | Ground | Ignition switch: ON | Battery voltage |
| | | | Ignition switch: OFF | 0 V |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 12.

9.CHECK ACTIVE GRILLE SHUTTER RELAY GROUND CIRCUIT

1. Turn ignition switch OFF

P059F ACTIVE GRILLE SHUTTER

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. Check the continuity between active grille shutter relay harness connector and ground.

| + | | - | Continuity |
|-----------------------------|----------|--------|------------|
| Active grille shutter relay | | | |
| Connector | Terminal | | |
| E72 | 1 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace the error-detected parts.

10.CHECK ACTIVE GRILLE SHUTTER RELAY

Check active grille shutter relay. Refer to [EC-346, "Component Inspection \(Active Grille Shutter Relay\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace active grille shutter relay.

11.CHECK ACTIVE GRILLE SHUTTER RELAY POWER SUPPLY CIRCUIT - 2

1. Check 5A fuse (No. 27).
2. Check the continuity between active grille shutter relay harness connector and fuse socket.

| + | | Fuse No. | Continuity |
|-----------------------------|----------|----------|------------|
| Active grille shutter relay | | | |
| Connector | Terminal | | |
| E72 | 5 | 27 | Existed |

3. Also check harness for short to ground.

Is the inspection result normal?

YES >> Perform trouble diagnosis for power supply circuit.

NO >> Repair or replace the error-detected parts.

12.CHECK ACTIVE GRILLE SHUTTER RELAY SIGNAL CIRCUIT - 2

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check the continuity between active grille shutter relay harness connector and IPDM E/R harness connector.

| + | | - | | Continuity |
|-----------------------------|----------|-----------|----------|------------|
| Active grille shutter relay | | IPDM E/R | | |
| Connector | Terminal | Connector | Terminal | |
| E72 | 2 | F42 | 39 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> Perform trouble diagnosis for power supply circuit.

NO >> Repair or replace the error-detected parts.

Component Inspection (Active Grille Shutter)

INFOID:000000009509491

1.CHECK ACTIVE GRILLE SHUTTER

Ⓜ With CONSULT

1. Start the engine.
2. Select "ACTIVE GRILLE SHUTTER" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
3. Touch "CALIBRTN".
4. After the calibration completes, check the operation of active grille shutter as follows.

P059F ACTIVE GRILLE SHUTTER

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| Condition | Active grille shutter |
|----------------|-----------------------|
| Select "CLOSE" | Close → Open |
| Select "OPEN" | Open → Close |

⊗ Without CONSULT

1. Turn ignition switch OFF.
2. Operate shutter by hands to close position.
3. Check the operation of active grille shutter as follows.

| Condition | Active grille shutter |
|---------------------|-----------------------|
| Ignition switch: ON | Close → Open |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace active grille shutter. Refer to [EXT-31. "Removal and Installation"](#).

Component Inspection (Active Grille Shutter Relay)

INFOID:000000009731738

1. CHECK ACTIVE GRILLE SHUTTER RELAY

1. Turn ignition switch OFF.
2. Remove active grille shutter relay.
3. Apply battery voltage to active grille shutter relay terminal, and check the continuity as follows.

| Active grille shutter relay | | Condition | Continuity |
|-----------------------------|---|--|------------|
| + | - | | |
| Terminal | | | |
| 5 | 3 | 12 V direct current supply between terminals 1 and 2 | Existed |
| | | No current supply | None |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace active grille shutter relay.

P0603 ECM POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >


[HR16DE]

P0603 ECM POWER SUPPLY

Description

INFOID:000000009020845

ECM has the memory function of the DTC memory, the air-fuel ratio feedback compensation value memory, the Idle Air Volume Learning value memory, etc. even when the ignition switch is turned OFF.



DTC Logic

INFOID:000000009020846

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P0603 | ECM BACK UP/CIRCUIT (ECM power supply circuit) | ECM back-up RAM system does not function properly. | <ul style="list-style-type: none">• Harness or connectors [ECM power supply (back up) circuit is open or shorted.]• ECM |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON wait at least 10 seconds.
2. Turn ignition switch OFF and wait at least 5 minutes
3. Turn ignition switch ON, wait at least 10 seconds.
4. Repeat step 2 and 3 for five times.
5. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-347, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020847

1. INSPECTION START

1. Erase DTC.
2. Perform DTC CONFIRMATION PROCEDURE.
See [EC-347, "DTC Logic"](#).

Is the 1st trip DTC P0603 displayed again?

- YES >> GO TO 2.
NO >> INSPECTION END

2. REPLACE ECM

P0603 ECM POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

1. Replace ECM. Refer to [EC-465, "Removal and Installation"](#).
2. Perform [EC-123, "Work Procedure"](#).

>> INSPECTION END

P0605 ECM

DTC Logic

INFOID:000000009020848

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | | Possible cause |
|---------|---------------------------|-------------------------|---|----------------|
| P0605 | Engine control module | A) | ECM calculation function is malfunctioning. | ECM |
| | | B) | ECM EEPROM system is malfunctioning. | |
| | | C) | ECM self shut-off function is malfunctioning. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A

1. Turn ignition switch ON.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-349, "Diagnosis Procedure"](#).
- NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION B

1. Turn ignition switch ON and wait at least 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
3. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-349, "Diagnosis Procedure"](#).
- NO >> GO TO 4.

4. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION C

1. Turn ignition switch ON and wait at least 1 second.
2. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
3. Repeat step 2 for 32 times.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-349, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020849

1. INSPECTION START

1. Erase DTC.
2. Perform DTC CONFIRMATION PROCEDURE.
See [EC-349, "DTC Logic"](#).

Is the 1st trip DTC P0605 displayed again?

- YES >> GO TO 2.
- NO >> INSPECTION END

2.REPLACE ECM

1. Replace ECM. Refer to [EC-465, "Removal and Installation"](#).
2. Perform [EC-123, "Work Procedure"](#).

>> INSPECTION END

P0607 ECM

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0607 ECM

DTC Logic

INFOID:000000009020850

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|----------------|
| P0607 | ECM (CAN communication bus) | When detecting error during the initial diagnosis of CAN controller of ECM. | ECM |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC.

Is DTC detected?

- YES >> Proceed to [EC-351, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020851

1. INSPECTION START

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC confirmation procedure. Refer to [EC-351, "DTC Logic"](#).
4. Check DTC.

Is the DTC P0607 displayed again?

- YES >> Replace ECM. Refer to [EC-465, "Removal and Installation"](#).
NO >> INSPECTION END

P0643 SENSOR POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P0643 SENSOR POWER SUPPLY

DTC Logic

INFOID:000000009020852

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|-----------------------------------|--|--|
| P0643 | Sensor power supply circuit short | ECM detects a voltage of power source for sensor is excessively low or high. | <ul style="list-style-type: none">• Harness or connectors (Accelerator pedal position 1 circuit is shorted.) (Throttle position sensor 1 circuit is shorted.) (Camshaft position sensor circuit is shorted.) (Exhaust valve timing control position sensor circuit is shorted.) (Engine oil pressure sensor circuit is shorted.)• Accelerator pedal position sensor• Throttle position sensor• Camshaft position sensor• Exhaust valve timing control position sensor• Engine oil pressure sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 1 second.
2. Check DTC.

Is DTC detected?

- YES >> Go to [EC-352, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020853

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check the voltage between ECM harness connector and ground.

P0643 SENSOR POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECM | | Ground | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal | | |
| F11 | 72 | Ground | 5 V |
| | 74 | | |
| | 78 | | |
| E16 | 106 | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 3.

3. CHECK SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check harness for short to power and short to ground, between the following terminals.

| ECM | | Sensor | | |
|-----------|----------|--|-----------|----------|
| Connector | Terminal | Item | Connector | Terminal |
| F11 | 72 | Throttle position sensor 1 | F7 | 2 |
| | 74 | Engine oil pressure sensor | F38 | 1 |
| | 78 | Camshaft position sensor | F21 | 1 |
| | | Exhaust valve timing control position sensor | F56 | |
| E16 | 106 | Accelerator pedal position sensor 1 | E12 | 4 |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair short to ground or short to power in harness or connectors.

4. CHECK COMPONENTS

Check the following.

- Throttle position sensor 1 (Refer to [EC-265, "Component Inspection"](#).)
- Engine oil pressure sensor (Refer to [EC-337, "Component Inspection"](#).)
- Camshaft position sensor (Refer to [EC-281, "Component Inspection"](#).)
- Exhaust valve timing control position sensor (Refer to [EC-281, "Component Inspection"](#).)
- Accelerator pedal position sensor 1 (Refer to [EC-413, "Component Inspection"](#).)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning component.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

P0850 PNP SWITCH

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

P0850 PNP SWITCH

Description

INFOID:000000009020854

When the selector lever position is Neutral position, park/neutral position (PNP) signal is ON.

DTC Logic

INFOID:000000009020855

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|------------------------------|--|---|
| P0850 | Park/neutral position signal | The park/neutral position (PNP) signal is not changed in the process of engine starting and driving. | <ul style="list-style-type: none">• Harness or connectors [The park/neutral position (PNP) signal circuit is open or shorted.]• Transmission range switch (CVT models)• Park/neutral position (PNP) switch (M/T models) |

DTC CONFIRMATION PROCEDURE

1.INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

YES >> GO TO 2.

NO >> GO TO 5.

2.PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 3.

3.CHECK PNP SIGNAL FUNCTION

With CONSULT

1. Turn ignition switch ON.
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT. Then check "P/N POSI SW" signal under the following conditions.

| Shift lever position | Known-good signal |
|---|-------------------|
| N or P position (CVT) Neutral position (M/T) | ON |
| Except above position | OFF |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Proceed to [EC-355, "Diagnosis Procedure"](#).

4.PERFORM DTC CONFIRMATION PROCEDURE

1. Select "DATA MONITOR" mode with CONSULT.
2. Start engine and warm it up to normal operating temperature.
3. Maintain the following conditions for at least 50 consecutive seconds.

CAUTION:

Always drive vehicle at a safe speed.

P0850 PNP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| | |
|---------------|----------------------------|
| ENG SPEED | 1,000 - 6,375 rpm |
| COOLAN TEMP/S | More than 65°C (149°F) |
| B/FUEL SCHDL | 2.0 - 31.9 msec |
| VHCL SPEED SE | More than 64 km/h (40 mph) |
| Shift lever | Suitable position |

4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-355, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

5.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-355, "Component Function Check"](#).

NOTE:

Use component function check the overall function of the park/neutral position (PNP) signal circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-355, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020856

1.PERFORM COMPONENT FUNCTION CHECK

1. Turn ignition switch ON.
2. Check the voltage between ECM harness connector and ground.

| ECM | | | | Condition | Voltage |
|-----------|--------------------|-----------|----------|-------------|-------------------------------|
| + | | - | | | |
| Connector | Terminal | Connector | Terminal | | |
| F11 | 69 (PNP signal) | E16 | 108 | Shift lever | P or N (CVT) Neutral (M/T) |
| | | | | | Except above |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-355, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020857

1.CHECK TRANSMISSION RANGE SWITCH (CVT) OR PARK/NEUTRAL POSITION (PNP) SWITCH (M/T) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect transmission range switch (CVT) or PNP switch (M/T) harness connector.
3. Turn ignition switch ON.
4. Check the voltage between transmission range switch (CVT) or PNP switch (M/T) harness connector and ground.

| Transmission range switch (CVT) / PNP switch (M/T) | | Ground | Voltage |
|--|----------|--------|-----------------|
| Connector | Terminal | | |
| F49 (CVT) | 7 | Ground | Battery voltage |
| F24 (M/T) | 2 | | |

Is the inspection result normal?

- YES >> GO TO 3.

P0850 PNP SWITCH

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 2.

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E7, M69 (M/T)
- Harness connectors E55, F55
- IPDM E/R harness connector E45 (CVT)
- 10 A fuse (No. 3) (M/T)
- 10 A fuse (No. 49) (CVT)
- Harness for open or short between transmission range switch (CVT) or PNP switch (M/T) and fuse

Is the inspection result normal?

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between transmission range switch (CVT) or PNP switch (M/T) harness connector and ECM harness connector.

| Transmission range switch (CVT) / PNP switch (M/T) | | ECM | | Continuity |
|--|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F49 (CVT) | 10 | F11 | 69 | Existed |
| F24 (M/T) | 3 | | | |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK TRANSMISSION RANGE SWITCH (CVT) OR PNP SWITCH (M/T)

Refer to [TM-147, "Component Inspection \(Transmission Range Switch\)"](#) (CVT) or [TM-15, "PARK/NEUTRAL POSITION \(PNP\) SWITCH : Component Inspection"](#) (M/T).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace transmission range switch (CVT) or PNP switch (M/T). Refer to [TM-252, "Removal and Installation"](#) (CVT) or [TM-24, "Removal and Installation"](#) (M/T).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

P1078 EVT CONTROL POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1078 EVT CONTROL POSITION SENSOR

DTC Logic

INFOID:000000009020858

DTC DETECTION LOGIC

NOTE:

If DTC P0340 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|---|
| P1078 | EXH TIM SEN/CIRC-B1 (Exhaust valve timing control position sensor) | An excessively high or low voltage from the sensor is sent to ECM. | <ul style="list-style-type: none"> Harness or connectors (Exhaust valve timing control position sensor circuit is open or shorted) Accumulation of debris to the signal pick-up portion of the camshaft Exhaust valve timing control position sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5 V with ignition switch ON.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for 10 seconds.
- Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-279, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020859

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace ground connection.

2. CHECK EXHAUST VALVE TIMING CONTROL POSITION SENSOR POWER SUPPLY CIRCUIT

- Disconnect exhaust valve timing control position sensor harness connector.
- Turn ignition switch ON.
- Check the voltage between exhaust valve timing control position sensor harness connector and ground.

| Exhaust valve timing control position sensor | | Ground | Voltage |
|--|----------|--------|-------------|
| Connector | Terminal | | |
| F56 | 1 | Ground | Approx. 5 V |

P1078 EVT CONTROL POSITION SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3.CHECK EXHAUST VALVE TIMING CONTROL POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connectors.
3. Check the continuity between exhaust valve timing control position sensor harness connector and ECM harness connector.

| Exhaust valve timing control position sensor | | ECM | | Continuity |
|--|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F56 | 2 | F11 | 63 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK EXHAUST VALVE TIMING CONTROL POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between exhaust valve timing control position sensor harness connector and ECM harness connector.

| Exhaust valve timing control position sensor | | ECM | | Continuity |
|--|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F56 | 3 | F11 | 48 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5.CHECK EXHAUST VALVE TIMING CONTROL POSITION SENSOR

Refer to [EC-359. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace exhaust valve timing control position sensor. Refer to [EM-48. "Exploded View"](#).

6.CHECK CAMSHAFT (EXT)


Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

Is the inspection result normal?

YES >> GO TO 7.

NO >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft. Refer to [EM-60. "Removal and Installation"](#).



7.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

P1078 EVT CONTROL POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

>> INSPECTION END

Component Inspection

INFOID:000000009020860


1. EXHAUST VALVE TIMING (EVT) CONTROL POSITION SENSOR-I

1. Turn ignition switch OFF.
2. Disconnect EVT control position sensor harness connector.
3. Loosen the fixing bolt of the sensor.
4. Remove the sensor. Refer to [EM-48. "Exploded View"](#).
5. Visually check the sensor for chipping.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace camshaft position sensor. Refer to [EM-48. "Exploded View"](#).



2. CHECK CAMSHAFT POSITION SENSOR-II

Check resistance camshaft position sensor terminals as follows.

| Terminals (Polarity) | Resistance [at 25°C (77°F)] |
|----------------------|-------------------------------|
| 1 (+) - 2 (-) | Except 0 or ∞ Ω |
| 1 (+) - 3 (-) | |
| 2 (+) - 3 (-) | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace camshaft position sensor. Refer to [EM-48. "Exploded View"](#).

P1148 CLOSED LOOP CONTROL

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1148 CLOSED LOOP CONTROL

DTC Logic

INFOID:000000009020861

DTC DETECTION LOGIC

NOTE:

DTC P1148 is displayed with DTC for A/F sensor 1.

When the DTC is detected, perform the trouble diagnosis of DTC corresponding to A/F sensor 1.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P1148 | CLOSED LOOP-B1 (Closed loop control function) | The closed loop control function does not operate even when vehicle is being driven in the specified condition. | <ul style="list-style-type: none">• Harness or connectors (A/F sensor 1 circuit is open or shorted.)• A/F sensor 1• A/F sensor 1 heater |

Diagnosis Procedure

INFOID:000000009020862

DTC P1148 is displayed with DTC for A/F sensor 1.

When the DTC is detected, perform the trouble diagnosis of DTC corresponding to A/F sensor 1.

Refer to [EC-86. "DTC Index"](#).

P117A AIR FUEL RATIO

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P117A AIR FUEL RATIO

DTC Logic

INFOID:000000009555272

DTC DETECTION LOGIC

NOTE:

If DTC P117A is displayed with other DTC, first perform the trouble diagnosis for the other DTC. Refer to [EC-86, "DTC Index"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|---|
| P117A | AIR FUEL RATIO B1 (AIR FUEL RATIO B1) | ECM detects a lean/rich air fuel ratio state in any cylinder for a specified length of time. | <ul style="list-style-type: none">• Fuel injector• Exhaust gas leaks• Incorrect fuel pressure• Mass air flow sensor• Intake air leaks• Lack of fuel• Incorrect PCV hose connection• Improper spark plug• Insufficient compression• The fuel injector circuit is open or shorted• Ignition coil• The ignition signal circuit is open or shorted |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING-1

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

NOTE:

Before performing the following procedure, confirm that battery voltage is 11 V or more at idle.

>> GO TO 2.

2. PRECONDITIONING-2

1. Turn ignition switch ON.
2. Clear the mixture ratio self-learning value. Refer to [EC-130, "Work Procedure"](#).

Will CONSULT be used?

- YES >> GO TO 3.
NO >> GO TO 6.

3. PERFORM DTC CONFIRMATION PROCEDURE-1

1. Turn ignition switch ON.
2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
3. Start engine.
4. Make sure that "COOLAN TEMP/S" indicates more than 80°C (176°F).

>> GO TO 4.

4. PERFORM DTC CONFIRMATION PROCEDURE-2

With CONSULT

1. Select "SYSTEM 1 DIAGNOSIS B B1" and "SYSTEM 1 DIAGNOSIS A B1" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
2. Drive vehicle under the following conditions for at least 5 consecutive seconds.

CAUTION:

P117A AIR FUEL RATIO

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

- Always drive vehicle at a safe speed.

| | |
|-------------------------|------------------------|
| ENG SPEED | 1,000 – 1,250rpm |
| COOLAN TEMP/S | More than 80°C (176°F) |
| B/FUEL SCHDL | 4 – 8 msec |
| Selector lever | D position |
| SYSTEM 1 DIAGNOSIS B B1 | PRSENT |

NOTE:

- Drive the vehicle at approximately 88 km/h (55MPH) allows easy diagnosis.
- Keep the accelerator pedal as possible during cruising.

3. Check "SYSTEM 1 DIAGNOSIS A B1" indication.

Is "CMPLT" displayed?

- YES >> GO TO 5.
NO >> GO TO 2.

5.PERFORM DTC CONFIRMATION PROCEDURE-3

Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-362, "Diagnosis Procedure"](#).
NO >> INSPECTION END

6.PERFORM DTC CONFIRMATION PROCEDURE-4

Without CONSULT

1. Start the engine and warm it up to normal operating temperature.
2. Drive vehicle under the following conditions for at least 5 consecutive seconds.

CAUTION:

- Always drive vehicle at a safe speed.

| | |
|-----------------------|-------------------|
| Engine speed | 1,000 – 1,250 rpm |
| Calculated load value | 26 – 46 % |
| Selector lever | D position |

NOTE:

- Drive the vehicle at approximately 88 km/h (55MPH) allows easy diagnosis.
- Keep the accelerator pedal as possible during cruising.

3. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-362, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009555273

1.CHECK FOR INTAKE AIR LEAK

1. Stop engine and check the following for connection.
 - Air duct
 - Vacuum hoses
 - PCV hose
 - Intake air passage between air duct to intake manifold
2. Start engine and let it idle.
3. Listen for an intake air leak after the mass air flow sensor.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.


2.CHECK EXHAUST GAS LEAK

P117A AIR FUEL RATIO

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Stop engine and visually check exhaust tube, three way catalyst and muffler for dents connection.
2. Start engine and let it idle.
3. Listen for an exhaust gas leak before three way catalyst (manifold).



Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace error-detected parts.

3.CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-135, "Work Procedure"](#).
2. Check fuel pressure. Refer to [EC-135, "Work Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 9.

4.CHECK MASS AIR FLOW SENSOR

With CONSULT

Check "MASS AIR FLOW" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
For specification, refer to [EC-466, "Mass Air Flow Sensor"](#).

With GST

Check mass air flow sensor signal in Service \$01 using GST.
For specification, refer to [EC-466, "Mass Air Flow Sensor"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or grounds. Refer to [EC-182, "Diagnosis Procedure"](#).

5.CHECK FUNCTION OF FUEL INJECTOR-1

With CONSULT

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
3. Check that each circuit produces a momentary engine speed drop.


Without CONSULT

1. Let engine idle.
2. Listen to each fuel injector operating sound.

Clicking noise should be heard.

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Perform trouble diagnosis for fuel injector, refer to [EC-434, "Component Function Check"](#).



6.CHECK FUNCTION OF FUEL INJECTOR-2

CAUTION:

P117A AIR FUEL RATIO

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Perform the following procedure in a place with no combustible objects and good ventilation.


1. Turn ignition switch OFF.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect all fuel injector harness connectors.
4. Remove fuel tube assembly. Refer to [EM-40, "Removal and Installation"](#).
Keep fuel hose and all fuel injectors connected to fuel tube.
5. Disconnect all ignition coil harness connectors.
6. Prepare pans or saucers under each fuel injector.
7. Crank engine for approximately 3 seconds.

- Fuel should be sprayed evenly for each fuel injector.
- Fuel must not drip from the tip of fuel injector.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace fuel injector. Refer to [EM-40, "Removal and Installation"](#).



7. CHECK FUNCTION OF IGNITION COIL-1

CAUTION:

Perform the following steps in a well-ventilated area with no combustibles.

1. Turn ignition switch OFF.
2. Remove fuel pump fuse from IPDM E/R to release fuel pressure.

NOTE:

CONSULT must not be used to release fuel pressure. It develops again during the following steps, if released by using CONSULT.

3. Start the engine.
4. After an engine stall, crank the engine two or three times to release all the fuel pressure.
5. Turn ignition switch OFF.
6. Disconnect all the harness connectors of ignition coil to prevent electric discharge from occurring in ignition coil.
7. Remove ignition coil assembly and spark plug of cylinder. Refer to [EM-47, "Removal and Installation"](#).
8. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
9. Connect spark plug and harness connector to ignition coil.
10. Allow a 13-17mm (0.52-0.66 in) spacing between spark plug and grounded metal portion as shown in the figure to fix the ignition coil with a rope or an equivalent.
11. Crank the engine for approximately 3 seconds to see if sparking occurs between spark plug and the grounded metal portion.

Spark should be generated.

CAUTION:

- The discharge voltage becomes 20 kV or higher. Therefore, always stay away from the spark plug and ignition coil at least 50 cm (19.7 in) during the inspection.
- Leaving a space of more than 17mm (0.66 in) may damage the ignition coil.

NOTE:

When the gap is less than 13 mm (0.52 in), a the spark might be generated even if the coil is malfunctioning.

Is the inspection result normal?


YES >> GO TO 8.

NO >> GO TO 10.

8. CHECK COMPRESSION PRESSURE

Check compression pressure. Refer to [EM-13, "Inspection"](#).

Is the inspection result normal?



P117A AIR FUEL RATIO

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

9. DETECT MALFUNCTIONING PART

Check fuel hoses and fuel tubes for clogging.

Is the inspection result normal?

- YES >> Replace fuel filter and fuel pump assembly. Refer to [FL-6, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

10. CHECK FUNCTION OF IGNITION COIL-2

1. Turn ignition switch OFF.
2. Disconnect spark plug and connect a non-malfunctioning spark plug.
3. Crank engine for approximately 3 seconds, and recheck whether spark is generated between the spark plug and the grounded metal portion.

Spark should be generated.

Is the inspection result normal?


- YES >> GO TO 11.
NO >> Check ignition coil, power transistor and their circuits. Refer to [EC-439, "Component Function Check"](#).

11. CHECK SPARK PLUG

Check the initial spark plug for fouling, etc.

Is the inspection result normal?

- YES >> 1. Repair or clean spark plug. Refer to [EM-21, "Removal and Installation"](#).
2. GO TO 12.
NO >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [EM-116, "Spark Plug"](#).



12. CHECK FUNCTION OF IGNITION COIL-3

1. Reconnect the initial spark plugs.
2. Crank engine for approximately 3 seconds, and recheck whether spark is generated between the spark plug and the grounded portion.

Spark should be generated.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Replace spark plug(s) with standard type one(s). For spark plug type, refer to [EM-116, "Spark Plug"](#).

P1212 TCS COMMUNICATION LINE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1212 TCS COMMUNICATION LINE

Description

INFOID:000000009020863

This CAN communication line is used to control the smooth engine operation during the TCS operation. Pulse signals are exchanged between ECM and “ABS actuator and electric unit (control unit)”.

Be sure to erase the malfunction information such as DTC not only for “ABS actuator and electric unit (control unit)” but also for ECM after TCS related repair.

DTC Logic

INFOID:000000009020864

DTC DETECTION LOGIC

NOTE:

- If DTC P1212 is displayed with DTC U1001, first perform the trouble diagnosis for DTC U1001. Refer to [EC-162, "DTC Logic"](#).
- If DTC P1212 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to [EC-351, "DTC Logic"](#).

Freeze frame data is not stored in the ECM for this self-diagnosis.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|--|
| P1212 | TCS/CIRC (TCS communication line) | ECM can not receive the information from “ABS actuator and electric unit (control unit)” continuously. | <ul style="list-style-type: none">• Harness or connectors (CAN communication line is open or shorted.)• ABS actuator and electric unit (control unit)• Dead (Weak) battery |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for at least 10 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Proceed to [EC-366, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020865

Perform the trouble diagnosis for TCS. Refer to [BRC-50, "Work Flow"](#).

NOTE:

If DTC P1212 is displayed with DTC UXXXX and/or P0607, perform the following trouble diagnosis.

- Trouble diagnosis for DTC UXXXX Refer to [EC-86, "DTC Index"](#).
- Trouble diagnosis for DTC P0607 Refer to [EC-351, "DTC Logic"](#).

P1217 ENGINE OVER TEMPERATURE

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1217 ENGINE OVER TEMPERATURE

DTC Logic

INFOID:000000009020866

DTC DETECTION LOGIC

NOTE:

- If DTC P1217 is displayed with DTC UXXXX, first perform the trouble diagnosis for DTC UXXXX.
- If DTC P1217 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to [EC-351, "DTC Logic"](#).

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|------------------------------------|--|---|
| P1217 | Engine over temperature (Overheat) | <ul style="list-style-type: none">• Cooling fan does not operate properly (Overheat).• Cooling fan system does not operate properly (Overheat).• Engine coolant was not added to the system using the proper filling method.• Engine coolant is not within the specified range. | <ul style="list-style-type: none">• Harness or connectors (The cooling fan circuit is open or shorted.)• IPDM E/R (Cooling fan low relay, high relay)• Cooling fan relay• Cooling fan motor• Radiator hose• Radiator• Radiator cap• Reservoir tank• Water pump• Thermostat |

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [CO-9, "Refilling"](#). Also, replace the engine oil. Refer to [LU-8, "Refilling"](#).

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-12, "Anti-Freeze Coolant Mixture Ratio"](#).
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

DTC CONFIRMATION PROCEDURE

1. PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-367, "Component Function Check"](#).

NOTE:

Use component function check to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to [EC-368, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009020867

1. PERFORM COMPONENT FUNCTION CHECK-I

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

P1217 ENGINE OVER TEMPERATURE

[HR16DE]


< DTC/CIRCUIT DIAGNOSIS >

Check the coolant level in the reservoir tank and radiator.

Allow engine to cool before checking coolant level.

Is the coolant level in the reservoir tank and/or radiator below the proper range?

- YES >> Go to [EC-368, "Diagnosis Procedure"](#).
- NO >> GO TO 2



2.PERFORM COMPONENT FUNCTION CHECK-II

Confirm whether customer filled the coolant or not.

Did customer fill the coolant?

- YES >> Go to [EC-368, "Diagnosis Procedure"](#).
- NO >> GO TO 3.

3.PERFORM COMPONENT FUNCTION CHECK-III

With CONSULT

1. Turn ignition switch ON.
2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT and touch "LOW" on the CONSULT screen.
3. Make sure that cooling fan operates at low speed.

Without CONSULT

1. Start engine and let it idle.
2. Turn air conditioner switch and blower fan switch ON.
3. Make sure that cooling fan operates at low speed.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Go to [EC-368, "Diagnosis Procedure"](#).

4.PERFORM COMPONENT FUNCTION CHECK-IV

With CONSULT

1. Touch "HI" on the CONSULT screen.
2. Make sure that cooling fan operates at higher speed than low speed.

Without CONSULT

1. Turn ignition switch OFF.
2. Turn air conditioner switch and blower fan switch OFF.
3. Disconnect engine coolant temperature sensor harness connector.
4. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
5. Restart engine and make sure that cooling fan operates at higher speed than low speed.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-368, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020868

1.CHECK COOLING FAN OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.
3. Make sure that cooling fan motor operate at each speed (LOW/HI).

Without CONSULT

1. Perform IPDM E/R auto active test and check cooling fan motor operation. Refer to [PCS-10, "Diagnosis Description"](#) (with I-Key), [PCS-39, "Diagnosis Description"](#) (without I-Key).
2. Make sure that cooling fan motor operate at each speed (Low/High).

P1217 ENGINE OVER TEMPERATURE

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to [EC-429, "Diagnosis Procedure"](#).

2.CHECK COOLING SYSTEM FOR LEAK-I

Check cooling system for leak. Refer to [CO-8, "Inspection"](#).

Is leakage detected?

YES >> GO TO 3.

NO >> GO TO 4.

3.CHECK COOLING SYSTEM FOR LEAK-II

Check the following for leak.

- Hose (Refer to [CO-8, "Inspection"](#).)
- Radiator (Refer to [CO-12, "RADIATOR : Inspection"](#).)
- Water pump (Refer to [CO-19, "Removal and Installation"](#).)

>> Repair or replace malfunctioning part.

4.CHECK RADIATOR CAP

Check radiator cap. Refer to [CO-12, "RADIATOR CAP : Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace radiator cap. Refer to [CO-14, "Exploded View"](#).

5.CHECK THERMOSTAT

Check thermostat. Refer to [CO-21, "Removal and Installation"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace thermostat. Refer to [CO-21, "Removal and Installation"](#).

6.CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-199, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace engine coolant temperature sensor. Refer to [CO-24, "Exploded View"](#).

7.OVERHEATING CAUSE ANALYSIS

If the cause cannot be isolated, check [CO-6, "Troubleshooting Chart"](#).

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

P1225 TP SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

P1225 TP SENSOR

DTC Logic

INFOID:000000009020869

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P1225 | Closed throttle position learning performance | Closed throttle position learning value is excessively low. | Electric throttle control actuator (TP sensor 1 and 2) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-370, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure


INFOID:000000009020870

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch OFF.
2. Remove the intake air duct. Refer to [EM-26, "Removal and Installation"](#).
3. Check if foreign matter is caught between the throttle valve and the housing.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Remove the foreign matter and clean the electric throttle control actuator inside, and then perform throttle valve closed position learning. Refer to [EC-127, "Work Procedure"](#).



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-26, "Removal and Installation"](#).

>> INSPECTION END

P1226 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1226 TP SENSOR

DTC Logic

INFOID:000000009020871

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|--|--|
| P1226 | Closed throttle position learning performance | Closed throttle position learning is not performed successfully, repeatedly. | Electric throttle control actuator (TP sensor 1 and 2) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Repeat steps 2 and 3 for 32 times.
5. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-371, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure


INFOID:000000009020872

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch OFF.
2. Remove the intake air duct. Refer to [EM-26, "Removal and Installation"](#).
3. Check if foreign matter is caught between the throttle valve and the housing.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Remove the foreign matter and clean the electric throttle control actuator inside, and then perform throttle valve closed position learning. Refer to [EC-127, "Work Procedure"](#).



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-26, "Removal and Installation"](#).

>> INSPECTION END

P1550 BATTERY CURRENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1550 BATTERY CURRENT SENSOR

DTC Logic

INFOID:000000009429297

DTC DETECTION LOGIC

NOTE:

If DTC P1550 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-372, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|--|---|
| P1550 | Battery current sensor circuit range/performance | The output voltage of the battery current sensor remains within the specified range while engine is running. | <ul style="list-style-type: none">• Harness or connectors (The sensor circuit is open or shorted.)• Battery current sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and wait at least 10 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-372, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009429298

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK BATTERY CURRENT SENSOR POWER SUPPLY CIRCUIT

1. Disconnect battery current sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between battery current sensor harness connector and ground.

| Battery current sensor | | Ground | Voltage |
|------------------------|----------|--------|------------|
| Connector | Terminal | | |
| F9 | 1 | Ground | Approx. 5V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

3. CHECK BATTERY CURRENT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between battery current sensor harness connector and ECM harness connector.

P1550 BATTERY CURRENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| Battery current sensor | | ECM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F9 | 3 | F11 | 68 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

4.CHECK BATTERY CURRENT SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between battery current sensor harness connector and ECM harness connector.

| Battery current sensor | | ECM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F9 | 4 | F11 | 58 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

5.CHECK BATTERY CURRENT SENSOR

Refer to [EC-373, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace battery negative cable assembly.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).


>> INSPECTION END

Component Inspection

INFOID:000000009429299

1.CHECK BATTERY CURRENT SENSOR

1. Reconnect harness connectors disconnected.
2. Disconnect battery negative cable.
3. Install jumper cable between battery negative terminal and body ground.
4. Turn ignition switch ON.
5. Check the voltage between ECM harness connector and ground.



| ECM | | Ground | Voltage |
|-----------|---------------------------------------|--------|--------------|
| Connector | Terminal | | |
| F11 | 58 (Battery current sensor signal) | Ground | Approx. 2.5V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace battery negative cable assembly.

P1551, P1552 BATTERY CURRENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1551, P1552 BATTERY CURRENT SENSOR

DTC Logic

INFOID:000000009429301

DTC DETECTION LOGIC

NOTE:

If DTC P1551 or P1552 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-374, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P1551 | Battery current sensor circuit low input | An excessively low voltage from the sensor is sent to ECM. | • Harness or connectors (The sensor circuit is open or shorted.) • Battery current sensor |
| P1552 | Battery current sensor circuit high input | An excessively high voltage from the sensor is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V with ignition switch ON

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON wait at least 10 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-374, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009429302

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK BATTERY CURRENT SENSOR POWER SUPPLY CIRCUIT

1. Disconnect battery current sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between battery current sensor harness connector and ground.

| Battery current sensor | | Ground | Voltage |
|------------------------|----------|--------|------------|
| Connector | Terminal | | |
| F9 | 1 | Ground | Approx. 5V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

3. CHECK BATTERY CURRENT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.

P1551, P1552 BATTERY CURRENT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect ECM harness connector.
3. Check the continuity between battery current sensor harness connector and ECM harness connector.

| Battery current sensor | | ECM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F9 | 3 | F11 | 68 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

4.CHECK BATTERY CURRENT SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between battery current sensor harness connector and ECM harness connector.

| Battery current sensor | | ECM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F9 | 4 | F11 | 58 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

5.CHECK BATTERY CURRENT SENSOR

Refer to [EC-375, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace battery negative cable assembly.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009429303

1.CHECK BATTERY CURRENT SENSOR


1. Reconnect harness connectors disconnected.
2. Disconnect battery negative cable.
3. Install jumper cable between battery negative terminal and body ground.
4. Turn ignition switch ON.
5. Check the voltage between ECM harness connector and ground.

| ECM | | Ground | Voltage |
|-----------|---------------------------------------|--------|--------------|
| Connector | Terminal | | |
| F11 | 58 (Battery current sensor signal) | Ground | Approx. 2.5V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace battery negative cable assembly.



P1553 BATTERY CURRENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1553 BATTERY CURRENT SENSOR

DTC Logic

INFOID:000000009429305

DTC DETECTION LOGIC

NOTE:

If DTC P1553 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-376, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|------------------------------------|--|---|
| P1553 | Battery current sensor performance | The signal voltage transmitted from the sensor to ECM is higher than the amount of the maximum power generation. | <ul style="list-style-type: none">• Harness or connectors (The sensor circuit is open or shorted.)• Battery current sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and wait at least 10 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-376, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009429306

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK BATTERY CURRENT SENSOR POWER SUPPLY CIRCUIT

1. Disconnect battery current sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between battery current sensor harness connector and ground.

| Battery current sensor | | Ground | Voltage |
|------------------------|----------|--------|------------|
| Connector | Terminal | | |
| F9 | 1 | Ground | Approx. 5V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

3. CHECK BATTERY CURRENT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between battery current sensor harness connector and ECM harness connector.

P1553 BATTERY CURRENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| Battery current sensor | | ECM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F9 | 3 | F11 | 68 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

4.CHECK BATTERY CURRENT SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between battery current sensor harness connector and ECM harness connector.

| Battery current sensor | | ECM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F9 | 4 | F11 | 58 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

5.CHECK BATTERY CURRENT SENSOR

Refer to [EC-377, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace battery negative cable assembly.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009429307

1.CHECK BATTERY CURRENT SENSOR


1. Reconnect harness connectors disconnected.
2. Disconnect battery negative cable.
3. Install jumper cable between battery negative terminal and body ground.
4. Turn ignition switch ON.
5. Check the voltage between ECM harness connector and ground.

| ECM | | Ground | Voltage |
|-----------|---------------------------------------|--------|--------------|
| Connector | Terminal | | |
| F11 | 58 (Battery current sensor signal) | Ground | Approx. 2.5V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace battery negative cable assembly.



JPBIA3287ZZ

P1554 BATTERY CURRENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1554 BATTERY CURRENT SENSOR

DTC Logic

INFOID:000000009429309

DTC DETECTION LOGIC

NOTE:

If DTC P1554 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-378, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|------------------------------------|--|--|
| P1554 | Battery current sensor performance | The output voltage of the battery current sensor is lower than the specified value while the battery voltage is high enough. | <ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Battery current sensor |

DTC CONFIRMATION PROCEDURE

1.PERFORM COMPONENT FUNCTION CHECK

Perform component function check. Refer to [EC-378, "Component Function Check"](#).

NOTE:

Use component function check to check the overall function of the battery current sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to [EC-379, "Diagnosis Procedure"](#).

Component Function Check

INFOID:000000009429310

1.PRECONDITIONING

TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 12.8V at idle.
- Before performing the following procedure, confirm that all load switches and A/C switch are turned OFF.

>> GO TO 2.

2.PERFORM COMPONENT FUNCTION CHECK

Ⓜ With CONSULT

1. Start engine and let it idle.
2. Select "BAT CUR SEN" in "DATA MONITOR" mode with CONSULT.
3. Check "BAT CUR SEN" indication for 10 seconds.
"BAT CUR SEN" should be above 2,300mV at least once.

ⓧ Without CONSULT

1. Start engine and let it idle.
2. Check the voltage between ECM harness connector and ground.

| ECM | | Ground | Voltage |
|-----------|---------------------------------------|--------|--------------------------|
| Connector | Terminal | | |
| F11 | 58 (Battery current sensor signal) | Ground | Above 2.3V at least once |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to [EC-379, "Diagnosis Procedure"](#).

P1554 BATTERY CURRENT SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

INFOID:000000009429311

Diagnosis Procedure

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44. "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK BATTERY CURRENT SENSOR POWER SUPPLY CIRCUIT

1. Disconnect battery current sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between battery current sensor harness connector and ground.

| Battery current sensor | | Ground | Voltage |
|------------------------|----------|--------|------------|
| Connector | Terminal | | |
| F9 | 1 | Ground | Approx. 5V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

3. CHECK BATTERY CURRENT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between battery current sensor harness connector and ECM harness connector.

| Battery current sensor | | ECM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F9 | 3 | F11 | 68 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

4. CHECK BATTERY CURRENT SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between battery current sensor harness connector and ECM harness connector.

| Battery current sensor | | ECM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F9 | 4 | F11 | 58 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair open circuit or sort to ground or short to power in harness or connectors.

5. CHECK BATTERY CURRENT SENSOR

Refer to [EC-380. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace battery negative cable assembly.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

P1554 BATTERY CURRENT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

>> INSPECTION END


Component Inspection

INFOID:000000009429312

1. CHECK BATTERY CURRENT SENSOR

1. Reconnect harness connectors disconnected.
2. Disconnect battery negative cable.
3. Install jumper cable between battery negative terminal and body ground.
4. Turn ignition switch ON.
5. Check the voltage between ECM harness connector and ground.

| ECM | | Ground | Voltage |
|-----------|---------------------------------------|--------|--------------|
| Connector | Terminal | | |
| F11 | 58 (Battery current sensor signal) | Ground | Approx. 2.5V |



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace battery negative cable assembly.

P1564 ASCD STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1564 ASCD STEERING SWITCH

DTC Logic

INFOID:000000009020873

DTC DETECTION LOGIC

NOTE:

If DTC P1564 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-349, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|--|---|
| P1564 | ASCD SW (ASCD steering switch) | <ul style="list-style-type: none">An excessively high voltage signal from the ASCD steering switch is sent to ECM.ECM detects that input signal from the ASCD steering switch is out of the specified range.ECM detects that the ASCD steering switch is stuck ON. | <ul style="list-style-type: none">Harness or connectors (ASCD steering switch circuit is open or shorted.)ASCD steering switchECM |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Wait at least 10 seconds.
- Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
- Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
- Press ACCEL/RES switch for at least 10 seconds, then release it and wait at least 10 seconds.
- Press COAST/SET switch for at least 10 seconds, then release it and wait at least 10 seconds.
- Check DTC.

Is DTC detected?

- YES >> Proceed to [EC-381, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020874

1. CHECK ASCD STEERING SWITCH CIRCUIT

 With CONSULT

- Turn ignition switch ON.
- Select "MAIN SW", "CANCEL SW", "RESUME/ACC SW" and "SET SW" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
- Check each item indication as per the following conditions.

| Monitor item | Condition | Indication | |
|---------------|------------------|------------|-----|
| MAIN SW | MAIN switch | Pressed | ON |
| | | Released | OFF |
| CANCEL SW | CANCEL switch | Pressed | ON |
| | | Released | OFF |
| RESUME/ACC SW | ACCEL/RES switch | Pressed | ON |
| | | Released | OFF |

P1564 ASCD STEERING SWITCH

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| Monitor item | Condition | Indication |
|--------------|-----------------------------|------------|
| SET SW | COAST/SET switch Pressed | ON |
| | Released | OFF |

⊗ Without CONSULT

1. Turn ignition switch ON.
2. Check the voltage between ECM harness connector terminals.

| ECM | | | Condition | Voltage (Approx.) |
|-----------|----------|----|--------------------------------------|-------------------|
| Connector | + | - | | |
| | Terminal | | | |
| E16 | 94 | 95 | MAIN switch: Pressed | 0 V |
| | | | CANCEL switch: Pressed | 1 V |
| | | | COAST/SET switch: Pressed | 2 V |
| | | | ACCEL/RES switch: Pressed | 3 V |
| | | | All ASCD steering switches: Released | 4 V |

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
 NO >> GO TO 2.

2.CHECK ASCD STEERING SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect combination switch (spiral cable) harness connector.
4. Check the continuity between combination switch (spiral cable) and ECM harness connector.

| Combination switch (Spiral cable) | | ECM | | Continuity |
|-----------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M30 | 32 | E16 | 95 | Existed |

5. Also check harness for short to ground and to power.

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace error-detected parts.

3.CHECK ASCD STEERING SWITCH INPUT SIGNAL CIRCUIT

1. Check the continuity between ECM harness connector and combination switch.

| Combination switch (Spiral cable) | | ECM | | Continuity |
|-----------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M30 | 25 | E16 | 94 | Existed |

2. Also check harness for short to ground and to power.

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace error-detected parts.

4.CHECK ASCD STEERING SWITCH

Refer to [EC-383, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
 NO >> Replace ASCD steering switch. Refer to [ST-8, "Removal and Installation"](#).

P1564 ASCD STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Component Inspection

INFOID:000000009020875

1. CHECK ASCD STEERING SWITCH

1. Disconnect combination switch (spiral cable) harness connector.
2. Check the resistance between combination switch harness connector terminals as per the following conditions.

| Combination switch (Spiral cable) | | | Condition | Resistance (Approx.) |
|--------------------------------------|-----------|----|--------------------------------------|-------------------------|
| Connector | + | - | | |
| | Terminals | | | |
| M88 | 13 | 16 | MAIN switch: Pressed | 0 Ω |
| | | | CANCEL switch: Pressed | 250 Ω |
| | | | COAST/SET switch: Pressed | 660 Ω |
| | | | ACCEL/RES switch: Pressed | 1,480 Ω |
| | | | All ASCD steering switches: Released | 4,000 Ω |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ASCD steering switch. Refer to [ST-8. "Removal and Installation"](#).

P1572 ASCD BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1572 ASCD BRAKE SWITCH

DTC Logic

INFOID:000000009020876

DTC DETECTION LOGIC

NOTE:

- If DTC P1572 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-349, "DTC Logic"](#).
- This self-diagnosis has the one trip detection logic. When malfunction A is detected, DTC is not stored in ECM memory. And in that case, 1st trip DTC and 1st trip freeze frame data are displayed. 1st trip DTC is erased when ignition switch OFF. And even when malfunction A is detected in two consecutive trips, DTC is not stored in ECM memory.

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | | Possible cause |
|---------|---|-------------------------|--|--|
| P1572 | ASCD BRAKE SW (ASCD brake switch) | A) | When the vehicle speed is above 30 km/h (19 MPH), ON signals from the stop lamp switch and the ASCD brake switch are sent to the ECM at the same time. | <ul style="list-style-type: none">• Harness or connectors (Stop lamp switch circuit is shorted.) (ASCD brake switch circuit is shorted.)• Stop lamp switch• ASCD brake switch• Incorrect stop lamp switch installation• Incorrect ASCD brake switch installation• ECM |
| | | B) | ASCD brake switch signal is not sent to ECM for extremely long time while the vehicle is driving. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

NOTE:

Procedure for malfunction B is not described here. It takes extremely long time to complete procedure for malfunction B. By performing procedure for malfunction A, the incident that causes malfunction B can be detected.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A

1. Start engine.
2. Press MAIN switch and make sure that CRUISE indicator is displayed in combination meter.
3. Drive the vehicle for at least 5 consecutive seconds as per the following conditions.

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

| | |
|----------------|----------------------------|
| Vehicle speed | More than 30 km/h (19 mph) |
| Selector lever | Suitable position |

4. Check DTC.

Is DTC detected?

- YES >> Proceed to [EC-389, "Diagnosis Procedure"](#).
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION B

1. Drive the vehicle for at least 5 consecutive seconds as per the following conditions.

CAUTION:

P1572 ASCD BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Always drive vehicle at a safe speed.

NOTE:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

| | |
|------------------|--|
| Vehicle speed | More than 30 km/h (19 mph) |
| Selector lever | Suitable position |
| Driving location | Depress the brake pedal for more than five seconds so as not to come off from the above-mentioned vehicle speed. |

2. Check DTC.

Is DTC detected?

- YES >> Proceed to [EC-389, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020877

1.CHECK OVERALL FUNCTION-I

With CONSULT

1. Turn ignition switch ON.
2. Select "BRAKE SW1" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
3. Check "BRAKE SW1" indication as per the following conditions.

| Monitor item | Condition | | Indication |
|--------------|-------------|--------------------|------------|
| BRAKE SW1 | Brake pedal | Slightly depressed | OFF |
| | | Fully released | ON |

Without CONSULT

1. Turn ignition switch ON.
2. Check the voltage between ECM harness connector terminals as per the following.

| ECM | | | Condition | Voltage (Approx.) |
|-----------|----------|-----|--------------------|-------------------|
| Connector | + | - | | |
| | Terminal | | | |
| E16 | 100 | 108 | Slightly depressed | 0 V |
| | | | Fully released | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

2.CHECK OVERALL FUNCTION-II

With CONSULT

Select "BRAKE SW2" and check indication as per the following conditions.

| Monitor item | Condition | | Indication |
|--------------|-------------|--------------------|------------|
| BRAKE SW2 | Brake pedal | Slightly depressed | ON |
| | | Fully released | OFF |

Without CONSULT

Check the voltage between ECM harness connector terminals as per the following conditions.

P1572 ASCD BRAKE SWITCH

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| ECM | | | Condition | Voltage (Approx.) | |
|-----------|----------|-----|-------------|--------------------|-----------------|
| Connector | + | - | | | |
| | Terminal | | | | |
| E16 | 99 | 108 | Brake pedal | Slightly depressed | Battery voltage |
| | | | | Fully released | 0 V |

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> GO TO 6.

3. CHECK ASCD BRAKE SWITCH POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.
4. Check the voltage between ASCD brake switch harness connector and ground.

| ASCD brake switch | | Ground | Voltage |
|-------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Perform the trouble diagnosis for power supply circuit.

4. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between ASCD brake switch harness connector and ECM harness connector.

| ASCD brake switch | | ECM | | Continuity |
|-------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 2 | E16 | 100 | Existed |

4. Also check harness for short to ground and to power.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace error-detected parts.

5. CHECK ASCD BRAKE SWITCH

Check the ASCD brake switch. Refer to [EC-426, "Component Inspection \(ASCD Brake Switch\)"](#)

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Replace ASCD brake switch. Refer to [BR-19, "Exploded View"](#).

6. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check the voltage between stop lamp switch harness connector and ground.

| Stop lamp switch | | Ground | Voltage |
|------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| E13 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Perform the trouble diagnosis for power supply circuit.

P1572 ASCD BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

7. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check the continuity between stop lamp switch harness connector and ECM harness connector.

| Stop lamp switch | | ECM | | Continuity |
|------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E13 | 2 | E16 | 99 | Existed |

3. Also check harness for short to ground and to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace error-detected parts.

8. CHECK STOP LAMP SWITCH

Check the stop lamp switch. Refer to [EC-387, "Component Inspection \(Stop Lamp Switch\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace stop lamp switch. Refer to [BR-19, "Exploded View"](#).

Component Inspection (ASCD Brake Switch)

INFOID:000000009020878

1. CHECK ASCD BRAKE SWITCH-I

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Check the continuity between ASCD brake switch terminals as per the following conditions.

| ASCD brake switch | | Condition | Continuity | |
|-------------------|---|-------------|--------------------|-------------|
| Terminals | | | | |
| 1 | 2 | Brake pedal | Fully released | Existed |
| | | | Slightly depressed | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK ASCD BRAKE SWITCH-II

1. Adjust ASCD brake switch installation. Refer to [BR-8, "Inspection and Adjustment"](#).
2. Check the continuity between ASCD brake switch terminals as per the following conditions.

| ASCD brake switch | | Condition | Continuity | |
|-------------------|---|-------------|--------------------|-------------|
| Terminals | | | | |
| 1 | 2 | Brake pedal | Fully released | Existed |
| | | | Slightly depressed | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ASCD brake switch. Refer to [BR-19, "Exploded View"](#).

Component Inspection (Stop Lamp Switch)

INFOID:000000009020879

1. CHECK STOP LAMP SWITCH-I

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check the continuity between stop lamp switch terminals as per the following conditions.

P1572 ASCD BRAKE SWITCH

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| Stop lamp switch | | Condition | Continuity | |
|------------------|---|-------------|--------------------|-------------|
| Terminals | | | | |
| 1 | 2 | Brake pedal | Fully released | Not existed |
| | | | Slightly depressed | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK STOP LAMP SWITCH-II

1. Adjust stop lamp switch installation. Refer to [BR-20, "Inspection and Adjustment"](#).
2. Check the continuity between stop lamp switch terminals as per the following conditions.

| Stop lamp switch | | Condition | Continuity | |
|------------------|---|-------------|--------------------|-------------|
| Terminals | | | | |
| 1 | 2 | Brake pedal | Fully released | Not existed |
| | | | Slightly depressed | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch. Refer to [BR-19, "Exploded View"](#).

P1574 ASCD VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1574 ASCD VEHICLE SPEED SENSOR

Description

INFOID:000000009020880

The ECM receives two vehicle speed sensor signals via CAN communication line. One is sent from combination meter, and the other is from TCM (Transmission control module). The ECM uses these signals for ASCD control. Refer to [EC-45, "AUTOMATIC SPEED CONTROL DEVICE \(ASCD\) : System Description"](#) for ASCD functions.

DTC Logic

INFOID:000000009020881

DTC DETECTION LOGIC

NOTE:

- If DTC P1574 is displayed with DTC U1001, first perform the trouble diagnosis for DTC U1001. Refer to [EC-162, "DTC Logic"](#).
- If DTC P1574 is displayed with DTC P0500, first perform the trouble diagnosis for DTC P0500. Refer to [EC-329, "DTC Logic"](#).
- If DTC P1574 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-349, "DTC Logic"](#).
- If DTC P1574 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to [EC-351, "DTC Logic"](#).

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible cause |
|---------|---|---|--|
| P1574 | ASCD VHL SPD SEN (ASCD vehicle speed sensor) | ECM detects a difference between two vehicle speed signals is out of the specified range. | <ul style="list-style-type: none">• Harness or connectors (CAN communication line is open or shorted.)• ABS actuator and electric unit (control unit)• TCM• ECM |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine.
2. Drive the vehicle at more than 40 km/h (25 MPH).

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

This procedure may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

3. Check DTC.

Is DTC detected?

- YES >> Proceed to [EC-389, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020882

1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [TM-93, "CONSULT Function"](#).

Is DTC detected?

P1574 ASCD VEHICLE SPEED SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 2.

YES >> Perform trouble shooting relevant to DTC indicated.

2.CHECK DTC WITH “ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)”

Check DTC with ABS actuator and electric unit (control unit). Refer to [BRC-30. "CONSULT Function \(ABS\)".](#)

Is DTC detected?

NO >> INSPECTION END

YES >> Perform trouble shooting relevant to DTC indicated.

P1715 INPUT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1715 INPUT SPEED SENSOR

Description

INFOID:000000009020883

ECM receives input speed sensor signal from TCM via the CAN communication line. ECM uses this signal for engine control.

DTC Logic

INFOID:000000009020884

DTC DETECTION LOGIC

NOTE:

- If DTC P1715 is displayed with DTC UXXXX, first perform the trouble diagnosis for DTC UXXXX.
- If DTC P1715 is displayed with DTC P0335, first perform the trouble diagnosis for DTC P0335. Refer to [EC-275, "DTC Logic"](#).
- If DTC P1715 is displayed with DTC P0340, first perform the trouble diagnosis for DTC P0340. Refer to [EC-279, "DTC Logic"](#).
- If DTC P1715 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-349, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---------------------------------|--|---|
| P1715 | Input speed sensor (TCM output) | Input speed sensor signal is different from the theoretical value calculated by ECM from output speed sensor signal and engine rpm signal. | <ul style="list-style-type: none">• Harness or connectors (The CAN communication line is open or shorted)• Harness or connectors (Input speed sensor circuit is open or shorted)• TCM |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and drive the vehicle at more than 50 km/h (31 MPH) for at least 5 seconds.

CAUTION:

Always drive vehicle at a safe speed.

2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >> Go to [EC-391, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020885

1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [TM-112, "DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble shooting relevant to DTC indicated.

2. REPLACE TCM

Replace TCM. Refer to [TM-237, "Removal and Installation"](#).

P1715 INPUT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

>> INSPECTION END

P1720 VSS

Description

INFOID:000000009020886

ECM receives two vehicle speed signals via the CAN communication line. One is sent from “ABS actuator and electric unit (control unit)” via combination meter, and the other is from TCM (Transmission control module). ECM uses these signals for engine control.

DTC Logic

INFOID:000000009020887

DTC DETECTION LOGIC

NOTE:

- If DTC P1720 is displayed with DTC UXXXX, first perform the trouble diagnosis for DTC UXXXX.
- If DTC P1720 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-349, "DTC Logic"](#).
- If DTC P1720 is displayed with DTC P0607, first perform the trouble diagnosis for DTC P0607. Refer to [EC-351, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|-----------------------------------|---|--|
| P1720 | Vehicle speed sensor (TCM output) | The difference between two vehicle speed signals is out of the specified range. | <ul style="list-style-type: none"> • Harness or connectors (Secondary speed sensor circuit is open or shorted.) (Wheel sensor circuit is open or shorted.) • TCM • Secondary speed sensor • ABS actuator and electric unit (control unit) • Wheel sensor • Combination meter |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine.
2. Drive vehicle at a speed of 20 km/h (12 MPH) or more for at least 5 seconds without depressing the brake pedal.
3. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-393, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020888

1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [TM-112, "DTC Index"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Perform trouble shooting relevant to DTC indicated.

2. CHECK DTC WITH “ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)”

Check DTC with “ABS actuator and electric unit (control unit)”. Refer to [BRC-41, "DTC Index"](#).

Is the inspection result normal?

P1720 VSS

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Perform trouble shooting relevant to DTC indicated.

3.CHECK COMBINATION METER FUNCTION

Check combination meter function. Refer to [MWI-21. "DTC Index"](#).

>> INSPECTION END

P1805 BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P1805 BRAKE SWITCH

DTC Logic

INFOID:000000009020889

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---------------------------|--|--|
| P1805 | Brake switch | A brake switch signal is not sent to ECM for extremely long time while the vehicle is driving. | <ul style="list-style-type: none"> • Harness or connectors (Stop lamp switch circuit is open or shorted.) • Stop lamp switch |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase DTC.
4. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-395. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020890

1. CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Check the stop lamp when depressing and releasing the brake pedal.

| Brake pedal | Stop lamp |
|--------------------|-----------------|
| Fully released | Not illuminated |
| Slightly depressed | Illuminated |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 2.

2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check the voltage between stop lamp switch harness connector and ground.

| Stop lamp switch | | Ground | Voltage |
|------------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| E57 (M/T) E13 (CVT) | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- 10 A fuse (No. 30)
- Harness for open or short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

P1805 BRAKE SWITCH

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect stop lamp switch harness connector.
2. Disconnect ECM harness connector.
3. Check the continuity between ECM harness connector and stop lamp switch harness connector.

| ECM | | Stop lamp switch | | Continuity |
|-----------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E16 | 99 | E57 (M/T) E13 (CVT) | 2 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK STOP LAMP SWITCH

Refer to [EC-396, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace brake pedal assembly. Refer to [BR-19, "Removal and Installation"](#).

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020891

1. CHECK STOP LAMP SWITCH-I

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check the continuity between stop lamp switch terminals under the following conditions.

| Terminals | Condition | | Continuity |
|-----------|-------------|--------------------|-------------|
| 1 and 2 | Brake pedal | Fully released | Not existed |
| | | Slightly depressed | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK STOP LAMP SWITCH-II

1. Adjust stop lamp switch installation. Refer to [BR-20, "Inspection and Adjustment"](#).
2. Check the continuity between stop lamp switch terminals under the following conditions.

| Terminals | Condition | | Continuity |
|-----------|-------------|--------------------|-------------|
| 1 and 2 | Brake pedal | Fully released | Not existed |
| | | Slightly depressed | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace brake pedal assembly. Refer to [BR-19, "Removal and Installation"](#).

P2096, P2097 A/F SENSOR 1

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2096, P2097 A/F SENSOR 1

DTC Logic

INFOID:000000009445313

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition | Possible Cause |
|---------|---|--|--|
| P2096 | POST CAT FUEL TRIM SYS B1 (Post catalyst fuel trim system too lean bank 1) | The output voltage computed by ECM from the A/F sensor 1 signal is shifts to the lean side for a specified period. | <ul style="list-style-type: none">• A/F sensor 1• A/F sensor 1 heater• Heated oxygen sensor 2 |
| P2097 | POST CAT FUEL TRIM SYS B1 (Post catalyst fuel trim system too rich bank 1) | The A/F signal computed by ECM from the A/F sensor 1 signal is shifts to the rich side for a specified period. | <ul style="list-style-type: none">• Fuel pressure• Fuel injector• Intake air leaks• Exhaust gas leaks |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Clear the mixture ratio self-learning value. Refer to [EC-130, "Work Procedure"](#).
2. Turn ignition switch OFF and wait at least 10 seconds.
3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for 1 minute under no load.
4. Let engine idle for 1 minute.
5. Keep engine speed between 2,500 and 3,000 rpm for 20 minutes.
6. Check 1st trip DTC.

Is 1st trip DTC detected?

- YES >> Go to [EC-397, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009445314

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. RETIGHTEN A/F SENSOR 1 AND HEATED OXYGEN SENSOR 2

Loosen and retighten the A/F sensor 1 and heated oxygen sensor 2. Refer to [EM-31, "Removal and Installation"](#).

>> GO TO 3.

3. CHECK FOR EXHAUST GAS LEAK

1. Start engine and run it at idle.

P2096, P2097 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. Listen for an exhaust gas leak before the three way catalyst 2.

Is exhaust gas detected?

- YES >> Repair or replace.
- NO >> GO TO 4.

4.CHECK FOR INTAKE AIR LEAK

1. Start engine and run it at idle.
2. Listen for an intake air leak after the mass air flow sensor.

Is intake air leak detected?

- YES >> Repair or replace.
- NO >> GO TO 5.

5.CLEAR THE MIXTURE RATIO SELF-LEARNING VALUE

1. Clear the mixture ratio self-learning value. Refer to [EC-130. "Work Procedure"](#).
2. Run engine for at least 10 minutes at idle speed.

Is the 1st trip DTC P0171 or P0172 detected? Is it difficult to start engine?

- YES >> Perform trouble diagnosis for DTC P0171 or P0172. Refer to [EC-245. "DTC Logic"](#) or [EC-249. "DTC Logic"](#).
- NO >> GO TO 6.

6.CHECK HARNESS CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect A/F sensor 1 harness connector.
3. Check harness connector for water.

Water should not exit.

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Repair or replace harness connector.

7.CHECK A/F SENSOR 1 POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check the voltage between A/F sensor 1 harness connector and ground.

| A/F sensor 1 | | Ground | Voltage |
|--------------|----------|--------|-----------------|
| Connector | Terminal | | |
| F12 | 4 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 9.
- NO >> GO TO 8.

8.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R harness connector F42
- 20A fuse (No. 53)
- Harness for open or short between A/F sensor 1 and fuse

>> Repair or replace harness or connectors.

9.CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

P2096, P2097 A/F SENSOR 1

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| A/F sensor 1 | | ECM | | Continuity |
|--------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F12 | 1 | F11 | 49 | Existed |
| | 2 | | 53 | |

4. Check the continuity between ECM harness connector or A/F sensor 1 harness connector and ground.

| A/F sensor 1 | | ECM | | Ground | Continuity |
|--------------|----------|-----------|----------|--------|-------------|
| Connector | Terminal | Connector | Terminal | | |
| F12 | 1 | F11 | 49 | Ground | Not existed |
| | 2 | | 53 | | |

5. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK A/F SENSOR 1 HEATER

Refer to [EC-172, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 11.

NO >> GO TO 13.

11. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-223, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 12.

NO >> Replace heated oxygen sensor 2. Refer to [EX-5, "Exploded View"](#).

12. CHECK INTERMITTENT INCIDENT

Perform [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> GO TO 13.

NO >> Repair or replace.

13. REPLACE AIR FUEL RATIO (A/F) SENSOR 1

Replace air fuel ratio (A/F) sensor 1. Refer to [EM-31, "Removal and Installation"](#).

CAUTION:

- Discard any sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new sensor, clean exhaust system threads using oxygen sensor thread cleaner tool [commercial service tool: (J-43897-18) or (J-43897-12)] and approved anti-seize lubricant (commercial service tool).

Do you have CONSULT?

YES >> GO TO 14.

NO >> GO TO 15.

14. CONFIRM A/F ADJUSTMENT DATA

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "A/F ADJ-B1" in "DATA MONITOR" mode with CONSULT.
3. Make sure that "0.000" is displayed on CONSULT screen.

Is "0.000" displayed?

YES >> INSPECTION END

NO >> GO TO 15.

P2096, P2097 A/F SENSOR 1

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

15. CLEAR THE MIXTURE RATIO SELF-LEARNING VALUE


Clear the mixture ratio self-learning value. Refer to [EC-130. "Work Procedure"](#).

Do you have CONSULT?

YES >> GO TO 16.

NO >> INSPECTION END

16. CONFIRM A/F ADJUSTMENT DATA

 **With CONSULT**

1. Turn ignition switch ON.
2. Select "A/F ADJ-B1" in "DATA MONITOR" mode with CONSULT.
3. Make sure that "0.000" is displayed on CONSULT screen.

>> INSPECTION END

P2100, P2103 THROTTLE CONTROL MOTOR RELAY

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2100, P2103 THROTTLE CONTROL MOTOR RELAY

DTC Logic

INFOID:000000009020892

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|--|---|
| P2100 | Throttle control motor relay circuit open | ECM detects a voltage of power source for throttle control motor is excessively low. | <ul style="list-style-type: none"> • Harness or connectors (Throttle control motor relay circuit is open) • Throttle control motor relay |
| P2103 | Throttle control motor relay circuit short | ECM detect the throttle control motor relay is stuck ON. | <ul style="list-style-type: none"> • Harness or connectors (Throttle control motor relay circuit is shorted) • Throttle control motor relay |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8 V.

With DTC is detected?

- P2100 >> GO TO 2.
- P2103 >> GO TO 3.

2. PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P2100

1. Turn ignition switch ON and wait at least 2 seconds.
2. Start engine and let it idle for 5 seconds.
3. Check DTC.

Is DTC detected?

- YES >> Go to [EC-401. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

3. PERFORM DTC CONFIRMATION PROCEDURE FOR DTC P2103

1. Turn ignition switch ON and wait at least 1 second.
2. Check DTC.

Is DTC detected?

- YES >> Go to [EC-401. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020893

1. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Check voltage between ECM harness connector and ground.

| ECM | | | | Voltage |
|-----------|----------|-----------|----------|-----------------|
| + | | - | | |
| Connector | Terminal | Connector | Terminal | |
| F10 | 15 | E16 | 108 | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> GO TO 2.

P2100, P2103 THROTTLE CONTROL MOTOR RELAY

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

2. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-I

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector F115.
3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

| ECM | | IPDM E/R | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F10 | 15 | F42 | 32 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R connector F42
- Harness for open or short between IPDM E/R and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUSE

1. Disconnect 20 A fuse (No. 53) from IPDM E/R.
2. Check 20 A fuse for blown.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace 20 A fuse.

5. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-I

1. Check voltage between ECM harness connector and ground under the following conditions.

| ECM | | | | Conditions | Voltage |
|-----------|----------|-----------|----------|----------------------|-----------------|
| + | | - | | | |
| Connector | Terminal | Connector | Terminal | | |
| F10 | 2 | E16 | 108 | Ignition switch: OFF | Approx. 0 V |
| | | | | Ignition switch: ON | Battery voltage |

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect IPDM E/R harness connector F42.
4. Check the continuity between ECM harness connector and IPDM E/R harness connector.

| ECM | | IPDM E/R | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F10 | 2 | F42 | 29 | Existed |

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 7.

P2100, P2103 THROTTLE CONTROL MOTOR RELAY

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

7. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R connector F42
- Harness for open or short between IPDM E/R and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUSE

1. Disconnect 15 A fuse (No. 52) from IPDM E/R.
2. Check 15 A fuse for blown.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace 15 A fuse.

9. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation"](#) (with I-Key), [PCS-60, "Removal and Installation"](#) (without I-Key).

NO >> Repair or replace harness or connectors.

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P2101 ELECTRIC THROTTLE CONTROL FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2101 ELECTRIC THROTTLE CONTROL FUNCTION

DTC Logic

INFOID:000000009020894

DTC DETECTION LOGIC

NOTE:

- If DTC P2101 is displayed with DTC P2100, first perform the trouble diagnosis for DTC P2100. Refer to [EC-401, "DTC Logic"](#).
- If DTC P2101 is displayed with DTC P2119, first perform the trouble diagnosis for DTC P2119. Refer to [EC-410, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---------------------------------------|---|--|
| P2101 | Electric throttle control performance | Electric throttle control function does not operate properly. | <ul style="list-style-type: none">• Harness or connectors (Throttle control motor circuit is open or shorted)• Electric throttle control actuator |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V when engine is running.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 2 seconds.
2. Start engine and let it idle for 5 seconds.
3. Check DTC.

Is DTC detected?

- YES >> Go to [EC-404, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020895

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Turn ignition switch ON.
2. Check the voltage between ECM harness connector and ground.

P2101 ELECTRIC THROTTLE CONTROL FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECM | | | | Condition | Voltage |
|-----------|----------|-----------|----------|---------------------|-----------------|
| + | | - | | | |
| Connector | Terminal | Connector | Terminal | | |
| F10 | 2 | E16 | 108 | Ignition switch OFF | Approx. 0 V |
| | | | | Ignition switch ON | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 11.
NO >> GO TO 3.

3.CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Check voltage between ECM harness connector and ground.

| ECM | | | | Voltage |
|-----------|----------|-----------|----------|-----------------|
| + | | - | | |
| Connector | Terminal | Connector | Terminal | |
| F10 | 15 | E16 | 108 | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 4.

4.CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-II

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector F42.
3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

| IPDM E/R | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F42 | 32 | F10 | 15 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 5.

5.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R connector F42
- Harness for open or short between IPDM E/R and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

6.CHECK FUSE

1. Disconnect 20 A fuse (No. 53) from IPDM E/R.
2. Check 20 A fuse for blown.

Is the inspection result normal?

- YES >> GO TO 10.
NO >> Replace 20 A fuse.

7.CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT-III

1. Disconnect ECM harness connector.
2. Disconnect IPDM E/R harness connector F42.
3. Check the continuity between ECM harness connector and IPDM E/R harness connector.

P2101 ELECTRIC THROTTLE CONTROL FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| IPDM E/R | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F42 | 29 | F10 | 2 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 10.
- NO >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R connector F42
- Harness for open or short between IPDM E/R and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK FUSE

1. Disconnect 15 A fuse (No. 52) from IPDM E/R.
2. Check 15 A fuse for blown.

Is the inspection result normal?

- YES >> GO TO 10.
- NO >> Replace 15 A fuse.

10. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation"](#).
- NO >> Repair or replace harness or connectors.

11. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch OFF.
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

| Electric throttle control actuator | | ECM | | Continuity |
|------------------------------------|----------|-----------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| F7 | 5 | F10 | 1 | Not existed |
| | | | 4 | Existed |
| F7 | 6 | F10 | 1 | Existed |
| | | | 4 | Not existed |

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 12.
- NO >> Repair or replace harness or connectors.

12. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct. Refer to [EM-26, "Removal and Installation"](#)

P2101 ELECTRIC THROTTLE CONTROL FUNCTION

[HR16DE]


< DTC/CIRCUIT DIAGNOSIS >

2. Check if foreign matter is caught between the throttle valve and the housing.

Is the inspection result normal?

YES >> GO TO 13.

NO >> Remove the foreign matter and clean the electric throttle control actuator inside, and then perform throttle valve closed position learning. Refer to [EC-127, "Work Procedure"](#).



13.CHECK THROTTLE CONTROL MOTOR

Refer to [EC-407, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 14.

NO >> GO TO 15.

14.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> GO TO 15.

NO >> Repair or replace harness or connectors.

15.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace malfunction electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020896

1.CHECK THROTTLE CONTROL MOTOR

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between electric throttle control actuator terminals as follows.

| Terminals | Resistance [at 25°C (77°F)] |
|-----------|-----------------------------|
| 5 and 6 | Approx. 1 - 15 Ω |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

P2118 THROTTLE CONTROL MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2118 THROTTLE CONTROL MOTOR

DTC Logic

INFOID:000000009020897

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--------------------------------------|--|--|
| P2118 | Throttle control motor circuit short | ECM detects short in both circuits between ECM and throttle control motor. | <ul style="list-style-type: none">• Harness or connectors (Throttle control motor circuit is shorted.)• Electric throttle control actuator (Throttle control motor) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 2 seconds.
2. Start engine and let it idle for 5 seconds.
3. Check DTC.

Is DTC detected?

- YES >> Go to [EC-408. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020898

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44. "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect electric throttle control actuator harness connector.
2. Disconnect ECM harness connector.
3. Check the continuity between electric throttle control actuator harness connector and ECM harness connector.

| Electric throttle control actuator | | ECM | | Continuity |
|------------------------------------|----------|-----------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| F7 | 5 | F10 | 1 | Not existed |
| | | | 4 | Existed |
| F7 | 6 | F10 | 1 | Existed |
| | | | 4 | Not existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 3.

P2118 THROTTLE CONTROL MOTOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness or connectors.

3.CHECK THROTTLE CONTROL MOTOR

Refer to [EC-409, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020899

1.CHECK THROTTLE CONTROL MOTOR

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between electric throttle control actuator terminals as follows.

| Terminals | Resistance [at 25°C (77°F)] |
|-----------|-----------------------------|
| 5 and 6 | Approx. 1 - 15 Ω |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

P2119 ELECTRIC THROTTLE CONTROL ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2119 ELECTRIC THROTTLE CONTROL ACTUATOR

DTC Logic

INFOID:000000009020900

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | | Possible cause |
|---------|------------------------------------|-------------------------|---|------------------------------------|
| P2119 | Electric throttle control actuator | A) | Electric throttle control actuator does not function properly due to the return spring malfunction. | Electric throttle control actuator |
| | | B) | Throttle valve opening angle in fail-safe mode is not in specified range. | |
| | | C) | ECM detect the throttle valve is stuck open. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION A AND B

1. Turn ignition switch ON and wait at least 1 second.
2. Set selector lever to D (CVT) or 1st (M/T) position and wait at least 3 seconds.
3. Set selector lever to P (CVT) or Neutral (M/T) position.
4. Turn ignition switch OFF and wait at least 10 seconds.
5. Turn ignition switch ON and wait at least 1 second.
6. Set selector lever to D (CVT) or 1st (M/T) position and wait at least 3 seconds.
7. Set selector lever to P (CVT) or Neutral (M/T) position.
8. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
9. Check DTC.

Is DTC detected?

- YES >> Go to [EC-410, "Diagnosis Procedure"](#).
NO >> GO TO 3.

3. PERFORM DTC CONFIRMATION PROCEDURE FOR MALFUNCTION C

1. Turn ignition switch ON and wait at least 1 second.
2. Set selector lever to D (CVT) or 1st (M/T) position and wait at least 3 seconds.
3. Set selector lever to P (CVT) or Neutral (M/T) position.
4. Start engine and let it idle for 3 seconds.
5. Check DTC.

Is DTC detected?

- YES >> Go to [EC-410, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020901

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch OFF.
2. Remove the intake air duct. Refer to [EM-26, "Removal and Installation"](#).

P2119 ELECTRIC THROTTLE CONTROL ACTUATOR

[HR16DE]


< DTC/CIRCUIT DIAGNOSIS >

3. Check if foreign matter is caught between the throttle valve and the housing.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Remove the foreign matter and clean the electric throttle control actuator inside, and then perform throttle valve closed position learning. Refer to [EC-127, "Work Procedure"](#).



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

P2122, P2123 APP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2122, P2123 APP SENSOR

DTC Logic

INFOID:000000009020902

DTC DETECTION LOGIC

NOTE:

If DTC P2122 or P2123 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P2122 | Accelerator pedal position sensor 1 circuit low input | An excessively low voltage from the APP sensor 1 is sent to ECM. | <ul style="list-style-type: none">• Harness or connectors (APP sensor 1 circuit is open or shorted.)• Accelerator pedal position sensor (APP sensor 1) |
| P2123 | Accelerator pedal position sensor 1 circuit high input | An excessively high voltage from the APP sensor 1 is sent to ECM. | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 1 second.
2. Check DTC.

Is DTC detected?

- YES >> Go to [EC-412, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020903

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between APP sensor harness connector and ground.

| APP sensor | | Ground | Voltage (Approx.) |
|------------|----------|--------|-------------------|
| Connector | Terminal | | |
| E12 | 4 | Ground | 5 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair open circuit or short to ground or short to power in harness or connectors.

P2122, P2123 APP SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between APP sensor harness connector and ECM harness connector.

| APP sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E12 | 2 | E16 | 111 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK APP SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between APP sensor harness connector and ECM harness connector.

| APP sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E12 | 3 | E16 | 110 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5.CHECK APP SENSOR

Refer to [EC-413, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6.REPLACE ACCELERATOR PEDAL ASSEMBLY

Replace accelerator pedal assembly. Refer to [ACC-3, "Exploded View"](#).

>> INSPECTION END

7.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020904

1.CHECK ACCELERATOR PEDAL POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check the voltage between ECM harness connector and ground.

P2122, P2123 APP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECM | | | Condition | Voltage |
|-----------|------------------------------|-----|-----------------|--------------|
| Connector | Terminal | | | |
| | + | - | | |
| E16 | 110 (APP sensor 1 signal) | 111 | Fully released | 0.6 - 0.9 V |
| | | | Fully depressed | 3.9 - 4.7 V |
| | 103 (APP sensor 2 signal) | 104 | Fully released | 0.3 - 0.6 V |
| | | | Fully depressed | 1.95 - 2.4 V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE ACCELERATOR PEDAL ASSEMBLY

Replace accelerator pedal assembly. Refer to [ACC-3, "Exploded View"](#).

>> INSPECTION END

P2127, P2128 APP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2127, P2128 APP SENSOR

DTC Logic

INFOID:000000009020905

DTC DETECTION LOGIC

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P2127 | Accelerator pedal position sensor 2 circuit low input | An excessively low voltage from the APP sensor 2 is sent to ECM. | <ul style="list-style-type: none"> Harness or connectors (APP sensor 2 circuit is open or shorted.) [Crankshaft position sensor (POS) circuit is shorted.] (Refrigerant pressure sensor circuit is shorted.) |
| P2128 | Accelerator pedal position sensor 2 circuit high input | An excessively high voltage from the APP sensor 2 is sent to ECM. | <ul style="list-style-type: none"> Accelerator pedal position sensor (APP sensor 2) Crankshaft position sensor (POS) Refrigerant pressure sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

- Turn ignition switch OFF and wait at least 10 seconds.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- Start engine and let it idle for 1 second.
- Check DTC.

Is DTC detected?

YES >> Go to [EC-415, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020906

1. CHECK GROUND CONNECTION

- Turn ignition switch OFF.
- Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-I

- Disconnect accelerator pedal position (APP) sensor harness connector.
- Turn ignition switch ON.
- Check the voltage between APP sensor harness connector and ground.

| APP sensor | | Ground | Voltage |
|------------|----------|--------|-------------|
| Connector | Terminal | | |
| E12 | 5 | Ground | Approx. 5 V |

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 3.

P2127, P2128 APP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

3. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between APP sensor harness connector and ECM harness connector.

| APP sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E12 | 5 | E16 | 102 | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK SENSOR POWER SUPPLY CIRCUIT

Check harness for short to power and short to ground, between the following terminals.

| ECM | | Sensor | | |
|-----------|----------|----------------------------------|-----------|----------|
| Connector | Terminal | Item | Connector | Terminal |
| F11 | 75 | Crankshaft position sensor (POS) | F15 | 1 |
| E16 | 101 | Refrigerant pressure sensor | E17 | 3 |
| | 102 | APP sensor | E12 | 5 |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair short to ground or short to power in harness or connectors.

5. CHECK COMPONENTS

Check the following.

- Crankshaft position sensor (POS) (Refer to [EC-277, "Component Inspection"](#).)
- Refrigerant pressure sensor (Refer to [EC-450, "Diagnosis Procedure"](#).)

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace malfunctioning component.

6. CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between APP sensor harness connector and ECM harness connector.

| APP sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E12 | 1 | E16 | 104 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between APP sensor harness connector and ECM harness connector.

| APP sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E12 | 6 | E16 | 103 | Existed |

2. Also check harness for short to ground and short to power.

P2127, P2128 APP SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

8.CHECK APP SENSOR

Refer to [EC-417, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> GO TO 9.

9.REPLACE ACCELERATOR PEDAL ASSEMBLY

Replace accelerator pedal assembly. Refer to [ACC-3, "Exploded View"](#).

>> INSPECTION END

10.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020907

1.CHECK ACCELERATOR PEDAL POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check the voltage between ECM harness connector and ground.

| ECM | | | Condition | Voltage |
|-----------|------------------------------|-----|-----------------|--------------|
| Connector | Terminal | | | |
| | + | - | | |
| E16 | 110 (APP sensor 1 signal) | 111 | Fully released | 0.6 - 0.9 V |
| | | | Fully depressed | 3.9 - 4.7 V |
| | 103 (APP sensor 2 signal) | 104 | Fully released | 0.3 - 0.6 V |
| | | | Fully depressed | 1.95 - 2.4 V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.REPLACE ACCELERATOR PEDAL ASSEMBLY

Replace accelerator pedal assembly. Refer to [ACC-3, "Exploded View"](#).

>> INSPECTION END

P2135 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2135 TP SENSOR

DTC Logic

INFOID:000000009020908

DTC DETECTION LOGIC

NOTE:

If DTC P2135 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|--|---|---|
| P2135 | Throttle position sensor circuit range/performance | Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2. | <ul style="list-style-type: none">• Harness or connector (TP sensor 1 and 2 circuit is open or shorted.)• Electric throttle control actuator (TP sensor 1 and 2) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 1 second.
2. Check DTC.

Is DTC detected?

- YES >> Go to [EC-418, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020909

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch ON.
3. Check the voltage between electric throttle control actuator harness connector and ground.

| Electric throttle control actuator | | Ground | Voltage |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| F7 | 2 | Ground | Approx. 5 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

P2135 TP SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between electric throttle control actuator harness connector and ground.

| Electric throttle control actuator | | ECM | | Continuity |
|------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F7 | 4 | F11 | 36 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between electric throttle control actuator harness connector and ground.

| Electric throttle control actuator | | ECM | | Continuity |
|------------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F7 | 1 | F11 | 33 | Existed |
| | 3 | | 34 | |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

5.CHECK THROTTLE POSITION SENSOR

Refer to [EC-419, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6.REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

7.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020910

1.CHECK THROTTLE POSITION SENSOR

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Perform [EC-127, "Work Procedure"](#).
4. Turn ignition switch ON.
5. Set selector lever to D (CVT) or 1st (M/T) position.
6. Check the voltage between ECM harness connector and ground.

P2135 TP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| ECM | | Condition | Voltage | |
|-----------|----------------------------|-------------------|-----------------|------------------|
| Connector | Terminal | | | |
| | + | | | |
| | - | | | |
| F11 | 33 (TP sensor 1 signal) | Accelerator pedal | Fully released | More than 0.36 V |
| | | | Fully depressed | Less than 4.75 V |
| | 34 (TP sensor 2 signal) | | Fully released | Less than 4.75 V |
| | | | Fully depressed | More than 0.36 V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

Replace electric throttle control actuator. Refer to [EM-28, "Removal and Installation"](#).

>> INSPECTION END

P2138 APP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

P2138 APP SENSOR

DTC Logic

INFOID:000000009020911

DTC DETECTION LOGIC

NOTE:

If DTC P2138 is displayed with DTC P0643, first perform the trouble diagnosis for DTC P0643. Refer to [EC-352, "DTC Logic"](#).

| DTC No. | Trouble diagnosis content | DTC detecting condition | Possible cause |
|---------|---|---|---|
| P2138 | Accelerator pedal position sensor circuit range/performance | Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2. | <ul style="list-style-type: none"> • Harness or connector (APP sensor 1 and 2 circuit is open or shorted.) [Crankshaft position sensor (POS) circuit is shorted.] (Refrigerant pressure sensor circuit is shorted.) • Accelerator pedal position sensor (APP sensor 1 and 2) • Crankshaft position sensor (POS) • Refrigerant pressure sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10 V at idle.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and let it idle for 1 second.
2. Check DTC.

Is DTC detected?

YES >> Go to [EC-421, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020912

1. CHECK GROUND CONNECTION

1. Turn ignition switch OFF.
2. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace ground connection.

2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between APP sensor harness connector and ground.

| APP sensor | | Ground | Voltage |
|------------|----------|--------|-------------|
| Connector | Terminal | | |
| E12 | 4 | Ground | Approx. 5 V |

Is the inspection result normal?

YES >> GO TO 3.

P2138 APP SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair open circuit or short to ground or shot to power in harness or connectors.

3.CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-I

Check the voltage between APP sensor harness connector and ground.

| APP sensor | | Ground | Voltage |
|------------|----------|--------|-------------|
| Connector | Terminal | | |
| E12 | 5 | Ground | Approx. 5 V |

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 4.

4.CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between APP sensor harness connector and ECM harness connector.

| APP sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E12 | 5 | E16 | 102 | Existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair open circuit or short to ground or shot to power in harness or connectors.

5.CHECK SENSOR POWER SUPPLY CIRCUIT

Check harness for short to power and short to ground, between the following terminals.

| ECM | | Sensor | | |
|-----------|----------|----------------------------------|-----------|----------|
| Connector | Terminal | Item | Connector | Terminal |
| F11 | 75 | Crankshaft position sensor (POS) | F15 | 1 |
| E16 | 101 | Refrigerant pressure sensor | E17 | 3 |
| | 102 | APP sensor | E12 | 5 |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair short to ground or short to power in harness or connectors.

6.CHECK COMPONENTS

Check the following.

- Crankshaft position sensor (POS) (Refer to [EC-277, "Component Inspection".](#))
- Refrigerant pressure sensor (Refer to [EC-450, "Diagnosis Procedure".](#))

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace malfunctioning component.

7.CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between APP sensor harness connector and ECM harness connector as follows.

| APP sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E12 | 1 | E16 | 104 | Existed |
| | 2 | | 111 | |

P2138 APP SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between APP sensor harness connector and ECM harness connector as follows.

| APP sensor | | ECM | | Continuity |
|------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E12 | 3 | E16 | 110 | Existed |
| | 6 | | 103 | |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK APP SENSOR

Refer to [EC-423, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 11.

NO >> GO TO 10.

10. REPLACE ACCELERATOR PEDAL ASSEMBLY

Replace accelerator pedal assembly. Refer to [ACC-3, "Exploded View"](#).

>> INSPECTION END

11. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009020913

1. CHECK ACCELERATOR PEDAL POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch ON.
3. Check the voltage between ECM harness connector and ground.

| ECM | | | Condition | Voltage |
|-----------|------------------------------|-----|-----------------|--------------|
| Connector | Terminal | | | |
| | + | - | | |
| E16 | 110 (APP sensor 1 signal) | 111 | Fully released | 0.6 - 0.9 V |
| | | | Fully depressed | 3.9 - 4.7 V |
| | 103 (APP sensor 2 signal) | 104 | Fully released | 0.3 - 0.6 V |
| | | | Fully depressed | 1.95 - 2.4 V |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. REPLACE ACCELERATOR PEDAL ASSEMBLY

Replace accelerator pedal assembly. Refer to [ACC-3, "Exploded View"](#).

P2138 APP SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

>> INSPECTION END

ASCD BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

ASCD BRAKE SWITCH

Component Function Check


INFOID:000000009020916

1. CHECK ASCD BRAKE SWITCH FUNCTION

 With CONSULT

1. Turn ignition switch ON.
2. Select "BRAKE SW1" in "DATA MONITOR" mode of "ENGINE" using CONSULT.
3. Check "BRAKE SW1" indication as per the following conditions.

| Monitor item | Condition | | Indication |
|--------------|-------------|--------------------|------------|
| BRAKE SW1 | Brake pedal | Slightly depressed | OFF |
| | | Fully released | ON |

 Without CONSULT

1. Turn ignition switch ON.
2. Check the voltage between ECM harness connector terminals as per the following.

| ECM | | | Condition | Voltage (Approx.) |
|-----------|----------|-----|--------------------------------|-------------------|
| Connector | + | - | | |
| | Terminal | | | |
| E16 | 100 | 108 | Brake pedal Slightly depressed | 0 V |
| | | | Fully released | Battery voltage |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to [EC-425. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020917

1. CHECK ASCD BRAKE SWITCH POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Turn ignition switch ON.
4. Check the voltage between ASCD brake switch harness connector and ground.

| ASCD brake switch | | Ground | Voltage |
|-------------------|----------|--------|-----------------|
| Connector | Terminal | | |
| E36 | 1 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform the trouble diagnosis for power supply circuit.

2. CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between ASCD brake switch harness connector and ECM harness connector.

| ASCD brake switch | | ECM | | Continuity |
|-------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E36 | 2 | E16 | 100 | Existed |

4. Also check harness for short to ground and to power.

Is the inspection result normal?

ASCD BRAKE SWITCH

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
NO >> Repair or replace error-detected parts.

3.CHECK ASCD BRAKE SWITCH

Check the ASCD brake switch. Refer to [EC-426. "Component Inspection \(ASCD Brake Switch\)"](#)

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
NO >> Replace ASCD brake switch. Refer to [ACC-3. "Exploded View"](#).

Component Inspection (ASCD Brake Switch)

INFOID:000000009020918

1.CHECK ASCD BRAKE PEDAL POSITION SWITCH-I

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch harness connector.
3. Check the continuity between ASCD brake switch terminals as per the following conditions.

| ASCD brake switch | | Condition | Continuity | |
|-------------------|---|-------------|--------------------|-------------|
| Terminal | | | | |
| 1 | 2 | Brake pedal | Fully released | Existed |
| | | | Slightly depressed | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2.CHECK ASCD BRAKE SWITCH-II

1. Adjust ASCD brake switch installation. Refer to [BR-20. "Inspection and Adjustment"](#).
2. Check the continuity between ASCD brake switch terminals as per the following conditions.

| ASCD brake switch | | Condition | Continuity | |
|-------------------|---|-------------|--------------------|-------------|
| Terminal | | | | |
| 1 | 2 | Brake pedal | Fully released | Existed |
| | | | Slightly depressed | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace ASCD brake switch. Refer to [BR-19. "Exploded View"](#).

CLUTCH PEDAL POSITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

CLUTCH PEDAL POSITION SWITCH

Component Function Check

INFOID:000000009762984

1. CHECK CLUTCH PEDAL POSITION SWITCH FUNCTION

With CONSULT

1. Turn ignition switch ON.
2. Select "ENGINE" using CONSULT.
3. Select "CLUTCH P/P SW" in "DATA MONITOR" mode.
4. Check "CLUTCH P/P SW" indication under the following conditions.

| Monitor item | Condition | | Indication |
|---------------|--------------|-----------------|------------|
| CLUTCH P/P SW | Clutch pedal | Fully released | OFF |
| | | Fully depressed | ON |

Without CONSULT

1. Turn ignition switch ON.
2. Check the voltage between ECM harness connector and ground.

| ECM | | | | Condition | Voltage |
|-----------|---|-----------|----------|-----------------|-----------------|
| + | | - | | | |
| Connector | Terminal | Connector | Terminal | Clutch pedal | |
| E16 | 92 (Clutch pedal position switch signal) | E16 | 108 | | |
| | | | | Fully depressed | Battery voltage |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Go to [EC-427. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009762985

1. CHECK CLUTCH PEDAL POSITION SWITCH GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect clutch pedal position switch harness connector.
3. Check the continuity between clutch pedal position switch harness connector and ground.

| Clutch pedal position switch | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| E48 | 4 | Ground | Existed |

4. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair open circuit or short to power in harness or connectors.

2. CHECK CLUTCH PEDAL POSITION SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check the continuity between clutch pedal position switch harness connector and ECM harness connector.

| Clutch pedal position switch | | ECM | | Continuity |
|------------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E48 | 3 | E16 | 92 | Existed |

3. Also check harness for short to ground and short to power.

CLUTCH PEDAL POSITION SWITCH

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3.CHECK CLUTCH PEDAL POSITION SWITCH

Refer to [EC-428. "Component Inspection \(Clutch Pedal Position Switch\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace clutch pedal position switch. Refer to [CL-10. "Exploded View"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection (Clutch Pedal Position Switch)

INFOID:000000009762986

1.CHECK CLUTCH PEDAL POSITION SWITCH-I

1. Turn ignition switch OFF.
2. Disconnect clutch pedal position switch harness connector.
3. Check the continuity between clutch pedal position switch terminals under the following conditions.

| Clutch pedal position switch | | Condition | | Continuity |
|------------------------------|-----------|--------------|-----------------|-------------|
| Connector | Terminals | | | |
| E48 | 3 and 4 | Clutch pedal | Fully released | Existed |
| | | | Fully depressed | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK CLUTCH PEDAL POSITION SWITCH-II

1. Adjust clutch pedal position switch installation. Refer to [CL-11. "Inspection and Adjustment"](#).
2. Check the continuity between clutch pedal position switch terminals under the following conditions.

| Clutch pedal position switch | | Condition | | Continuity |
|------------------------------|-----------|--------------|-----------------|-------------|
| Connector | Terminals | | | |
| E48 | 3 and 4 | Clutch pedal | Fully released | Existed |
| | | | Fully depressed | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace clutch pedal position switch. Refer to [CL-10. "Exploded View"](#).

COOLING FAN

Component Function Check

INFOID:000000009020919

1. CHECK COOLING FAN FUNCTION

 With CONSULT

1. Turn ignition switch ON.
2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT.
3. Touch "LOW" and "HI" on the CONSULT screen.
4. Check that cooling fan operates.

NOTE:

The cooling fan operates at high speeds even when "LOW" is selected in CONSULT "ACTIVE TEST". (For single connector cooling fan with M/T models)

 Without CONSULT

1. Perform IPDM E/R auto active test and check cooling fan motor operation. Refer to [PCS-10. "Diagnosis Description"](#).
2. Check that cooling fan operates.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Refer to [EC-429. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020920

1. CHECK COOLING FAN MOTOR CIRCUIT

1. Disconnect cooling fan motor harness connector.
2. Check the continuity between IPDM E/R harness connector and cooling fan motor harness connector.

CVT models

| IPDM E/R | | Cooling fan motor | | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E43 | 7 | E5 | 1 | Existed |
| | 5 | E32 | 3 | |

M/T models

| IPDM E/R | | Cooling fan motor | | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E43 | 7 | E31 | 2 | Existed |
| | 5 | | 1 | |

3. Check the continuity between cooling fan relay harness connector and cooling fan motor harness connector.

CVT models

| Cooling fan relay | | Cooling fan motor | | Continuity |
|-------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E62 | 5 | E32 | 4 | Existed |

M/T models

| Cooling fan relay | | Cooling fan motor | | Continuity |
|-------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E62 | 5 | E31 | 4 | Existed |

4. Check the continuity between cooling fan motor harness connector and ground.

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

COOLING FAN

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

CVT models

| Cooling fan motor | | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector | Terminal | | |
| E5 | 2 | Ground | Existed |

M/T models

| Cooling fan motor | | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector | Terminal | | |
| E31 | 3 | Ground | Existed |

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

2.CHECK COOLING FAN RELAY CIRCUIT

1. Disconnect cooling fan relay harness connector.
2. Disconnect IPDM E/R harness connector.
3. Check the continuity between IPDM E/R harness connector and cooling fan relay harness connector.

| IPDM E/R | | Cooling fan relay | | Continuity |
|-----------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E46 | 65 | E62 | 1 | Existed |
| | 59 | | 2 | |

4. Check the continuity between cooling fan relay harness connector and ground.

| Cooling fan relay | | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector | Terminal | | |
| E62 | 3 | Ground | Existed |

5. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3.CHECK COOLING FAN RELAY

Refer to [EC-431, "Component Inspection \(Cooling Fan Relay\)"](#).

YES or NO

YES >> GO TO 4.

NO >> Replace cooling fan relay.

4.CHECK COOLING FAN MOTOR

Refer to [EC-431, "Component Inspection \(Cooling Fan Motor\)"](#).

YES or NO

YES >> GO TO 5.

NO >> Replace cooling fan motor. Refer to [CO-17, "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Perform [GI-41, "Intermittent Incident"](#).

YES or NO

YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation"](#)(with I-Key), [PCS-60, "Removal and Installation"](#)(without I-Key).

NO >> Repair or replace harness or connector.

COOLING FAN

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Component Inspection (Cooling Fan Motor)

INFOID:000000009020921

1. CHECK COOLING FAN MOTOR

1. Turn ignition switch OFF.
2. Disconnect cooling fan motor harness connector.
3. Supply cooling fan motor terminals with battery voltage and check operation.

CVT models

| Cooling fan motor | | | Operation |
|-------------------|-----------|---|----------------------------|
| Connector | + | - | |
| | terminals | | |
| E5 | 1 | 2 | Cooling fan motor operates |
| E32 | 3 | 4 | |

M/T models

| Cooling fan motor | | | Operation |
|-------------------|-----------|---|----------------------------|
| Connector | + | - | |
| | terminals | | |
| E31 | 2 | 3 | Cooling fan motor operates |
| | 1 | 4 | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace cooling fan motor. Refer to [CO-17, "Exploded View"](#).

Component Inspection (Cooling Fan Relay)

INFOID:000000009020922

1. CHECK COOLING FAN RELAY


1. Turn ignition switch OFF.
2. Remove cooling fan relay.
3. Check continuity between cooling fan relay terminals under the following conditions.

| Cooling fan relay terminals | | Conditions | Continuity |
|-----------------------------|---|-------------------|-------------|
| 3 | 5 | | |
| | | No current supply | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace cooling fan relay.



ELECTRICAL LOAD SIGNAL

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

ELECTRICAL LOAD SIGNAL

Description

INFOID:000000009020923

The electrical load signal (Headlamp switch signal, rear window defogger switch signal, etc.) is transferred to ECM through the CAN communication line.

Component Function Check

INFOID:000000009020924

1. CHECK REAR WINDOW DEFOGGER SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "DATA MONITOR" mode with CONSULT.
3. Select "LOAD SIGNAL" and check indication under the following conditions.

| Monitor item | Condition | Indication | |
|--------------|-----------------------------|------------|-----|
| LOAD SIGNAL | Rear window defogger switch | ON | ON |
| | | OFF | OFF |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to [EC-432, "Diagnosis Procedure"](#).

2. CHECK LIGHTING SWITCH FUNCTION

Check "LOAD SIGNAL" indication under the following conditions.

| Monitor item | Condition | Indication | |
|--------------|-----------------|--------------------|-----|
| LOAD SIGNAL | Lighting switch | ON at 2nd position | ON |
| | | OFF | OFF |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Go to [EC-432, "Diagnosis Procedure"](#).

3. CHECK HEATER FAN CONTROL SWITCH FUNCTION

Select "HEATER FAN SW" and check indication under the following conditions.

| Monitor item | Condition | Indication | |
|---------------|---------------------------|------------|-----|
| HEATER FAN SW | Heater fan control switch | ON | ON |
| | | OFF | OFF |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to [EC-432, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020925

1. INSPECTION START

Confirm the malfunctioning circuit (rear window defogger, headlamp or heater fan). Refer to [EC-432, "Component Function Check"](#).

Which circuit is related to the incident?

Rear window defogger>>GO TO 2

Headlamp>>GO TO 3.

Heater fan>>GO TO 4.

2. CHECK REAR WINDOW DEFOGGER SYSTEM

Perform trouble diagnosis of rear window defogger system. Refer to [DEF-17, "Work Flow"](#).

ELECTRICAL LOAD SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

>> INSPECTION END

3.CHECK HEADLAMP SYSTEM

Perform trouble diagnosis of headlamp system. Refer to [EXL-66, "Work Flow"](#).

>> INSPECTION END

4.CHECK AIR CONDITIONING SYSTEM

Perform trouble diagnosis of air conditioning system. Refer to [HA-12, "Workflow"](#).

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

FUEL INJECTOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

FUEL INJECTOR

Component Function Check

INFOID:000000009020926

1.INSPECTION START

Turn ignition switch to START.

Is any cylinder ignited?

- YES >> GO TO 2.
- NO >> Go to [EC-434, "Diagnosis Procedure"](#).

2.CHECK FUEL INJECTOR FUNCTION

Ⓟ With CONSULT

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.
3. Make sure that each circuit produces a momentary engine speed drop.


ⓧ Without CONSULT

1. Let engine idle.
2. Listen to each fuel injector operating sound.

Clicking noise should be heard.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-434, "Diagnosis Procedure"](#).



Diagnosis Procedure

INFOID:000000009020927

1.CHECK FUEL INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuel injector harness connector.
3. Turn ignition switch ON.
4. Check the voltage between fuel injector harness connector and ground.

| Fuel injector | | | | Ground | Voltage | | | | | | |
|---------------|-----------|--------------|----------|--------|-----------------|--------|-----------------|--------|-----------------|--------|-----------------|
| Cylinder | Connector | Front / Rear | Terminal | | | | | | | | |
| 1 | F17 | Front | 1 | Ground | Battery voltage | | | | | | |
| | F53 | Rear | | | | | | | | | |
| 2 | F18 | Front | 1 | | | Ground | Battery voltage | | | | |
| | F54 | Rear | | | | | | | | | |
| 3 | F19 | Front | 1 | | | | | Ground | Battery voltage | | |
| | F29 | Rear | | | | | | | | | |
| 4 | F20 | Front | 1 | | | | | | | Ground | Battery voltage |
| | F30 | Rear | | | | | | | | | |

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following.

- IPDM E/R connector F42

FUEL INJECTOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- 10 A fuse (No. 55)
- Harness for open or short between fuel injector and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

3.CHECK FUEL INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between fuel injector harness connector and ECM harness connector.

| Fuel injector | | | | ECM | | Continuity |
|---------------|-----------|--------------|----------|-----------|----------|------------|
| Cylinder | Connector | Front / Rear | Terminal | Connector | Terminal | |
| 1 | F17 | Front | 2 | F10 | 31 | Existed |
| | F53 | Rear | | | 12 | |
| 2 | F18 | Front | 2 | | 30 | |
| | F54 | Rear | | | 20 | |
| 3 | F19 | Front | 2 | | 29 | |
| | F29 | Rear | | | 16 | |
| 4 | F20 | Front | 2 | | 25 | |
| | F30 | Rear | | | 24 | |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK FUEL INJECTOR

Refer to [EC-435, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning fuel injector. Refer to [EM-40, "Removal and Installation"](#)

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

Component Inspection

INFOID:000000009020928

1.CHECK FUEL INJECTOR

1. Turn ignition switch OFF.
2. Disconnect fuel injector harness connector.
3. Check resistance between fuel injector terminals as follows.

| Terminals | Resistance |
|-----------|---|
| 1 and 2 | 11.1 - 14.5 Ω [at 10 - 60°C (50 - 140°F)] |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace malfunctioning fuel injector. Refer to [EM-40, "Removal and Installation"](#).

FUEL PUMP

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

FUEL PUMP

Component Function Check

INFOID:000000009020929


1.CHECK FUEL PUMP FUNCTION

1. Turn ignition switch ON.
2. Pinch fuel feed hose (1) with two fingers.

Fuel pressure pulsation should be felt on the fuel feed hose for 1 second after ignition switch is turned ON.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> [EC-436. "Diagnosis Procedure"](#).



INFOID:000000009020930

Diagnosis Procedure

1.CHECK FUEL PUMP POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Turn ignition switch ON.
4. Check the voltage between ECM harness connector and ground.

| ECM | | | | Voltage |
|-----------|----------|-----------|----------|-----------------|
| + | | - | | |
| Connector | Terminal | Connector | Terminal | |
| F10 | 23 | E16 | 108 | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK FUEL PUMP POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check the continuity between IPDM E/R harness connector and ECM harness connector.

| IPDM E/R | | ECM | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F43 | 43 | F10 | 23 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 8.
 NO >> Repair open circuit or short to ground or short to power in harness or connectors.

3.CHECK FUEL PUMP POWER SUPPLY CIRCUIT-III

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Disconnect "fuel level sensor unit and fuel pump" harness connector.
4. Turn ignition switch ON.
5. Check the voltage between "fuel level sensor unit and fuel pump" harness connector and ground.

FUEL PUMP

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

| Fuel level sensor unit and fuel pump | | Ground | Voltage |
|--------------------------------------|----------|--------|---|
| Connector | Terminal | | |
| B44 | 1 | Ground | Battery voltage should exist 1 second after ignition switch is turned ON. |

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 4.

4. CHECK FUSE

1. Turn ignition switch OFF.
2. Disconnect 15 A fuse (No. 48) from IPDM E/R.
3. Check 15 A fuse.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace 15 A fuse.

5. CHECK FUEL PUMP POWER SUPPLY CIRCUIT-IV

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check the continuity between IPDM E/R harness connector and "fuel level sensor unit and fuel pump" harness connector.

| IPDM E/R | | Fuel level sensor unit and fuel pump | | Continuity |
|-----------|----------|--------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E44 | 9 | B44 | 1 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair open circuit, short to ground or short to power in harness or connectors.

6. CHECK FUEL PUMP GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check the continuity between "fuel level sensor unit and fuel pump" harness connector and ground.

| Fuel level sensor unit and fuel pump | | Ground | Continuity |
|--------------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B44 | 3 | Ground | Existed |

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair open circuit or short to power in harness or connectors.

7. CHECK FUEL PUMP

Refer to [EC-438, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Replace "fuel level sensor unit and fuel pump". Refer to [FL-6, "Exploded View"](#).

8. CHECK INTERMITTENT INCIDENT

Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

FUEL PUMP

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-31, "Removal and Installation"](#).
NO >> Repair open circuit, short to ground or short to power in harness or connectors.

Component Inspection

INFOID:000000009020931

1. CHECK FUEL PUMP

1. Turn ignition switch OFF.
2. Disconnect "fuel level sensor unit and fuel pump" harness connector.
3. Check resistance between "fuel level sensor unit and fuel pump" terminals as follows.

| Terminals | Resistance [at 25°C (77°F)] |
|-----------|-----------------------------|
| 1 and 3 | 0.2 - 5.0 Ω |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace "fuel level sensor unit and fuel pump". Refer to [FL-6, "Exploded View"](#).

IGNITION SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

IGNITION SIGNAL

Component Function Check

INFOID:000000009020932

1.INSPECTION START

Turn ignition switch OFF, and restart engine.

Does the engine start?

- YES-1 >> With CONSULT: GO TO 2.
- YES-2 >> Without CONSULT: GO TO 3.
- NO >> Go to [EC-439, "Diagnosis Procedure"](#).

2.IGNITION SIGNAL FUNCTION

With CONSULT

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT.
2. Make sure that each circuit produces a momentary engine speed drop.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-439, "Diagnosis Procedure"](#).

3.IGNITION SIGNAL FUNCTION

Without CONSULT

1. Let engine idle.
2. Check the voltage signal between ECM harness connector and ground with an oscilloscope.

| ECM | | | | Voltage signal |
|-----------|----------|-----------|----------|----------------|
| + | | - | | |
| Connector | Terminal | Connector | Terminal | |
| F7 | 17 | E16 | 108 | |
| | 18 | | | |
| | 21 | | | |
| | 22 | | | |

NOTE:

The pulse cycle changes depending on rpm at idle.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-439, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020933

1.CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

1. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
2. Check the voltage between ECM harness connector and ground.

| ECM | | | Voltage |
|-----------|----------|-----|-----------------|
| Connector | Terminal | | |
| | + | - | |
| E16 | 105 | 108 | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Go to [EC-157, "Diagnosis Procedure"](#).

IGNITION SIGNAL

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

1. Turn ignition switch OFF.
2. Disconnect condenser harness connector.
3. Turn ignition switch ON.
4. Check the voltage between condenser harness connector and ground.

| Condenser | | Ground | Voltage |
|-----------|----------|--------|-----------------|
| Connector | Terminal | | |
| F26 | 1 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 3.

3. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector F42.
3. Check the continuity between IPDM E/R harness connector and condenser harness connector.

| IPDM E/R | | Condenser | | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| F42 | 34 | F26 | 1 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 11.
NO >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between IPDM E/R and condenser

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check the continuity between condenser harness connector and ground.

| Condenser | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| F26 | 2 | Ground | Existed |

3. Also check harness for short to power.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CONDENSER

Refer to [EC-443. "Component Inspection \(Condenser\)"](#)

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Replace condenser.

7. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV

1. Reconnect all harness connectors disconnected.
2. Disconnect ignition coil harness connector.

IGNITION SIGNAL

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

3. Turn ignition switch ON.
4. Check the voltage between ignition coil harness connector and ground.

| Ignition coil | | | Ground | Voltage |
|---------------|-----------|----------|--------|-----------------|
| Cylinder | Connector | Terminal | | |
| 1 | F34 | 3 | Ground | Battery voltage |
| 2 | F35 | 3 | | |
| 3 | F36 | 3 | | |
| 4 | F37 | 3 | | |

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

8.CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Check the continuity between ignition coil harness connector and ground.

| Ignition coil | | | Ground | Continuity |
|---------------|-----------|----------|--------|------------|
| Cylinder | Connector | Terminal | | |
| 1 | F34 | 2 | Ground | Existed |
| 2 | F35 | 2 | | |
| 3 | F36 | 2 | | |
| 4 | F37 | 2 | | |

3. Also check harness for short to power.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair open circuit or short to power in harness or connectors.

9.CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check the continuity between ECM harness connector and ignition coil harness connector.

| Ignition coil | | | ECM | | Continuity |
|---------------|-----------|----------|-----------|----------|------------|
| Cylinder | Connector | Terminal | Connector | Terminal | |
| 1 | F34 | 1 | F10 | 17 | Existed |
| 2 | F35 | 1 | | 18 | |
| 3 | F36 | 1 | | 22 | |
| 4 | F37 | 1 | | 21 | |

3. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

10.CHECK IGNITION COIL WITH POWER TRANSISTOR

Refer to [EC-442. "Component Inspection \(Ignition Coil with Power Transistor\)".](#)

Is the inspection result normal?

YES >> GO TO 11.

NO >> Replace malfunctioning ignition coil with power transistor. Refer to [EM-47. "Removal and Installation".](#)

11.CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident".](#)

>> INSPECTION END

Component Inspection (Ignition Coil with Power Transistor)

INFOID:000000009020934

1. CHECK IGNITION COIL WITH POWER TRANSISTOR-I

1. Turn ignition switch OFF.
2. Disconnect ignition coil harness connector.
3. Check resistance between ignition coil terminals as follows.

| Terminals | Resistance |
|-----------|--|
| 1 and 2 | Except 0 or ∞ Ω [at 25°C (77°F)] |
| 1 and 3 | Except 0 Ω [at 25°C (77°F)] |
| 2 and 3 | |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace malfunctioning ignition coil with power transistor. Refer to [EM-47, "Removal and Installation"](#).

2. CHECK IGNITION COIL WITH POWER TRANSISTOR-II

CAUTION:

Do the following procedure in the place where ventilation is good without the combustible.

1. Turn ignition switch OFF.
2. Reconnect all harness connectors disconnected.
3. Remove fuel pump fuse in IPDM E/R to release fuel pressure.

NOTE:

Do not use CONSULT to release fuel pressure, or fuel pressure applies again during the following procedure.

4. Start engine.
5. After engine stalls, crank it two or three times to release all fuel pressure.
6. Turn ignition switch OFF.
7. Remove all ignition coil harness connectors to avoid the electrical discharge from the ignition coils.
8. Remove ignition coil and spark plug of the cylinder to be checked.
9. Crank engine for 5 seconds or more to remove combustion gas in the cylinder.
10. Connect spark plug and harness connector to ignition coil.
11. Fix ignition coil using a rope etc. with gap of 13 - 17 mm (0.52 - 0.66 in) between the edge of the spark plug and grounded metal portion as shown in the figure.
12. Crank engine for about three seconds, and check whether spark is generated between the spark plug and the grounded metal portion.


Spark should be generated.

CAUTION:

- Do not approach to the spark plug and the ignition coil within 50 cm (19.7 in). Be careful not to get an electrical shock while checking, because the electrical discharge voltage becomes 20 kV or more.
- It might cause to damage the ignition coil if the gap of more than 17 mm (0.66 in) is taken.

NOTE:

When the gap is less than 13 mm (0.52 in), the spark might be generated even if the coil is malfunctioning.



Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace malfunctioning ignition coil with power transistor. Refer to [EM-47, "Removal and Installation"](#).

IGNITION SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Component Inspection (Condenser)

INFOID:000000009020935

1. CHECK CONDENSER

1. Turn ignition switch OFF.
2. Disconnect condenser harness connector.
3. Check resistance between condenser terminals as follows.

| Terminals | Resistance [at 25°C (77°F)] |
|-----------|-----------------------------|
| 1 and 2 | Above 1 MΩ |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace condenser.

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

MALFUNCTION INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

MALFUNCTION INDICATOR LAMP

Component Function Check

INFOID:000000009020936

1.CHECK MIL FUNCTION

1. Turn ignition switch ON.
2. Make sure that MIL lights up.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to [EC-444, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020937

1.CHECK DTC

Check that DTC UXXXX is not displayed.

Is DTC detected?

- YES >> Perform trouble diagnosis for DTC UXXXX.
- NO >> GO TO 2.

2.CHECK COMBINATION METER

Check DTC with combination meter. Refer to [MWI-21, "DTC Index"](#).

Is DTC detected?

- YES >> Perform troubleshooting relevant to DTC indicated.
- NO >> GO TO 3.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-54, "Removal and Installation"](#).
- NO >> Repair or replace harness or connectors.

ON BOARD REFUELING VAPOR RECOVERY (ORVR)

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

ON BOARD REFUELING VAPOR RECOVERY (ORVR)

Component Function Check

INFOID:000000009020938

1.CHECK ORVR FUNCTION

Check whether the following symptoms are present.

- Fuel odor from EVAP canister is strong.
- Cannot refuel/Fuel odor from the fuel filler opening is strong while refueling.

Is any symptom present?

- YES >> Go to [EC-445, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009020939

1.INSPECTION START

Check whether the following symptoms are present.

- A: Fuel odor from EVAP canister is strong.
B: Cannot refuel/Fuel odor from the fuel filler opening is strong while refueling.

Which symptom is present?

- A >> GO TO 2.
B >> GO TO 8.

2.CHECK EVAP CANISTER

1. Remove EVAP canister with EVAP canister vent control valve and EVAP control system pressure sensor attached.
2. Weigh the EVAP canister with EVAP canister vent control valve and EVAP control system pressure sensor attached.

The weight should be less than 1.6 kg (3.5 lb).

Is the inspection result normal?


- YES >> GO TO 3.
NO >> GO TO 4.

3.CHECK IF EVAP CANISTER IS SATURATED WITH WATER

Check if water will drain from EVAP canister.

Does water drain from the EVAP canister?

- YES >> GO TO 4.
NO >> GO TO 7.



4.REPLACE EVAP CANISTER

Replace EVAP canister with a new one.

>> GO TO 5.

5.CHECK DRAIN FILTER

Refer to [EC-449, "Component Inspection \(Drain filter\)"](#).

Is the inspection result normal?

- OK >> GO TO 6.
NO >> Replace drain filter.

6.DETECT MALFUNCTIONING PART

ON BOARD REFUELING VAPOR RECOVERY (ORVR)

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

Check the EVAP hose between EVAP canister and vehicle frame for clogging or poor connection.

>> Repair or replace EVAP hose.

7. CHECK REFUELING EVAP VAPOR CUT VALVE

Refer to [EC-447, "Component Inspection \(Refueling EVAP vapor cut valve\)"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace refueling EVAP vapor cut valve with fuel tank.

8. CHECK EVAP CANISTER

1. Remove EVAP canister with EVAP canister vent control valve and EVAP control system pressure sensor attached.
2. Weigh the EVAP canister with EVAP canister vent control valve and EVAP control system pressure sensor attached.

The weight should be less than 1.6 kg (3.5 lb).

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 10.


9. CHECK IF EVAP CANISTER IS SATURATED WITH WATER

Check if water will drain from EVAP canister.

Does water drain from the EVAP canister?

YES >> GO TO 10.

NO >> GO TO 13.



10. REPLACE EVAP CANISTER

Replace EVAP canister with a new one.

>> GO TO 11.

11. CHECK DRAIN FILTER

Refer to [EC-449, "Component Inspection \(Drain filter\)"](#).

Is the inspection result normal?

OK >> GO TO 12.

NO >> Replace drain filter.

12. DETECT MALFUNCTIONING PART

Check the EVAP hose between EVAP canister and vehicle frame for clogging or poor connection.

>> Repair or replace EVAP hose.

13. CHECK VENT HOSES AND VENT TUBES

Check hoses and tubes between EVAP canister and refueling control valve for clogging, kink, looseness and improper connection.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair or replace hoses and tubes.

14. CHECK RECIRCULATION LINE

ON BOARD REFUELING VAPOR RECOVERY (ORVR)

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

Check recirculation line for clogging, dents and cracks.

Is the inspection result normal?

YES >> GO TO 15.

NO >> Replace fuel filler tube.

15. CHECK REFUELING EVAP VAPOR CUT VALVE

Refer to [EC-447, "Component Inspection \(Refueling EVAP vapor cut valve\)"](#).

Is the inspection result normal?

YES >> GO TO 16.

NO >> Replace refueling EVAP vapor cut valve with fuel tank.

16. CHECK FUEL FILLER TUBE

Check fuel filler tube and hose connected to the fuel tank for clogging, dents and cracks.

Is the inspection result normal?

YES >> GO TO 17.

NO >> Replace fuel filler tube.

17. CHECK ONE-WAY FUEL VALVE-I

Check one-way valve for clogging.

Is the inspection result normal?

YES >> GO TO 18.

NO >> Repair or replace one-way fuel valve with fuel tank.

18. CHECK ONE-WAY FUEL VALVE-II


1. Make sure that fuel is drained from the tank.
2. Remove fuel filler tube and hose.
3. Check one-way fuel valve for operation as per the following.
When a stick is inserted, the valve should open, when removing stick it should close.

Do not drop any material into the tank.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace fuel filler tube or replace one-way fuel valve with fuel tank.



Component Inspection (Refueling EVAP vapor cut valve)

INFOID:000000009020940

1. INSPECTION START

Do you have CONSULT?

Do you have CONSULT?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK REFUELING EVAP VAPOR CUT VALVE

Ⓜ With CONSULT


1. Remove fuel tank. Refer to [FL-10, "Removal and Installation"](#).
2. Drain fuel from the tank as per the following:
 - Remove fuel feed hose located on the fuel gauge retainer.
 - Connect a spare fuel hose, one side to fuel gauge retainer where the hose was removed and the other side to a fuel container.
 - Drain fuel using "FUEL PUMP RELAY" in "ACTIVE TEST" mode of "ENGINE" using CONSULT.
3. Check refueling EVAP vapor cut valve for being stuck to close as per the following.
Blow air into the refueling EVAP vapor cut valve (from the end of EVAP/ORVR line hose), and check that the air flows freely into the tank.
4. Check refueling EVAP vapor cut valve for being stuck to open as per the following.

ON BOARD REFUELING VAPOR RECOVERY (ORVR)

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

- Connect vacuum pump to hose end.
 - Remove fuel gauge retainer with fuel gauge unit.
- Always replace O-ring with new one.**
- Put fuel tank upside down.
 - Apply vacuum pressure to hose end [-13.3 kPa (-0.136 kg/cm³, -1.93 psi)] with fuel gauge retainer remaining open and check that the pressure is applicable.



- 1. Filler tube
- 2. Recirculation line
- 3. EVAP/ORVR line
- 4. Vacuum/pressure handy pump
- 5. Fuel tank

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace refueling EVAP vapor cut valve with fuel tank. Refer to [FL-10. "Removal and Installation"](#).

3. CHECK REFUELING EVAP VAPOR CUT VALVE

⊗ Without CONSULT

1. Remove fuel tank. Refer to [FL-10. "Removal and Installation"](#).
2. Drain fuel from the tank as per the following:
 - Remove fuel gauge retainer.
 - Drain fuel from the tank using a handy pump into a fuel container.
3. Check refueling EVAP vapor cut valve for being stuck to close as per the following.
Blow air into the refueling EVAP vapor cut valve (from the end of EVAP/ORVR line hose), and check that the air flows freely into the tank.
4. Check refueling EVAP vapor cut valve for being stuck to open as per the following.
 - Connect vacuum pump to hose end.
 - Remove fuel gauge retainer with fuel gauge unit.


Always replace O-ring with new one.

 - Put fuel tank upside down.
 - Apply vacuum pressure to hose end [-13.3 kPa (-0.136 kg/cm³, -1.93 psi)] with fuel gauge retainer remaining open and check that the pressure is applicable.

ON BOARD REFUELING VAPOR RECOVERY (ORVR)

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]



1. Filler tube
2. Recirculation line
3. EVAP/ORVR line
4. Vacuum/pressure handy pump
5. Fuel tank

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace refueling EVAP vapor cut valve with fuel tank. Refer to [FL-10, "Removal and Installation"](#).

Component Inspection (Drain filter)

INFOID:000000009020941


1. CHECK DRAIN FILTER

1. Check visually for insect nests in the drain filter air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.
4. Blow air into port A and check that it flows freely out of port B.
5. Block port B.
6. Blow air into port A and check that there is no leakage.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace drain filter.



REFRIGERANT PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HR16DE]

REFRIGERANT PRESSURE SENSOR

Component Function Check

INFOID:000000009020942

1. CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn A/C switch and blower fan switch ON.
3. Check the voltage between ECM harness connector and ground.

| Connector | ECM Terminal | | Voltage |
|-----------|---|----|------------|
| | + | - | |
| E16 | 101 (Refrigerant pressure sensor signal) | 98 | 1.0 - 4.0V |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Go to [EC-450, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009020943

1. CHECK GROUND CONNECTION

1. Turn A/C switch and blower fan switch OFF.
2. Stop engine.
3. Turn ignition switch OFF.
4. Check ground connection E15. Refer to Ground Inspection in [GI-44, "Circuit Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace ground connection.

2. CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Disconnect refrigerant pressure sensor harness connector.
2. Turn ignition switch ON.
3. Check the voltage between refrigerant pressure sensor harness connector and ground.

| Refrigerant pressure sensor | | Ground | Voltage |
|-----------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| E17 | 3 | Ground | Approx. 5 V |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between refrigerant pressure sensor harness connector and ECM harness connector.

REFRIGERANT PRESSURE SENSOR

[HR16DE]

< DTC/CIRCUIT DIAGNOSIS >

| Refrigerant pressure sensor | | ECM | | Continuity |
|-----------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E17 | 1 | E16 | 98 | Existed |

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check the continuity between ECM harness connector and refrigerant pressure sensor harness connector.

| Refrigerant pressure sensor | | ECM | | Continuity |
|-----------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E17 | 2 | E16 | 85 | Existed |

2. Also check harness for short to ground and short to power.

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [GI-41. "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace refrigerant pressure sensor. Refer to [HA-30. "REFRIGERANT PRESSURE SENSOR : Removal and Installation"](#).
- NO >> Repair or replace.

ENGINE CONTROL SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HR16DE]

SYMPTOM DIAGNOSIS

ENGINE CONTROL SYSTEM SYMPTOMS

Symptom Table

INFOID:000000009020944

SYSTEM — BASIC ENGINE CONTROL SYSTEM

| | | SYMPTOM | | | | | | | | | | | Reference page | | |
|--------------------------------------|---------------------------------------|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|----------------|---------------------------|---|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | | EXCESSIVE OIL CONSUMPTION | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Fuel | Fuel pump circuit | 1 | 1 | 2 | 3 | 2 | | 2 | 2 | | | 3 | | 2 | EC-436. "Component Function Check" |
| | Fuel pressure regulator system | 3 | 3 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | | 4 | | | EC-135. "Work Procedure" |
| | Fuel injector circuit | 1 | 1 | 2 | 3 | 2 | | 2 | 2 | | | 2 | | | EC-434. "Component Function Check" |
| | Evaporative emission system | 3 | 3 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | | | EC-40. "EVAPORATIVE EMISSION SYSTEM : System Description" |
| Air | Positive crankcase ventilation system | 3 | 3 | 4 | 4 | 4 | 4 | 4 | 4 | 4 | | 4 | 1 | | EC-464. "Inspection" |
| | Incorrect idle speed adjustment | | | | | | 1 | 1 | 1 | 1 | | 1 | | | |
| | Electric throttle control actuator | 1 | 1 | 2 | 3 | 3 | 2 | 2 | 2 | 2 | | 2 | | 2 | EC-404. "DTC Logic" EC-408. "DTC Logic" EC-410. "DTC Logic" |
| Ignition | Incorrect ignition timing adjustment | 3 | 3 | 1 | 1 | 1 | | 1 | 1 | | | 1 | | | EC-460. "Inspection" |
| | Ignition signal circuit | 1 | 1 | 2 | 2 | 2 | | 2 | 2 | | | 2 | | | EC-439. "Diagnosis Procedure" |
| Main power supply and ground circuit | | 2 | 2 | 3 | 3 | 3 | | 3 | 3 | | 2 | 3 | | | EC-157. "Diagnosis Procedure" |

ENGINE CONTROL SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HR16DE]

| | SYMPTOM | | | | | | | | | | | | Reference page | |
|---|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|----------------|--|
| | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Mass air flow sensor circuit | 1 | | | 2 | | | | | | | | | | EC-187, "DTC Log-ic" |
| Engine coolant temperature sensor circuit | | | | | | 3 | | | 3 | | | | | EC-198, "DTC Log-ic" |
| Air fuel ratio (A/F) sensor 1 circuit | | 1 | 2 | 3 | 2 | | 2 | 2 | | | 2 | | | EC-210, "DTC Log-ic" EC-214, "DTC Log-ic" EC-217, "DTC Log-ic" EC-240, "DTC Log-ic" EC-397, "DTC Log-ic" |
| Throttle position sensor circuit | | | | | | 2 | | | 2 | | | | | EC-200, "DTC Log-ic" EC-264, "DTC Log-ic" EC-370, "DTC Log-ic" EC-371, "DTC Log-ic" EC-418, "DTC Log-ic" |
| Accelerator pedal position sensor circuit | | | 3 | 2 | 1 | | | | | | | | | EC-412, "DTC Log-ic" EC-415, "DTC Log-ic" EC-421, "DTC Log-ic" |
| Heated oxygen sensor 2 circuit | | | 6 | | 6 | | 6 | 6 | | | 5 | | | EC-220, "DTC Log-ic" EC-226, "DTC Log-ic" EC-234, "DTC Log-ic" |
| Knock sensor circuit | | | 2 | | | | | | | | 3 | | | EC-273, "DTC Log-ic" |
| Engine oil temperature sensor circuit | | | 4 | | 2 | | | | | | 3 | | | EC-262, "DTC Log-ic" |
| Engine oil pressure sensor circuit | | | 4 | | 4 | 3 | 3 | 3 | | | 3 | | | EC-336, "DTC Log-ic" |

A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

ENGINE CONTROL SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HR16DE]

| | SYMPTOM | | | | | | | | | | | | Reference page | |
|---|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|----------------|--|
| | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Crankshaft position sensor circuit | 2 | 2 | | | | | | | | | | | | EC-275, "DTC Log-ic" |
| Camshaft position sensor circuit | 3 | 2 | | | | | | | | | | | | EC-279, "DTC Log-ic" |
| Vehicle speed signal circuit | | 2 | 3 | | 3 | | | | | | 3 | | | EC-329, "DTC Log-ic" |
| ECM | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | | | EC-347, "DTC Log-ic" EC-349, "DTC Log-ic" |
| Intake valve timing control solenoid valve circuit | | 3 | 2 | | 1 | 3 | 2 | 2 | 3 | | 3 | | | EC-164, "DTC Log-ic" |
| Exhaust valve timing control solenoid valve circuit | | 3 | 2 | | 1 | 3 | 2 | 2 | 3 | | 3 | | | EC-168, "DTC Log-ic" |
| PNP signal circuit | | | 3 | | 3 | | 3 | 3 | | | 3 | | | EC-354, "DTC Log-ic" |
| Refrigerant pressure sensor circuit | | 2 | | | | 3 | | | 3 | | 4 | | | EC-450, "Diagnosis Procedure" |
| Electrical load signal circuit | | | | | | | 3 | | | | | | | EC-432, "Diagnosis Procedure" |
| Air conditioner circuit | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | | 3 | | 2 | HAC-31, "Workflow" |
| ABS actuator and electric unit (control unit) | | | 4 | | | | | | | | | | | BRC-50, "Work Flow" |

1 - 6: The numbers refer to the order of inspection.
(continued on next table)

SYSTEM — ENGINE MECHANICAL & OTHER

ENGINE CONTROL SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HR16DE]

| | | SYMPTOM | | | | | | | | | | | | | Reference page | |
|-----------------------|---|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|---------------------------------|----------------------------|---------------------------|-----------------------------|---|---|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATSWATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | BATTERY DEAD (UNDER CHARGE) | | |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | | |
| Fuel | Fuel tank | 5 | 5 | | | | | | | | | | | | FL-13. "Inspection" | |
| | Fuel piping | | | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | FL-9. "Inspection" | |
| | Vapor lock | | | | | | | | | | | | | | | — |
| | Valve deposit | | | | | | | | | | | | | | | — |
| | Poor fuel (Heavy weight gasoline, Low octane) | 5 | | | 5 | 5 | 5 | | 5 | 5 | | | | 5 | | |
| Air | Air duct | | | | | | | | | | | | | | EM-26. "Removal and Installation" | |
| | Air cleaner | | | | | | | | | | | | | | EM-26. "Exploded View" | |
| | Air leakage from air duct (Mass air flow sensor — electric throttle control actuator) | 5 | 5 | 5 | | 5 | | 5 | 5 | | | | 5 | | EM-26. "Exploded View" | |
| | Electric throttle control actuator | 5 | | | 5 | | 5 | | | 5 | | | | | EM-28. "Exploded View" | |
| | Air leakage from intake manifold/Collector/Gasket | | | | | | | | | | | | | | EM-28. "Exploded View" | |
| Crank-ing | Battery | | | | | | | | | | | | | | PG-61. "Work Flow" | |
| | Generator circuit | 1 | 1 | 1 | | 1 | | 1 | 1 | | | | | 1 | CHG-14. "Work Flow (With EXP-800 NI or GR8-1200 NI)" CHG-17. "Work Flow (Without EXP-800 NI or GR8-1200 NI)" | |
| | Starter circuit | 3 | | | | | | | | | | | 1 | | STR-21. "Work Flow (With GR8-1200 NI)" STR-24. "Work Flow (Without GR8-1200 NI)" | |
| | Signal plate | 6 | | | | | | | | | | | | | EM-92. "Exploded View" | |
| | PNP signal | 4 | | | | | | | | | | | | | TM-15. "BACK-UP LAMP SWITCH : Component Inspection" , TM-143. "Diagnosis Procedure" | |

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

ENGINE CONTROL SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HR16DE]

| | | SYMPTOM | | | | | | | | | | | | Reference page | |
|-----------------------|---|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|----------------|---|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | |
| Engine | Cylinder head | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | | 5 | 3 | | EM-79, "Inspection" |
| | Cylinder head gasket | | | | | | | | | | 4 | | | | |
| | Cylinder block | | | | | | | | | | | | 4 | | EM-101, "Inspection" |
| | Piston | | | | | | | | | | | | | | |
| | Piston ring | 6 | 6 | 6 | 6 | 6 | | 6 | 6 | | | 6 | | | |
| | Connecting rod | | | | | | | | | | | | | | |
| | Bearing | | | | | | | | | | | | | | |
| | Crankshaft | | | | | | | | | | | | | | |
| Valve mechanism | Timing chain | | | | | | | | | | | | | | EM-51, "Removal and Installation" |
| | Camshaft | | | | | | | | | | | | | | EM-68, "Inspection" |
| | Intake valve timing control | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | EM-48, "Removal and Installation" |
| | Exhaust valve timing control | | | | | | | | | | | | | | EM-48, "Removal and Installation" |
| | Intake valve | | | | | | | | | | | | 3 | | EM-68, "Inspection" |
| | Exhaust valve | | | | | | | | | | | | | | |
| Exhaust | Exhaust manifold/Tube/Muffler/Gasket | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | EX-4, "Inspection" EM-31, "Removal and Installation" |
| | Three way catalyst | | | | | | | | | | | | | | |
| Lubrication | Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery/Oil cooler | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | | 5 | | | EM-34, "Removal and Installation (Lower Oil Pan)" EM-37, "Removal and Installation (Upper Oil Pan)" LU-10, "Removal and Installation" LU-11, "Removal and Installation" LU-13, "Removal and Installation" |
| | Oil level (Low)/Filthy oil | | | | | | | | | | | | | | LU-7, "Inspection" |

ENGINE CONTROL SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HR16DE]

| | | SYMPTOM | | | | | | | | | | | | Reference page | | |
|--|--|----------------------------------|--------------|------------------------------|------------------------|---------------------------------|--------------------|--------------------|------------------|------------------------|----------------------------------|----------------------------|---------------------------|----------------|--|---|
| | | HARD/NO START/RESTART (EXCP. HA) | ENGINE STALL | HESITATION/SURGING/FLAT SPOT | SPARK KNOCK/DETONATION | LACK OF POWER/POOR ACCELERATION | HIGH IDLE/LOW IDLE | ROUGH IDLE/HUNTING | IDLING VIBRATION | SLOW/NO RETURN TO IDLE | OVERHEATS/WATER TEMPERATURE HIGH | EXCESSIVE FUEL CONSUMPTION | EXCESSIVE OIL CONSUMPTION | | BATTERY DEAD (UNDER CHARGE) | |
| Warranty symptom code | | AA | AB | AC | AD | AE | AF | AG | AH | AJ | AK | AL | AM | HA | | |
| Cooling | Radiator/Hose/Radiator filler cap | | | | | | | | | | | | | | CO-12. "RADIATOR : Inspection" CO-12. "RADIATOR CAP : Inspection" | |
| | Thermostat | | | | | | | | | 5 | | | | | CO-21. "Removal and Installation" | |
| | Water pump | 5 | 5 | 5 | 5 | 5 | | 5 | 5 | | 4 | 5 | | | CO-19. "Removal and Installation" | |
| | Water gallery | | | | | | | | | | | | | | | CO-4. "Engine Cooling System" |
| | Cooling fan | | | | | | | | | | | | | | | CO-17. "Removal and Installation" |
| | Coolant level (Low)/Contaminated coolant | | | | | | | | | | 5 | | | | | CO-8. "Inspection" |
| NATS (NISSAN Vehicle Immobilizer System) | | 1 | 1 | | | | | | | | | | | | SEC-162. "Work Flow" | |

1 - 6: The numbers refer to the order of inspection.

A
EC
C
D
E
F
G
H
I
J
K
L
M
N
O
P

NORMAL OPERATING CONDITION

Description

INFOID:000000009020945

FUEL CUT CONTROL (AT NO LOAD AND HIGH ENGINE SPEED)

If the engine speed is above 2,400 rpm under no load (for example, the shift lever position is neutral and engine speed is over 2,400 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed.

Fuel cut will be operated until the engine speed reaches 2,000 rpm, then fuel cut will be cancelled.

NOTE:

This function is different from deceleration control listed under Multiport Fuel Injection (MFI) System, [EC-32](#). "[MULTIPOINT FUEL INJECTION SYSTEM : System Description](#)".

PERIODIC MAINTENANCE

IDLE SPEED

Inspection

INFOID:000000009020946



1. CHECK IDLE SPEED

With CONSULT

Check idle speed in "DATA MONITOR" mode with CONSULT.

Without CONSULT

Check idle speed by installing the pulse type tachometer clamp on the loop wire or on suitable high-tension wire which installed between No.1 ignition coil and No.1 spark plug.

With GST

Check idle speed with Service \$01 of GST.

>> INSPECTION END

A
C
D
E
F
G
H
I
J
K
L
M
N
O
P

IGNITION TIMING

< PERIODIC MAINTENANCE >

[HR16DE]


IGNITION TIMING

Inspection

INFOID:000000009020947

1. CHECK IGNITION TIMING


1. Attach timing light (A) to loop wire (1) as shown.



2. Check ignition timing.

1 : Timing indicator

>> INSPECTION END



EVAPORATIVE EMISSION SYSTEM

< PERIODIC MAINTENANCE >

[HR16DE]

EVAPORATIVE EMISSION SYSTEM


Inspection

INFOID:000000009020948

1. CHECK EVAP CANISTER

1. Block port (B).
2. Blow air into port (A) and check that it flows freely out of port (C).
3. Release blocked port (B).
4. Apply vacuum pressure to port (B) and check that vacuum pressure exists at the ports (A) and (C).
5. Block port (A) and (B).
6. Apply pressure to port (C) and check that there is no leakage.

>> INSPECTION END



A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

EVAP LEAK CHECK

< PERIODIC MAINTENANCE >

[HR16DE]

EVAP LEAK CHECK

Inspection

INFOID:000000009020949

CAUTION:

- Do not use compressed air or a high pressure pump.
- Do not exceed 4.12 kPa (0.042 kg/cm², 0.6 psi) of pressure in EVAP system.


NOTE:

- Do not start engine.
- Improper installation of EVAP service port adapter [commercial service tool: (J-41413-OBDD)] to the EVAP service port may cause a leak.


1. EVAP LEAK CHECK

Ⓜ With CONSULT

1. Install EVAP service port adapter [commercial service tool: (J-41413-OBDD)] and pressure pump to EVAP service port.
2. Turn ignition switch ON.
3. Select the "EVAP SYSTEM CLOSE" in "WORK SUPPORT" mode of "ENGINE" using CONSULT.
4. Touch "START". A bar graph (Pressure indicating display) will appear on the screen.
5. Apply positive pressure to the EVAP system until the pressure indicator reaches the middle of the bar graph.
6. Remove EVAP service port adapter [commercial service tool: (J-41413-OBDD)] and hose with pressure pump.




7. Locate the leak using a leak detector [commercial service tool: (J-41416)]. Refer to [EC-40, "EVAPORATIVE EMISSION SYSTEM : System Description"](#).



⊗ Without CONSULT

1. Install EVAP service port adapter [commercial service tool: (J-41413-OBDD)] and pressure pump to EVAP service port.
2. Apply battery voltage between the terminals of EVAP canister vent control valve to make a closed EVAP system.
3. To locate the leak, deliver positive pressure to the EVAP system until pressure gauge points reach 1.38 to 2.76 kPa (0.014 to 0.028 kg/cm², 0.2 to 0.4 psi).
4. Remove EVAP service port adapter [commercial service tool: (J-41413-OBDD)] and hose with pressure pump.




EVAP LEAK CHECK

[HR16DE]

< PERIODIC MAINTENANCE >

5. Locate the leak using a leak detector [commercial service tool: (J-41416)]. Refer to [EC-40, "EVAPORATIVE EMISSION SYSTEM : System Description"](#).

>> INSPECTION END



A

EC

C

D

E

F

G

H

I

J

K

L

M

N

O

P

POSITIVE CRANKCASE VENTILATION

< PERIODIC MAINTENANCE >

[HR16DE]

POSITIVE CRANKCASE VENTILATION

Inspection

INFOID:000000009020950


1. CHECK PCV VALVE

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace PCV valve. Refer to [EM-48. "Exploded View"](#).



REMOVAL AND INSTALLATION


ECM

Exploded View

INFOID:000000009020951

A

EC



① ECM bracket

② ECM

↔ : Vehicle front

C

D

E

F

G

H

Removal and Installation

INFOID:000000009020952

CAUTION:

Perform **ADDITIONAL SERVICE WHEN REPLACING ECM**. Refer to [EC-123, "Work Procedure"](#).

REMOVAL

1. Remove fusible link bracket. Keep a service area.
2. Disconnect ECM harness connectors. Refer to [HARNES CONNECTOR \(LEVER LOCKING TYPE\) in PG-53, "Description"](#).
3. Remove ECM mounting nuts, and then remove ECM.

INSTALLATION

Install in the reverse order of removal.

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[HR16DE]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Idle Speed

INFOID:000000009020953

| Transmission | Condition | Specification |
|--------------|--------------------------------|---------------|
| CVT | No load* (in P or N position) | 650 ± 50 rpm |
| M/T | No load* (in Neutral position) | 650 ± 50 rpm |

*: Under the following conditions

- A/C switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Ignition Timing

INFOID:000000009020954

| Transmission | Condition | Specification |
|--------------|--------------------------------|---------------|
| CVT | No load* (in P or N position) | 4 ± 5°BTDC |
| M/T | No load* (in Neutral position) | 10 ± 5°BTDC |

*: Under the following conditions

- A/C switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Calculated Load Value

INFOID:000000009020955

| Condition | Specification (Using CONSULT or GST) |
|--------------|--------------------------------------|
| At idle | 10 – 35% |
| At 2,500 rpm | 10 – 35% |

Mass Air Flow Sensor

INFOID:000000009020956

| | |
|--------------------------------------|--|
| Supply voltage | Battery voltage (11 – 14 V) |
| Output voltage at idle | 0.8 – 1.3 V* |
| Mass air flow (Using CONSULT or GST) | 0.8 – 4.0 g/s at idle* 2.0 – 10.0 g/s at 2,500 rpm* |

*: Engine is warmed up to normal operating temperature and running under no load.