

SECTION **MWI**

METER, WARNING LAMP & INDICATOR

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

CONTENTS

TYPE A	
HOW TO USE THIS MANUAL 5	SHIFT POSITION INDICATOR : System Diagram ...14
APPLICATION NOTICE 5	SHIFT POSITION INDICATOR : System Description14
Information5	HIGH WATER TEMPERATURE WARNING LAMP ...14
PRECAUTION 6	HIGH WATER TEMPERATURE WARNING LAMP : System Description 15
PRECAUTIONS 6	OIL PRESSURE WARNING LAMP15
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"6	OIL PRESSURE WARNING LAMP : System Diagram15
Precaution for Work6	OIL PRESSURE WARNING LAMP : System Description 16
PREPARATION 7	METER ILLUMINATION16
PREPARATION 7	METER ILLUMINATION : System Description16
Special Service Tool7	INFORMATION DISPLAY16
Commercial Service Tools7	INFORMATION DISPLAY : System Diagram16
SYSTEM DESCRIPTION 8	INFORMATION DISPLAY : System Description16
COMPONENT PARTS 8	DIAGNOSIS SYSTEM (COMBINATION METER)18
Component Parts Location8	Diagnosis Description18
Component Description9	CONSULT Function19
SYSTEM10	ECU DIAGNOSIS INFORMATION22
METER SYSTEM10	COMBINATION METER22
METER SYSTEM : System Diagram 10	Reference Value22
METER SYSTEM : System Description 10	Fail-Safe24
METER SYSTEM : Arrangement of Combination Meter 12	DTC Index25
METER SYSTEM : Fail-Safe 12	BCM (BODY CONTROL MODULE)26
SPEEDOMETER13	List of ECU Reference26
SPEEDOMETER : System Description 13	WIRING DIAGRAM27
TACHOMETER13	METER SYSTEM27
TACHOMETER : System Description 14	Wiring Diagram27
SHIFT POSITION INDICATOR14	BASIC INSPECTION38

MWI

DIAGNOSIS AND REPAIR WORKFLOW	38	THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF	51
Work Flow	38	Description	51
DTC/CIRCUIT DIAGNOSIS	39	Diagnosis Procedure	51
U1000 CAN COMM CIRCUIT	39	THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, or DOES NOT DISPLAY	52
DTC Logic	39	Description	52
Diagnosis Procedure	39	Diagnosis Procedure	52
U1010 CONTROL UNIT (CAN)	40	REMOVAL AND INSTALLATION	53
Description	40	COMBINATION METER	53
DTC Logic	40	Removal and Installation	53
Diagnosis Procedure	40	UNIT DISASSEMBLY AND ASSEMBLY ...	54
DTC B2205 VEHICLE SPEED CIRCUIT	41	COMBINATION METER	54
Description	41	Exploded View	54
DTC Logic	41	Disassembly and Assembly	54
Diagnosis Procedure	41	TYPE B	
B2267 ENGINE SPEED	42	HOW TO USE THIS MANUAL	55
Description	42	APPLICATION NOTICE	55
DTC Logic	42	Information	55
Diagnosis Procedure	42	PRECAUTION	56
B2268 WATER TEMP	43	PRECAUTIONS	56
Description	43	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	56
DTC Logic	43	Precaution for Work	56
Diagnosis Procedure	43	PREPARATION	57
POWER SUPPLY AND GROUND CIRCUIT	44	PREPARATION	57
COMBINATION METER	44	Special Service Tool	57
COMBINATION METER : Diagnosis Procedure ...	44	Commercial Service Tools	57
BCM (BODY CONTROL MODULE)	44	SYSTEM DESCRIPTION	58
BCM (BODY CONTROL MODULE) : Diagnosis Procedure	45	COMPONENT PARTS	58
FUEL LEVEL SENSOR SIGNAL CIRCUIT	46	Component Parts Location	58
Description	46	Component Description	59
Component Function Check	46	SYSTEM	60
Diagnosis Procedure	46	METER SYSTEM	60
Component Inspection	47	METER SYSTEM : System Diagram	60
WASHER FLUID LEVEL SWITCH CIRCUIT ...	48	METER SYSTEM : System Description	60
Description	48	METER SYSTEM : Arrangement of Combination Meter	62
Diagnosis Procedure	48	METER SYSTEM : Fail-Safe	62
Component Inspection	48	SPEEDOMETER	63
SYMPTOM DIAGNOSIS	49	SPEEDOMETER : System Diagram	63
THE FUEL GAUGE INDICATOR DOES NOT OPERATE	49	SPEEDOMETER : System Description	63
Description	49	TACHOMETER	63
Diagnosis Procedure	49		
THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON	50		
Description	50		
Diagnosis Procedure	50		

TACHOMETER : System Diagram	64	Diagnosis Procedure	91	A
TACHOMETER : System Description	64	B2267 ENGINE SPEED	92	B
SHIFT POSITION INDICATOR	64	Description	92	
SHIFT POSITION INDICATOR : System Diagram...	64	DTC Logic	92	
SHIFT POSITION INDICATOR : System Description	64	Diagnosis Procedure	92	
OIL PRESSURE WARNING LAMP	64	B2268 WATER TEMP	93	C
OIL PRESSURE WARNING LAMP : System Diagram	64	Description	93	
OIL PRESSURE WARNING LAMP : System Description	64	DTC Logic	93	
METER ILLUMINATION CONTROL	64	Diagnosis Procedure	93	
METER ILLUMINATION CONTROL : System Diagram	65	POWER SUPPLY AND GROUND CIRCUIT	94	D
METER ILLUMINATION CONTROL : System Description	65	COMBINATION METER	94	E
INFORMATION DISPLAY	65	COMBINATION METER : Diagnosis Procedure	94	
INFORMATION DISPLAY : System Diagram	65	BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM)	94	F
INFORMATION DISPLAY : System Description	65	BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM) : Diagnosis Procedure	95	
DIAGNOSIS SYSTEM (COMBINATION METER)	68	BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM)	95	G
Diagnosis Description	68	BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) : Diagnosis Procedure	95	
CONSULT Function	69	FUEL LEVEL SENSOR SIGNAL CIRCUIT	97	H
ECU DIAGNOSIS INFORMATION	72	Description	97	I
COMBINATION METER	72	Component Function Check	97	
Reference Value	72	Diagnosis Procedure	97	J
Fail-Safe	75	Component Inspection	98	
DTC Index	75	WASHER FLUID LEVEL SWITCH CIRCUIT	99	K
BCM (BODY CONTROL MODULE)	76	Description	99	
List of ECU Reference	76	Diagnosis Procedure	99	
WIRING DIAGRAM	77	Component Inspection	99	
METER SYSTEM	77	SYMPTOM DIAGNOSIS	100	L
Wiring Diagram	77	THE FUEL GAUGE INDICATOR DOES NOT OPERATE	100	M
BASIC INSPECTION	88	Description	100	
DIAGNOSIS AND REPAIR WORKFLOW	88	Diagnosis Procedure	100	
Work Flow	88	THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON	101	MWI
DTC/CIRCUIT DIAGNOSIS	89	Description	101	
U1000 CAN COMM CIRCUIT	89	Diagnosis Procedure	101	
DTC Logic	89	THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF	102	O
Diagnosis Procedure	89	Description	102	
U1010 CONTROL UNIT (CAN)	90	Diagnosis Procedure	102	P
Description	90	THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, or DOES NOT DISPLAY	103	
DTC Logic	90	Description	103	
Diagnosis Procedure	90	Diagnosis Procedure	103	
DTC B2205 VEHICLE SPEED CIRCUIT	91			
Description	91			
DTC Logic	91			

REMOVAL AND INSTALLATION	104	UNIT DISASSEMBLY AND ASSEMBLY ..	105
COMBINATION METER	104	COMBINATION METER	105
Removal and Installation	104	Exploded View	105
		Disassembly and Assembly	105

APPLICATION NOTICE

< HOW TO USE THIS MANUAL >



[TYPE A]

HOW TO USE THIS MANUAL

APPLICATION NOTICE

Information

INFOID:000000009266559

Service information	Design of combination meter
TYPE A	
TYPE B	

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009266560

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:000000009645417

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[TYPE A]


PREPARATION

PREPARATION

Special Service Tool


INFOID:000000009601587

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
<p>— (J-46534) Trim Tool Set</p>  <p style="text-align: center;">AWJIA0483ZZ</p>	<p>Removing trim components</p>

Commercial Service Tools

INFOID:000000009266561

Tool name	Description
<p>Power tool</p>  <p style="text-align: center;">PIIB1407E</p>	<p>Loosening nuts, screws and bolts</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMPONENT PARTS

< SYSTEM DESCRIPTION >













[TYPE A]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009266562



AWNIA2714ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[TYPE A]

- | | | | |
|--|--|---|---|
| 1. ABS actuator and electric unit (control unit) | 2. Combination meter | 3. CVT shift selector (O/D OFF switch) (with CVT)
A/T shift selector (O/D OFF switch) (with A/T) | A |
| 4. Air bag diagnosis sensor unit (view with center console removed) | 5. Parking brake switch (view with center console removed) | 6. Seat belt buckle switch LH | B |
| 7. Fuel level sensor unit and fuel pump (view with rear seat and access cover removed) | 8. Front door switch LH | 9. BCM (view with instrument panel removed) | C |
| 10. EPS control unit (view with instrument lower panel removed) | 11. Brake fluid level switch (view with IPDM E/R removed) | 12. ECM (view with IPDM E/R removed) | D |
| 13. TCM | 14. Oil pressure sensor | 15. Washer fluid level switch (if equipped) | E |

Component Description

INFOID:000000009266563

Unit	Description
Combination meter	The combination meter controls the following items according to the signals received from each unit. <ul style="list-style-type: none"> • Speedometer • Engine oil pressure gauge • Warning lamps • Information display • Oil pressure sensor signal • Tachometer • Fuel gauge • Indicator lamps • Warning chime
CVT shift selector (O/D OFF switch) (with CVT) A/T shift selector (O/D OFF switch) (with A/T)	Transmits the overdrive off switch signal to the combination meter.
Seat belt buckle switch (LH)	Transmits the seat belt buckle switch (LH) signal to the combination meter.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the combination meter via CAN communication.
Air bag diagnosis sensor unit	Transmits the air bag signal and seat belt buckle switch (RH) signal to the combination meter.
EPS Control unit	Transmits the EPS signal to the combination meter via CAN communication.
TCM	Transmits the shift position signal to the combination meter via CAN communication.
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Engine speed signal • Engine coolant temperature signal • Fuel consumption monitor signal • Oil pressure sensor signal
BCM	Transmits the security signal to the combination meter. Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Low tire pressure warning signal • Door open switch signal
Washer fluid level switch (if equipped)	Transmits the washer fluid level switch signal to the combination meter.
Fuel level sensor unit	Transmits the fuel level sensor signal to the combination meter.
Parking brake switch	Transmits the parking brake switch signal to the combination meter.
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
TCM	Transmits the shift position signal to the combination meter via CAN communication.
Oil pressure sensor	Transmits the oil pressure sensor signal to the ECM.


SYSTEM

METER SYSTEM

METER SYSTEM : System Diagram

INFOID:000000009266564

SYSTEM DIAGRAM



METER SYSTEM : System Description

INFOID:000000009266565

COMBINATION METER

Combination Meter

- The combination meter monitors signals from switches, sensors and modules to control the following functions:
 - Speedometer/Tachometer
 - Shift position indicator
 - Warning lamps
 - Indicator lamps
 - Meter illumination control
 - Information display
- The combination meter has an integrated buzzer that is activated when it receives a signal from the BCM via CAN communication. Refer to [WCS-7. "WARNING CHIME SYSTEM : System Description"](#) for further details.
- The combination meter includes a self diagnosis function.
- The combination meter can be diagnosed with CONSULT.

METER CONTROL FUNCTION LIST

System	Description	Reference
Speedometer	Indicates vehicle speed.	MWI-13
Tachometer	Indicates engine speed.	MWI-14
Shift position indicator (with CVT or A/T)	Display shift position.	MWI-14

SYSTEM

< SYSTEM DESCRIPTION >

[TYPE A]

System		Description	Reference	
Warning lamp/ indicator lamp	Oil pressure warning lamp	The warning lamp turns ON when it receives the oil pressure warning signal.	MWI-15	
	Seat belt warning lamp	The warning lamp turns ON when the LH seat belt is unfastened and the vehicle is moving, and turns OFF when the seat belt is fastened.	SRC-11	
	High temperature warning lamp	The ECM monitors the engine coolant temperature sensor and sends a signal to the combination meter to turn on the high temperature warning lamp via CAN communication.	MWI-15	
Meter illumination control	Meter illumination control function	Illumination control is enabled when the combination switch (lighting switch) is in the 1st or 2nd position changing from daytime mode to nighttime mode.	MWI-16	
	Meter illumination control switch	The operation of the illumination control switch changes the brightness of meter illumination.		
Information display	Fuel gauge	Indicates fuel level.	MWI-16	
	Odo/trip meter	Displays mileage.		
	Trip computer	Instant fuel consumption		Displays current fuel consumption.
		Average fuel consumption		Displays average fuel consumption.
	Distance to empty	Displays distance to empty.		

A
B
C
D
E
F
G
H
I
J
K
L
M

MWI

O
P


SYSTEM

< SYSTEM DESCRIPTION >

[TYPE A]

METER SYSTEM : Arrangement of Combination Meter

INFOID:00000009266566



METER SYSTEM : Fail-Safe

INFOID:00000009266567

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

SYSTEM

< SYSTEM DESCRIPTION >

[TYPE A]


Function		Specifications	
Speedometer		Reset to zero by suspending communication.	
Tachometer			
Meter Illumination		When suspending communication, changes to nighttime mode.	
Information display	Trip computer	Instant fuel consumption	0 km/h is displayed.
		Average fuel consumption	<ul style="list-style-type: none"> When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result. When reception time of an abnormal signal is more than 2 seconds, the last result calculated during normal condition is indicated.
		Distance to empty	
	Odo/trip meter	An indicated value is maintained at communications blackout.	
	Shift position indicator	The indicator turns OFF by suspending communication.	
Buzzer		The buzzer turns off by suspending communication.	
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns ON by suspending communication.	
	EPS warning lamp		
	Brake warning lamp		
	Malfunction indicator lamp (MIL)		
	High water temperature warning lamp	The lamp turns OFF by suspending communication.	
	High beam indicator lamp		
	Turn signal indicator lamp		
	Door warning lamp		
	Oil pressure warning lamp		
	O/D OFF indicator lamp		

SPEEDOMETER

SPEEDOMETER : System Description

INFOID:000000009266568

SYSTEM DIAGRAM



DESCRIPTION

The ABS actuator and electric unit (control unit) receives each wheel speed sensor signal and provides a vehicle speed signal to the combination meter via CAN communication.

TACHOMETER

SYSTEM


< SYSTEM DESCRIPTION >

[TYPE A]

TACHOMETER : System Description

INFOID:000000009266569

SYSTEM DIAGRAM



DESCRIPTION


The crank position sensor sends a crankshaft position signal to the ECM. The ECM provides an engine speed signal to the combination meter via CAN communication lines. The tachometer indicates engine speed in revolutions per minute (rpm).

SHIFT POSITION INDICATOR


SHIFT POSITION INDICATOR : System Diagram

INFOID:000000009266570

WITH CVT



WITH A/T



SHIFT POSITION INDICATOR : System Description

INFOID:000000009266571

DESCRIPTION

The combination meter receives the shift position signal from TCM via CAN communication, and displays the position of the shift indicator.

HIGH WATER TEMPERATURE WARNING LAMP

SYSTEM


< SYSTEM DESCRIPTION >

[TYPE A]

HIGH WATER TEMPERATURE WARNING LAMP : System Description

INFOID:000000009266572


SYSTEM DIAGRAM



DESCRIPTION

The ECM monitors the engine coolant temperature from the engine coolant temperature sensor. When the coolant temperature is above the specified value, the ECM sends a CAN communication signal to the combination meter turning on the high temperature warning lamp.

Timing Chart




OIL PRESSURE WARNING LAMP

MWI

OIL PRESSURE WARNING LAMP : System Diagram

INFOID:000000009266573

SYSTEM DIAGRAM



SYSTEM

< SYSTEM DESCRIPTION >

[TYPE A]

OIL PRESSURE WARNING LAMP : System Description

INFOID:000000009266574

DESCRIPTION


The combination meter turns the oil pressure warning lamp ON when receiving a signal from the ECM via CAN communication.

METER ILLUMINATION

METER ILLUMINATION : System Description

INFOID:000000009266575

SYSTEM DIAGRAM



DESCRIPTION

Meter Illumination Control Function


Meter illumination control is enabled when the meter receives a signal from the BCM that the combination switch is in the 1st or 2nd position, the meter switches from Daytime mode to Nighttime mode.

	Condition	Meter illumination
Combination switch (lighting switch)	1ST or 2ND position	Nighttime mode
	Off	Daytime mode

INFORMATION DISPLAY

INFORMATION DISPLAY : System Diagram

INFOID:000000009266576



INFORMATION DISPLAY : System Description

INFOID:000000009266577

DESCRIPTION

- The combination meter receives signals from switches, sensors and modules for operating the following functions on the information display.
 - Odo/trip meter
 - Fuel gauge

SYSTEM

< SYSTEM DESCRIPTION >

[TYPE A]

- Trip computer
- Interrupt indication
- Meter illumination level
- Setting
- Low fuel warning
- Loose fuel cap warning

ODO/TRIP METER

The combination meter calculates mileage using the vehicle speed signal from the ABS actuator and electric unit (control unit) and displays the mileage on the information display.

FUEL GAUGE


Control Outline

The fuel level sensor unit sends a variable resistor signal to the combination meter. The fuel gauge indicates the approximate fuel level in the fuel tank.

Refuel Control

The unit detects the driver is refueling the vehicle and accelerates the fuel gauge segment movement if the fuel level changes by 9 ℓ (2-3/8 US, 2 Imp gal) or more.

Lighting segment-resistance relationship



INTERRUPT INDICATION

The combination meter may interrupt the current information display with a warning, alert or maintenance reminder on the information display, based on signals received from each unit and switch.

Low Fuel Warning

The low fuel warning turns ON when the fuel level in the fuel tank reaches approximately 6.3 ℓ (1-5/8 US gal, 1-3/8 Imp gal).

LOOSE FUEL CAP WARNING

The LOOSE FUEL CAP message will display in the information display when the fuel-filler cap is not tightened correctly. The message will turn off as soon as the ECM detects the fuel-filler cap is properly tightened. The ECM provides a loose fuel cap signal to the combination meter via CAN communication lines.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

[TYPE A]

DIAGNOSIS SYSTEM (COMBINATION METER)

Diagnosis Description

INFOID:000000009266578


ON BOARD DIAGNOSIS ITEM


The information display, speedometer and tachometer can be checked in self-diagnosis mode.


NOTE:


- Check combination meter power supply and ground circuits if self-diagnosis mode does not start. Refer to [MWI-94, "COMBINATION METER : Diagnosis Procedure"](#). Replace combination meter if power supply and ground circuits are found to be normal and self-diagnosis mode does not start. Refer to [MWI-104, "Removal and Installation"](#).
- Combination meter self-diagnosis mode will function with the ignition switch in ON. Combination meter self-diagnosis mode will exit upon turning the ignition switch to OFF.

METHOD OF STARTING

1. Turn the ignition switch OFF.
2. Turn the ignition switch ON while pressing and holding the  switch (1) for 0.8 seconds or more.




3. Press the  switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON.)
4. The combination meter is turned to self-diagnosis mode.
 - All segments of the information display are displayed.




DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

[TYPE A]

5. Each meter activates by pressing the  switch.



NOTE:

- If any of the meters or gauges is not activated, replace combination meter.
- The figure is reference.

CONSULT Function

INFOID:000000009266579

APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown.

METER/M&A Diagnosis mode	Description
SELF DIAGNOSTIC RESULT	The combination meter self-diagnosis results.
DATA MONITOR	Displays combination meter input/output data in real time.
SPECIAL FUNCTION	Lighting history of the warning lamp and indicator lamp can be checked.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

SELF DIAG RESULT

Refer to [MWI-75, "DTC Index"](#).

DATA MONITOR

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h] or [mph]	X	Displays the value of vehicle speed signal.
SPEED OUTPUT [km/h] or [mph]	X	Displays the value of vehicle speed signal, which is transmitted to each unit with CAN communication.
ODO OUTPUT [km/h or mph]		Displays odometer signal value transmitted to other units via CAN communication.
TACHO METER [rpm]	X	Displays the value of engine speed signal, which is input from ECM.
FUEL METER [L]	X	Displays the fuel level.
W TEMP METER [°C] or [°F]	X	Displays the value of engine coolant temperature signal, which is input from ECM.
ABS W/L [ON/OFF]		Displays [ON/OFF] condition of ABS warning indicator

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

[TYPE A]

Display item [Unit]	MAIN SIGNALS	Description
BRAKE W/L [ON/OFF]		Displays [ON/OFF] condition of brake warning indicator.
DOOR W/L [ON/OFF]		Displays [ON/OFF] condition of door warning indicator.
HI-BEAM IND [ON/OFF]		Displays [ON/OFF] condition of high beam indicator.
TURN IND [ON/OFF]		Displays [ON/OFF] condition of turn indicator.
LIGHT IND [ON/OFF]		Displays [ON/OFF] condition of light indicator.
OIL W/L [ON/OFF]		Displays [ON/OFF] condition of oil pressure warning indicator.
MIL [ON/OFF]		Displays [ON/OFF] condition of malfunction indicator.
CRUISE IND [Off]		Displays [ON/OFF] condition of CRUISE indicator.
O/D OFF IND [ON/OFF]		Displays [ON/OFF] condition of O/D OFF indicator.
FUEL W/L [ON/OFF]		Displays [ON/OFF] condition of low-fuel warning indicator.
O/D OFF SW [ON/OFF]		Displays [ON/OFF] condition of O/D OFF switch.
REAR DEF SW [ON/OFF]		Displays [ON/OFF] condition of rear window defogger switch.
BRAKE SW [ON/OFF]		Displays [ON/OFF] condition of brake switch.
EPS W/L [ON/OFF]		Displays [ON/OFF] condition of EPS indicator.
CHAGE W/L [Off]		Displays [ON/OFF] condition of charge warning indicator.
SHIFT IND		Displays shift selector position.
FUEL CAP W/L [Off]		Displays [ON/OFF] condition of loose fuel cap warning message.
AIR PRES W/L [ON/OFF]		Displays [ON/OFF] condition of tire pressure warning lamp.
PKB SW [ON/OFF]		Status of parking brake switch.
BUCKLE SW [ON/OFF]		Status of seat belt buckle switch (LH).
PASS BUCKLE SW [ON/OFF]		Status of passenger seat belt buckle switch (RH).
BRAKE OIL SW [ON/OFF]		Status of brake fluid level switch.
DISTANCE [km] or [Mi]		Displays distance to empty.
BUZZER [ON/OFF]	X	Displays [ON/OFF] condition of buzzer.
SLIP IND [ON/OFF]		Displays [ON/OFF] condition of SLIP indicator lamp.
VDC/TCS IND [ON/OFF]		Displays [ON/OFF] condition of VDC OFF indicator lamp.

NOTE:

DIAGNOSIS SYSTEM (COMBINATION METER)

[TYPE A]

< SYSTEM DESCRIPTION >

Some items are not available according to vehicle specification.

SPECIAL FUNCTION

Special menu

Display item	Description
W/L ON HISTORY	Lighting history of warning lamp and indicator lamp can be checked.

W/L ON HISTORY

- Stores histories when warning/indicator lamp is turned on.
- “W/L ON HISTORY” indicates the “TIME” when the warning/ indicator lamp is turned on.
- The “TIME” above is:
 - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
 - 1 - 39: The number of times the engine was restarted after the 0 condition.
 - NO W/L ON HISTORY: Stores NO (0) turning on history of warning/indicator lamp.

NOTE:

- W/L ON HISTORY is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

Display Item

Display item	Description
ABS W/L	Lighting history of ABS warning lamp.
VDC/TCS IND	Lighting history of VDC warning lamp.
SLIP IND	Lighting history of SLIP warning lamp.
BRAKE W/L	Lighting history of brake warning lamp.
OIL W/L	Lighting history of oil pressure warning lamp.
C-ENG W/L	Lighting history of malfunction indicator lamp (MIL).
AIR PRES W/L	Lighting history of tire pressure warning lamp.
EPS W/L	Lighting history of EPS warning lamp.
CHAGE W/L	Lighting history of charging warning lamp.
DOOR W/L	Lighting history of door warning lamp.
CRUISE W/L	Lighting history of cruise warning lamp.
O/D OFF IND	Lighting history of O/D OFF indicator lamp.
FUEL W/L	Lighting history of fuel warning lamp.
WASHER W/L	Lighting history of washer warning lamp.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[TYPE A]

ECU DIAGNOSIS INFORMATION

COMBINATION METER

Reference Value

INFOID:000000009266580

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Display content	Data monitor	
		Condition	Reference value in normal operation
SPEED METER [km/h or mph]	Speed meter operation	While driving	Vehicle speed matches speed meter
SPEED OUTPUT [km/h or mph]	Vehicle speed	While driving	The speed output signal value matches speed meter via CAN communication.
ODO OUTPUT [km/h or mph]	ODO meter operation	Driving	Distance driven
TACHO METER [rpm]	Tacho meter operation	Engine running	The tacho meter is approx. value of engine speed via CAN communication.
FUEL METER [L]	Fuel level	Ignition ON	Fuel level in fuel tank is approx.
W TEMP METER [°C] or [°F]	Engine coolant temperature	Engine running	Input value of engine coolant temperature signal via CAN communication.
ABS W/L	ABS warning lamp	When ABS warning lamp is ON	On
		When ABS warning lamp is OFF	Off
BRAKE W/L	Brake warning lamp	When Brake warning lamp is ON	On*
		When Brake warning lamp is OFF	Off
DOOR W/L	Door open warning lamp	When Door warning lamp is ON	On
		When Door warning lamp is OFF	Off
HI-BEAM IND	HI-Beam indicator lamp	When High-beam indicator lamp is ON	On
		When High-beam indicator lamp is OFF	Off
TURN IND	Turn signal indicator	When Turn signal indicator lamp is ON	On
		When Turn signal indicator lamp is OFF	Off
LIGHT IND	Light indicator	When Tail lamp indicator lamp is ON	On
		When Tail lamp indicator lamp is OFF	Off
OIL W/L	Oil pressure warning light	When Oil pressure warning lamp is ON	On
		When Oil pressure warning lamp is OFF	Off
MIL	MIL warning lamp	When Malfunction indicator lamp (MIL) is ON	On
		When Malfunction indicator lamp (MIL) is OFF	Off
CRUISE IND	Cruise indicator lamp	When cruise indicator lamp is ON.	On
		When cruise indicator lamp is OFF.	Off
O/D OFF IND	O/D OFF indicator	When the O/D OFF indicator lamp is OFF.	Off
		When the O/D OFF indicator lamp is OFF.	On
O/D OFF SW	O/D OFF switch	When the O/D OFF switch is pressed to OFF.	Off
		When the O/D OFF switch is pressed to ON.	On

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[TYPE A]

Monitor Item	Display content	Data monitor	
		Condition	Reference value in normal operation
REAR DEF SW	Rear defogger switch	When rear defogger switch is pressed to ON	On
		When rear defogger switch is pressed to Off	Off
BRAKE SW	Brake switch	When brake pedal is applied	On
		When brake pedal is released	Off
FUEL W/L	Low fuel warning	When low fuel warning is ON	On
		When low fuel warning is OFF	Off
EPS W/L	EPS warning lamp	EPS warning lamp ON	On
		EPS warning lamp OFF	Off
CHAGE W/L	Charge warning lamp	Engine running	Off
SHIFT IND	Shift position indicator	The shift position indicator displayed.	[P, R, N, D, L] (CVT) [P, R, N, D, 2, 1] (A/T)
FUEL CAP W/L	Loose fuel cap warning	When the fuel-filler cap is installed incorrectly.	On
		When the fuel-filler cap is installed correctly.	Off
AIR PRES W/L	Tire pressure warning lamp operation	When tire pressure warning lamp is ON	On
		When tire pressure warning lamp is OFF	Off
PKB SW	Parking brake switch	When parking brake is active	On
		When parking brake is inactive	Off
BUCKLE SW	Seat belt buckle switch LH	When seat belt buckle is unfastened (LH).	On
		When seat belt buckle is fastened (LH).	Off
BRAKE OIL SW	Brake fluid level switch	When brake fluid level switch ON	On
		When brake fluid level switch OFF	Off
PASS BUCKLE SW	Seat belt buckle switch RH	When passenger seat is occupied and seat belt buckle is unfastened (RH).	On
		When passenger seat is unoccupied and seat belt buckle is unfastened (RH).	Off
DISTANCE	Distance to empty	While driving	[km/h or mph]
BUZZER	Buzzer operation	When Buzzer is ON	On
		When Buzzer is OFF	Off
SLIP IND	Slip indicator lamp	When SLIP indicator lamp is ON.	On
		When SLIP indicator lamp is OFF.	Off
VDC/TCS IND	VDC indicator lamp	When VDC indicator lamp is ON.	On
		When VDC indicator lamp is OFF	Off

*: Displays "OFF" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.

NOTE:


Some items are not available according to vehicle specification.

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[TYPE A]

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No.	Wire color	Item	Condition		Reference value (V) (Approx.)
			Ignition switch	Operation or condition	
1	R	Battery power supply	OFF		Battery voltage
2	LG	Stop lamp switch	ON	Brake pedal pressed	Battery voltage
				Brake pedal released	0
3	GR	Ignition switch ON or START	ON	—	Battery voltage
4	W	Fuel level sensor signal (+)	—	—	Refer to MWI-98, "Component Inspection" .
8	L	CAN-H	—	—	—
10	P	CAN-L	—	—	—
11	V	Washer fluid level switch (Canada models)	ON	Washer fluid level low	0
				Washer fluid level normal	Battery voltage
19	B	Illumination control output	—	—	—
21	B	Ground	—	—	0
22	B				
23	B/W				
26	GR	Fuel level sensor ground (-)	—	—	0
28	P	O/D OFF switch	ON	O/D OFF switch pressed	0
				O/D OFF switch released	Battery voltage
31	G	Security	—	—	—
32	V	Air bag	ON	—	0
33	G	Seat belt buckle switch RH	ON	Fastened (OFF)	Battery voltage
				Unfastened (ON)	0
34	V	Seat belt buckle switch LH	ON	Fastened (OFF)	Battery voltage
				Unfastened (ON)	0
35	Y	Generator	ON	Generator voltage low	0
				Generator voltage normal	Battery voltage
36	LG	Brake fluid level switch	ON	Brake fluid level is normal	Battery voltage
				Brake fluid level low	0
37	SB	Parking brake switch	ON	Parking brake pedal applied	0
				Parking brake pedal released	Battery voltage

Fail-Safe

INFOID:000000009266581

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[TYPE A]

Function		Specifications	
Speedometer		Reset to zero by suspending communication.	
Tachometer			
Meter Illumination		When suspending communication, changes to nighttime mode.	
Information display	Trip computer	Instant fuel consumption	0 km/h is displayed.
		Average fuel consumption	<ul style="list-style-type: none"> • When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result. • When reception time of an abnormal signal is more than 2 seconds, the last result calculated during normal condition is indicated.
		Distance to empty	
	Odo/trip meter		An indicated value is maintained at communications blackout.
	Shift position indicator		The indicator turns OFF by suspending communication.
Buzzer		The buzzer turns off by suspending communication.	
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns ON by suspending communication.	
	EPS warning lamp		
	Brake warning lamp		
	Malfunction indicator lamp (MIL)		
	High water temperature warning lamp	The lamp turns OFF by suspending communication.	
	High beam indicator lamp		
	Turn signal indicator lamp		
	Door warning lamp		
	Oil pressure warning lamp		
	O/D OFF indicator lamp		

DTC Index

INFOID:000000009266582

Display contents of CONSULT	Diagnostic item is detected when...	Refer to
CAN COMM CIRCUIT [U1000]	When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more.	MWI-39
CONTROL UNIT (CAN) [U1010]	When detecting error during the initial diagnosis of the CAN controller of combination meter.	MWI-40
VEHICLE SPEED [B2205]	The abnormal vehicle speed signal is input from the ABS actuator and electric unit (control unit) for 2 seconds or more.	MWI-41
ENGINE SPEED [B2267]	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	MWI-42
WATER TEMP [B2268]	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	MWI-43

MWI

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[TYPE A]

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:000000009266583

ECU	Reference
BCM	BCS-93. "Reference Value"
	BCS-107. "Wiring Diagram"
	BCS-104. "Fail-safe"
	BCS-104. "DTC Inspection Priority Chart"
	BCS-105. "DTC Index"

METER SYSTEM

< WIRING DIAGRAM >


[TYPE A]

WIRING DIAGRAM

METER SYSTEM

Wiring Diagram

INFOID:000000009266584



ABNWA1771GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< WIRING DIAGRAM >

[TYPE A]

- <AS> : WITH ASCD
- <TW> : WITH TIRE PRESSURE MONITOR SYSTEM
- <WI> : WITH IMMOBILIZER




ABNWA1772GB

METER SYSTEM

< WIRING DIAGRAM >

[TYPE A]

- ◁ A ▷ : WITH AT
- ◁ AD ▷ : WITH AT OR CVT
- ◁ N ▷ : FOR CANADA
- ◁ VT ▷ : WITH CVT




ABNWA1535GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI


METER CONNECTORS - TYPE A

Connector No.	M10
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-
6	L	-
7	L	-
13	P	-
14	P	-
16	P	-
17	P	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	P	-

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	V	-
5	GR	-
6	W	-
15	W	-
16	LG	-
17	P	-
18	SB	-

Connector No.	M17
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	SB	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	P	DOOR SW (AS)
13	LG	DOOR SW (RR)
23	G	SECURITY INDICATOR OUTPUT
39	L	CAN-H
40	P	CAN-L

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
42	P	TR ROOM LAMP SW
47	SB	DOOR SW (DR)
48	W	DOOR SW (RL)

METER SYSTEM


< WIRING DIAGRAM >

[TYPE A]

Terminal No.	Color of Wire	Signal Name
25	-	-
26	GR	FUEL GND
27	-	-
28	P	O/D OFF/SPORT SW
29	-	-
30	-	-
31	G	SECURITY
32	V	AVBAG
33	G	AS BUCKLE SW
34	V	DR BUCKEL SW
35	Y	CHG
36	LG	BRAKE OIL SW
37	SB	PKB
38	-	-
39	-	-
40	-	-


Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
9	-	-
10	P	CAN-L
11	V	WASHER SW
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-
18	-	-
19	B	ILL CONT OUTPUT
20	-	-
21	B	GND (POWER)
22	B	GND (CIRCUIT)
23	B/W	GND (ILL)
24	-	-

Connector No.	M24
Connector Name	COMBINATION METER (WITH TYPE A)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	BAT
2	LG	BRAKE SW
3	GR	IGN
4	W	FUEL SIG
5	-	-
6	-	-
7	-	-


Connector No.	M38
Connector Name	CVT SHIFT SELECTOR
Connector Color	WHITE



Connector No.	M37
Connector Name	A/T SHIFT SELECTOR
Connector Color	WHITE



Connector No.	M35
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
1	P	-
2	B/W	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	B/W	-

Terminal No.	Color of Wire	Signal Name
23	V	AIRBAG W/L
24	G	SEATBELT REMINDER

ABN1A4542GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< WIRING DIAGRAM >


[TYPE A]

Connector No.	M53
Connector Name	EPS CONTROL UNIT
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	CAN-L
2	L	CAN-H

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17A	Y	-
18A	LG	-
20A	P	-
21A	L	-
29A	V	-

Connector No.	E7
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17A	V	-
18A	LG	-
20A	P	-
21A	L	-
29A	R	-

METER SYSTEM

< WIRING DIAGRAM >


[TYPE A]

Connector No.	E16
Connector Name	ECM
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
83	P	CAN-L
84	L	CAN-H

Connector No.	E14
Connector Name	JOINT CONNECTOR-E03
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-
4	P	-
5	P	-
8	L	-
9	L	-
10	L	-
11	L	-
12	L	-

Connector No.	E8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
19	V	-

Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
61	P	CAN-L
62	L	CAN-H

Connector No.	E40
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-

Connector No.	E33
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

ABNIA3815GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



METER SYSTEM

< WIRING DIAGRAM >

[TYPE A]

Connector No.	F4
Connector Name	GENERATOR
Connector Color	-




Terminal No.	Color of Wire	Signal Name
5	B/GR	-

Connector No.	F1
Connector Name	GENERATOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	L/W	-

Connector No.	E50
Connector Name	WASHER FLUID LEVEL SWITCH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	F38
Connector Name	ENGINE OIL PRESSURE SENSOR
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	O	-
2	Y	-
3	L	-

Connector No.	F11
Connector Name	ECM
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
47	Y	ENGINE OIL PRESSURE SENSOR
60	L	SENSOR GROUND
74	O	SENSOR GROUND

Connector No.	F8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
19	L/W	-

ABNIA4569GB

METER SYSTEM

< WIRING DIAGRAM >


[TYPE A]

Connector No.	B6
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-

Connector No.	F57
Connector Name	TCM (TRANSMISSION CONTROL MODULE) (WITH AT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

Connector No.	F44
Connector Name	TCM (TRANSMISSION CONTROL MODULE) (WITH CVT)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

Connector No.	B13
Connector Name	SEAT BELT BUCKLE SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-

Connector No.	B9
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
30	O	LH SEAT BELT BUCKLE SWITCH (+)

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	LG	-

ABNIA3810GB

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

METER SYSTEM

< WIRING DIAGRAM >


[TYPE A]

Connector No.	B20
Connector Name	TRUNK LID SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	B	-

Connector No.	B17
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	B37
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
29	O	RH SEAT BELT BUCKLE SWITCH (+)

Connector No.	B29
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	P	-

Connector No.	B24
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	O	-
5	P	-
6	R	-
15	V	-
16	R	-
17	L	-
18	LG	-

ABNIA3811GB

METER SYSTEM

< WIRING DIAGRAM >

[TYPE A]


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

Connector No.	B45
Connector Name	SEAT BELT BUCKLE SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-

Connector No.	B44
Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	R	-
5	P	-

MWI

ABNIA3816GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009266585

OVERALL SEQUENCE



DETAILED FLOW

1.CONFIRM SYMPTOM

Confirm symptom or customer complaint.

>> GO TO 2

2.SELF-DIAGNOSIS OF COMBINATION METER

Perform self-diagnosis of combination meter. Refer to [MWI-18, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> GO TO 3

NO >> If self-diagnosis will not start, check power supply and ground circuit of combination meter. Refer to [MWI-44, "COMBINATION METER : Diagnosis Procedure"](#). If power supply and ground circuits are OK, replace combination meter. Refer to [MWI-53, "Removal and Installation"](#).

3.CHECK COMBINATION METER WITH CONSULT

Select "METER/M&A" on CONSULT and perform self-diagnosis of combination meter. Refer to [MWI-19, "CONSULT Function"](#).

Is the inspection result normal?

YES >> Check symptom. GO TO 4.

NO >> Refer to [MWI-25, "DTC Index"](#).

4.CHECK SYSTEM OPERATION

Check the combination meter to verify that the repair has been completed successfully.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 1

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Logic

INFOID:000000009266586

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
U1000	CAN COMM CIRCUIT	When CAN communication signal is not continuously received for 2 seconds or more	CAN communication system malfunction

Diagnosis Procedure

INFOID:000000009266587

1. CHECK DTC DETECTION

Ⓜ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self diagnostic result.

Is DTC U1000 detected?

- YES >> Proceed to diagnosis procedure. Refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-45, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000009266588

Initial diagnosis of combination meter.

DTC Logic

INFOID:000000009266589

DTC DETECTION LOGIC

DTC	CONSULT	Description	Probable malfunction location
U1010	CONTROL UNIT (CAN)	Error detected during the initial diagnosis of the CAN controller of combination meter.	Combination meter

Diagnosis Procedure

INFOID:000000009266590

1. REPLACE COMBINATION METER

Replace combination meter. Refer to [MWI-53. "Removal and Installation"](#).

>> Inspection End.

DTC B2205 VEHICLE SPEED CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

DTC B2205 VEHICLE SPEED CIRCUIT

Description

INFOID:000000009266591

The ABS actuator and electric unit (control unit) provides a vehicle speed signal to the combination meter via CAN communication lines.

DTC Logic

INFOID:000000009266592

DTC	CONSULT	Detection condition	Possible malfunction location
B2205	VEHICLE SPEED CIRC [B2205]	Malfunction is detected when an erroneous speed signal is received for 2 seconds or more.	<ul style="list-style-type: none">• Combination meter• ABS actuator and electric unit (control unit)

Diagnosis Procedure

INFOID:000000009266593

1. CHECK COMBINATION METER INPUT SIGNAL

1. Start engine and select METER/M&A on CONSULT.
2. Using SPEED METER on DATA MONITOR, compare the DATA MONITOR value with the combination meter speedometer. Speedometer and DATA MONITOR indications should be close.

Is the inspection result normal?

- YES >> Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-32, "CONSULT Function \(ABS\)"](#).
- NO >> Replace combination meter. Refer to [MWI-53, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

B2267 ENGINE SPEED

Description

INFOID:000000009266594

The engine speed signal is transmitted from ECM to the combination meter via CAN communication.

DTC Logic

INFOID:000000009266595

DTC DETECTION LOGIC

DTC	CONSULT	Diagnostic item is detected when...	Probable malfunction location
B2267	ENGINE SPEED	Malfunction is detected when an erroneous engine speed signal is received for 2 seconds or more.	<ul style="list-style-type: none">• Crankshaft position sensor (POS)• ECM

Diagnosis Procedure

INFOID:000000009266596

1. CHECK COMBINATION METER INPUT SIGNAL

1. Start engine and select METER/M&A on CONSULT.
2. Using TACHO METER on DATA MONITOR, compare the value of DATA MONITOR with tachometer of combination meter. Tachometer and DATA MONITOR indications should be close.

Is the inspection result normal?

- YES >> Perform ECM self-diagnosis. Refer to [EC-61, "CONSULT Function"](#).
- NO >> Replace combination meter. Refer to [MWI-53, "Removal and Installation"](#).

B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

B2268 WATER TEMP

Description

INFOID:000000009266597

The engine coolant temperature signal is transmitted from ECM to the combination meter via CAN communication.

DTC Logic

INFOID:000000009266598

DTC DETECTION LOGIC

DTC	CONSULT	Detection Condition	Possible malfunction location
B2268	WATER TEMP	ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more	<ul style="list-style-type: none">• Engine coolant temperature sensor• ECM

Diagnosis Procedure

INFOID:000000009266599

1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of "ENGINE", and repair or replace malfunctioning parts.

>> Refer to [EC-61. "CONSULT Function"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000009266600

Regarding Wiring Diagram information, refer to [MWI-77. "Wiring Diagram"](#).

1. CHECK FUSE

Check for blown combination meter fuses.

Power source	Fuse No.
Battery	8
Ignition switch ON or START	3

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the fuse after repairing the affected circuit.

2. CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector and ground.

1. Turn ignition switch to OFF.
2. Disconnect combination meter connector.
3. Check voltage between combination meter harness connector M24 terminals 1, 3 and ground.

Terminals		Ignition switch position	Voltage (Approx.)
(+)	(-)		
Combination meter		Ground	Battery voltage
Connector	Terminal		
M24	1		ON
	3		OFF
		ON	Battery voltage
		OFF	0

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between combination meter harness connector M24 terminals 21, 22, 23 and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M24	21	Ground	Yes
	22		
	23		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

BCM (BODY CONTROL MODULE)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000009505246

Regarding Wiring Diagram information, refer to [BCS-107. "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	12 (10A)
70		G (40A)
11	Ignition switch ACC or ON	18 (10A)
38	Ignition switch ON or START	2 (10A)

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM connector and ground.

BCM		Ground	Ignition switch position		
Connector	Terminal		OFF	ACC	ON
M20	57	—	Battery voltage	Battery voltage	Battery voltage
	70				
M18	11		0 V	Battery voltage	Battery voltage
	38		0 V	0 V	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

FUEL LEVEL SENSOR SIGNAL CIRCUIT

Description

INFOID:000000009266603

The fuel level sensor unit and fuel pump detects the approximate fuel level in the fuel tank and transmits the fuel level signal to the combination meter.

Component Function Check

INFOID:000000009266604

1.COMBINATION METER INPUT SIGNAL

1. Select METER/M&A on CONSULT.
2. Using FUEL METER of DATA MONITOR, compare the DATA MONITOR value with the fuel gauge position.

Fuel gauge indication position	Reference value of data monitor [L]
1	Approx. 41.1
3/4	Approx. 30.8
1/2	Approx. 20.5
1/4	Approx. 10.2
0	Approx. 2.5

Does monitor value match fuel gauge reading?

YES >> Inspection End.

NO >> Replace combination meter. Refer to [MWI-53. "Removal and Installation"](#).

Diagnosis Procedure

INFOID:000000009266605

Regarding Wiring Diagram information, refer to [MWI-27. "Wiring Diagram"](#).

1.CHECK HARNESS CONNECTOR

1. Turn ignition switch OFF.
2. Check combination meter and fuel level sensor unit terminals (meter-side and harness-side) for poor connection.

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace terminals or connectors.

2.CHECK FUEL LEVEL SENSOR UNIT CIRCUIT

1. Disconnect combination meter harness connector M24 and fuel level sensor unit and fuel pump harness connector B44.
2. Check continuity between combination meter harness connector M24 terminal 4 and fuel level sensor unit and fuel pump harness connector B44 terminal 2.

Connector	Terminal	Connector	Terminal	Continuity
M24	4	B44	2	Yes

3. Check continuity between fuel level sensor unit and fuel pump harness connector B44 terminal 2 and ground.

Connector	Terminal	Ground	Continuity
B44	2		No

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair harness or connector.

FUEL LEVEL SENSOR SIGNAL CIRCUIT

[TYPE A]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT

1. Check continuity between combination meter harness connector M24 terminal 26 and fuel level sensor unit and fuel pump harness connector B44 terminal 5.

Connector	Terminal	Connector	Terminal	Continuity
M24	26	B44	5	Yes

2. Check continuity between fuel level sensor unit and fuel pump harness connector B44 terminal 5 and ground.

Connector	Terminal	Ground	Continuity
B44	5		No

Is the inspection result normal?

- YES >> GO TO 4
 NO >> Repair harness or connector.

4. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and verify the float arm does not interfere or bind with the internal components in the fuel tank.

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Install the fuel level sensor unit properly.

Component Inspection

INFOID:000000009266606

1. REMOVE FUEL LEVEL SENSOR UNIT

Remove the fuel level sensor unit. Refer to [FL-5, "Removal and Installation"](#).

>> GO TO 2.

2. CHECK FUEL LEVEL SENSOR UNIT


Check the resistance between fuel level sensor unit and fuel pump.

Terminals		Condition	Resistance (Ω) (Approx.)	Height [mm (in)]
Fuel level sensor unit				
2	5	Full* (2)	91	177 (6.97)
		Empty* (1)	283	15 (0.59)

*: When float rod is in contact with stopper.

Is inspection result OK?

- YES >> Inspection End.
 NO >> Replace fuel level sensor unit and fuel pump. Refer to [FL-5, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

WASHER FLUID LEVEL SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE A]

WASHER FLUID LEVEL SWITCH CIRCUIT

Description

INFOID:000000009266607

Transmits the washer fluid level switch signal to the combination meter.

Diagnosis Procedure

INFOID:000000009266608

Regarding Wiring Diagram information, refer to [MWI-27, "Wiring Diagram"](#).

1. CHECK WASHER FLUID LEVEL SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and washer fluid level switch connector.
3. Check continuity between combination meter harness connector M24 terminal 11 and washer fluid level switch harness connector E50 terminal 1.

Connector	Terminal	Connector	Terminal	Continuity
M24	11	E50	1	Yes

4. Check continuity between combination meter harness connector M24 terminal 11 and ground.

Connector	Terminal	Ground	Continuity
M24	11	Ground	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

2. CHECK WASHER FLUID LEVEL SWITCH GROUND CIRCUIT

Check continuity between washer fluid level switch harness connector E50 terminal 2 and ground.

Connector	Terminal	Ground	Continuity
E50	2	Ground	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connector.

Component Inspection

INFOID:000000009266609

1. CHECK WASHER FLUID LEVEL SWITCH

Check continuity between washer fluid level switch terminals 1 and 2.

Terminal	Washer fluid level	Continuity
1 - 2	Low	Yes
	High	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace washer fluid level switch. Refer to [WW-49, "Exploded View"](#).

THE FUEL GAUGE INDICATOR DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[TYPE A]

SYMPTOM DIAGNOSIS

THE FUEL GAUGE INDICATOR DOES NOT OPERATE

Description

INFOID:000000009266610

Fuel gauge will not indicate from a certain position.

Diagnosis Procedure

INFOID:000000009266611

1. CHECK COMBINATION METER INPUT SIGNAL

1. Select METER/M&A on CONSULT.
2. Using "DATA MONITOR, compare the monitor value with the fuel gauge reading on the combination meter. Refer to [MWI-46. "Component Function Check"](#).

Does monitor value match fuel gauge reading?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-53. "Removal and Installation"](#).

2. CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

Check the fuel level sensor signal circuit. Refer to [MWI-46. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. COMPONENT INSPECTION

Perform a component inspection on the fuel level sensor unit. Refer to [MWI-47. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace fuel level sensor unit. Refer to [FL-5. "Removal and Installation"](#).

4. CHECK FLOAT INTERFERENCE

Check that the float arm does not interfere or bind with components in the fuel tank.

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-53. "Removal and Installation"](#).

NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

[TYPE A]

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

Description

INFOID:000000009266612

The oil pressure warning lamp stays OFF when the ignition switch is turned ON.

Diagnosis Procedure

INFOID:000000009266613

1. CHECK COMBINATION METER OIL PRESSURE WARNING LIGHT

1. Select METER/M&A on CONSULT.
2. Observe OIL W/L DATA MONITOR while operating the ignition switch.

Component	Condition	CONSULT
Oil pressure warning light	Ignition ON	ON
	Ignition OFF	OFF

Is the inspection result normal?

- YES >> Inspection end.
NO >> Replace combination meter. Refer to [MWI-53, "Removal and Installation"](#).

THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[TYPE A]

THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

Description

INFOID:000000009266614

The oil pressure warning lamp remains on while the engine is running (normal oil pressure).

Diagnosis Procedure

INFOID:000000009266615

1. CHECK COMBINATION METER INPUT SIGNAL

1. Start the engine and select METER/M&A on CONSULT.
2. Observe OIL W/L DATA MONITOR and the operation of the oil pressure warning lamp on the combination meter.

Component	Condition	CONSULT
Oil pressure warning light	Engine running	OFF

Is the inspection result normal?

- YES >> Perform ECM self-diagnosis. Refer to [EC-61, "CONSULT Function"](#).
NO >> Replace combination meter. Refer to [MWI-53, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

[TYPE A]

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000009266616

- The warning is still displayed even after washer fluid is added.
- The warning is not displayed even though the washer tank is empty.

Diagnosis Procedure

INFOID:000000009266617

1.CHECK WASHER FLUID LEVEL SWITCH

Perform a unit check for the washer fluid level switch. Refer to [MWI-48. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace washer fluid level switch. Refer to [WW-49. "Exploded View"](#).

2.CHECK WASHER FLUID LEVEL SWITCH SIGNAL CIRCUIT

Check the washer fluid level switch signal circuit. Refer to [MWI-48. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-53. "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

COMBINATION METER

< REMOVAL AND INSTALLATION >

[TYPE A]

REMOVAL AND INSTALLATION

COMBINATION METER

Removal and Installation


INFOID:000000009266618

REMOVAL

1. Disconnect the negative battery terminal. Refer to [PG-63. "Removal and Installation"](#).
2. Remove cluster lid A. Refer to [IP-19. "Removal and Installation"](#).
3. Remove the combination meter screws.
4. Pull the combination meter straight out to disengage resin clips.

NOTE:

The illustration shows the clip positions on the back of the combination meter.



5. Disconnect the harness connector from the combination meter and remove.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMBINATION METER

< UNIT DISASSEMBLY AND ASSEMBLY >


[TYPE A]

UNIT DISASSEMBLY AND ASSEMBLY

COMBINATION METER

Exploded View

INFOID:000000009266619



1. Unified meter control unit 2. Front cover

Disassembly and Assembly

INFOID:000000009266620

DISASSEMBLY

1. Disengage the tabs to separate front cover using a suitable tool.
2. Pull the front cover straight out to remove from the unified meter control unit.

CAUTION:

- Do not touch the display, pointer, the inside of front cover and the printed area of the dial during the work.
- Keep away from magnetic sources.
- Do not damage the front cover.

ASSEMBLY

Assembly is in the reverse order of disassembly.

CAUTION:

- Do not touch the display, pointer, the inside of front cover and the printed area of the dial during the work.
- Keep away from magnetic sources.
- Do not damage the front cover.

APPLICATION NOTICE

< HOW TO USE THIS MANUAL >



[TYPE B]

HOW TO USE THIS MANUAL

APPLICATION NOTICE

Information

INFOID:000000009266495

Service information	Design of combination meter
TYPE A	
TYPE B	

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009266496

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:000000009645418

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[TYPE B]


PREPARATION

PREPARATION

Special Service Tool


INFOID:000000009601589

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim Tool Set  <p style="text-align: center;">AWJIA0483ZZ</p>	Removing trim components

Commercial Service Tools

INFOID:000000009266497

Tool name	Description
Power tool  <p style="text-align: center;">PIIB1407E</p>	Loosening nuts, screws and bolts

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[TYPE B]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009266498



AWNIA2712ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[TYPE B]

- | | | | |
|---|--|--|---|
| 1. ABS actuator and electric unit (control unit) | 2. Combination meter | 3. CVT shift selector (O/D OFF switch) | A |
| 4. Air bag diagnosis sensor unit (view with center console removed) | 5. Parking brake switch (view with center console removed) | 6. Fuel level sensor unit and fuel pump (view with rear seat and access cover removed) | B |
| 7. Seat belt buckle switch LH | 8. Front door switch LH | 9. BCM (view with instrument panel removed) | C |
| 10. EPS control unit (view with instrument lower panel removed) | 11. Brake fluid level switch (view with IPDM E/R removed) | 12. ECM (view with IPDM E/R removed) | D |
| 13. TCM | 14. Oil pressure sensor | 15. Washer fluid level switch (if equipped) (view with front fascia removed) | E |

Component Description

INFOID:000000009266499

Unit	Description	
Combination meter	The combination meter controls the following items according to the signals received from each unit. <ul style="list-style-type: none"> • Speedometer • Engine coolant temperature gauge • Warning lamps • Information display • Tachometer • Fuel gauge • Indicator lamps • Warning chime • Illumination control 	F
CVT shift selector switch	Transmits the overdrive off switch signal to the combination meter.	G
Seat belt buckle switch (LH)	Transmits the seat belt buckle switch (LH) signal to the combination meter.	H
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the combination meter via CAN communication.	I
Air bag diagnosis sensor unit	Transmits the air bag signal and seat belt buckle switch (RH) signal to the combination meter.	J
EPS Control unit	Transmits the EPS signal to the combination meter via CAN communication.	K
TCM	Transmits the shift position signal to the combination meter via CAN communication.	L
ECM	Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Engine speed signal • Engine coolant temperature signal • Fuel consumption monitor signal • Oil pressure sensor signal 	M
BCM	Transmits the security signal to the combination meter. Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Low tire pressure warning signal • Door open switch signal 	MWI
Washer fluid level switch (if equipped)	Transmits the washer fluid level switch signal to the combination meter.	O
Fuel level sensor unit and fuel pump	Transmits the fuel level sensor signal to the combination meter.	P
Parking brake switch	Transmits the parking brake switch signal to the combination meter.	
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.	
Oil pressure sensor	Transmits the oil pressure sensor signal to the ECM.	


SYSTEM

METER SYSTEM

METER SYSTEM : System Diagram

INFOID:000000009266500

SYSTEM DIAGRAM



METER SYSTEM : System Description

INFOID:000000009266501

COMBINATION METER

Combination Meter

- The combination meter monitors signals from switches, sensors and modules to control the following functions:
 - Speedometer/Tachometer
 - Shift position indicator
 - Warning lamps
 - Indicator lamps
 - Meter illumination control
 - Information display
- The combination meter has an integrated buzzer that is activated when it receives a signal from the BCM via CAN communication. Refer to [WCS-7. "WARNING CHIME SYSTEM : System Description"](#) for further details.
- The combination meter includes a self diagnosis function.
- The combination meter can be diagnosed with CONSULT.

METER CONTROL FUNCTION LIST

SYSTEM

< SYSTEM DESCRIPTION >

[TYPE B]

System	Description	Reference	
Speedometer	Indicates vehicle speed.	MWI-63. "SPEEDOMETER : System Description"	
Tachometer	Indicates engine speed.	MWI-64. "TACHOMETER : System Description"	
Shift position indicator (CVT models)	Display shift position.	MWI-64. "SHIFT POSITION INDICATOR : System Description"	
Warning lamp/indicator lamp	Oil pressure warning lamp	MWI-64. "OIL PRESSURE WARNING LAMP : System Description"	
	Seat belt warning lamp	SRC-12. "SEAT BELT WARNING LAMP SYSTEM : System Description"	
Meter illumination control	Meter illumination control function	MWI-65. "METER ILLUMINATION CONTROL : System Description"	
	Meter illumination control switch		
Information display	Engine coolant temperature gauge	MWI-65. "INFORMATION DISPLAY : System Description"	
	Fuel gauge		
	Odo/trip meter		
	Trip computer		Instant fuel consumption
			Average fuel consumption
Distance to empty			

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI


SYSTEM

< SYSTEM DESCRIPTION >

[TYPE B]

METER SYSTEM : Arrangement of Combination Meter

INFOID:000000009266502



AWNIA2713GB

METER SYSTEM : Fail-Safe

INFOID:000000009266503

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

SYSTEM

< SYSTEM DESCRIPTION >


[TYPE B]

Function		Specifications	
Speedometer		Reset to zero by suspending communication.	
Tachometer			
Illumination control		When suspending communication, changes to nighttime mode.	
Shift position indicator		When suspending communication, not indicate.	
Information display	Trip computer	Current fuel consumption	<ul style="list-style-type: none"> When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result. When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.
		Average fuel consumption	
		Distance to empty	
	Engine coolant temperature gauge		Reset to zero by suspending communication.
Odo/trip meter		An indicated value is maintained at communications blackout.	
Buzzer		The buzzer turns OFF by suspending communication.	
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns ON by suspending communication.	
	Malfunction indicator lamp (MIL)		
	EPS warning lamp		
	Brake warning lamp		
	High beam indicator lamp		
	Turn signal indicator lamp	The lamp turns OFF by suspending communication.	
	Door warning lamp		
	Light indicator lamp		
	Oil pressure warning lamp		
	Key warning lamp		
	O/D OFF indicator lamp		
	Shift P warning lamp		
	Engine start operation indicator lamp		

SPEEDOMETER

SPEEDOMETER : System Diagram

INFOID:000000009266504



SPEEDOMETER : System Description

INFOID:000000009266505

The ABS actuator and electric unit (control unit) receives each wheel speed sensor signal and provides a vehicle speed signal to the combination meter via CAN communication.

TACHOMETER


SYSTEM

< SYSTEM DESCRIPTION >

[TYPE B]

TACHOMETER : System Diagram

INFOID:000000009266506



TACHOMETER : System Description


INFOID:000000009266507

The crank position sensor sends a crankshaft position signal to the ECM. The ECM provides an engine speed signal to the combination meter via CAN communication lines. The tachometer indicates engine speed in revolutions per minute (rpm).

SHIFT POSITION INDICATOR

SHIFT POSITION INDICATOR : System Diagram

INFOID:000000009266508



SHIFT POSITION INDICATOR : System Description

INFOID:000000009266509

DESCRIPTION


The combination meter receives the shift position signal from TCM via CAN communication, and displays the position of the shift indicator.

OIL PRESSURE WARNING LAMP

OIL PRESSURE WARNING LAMP : System Diagram

INFOID:000000009266510

SYSTEM DIAGRAM



OIL PRESSURE WARNING LAMP : System Description

INFOID:000000009266511

DESCRIPTION

The combination meter turns the oil pressure warning lamp ON when receiving a signal from the ECM via CAN communication.

METER ILLUMINATION CONTROL


SYSTEM

< SYSTEM DESCRIPTION >

[TYPE B]

METER ILLUMINATION CONTROL : System Diagram

INFOID:000000009266512



METER ILLUMINATION CONTROL : System Description

INFOID:000000009266513

DESCRIPTION

Meter Illumination Control Function

- Meter illumination control is enabled when the meter receives a signal from the BCM that the combination switch is in the 1st or 2nd position and the meter switches from Daytime mode to Nighttime mode.

Condition		Meter illumination
Combination switch (lighting switch)	1ST or 2ND position	Nighttime mode
	Off	Daytime mode

Meter Illumination Control Switch


The operation of the illumination control switch changes brightness of the meter illumination.

Meter illumination	The number of adjustable steps
Daytime	12 step
Nighttime	12 step

INFORMATION DISPLAY

INFORMATION DISPLAY : System Diagram

INFOID:000000009266514



INFORMATION DISPLAY : System Description

INFOID:000000009266515

DESCRIPTION

- The combination meter receives signals from switches, sensors and modules for operating the following functions on the information display.
 - Odo/trip meter

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

SYSTEM

[TYPE B]

< SYSTEM DESCRIPTION >

- Engine coolant temperature gauge
- Fuel gauge
- Trip computer
- Interrupt indication
- Meter illumination level
- Setting
- Low fuel warning
- Loose fuel cap warning

ODO/TRIP METER

The combination meter calculates mileage using the vehicle speed signal from the ABS actuator and electric unit (control unit) and displays the mileage on the information display.

ENGINE COOLANT TEMPERATURE GAUGE

The engine coolant temperature gauge indicates the engine coolant temperature. The ECM provides an engine coolant temperature signal to the combination meter via CAN communication.

FUEL GAUGE


Control Outline

The fuel level sensor unit sends a variable resistor signal to the combination meter. The fuel gauge indicates the approximate fuel level in the fuel tank.

Refuel Control

The unit detects the driver is refueling the vehicle and accelerates the fuel gauge segment movement if the fuel level changes by 9 ℓ (2-3/8 US, 2 Imp gal) or more.

Lighting segment-resistance relationship



INTERRUPT INDICATION

Low Fuel Warning

The low fuel warning turns ON when the fuel level in the fuel tank reaches approximately 7 ℓ (1-7/8 US gal, 1-1/2 Imp gal).

SYSTEM

< SYSTEM DESCRIPTION >

[TYPE B]

LOOSE FUEL CAP WARNING

The LOOSE FUEL CAP message will display in the information display when the fuel-filler cap is not tightened correctly. The message will turn off as soon as the ECM detects the fuel-filler cap is properly tightened. The ECM provides a loose fuel cap signal to the combination meter via CAN communication lines.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

[TYPE B]

DIAGNOSIS SYSTEM (COMBINATION METER)

Diagnosis Description

INFOID:000000009266516

COMBINATION METER SELF-DIAGNOSIS MODE

The information display, speedometer and tachometer can be checked in self-diagnosis mode.


STARTING COMBINATION METER SELF-DIAGNOSIS MODE

NOTE:


- Check combination meter power supply and ground circuits if self-diagnosis mode does not start. Refer to [MWI-94, "COMBINATION METER : Diagnosis Procedure"](#). Replace combination meter if power supply and ground circuits are found to be normal and self-diagnosis mode does not start. Refer to [MWI-104, "Removal and Installation"](#).
- Combination meter self-diagnosis mode will function with the ignition switch in ON. Combination meter self-diagnosis mode will exit upon turning the ignition switch to OFF.

How to Initiate Self-Diagnosis Mode

1. Turn ignition switch ON, press the odo/trip meter switch (1) to "trip A" or "trip B".
2. Turn ignition switch to OFF.
3. Continue holding the odo/trip meter switch (1) and turn the ignition switch ON.
4. Verify the trip meter displays "0000.0".
5. Press the meter control switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON).



6. The combination meter self-diagnosis mode is activated.
 - Verify all segments of the information display and shift position indicator (A) for CVT models are displayed.




DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

[TYPE B]

7. Each meter activates by pressing the meter control switch.



NOTE:

- If any of the meters or gauges is not activated, replace combination meter.
- The figure is reference.

CONSULT Function

INFOID:000000009266517

APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown.

METER/M&A Diagnosis mode	Description
SELF DIAGNOSTIC RESULT	The combination meter self-diagnosis results.
DATA MONITOR	Displays combination meter input/output data in real time.
SPECIAL FUNCTION	Lighting history of the warning lamp and indicator lamp can be checked.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

SELF DIAG RESULT

Refer to [MWI-75. "DTC Index"](#).

DATA MONITOR

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h] or [mph]	X	Displays the value of vehicle speed signal.
SPEED OUTPUT [km/h] or [mph]	X	Displays the value of vehicle speed signal, which is transmitted to each unit with CAN communication.
ODO OUTPUT [km/h or mph]		Displays odometer signal value transmitted to other units via CAN communication.
TACHO METER [rpm]	X	Displays the value of engine speed signal, which is input from ECM.
FUEL METER [L]	X	Displays the fuel level.
W TEMP METER [°C] or [°F]	X	Displays the value of engine coolant temperature signal, which is input from ECM.
ABS W/L [ON/OFF]		Displays [ON/OFF] condition of ABS warning indicator
BRAKE W/L [ON/OFF]		Displays [ON/OFF] condition of brake warning indicator.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

[TYPE B]

Display item [Unit]	MAIN SIGNALS	Description
DOOR W/L [ON/OFF]		Displays [ON/OFF] condition of door warning indicator.
HI-BEAM IND [ON/OFF]		Displays [ON/OFF] condition of high beam indicator.
TURN IND [ON/OFF]		Displays [ON/OFF] condition of turn indicator.
LIGHT IND [ON/OFF]		Displays [ON/OFF] condition of light indicator.
OIL W/L [ON/OFF]		Displays [ON/OFF] condition of oil pressure warning indicator.
MIL [ON/OFF]		Displays [ON/OFF] condition of malfunction indicator.
CRUISE IND [Off]		Displays [ON/OFF] condition of CRUISE indicator.
O/D OFF IND [ON/OFF]		Displays [ON/OFF] condition of O/D OFF indicator.
FUEL W/L [ON/OFF]		Displays [ON/OFF] condition of low-fuel warning indicator.
KEY G/Y W/L [ON/OFF]		Displays [ON/OFF] condition of key warning lamp.
O/D OFF SW [ON/OFF]		Displays [ON/OFF] condition of O/D OFF switch.
REAR DEF SW [ON/OFF]		Displays [ON/OFF] condition of rear window defogger switch.
BRAKE SW [ON/OFF]		Displays [ON/OFF] condition of brake switch.
EPS W/L [ON/OFF]		Displays [ON/OFF] condition of EPS indicator.
CHAGE W/L [Off]		Displays [ON/OFF] condition of charge warning indicator.
LCD		Displays the value of Intelligent Key system message indication.
SHIFT IND [P, R, N, D, L]		Displays shift selector position.
FUEL CAP W/L [Off]		Displays [ON/OFF] condition of loose fuel cap warning message.
AIR PRES W/L [ON/OFF]		Displays [ON/OFF] condition of tire pressure warning lamp.
PKB SW [ON/OFF]		Status of parking brake switch.
BUCKLE SW [ON/OFF]		Status of seat belt buckle switch (LH).
PASS BUCKLE SW [ON/OFF]		Status of passenger seat belt buckle switch (RH).
BRAKE OIL SW [ON/OFF]		Status of brake fluid level switch.
DISTANCE [km] or [Mi]		Displays distance to empty.
BUZZER [ON/OFF]	X	Displays [ON/OFF] condition of buzzer.

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

[TYPE B]

Display item [Unit]	MAIN SIGNALS	Description
SLIP IND [ON/OFF]		Displays [ON/OFF] condition of SLIP indicator lamp.
VDC/TCS IND [ON/OFF]		Displays [ON/OFF] condition of VDC OFF indicator lamp.

NOTE:

Some items are not available according to vehicle specification.

SPECIAL FUNCTION

Special menu

Display item	Description
W/L ON HISTORY	Lighting history of warning lamp and indicator lamp can be checked.

W/L ON HISTORY

- Stores histories when warning/indicator lamp is turned on.
- “W/L ON HISTORY” indicates the “TIME” when the warning/ indicator lamp is turned on.
- The “TIME” above is:
 - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
 - 1 - 39: The number of times the engine was restarted after the 0 condition.
 - NO W/L ON HISTORY: Stores NO (0) turning on history of warning/indicator lamp.

NOTE:

- W/L ON HISTORY is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

Display Item

Display item	Description
ABS W/L	Lighting history of ABS warning lamp.
VDC/TCS IND	Lighting history of VDC warning lamp.
SLIP IND	Lighting history of SLIP warning lamp.
BRAKE W/L	Lighting history of brake warning lamp.
OIL W/L	Lighting history of oil pressure warning lamp.
C-ENG W/L	Lighting history of malfunction indicator lamp (MIL).
AIR PRES W/L	Lighting history of tire pressure warning lamp.
EPS W/L	Lighting history of EPS warning lamp.
CHAGE W/L	Lighting history of charging warning lamp.
DOOR W/L	Lighting history of door warning lamp.
CRUISE W/L	Lighting history of cruise warning lamp.
O/D OFF IND	Lighting history of O/D OFF indicator lamp.
FUEL W/L	Lighting history of fuel warning lamp.
WASHER W/L	Lighting history of washer warning lamp.

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[TYPE B]

ECU DIAGNOSIS INFORMATION

COMBINATION METER

Reference Value

INFOID:000000009266518

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Display content	Data monitor	
		Condition	Reference value in normal operation
SPEED METER [km/h or mph]	Speed meter operation	While driving	Vehicle speed matches speed meter
SPEED OUTPUT [km/h or mph]	Vehicle speed	While driving	The speed output signal value via CAN communication is approx. value of vehicle speed.
ODO OUTPUT [km/h or mph]	ODO meter operation	Driving	Distance driven
TACHO METER [rpm]	Tacho meter operation	Engine running	The tacho meter is approx. value of engine speed via CAN communication.
FUEL METER [L]	Fuel level	Ignition ON	Fuel level is approx. value of fuel gauge.
W TEMP METER [°C] or [°F]	Engine coolant temperature	Engine running	Input value of engine coolant temperature signal via CAN communication.
ABS W/L	ABS warning lamp	When ABS warning lamp is ON	On
		When ABS warning lamp is OFF	Off
BRAKE W/L	Brake warning lamp	When Brake warning lamp is ON	On*
		When Brake warning lamp is OFF	Off
DOOR W/L	Door open warning lamp	When Door warning lamp is ON	On
		When Door warning lamp is OFF	Off
HI-BEAM IND	HI-Beam indicator lamp	When High-beam indicator lamp is ON	On
		When High-beam indicator lamp is OFF	Off
TURN IND	Turn signal indicator	When Turn signal indicator lamp is ON	On
		When Turn signal indicator lamp is OFF	Off
LIGHT IND	Light indicator	When Tail lamp indicator lamp is ON	On
		When Tail lamp indicator lamp is OFF	Off
OIL W/L	Oil pressure warning light	When Oil pressure warning lamp is ON	On
		When Oil pressure warning lamp is OFF	Off
MIL	MIL warning lamp	When Malfunction indicator lamp (MIL) is ON	On
		When Malfunction indicator lamp (MIL) is OFF	Off
CRUISE IND	Cruise indicator lamp	When cruise indicator lamp is ON.	ON
		When cruise indicator lamp is OFF.	Off
O/D OFF IND	O/D OFF indicator	When O/D OFF indicator lamp is OFF.	Off
		When O/D OFF indicator lamp is ON.	On
O/D OFF SW	O/D OFF switch	When O/D OFF switch is pressed to OFF.	Off
		When O/D OFF switch is pressed to ON.	On
REAR DEF SW	Rear defogger switch	When rear defogger switch is pressed to ON	On
		When rear defogger is pressed to Off	Off

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[TYPE B]

Monitor Item	Display content	Data monitor		
		Condition	Reference value in normal operation	
BRAKE SW	Brake switch	When brake pedal is applied	On	A
		When brake pedal is released	Off	B
FUEL W/L	Low fuel warning	When low fuel warning is ON	On	C
		When low fuel warning is Off	Off	
KEY G/Y W/L	Key warning lamp	When key warning lamp is ON	On	
		When key warning lamp is OFF	Off	
EPS W/L	EPS warning lamp	EPS warning lamp ON	On	D
		EPS warning lamp OFF	Off	
CHAGE W/L	Charge warning lamp	Engine running	Off	E
LCD	—	Display the value of Intelligent Key system message indication.	—	
SHIFT IND	Shift position indicator	The position of the shift position selector.	[P, R, N, D, L]	F
FUEL CAP W/L	Loose fuel cap warning	When the fuel-filler cap is installed incorrectly.	On	G
		When the fuel-filler cap is installed correctly.	Off	
AIR PRES W/L	Tire pressure warning lamp operation	When tire pressure warning lamp is ON	ON	H
		When tire pressure warning lamp is OFF	Off	
PKB SW	Parking brake switch	When parking brake is active	On	
		When parking brake is inactive	Off	I
BUCKLE SW	Seat belt buckle switch LH	When seat belt buckle is unfastened (LH).	On	
		When seat belt buckle is fastened (LH).	Off	J
BRAKE OIL SW	Brake fluid level switch	When brake fluid level switch ON	On	
		When brake fluid level switch OFF	Off	
PASS BUCKLE SW	Seat belt buckle switch RH	When passenger seat is occupied and seat belt buckle is unfastened (RH).	On	K
		When passenger seat is unoccupied and seat belt buckle is unfastened (RH).	Off	L
DISTANCE	Distance to empty	While driving	[km/h or mph]	
BUZZER	Buzzer operation	When Buzzer is ON	On	M
		When Buzzer is OFF	Off	
SLIP IND	Slip indicator lamp	When SLIP indicator lamp is ON.	On	
		When SLIP indicator lamp is ON.	Off	MWI
VDC/TCS IND	VDC indicator lamp	When VDC indicator lamp is ON.	ON	
		When VDC indicator lamp is Off	OFF	O

*: Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.

NOTE:


Some items are not available according to vehicle specification.

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[TYPE B]

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No.	Wire color	Item	Condition		Reference value (V) (Approx.)
			Ignition switch	Operation or condition	
1	L	CAN-H	—	—	—
2	P	CAN-L	—	—	—
4	P	8P/R	—	—	—
6	W	Fuel level sensor signal (+)	—	—	Refer to MWI-98, "Component Inspection" .
7	V	Air bag	—	—	—
8	P	O/D OFF switch	ON	O/D OFF switch pressed	0
				O/D OFF switch released	Battery voltage
9	V	Seat belt buckle switch LH	ON	Unfastened (ON)	0
				Fastened (OFF)	Battery voltage
10	SB	Parking Brake switch	ON	Parking brake is inactive	0
				Parking brake is active	Battery voltage
11	LG	Brake fluid level switch	ON	Brake fluid level low	0
				Brake fluid level normal	Battery voltage
13	B	Illumination control switch (-)	—	—	—
15	R	Ignition switch ON or ACC	—	—	Battery voltage
17	V	Washer fluid level switch (Canada models)	ON	Washer fluid level low	0
				Washer fluid level normal	Battery voltage
18	G	Security	—	—	—
21	B/W	Ground	—	—	0
22	B				
23	B				
24	GR	Fuel level sensor ground (-)	ON	—	0
25	B/W	VDC ground	ON	—	0
27	R	Battery power supply	OFF	—	Battery voltage
28	GR	Ignition switch ON or START	ON	—	Battery voltage
29	G	Seat belt buckle switch RH	ON	Unfastened (ON)	0
				Fastened (OFF)	Battery voltage
30	LG	Stop lamp switch	ON	Brake pedal depressed	Battery voltage
				Brake pedal released	0
38	Y	Generator	ON	Generator voltage low	0
				Generator voltage normal	Battery voltage

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

[TYPE B]

Fail-Safe

INFOID:000000009266519

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

Function		Specifications	
Speedometer		Reset to zero by suspending communication.	
Tachometer			
Illumination control		When suspending communication, changes to nighttime mode.	
Shift position indicator		When suspending communication, not indicate.	
Information display	Trip computer	Current fuel consumption	<ul style="list-style-type: none"> When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result. When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.
		Average fuel consumption	
		Distance to empty	
	Engine coolant temperature gauge	Reset to zero by suspending communication.	
	Odo/trip meter	An indicated value is maintained at communications blackout.	
Buzzer		The buzzer turns OFF by suspending communication.	
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns ON by suspending communication.	
	Malfunction indicator lamp (MIL)		
	EPS warning lamp		
	Brake warning lamp		
	High beam indicator lamp		
	Turn signal indicator lamp	The lamp turns OFF by suspending communication.	
	Door warning lamp		
	Light indicator lamp		
	Oil pressure warning lamp		
	Key warning lamp		
	O/D OFF indicator lamp		
	Shift P warning lamp		
Engine start operation indicator lamp			

DTC Index

INFOID:000000009266520

Display contents of CONSULT	Diagnostic item is detected when...	Refer to
CAN COMM CIRCUIT [U1000]	When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more.	MWI-89. "Diagnosis Procedure"
CONTROL UNIT (CAN) [U1010]	When detecting error during the initial diagnosis of the CAN controller of combination meter.	MWI-90. "Diagnosis Procedure"
VEHICLE SPEED [B2205]	The abnormal vehicle speed signal is input from the ABS actuator and electric unit (control unit) for 2 seconds or more.	MWI-91. "Diagnosis Procedure"
ENGINE SPEED [B2267]	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	MWI-92. "Diagnosis Procedure"
WATER TEMP [B2268]	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	MWI-93. "Diagnosis Procedure"

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[TYPE B]

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:000000009266521

ECU	Reference
BCM (with Intelligent Key)	BCS-28. "Reference Value"
	BCS-50. "Wiring Diagram"
	BCS-45. "Fail-safe"
	BCS-47. "DTC Inspection Priority Chart"
	BCS-48. "DTC Index"
BCM (without Intelligent Key)	BCS-93. "Reference Value"
	BCS-107. "Wiring Diagram"
	BCS-104. "Fail-safe"
	BCS-104. "DTC Inspection Priority Chart"
	BCS-105. "DTC Index"


WIRING DIAGRAM

METER SYSTEM

Wiring Diagram

INFOID:000000009266522

METER - TYPE B



ABNWA1773GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


MWI

METER SYSTEM

< WIRING DIAGRAM >

[TYPE B]

- ◊IK◊ : WITH INTELLIGENT KEY SYSTEM
- ◊OK◊ : WITHOUT INTELLIGENT KEY SYSTEM
- ◊TW◊ : WITH TIRE PRESSURE MONITOR SYSTEM
- ◊WI◊ : WITH IMMOBILIZER
- *1 ◊IK◊ : 46 ◊OK◊ : 45
- ◊IK◊ : 13 ◊OK◊ : 12




ABNWA1774GB

METER SYSTEM

< WIRING DIAGRAM >

[TYPE B]

- ◻(IK) : WITH INTELLIGENT KEY SYSTEM
- ◻(N) : FOR CANADA
- ◻(VT) : WITH CVT




ABNWA1775GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER CONNECTORS - TYPE B

Connector No.	M10
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	L	-
4	L	-
6	L	-
7	L	-
13	P	-
14	P	-
16	P	-
17	P	-

Connector No.	M17
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	SB	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	P	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	P	DOOR SW (AS)
13	LG	DOOR SW (RR)
23	G	SECURITY INDICATOR OUTPUT
39	L	CAN-H
40	P	CAN-L

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	V	-
5	GR	-
6	W	-
15	W	-
16	LG	-
17	P	-
18	SB	-

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
42	P	TR ROOM LAMP SW
47	SB	DOOR SW (DR)
48	W	DOOR SW (RL)

METER SYSTEM

< WIRING DIAGRAM >


[TYPE B]

Connector No.	M53
Connector Name	EPS CONTROL UNIT
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	CAN-L
2	L	CAN-H

Connector No.	M38
Connector Name	CVT SHIFT SELECTOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	B/W	-

Connector No.	M35
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
23	V	AIRBAG W/L
24	G	SEATBELT REMINDER

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17A	Y	-
18A	LG	-
20A	P	-
21A	L	-
29A	V	-

ABN1A4545GB

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

METER SYSTEM

< WIRING DIAGRAM >

[TYPE B]

Connector No.	M82
Connector Name	COMBINATION METER (WITH TYPE B)
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
2	P	CAN-L
3	-	-
4	P	8P/R
5	-	-
6	W	FM SIG
7	V	AIR BAG
8	P	O/D OFF/SPORT SW

Terminal No.	Color of Wire	Signal Name
9	V	BELT
10	SB	PKB SW
11	LG	BRAKE OIL SW
12	-	-
13	B	OUTSIDE ILL OUTPUT
14	-	-
15	R	ACC SW
16	-	-
17	V	WASHER SW
18	G	SECURITY
19	-	-
20	-	-
21	B/W	GND (ILL)
22	B	GND (POWER)
23	B	GND (CIRCUIT)
24	GR	FM GND

Terminal No.	Color of Wire	Signal Name
25	B/W	VDC GND
26	-	-
27	R	BAT
28	GR	IGN
29	G	AS BELT
30	LG	BRAKE SW
31	-	-
32	-	-
33	-	-
34	-	-
35	-	-
36	-	-
37	-	-
38	Y	CHG
39	-	-
40	-	-

Connector No.	M97
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
23	G	SECURITY INDICATOR OUTPUT
39	L	CAN-H
40	P	CAN-L

Connector No.	M100
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
42	P	TRUNK/GLASS HATCH SW
45	P	DOOR SW (AS)
46	LG	DOOR SW (RR)
47	SB	DOOR SW (DR)
48	W	DOOR SW (RL)


41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

METER SYSTEM

< WIRING DIAGRAM >

[TYPE B]


Connector No.	E8
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
19	V	-

Terminal No.	Color of Wire	Signal Name
17A	V	-
18A	LG	-
20A	P	-
21A	L	-
29A	R	-

Connector No.	E7
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E16
Connector Name	ECM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
83	P	CAN-L
84	L	CAN-H

Terminal No.	Color of Wire	Signal Name
4	P	-
5	P	-
8	L	-
9	L	-
10	L	-
11	L	-
12	L	-

Connector No.	E14
Connector Name	JOINT CONNECTOR-E03
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-

ABNIA3812GB


A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

METER SYSTEM

< WIRING DIAGRAM >

[TYPE B]

Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
61	P	CAN-L
62	L	CAN-H

Connector No.	E40
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-

Connector No.	E33
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	F4
Connector Name	GENERATOR
Connector Color	-



Terminal No.	Color of Wire	Signal Name
5	B/GR	-

Connector No.	F1
Connector Name	GENERATOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	LW	-

Connector No.	E50
Connector Name	WASHER FLUID LEVEL SWITCH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

ABNIA3804GB

METER SYSTEM

< WIRING DIAGRAM >


[TYPE B]

Connector No.	F38
Connector Name	ENGINE OIL PRESSURE SENSOR
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	O	-
2	Y	-
3	L	-

Connector No.	F11
Connector Name	ECM
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
47	Y	ENGINE OIL PRESSURE SENSOR
60	L	SENSOR GROUND
74	O	SENSOR GROUND

Connector No.	F8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
19	L/W	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	LG	-

Connector No.	B6
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	V	-

Connector No.	F44
Connector Name	TCM (TRANSMISSION CONTROL MODULE) (WITH CVT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

ABNIA4547GB


A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

METER SYSTEM

< WIRING DIAGRAM >

[TYPE B]

Connector No.	B16
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	3	Color of Wire	L	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	B13
Connector Name	SEAT BELT BUCKLE SWITCH LH
Connector Color	WHITE




Terminal No.	1	Color of Wire	O	Signal Name	-
Terminal No.	2	Color of Wire	B	Signal Name	-

Connector No.	B9
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW




Terminal No.	30	Color of Wire	O	Signal Name	LH SEAT BELT BUCKLE SWITCH (+)
--------------	----	---------------	---	-------------	--------------------------------

Connector No.	B29
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	8	Color of Wire	P	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	B24
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	4	Color of Wire	O	Signal Name	-
Terminal No.	5	Color of Wire	P	Signal Name	-
Terminal No.	6	Color of Wire	R	Signal Name	-
Terminal No.	15	Color of Wire	V	Signal Name	-
Terminal No.	16	Color of Wire	R	Signal Name	-
Terminal No.	17	Color of Wire	L	Signal Name	-
Terminal No.	18	Color of Wire	LG	Signal Name	-

Connector No.	B17
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	3	Color of Wire	R	Signal Name	-
--------------	---	---------------	---	-------------	---

ABNIA4548GB

METER SYSTEM

< WIRING DIAGRAM >


[TYPE B]

Connector No.	B45
Connector Name	SEAT BELT BUCKLE SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-

Connector No.	B44
Connector Name	FUEL LEVEL SENSOR UNIT AND FUEL PUMP
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	R	-
5	P	-

Connector No.	B37
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Color	YELLOW



Terminal No.	Color of Wire	Signal Name
29	O	RH SEAT BELT BUCKLE SWITCH (+)

Connector No.	B51
Connector Name	TRUNK LID LOCK ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	B	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



ABNIA4549GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009266523

OVERALL SEQUENCE



DETAILED FLOW

1.CONFIRM SYMPTOM

Confirm symptom or customer complaint.

>> GO TO 2

2.SELF-DIAGNOSIS OF COMBINATION METER

Perform self-diagnosis of combination meter. Refer to [MWI-68, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> GO TO 3

NO >> If self-diagnosis will not start, check power supply and ground circuit of combination meter. Refer to [MWI-94, "COMBINATION METER : Diagnosis Procedure"](#). If power supply and ground circuits are OK, replace combination meter. Refer to [MWI-104, "Removal and Installation"](#).

3.CHECK COMBINATION METER WITH CONSULT

Select "METER/M&A" on CONSULT and perform self-diagnosis of combination meter. Refer to [MWI-69, "CONSULT Function"](#).

Is the inspection result normal?

YES >> Check symptom. GO TO 4.

NO >> Refer to [MWI-75, "DTC Index"](#).

4.CHECK SYSTEM OPERATION

Check the combination meter to verify that the repair has been completed successfully.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 1

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Logic

INFOID:000000009266524

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
U1000	CAN COMM CIRCUIT	When CAN communication signal is not continuously received for 2 seconds or more	CAN communication system malfunction

Diagnosis Procedure

INFOID:000000009266525

1. CHECK DTC DETECTION

Ⓜ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self diagnostic result.

Is DTC U1000 detected?

- YES >> Proceed to diagnosis procedure. Refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-45, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000009266526

Initial diagnosis of combination meter.

DTC Logic

INFOID:000000009266527

DTC DETECTION LOGIC

DTC	CONSULT	Description	Probable malfunction location
U1010	CONTROL UNIT (CAN)	Error detected during the initial diagnosis of the CAN controller of combination meter.	Combination meter

Diagnosis Procedure

INFOID:000000009266528

1. REPLACE COMBINATION METER

Replace combination meter. Refer to [MWI-104. "Removal and Installation"](#).

>> Inspection End.

DTC B2205 VEHICLE SPEED CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

DTC B2205 VEHICLE SPEED CIRCUIT

Description

INFOID:000000009266529

The ABS actuator and electric unit (control unit) provides a vehicle speed signal to the combination meter via CAN communication lines.

DTC Logic

INFOID:000000009266530

DTC	CONSULT	Detection condition	Possible malfunction location
B2205	VEHICLE SPEED CIRC [B2205]	Malfunction is detected when an erroneous speed signal is received for 2 seconds or more.	<ul style="list-style-type: none">Combination meterABS actuator and electric unit (control unit)

Diagnosis Procedure

INFOID:000000009266531

1. CHECK COMBINATION METER INPUT SIGNAL

1. Start engine and select METER/M&A on CONSULT.
2. Using SPEED METER on DATA MONITOR, compare the DATA MONITOR value with the combination meter speedometer. Speedometer and DATA MONITOR indications should be close.

Is the inspection result normal?

- YES >> Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-32, "CONSULT Function \(ABS\)"](#).
- NO >> Replace combination meter. Refer to [MWI-104, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

B2267 ENGINE SPEED

Description

INFOID:000000009266532

The engine speed signal is transmitted from ECM to the combination meter via CAN communication.

DTC Logic

INFOID:000000009266533

DTC DETECTION LOGIC

DTC	CONSULT	Diagnostic item is detected when...	Probable malfunction location
B2267	ENGINE SPEED	Malfunction is detected when an erroneous engine speed signal is received for 2 seconds or more.	<ul style="list-style-type: none">• Crankshaft position sensor (POS)• ECM

Diagnosis Procedure

INFOID:000000009266534

1. CHECK COMBINATION METER INPUT SIGNAL

1. Start engine and select METER/M&A on CONSULT.
2. Using TACHO METER on DATA MONITOR, compare the value of DATA MONITOR with tachometer of combination meter. Tachometer and DATA MONITOR indications should be close.

Is the inspection result normal?

- YES >> Perform ECM self-diagnosis. Refer to [EC-61, "CONSULT Function"](#).
- NO >> Replace combination meter. Refer to [MWI-104, "Removal and Installation"](#).

B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

B2268 WATER TEMP

Description

INFOID:000000009266535

The engine coolant temperature signal is transmitted from ECM to the combination meter via CAN communication.

DTC Logic

INFOID:000000009266536

DTC DETECTION LOGIC

DTC	CONSULT	Detection Condition	Possible malfunction location
B2268	WATER TEMP	ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more	<ul style="list-style-type: none">• Engine coolant temperature sensor• ECM

Diagnosis Procedure

INFOID:000000009266537

1.PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of "ENGINE", and repair or replace malfunctioning parts.

>> Refer to [EC-61. "CONSULT Function"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000009266538

Regarding Wiring Diagram information, refer to [MWI-77. "Wiring Diagram"](#).

1. CHECK FUSE

Check for blown combination meter fuses.

Power source	Fuse No.
Battery	8
Ignition switch ON or START	3
Ignition switch ACC or ON	18

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the fuse after repairing the affected circuit.

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector M82, terminals 27, 28, 15 and ground.

Terminals		Ignition switch position				
(+)		(-)	OFF	ACC	ON	START
Connector	Terminal					
M82	27	Ground	Battery voltage	Battery voltage	Battery voltage	Battery voltage
	28		0V	0V	Battery voltage	Battery voltage
	15		0V	Battery voltage	Battery voltage	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness for open between combination meter and fuse.

3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M82, terminals 21, 22, 23 and ground.

Terminals		Continuity	
(+)			(-)
Connector	Terminal		
M82	21	Ground	Yes
	22		
	23		

Is the inspection result normal?

YES >> Inspection End.

NO >> Check ground harness.

BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM) : Diagnosis Procedure

INFOID:000000009505247

Regarding Wiring Diagram information, refer to [BCS-50. "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	12 (10A)
70		G (40A)

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M99.
2. Check voltage between BCM connector M99 and ground.

BCM		Ground	Voltage
Connector	Terminal		
M99	57	—	Battery voltage
	70		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M99 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M99	67	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair harness or connector.

BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM)

MWI

BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) : Diagnosis Procedure

INFOID:000000009505248

Regarding Wiring Diagram information, refer to [BCS-107. "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	12 (10A)
70		G (40A)
11	Ignition switch ACC or ON	18 (10A)
38	Ignition switch ON or START	2 (10A)

Is the fuse blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM connector and ground.

BCM		Ground	Ignition switch position		
Connector	Terminal		OFF	ACC	ON
M20	57	—	Battery voltage	Battery voltage	Battery voltage
	70				
M18	11		0 V	Battery voltage	Battery voltage
	38		0 V	0 V	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between BCM connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67	—	Yes

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair harness or connector.

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

FUEL LEVEL SENSOR SIGNAL CIRCUIT

Description

INFOID:000000009266541

The fuel level sensor unit and fuel pump detects the approximate fuel level in the fuel tank and transmits the fuel level signal to the combination meter.

Component Function Check

INFOID:000000009266542

1.COMBINATION METER INPUT SIGNAL

1. Select METER/M&A on CONSULT.
2. Using FUEL METER of DATA MONITOR, compare the DATA MONITOR value with the fuel gauge position.

Fuel gauge indication position	Reference value of data monitor [L]
1	Approx. 41.1
3/4	Approx. 30.8
1/2	Approx. 20.5
1/4	Approx. 10.2
0	Approx. 2.5

Does monitor value match fuel gauge reading?

- YES >> Inspection End.
NO >> Replace combination meter. Refer to [MWI-104. "Removal and Installation"](#).

Diagnosis Procedure

INFOID:000000009266543

Regarding Wiring Diagram information, refer to [MWI-77. "Wiring Diagram"](#).

1.CHECK HARNESS CONNECTOR

1. Turn ignition switch OFF.
2. Check combination meter and fuel level sensor unit terminals (meter-side and harness-side) for poor connection.

Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace terminals or connectors.

2.CHECK FUEL LEVEL SENSOR UNIT CIRCUIT

1. Disconnect combination meter harness connector M82 and fuel level sensor unit and fuel pump harness connector B44.
2. Check continuity between combination meter harness connector M82 terminal 6 and fuel level sensor unit and fuel pump harness connector B44 terminal 2.

Connector	Terminal	Connector	Terminal	Continuity
M82	6	B44	2	Yes

3. Check continuity between fuel level sensor unit and fuel pump harness connector B44 terminal 2 and ground.

Connector	Terminal	Ground	Continuity
B44	2		No

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

FUEL LEVEL SENSOR SIGNAL CIRCUIT

[TYPE B]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT

1. Check continuity between combination meter harness connector M82 terminal 24 and fuel level sensor unit and fuel pump harness connector B44 terminal 5.

Connector	Terminal	Connector	Terminal	Continuity
M82	24	B44	5	Yes

2. Check continuity between fuel level sensor unit and fuel pump harness connector B44 terminal 5 and ground.

Connector	Terminal	Ground	Continuity
B44	5		No

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair harness or connector.

4. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and verify the float arm does not interfere or bind with the internal components in the fuel tank.

Is the inspection result normal?

YES >> Inspection End.

NO >> Install the fuel level sensor unit properly.

Component Inspection

INFOID:000000009266544

1. REMOVE FUEL LEVEL SENSOR UNIT

Remove the fuel level sensor unit. Refer to [FL-5, "Removal and Installation"](#).

>> GO TO 2.

2. CHECK FUEL LEVEL SENSOR UNIT

Check the resistance between fuel level sensor unit and fuel pump.


Terminals		Condition	Resistance (Ω) (Approx.)	Height [mm (in)]
Fuel level sensor unit				
2	5	Full* (2)	91	177 (6.97)
		Empty* (1)	283	15 (0.59)

*: When float rod is in contact with stopper.

Is inspection result OK?

YES >> Inspection End.

NO >> Replace fuel level sensor unit and fuel pump. Refer to [FL-5, "Removal and Installation"](#).



WASHER FLUID LEVEL SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TYPE B]

WASHER FLUID LEVEL SWITCH CIRCUIT

Description

INFOID:000000009266545

Transmits the washer fluid level switch signal to the combination meter.

Diagnosis Procedure

INFOID:000000009266546

Regarding Wiring Diagram information, refer to [MWI-77, "Wiring Diagram"](#).

1.CHECK WASHER FLUID LEVEL SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector M82 and washer fluid level switch connector E50.
3. Check continuity between combination meter harness connector M82 terminal 17 and washer fluid level switch harness connector E50 terminal 1.

Connector	Terminal	Connector	Terminal	Continuity
M82	17	E50	1	Yes

4. Check continuity between combination meter harness connector M82 terminal 17 and ground.

Connector	Terminal	Ground	Continuity
M82	17	Ground	No

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace harness or connector.

2.CHECK WASHER FLUID LEVEL SWITCH GROUND CIRCUIT

Check continuity between washer fluid level switch harness connector E50 terminal 2 and ground.

Connector	Terminal	Ground	Continuity
E50	2	Ground	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Repair or replace harness or connector.

Component Inspection

INFOID:000000009266547

1.CHECK WASHER FLUID LEVEL SWITCH

Check continuity between washer fluid level switch terminals 1 and 2.

Terminal	Washer fluid level	Continuity
1 - 2	Low	Yes
	High	No

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace washer fluid level switch. Refer to [WW-49, "Exploded View"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE FUEL GAUGE INDICATOR DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[TYPE B]

SYMPTOM DIAGNOSIS

THE FUEL GAUGE INDICATOR DOES NOT OPERATE

Description

INFOID:000000009266548

Fuel gauge will not indicate from a certain position.

Diagnosis Procedure

INFOID:000000009266549

1. CHECK COMBINATION METER INPUT SIGNAL

1. Select METER/M&A on CONSULT.
2. Using "DATA MONITOR", compare the monitor value with the fuel gauge reading on the combination meter. Refer to [MWI-97. "Component Function Check"](#).

Does monitor value match fuel gauge reading?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-104. "Removal and Installation"](#).

2. CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

Check the fuel level sensor signal circuit. Refer to [MWI-97. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. COMPONENT INSPECTION

Perform a component inspection on the fuel level sensor unit. Refer to [MWI-98. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace fuel level sensor unit. Refer to [FL-5. "Removal and Installation"](#).

4. CHECK FLOAT INTERFERENCE

Check that the float arm does not interfere or bind with components in the fuel tank.

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-104. "Removal and Installation"](#).

NO >> Repair or replace malfunctioning parts.

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

[TYPE B]

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

Description

INFOID:000000009266550

The oil pressure warning lamp stays of when the ignition switch is turned ON.

Diagnosis Procedure

INFOID:000000009266551

1. CHECK COMBINATION METER OIL PRESSURE WARNING LIGHT

1. Select METER/M&A on CONSULT.
2. Observe OIL W/L DATA MONITOR while operating the ignition switch.

Component	Condition	CONSULT
Oil pressure warning light	Ignition ON	ON
	Ignition OFF	OFF

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace combination meter. Refer to [MWI-104, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[TYPE B]

THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

Description

INFOID:000000009266552

The oil pressure warning lamp remains on while the engine is running (normal oil pressure).

Diagnosis Procedure

INFOID:000000009266553

1. CHECK COMBINATION METER INPUT SIGNAL

1. Start the engine and select METER/M&A on CONSULT.
2. Observe OIL W/L DATA MONITOR and the operation of the oil pressure warning lamp on the combination meter.

Component	Condition	CONSULT
Oil pressure warning light	Engine running	OFF

Is the inspection result normal?

- YES >> Perform ECM self-diagnosis. Refer to [EC-61, "CONSULT Function"](#).
- NO >> Replace combination meter. Refer to [MWI-104, "Removal and Installation"](#).

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

[TYPE B]

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000009266554

- The warning is still displayed even after washer fluid is added.
- The warning is not displayed even though the washer tank is empty.

Diagnosis Procedure

INFOID:000000009266555

1. CHECK WASHER FLUID LEVEL SWITCH

Perform a unit check for the washer fluid level switch. Refer to [MWI-99. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Replace washer fluid level switch. Refer to [WW-49. "Exploded View"](#).

2. CHECK WASHER FLUID LEVEL SWITCH SIGNAL CIRCUIT

Check the washer fluid level switch signal circuit. Refer to [MWI-99. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-104. "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMBINATION METER

< REMOVAL AND INSTALLATION >

[TYPE B]

REMOVAL AND INSTALLATION

COMBINATION METER

Removal and Installation


INFOID:000000009266556

REMOVAL

1. Disconnect the negative battery terminal. Refer to [PG-63. "Removal and Installation"](#).
2. Remove cluster lid A. Refer to [IP-19. "Removal and Installation"](#).
3. Remove the combination meter screws.
4. Pull the combination meter straight out to disengage resin clips.

NOTE:

The illustration shows the clip positions on the back of the combination meter.



JSNIA3895ZZ

5. Disconnect the harness connector from the combination meter and remove.

INSTALLATION

Installation is in the reverse order of removal.

COMBINATION METER

< UNIT DISASSEMBLY AND ASSEMBLY >


[TYPE B]

UNIT DISASSEMBLY AND ASSEMBLY

COMBINATION METER

Exploded View

INFOID:000000009266557



1. Unified meter control unit
2. Front cover
3. Finisher

Disassembly and Assembly

INFOID:000000009266558

DISASSEMBLY

1. Disengage the pawls of the finisher using a suitable tool and remove the finisher.
2. Remove the screws of the front cover.
3. Disengage the pawls of the front cover using a suitable tool.
4. Pull the front cover straight out to remove from the unified meter control unit.

CAUTION:

- Do not touch the display, pointer, the inside of front cover and the printed area of the dial during the work.
- Keep away from magnetic sources.
- Do not damage the front cover.

ASSEMBLY

Assembly is in the reverse order of disassembly.

CAUTION:

- Do not touch the display, pointer, the inside of front cover and the printed area of the dial during the work.
- Keep away from magnetic sources.
- Do not damage the front cover.