

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN

<p>PRECAUTIONS 4</p> <p> Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 4</p> <p> Precautions When Using CONSULT-II 4</p> <p> CHECK POINTS FOR USING CONSULT-II 4</p> <p> Precautions For Trouble Diagnosis 4</p> <p> CAN SYSTEM 4</p> <p> Precautions For Harness Repair 5</p> <p> CAN SYSTEM 5</p> <p>TROUBLE DIAGNOSES WORK FLOW 6</p> <p> When Displaying CAN Communication System Errors 6</p> <p> WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM 6</p> <p> WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM 6</p> <p> TROUBLE DIAGNOSIS FLOW CHART 7</p> <p> Diagnosis Procedure 8</p> <p> SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE) 8</p> <p> ACQUISITION OF DATA BY CONSULT-II 9</p> <p> HOW TO USE CHECK SHEET TABLE 10</p> <p> CAN Diagnostic Support Monitor 16</p> <p> DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM 16</p> <p> DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM 17</p> <p> DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR DIFFERENTIAL LOCK CONTROL UNIT 17</p> <p> DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR BCM 18</p> <p> DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TRANSFER CONTROL UNIT 18</p> <p> DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ABS ACTUATOR AND</p>	<p>ELECTRIC UNIT (CONTROL UNIT) 19</p> <p>DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR IPDM E/R 20</p> <p>CAN COMMUNICATION 21</p> <p> System Description 21</p> <p> CAN Communication Unit 21</p> <p> TYPE 1 22</p> <p> TYPE 2 24</p> <p> TYPE 3 25</p> <p> TYPE 4 26</p> <p> TYPE 5 28</p> <p> TYPE 6/ TYPE 7 30</p> <p> TYPE 8/ TYPE 9 32</p> <p> TYPE 10 34</p> <p> TYPE 11/ TYPE 12 36</p> <p>CAN SYSTEM (TYPE 1) 39</p> <p> System Description 39</p> <p> Component Parts and Harness Connector Location.. 39</p> <p> Schematic 40</p> <p> Wiring Diagram — CAN — 41</p> <p> CHECK SHEET 44</p> <p> CHECK SHEET RESULTS (EXAMPLE) 46</p> <p> Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit 53</p> <p> ECM Circuit Inspection 54</p> <p> Data Link Connector Circuit Inspection 55</p> <p> BCM Circuit Inspection 55</p> <p> Combination Meter Circuit Inspection 56</p> <p> ABS Actuator and Electric Unit (Control Unit) Circuit Inspection 56</p> <p> IPDM E/R Circuit Inspection 57</p> <p> CAN Communication Circuit Inspection 58</p> <p> IPDM E/R Ignition Relay Circuit Inspection 61</p> <p>CAN SYSTEM (TYPE 2) 62</p> <p> System Description 62</p> <p> Component Parts and Harness Connector Location.. 62</p> <p> Schematic 63</p> <p> Wiring Diagram — CAN — 64</p> <p> CHECK SHEET 67</p> <p> CHECK SHEET RESULTS (EXAMPLE) 69</p>
---	---

F
G
H
I
J
LAN

L
M

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit	76	Circuit	153
ECM Circuit Inspection	77	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	154
Data Link Connector Circuit Inspection	78	ECM Circuit Inspection	155
BCM Circuit Inspection	78	TCM Circuit Inspection	156
Combination Meter Circuit Inspection	79	Steering Angle Sensor Circuit Inspection	156
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	79	Data Link Connector Circuit Inspection	157
IPDM E/R Circuit Inspection	80	BCM Circuit Inspection	157
CAN Communication Circuit Inspection	81	Combination Meter Circuit Inspection	158
IPDM E/R Ignition Relay Circuit Inspection	84	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	158
CAN SYSTEM (TYPE 3)	85	IPDM E/R Circuit Inspection	159
System Description	85	CAN Communication Circuit Inspection	160
Component Parts and Harness Connector Location ..	85	IPDM E/R Ignition Relay Circuit Inspection	164
Schematic	86	CAN SYSTEM (TYPE 6)	165
Wiring Diagram — CAN —	87	System Description	165
CHECK SHEET	90	Component Parts and Harness Connector Location ..	165
CHECK SHEET RESULTS (EXAMPLE)	92	Schematic	166
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	100	Wiring Diagram — CAN —	167
ECM Circuit Inspection	101	CHECK SHEET	170
Steering Angle Sensor Circuit Inspection	102	CHECK SHEET RESULTS (EXAMPLE)	172
Data Link Connector Circuit Inspection	102	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	180
BCM Circuit Inspection	103	ECM Circuit Inspection	181
Combination Meter Circuit Inspection	103	Data Link Connector Circuit Inspection	182
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	104	BCM Circuit Inspection	182
IPDM E/R Circuit Inspection	104	Combination Meter Circuit Inspection	183
CAN Communication Circuit Inspection	105	Transfer Control Unit Circuit Inspection	183
IPDM E/R Ignition Relay Circuit Inspection	108	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	184
CAN SYSTEM (TYPE 4)	109	IPDM E/R Circuit Inspection	184
System Description	109	CAN Communication Circuit Inspection	185
Component Parts and Harness Connector Location ..	109	IPDM E/R Ignition Relay Circuit Inspection	188
Schematic	110	CAN SYSTEM (TYPE 7)	189
Wiring Diagram — CAN —	111	System Description	189
CHECK SHEET	114	Component Parts and Harness Connector Location ..	189
CHECK SHEET RESULTS (EXAMPLE)	116	Schematic	190
Inspection Between TCM and Data Link Connector Circuit	125	Wiring Diagram — CAN —	191
Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	126	CHECK SHEET	194
ECM Circuit Inspection	127	CHECK SHEET RESULTS (EXAMPLE)	196
TCM Circuit Inspection	128	Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit ...	205
Data Link Connector Circuit Inspection	128	ECM Circuit Inspection	206
BCM Circuit Inspection	129	Differential Lock Control Unit Circuit Inspection ...	207
Combination Meter Circuit Inspection	129	Data Link Connector Circuit Inspection	207
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	130	BCM Circuit Inspection	208
IPDM E/R Circuit Inspection	130	Combination Meter Circuit Inspection	208
CAN Communication Circuit Inspection	131	Transfer Control Unit Circuit Inspection	209
IPDM E/R Ignition Relay Circuit Inspection	135	ABS Actuator and Electric Unit (Control Unit) Circuit Inspection	209
CAN SYSTEM (TYPE 5)	136	IPDM E/R Circuit Inspection	210
System Description	136	CAN Communication Circuit Inspection	211
Component Parts and Harness Connector Location ..	136	IPDM E/R Ignition Relay Circuit Inspection	214
Schematic	137	CAN SYSTEM (TYPE 8)	215
Wiring Diagram — CAN —	138	System Description	215
CHECK SHEET	141	Component Parts and Harness Connector Location ..	215
CHECK SHEET RESULTS (EXAMPLE)	143	Schematic	216
Inspection Between TCM and Data Link Connector Circuit	153	Wiring Diagram — CAN —	217
		CHECK SHEET	220

CHECK SHEET RESULTS (EXAMPLE)	222	ABS Actuator and Electric Unit (Control Unit) Circuit	
Inspection Between Data Link Connector and ABS		Inspection	290
Actuator and Electric Unit (Control Unit) Circuit ..	231	IPDM E/R Circuit Inspection	291
ECM Circuit Inspection	232	CAN Communication Circuit Inspection	292
Steering Angle Sensor Circuit Inspection	233	IPDM E/R Ignition Relay Circuit Inspection	296
Data Link Connector Circuit Inspection	233	CAN SYSTEM (TYPE 11)	297
BCM Circuit Inspection	234	System Description	297
Combination Meter Circuit Inspection	234	Component Parts and Harness Connector Location	297
Transfer Control Unit Circuit Inspection	235	Schematic	298
ABS Actuator and Electric Unit (Control Unit) Circuit		Wiring Diagram — CAN —	299
Inspection	235	CHECK SHEET	302
IPDM E/R Circuit Inspection	236	CHECK SHEET RESULTS (EXAMPLE)	304
CAN Communication Circuit Inspection	237	Inspection Between TCM and Data Link Connector	
IPDM E/R Ignition Relay Circuit Inspection	240	Circuit	315
CAN SYSTEM (TYPE 9)	241	Inspection Between Data Link Connector and ABS	
System Description	241	Actuator and Electric Unit (Control Unit) Circuit ..	316
Component Parts and Harness Connector Location	241	ECM Circuit Inspection	317
Schematic	242	TCM Circuit Inspection	318
Wiring Diagram — CAN —	243	Steering Angle Sensor Circuit Inspection	318
CHECK SHEET	246	Data Link Connector Circuit Inspection	319
CHECK SHEET RESULTS (EXAMPLE)	248	BCM Circuit Inspection	319
Inspection Between Data Link Connector and ABS		Combination Meter Circuit Inspection	320
Actuator and Electric Unit (Control Unit) Circuit ..	258	Transfer Control Unit Circuit Inspection	320
ECM Circuit Inspection	259	ABS Actuator and Electric Unit (Control Unit) Circuit	
Differential Lock Control Unit Circuit Inspection ..	260	Inspection	321
Steering Angle Sensor Circuit Inspection	260	IPDM E/R Circuit Inspection	321
Data Link Connector Circuit Inspection	261	CAN Communication Circuit Inspection	322
BCM Circuit Inspection	261	IPDM E/R Ignition Relay Circuit Inspection	326
Combination Meter Circuit Inspection	262	CAN SYSTEM (TYPE 12)	327
Transfer Control Unit Circuit Inspection	262	System Description	327
ABS Actuator and Electric Unit (Control Unit) Circuit		Component Parts and Harness Connector Location	327
Inspection	263	Schematic	328
IPDM E/R Circuit Inspection	263	Wiring Diagram — CAN —	329
CAN Communication Circuit Inspection	264	CHECK SHEET	332
IPDM E/R Ignition Relay Circuit Inspection	267	CHECK SHEET RESULTS (EXAMPLE)	334
CAN SYSTEM (TYPE 10)	268	Inspection Between TCM and Data Link Connector	
System Description	268	Circuit	346
Component Parts and Harness Connector Location	268	Inspection Between Data Link Connector and ABS	
Schematic	269	Actuator and Electric Unit (Control Unit) Circuit ..	347
Wiring Diagram — CAN —	270	ECM Circuit Inspection	348
CHECK SHEET	273	TCM Circuit Inspection	349
CHECK SHEET RESULTS (EXAMPLE)	275	Differential Lock Control Unit Circuit Inspection ..	349
Inspection Between TCM and Data Link Connector		Steering Angle Sensor Circuit Inspection	350
Circuit	285	Data Link Connector Circuit Inspection	350
Inspection Between Data Link Connector and ABS		BCM Circuit Inspection	351
Actuator and Electric Unit (Control Unit) Circuit ..	286	Combination Meter Circuit Inspection	351
ECM Circuit Inspection	287	Transfer Control Unit Circuit Inspection	352
TCM Circuit Inspection	288	ABS Actuator and Electric Unit (Control Unit) Circuit	
Data Link Connector Circuit Inspection	288	Inspection	352
BCM Circuit Inspection	289	IPDM E/R Circuit Inspection	353
Combination Meter Circuit Inspection	289	CAN Communication Circuit Inspection	354
Transfer Control Unit Circuit Inspection	290	IPDM E/R Ignition Relay Circuit Inspection	358

PRECAUTIONS**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

UKS0017I

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

UKS0017J

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-6. "TROUBLE DIAGNOSES WORK FLOW"](#) .


**Precautions For Trouble Diagnosis
CAN SYSTEM**

UKS0017K


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.

Precautions For Harness Repair
CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

PF0:00004

When Displaying CAN Communication System Errors

UKS0046G


WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM

- CAN communication line is open. (CAN H, CAN L, or both)
- CAN communication line is shorted. (Ground, between CAN lines, or other harnesses)
- The areas related to CAN communication of unit is malfunctioning.

WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM

- Removal and installation of parts : When the units that perform CAN communication or the sensors related to CAN communication are removed and installed, malfunction may be detected (or DTC other than CAN communication may be detected).
- Fuse blown out (removed): CAN communication of the unit may be stopped at such time.
- Low voltage : If the voltage decreases because of battery discharge when IGN is ON, malfunction may be detected by self-diagnosis according to the units.

TROUBLE DIAGNOSIS FLOW CHART



- Step 1 : Refer to [LAN-8, "SELECTING CAN SYSTEM TYPE \(HOW TO USE SPECIFICATION TABLE\)"](#) .
- Step 2 : Refer to [LAN-9, "ACQUISITION OF DATA BY CONSULT-II"](#) .
- Step 3 : Refer to [LAN-10, "HOW TO USE CHECK SHEET TABLE"](#) .
- Step 4 : Refer to [LAN-11, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- Step 5 : Check and repair according to system diagnosis.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS0046H

Diagnosis Procedure

SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)

Determine CAN system type from the equipment of the vehicle to select applicable check sheet.

(Example) Wagon/4WD/VQ40DE/AT/VDC/Without electronic locking rear differential

CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Wagon															
Axle	2WD						4WD									
Engine	VQ40DE															
Transmission	M/T				A/T				M/T				A/T			
Brake control	ABS	ABLS	VDC	ABS	VDC	ABLS	VDC	ABLS	VDC	ABLS	VDC	ABLS	VDC			
Electronic locking rear differential						X		X				X				
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12				
CAN system trouble diagnosis	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.	.XX. .YY.			

Check basic specification of the vehicle.

Select "x" if it is model with electronic locking rear differential.

Which number is selected when sequentially selecting from the top of the specification table?
The number is "CAN system type" of the applicable vehicle.

In the case of this example:
It corresponds to type 11.

X: Applicable

PKIB9481E

TROUBLE DIAGNOSES WORK FLOW

[CAN]

ACQUISITION OF DATA BY CONSULT-II

Attach the data acquired by CONSULT-II on the check sheet determined according to CAN system type.

Copy "SELECT SYSTEM" screen of CONSULT-II.

SELECT SYSTEM	
ENGINE	
A/T	
ABS	
AIR BAG	
IPDM E/R	
METER	
Page Down	
BACK	LIGHT COPY

SELECT SYSTEM	
A/T	
ABS	
AIR BAG	
IPDM E/R	
METER	
ALL MODE AWD/4WD	
Page Up	
BACK	LIGHT COPY

Check sheet table

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS			
			ECM	TCM	STRG	BCM	METER	AWD/4WD	VDC/TCS/ABS	IPDM E/R	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
ENGINE	--	NG	UNKNWN	--	UNKNWN	--	UNKNWN	UNKNWN	UNKNWN	UNKNWN	UNKNWN	--	--
A/T	--	NG	UNKNWN	--	UNKNWN	--	UNKNWN	UNKNWN	UNKNWN	UNKNWN	UNKNWN	--	--
BCM	No indication	NG	UNKNWN	--	UNKNWN	--	UNKNWN	UNKNWN	UNKNWN	UNKNWN	UNKNWN	--	--
METER	No indication	--	--	--	--	--	--	--	--	--	--	--	--
ALL MODE AWD/4WD	--	NG	UNKNWN	UNKNWN	UNKNWN	--	--	UNKNWN	--	UNKNWN	--	--	--
ABS	--	NG	UNKNWN	UNKNWN	UNKNWN	UNKNWN	--	--	UNKNWN	--	--	--	--
IPDM E/R	No indication	--	UNKNWN	UNKNWN	UNKNWN	--	--	UNKNWN	--	UNKNWN	--	--	--

Symptoms :

Attach copy of SELECT SYSTEM

Attach copy of SELECT SYSTEM

Copy "SELF-DIAG RESULTS" screen of CONSULT-II.

SELF-DIAG RESULTS	
DTC RESULTS TIME	
CAN COMM CIRCUIT (U1000)	
ERASE PRINT	
MODE BACK LIGHT COPY	

SELF-DIAG RESULTS	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
ERASE PRINT	
MODE BACK LIGHT COPY	

Attach copy of ENGINE SELF-DIAG RESULTS

Attach copy of A/T SELF-DIAG RESULTS

Attach copy of BCM SELF-DIAG RESULTS

Attach copy of METER SELF-DIAG RESULTS

Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS

Attach copy of ABS SELF-DIAG RESULTS

Attach copy of IPDM E/R SELF-DIAG RESULTS

Copy "CAN DIAG SUPPORT MNTR" screen of CONSULT-II.

CAN DIAG SUPPORT MNTR	
ENGINE	
PRSNLT	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METERM&A	OK
ICC	UNKNWN
BCM/SEC	UNKNWN
IPDM E/R	OK
AWD/4WD/4WD	OK
PRINT Scroll Down	
MODE	BACK LIGHT COPY

CAN DIAG SUPPORT MNTR	
ABS	
PRSNLT	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
TCM	OK
METERM&A	UNKNWN
STRG	OK
ICC	UNKNWN
AWD/4WD	OK
PRINT	
MODE	BACK LIGHT COPY

CAN DIAG SUPPORT MNTR	
IPDM E/R	
PRSNLT	
TRANSMIT DIAG	OK
ECM	OK
BCM/SEC	UNKNWN
PRINT	
MODE	BACK LIGHT COPY

Attach copy of ENGINE CAN DIAG SUPPORT MNTR

Attach copy of A/T CAN DIAG SUPPORT MNTR

Attach copy of BCM CAN DIAG SUPPORT MNTR

Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR

Attach copy of ABS CAN DIAG SUPPORT MNTR

HOW TO USE CHECK SHEET TABLE

Use when the initial conditions are reproduced Use when the initial conditions are not reproduced

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R			
			ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

① ② ③ ④ ⑤

PKIB7197E

1. Unit names displayed on CONSULT-II.
2. “No indication” : Put a check mark to it if the unit name described in step 1 is not displayed on “SELECT SYSTEM” screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)
“—” : Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
3. “NG” : Display “NG” when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if “NG” is displayed.
“—” : Column not used (Initial diagnosis is not performed.)
4. “UNKWN” : Display “UNKWN” when the diagnosed unit does not transmit the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—” : Column not used (Transmit diagnosis is not performed.)
5. “UNKWN” : Display “UNKWN” when the diagnosed unit does not receive the data normally. Put a check mark to it if “UNKWN” is displayed on CONSULT-II.
“—” : Column not used (It is not necessary for CAN communication trouble diagnosis.)

NOTE:

CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- When the initial conditions are reproduced. Refer to [LAN-11, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- When the initial conditions are not reproduced. Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) .

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Reproduced

ENGINE	
PRSN	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	UNKWN
IPDM E/R	OK
AWD/4WD/e4WD	OK
PRINT	Scroll Down
MODE	BACK LIGHT COPY

ENGINE	
PRSN	
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	UNKWN
IPDM E/R	OK
AWD/4WD/e4WD	OK
EPS	UNKWN
PRINT	Scroll Up
MODE	BACK LIGHT COPY

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
	Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R		
			ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

ENGINE
A/T
ABS
AIR BAG
IPDM E/R
METER
Page Down
BACK LIGHT COPY

A/T
ABS
AIR BAG
IPDM E/R
METER
ALL MODE AWD/4WD
Page Up
BACK LIGHT COPY

PKIB7198E

- Put a check mark to "No indication" if some of unit names listed on the column of diagnosis system selection screen of a check sheet table are not displayed on "SELECT SYSTEM" screen attached to the check sheet.

NOTE:

Put a check mark to "No indication" of BCM because BCM is not displayed on "SELECT SYSTEM" screen.


- Confirm the unit name that "UNKWN" is displayed from the copy of "CAN DIAG SUPPORT MNTR" screen of "ENGINE" attached to the check sheet, and then put a check mark to the check sheet table.

NOTE:

In "CAN DIAG SUPPORT MNTR" screen, "UNKWN" is displayed on "ICC", "BCM/SEC" and "EPS". But put a check mark to "BCM/SEC" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.

TROUBLE DIAGNOSES WORK FLOW

[CAN]



PKIB7199E

3. Confirm the unit name that “UNKWVN” is displayed on the copy of “CAN DIAG SUPPORT MNTR” screen of “A/T”, “ALL MODE AWD/4WD”, “ABS” and “IPDM E/R” as well as “ENGINE”. And then, put a check mark to the check sheet table.

NOTE:

- For “A/T”, “UNKWVN” is displayed on “ICC/e4WD”. But, do not put a check mark to their columns of reception diagnosis of the check sheet table because “UNKWVN” is not listed.
- For “ALL MODE AWD/4WD”, “UNKWVN” is not displayed“. Do not put a check mark to it.
- For “ABS”, “UNKWVN” is displayed on “ICC”. But, do not put a check mark to their columns of reception diagnosis of the check sheet table because “UNKWVN” is not listed.
- For “IPDM E/R”, “UNKWVN” is displayed on “BCM/SEC”. Put a check mark to it.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of CAN diagnosis support monitor

Check sheet table


SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R			
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Choose similar indications between the results of CAN diagnosis support monitor and the results of the check sheet. Malfunctioning parts are found.

Case 7
Check BCM circuit.

Check sheet results (example)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R			
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—



PKIB7200E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT [U1000]" in "Check sheet results (example)" change to "—". Then, ignore check marks on the check sheet table.

4. Perform system diagnosis for possible causes identified.
5. Perform diagnosis again after inspection and repair. Make sure that repair is completely performed, and then end the procedure.

Start CAN system trouble diagnosis if this procedure can be confirmed. Refer to [LAN-21, "CAN Communication Unit"](#).

TROUBLE DIAGNOSES WORK FLOW

[CAN]

Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SYSTEM ENGINE

SELF-DIAG RESULTS

DTC RESULTS TIME

CAN COMM CIRCUIT [U1001] 1t

SYSTEM A/T

SELF-DIAG RESULTS

DTC RESULTS

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM BCM

SELF-DIAG RESULTS

DTC RESULTS TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM METER

SELF-DIAG RESULTS

DTC RESULTS TIME

CAN COMM CIRCUIT [U1000] 2

SYSTEM ALL MODE AWD/4WD

SELF-DIAG RESULTS

DTC RESULTS

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM ABS

SELF-DIAG RESULTS

DTC RESULTS TIME

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.

SYSTEM IPDM E/R

SELF-DIAG RESULTS

DTC RESULTS TIME

CAN COMM CIRCUIT [U1000] PAST

PKIB7201E

- See “SELF-DIAG RESULTS” of all units attached to the check sheet. If “CAN COMM CIRCUIT”, “CAN COMM CIRCUIT [U1000]” or “CAN COMM CIRCUIT [U1001]” is displayed, put a check mark to the applicable column of self-diagnostic results of the check sheet table.

NOTE:

- For “ENGINE”, “CAN COMM CIRCUIT [U1001]” are displayed. Put a check mark to it.
- For “A/T”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “BCM”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “METER”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.
- For “ALL MODE AWD/4WD”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “ABS”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “IPDM E/R”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

The arranged results of self-diagnosis

Check sheet table

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
			Receive diagnosis							Receive diagnosis					
			ECM	TCM	STRG	BCM /SEC	METER /M/A	AWD/4WD /MWD	VDC/TCS /ABS	IPDM E/R	BCM /SEC	METER /M/A			AWD/4WD /MWD
ENGINE	-	NG	UNKNW	-	UNKNW	-	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
A/T	-	NG	UNKNW	UNKNW	-	-	-	UNKNW	UNKNW	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
BCM	No indication	NG	UNKNW	UNKNW	-	-	-	UNKNW	UNKNW	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
METER	No indication	-	-	-	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	-	NG	UNKNW	UNKNW	UNKNW	UNKNW	-	UNKNW	-	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKNW	UNKNW	UNKNW	UNKNW	-	-	UNKNW	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indication	-	UNKNW	UNKNW	-	-	-	UNKNW	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-



When the arranged results of self-diagnosis and check sheet results (example) are corresponding, possible causes can be selected.

Case 7
Check BCM circuit.

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
			Receive diagnosis							Receive diagnosis					
			ECM	TCM	STRG	BCM /SEC	METER /M/A	AWD/4WD /MWD	VDC/TCS /ABS	IPDM E/R	BCM /SEC	METER /M/A			AWD/4WD /MWD
ENGINE	-	NG	UNKNW	-	UNKNW	-	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
A/T	-	NG	UNKNW	UNKNW	-	-	-	UNKNW	UNKNW	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
BCM	No indication	NG	UNKNW	UNKNW	-	-	-	UNKNW	UNKNW	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
METER	No indication	-	-	-	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	-	NG	UNKNW	UNKNW	UNKNW	UNKNW	-	UNKNW	-	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKNW	UNKNW	UNKNW	UNKNW	-	-	UNKNW	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indication	-	UNKNW	UNKNW	-	-	-	UNKNW	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-

Case 11
Check IPDM E/R circuit.

SELECT SYSTEM screen	Initial diagnosis	Transfer diagnosis	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
			Receive diagnosis							Receive diagnosis					
			ECM	TCM	STRG	BCM /SEC	METER /M/A	AWD/4WD /MWD	VDC/TCS /ABS	IPDM E/R	BCM /SEC	METER /M/A			AWD/4WD /MWD
ENGINE	-	NG	UNKNW	-	UNKNW	-	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	UNKNW	CAN COMM CIRCUIT [U1000]	CAN COMM CIRCUIT [U1001]
A/T	-	NG	UNKNW	UNKNW	-	-	-	UNKNW	UNKNW	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
BCM	No indication	NG	UNKNW	UNKNW	-	-	-	UNKNW	UNKNW	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
METER	No indication	-	-	-	-	-	-	-	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
ALL MODE AWD/4WD	-	NG	UNKNW	UNKNW	UNKNW	UNKNW	-	UNKNW	-	UNKNW	-	-	-	CAN COMM CIRCUIT [U1000]	-
ABS	-	NG	UNKNW	UNKNW	UNKNW	UNKNW	-	-	UNKNW	-	-	-	-	CAN COMM CIRCUIT [U1000]	-
IPDM E/R	No indication	-	UNKNW	UNKNW	-	-	-	UNKNW	-	-	-	-	-	CAN COMM CIRCUIT [U1000]	-



PKIB7202E

NOTE:

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKNW" and "CAN COMM CIRCUIT [U1000]" in "Check sheet results (example)" change to "-". Then, ignore check marks on the check sheet table.

2. For the selected possible causes, it is expected that malfunctions have been found in the past.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS0046I

CAN Diagnostic Support Monitor

DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM

(Example)	CAN DIAG SUPPORT MNTR	CAN DIAG SUPPORT MNTR																																																								
	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td></td><td style="text-align: right;">PRSNT</td></tr> <tr><td>INITIAL DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TCM</td><td style="text-align: right;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: right;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: right;">OK</td></tr> <tr><td>ICC</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: right;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: right;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>PRINT</td><td style="text-align: right;">Scroll Down</td></tr> <tr><td>MODE</td><td>BACK</td></tr> <tr><td>LIGHT</td><td>COPY</td></tr> </table>	ENGINE			PRSNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	PRINT	Scroll Down	MODE	BACK	LIGHT	COPY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td></td><td style="text-align: right;">PRSNT</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TCM</td><td style="text-align: right;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: right;">OK</td></tr> <tr><td>METER/M&A</td><td style="text-align: right;">OK</td></tr> <tr><td>ICC</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: right;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: right;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>EPS</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>PRINT</td><td style="text-align: right;">Scroll Up</td></tr> <tr><td>MODE</td><td>BACK</td></tr> <tr><td>LIGHT</td><td>COPY</td></tr> </table>	ENGINE			PRSNT	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	EPS	UNKWN	PRINT	Scroll Up	MODE	BACK	LIGHT	COPY
ENGINE																																																										
	PRSNT																																																									
INITIAL DIAG	OK																																																									
TRANSMIT DIAG	OK																																																									
TCM	OK																																																									
VDC/TCS/ABS	OK																																																									
METER/M&A	OK																																																									
ICC	UNKWN																																																									
BCM/SEC	OK																																																									
IPDM E/R	OK																																																									
AWD/4WD/e4WD	UNKWN																																																									
PRINT	Scroll Down																																																									
MODE	BACK																																																									
LIGHT	COPY																																																									
ENGINE																																																										
	PRSNT																																																									
TRANSMIT DIAG	OK																																																									
TCM	OK																																																									
VDC/TCS/ABS	OK																																																									
METER/M&A	OK																																																									
ICC	UNKWN																																																									
BCM/SEC	OK																																																									
IPDM E/R	OK																																																									
AWD/4WD/e4WD	UNKWN																																																									
EPS	UNKWN																																																									
PRINT	Scroll Up																																																									
MODE	BACK																																																									
LIGHT	COPY																																																									
		SKIB0591E																																																								

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
ENGINE	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC	ICC is not diagnosed.	UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	AWD/4WD/e4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN
EPS	EPS is not diagnosed.	UNKWN	

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TCM

(Example) CAN DIAG SUPPORT MNTR

A/T	
PRSN	OK
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC/e4WD	UNKWN
AWD/4WD	OK
PRINT	
MODE	BACK
LIGHT	COPY

SKIB2335E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
A/T	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC/e4WD	ICC/e4WD is not diagnosed.	UNKWN
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR DIFFERENTIAL LOCK CONTROL UNIT

(Example) CAN DIAG SUPPORT MNTR

DIFF LOCK	
PRSN	OK
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	OK
VDC/TCS/ABS	OK
AWD/4WD	OK
PRINT	
MODE	BACK
LIGHT	COPY

PKIB7196E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
DIFF LOCK	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR BCM

(Example) CAN DIAG SUPPORT MNTR

BCM			
			PRSNT
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
IPDM E/R	OK		
METER/M&A	UNKWVN		
I-KEY	OK		
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0593E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
BCM	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWVN
	ECM	Make sure of normal reception from ECM.	OK/UNKWVN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWVN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWVN
	I-KEY	I-KEY is not diagnosed.	OK

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWVN : The diagnosed unit does not transmit or receive the applicable data normally.

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR TRANSFER CONTROL UNIT

(Example) CAN DIAG SUPPORT MNTR

ALL MODE AWD/4WD			
			PRSNT
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
VDC/TCS/ABS	OK		
TCM	UNKWVN		
METER/M&A	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIB5232E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ALL MODE AWD/ 4WD	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWVN
	ECM	Make sure of normal reception from ECM.	OK/UNKWVN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWVN
	TCM	Make sure of normal reception from TCM.	OK/UNKWVN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWVN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWVN : The diagnosed unit does not transmit or receive the applicable data normally.

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

(Example)

CAN DIAG SUPPORT MNTR			
ABS			
	PRSENT		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
TCM	OK		
METER/M&A	UNKWVN		
STRG	OK		
ICC	UNKWVN		
AWD/4WD	OK		
DIFF LOCK	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIB7433E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWVN
	ECM	Make sure of normal reception from ECM.	OK/UNKWVN
	TCM	Make sure of normal reception from TCM.	OK/UNKWVN
	METER/M&A	METER/M&A is not diagnosed.	UNKWVN
	STRG	Make sure of normal reception from steering angle sensor.	OK/UNKWVN
	ICC	ICC is not diagnosed.	UNKWVN
	AWD/4WD	Make sure of normal reception from transfer control unit.	OK/UNKWVN
	DIFF LOCK	Make sure of normal reception from differential lock control unit.	OK/UNKWVN

Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWVN : The diagnosed unit does not transmit or receive the applicable data normally.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

TROUBLE DIAGNOSES WORK FLOW

[CAN]

DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR IPDM E/R

(Example) CAN DIAG SUPPORT MNTR

IPDM E/R			
	PRSNLT	PAST	
TRANSMIT DIAG	OK	OK	
ECM	OK	OK	
BCM/SEC	OK	OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0595E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	Past
IPDM E/R	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/–	OK/0/1~39/–
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/–	
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/–	

Display Results (Present)

- OK : Normal
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.
- – : There is no received unit or the unit is not in the condition that reception diagnosis is performed.

Display Results (Past)

- OK : Normal
- 0 : There is malfunction now.
- 1 ~ 39 : Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- – : Undiagnosed

CAN COMMUNICATION

System Description

UKS0046J

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

UKS0046K

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Wagon											
Axle	2WD						4WD					
Engine	VQ40DE											
Transmission	M/T			A/T			M/T			A/T		
Brake control	ABS	ABLS	VDC	ABS	VDC	ABLS	VDC	ABLS	VDC	ABLS	VDC	
Electronic locking rear differential							×		×			×
CAN system type	1	2	3	4	5	6	7	8	9	10	11	12
CAN system trouble diagnosis	LAN-39	LAN-62	LAN-85	LAN-109	LAN-136	LAN-165	LAN-189	LAN-215	LAN-241	LAN-268	LAN-297	LAN-327

×: Applicable


NOTE:

Confirming the presence of the following items helps to identify CAN system type.

- Models with 4WD




- Models with VDC




CAN COMMUNICATION

[CAN]

- Models with ABL S




- Models with electronic locking rear differential



TYPE 1

System diagram

- Type 1



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T		R		
Engine status signal	T	R			
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T				
A/C switch signal	R	T			
A/C compressor request signal	T				R

CAN COMMUNICATION


[CAN]

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R	
Blower fan motor switch signal	R	T				A
Cooling fan speed request signal	T				R	B
Low beam request signal		T			R	
Low beam status signal	R				T	C
High beam request signal		T	R		R	
High beam status signal	R				T	
Position light request signal		T			R	D
Front fog light request signal		T	R		R	
Day time running light request signal		T			R	
Sleep wake up signal		T	R		R	E
Door switch signal		T	R		R	
Seat belt buckle switch signal		R	T			F
Ignition switch signal		T			R	
Theft warning horn request signal		T			R	
Horn chirp signal		T			R	G
Front wiper request signal		T			R	
Front wiper stop position signal		R			T	H
Rear window defogger switch signal		T			R	
Rear window defogger control signal	R				T	
Buzzer output signal		T	R			I
Fuel consumption monitor signal	T		R			
Fuel level sensor signal	R		T			J
Turn indicator signal		T	R			
Brake warning lamp signal			R	T		
ABS warning lamp signal			R	T		LAN
Malfunction indicator lamp signal	T		R			
ASCD CRUISE lamp signal	T		R			L
ASCD SET lamp signal	T		R			
Vehicle speed signal	R		R	T		
	R	R	T			M
Power generation command value signal	T				R	

TYPE 2

System diagram

- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T		R	R	
Engine status signal	T	R			
Engine coolant temperature signal	T		R		
Accelerator pedal position signal	T			R	
A/C switch signal	R	T			
A/C compressor request signal	T				R
Blower fan motor switch signal	R	T			
Cooling fan speed request signal	T				R
Low beam request signal		T			R
Low beam status signal	R				T
High beam request signal		T	R		R
High beam status signal	R				T
Position light request signal		T			R
Front fog light request signal		T	R		R
Day time running light request signal		T			R
Sleep wake up signal		T	R		R
Door switch signal		T	R		R
Seat belt buckle switch signal		R	T		
Ignition switch signal		T			R
Theft warning horn request signal		T			R
Horn chirp signal		T			R
Front wiper request signal		T			R
Front wiper stop position signal		R			T
Rear window defogger switch signal		T			R
Rear window defogger control signal	R				T

CAN COMMUNICATION


[CAN]

Signals	ECM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Buzzer output signal		T	R		
Fuel consumption monitor signal	T		R		
Fuel level sensor signal	R		T		
Turn indicator signal		T	R		
Brake warning lamp signal			R	T	
ABS warning lamp signal			R	T	
SLIP indicator lamp signal			R	T	
Malfunction indicator lamp signal	T		R		
ASCD CRUISE lamp signal	T		R		
ASCD SET lamp signal	T		R		
Vehicle speed signal	R		R	T	
	R	R	T		
Power generation command value signal	T				R

TYPE 3

System diagram


- Type 3



TYPE 4

System diagram

- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R		
Engine status signal	T		R			
Engine coolant temperature signal	T			R		
Accelerator pedal position signal	T	R				
Closed throttle position signal	T	R				
Wide open throttle position signal	T	R				
Battery voltage signal	T	R				
A/T self-diagnosis signal	R	T				
Turbine revolution signal	R	T				
Output shaft revolution signal	R	T				
A/C switch signal	R		T			
A/C compressor request signal	T	R				R
Blower fan motor switch signal	R		T			
Cooling fan speed request signal	T					R
Low beam request signal			T			R
Low beam status signal	R					T
High beam request signal			T	R		R
High beam status signal	R					T
Position light request signal			T			R
Front fog light request signal			T	R		R
Day time running light request signal			T			R
Sleep wake up signal			T	R		R
Door switch signal			T	R		R
Seat belt buckle switch signal			R	T		

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Ignition switch signal			T			R
Theft warning horn request signal			T			R
Horn chirp signal			T			R
Front wiper request signal			T			R
Front wiper stop position signal			R			T
Rear window defogger switch signal			T			R
Rear window defogger control signal	R					T
Buzzer output signal			T	R		
Fuel consumption monitor signal	T			R		
Fuel level sensor signal	R			T		
Turn indicator signal			T	R		
Brake warning lamp signal				R	T	
ABS warning lamp signal				R	T	
Malfunction indicator lamp signal	T			R		
ASCD CRUISE lamp signal	T			R		
ASCD SET lamp signal	T			R		
ASCD operation signal	T	R				
ASCD OD cancel request	T	R				
A/T fluid temperature sensor signal	R	T		R		
A/T position indicator lamp signal	R	T		R		
O/D OFF indicator signal		T		R		
Overdrive control switch signal		R		T		
1st position switch signal		R		T		
Stop lamp switch signal		R		T		
Vehicle speed signal	R			R	T	
	R	R	R	T		
Power generation command value signal	T					R

A
B
C
D
E
F
G
H
I
J
LAN
L
M


CAN COMMUNICATION

[CAN]

TYPE 5

System diagram

- Type 5



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Steering angle sensor	BCM	Combina- tion meter	ABS actua- tor and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R			R	R	
Engine status signal	T			R			
Engine coolant temperature signal	T				R		
Accelerator pedal position signal	T	R				R	
Closed throttle position signal	T	R					
Wide open throttle position signal	T	R					
Battery voltage signal	T	R					
A/T self-diagnosis signal	R	T					
Turbine revolution signal	R	T					
Output shaft revolution signal	R	T					
A/C switch signal	R			T			
A/C compressor request signal	T	R					R
Blower fan motor switch signal	R			T			
Cooling fan speed request signal	T						R
Low beam request signal				T			R
Low beam status signal	R						T
High beam request signal				T	R		R
High beam status signal	R						T
Position light request signal				T			R
Front fog light request signal				T	R		R
Day time running light request signal				T			R
Sleep wake up signal				T	R		R
Door switch signal				T	R		R
Seat belt buckle switch signal				R	T		

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Steering angle sensor	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Ignition switch signal				T			R
Theft warning horn request signal				T			R
Horn chirp signal				T			R
Front wiper request signal				T			R
Front wiper stop position signal				R			T
Rear window defogger switch signal				T			R
Rear window defogger control signal	R						T
Buzzer output signal				T	R		
Fuel consumption monitor signal	T				R		
Fuel level sensor signal	R				T		
Turn indicator signal				T	R		
Brake warning lamp signal					R	T	
ABS warning lamp signal					R	T	
VDC OFF indicator lamp signal					R	T	
SLIP indicator lamp signal					R	T	
HDC indicator lamp signal*					R	T	
Malfunction indicator lamp signal	T				R		
ASCD CRUISE lamp signal	T				R		
ASCD SET lamp signal	T				R		
ASCD operation signal	T	R					
ASCD OD cancel request	T	R					
A/T fluid temperature sensor signal	R	T			R		
A/T position indicator lamp signal	R	T			R	R	
O/D OFF indicator signal		T			R		
Overdrive control switch signal		R			T	R	
1st position switch signal		R			T		
Stop lamp switch signal		R		R	T		
Vehicle speed signal	R				R	T	
	R	R		R	T		
Steering angle sensor signal			T			R	
Power generation command value signal	T						R


NOTE:

*: HDC model only


A
B
C
D
E
F
G
H
I
J
LAN
L
M

TYPE 6/ TYPE 7
System diagram

- Type 6



- Type 7



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Differential lock control unit	BCM	Combina-tion meter	Transfer control unit	ABS actua-tor and electric unit (control unit)	IPDM E/R
Engine speed signal	T			R	R	R	
Engine status signal	T		R				
Engine coolant temperature signal	T			R			
Accelerator pedal position signal	T					R	
A/C switch signal	R		T				
A/C compressor request signal	T						R
Blower fan motor switch signal	R		T				
Cooling fan speed request signal	T						R
Low beam request signal			T				R

CAN COMMUNICATION


[CAN]

Signals	ECM	Differential lock control unit	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Low beam status signal	R						T
High beam request signal			T	R			R
High beam status signal	R						T
Position light request signal			T				R
Front fog light request signal			T	R			R
Day time running light request signal			T				R
Sleep wake up signal			T	R			R
Door switch signal			T	R			R
Seat belt buckle switch signal			R	T			
Ignition switch signal			T				R
Theft warning horn request signal			T				R
Horn chirp signal			T				R
Front wiper request signal			T				R
Front wiper stop position signal			R				T
Rear window defogger switch signal			T				R
Rear window defogger control signal	R						T
Buzzer output signal			T	R			
Fuel consumption monitor signal	T			R			
Fuel level sensor signal	R			T			
Turn indicator signal			T	R			
Brake warning lamp signal				R		T	
ABS warning lamp signal				R		T	
SLIP indicator lamp signal				R		T	
Malfunction indicator lamp signal	T			R			
ASCD CRUISE lamp signal	T			R			
ASCD SET lamp signal	T			R			
Stop lamp switch signal			R	T	R	T	
Vehicle speed signal	R			R		T	
	R		R	T	R		
Differential lock switch signal		T				R	
Differential lock indicator signal		T				R	
4WD shift switch signal	R	R			T	R	
Power generation command value signal	T						R


A
B
C
D
E
F
G
H
I
J
LAN
L
M

TYPE 8/ TYPE 9
System diagram

- Type 8



- Type 9



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Differential lock control unit	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T				R	R	R	
Engine status signal	T			R				
Engine coolant temperature signal	T				R			
Accelerator pedal position signal	T						R	
A/C switch signal	R			T				
A/C compressor request signal	T							R
Blower fan motor switch signal	R			T				
Cooling fan speed request signal	T							R
Low beam request signal				T				R

CAN COMMUNICATION

[CAN]

Signals	ECM	Differential lock control unit	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Low beam status signal	R							T
High beam request signal				T	R			R
High beam status signal	R							T
Position light request signal				T				R
Front fog light request signal				T	R			R
Day time running light request signal				T				R
Sleep wake up signal				T	R			R
Door switch signal				T	R			R
Seat belt buckle switch signal				R	T			
Ignition switch signal				T				R
Theft warning horn request signal				T				R
Horn chirp signal				T				R
Front wiper request signal				T				R
Front wiper stop position signal				R				T
Rear window defogger switch signal				T				R
Rear window defogger control signal	R							T
Buzzer output signal				T	R			
Fuel consumption monitor signal	T				R			
Fuel level sensor signal	R				T			
Turn indicator signal				T	R			
Brake warning lamp signal					R		T	
ABS warning lamp signal					R		T	
VDC OFF indicator lamp signal					R		T	
SLIP indicator lamp signal					R		T	
HDC indicator lamp signal					R		T	
Malfunction indicator lamp signal	T				R			
ASCD CRUISE lamp signal	T				R			
ASCD SET lamp signal	T				R			
Stop lamp switch signal						R	T	
Vehicle speed signal	R				R		T	
	R			R	T	R		
Steering angle sensor signal			T			R	R	
Differential lock switch signal		T					R	
Differential lock indicator signal		T					R	
4WD shift switch signal	R	R				T	R	
Power generation command value signal	T							R


NOTE:

*: HDC model only

TYPE 10

System diagram

- Type 10



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actua- tor and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R	R	
Engine status signal	T		R				
Engine coolant temperature signal	T			R			
Accelerator pedal position signal	T	R				R	
Closed throttle position signal	T	R					
Wide open throttle position signal	T	R					
Battery voltage signal	T	R					
A/T self-diagnosis signal	R	T					
Turbine revolution signal	R	T					
Output shaft revolution signal	R	T			R		
A/C switch signal	R		T				
A/C compressor request signal	T	R					R
Blower fan motor switch signal	R		T				
Cooling fan speed request signal	T						R
Low beam request signal			T				R
Low beam status signal	R						T
High beam request signal			T	R			R
High beam status signal	R						T
Position light request signal			T				R
Front fog light request signal			T	R			R
Day time running light request signal			T				R
Sleep wake up signal			T	R			R
Door switch signal			T	R			R
Seat belt buckle switch signal			R	T			

CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	BCM	Combina- tion meter	Transfer control unit	ABS actua- tor and electric unit (control unit)	IPDM E/R
Ignition switch signal			T				R
Theft warning horn request signal			T				R
Horn chirp signal			T				R
Front wiper request signal			T				R
Front wiper stop position signal			R				T
Rear window defogger switch signal			T				R
Rear window defogger control signal	R						T
Buzzer output signal			T	R			
Fuel consumption monitor signal	T			R			
Fuel level sensor signal	R			T			
Turn indicator signal			T	R			
Brake warning lamp signal				R		T	
ABS warning lamp signal				R		T	
SLIP indicator lamp signal				R		T	
Malfunction indicator lamp signal	T			R			
ASCD CRUISE lamp signal	T			R			
ASCD SET lamp signal	T			R			
ASCD operation signal	T	R					
ASCD OD cancel request	T	R					
A/T fluid temperature sensor signal	R	T		R			
A/T position indicator lamp signal	R	T		R	R	R	
O/D OFF indicator signal		T		R			
Overdrive control switch signal		R		T		R	
1st position switch signal		R		T			
Stop lamp switch signal		R	R	T			
					R	T	
Vehicle speed signal	R			R		T	
	R	R	R	T	R		
4WD shift switch signal	R	R			T	R	
Power generation command value signal	T						R

A
B
C
D
E
F
G
H
I
J
LAN
L
M


TYPE 11/ TYPE 12

System diagram

- Type 11



- Type 12



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Differential lock control unit	Steering angle sensor	BCM	Combination meter	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R				R	R	R	
Engine status signal	T				R				
Engine coolant temperature signal	T					R			
Accelerator pedal position signal	T	R						R	
Closed throttle position signal	T	R							
Wide open throttle position signal	T	R							
Battery voltage signal	T	R							
A/T self-diagnosis signal	R	T							

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Differ- ential lock control unit	Steer- ing angle sensor	BCM	Combi- nation meter	Trans- fer con- trol unit	ABS actua- tor and electric unit (control unit)	IPDM E/ R
Turbine revolution signal	R	T							
Output shaft revolution signal	R	T					R		
A/C switch signal	R				T				
A/C compressor request signal	T	R							R
Blower fan motor switch signal	R				T				
Cooling fan speed request signal	T								R
Low beam request signal					T				R
Low beam status signal	R								T
High beam request signal					T	R			R
High beam status signal	R								T
Position light request signal					T				R
Front fog light request signal					T	R			R
Day time running light request signal					T				R
Sleep wake up signal					T	R			R
Door switch signal					T	R			R
Seat belt buckle switch signal					R	T			
Ignition switch signal					T				R
Theft warning horn request signal					T				R
Horn chirp signal					T				R
Front wiper request signal					T				R
Front wiper stop position signal					R				T
Rear window defogger switch signal					T				R
Rear window defogger control signal	R								T
Buzzer output signal					T	R			
Fuel consumption monitor signal	T					R			
Fuel level sensor signal	R					T			
Turn indicator signal					T	R			
Brake warning lamp signal						R		T	
ABS warning lamp signal						R		T	
VDC OFF indicator lamp signal						R		T	
SLIP indicator lamp signal						R		T	
HDC indicator lamp signal						R		T	
Malfunction indicator lamp signal	T					R			
ASCD CRUISE lamp signal	T					R			
ASCD SET lamp signal	T					R			
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							
A/T fluid temperature sensor signal	R	T				R			
A/T position indicator lamp signal	R	T				R	R	R	
O/D OFF indicator signal		T				R			

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	Differ- ential lock control unit	Steer- ing angle sensor	BCM	Combi- nation meter	Trans- fer con- trol unit	ABS actua- tor and electric unit (control unit)	IPDM E/ R
Overdrive control switch signal		R				T		R	
1st position switch signal		R				T			
Stop lamp switch signal		R			R	T			
							R	T	
Vehicle speed signal	R					R		T	
	R	R			R	T	R		
Steering angle sensor signal				T			R	R	
Differential lock switch signal			T					R	
Differential lock indicator signal			T					R	
4WD shift switch signal	R	R	R				T	R	
Power generation command value signal	T								R

CAN SYSTEM (TYPE 1)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 1)

[CAN]

Schematic

UKS0046N





BKWA0571E

Wiring Diagram — CAN —

UKS00460

LAN-CAN-01

▬ : DATA LINE







REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0572E

LAN-CAN-02

— : DATA LINE





BKWA0573E

CAN SYSTEM (TYPE 1)

[CAN]

LAN-CAN-03

— : DATA LINE



BKWA0574E

CAN SYSTEM (TYPE 1)

[CAN]

UKS0046P

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6516E

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN

PKIB6517E

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-53, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7252E




PKIB7058E

Case 2

Check ECM circuit. Refer to [LAN-54, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7253E



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-55, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7254E




PKIB7060E

Case 4

Check BCM circuit. Refer to [LAN-55, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7255E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-56, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7256E



PKIB7062E

CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-56, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7257E



PKIB7126E

CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check IPDM E/R circuit. Refer to [LAN-57, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7258E



Case 8

Check CAN communication circuit. Refer to [LAN-58, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7259E

Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-61, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7260E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-61, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWVN	UNKWVN	—	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7261E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS0046Q

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS0046R


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS0046S

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS0046T

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS0046U

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS0046V

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS0046W

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E152.




4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 5.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M31
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.

14 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 6.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M31
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and harness connector M91




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
 - Harness between IPDM E/R and harness connector E26



A
B
C
D
E
F
G
H
I
J
LAN
L
M

7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 2)


System Description

UKS0046Z

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS00470




CAN SYSTEM (TYPE 2)

[CAN]

Schematic

UKS00471

A
B
C
D
E
F
G
H
I
J
LAN
L
M





BKWA0571E

Wiring Diagram — CAN —

LAN-CAN-04

▬ : DATA LINE



REFER TO THE FOLLOWING.


(M31) - SUPER MULTIPLE JUNCTION (SMJ)

CAN SYSTEM (TYPE 2)


[CAN]

LAN-CAN-05

— : DATA LINE




A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0539E

— : DATA LINE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(M91) W

37	38	39	40	41	42
43	44	45	46	47	48

(E122) W

16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32

(E125) B

CAN SYSTEM (TYPE 2)

[CAN]

UKS00473

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6520E

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB6517E

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-76, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7262E



CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-77, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7263E



CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-78, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7264E



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check BCM circuit. Refer to [LAN-78, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7265E



CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-79, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7266E



CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-79, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7267E




Case 7

Check IPDM E/R circuit. Refer to [LAN-80, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7268E



Case 8

Check CAN communication circuit. Refer to [LAN-81, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7269E

Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-84, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7270E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-84, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7271E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS00474

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS00476

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and BCM.



UKS00477

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS00478

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS00479

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS0047A

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

CAN Communication Circuit Inspection**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.

**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.

94 – 86 : Approx. 108 – 132 Ω


3. Check resistance between IPDM E/R terminals 39 and 40.

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS0047C

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 3)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



BKIA0185E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 3)

[CAN]

Schematic

UKS004JH



BKWA0597E



Wiring Diagram — CAN —

UKS004JI

LAN-CAN-07

▬ : DATA LINE

A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)






BKWA0598E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-08

— : DATA LINE





BKWA0599E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-09

▬ : DATA LINE



BKWA0600E

CAN SYSTEM (TYPE 3)

[CAN]

UKS004JJ

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table											
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

SKIB4914E

CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN

PKIB6517E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-100, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4915E



CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-101, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4916E



CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check steering angle sensor circuit. Refer to [LAN-102, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4917E



CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check data link connector circuit. Refer to [LAN-102. "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4918E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check BCM circuit. Refer to [LAN-103, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SKIB4919E



CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check combination meter circuit. Refer to [LAN-103, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4920E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-104, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	✓	✓	✓	✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4921E



CAN SYSTEM (TYPE 3)


[CAN]

Case 8

Check IPDM E/R circuit. Refer to [LAN-104, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

SKIB4922E



Case 9

Check CAN communication circuit. Refer to [LAN-105, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	✓	—	—	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	✓	✓	✓	✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4923E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-108, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4924E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-108, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

SKIB4925E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS004JK

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).

6 (L) – 11 (L) : Continuity should exist.
14 (P) – 10 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).

11 (L) – 11 (L) : Continuity should exist.
10 (P) – 15 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS004JM

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS004JN

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



UKS004JO

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS004JP

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS004JQ

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS004JR

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS004J/S

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - Steering angle sensor
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.


94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - Steering angle sensor
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS004JT

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 4)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 4)

[CAN]

Schematic

UKS004J1



BKWA0575E

CAN SYSTEM (TYPE 4)





[CAN]

Wiring Diagram — CAN —

UKS004J2

LAN-CAN-10

▬ : DATA LINE




REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0541E

LAN-CAN-11

▬ : DATA LINE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

M18
W



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1



M22
W

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

M24
W

BKWA0542E

▬ : DATA LINE



BKWA0543E

CAN SYSTEM (TYPE 4)

[CAN]

UKS004J3

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6518E

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	A
Attach copy of METER SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	B
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	C
	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	D
			E
			F
			G
			H
			I
			J
			LAN
			L
			M

PKIB5017E

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-125, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7272E



PKIB7128E

CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-126, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1011) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7273E



CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-127, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW [✓] N	—	UNK [✓] WN	UNK [✓] WN	UNK [✓] WN	UNK [✓] WN	CAN COMM CIRCUIT (U100) [✓]	CAN COMM CIRCUIT (U101) [✓]
A/T	—	NG	UNKWN	UNK [✓] WN	—	—	UNKWN	—	CAN COMM CIRCUIT (U100) [✓]	—
BCM	No indication	NG	UNKWN	UNK [✓] WN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) [✓]	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) [✓]	—
ABS	—	NG	UNKWN	UNK [✓] WN	—	—	—	—	CAN COMM CIRCUIT (U100) [✓]	—
IPDM E/R	No indication	—	UNKWN	UNK [✓] WN	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) [✓]	—

PKIB7274E




PKIB7130E

Case 4

Check TCM circuit. Refer to [LAN-128, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	UNKWN ✓	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7275E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-128, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7276E




PKIB7132E

Case 6

Check BCM circuit. Refer to [LAN-129, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7277E



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-129, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7278E



PKIB7134E

CAN SYSTEM (TYPE 4)


[CAN]

Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-130, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7279E



PKIB7135E

CAN SYSTEM (TYPE 4)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-130, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7280E



PKIB7136E

Case 10

Check CAN communication circuit. Refer to [LAN-131, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7281E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-135, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
AT	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7282E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-135, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7283E

Inspection Between TCM and Data Link Connector Circuit

UKS004J4

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS004J5

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS004.J7

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS004.J8

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



UKS004J9

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS004JA

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS004JB

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS004JC

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS004JD

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.

**7. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.

**8. CHECK HARNESS FOR SHORT CIRCUIT**

1. Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.

94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
 NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
 NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
 Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS004JE

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 5)


System Description

UKS004II

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS004IJ




BKIA0177E

CAN SYSTEM (TYPE 5)

[CAN]

Schematic

UKS004IK



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0544E

CAN SYSTEM (TYPE 5)



[CAN]

UKS004L

Wiring Diagram — CAN —

LAN-CAN-13

■ : DATA LINE




REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0545E

LAN-CAN-14

▬ : DATA LINE





A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0546E

LAN-CAN-15

▬ : DATA LINE



BKWA0547E

CAN SYSTEM (TYPE 5)

[CAN]

UKS0041M

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table													
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5017E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-153, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB9504E



CAN SYSTEM (TYPE 5)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to LAN-154, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit"

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R			
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9505E



CAN SYSTEM (TYPE 5)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-155, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWVN	—	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWVN	UNKWVN	—	—	—	UNKWVN	UNKWVN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	—	UNKWVN	—	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB9506E



CAN SYSTEM (TYPE 5)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-156, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9507E



CAN SYSTEM (TYPE 5)


[CAN]

Case 5

Check steering angle sensor circuit. Refer to [LAN-156, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9508E



A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN SYSTEM (TYPE 5)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-157, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9509E



CAN SYSTEM (TYPE 5)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-157, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB9510E



CAN SYSTEM (TYPE 5)


[CAN]

Case 8

Check combination meter circuit. Refer to [LAN-158, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9511E




Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-158, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9512E




Case 10

Check IPDM E/R circuit. Refer to [LAN-159, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB9513E



Case 11

Check CAN communication circuit. Refer to [LAN-160, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	CAN COMM CIRCUIT (U001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB9514E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-164, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	✓	—	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB9515E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-164, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	STRG	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB9516E

Inspection Between TCM and Data Link Connector Circuit

UKS004IN

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS00410

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS0041P

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS0041Q

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS0041R

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS004IS

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS004IT

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS004IU

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS004IV

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS004IW

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.



A
B
C
D
E
F
G
H
I
J

LAN

L
M

7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.


94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 13.

NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS0041Y

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 6)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



BKIA0178E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 6)

[CAN]

Schematic

UKS00415



BKWA0576E



Wiring Diagram — CAN —

UKS00416

LAN-CAN-16

▬ : DATA LINE

A
B
C
D
E
F
G
H
I
J
LAN
L
M








REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0548E

LAN-CAN-17


— : DATA LINE




BKWA0549E

LAN-CAN-18

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0550E

CAN SYSTEM (TYPE 6)

[CAN]

UKS00417

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table											
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6526E

CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

A
B
C
D
E
F
G
H
I
J
LAN
L
M

PKIB6525E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-180, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7320E



CAN SYSTEM (TYPE 6)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-181, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7321E



PKIB7148E

CAN SYSTEM (TYPE 6)


[CAN]

Case 3

Check data link connector circuit. Refer to [LAN-182, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7322E



CAN SYSTEM (TYPE 6)


[CAN]

Case 4

Check BCM circuit. Refer to [LAN-182, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7323E



CAN SYSTEM (TYPE 6)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-183, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7324E



CAN SYSTEM (TYPE 6)


[CAN]

Case 6

Check transfer control unit circuit. Refer to [LAN-183, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7325E



CAN SYSTEM (TYPE 6)


[CAN]

Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-184, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7326E




Case 8

Check IPDM E/R circuit. Refer to [LAN-184, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7327E



Case 9

Check CAN communication circuit. Refer to [LAN-185, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7328E

Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-188, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) style="text-align: center;">✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) style="text-align: center;">✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	✓	—	CAN COMM CIRCUIT (U1000) style="text-align: center;">✓	—
ABS	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7329E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-188, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) style="text-align: center;">✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7330E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS00418

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS004IA

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and BCM.



UKS004IB

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS0041C

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS0041D

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS004IE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

UKS004IF

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS004IG

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
 - Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.

40 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
 - Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.

94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 9.
 NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 10.
 NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS0041H

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 7)


System Description

UKS004HN

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS004HO




BKIA0179E

CAN SYSTEM (TYPE 7)

[CAN]

Schematic

UKS004HP



BKWA0577E

CAN SYSTEM (TYPE 7)


[CAN]

Wiring Diagram — CAN —


UKS004HQ

LAN-CAN-19

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M









REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0551E

LAN-CAN-20

— — — : DATA LINE





BKWA0552E

CAN SYSTEM (TYPE 7)

[CAN]

LAN-CAN-21

▬ : DATA LINE



BKWA0553E

CAN SYSTEM (TYPE 7)

[CAN]

UKS004HR

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table												
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6527E

CAN SYSTEM (TYPE 7)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of DIFF LOCK SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of DIFF LOCK CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6528E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-205, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R			
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7331E



CAN SYSTEM (TYPE 7)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-206, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7332E



CAN SYSTEM (TYPE 7)


[CAN]

Case 3

Check differential lock control unit circuit. Refer to [LAN-207, "Differential Lock Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7333E



PKIB7157E

CAN SYSTEM (TYPE 7)


[CAN]

Case 4

Check data link connector circuit. Refer to [LAN-207, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7334E



CAN SYSTEM (TYPE 7)


[CAN]

Case 5

Check BCM circuit. Refer to [LAN-208, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7335E



CAN SYSTEM (TYPE 7)


[CAN]

Case 6

Check combination meter circuit. Refer to [LAN-208, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7336E



PKIB7160E

CAN SYSTEM (TYPE 7)


[CAN]

Case 7

Check transfer control unit circuit. Refer to [LAN-209, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7337E



PKIB7161E

CAN SYSTEM (TYPE 7)


[CAN]

Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-209, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7338E



CAN SYSTEM (TYPE 7)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-210, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7339E



Case 10

Check CAN communication circuit. Refer to [LAN-211, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7340E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-214, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWVN	UNKWVN	—	—	—	UNKWVN	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7341E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-214, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	DIFF LOCK	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWVN	UNKWVN	—	—	—	UNKWVN	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7342E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS004HS

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS004HT


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS004HU

Differential Lock Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector M70 terminals 5 (L) and 4 (P).

5 (L) – 4 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace differential lock control unit.
 NG >> Repair harness between differential lock control unit and data link connector.



UKS004HV

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .
 NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS004HY

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS004HZ

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - Differential lock control unit
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E152.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Differential lock control unit connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



SKIA6868E

5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



PKIA9872E

6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



PKIA8141E

7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



SKIB2821E

8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.


94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



LKIA0037E

9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - Differential lock control unit
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS00412

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 8)

PFP:23710


System Description

UKS004H7

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS004H8



BKIA0180E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 8)

[CAN]

Schematic

UKS004H9



BKWA0554E

CAN SYSTEM (TYPE 8)

[CAN]



Wiring Diagram — CAN —

UKS004HA

LAN-CAN-22

▬ : DATA LINE

A
B
C
D
E
F
G
H
I
J
LAN
L
M





REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0555E

LAN-CAN-23

▬ : DATA LINE





BKWA0556E

CAN SYSTEM (TYPE 8)

[CAN]

LAN-CAN-24

— : DATA LINE



BKWA0557E

CAN SYSTEM (TYPE 8)

[CAN]

UKS004HB

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table												
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB9517E

CAN SYSTEM (TYPE 8)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

A
B
C
D
E
F
G
H
I
J
LAN
L
M

PKIB6525E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-231, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	✓	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB9520E



CAN SYSTEM (TYPE 8)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-232, "ECM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW ^N	—	—	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	UNKW ^N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	—	UNKW ^N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	UNKW ^N	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9521E



CAN SYSTEM (TYPE 8)


[CAN]

Case 3

Check steering angle sensor circuit. Refer to [LAN-233, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB9522E



CAN SYSTEM (TYPE 8)


[CAN]

Case 4

Check data link connector circuit. Refer to [LAN-233, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9523E



CAN SYSTEM (TYPE 8)


[CAN]

Case 5

Check BCM circuit. Refer to [LAN-234, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U000)	—	

PKIB9524E




Case 6

Check combination meter circuit. Refer to [LAN-234, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓	
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	✓	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9525E



CAN SYSTEM (TYPE 8)


[CAN]

Case 7

Check transfer control unit circuit. Refer to [LAN-235, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9526E



CAN SYSTEM (TYPE 8)


[CAN]

Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-235, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB9527E



CAN SYSTEM (TYPE 8)


[CAN]

Case 9

Check IPDM E/R circuit. Refer to [LAN-236, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9528E



Case 10

Check CAN communication circuit. Refer to [LAN-237, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9529E

Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-240, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9530E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-240, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9531E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS004HC

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS004HD


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



UKS004HE

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS004HF

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS004HI

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS004HJ

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.




3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.
86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.


94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS004HM

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 9)

System Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location



BKIA0181E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 9)

[CAN]

Schematic

UKS004GS



BKWA0558E

CAN SYSTEM (TYPE 9)


[CAN]

Wiring Diagram — CAN —


UKS004GT

LAN-CAN-25

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M





REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0559E

LAN-CAN-26

— : DATA LINE





BKWA0560E

CAN SYSTEM (TYPE 9)

[CAN]

LAN-CAN-27

▬ : DATA LINE



BKWA0561E

CAN SYSTEM (TYPE 9)

[CAN]

UKS004GU

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table														
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB9532E

CAN SYSTEM (TYPE 9)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of DIFF LOCK SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of DIFF LOCK CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6528E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-258, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB9535E



CAN SYSTEM (TYPE 9)


[CAN]

Case 2

Check ECM circuit. Refer to [LAN-259, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW N	—	—	—	UNKW N	UNKW N	UNKW N	UNKW N	UNKW N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
DIFF LOCK	—	NG	UNKW N	UNKW N	—	—	—	—	UNKW N	UNKW N	—	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKW N	UNKW N	—	—	—	UNKW N	—	—	UNKW N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	—	NG	UNKW N	UNKW N	—	—	—	UNKW N	—	UNKW N	—	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	UNKW N	—	UNKW N	—	UNKW N	—	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—	CAN COMM CIRCUIT (U000)	—

PKIB9536E



CAN SYSTEM (TYPE 9)


[CAN]

Case 3

Check differential lock control unit circuit. Refer to [LAN-260, "Differential Lock Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9537E



PKIB9494E

CAN SYSTEM (TYPE 9)


[CAN]

Case 4

Check steering angle sensor circuit. Refer to [LAN-260, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9538E



PKIB9495E

CAN SYSTEM (TYPE 9)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-261, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9539E



CAN SYSTEM (TYPE 9)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-261, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—	

PKIB9540E



CAN SYSTEM (TYPE 9)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-262, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN ✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN ✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB9541E



CAN SYSTEM (TYPE 9)


[CAN]

Case 8

Check transfer control unit circuit. Refer to [LAN-262, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9542E




PKIB9499E

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-263, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9543E




Case 10

Check IPDM E/R circuit. Refer to [LAN-263, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R	
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB9544E



Case 11

Check CAN communication circuit. Refer to [LAN-264, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R	
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKWN ✓	—	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
DIFF LOCK	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	—	UNKWN ✓	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
ABS	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIB9545E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-267, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9546E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-267, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R
				ECM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB9547E

Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS004GV

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS004GW

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and data link connector.



Differential Lock Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector M70 terminals 5 (L) and 4 (P).

5 (L) – 4 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace differential lock control unit.
 NG >> Repair harness between differential lock control unit and data link connector.



Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS004GZ

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS004H0

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS004H1

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS004H2

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS004H3

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS004H4

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS004H5

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - Differential lock control unit
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E152.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E152.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E152.



4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Differential lock control unit connector
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




8. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
- Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 9.
NG >> Replace ECM and/or IPDM E/R.



9. CHECK SYMPTOM

- Fill in described symptoms on the column "Symptom" in the check sheet.
- Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 10.
NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

10. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

- Turn ignition switch OFF.
- Disconnect the battery cable from the negative terminal.
- Disconnect the unit connector.
- Connect the battery cable to the negative terminal.
- Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
- Make sure that the same symptom is reproduced.
 - Differential lock control unit
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS004H6

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 10)

PFP:23710


System Description

UKS004G9

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS004GA




CAN SYSTEM (TYPE 10)

[CAN]

Schematic

UKS004GB



A
B
C
D
E
F
G
H
I
J
L
M

LAN

BKWA0578E

CAN SYSTEM (TYPE 10)






[CAN]

Wiring Diagram — CAN —

UKS004GC

LAN-CAN-28

▬ : DATA LINE



REFER TO THE FOLLOWING.

(M31) - SUPER MULTIPLE JUNCTION (SMJ)






BKWA0562E

CAN SYSTEM (TYPE 10)

[CAN]

LAN-CAN-29



— : DATA LINE



BKWA0563E

LAN-CAN-30

— : DATA LINE



BKWA0564E

CAN SYSTEM (TYPE 10)

[CAN]

UKS004GD

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table												
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

PKIB6531E

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 10)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
METER
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB5022E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-285, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R		
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS			
ENGINE	—	NG	UNKWN	—	UNKWN	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	✓	✓	✓	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	✓	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	✓	✓	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7032E




PKIB7164E

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-286, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7033E




Case 3

Check ECM circuit. Refer to [LAN-287, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	✓	—	✓	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	✓	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	✓	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	✓	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	✓	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIB7034E



CAN SYSTEM (TYPE 10)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-288, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7035E



PKIB7167E

CAN SYSTEM (TYPE 10)


[CAN]

Case 5

Check data link connector circuit. Refer to [LAN-288, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7036E



A
B
C
D
E
F
G
H
I
J
K
L
M


LAN

Case 6

Check BCM circuit. Refer to [LAN-289, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB7037E




Case 7

Check combination meter circuit. Refer to [LAN-289, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	✓ CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	✓	UNKWN	UNKWN	—	✓ CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	✓ CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7038E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 10)


[CAN]

Case 8

Check transfer control unit circuit. Refer to [LAN-290, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7039E




PKIB7171E

Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-290, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7040E



CAN SYSTEM (TYPE 10)


[CAN]

Case 10

Check IPDM E/R circuit. Refer to [LAN-291, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7041E



Case 11

Check CAN communication circuit. Refer to [LAN-292, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	UNKW	—	—	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7042E

Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-296, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWVN	UNKWVN	—	—	UNKWVN	UNKWVN	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	UNKWVN	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWVN	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7043E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-296, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWVN	—	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	UNKWVN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWVN	—	—	—	—	—	UNKWVN	—	CAN COMM CIRCUIT (U100)	—
BCM	No indication	NG	UNKWVN	UNKWVN	—	—	UNKWVN	—	—	UNKWVN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWVN	UNKWVN	UNKWVN	—	UNKWVN	—	UNKWVN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWVN	—	UNKWVN	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWVN	UNKWVN	—	UNKWVN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7044E

Inspection Between TCM and Data Link Connector Circuit

UKS004GE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS004GF

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS004GG

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS004GH

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS004GI

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



UKS004GJ

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS004GK

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS004GL

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS004GM

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P)

: Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS004GN

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P)

: Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
 - ECM
 - TCM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 39 and 40.


94 – 86 : Approx. 108 – 132 Ω

39 – 40 : Approx. 108 – 132 Ω

OK or NG

OK >> GO TO 13.

NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 14.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS004GP

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

CAN SYSTEM (TYPE 11)

PFP:23710


System Description

UKS004FR

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS004FS



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 11)

[CAN]

Schematic

UKS004FT



BKWA0579E

CAN SYSTEM (TYPE 11)


[CAN]

Wiring Diagram — CAN —

UKS004FU

LAN-CAN-31




▬ : DATA LINE



NEXT PAGE

A
B
C
D
E
F
G
H
I
J
L
M

LAN





REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0565E

LAN-CAN-32

▬ : DATA LINE





BKWA0566E

CAN SYSTEM (TYPE 11)

[CAN]

LAN-CAN-33

▬ : DATA LINE



BKWA0567E

CAN SYSTEM (TYPE 11)

[CAN]

UKS004FV

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 11)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of METER SELF-DIAG RESULTS
Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	
Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A
B
C
D
E
F
G
H
I
J
LAN
L
M

LAN

PKIB5022E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-315, "Inspection Between TCM and Data Link Connector Circuit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5127E



CAN SYSTEM (TYPE 11)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-316, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5128E



PKIB7186E

CAN SYSTEM (TYPE 11)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-317, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKN	UNKN	UNKN	—	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKN	UNKN	—	—	—	UNKN	UNKN	UNKN	UNKN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKN	UNKN	—	—	—	UNKN	—	—	UNKN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKN	UNKN	UNKN	—	—	UNKN	—	UNKN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKN	UNKN	UNKN	UNKN	—	—	UNKN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKN	UNKN	—	—	UNKN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5129E




PKIB7187E

Case 4

Check TCM circuit. Refer to [LAN-318, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	✓	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	✓	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000) ✓	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	✓	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100) ✓	—
ABS	—	NG	UNKWN	UNKWN	✓	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5130E




Case 5

Check steering angle sensor circuit. Refer to [LAN-318, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5131E



CAN SYSTEM (TYPE 11)


[CAN]

Case 6

Check data link connector circuit. Refer to [LAN-319, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5132E



CAN SYSTEM (TYPE 11)


[CAN]

Case 7

Check BCM circuit. Refer to [LAN-319, "BCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5133E




Case 8

Check combination meter circuit. Refer to [LAN-320, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	✓	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	✓	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5134E




Case 9

Check transfer control unit circuit. Refer to [LAN-320, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	✓	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	✓	✓	✓	—	—	✓	—	✓	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5135E




Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-321, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5136E




Case 11

Check IPDM E/R circuit. Refer to [LAN-321, "IPDM E/R Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS				
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS						
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN	✓	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5137E



Case 12

Check CAN communication circuit. Refer to [LAN-322, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS				
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										IPDM E/R		
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS						
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIB5138E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-326, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5139E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-326, "IPDM E/R Ignition Relay Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB5140E

Inspection Between TCM and Data Link Connector Circuit

UKS004FW

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS004FX

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS004FY

LAN


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS004FZ

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS004G0

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS004G1

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
 NG >> Repair harness between data link connector and BCM.



UKS004G2

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS004G3

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between combination meter and data link connector.



UKS004G4

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

UKS004G6

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS004G6

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



UKS004G7

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



SKIA6865E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.


94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14




6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 7.
 NG >> Repair harness between harness connector E5 and harness connector E152.



7. CHECK HARNESS FOR SHORT CIRCUIT


- Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.

2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 8.
 NG >> Repair harness between harness connector E5 and harness connector E152.




8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 9.
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M31
 - Harness between data link connector and steering angle sensor
 - Harness between data link connector and BCM
 - Harness between data link connector and combination meter
 - Harness between data link connector and transfer control unit
 - Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
3. Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS004G8

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 12)

PFP:23710


System Description

UKS004F8

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

UKS004F9



BKIA0184E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 12)

[CAN]

Schematic

UKS004FA



BKWA0580E

CAN SYSTEM (TYPE 12)


[CAN]

Wiring Diagram — CAN —

UKS004FB




LAN-CAN-34

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
L
M



LAN



REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0568E

LAN-CAN-35




BKWA0569E

CAN SYSTEM (TYPE 12)


[CAN]

LAN-CAN-36

— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



BKWA0570E

CAN SYSTEM (TYPE 12)

[CAN]

UKS004FC

CHECK SHEET

NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis												
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 12)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of DIFF LOCK SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of METER SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of DIFF LOCK CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6533E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Case 1

Check harness between TCM and data link connector circuit. Refer to [LAN-346, "Inspection Between TCM and Data Link Connector Circuit"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis												
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7003E



CAN SYSTEM (TYPE 12)


[CAN]

Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit) circuit. Refer to [LAN-347, "Inspection Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\) Circuit"](#)

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis												
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
AT	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7004E



CAN SYSTEM (TYPE 12)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-348, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTNR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW [✓] N	UNKW [✓] N	—	—	—	UNKW [✓] N	—	UNKW [✓] N	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	—	UNKW [✓] N	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7005E



PKIB6589E

CAN SYSTEM (TYPE 12)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-349, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R	
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS					
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	✓	CAN COMM CIRCUIT (U1001)	✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	✓	—	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	✓	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	✓	—	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	✓	—	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	✓	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	✓	—	—

PKIB9491E



CAN SYSTEM (TYPE 12)


[CAN]

Case 5

Check differential lock control unit circuit. Refer to [LAN-349, "Differential Lock Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7007E



CAN SYSTEM (TYPE 12)


[CAN]

Case 6

Check steering angle sensor circuit. Refer to [LAN-350, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7008E



CAN SYSTEM (TYPE 12)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-350, "Data Link Connector Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTNR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKW	UNKW	—	—	—	—	—	UNKW	UNKW	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	CAN COMM CIRCUIT (U1000)	—
METER	No indication ✓	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7009E



CAN SYSTEM (TYPE 12)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-351, "BCM Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7010E



CAN SYSTEM (TYPE 12)


[CAN]

Case 9

Check combination meter circuit. Refer to [LAN-351, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIB7011E




PKIB6595E

Case 10

Check transfer control unit circuit. Refer to [LAN-352, "Transfer Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7012E



CAN SYSTEM (TYPE 12)


[CAN]

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-352, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000) ✓	—
ABS	—	✓	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7013E



PKIB6597E

CAN SYSTEM (TYPE 12)


[CAN]

Case 12

Check IPDM E/R circuit. Refer to [LAN-353, "IPDM E/R Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	UNKW	—	UNKW	—	—	UNKW	UNKW	UNKW	UNKW	UNKW	UNKW	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKW	UNKW	—	—	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7014E



Case 13

Check CAN communication circuit. Refer to [LAN-354, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis											IPDM E/R
				ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS				
ENGINE	—	NG	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKW	UNKW	—	—	—	—	UNKW	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKW	UNKW	—	—	—	—	—	UNKW	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKW	UNKW	—	—	—	—	UNKW	—	—	UNKW	—	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	—	UNKW	—	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW	UNKW	UNKW	UNKW	UNKW	—	—	UNKW	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7015E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-358, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7016E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-358, "IPDM E/R Ignition Relay Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR											SELF-DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	Receive diagnosis											
			ECM	TCM	DIFF LOCK	STRG	BCM /SEC	METER /M&A	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	—	—	—	—	—	—	—	UNKWN	—	CAN COMM CIRCUIT (U100)	—
DIFF LOCK	—	NG	UNKWN	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	—	—	UNKWN	—	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
METER	No indication	—	—	—	—	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
ALL MODE AWD/4WD	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIB7017E

Inspection Between TCM and Data Link Connector Circuit

UKS004FD

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E152
 - Harness connector M31

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F14 terminals 2 (L), 3 (P).


3 (L) – 2 (L) : Continuity should exist.

8 (P) – 3 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L), 3 (P) and harness connector E152 terminals 52G (L), 51G (P).


2 (L) – 52G (L) : Continuity should exist.

3 (P) – 51G (P) : Continuity should exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness.



4. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M31 terminals 52G (L), 51G (P) and data link connector M22 terminals 6 (L), 14 (P).


52G (L) – 6 (L) : Continuity should exist.

51G (P) – 14 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



Inspection Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Circuit

UKS004FE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M91
 - Harness connector E26

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M91.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M91 terminals 11 (L), 10 (P).


6 (L) – 11 (L) : Continuity should exist.

14 (P) – 10 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E26 terminals 11 (L), 10 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L), 15 (P).


11 (L) – 11 (L) : Continuity should exist.

10 (P) – 15 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



ECM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E2
 - Harness connector F32

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

UKS004FF


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



UKS004FG

TCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) – 8 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace control valve with TCM.
 NG >> Repair harness between A/T assembly and harness connector F14.



UKS004FH

Differential Lock Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of differential lock control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect differential lock control unit connector.
2. Check resistance between differential lock control unit harness connector M70 terminals 5 (L) and 4 (P).

5 (L) – 4 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace differential lock control unit.
 NG >> Repair harness between differential lock control unit and data link connector.



UKS004FI

Steering Angle Sensor Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 4 (L) and 5 (P).

4 (L) – 5 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



UKS004FJ

Data Link Connector Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) – 14 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and BCM.



UKS004FK

BCM Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness between BCM and data link connector.



UKS004FL

Combination Meter Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 12 (L) and 11 (P).

12 (L) – 11 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



UKS004FM

Transfer Control Unit Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector M152 terminals 1 (L) and 2 (P).

1 (L) – 2 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and data link connector.



UKS004FN

ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) – 15 (P) : Approx. 54 – 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



UKS004FO

IPDM E/R Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) – 40 (P) : Approx. 108 – 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



PKIA8141E

CAN Communication Circuit Inspection

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, and harness side).
 - ECM
 - TCM
 - Differential lock control unit
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E2.
2. Check continuity between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) – 86 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness between ECM and harness connector E2.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector E16 terminals 94 (L), 86 (P) and ground.

94 (L) – Ground : Continuity should not exist.

86 (P) – Ground : Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness between ECM and harness connector E2.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect A/T assembly connector and harness connector F14.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).


3 (L) – 8 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and ground.

3 (L) – Ground : Continuity should not exist.


8 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between A/T assembly and harness connector F32
- Harness between A/T assembly and harness connector F14



6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect harness connector E152.
2. Check continuity between harness connector E5 terminals 2 (L) and 3 (P).

2 (L) – 3 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E5 and harness connector E152.



A
B
C
D
E
F
G
H
I
J

LAN

L
M

7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between harness connector E5 terminals 2 (L), 3 (P) and ground.


2 (L) – Ground : Continuity should not exist.

3 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E5 and harness connector E152.



8. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
 - Differential lock control unit connector
 - Steering angle sensor connector
 - BCM connector
 - Combination meter connector
 - Transfer control unit connector
 - Harness connector M91
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


6 (L) – 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 9.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) – Ground : Continuity should not exist.


14 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 10.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M31
- Harness between data link connector and differential lock control unit
- Harness between data link connector and steering angle sensor
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and transfer control unit
- Harness between data link connector and harness connector M91



10. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).


39 (L) – 40 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 11.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26



11. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E122 terminals 39 (L), 40 (P) and ground.

39 (L) – Ground : Continuity should not exist.


40 (P) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 12.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between IPDM E/R and ABS actuator and electric unit (control unit)
- Harness between IPDM E/R and harness connector E26




12. CHECK ECM AND IPDM E/R INTERNAL CIRCUIT

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
94 – 86 : Approx. 108 – 132 Ω
3. Check resistance between IPDM E/R terminals 39 and 40.
39 – 40 : Approx. 108 – 132 Ω

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM and/or IPDM E/R.



13. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

- OK >> GO TO 14.
NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

14. CHECK UNIT REPRODUCIBILITY

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the unit connector.
4. Connect the battery cable to the negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
 - TCM
 - Differential lock control unit
 - Steering angle sensor
 - BCM
 - Combination meter
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - ECM
 - IPDM E/R

Inspection results

- Reproduced>>Install removed unit, and then check the other unit.
Not reproduced>>Replace removed unit.

IPDM E/R Ignition Relay Circuit Inspection

UKS004FQ

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-14, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).