

# STR

SECTION STARTING SYSTEM

## CONTENTS

<b>PRECAUTION</b>	2	M/T : Component Description	9
<b>PRECAUTIONS</b>	2	<b>COMPONENT DIAGNOSIS</b>	10
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	<b>B TERMINAL CIRCUIT</b>	10
		Description	10
		Diagnosis Procedure	10
<b>PREPARATION</b>	3	<b>S CONNECTOR CIRCUIT</b>	12
<b>PREPARATION</b>	3	Description	12
Special Service Tool	3	Diagnosis Procedure	12
Commercial Service Tool	3		
<b>BASIC INSPECTION</b>	4	<b>STARTING SYSTEM</b>	14
<b>DIAGNOSIS AND REPAIR WORKFLOW</b>	4	Wiring Diagram	14
Work Flow	4		
<b>FUNCTION DIAGNOSIS</b>	7	<b>SYMPTOM DIAGNOSIS</b>	18
<b>STARTING SYSTEM</b>	7	Starting System	18
		Symptom Table	18
<b>A/T</b>	7	<b>ON-VEHICLE REPAIR</b>	19
A/T : System Diagram	7	<b>STARTER MOTOR</b>	19
A/T : System Description	7	Exploded View	19
A/T : Component Parts Location	7	Removal and Installation	19
A/T : Component Description	8		
<b>M/T</b>	8	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b>	21
M/T : System Diagram	8		
M/T : System Description	8	<b>STARTER MOTOR</b>	21
M/T : Component Parts Location	9	Starter	21

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000005804648

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

## PREPARATION

< PREPARATION >


### PREPARATION

#### PREPARATION

##### Special Service Tool


INFOID:0000000005280275

STR

Tool number (Kent Moore No.) Tool name	Description
— (—) Model GR-8 Multitasking Battery Diagnostic Station	 Tests Batteries, starting and charging system. For operating instructions, refer to diagnostic station instruction manual. AWIIIA1239ZZ

##### Commercial Service Tool

INFOID:0000000005280276

Tool name	Description
Power tool	 Loosening bolts and nuts PBIC0190E

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:0000000005280277

#### OVERALL SEQUENCE



#### DETAILED FLOW

# DIAGNOSIS AND REPAIR WORKFLOW

## < BASIC INSPECTION >

### **NOTE:**

To ensure a complete and thorough diagnosis, the battery, starter motor and generator test segments must be done as a set from start to finish.

## 1. DIAGNOSIS WITH MULTITASKING BATTERY DIAGNOSTIC STATION

Perform the starting system test with multitasking battery diagnostic station. For details and operating instructions, refer to diagnostic station instruction manual.

STR

### Test result

C

D

E

F

G

H

I

J

K

L

M

N

O

P

CRANKING NORMAL>>GO TO 2

LOW VOLTAGE>>GO TO 5

CHARGE BATTERY>>Perform the slow battery charging procedure. (Initial rate of charge is 10A for 12 hours.) Perform battery test again. Refer to diagnostic station instruction manual.

REPLACE BATTERY>>Before replacing battery, clean the battery cable clamps and battery posts. Perform battery test again. Refer to diagnostic station instruction manual. If second test result is "REPLACE BATTERY", then do so, refer to [PG-71, "Removal and Installation"](#). Perform battery test again to confirm repair.

## 2. CRANKING CHECK

Check that the starter motor operates properly.

### Does the engine crank normally?

F

YES >> GO TO 3

G

NO >> GO TO 4

H

## 3. ENGINE START CHECK

I

Check that the engine starts.

J

### Does the engine start?

K

L

M

N

O

P

YES >> Starter motor is OK. Inspection End.

P

NO >> Perform further diagnosis of engine mechanical or engine control system. Refer to EM and EC sections. Once resolved, perform battery test again.

## 4. STARTER MOTOR ACTIVATION

Check that the starter motor operates.

P

### Does the starter motor turn?

P

YES >> Check ring gear and starter motor drive pinion. Once resolved, perform battery test again.

P

NO >> GO TO 7

## 5. COMPARISON BETWEEN ENGINE COOLANT AND CRANKING VOLTAGE

P

Compare the engine coolant temperature and verify the cranking voltage is within specification.

Minimum Specification of Cranking Voltage Referencing Coolant Temperature

Engine coolant temperature [°C (°F)]	Voltage [V]
-30 to -20 (-22 to -4)	8.6
-19 to -10 (-2 to 14)	9.1
-9 to 0 (16 to 32)	9.5
More than 1 (More than 34)	9.9

### Is the voltage less than the specified value?

O

P

YES >> GO TO 7

P

NO >> GO TO 6

## 6. STARTER OPERATION

P

Check the starter operation.

P

### Does the starter motor turn smoothly?

P

YES >> Starter motor is OK. Inspection End.

P

NO >> GO TO 7

## 7. "B" TERMINAL CIRCUIT INSPECTION

P

Check "B" terminal circuit. Refer to [STR-10, "Diagnosis Procedure"](#).

P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

Is "B" terminal circuit normal?

YES >> GO TO 8

NO >> Repair as needed.

## 8. "S" CONNECTOR CIRCUIT INSPECTION

Check "S" connector circuit. Refer to [STR-12, "Diagnosis Procedure"](#).

Is "S" connector circuit normal?

YES >> GO TO 9

NO >> Repair as needed.

## 9. ENGINE ROTATION STATUS

Check that the engine can be rotated by hand.

Does the engine turn freely by hand?

YES >> Replace starter motor. Refer to [STR-19, "Removal and Installation"](#).

NO >> Perform further diagnosis of engine mechanical or powertrain mechanism. Refer to EM or TM sections. Once resolved, perform battery test again. Refer to diagnostic station instruction manual.

# STARTING SYSTEM

< FUNCTION DIAGNOSIS >

## FUNCTION DIAGNOSIS


### STARTING SYSTEM

A/T

A/T : System Diagram

INFOID:0000000005280278

STR



AWBIA0433GB


A/T : System Description

INFOID:0000000005280279

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the cylinder block. With power and ground supplied, the starter motor operates.

A/T : Component Parts Location

INFOID:0000000005280280



1. A/T assembly F9 (with built in TCM F502)
2. IPDM E/R E119, E120, E122, E124
3. BCM M18 (view with lower instrument panel LH removed)

# STARTING SYSTEM

< FUNCTION DIAGNOSIS >

A/T : Component Description


INFOID:0000000005280281

Component part	Description
TCM	TCM supplies power to the starter relay inside the IPDM E/R when the A/T shift selector is placed in the P or N position.
BCM	BCM sends a starter request signal to the CPU of the IPDM E/R over the CAN communication lines.
IPDM E/R	CPU inside IPDM E/R operates the starter relay at the request of the BCM over the CAN communication lines.
Starter motor	The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power.

M/T

M/T : System Diagram

INFOID:0000000005280282



M/T : System Description

INFOID:0000000005280283

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the cylinder block. With power and ground supplied, the starter motor operates.


# STARTING SYSTEM

< FUNCTION DIAGNOSIS >

M/T : Component Parts Location

INFOID:0000000005280284

A



STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

2. Clutch interlock switch E163

3. IPDM E/R E119, E120, E122, E124

1. Clutch pedal

4. BCM M18 (view with lower instrument panel LH removed)

M/T : Component Description

INFOID:0000000005280285

Component part	Description
Clutch interlock switch	Clutch interlock switch supplies power to the coil side of the starter relay when the clutch pedal is depressed to crank the engine.
BCM	BCM sends a starter request signal to the CPU of the IPDM E/R over the CAN communication lines.
IPDM E/R	CPU inside IPDM E/R operates the starter relay at the request of the BCM over the CAN communication lines.
Starter motor	The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power.

## B TERMINAL CIRCUIT

< COMPONENT DIAGNOSIS >

# COMPONENT DIAGNOSIS

## B TERMINAL CIRCUIT

### Description

INFOID:0000000005280286

Terminal "2" (B) is constantly supplied with battery power.

### Diagnosis Procedure

INFOID:0000000005280287

Regarding Wiring Diagram information, refer to XX-XX, \*\*\*\*\*.

#### CAUTION:

Perform diagnosis under the condition that the engine cannot start by the following procedure.

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is depleted.


### 1.CHECK TERMINAL 2 POWER SUPPLY VOLTAGE

1. Place the ignition switch in the OFF position.
2. Make sure that starter motor connector E210 terminal 2 connection is clean and tight.
3. Check voltage between starter motor connector E210 terminal 2 and ground.

(+)		(-)	Voltage
Connector	Terminal	Ground	Battery voltage
E210	2	Ground	Battery voltage

Is there battery voltage present?

- YES >> GO TO 2  
NO >> Check harness between battery and starter motor for open circuit.




### 2.CHECK BATTERY CABLE (VOLTAGE DROP TEST)

1. Shift the transmission into park or neutral.
2. Check voltage between battery positive terminal and starter motor connector E210 terminal 2 while cranking the engine.

(-)		(+)	Condition	Voltage
Connector	Terminal	Battery (+) terminal	While cranking the engine	Less than 0.2V
E210	2	Battery (+) terminal	While cranking the engine	Less than 0.2V

Is the voltage drop less than 0.2V?

- YES >> GO TO 3  
NO >> Check harness between the battery and the starter motor for high resistance.



### 3.CHECK GROUND CIRCUIT STATUS (VOLTAGE DROP TEST)

## B TERMINAL CIRCUIT

### < COMPONENT DIAGNOSIS >


Check voltage between starter motor case and battery negative terminal while cranking the engine.

(+)	(-)	Condition	Voltage
Starter motor case	Battery (-) terminal	While cranking the engine	Less than 0.2V

Is the voltage drop less than 0.2V?

YES >> Terminal 2 circuit is OK. Further inspection necessary.  
Refer to [STR-4, "Work Flow"](#).

NO >> Check the starter motor case to engine mounting for high resistance.



# S CONNECTOR CIRCUIT

< COMPONENT DIAGNOSIS >

## S CONNECTOR CIRCUIT

### Description

INFOID:0000000005280288

Terminal "1" (S) is the power supply for the starter motor magnetic switch. Terminal 1 is supplied with power when the ignition switch is placed in the START position while the A/T shift selector is in the P or N position.

### Diagnosis Procedure

INFOID:0000000005280289

Regarding Wiring Diagram information, refer to [STR-14, "Wiring Diagram"](#).

#### CAUTION:


Perform diagnosis under the condition that engine cannot start by the following procedure.

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is released.

### 1.CHECK STARTER MOTOR MAGNETIC SWITCH CIRCUIT

1. Place the ignition switch in the OFF position.
2. Disconnect starter motor connector E207.
3. Place the A/T shift selector into the P or N position.
4. Check voltage between starter motor harness connector E207 terminal 1 and ground with the ignition in the START position.

Connector	(+)	(-)	Condition	Voltage
Connector	Terminal	Terminal		
E207	1	Ground	While cranking the engine	Battery voltage



Is battery voltage present?

- YES >> Magnetic switch circuit is OK. Further inspection necessary. Refer to [STR-4, "Work Flow"](#).  
NO >> GO TO 2

### 2.CHECK CONNECTOR

1. Place the ignition switch in the OFF position.
2. Check the IPDM E/R harness connector E120 and starter motor harness connector E207 for damage, bent pins and loose connections.


Is the inspection result normal?

- YES >> GO TO 3  
NO >> Repair the terminal and connector.

### 3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect IPDM E/R connector E120 and starter motor connector E207.
2. Check continuity between starter motor harness connector E207 (A) terminal 1 and IPDM E/R harness connector E120 (B) terminal 19.

Connector	A	Connector	B	Continuity
Connector	Terminal	Connector	Terminal	
E207	1	E120	19	Yes



3. Check continuity between starter motor harness connector E207 (A) terminal 1 and ground.

## S CONNECTOR CIRCUIT

< COMPONENT DIAGNOSIS >

Connector	Terminal	—	Continuity
E207	1	Ground	No

A

Are the continuity test results as specified?

YES    >> Further inspection necessary. Refer to [STR-4, "Work Flow"](#).

NO    >> Repair the harness.

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

# STARTING SYSTEM

< COMPONENT DIAGNOSIS >


## STARTING SYSTEM

### Wiring Diagram

INFOID:0000000005280290

: WITH A/T  
 : WITH M/T

### STARTING SYSTEM



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

† : THIS CONNECTOR IS AN INTEGRAL PART OF THE FUSIBLE LINK BOX (BATTERY).

ABBWA0527GB

# STARTING SYSTEM

< COMPONENT DIAGNOSIS >

## STARTING SYSTEM CONNECTORS

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M26
Connector Name	IGNITION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	GR	-
4	G	-

Terminal No.	Color of Wire	Signal Name
B	G	-
ST	GR	-

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	R	-



Terminal No.	Color of Wire	Signal Name
14	W/G	A/T ECU IGN SUPPLY

Terminal No.	Color of Wire	Signal Name
1	W	-

A      B      C      D      E      F      G      H      I      J      K      L      M      N      O      P


# STARTING SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L
48	R	INHIBIT SW

Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)




Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	W	STARTER MTR
21	GR	IGN SW (ST)

Terminal No.	Color of Wire	Signal Name
WIRE TO WIRE	—	—
CONNECTOR COLOR	GRAY	—



Connector No.	E163
Connector Name	CLUTCH INTERLOCK SWITCH
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	W	—

Terminal No.	Color of Wire	Signal Name
6	B/R	—

ABBIA0722GB

# STARTING SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	F9
Connector Name	A/T ASSEMBLY
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
9	R	-

Connector No.	E210
Connector Name	STARTER MOTOR
Connector Color	-



Terminal No.	Color of Wire	Signal Name
2	B/R	-


Connector No.	E207
Connector Name	STARTER MOTOR
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W	-


Terminal No.	Color of Wire	Signal Name
9	R	-

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
9	R	-

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	R	-

A      B      C      D      E      F      G      H      I      J      K      L      M      N      O      P

STR

## STARTING SYSTEM

< SYMPTOM DIAGNOSIS >

# SYMPTOM DIAGNOSIS

## STARTING SYSTEM

### Symptom Table

INFOID:000000005280291

Symptom	Reference
No normal cranking	Refer to <a href="#">STR-4, "Work Flow".</a>
Starter motor does not rotate	

# STARTER MOTOR


< ON-VEHICLE REPAIR >

## ON-VEHICLE REPAIR STARTER MOTOR

### Exploded View

INFOID:0000000005280292

STR




1. Starter cover
2. Starter motor assembly
3. Starter cover plate (rear)
4. Transmission housing

### Removal and Installation

INFOID:0000000005280293

#### REMOVAL

1. Disconnect the negative battery terminal.
2. Remove starter cover bolts and starter cover.
3. Disconnect terminal "1" (S) connector and terminal "2" (B) nut.
4. Remove the two starter bolts, using power tools.
5. Remove the starter motor.



#### INSTALLATION

Installation is in the reverse order of removal.

## STARTER MOTOR

< ON-VEHICLE REPAIR >

**CAUTION:**

Tighten terminal "2" (B) nut carefully.

## STARTER MOTOR

< SERVICE DATA AND SPECIFICATIONS (SDS)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## STARTER MOTOR

Starter

INFOID:000000005280294

STR

Application	All Models	
Manufacturer	Mitsubishi M001TA0072ZC	
Type	Reduction gear type	
System voltage	12V	
No-load	Terminal voltage	11V
	Current	Less than 120A
	Revolution	More than 3,100 rpm