

# VTL

## SECTION

## VENTILATION SYSTEM

<b>PRECAUTION .....</b>	<b>2</b>
<b>PRECAUTIONS .....</b>	<b>2</b>
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	2
Precaution for Working with HFC-134a (R-134a).....	2
Precaution for Procedure without Cowl Top Cover.....	3
<b>PREPARATION .....</b>	<b>4</b>
<b>PREPARATION .....</b>	<b>4</b>
Commercial Service Tool .....	4
<b>ON-VEHICLE REPAIR .....</b>	<b>5</b>
<b>CONTROL UNIT .....</b>	<b>5</b>
Removal and Installation .....	5
<b>INTAKE SENSOR .....</b>	<b>6</b>
Removal and Installation .....	6
<b>BLOWER MOTOR .....</b>	<b>7</b>
Component .....	7
Removal and Installation .....	7

<b>VARIABLE BLOWER CONTROL .....</b>	<b>8</b>
Removal and Installation .....	8
<b>HEATER &amp; COOLING UNIT ASSEMBLY .....</b>	<b>9</b>
Component .....	9
Removal and Installation .....	9
<b>EVAPORATOR .....</b>	<b>11</b>
Removal and Installation .....	11
<b>HEATER CORE .....</b>	<b>13</b>
Component .....	13
Removal and Installation .....	13
<b>INTAKE DOOR MOTOR .....</b>	<b>14</b>
Removal and Installation .....	14
<b>MODE DOOR MOTOR .....</b>	<b>15</b>
Removal and Installation .....	15
<b>AIR MIX DOOR MOTOR .....</b>	<b>16</b>
Removal and Installation .....	16
<b>DUCTS AND GRILLES .....</b>	<b>17</b>
Component .....	17
Removal and Installation .....	18

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000005786165

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### Precaution for Working with HFC-134a (R-134a)

INFOID:0000000005280354

#### **WARNING:**

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. If the refrigerants are mixed compressor failure is likely to occur. Refer to [HA-4, "Contaminated Refrigerant"](#). To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use refrigerant recovery/recycling equipment and refrigerant identifier.
- Use only specified oil for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If oil other than that specified is used, compressor failure is likely to occur.
- The specified HFC-134a (R-134a) oil rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
  - When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
  - When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
  - Only use the specified oil from a sealed container. Immediately reseal containers of oil. Without proper sealing, oil will become moisture saturated and should not be used.
  - Avoid breathing A/C refrigerant and oil vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from the A/C system using certified service equipment meeting requirements of SAE J2210 [HFC-134a (R-134a) recycling equipment], or SAE J2209 [HFC-134a (R-134a) recovery equipment]. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and oil manufacturers.
  - Do not allow the refrigerant oil to come in contact with styrofoam parts. Damage may result.


## PRECAUTIONS

< PRECAUTION >

### Precaution for Procedure without Cowl Top Cover

INFOID:000000005280355

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



A

B

C

D

E

F

G

H

VTL

J

K

L

M

N

O

P

## PREPARATION

< PREPARATION >

# PREPARATION

## PREPARATION

### Commercial Service Tool

INFOID:000000005280356

Tool name	Description
Power tool	 PIIB1407E

# CONTROL UNIT

< ON-VEHICLE REPAIR >

## ON-VEHICLE REPAIR

### CONTROL UNIT

#### Removal and Installation

INFOID:000000005280357

A

B

C

D

E

F

G

H

VTL

J

K


L

M

N

O

P



LBIA0416E

#### Installation

Installation is in the reverse order of removal.

# INTAKE SENSOR

< ON-VEHICLE REPAIR >


## INTAKE SENSOR

### Removal and Installation

INFOID:0000000005280358

#### REMOVAL

1. Remove the front kick plate. Refer to [INT-14, "Removal and Installation"](#).
  2. Remove the lower dash side finisher. Refer to [IP-10, "Exploded View"](#).
  3. Remove the front pillar lower finisher. Refer to [INT-14, "Removal and Installation"](#).
  4. Remove the assist grip handle.
  5. Remove the front pillar upper finisher. Refer to [INT-14, "Removal and Installation"](#).
  6. Remove the lower glove box. Refer to [IP-10, "Exploded View"](#).
  7. Remove the upper glove box (cluster lid E). Refer to [IP-10, "Exploded View"](#).
  8. Disconnect the intake sensor electrical connector.
- NOTE:**  
The intake sensor is located on the top of the front heater and cooling unit assembly next to the A/C evaporator cover.
9. Twist the intake sensor to remove the intake sensor from the front heater and cooling unit assembly.



#### INSTALLATION

Installation is in the reverse order of removal.

# BLOWER MOTOR


< ON-VEHICLE REPAIR >

## BLOWER MOTOR

### Component

INFOID:0000000005280359

Front Blower Motor



1. Front heater and cooling unit assembly
2. Front blower motor
3. Variable blower control (front)

### Removal and Installation

INFOID:0000000005280360

#### FRONT BLOWER MOTOR

VTL

##### Removal

1. Remove the lower glove box assembly. Refer to [IP-10, "Exploded View"](#).
2. Disconnect the front blower motor electrical connector.
3. Remove the three screws and remove the front blower motor.
4. Remove the blower wheel.

J

K

##### Installation

Installation is in the reverse order of removal.

L

M

N

O

P

# VARIABLE BLOWER CONTROL


< ON-VEHICLE REPAIR >

## VARIABLE BLOWER CONTROL

### Removal and Installation

INFOID:0000000005280361

Variable Blower Control



- |   |                      |                       |
|---|----------------------|-----------------------|
| 1. Front heater and cooling unit assembly | 2. Intake door motor | 3. Air mix door motor |
| 4. Variable blower control (front)        | 5. Mode door motor   |                       |

### REMOVAL

1. Disconnect the variable blower control (front) electrical connector.
2. Remove the two screws and remove the variable blower control (front).

### INSTALLATION

Installation is in the reverse order of removal.

# HEATER & COOLING UNIT ASSEMBLY

< ON-VEHICLE REPAIR >


## HEATER & COOLING UNIT ASSEMBLY

### Component

INFOID:0000000005280363

#### Front Heater and Cooling Unit Assembly

SEC. 271 • 276 • 278



: N·m (kg-m, in-lb)

: Always replace after every disassembly.

WJIA1621E

1. Front high-pressure A/C pipe
2. Front low-pressure A/C pipe
3. Front expansion valve
4. Front heater core and evaporator pipes grommet
5. Front A/C drain hose grommet
6. Front A/C drain hose
7. Front heater core pipe mounts
8. Front heater core pipes
9. Front heater and cooling unit assembly

### Removal and Installation

INFOID:0000000005280364

#### FRONT HEATER AND COOLING UNIT ASSEMBLY

##### Removal

1. Discharge the refrigerant from the A/C system. Refer to [HA-27, "HFC-134a \(R-134a\) Service Procedure"](#).
2. Drain the coolant from the engine cooling system. Refer to [CO-11, "Changing Engine Coolant"](#).
3. Disconnect the battery negative and positive terminals.

# HEATER & COOLING UNIT ASSEMBLY

## < ON-VEHICLE REPAIR >

4. Remove the front heater core pipes RH nut.
5. Disconnect the front heater core hoses from the front heater core.
6. Disconnect the high- and low-pressure A/C pipes from the front expansion valve.
7. Move the two front seats to the rear most position on the seat track.
8. Remove the instrument panel and center console assembly. Refer to [IP-11, "Removal and Installation"](#).
9. Remove the two front floor ducts.
10. Remove the steering column. Refer to [ST-12, "Removal and Installation"](#).
11. Disconnect the instrument panel wire harness at the RH and LH in-line connector brackets, and the fuse block (SMJ) electrical connectors. Refer to [PCS-8, "Component Parts Location"](#).
12. Remove the covers then remove the three steering member bolts from each side to disconnect the steering member from the vehicle body. Refer to [IP-10, "Exploded View"](#).
13. Remove the front heater and cooling unit assembly with it attached to the steering member, from the vehicle.
- CAUTION:**
  - Use care not to damage the seats and interior trim panels when removing the front heater and cooling unit assembly with it attached to the steering member.
  - Use suitable plugs on the heater core pipes to prevent coolant leakage.
14. Remove the front heater and cooling unit assembly from the steering member.

## Installation


Installation is in the reverse order of removal.

## CAUTION:

- Replace the O-ring of the low-pressure A/C pipe and high-pressure A/C pipe with a new one, and apply compressor oil to the O-ring for installation. Refer to [HA-25, "Component"](#).
- After charging the refrigerant, check for leaks. Refer to [HA-20, "Checking of Refrigerant Leaks"](#).

## NOTE:

- Fill the engine cooling system with the specified coolant mixture. Refer to [CO-11, "Changing Engine Coolant"](#).
- Recharge the A/C system. Refer to [HA-27, "HFC-134a \(R-134a\) Service Procedure"](#).



# EVAPORATOR

< ON-VEHICLE REPAIR >


## EVAPORATOR

### Removal and Installation

INFOID:0000000005280365

Front Heater and Cooling Unit Assembly

SEC. 270 • 271 • 272



- LJIA0178E
- |   |   |                        |
|---|---|------------------------|
| 1. Center ventilator connector duct               | 2. Front heater core cover                        | 3. Intake air case     |
| 4. Front heater core and evaporator pipes bracket | 5. Front heater core and evaporator pipes grommet | 6. Front heater core   |
| 7. Upper heater and cooling unit case             | 8. Front expansion valve                          | 9. Front evaporator    |
| 10. Lower heater and cooling unit case            | 11. Variable blower control (front)               | 12. Front blower motor |

### REMOVAL

# EVAPORATOR

## < ON-VEHICLE REPAIR >

1. Remove the front heater core. Refer to [VTL-13, "Removal and Installation"](#).
2. Separate the heater and cooling unit case.
3. Remove the front evaporator.
4. Remove the front expansion valve.

## INSTALLATION

Installation is in the reverse order of removal.

### **CAUTION:**

Replace the O-rings on the front A/C low-pressure flexible A/C hose and the front high-pressure A/C pipe with new ones. Apply compressor oil to the O-rings for installation.


# HEATER CORE

< ON-VEHICLE REPAIR >

## HEATER CORE

### Component

INFOID:0000000005280366



A  
B  
C  
D  
E  
F  
G  
H

VTL

1. Front heater core and evaporator pipe bracket
2. Front heater core
3. Front heater and cooling unit assembly
4. Front heater core cover

J

K

L

M

N

O

P

### Removal and Installation

INFOID:0000000005280367

#### FRONT HEATER CORE

##### Removal

1. Remove the front heater and cooling unit assembly. Refer to [VTL-9, "Removal and Installation"](#).
2. Remove the three screws and remove the front heater core cover.
3. Remove the front heater core and evaporator pipe bracket.
4. Remove the front heater core.

##### Installation

Installation is in the reverse order of removal.


# INTAKE DOOR MOTOR

## < ON-VEHICLE REPAIR > INTAKE DOOR MOTOR

### Removal and Installation

INFOID:0000000005280368

Intake Door Motor - Front Heater and Cooling Unit Assembly



- |   |                      |                       |
|---|----------------------|-----------------------|
| 1. Front heater and cooling unit assembly | 2. Intake door motor | 3. Air mix door motor |
| 4. Variable blower control (front)        | 5. Mode door motor   |                       |

### REMOVAL

1. Remove the front heater and cooling unit assembly. Refer to [VTL-9, "Removal and Installation"](#).
2. Disconnect the intake door motor electrical connector.
3. Remove the three screws and remove the intake door motor.

### INSTALLATION

Installation is in the reverse order of removal.

# MODE DOOR MOTOR


< ON-VEHICLE REPAIR >

## MODE DOOR MOTOR

### Removal and Installation

INFOID:0000000005280369

Mode Door Motor - Front Heater and Cooling Unit Assembly



- |   |                      |                       |
|---|----------------------|-----------------------|
| 1. Front heater and cooling unit assembly | 2. Intake door motor | 3. Air mix door motor |
| 4. Variable blower control (front)        | 5. Mode door motor   |                       |

A  
B  
C  
D  
E  
F  
G  
H

VTL

J  
K  
L  
M  
N  
O  
P

### REMOVAL

1. Remove the instrument panel side finisher. Refer to [IP-10, "Exploded View"](#).
2. Remove the lower instrument cover. Refer to [IP-10, "Exploded View"](#).
3. Remove the BCM. Refer to [BCS-56, "Removal and Installation"](#).
4. Disconnect the mode door motor electrical connector.
5. Remove the three screws and remove the mode door motor.

### INSTALLATION

Installation is in the reverse order of removal.

# AIR MIX DOOR MOTOR


< ON-VEHICLE REPAIR >

## AIR MIX DOOR MOTOR

### Removal and Installation

INFOID:0000000005280370

Air Mix Door Motor - Front Heater and Cooling Unit Assembly



- |   |                      |                       |
|---|----------------------|-----------------------|
| 1. Front heater and cooling unit assembly | 2. Intake door motor | 3. Air mix door motor |
| 4. Variable blower control (front)        | 5. Mode door motor   |                       |

### REMOVAL

1. Remove the front heater and cooling unit assembly. Refer to [VTL-9, "Removal and Installation"](#).
2. Disconnect the air mix door motor electrical connector.
3. Remove the three screws and remove the air mix door motor.

### INSTALLATION

Installation is in the reverse order of removal.

# DUCTS AND GRILLES

< ON-VEHICLE REPAIR >


## DUCTS AND GRILLES

### Component

INFOID:0000000005280371

SEC. 270 • 271

Ducts



VTL

J

K

L

M

N

O

P

1. Defroster nozzle
4. RH side demister duct

2. LH side demister duct
5. RH ventilator duct


3. LH ventilator duct
6. Center ventilator duct

# DUCTS AND GRILLES

## < ON-VEHICLE REPAIR >

- |   |                                 |                         |
|---|---------------------------------|-------------------------|
| 7. Front heater and cooling unit assembly | 8. Floor connector duct grilles | 9. Floor connector duct |
| 10. Front floor ducts                     | 11. Rear floor ducts            |                         |

### Grilles



- |                                      |                              |                            |
|--------------------------------------|------------------------------|----------------------------|
| 1. Instrument panel and pad assembly | 2. LH side ventilator grille | 3. LH ventilator grille    |
| 4. RH side ventilator grille         | 5. RH side ventilator grille | 6. RH side demister grille |

## Removal and Installation

INFOID:0000000005280372

### DEFROSTER NOZZLE

#### Removal

1. Remove the front heater and cooling unit assembly. Refer to [VTL-9, "Removal and Installation"](#).
2. Remove the defroster nozzle.

#### Installation

Installation is in the reverse order of removal.

### RH AND LH SIDE DEMISTER DUCT

#### Removal

1. Remove the front heater and cooling unit assembly. Refer to [VTL-9, "Removal and Installation"](#).
2. Remove the RH or LH side demister duct.

#### Installation

# DUCTS AND GRILLES

## < ON-VEHICLE REPAIR >

Installation is in the reverse order of removal.

### RH AND LH VENTILATOR DUCT

Removal

1. Remove the front heater and cooling unit assembly. Refer to [VTL-9, "Removal and Installation"](#).
2. Remove the RH or LH ventilator duct.

Installation

Installation is in the reverse order of removal.

### CENTER VENTILATOR DUCT

Removal

1. Remove the front heater and cooling unit assembly. Refer to [VTL-9, "Removal and Installation"](#).
2. Remove the defroster nozzle.
3. Remove the RH and LH ventilator ducts.
4. Remove the RH and LH side demister ducts.
5. Remove the center ventilator duct.

Installation

Installation is in the reverse order of removal.

### FLOOR CONNECTOR DUCT

Removal

1. Remove the front heater and cooling unit assembly. Refer to [VTL-9, "Removal and Installation"](#).
2. Remove the floor connector duct.

Installation

Installation is in the reverse order of removal.

### FRONT AND REAR FLOOR DUCTS

Removal

1. Remove the floor carpet. Refer to [INT-15, "Removal and Installation"](#).
2. Remove the clips and remove the front and rear floor ducts.

Installation

Installation is in the reverse order of removal.

### GRILLES

Removal

1. Remove the necessary interior trim panel(s) to access the grille. Refer to [INT-13, "Component"](#).
2. Remove the grille from the interior trim panel.

Installation

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

VTL

J

K

L

M

N

O

P