

SECTION EXL

EXTERIOR LIGHTING SYSTEM

CONTENTS

BASIC INSPECTION	4	Component Parts Location	18
DIAGNOSIS AND REPAIR WORKFLOW	4	Component Description	19
Work Flow	4	TRAILER TOW	20
FUNCTION DIAGNOSIS	7	System Diagram	20
HEADLAMP	7	System Description	20
System Diagram	7	Component Parts Location	21
System Description	7	Component Description	21
Component Parts Location	7	COMBINATION SWITCH READING SYSTEM	22
Component Description	8	System Diagram	22
DAYTIME RUNNING LIGHT SYSTEM	9	System Description	22
System Diagram	9	Component Parts Location	25
System Description	9	DIAGNOSIS SYSTEM (BCM)	27
Component Parts Location	10	HEADLAMP	27
Component Description	10	HEADLAMP : CONSULT-III Function (BCM -	
OFF-ROAD LAMPS	12	HEAD LAMP)	27
System Diagram	12	FLASHER	28
System Description	12	FLASHER : CONSULT-III Function (BCM -	
Component Parts Location	12	FLASHER)	28
Component Description	13	COMB SW	28
FRONT FOG LAMP	14	COMB SW : CONSULT-III Function (BCM -	
System Diagram	14	COMB SW)	28
System Description	14	DIAGNOSIS SYSTEM (IPDM E/R)	30
Component Parts Location	14	Diagnosis Description	30
Component Description	15	CONSULT - III Function (IPDM E/R)	32
TURN SIGNAL AND HAZARD WARNING		COMPONENT DIAGNOSIS	34
LAMPS	16	POWER SUPPLY AND GROUND CIRCUIT	34
System Diagram	16	BCM (BODY CONTROL MODULE)	34
System Description	16	BCM (BODY CONTROL MODULE) : Diagnosis	
Component Parts Location	16	Procedure	34
Component Description	17	IPDM E/R (INTELLIGENT POWER DISTRIBUTION	
PARKING, LICENSE PLATE AND TAIL		MODULE ENGINE ROOM)	35
LAMPS	18		
System Diagram	18		
System Description	18		

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure	35	PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM	85
		Wiring Diagram	85
HEADLAMP (HI) CIRCUIT	37	STOP LAMP	91
Description	37	Wiring Diagram	91
Component Function Check	37		
Diagnosis Procedure	37	BACK-UP LAMP	95
		Wiring Diagram	95
HEADLAMP (LO) CIRCUIT	39	TRAILER TOW	99
Description	39	Wiring Diagram	99
Component Function Check	39		
Diagnosis Procedure	39	ECU DIAGNOSIS	108
OFF-ROAD LAMPS SWITCH CIRCUIT	41	BCM (BODY CONTROL MODULE)	108
Description	41	Reference Value	108
Component Function Check	41	Terminal Layout	111
Diagnosis Procedure	41	Physical Values	111
OFF-ROAD LAMP COVER SENSOR CIRCUIT	43	Wiring Diagram	117
Description	43	Fail Safe	120
Component Function Check	43	DTC Inspection Priority Chart	121
Diagnosis Procedure	43	DTC Index	121
OFF-ROAD LAMPS CIRCUIT	45	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	123
Description	45	Reference Value	123
Component Function Check	45	Terminal Layout	124
Diagnosis Procedure	45	Physical Values	125
Component Inspection	47	Wiring Diagram	129
FRONT FOG LAMP CIRCUIT	48	Fail Safe	132
Description	48	DTC Index	134
Component Function Check	48	SYMPTOM DIAGNOSIS	135
Diagnosis Procedure	48	EXTERIOR LIGHTING SYSTEM SYMPTOMS	135
PARKING LAMP CIRCUIT	50	Symptom Table	135
Description	50	BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM	137
Component Function Check	50	Description	137
Diagnosis Procedure	50	Diagnosis Procedure	137
TURN SIGNAL LAMP CIRCUIT	55	BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON	138
Description	55	Description	138
Component Function Check	55	Diagnosis Procedure	138
Diagnosis Procedure	55	PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON	139
HEADLAMP	58	Description	139
Wiring Diagram	58	Diagnosis Procedure	139
DAYTIME LIGHT SYSTEM	62	BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON	140
Wiring Diagram	62	Description	140
FRONT FOG LAMP SYSTEM	70	Diagnosis Procedure	140
Wiring Diagram	70	PRECAUTION	141
OFF-ROAD LAMPS	74	PRECAUTIONS	141
Wiring Diagram	74		
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM	79		
Wiring Diagram	79		

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	141	
ON-VEHICLE REPAIR	142	
ADJUSTMENT AND INSPECTION	142	
HEADLAMP	142	
HEADLAMP : Aiming Adjustment	142	
FRONT FOG LAMP	143	
FRONT FOG LAMP : Aiming Adjustment	143	
REMOVAL AND INSTALLATION	145	
HEADLAMP	145	
Bulb Replacement	145	
Removal and Installation	145	
Disassembly and Assembly	146	
OPTICAL SENSOR	147	
Removal and Installation	147	
FRONT FOG LAMP	148	
Bulb Replacement	148	
Removal and Installation	148	
LIGHTING & TURN SIGNAL SWITCH	149	A
Removal and Installation	149	
HAZARD SWITCH	150	B
Removal and Installation	150	
HIGH-MOUNTED STOP LAMP	151	C
High-Mounted Stop Lamp	151	
LICENSE PLATE LAMP	152	D
Bulb Replacement	152	
Removal and Installation	152	
REAR COMBINATION LAMP	153	E
Bulb Replacement	153	
Removal and Installation	153	
OFF-ROAD LAMPS	155	F
Removal and Installation	155	
Disassembly and Assembly	155	
SERVICE DATA AND SPECIFICATIONS (SDS)	157	G
BULB SPECIFICATIONS	157	H
Headlamp	157	
Exterior Lamp	157	

EXL

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005268528

OVERALL SEQUENCE



AWLIA1661GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4

4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 6

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7

NO >> GO TO 8

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 11

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self diagnosis with CONSULT-III. Verified that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

YES >> GO TO 5
NO >> GO TO 11

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.
NO >> GO TO 3


HEADLAMP

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

HEADLAMP

System Diagram



System Description

INFOID:000000005569584

Control of the headlamp system operation is dependent upon the position of the combination switch (lighting and turn signal switch). When the combination switch (lighting and turn signal switch) is placed in the 2nd position, the BCM (body control module) receives input requesting the headlamps and park lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the headlamp LH high, headlamp RH high and headlamp low relay coils. When energized, these relays direct power to the respective headlamps, which then illuminate.


HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

With the combination switch (lighting and turn signal switch) in the 2ND position and placed in HIGH position, the BCM receives input requesting the headlamp high beams to illuminate. The flash to pass feature can be used any time and also sends a signal to the BCM. This input is communicated to the IPDM E/R via the CAN communication lines. The CPU of the combination meter controls the ON/OFF status off the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil which supplies power to the high beam headlamps.

The combination meter receives a high beam request signal (ON) via the CAN communication lines and turns the high beam indicator lamp ON.

Component Parts Location

INFOID:000000005268531



WKIA4957E

HEADLAMP

< FUNCTION DIAGNOSIS >

1. IPDM E/R E122, E123, E124
2. BCM M18, M20 (view with lower instrument panel LH removed)
3. Combination switch (lighting and turn signal switch) M28
4. Combination meter M24

Component Description

INFOID:000000005570630


Part name	Description
BCM	<ul style="list-style-type: none">• Receives combination switch (lighting and turn signal switch) request via BCM combination switch reading function.• Sends headlamp high/low request signal to the IPDM E/R.
IPDM E/R	Activates the headlamp high and headlamp low relays upon request from the BCM.
Combination switch (lighting and turn signal switch)	Outputs lighting requests to the BCM.

DAYTIME RUNNING LIGHT SYSTEM

< FUNCTION DIAGNOSIS >

DAYTIME RUNNING LIGHT SYSTEM

System Diagram



System Description

INFOID:000000005570631

The headlamp system for Canada vehicles is equipped with a daytime light control that activates the high beam headlamps at approximately half illumination whenever the engine is operating. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

OPERATION

The BCM monitors inputs from the parking brake switch and the combination switch (lighting and turn signal switch) to determine when to activate the daytime light system. The BCM sends a daytime light request to the IPDM E/R via the CAN communication lines. The IPDM E/R grounds the daytime light relay which in turn, provides power to the ground side of the LH high beam lamp. Power flows backward through the LH high beam lamp to the IPDM E/R, through the high beam fuses, through the RH high beam lamp circuit to the RH high beam lamp and on to ground. The high beam lamps are wired in series which causes them to illuminate at a reduced intensity.


EXL

DAYTIME RUNNING LIGHT SYSTEM

< FUNCTION DIAGNOSIS >

Component Parts Location

INFOID:000000005268535



WKIA4958E

- | | | |
|--|---|---|
| 1. IPDM E/R E119, E122, E123, E124 | 2. Parking brake switch B84 | 3. BCM M18, M20 (view with lower instrument panel LH removed) |
| 4. ECM E16 (view with ECM cover removed) | 5. Generator E205, E209 | 6. Daytime light relay 1 E103 |
| 7. Daytime light relay 2 E104 | 8. Combination switch (lighting and turn signal switch) M28 | 9. Combination meter M24 |

Component Description

INFOID:000000005570634

Part name	Description
BCM	<ul style="list-style-type: none"> Receives combination switch (lighting and turn signal switch) inputs via BCM combination switch reading function. Receives park brake applied input from the park brake switch. Receives engine running status from the ECM via CAN communication.
IPDM E/R	Receives daytime light request from the BCM and activates the daytime light relay.
Combination switch (lighting and turn signal switch)	Outputs lighting requests to the BCM.

DAYTIME RUNNING LIGHT SYSTEM

< FUNCTION DIAGNOSIS >

Parking brake switch	Outputs parking brake status to the combination meter which forwards that information to the BCM via CAN communication.
ECM	Outputs engine running status to the BCM.

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- EXL
- M
- N
- O
- P


OFF-ROAD LAMPS

< FUNCTION DIAGNOSIS >

OFF-ROAD LAMPS

System Diagram

INFOID:000000005268537



System Description

INFOID:000000005268538


The off-road lamps are activated with the off-road lamps switch. The off-road lamps switch provides a request signal to the BCM. The BCM grounds the off-road lamps relay coil to activate the off-road lamps. The high beam headlamps must be ON and the off-road lamp covers removed in order for the BCM to activate the off-road lamps relay.

OFF ROAD LAMP OPERATION

When the off-road lamps switch is in the ON position, the lighting switch is in the 2nd position with the high beams activated and the off-road lamp covers removed, the BCM grounds the off-road lamp relay coil to activate the off-road lamps. The BCM monitors the off-road lamps switch, the lighting switch position via the combination switch reading function and the off-road lamp covers via the off-road lamp cover sensors. The off-road lamp cover sensor is a magnetic sensor which monitors for the presence of the off-road lamp covers.

Component Parts Location

INFOID:000000005268539



1. Off-road lamp assembly
LH B527, B528
RH B529, B530
4. Off-road lamps relay M81

2. BCM M18, M19, M20 (view with lower instrument panel LH removed)
3. Off-road lamps switch M80

OFF-ROAD LAMPS

< FUNCTION DIAGNOSIS >

Component Description

INFOID:000000005268540

Part name	Description
BCM	<ul style="list-style-type: none">• Receives lighting switch requests via BCM combination switch reading function.• Receives off-road lamps request information from the off-road lamps switch.• Receives off-road lamp cover installation status from the off-road lamp cover sensors.• Grounds the off-road lamps relay to activate the off-road lamps.
Off-road lamps switch	Sends off-road lamps request signal to the BCM.
Combination switch (lighting and turn signal switch)	Monitors lighting switch position.
Off-road lamp cover sensors	Senses whether the off-road lamp covers are installed.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


FRONT FOG LAMP

< FUNCTION DIAGNOSIS >

FRONT FOG LAMP

System Diagram

INFOID:000000005569587



System Description

INFOID:000000005569588


The front fog lamps are activated with the combination switch (lighting and turn signal switch). The combination switch (lighting and turn signal switch) signal to the BCM is monitored with the BCM combination switch reading function. When the fog lamps are turned ON with the combination switch (lighting and turn signal switch), the BCM sends a front fog lamp request signal via CAN communication lines to the IPDM E/R. The IPDM E/R grounds the front fog lamp relay coil to activate the front fog lamps.

FRONT FOG LAMP OPERATION

When the combination switch (lighting and turn signal switch) is in front fog lamp ON position and also in 1ST or 2ND position or AUTO (if equipped) position (headlamp is ON), the BCM detects FR FOG ON and the HEAD LAMP1 or 2 ON. The BCM sends a front fog lamp request ON signal via the CAN communication lines to the IPDM E/R. The IPDM E/R then turns ON the front fog lamp relay sending power to the front fog lamps.

Component Parts Location

INFOID:000000005268543



1. IPDM E/R E122, E123, E124

2. BCM M18, M20 (view with lower instru-
ment panel LH removed)

3. Combination switch (lighting and turn
signal switch) M28

FRONT FOG LAMP

< FUNCTION DIAGNOSIS >

Component Description

INFOID:000000005268544

Part name	Description
BCM	<ul style="list-style-type: none">• Receives lighting switch requests via BCM combination switch reading function.• Sends headlamp high/low request signal to the IPDM E/R.
IPDM E/R	Activates the front fog lamp relay upon request from the BCM.
Combination switch (lighting and turn signal switch)	Outputs lighting requests to the BCM.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


TURN SIGNAL AND HAZARD WARNING LAMPS

< FUNCTION DIAGNOSIS >

TURN SIGNAL AND HAZARD WARNING LAMPS

System Diagram

INFOID:000000005569589



System Description

INFOID:000000005569590

TURN SIGNAL OPERATION


When the combination switch (lighting and turn signal switch) is in LH or RH position with the ignition switch in ON position, the BCM detects the TURN RH or TURN LH ON request. The BCM outputs the flasher signal to the respective turn signal lamp. The BCM also sends a turn indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates the appropriate turn signal indicator and audible buzzer.

HAZARD LAMP OPERATION

When the hazard switch is in ON position, the BCM detects the hazard switch signal ON. The BCM outputs the flasher signal (right and left). The BCM sends a hazard indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates the hazard indicator and audible buzzer.

Component Parts Location

INFOID:000000005268547



1. BCM M18, M20 (view with lower instrument panel LH removed)
2. Combination switch (lighting and turn signal switch) M28
3. Combination meter M24
4. Hazard switch M55

TURN SIGNAL AND HAZARD WARNING LAMPS

< FUNCTION DIAGNOSIS >

Component Description

INFOID:0000000005268548

Part name	Description
BCM	Controls turn signal and hazard flasher operation.
Combination switch (lighting and turn signal switch)	Lighting and turn signal switch requests are output to the BCM.
Hazard switch	Hazard flasher request signal is output to the BCM.
Combination meter	Outputs turn and hazard indicator as requested by the BCM.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


PARKING, LICENSE PLATE AND TAIL LAMPS

< FUNCTION DIAGNOSIS >

PARKING, LICENSE PLATE AND TAIL LAMPS

System Diagram

INFOID:000000005569591



AWLIA1723GB

System Description

INFOID:000000005569592

PARKING, LICENCE PLATE AND TAIL LAMPS OPERATION

When the combination switch (lighting and turn signal switch) is in 1ST position, BCM detects the LIGHTING SWITCH 1ST POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which sends power to the parking and instrument illumination circuits.

EXTERIOR LAMP BATTERY SAVER CONTROL


With the combination switch (lighting and turn signal switch) in the 2nd position and the ignition switch is turned from ON or ACC to OFF, the battery saver feature is activated.

Under this condition, the headlamps remain illuminated for 5 minutes unless the combination switch (lighting and turn signal switch) position is changed. If the combination switch (lighting and turn signal switch) position is changed, then the headlamps are turned off.

This setting can be changed by CONSULT-III. Refer to [BCS-23. "BATTERY SAVER : CONSULT-III Function \(BCM - BATTERY SAVER\)"](#).

Component Parts Location

INFOID:000000005268551



AWLIA0732ZZ

1. IPDM E/R E121, E122, E123, E124
2. BCM M18, M20 (view with lower instrument panel LH removed)
3. Combination switch (lighting and turn signal switch) M28

PARKING, LICENSE PLATE AND TAIL LAMPS

< FUNCTION DIAGNOSIS >

Component Description

INFOID:0000000005570633

Part name	Description
BCM	<ul style="list-style-type: none">Receives combination switch (lighting and turn signal switch) requests via BCM combination switch reading function.Sends parking light request signal to the IPDM E/R.
IPDM E/R	Activates the tail lamp relay upon request of the BCM.
Combination switch (lighting and turn signal switch)	Outputs lighting requests to the BCM.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


TRAILER TOW

< FUNCTION DIAGNOSIS >

TRAILER TOW

System Diagram

INFOID:000000005570659



System Description

INFOID:000000005570660

TRAILER TAIL LAMP OPERATION

The trailer tail lamps are controlled by the trailer tow relay 1 located in the IPDM E/R. With the combination switch (lighting and turn signal switch) in the 1st position, the BCM detects the LIGHTING SWITCH 1ST POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which activates the trailer tow relay 1 and sends power to the trailer connector.

TRAILER TURN SIGNAL LAMP OPERATION

The trailer turn signal lamps are controlled by the BCM. When the combination switch (lighting and turn signal switch) is in the LH or RH position with the ignition switch ON, the combination switch (lighting and turn signal switch) sends a signal to the BCM. The BCM detects the TURN RH or TURN LH ON request. The BCM sends a control signal to the respective trailer turn relay which sends power to the trailer connector.

TRAILER HAZARD LAMP OPERATION

The trailer hazard lamps are controlled by the BCM. When the hazard switch is pressed, the BCM detects the hazard ON request. The BCM then sends a control signal to both trailer turn relays which sends power to the trailer connector.

TRAILER BRAKE LAMP OPERATION


The trailer brake lamps are controlled by the BCM. When the brake pedal is depressed, the combination meter receives a stop lamp switch signal from the stop lamp switch. The combination meter then sends the brake signal to the BCM via the CAN communication lines. The BCM then sends a control signal to both trailer turn relays which sends power to the trailer connector.

TRAILER TOW

< FUNCTION DIAGNOSIS >

Component Parts Location

INFOID:0000000005570661



- | | | |
|--|------------------------------|---|
| 1. Stop lamp switch E38 (with M/T) or E39 (with A/T) (view with lower instrument panel LH removed) | 2. Brake pedal | 3. BCM, M18, M19, M20 (view with lower instrument panel LH removed) |
| 4. Trailer turn relay LH E169 | 5. IPDM E/R E119, E122, E124 | 6. Trailer turn relay RH E170 |
| 7. Trailer tow relay 2 E228 | 8. Trailer tow relay 1 E227 | 9. Combination switch (lighting and turn signal switch) M28 |
| 10. Combination meter M24 | | |

Component Description

INFOID:0000000005570662

EXL

Part name	Description
BCM	<ul style="list-style-type: none"> Receives lighting and turn signal requests from combination switch (lighting and turn signal switch). Receives stop lamp signal requests from combination meter via CAN communication. Sends lighting signal request to the IPDM E/R to control the tail lamp relay via CAN communication. Sends turn/hazard/brake control signal to the trailer turn relays.
IPDM E/R	Activates the tail lamp relay upon request from the BCM via CAN communication.
Combination meter	<ul style="list-style-type: none"> Receives stop lamp switch signal from stop lamp switch. Sends stop lamp signal request to the BCM via CAN communication.
Combination switch (lighting and turn signal switch)	Outputs lighting and turn signal requests to the BCM.


COMBINATION SWITCH READING SYSTEM

< FUNCTION DIAGNOSIS >

COMBINATION SWITCH READING SYSTEM

System Diagram

INFOID:000000005569593



System Description

INFOID:000000005569594

OUTLINE


- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM is a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch status.

COMBINATION SWITCH MATRIX

COMBINATION SWITCH READING SYSTEM

< FUNCTION DIAGNOSIS >

Combination switch circuit



Combination switch INPUT-OUTPUT system list

System	OUTPUT 1	OUTPUT 2	OUTPUT 3	OUTPUT 4	OUTPUT 5
INPUT 1	—	FR WASHER	FR WIPER LOW	TURN LH	TURN RH
INPUT 2	FR WIPER HI	—	FR WIPER INT	PASSING	HEADLAMP 1
INPUT 3	INT VOLUME 1	RR WASHER	—	HEADLAMP 2	HI BEAM
INPUT 4	RR WIPER INT	INT VOLUME 3	—	—	TAIL LAMP
INPUT 5	INT VOLUME 2	RR WIPER	—	FR FOG	—


NOTE:

Headlamp has a dual system switch.

COMBINATION SWITCH READING FUNCTION

Description

- BCM reads the status of the combination switch at 10 ms interval normally.



NOTE:


BCM reads the status of the combination switch at 20 ms interval when BCM is controlled at low power consumption control mode.

- BCM operates as follows and judges the status of the combination switch.
 - INPUT 1 - 5 outputs the voltage waveforms of 5 systems simultaneously.
 - It operates the transistor on OUTPUT side in the following order: OUTPUT 5 → 4 → 3 → 2 → 1.

COMBINATION SWITCH READING SYSTEM

< FUNCTION DIAGNOSIS >

- The voltage waveform of INPUT corresponding to the formed circuit changes according to the operation of the transistor on OUTPUT side if any (1 or more) switches are ON.
- It reads this change of the voltage as the status signal of the combination switch.




Operation Example

In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

Example 1: When a switch (TURN RH switch) is turned ON

- The circuit between INPUT 1 and OUTPUT 5 is formed when the TURN RH switch is turned ON.




- BCM detects the combination switch status signal "1E" when the signal of OUTPUT 5 is input to INPUT 1.
- BCM judges that the TURN RH switch is ON when the signal "1E" is detected.

Example 2: When some switches (turn RH switch, front wiper LO switch) are turned ON

COMBINATION SWITCH READING SYSTEM

< FUNCTION DIAGNOSIS >

- The circuits between INPUT 1 and OUTPUT 5 and between INPUT 1 and OUTPUT 3 are formed when the TURN RH switch and FR WIPER LOW switch are turned ON.



- BCM detects the combination switch status signal "1CE" when the signals of OUTPUT 3 and OUTPUT 5 are input to INPUT 1.
- BCM judges that the TURN RH switch and FR WIPER LOW switch are ON when the signal "1CE" is detected.


WIPER INTERMITTENT DIAL POSITION SETTING (FRONT WIPER INTERMITTENT OPERATION)

BCM judges the wiper intermittent dial 1 - 7 by the status of INT VOLUME 1, 2 and 3 switches.

Wiper intermittent dial position	Intermittent operation delay interval	INT VOLUME switch ON/OFF status		
		INT VOLUME 1 switch	INT VOLUME 2 switch	INT VOLUME 3 switch
1	Short ↑	ON	ON	ON
2		ON	ON	OFF
3		ON	OFF	OFF
4		OFF	OFF	OFF
5	Long ↓	OFF	OFF	ON
6		OFF	ON	ON
7		OFF	ON	OFF

Component Parts Location

INFOID:000000005569595



ALMIA0409ZZ

COMBINATION SWITCH READING SYSTEM

< FUNCTION DIAGNOSIS >

1. BCM M18, M19, M20 (view with lower instrument panel LH removed)
2. Combination switch (lighting and turn signal switch) M28
3. Combination switch (wiper and washer switch) M28

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (BCM)

HEADLAMP

HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)

INFOID:000000005569596

WORK SUPPORT

Work Item	Setting item	Setting
BATTERY SAVER SET	ON*	With the exterior lamp battery saver function
	OFF	Without the exterior lamp battery saver function

*: Initial setting

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Ignition switch (ON) status judged from IGN signal (ignition power supply)
ACC ON SW [ON/OFF]	Ignition switch (ACC) status judged from ACC signal (accessory power supply)
HI BEAM SW [ON/OFF]	Each switch status that BCM judges from the combination switch reading function
HEAD LAMP SW 1 [ON/OFF]	
HEAD LAMP SW 2 [ON/OFF]	
LIGHT SW 1ST [ON/OFF]	
PASSING SW [ON/OFF]	
FR FOG SW [ON/OFF]	
TURN SIGNAL R [ON/OFF]	
TURN SIGNAL L [ON/OFF]	
DOOR SW-DR [ON/OFF]	The switch status input from front door switch LH
DOOR SW-AS [ON/OFF]	The switch status input from front door switch RH
DOOR SW-RR [ON/OFF]	The switch status input from rear door switch RH
DOOR SW-RL [ON/OFF]	The switch status input from rear door switch LH
BACK DOOR SW [ON/OFF]	The switch status input from back door switch
CARGO LAMP SW [ON/OFF]	Cargo lamp status that BCM judges from the vehicle condition

ACTIVE TEST

Test Item	Operation	Description
TAIL LAMP	ON	Transmits the position light request signal to IPDM E/R with CAN communication to turn the tail lamp ON.
	OFF	Stops the tail lamp request signal transmission.
HEAD LAMP	HI	Transmits the high beam request signal with CAN communication to turn the headlamp (HI).
	LO	Transmits the low beam request signal with CAN communication to turn the headlamp (LO).
	OFF	Stops the high & low beam request signal transmission.
FR FOG LAMP	ON	Transmits the front fog lights request signal to IPDM E/R with CAN communication to turn the front fog lamp ON.
	OFF	Stops the front fog lights request signal transmission.
CARGO LAMP	ON	Transmits the cargo lamp request signal to IPDM E/R with CAN communication to turn the each lamp ON.
	OFF	Stops the cargo lamp request signal transmission.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

FLASHER

FLASHER : CONSULT-III Function (BCM - FLASHER)

INFOID:000000005569597

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Ignition switch (ON) status judged from IGN signal (ignition power supply)
HAZARD SW [ON/OFF]	The switch status input from the hazard switch
TURN SIGNAL R [ON/OFF]	Each switch condition that BCM judges from the combination switch reading function
TURN SIGNAL L [ON/OFF]	
BRAKE SW [ON/OFF]	The switch status input from the brake switch

ACTIVE TEST

Test Item	Operation	Description
FLASHER	RH	Outputs the voltage to turn the right side turn signal lamps ON.
	LH	Outputs the voltage to turn the left side turn signal lamps ON.
	OFF	Stops the voltage to turn the turn signal lamps OFF.

COMB SW

COMB SW : CONSULT-III Function (BCM - COMB SW)

INFOID:000000005569598

DATA MONITOR

Monitor Item [Unit]	Description
TURN SIGNAL R [OFF/ON]	Displays the status of the TURN RH switch in combination switch judged by BCM with the combination switch reading function
TURN SIGNAL L [OFF/ON]	Displays the status of the TURN LH switch in combination switch judged by BCM with the combination switch reading function
HI BEAM SW [OFF/ON]	Displays the status of the HI BEAM switch in combination switch judged by BCM with the combination switch reading function
HEAD LAMP SW 1 [OFF/ON]	Displays the status of the HEADLAMP switch in combination switch judged by BCM with the combination switch reading function
HEAD LAMP SW 2 [OFF/ON]	Displays the status of the HEADLAMP switch in combination switch judged by BCM with the combination switch reading function
LIGHT SW 1ST [OFF/ON]	Displays the status of the HEADLAMP switch in combination switch judged by BCM with the combination switch reading function
PASSING SW [OFF/ON]	Displays the status of the PASSING switch in combination switch judged by BCM with the combination switch reading function
FR FOG SW [OFF/ON]	Displays the status of the FR FOG switch in combination switch judged by BCM with the combination switch reading function
FR WIPER HI [OFF/ON]	Displays the status of the FR WIPER HI switch in combination switch judged by BCM with the combination switch reading function
FR WIPER LOW [OFF/ON]	Displays the status of the FR WIPER LOW switch in combination switch judged by BCM with the combination switch reading function
FR WIPER INT [OFF/ON]	Displays the status of the FR WIPER INT switch in combination switch judged by BCM with the combination switch reading function
FR WASHER SW [OFF/ON]	Displays the status of the FR WASHER switch in combination switch judged by BCM with the combination switch reading function

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

Monitor Item [Unit]	Description
INT VOLUME [1 - 7]	Displays the status of wiper intermittent dial position judged by BCM with the combination switch reading function
RR WIPER ON [OFF/ON]	Displays the status of the RR WIPER switch in combination switch judged by BCM with the combination switch reading function
RR WIPER INT [OFF/ON]	Displays the status of the RR WIPER INT switch in combination switch judged by BCM with the combination switch reading function
RR WASHER SW [OFF/ON]	Displays the status of the RR WASHER switch in combination switch judged by BCM with the combination switch reading function

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000005569599

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure low warning indicator
- Oil pressure gauge
- Rear window defogger
- Front wipers
- Tail, license and parking lamps
- Front fog lamps (if equipped)
- Headlamps (Hi, Lo)
- A/C compressor (magnetic clutch)
- Cooling fan

Operation Procedure

1. Close the hood and front door RH, and lift the wiper arms from the windshield (to prevent windshield damage due to wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield before hand.

2. Turn ignition switch OFF.
3. Turn the ignition switch ON and, within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:


When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.

CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-24, "Description"](#).
- Do not start the engine.

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 7 steps are repeated 3 times.




Item Number	Test Item	Operation Time/Frequency
1	Rear window defogger	10 seconds
2	Front wipers	LOW 5 seconds then HIGH 5 seconds
3	License plate, tail, parking and fog lamps (if equipped)	10 seconds

DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >

Item Number	Test Item	Operation Time/Frequency
4	Headlamps	LOW 10 seconds then HIGH ON-OFF 5 times
5	A/C compressor (magnet clutch)	ON-OFF 5 times
6	Cooling fan	LOW 5 seconds, then HIGH 5 seconds

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents		Possible cause
Oil pressure low warning indicator does not operate	Perform auto active test. Does the oil pressure low warning indicator operate?	YES	<ul style="list-style-type: none"> • IPDM E/R signal input circuit • ECM signal input circuit • CAN communication signal between ECM and combination meter
		NO	• CAN communication signal between IPDM E/R, BCM and combination meter
Oil pressure gauge does not operate	Perform auto active test. Does the oil pressure gauge operate?	YES	IPDM E/R signal input circuit
		NO	• CAN communication signal between IPDM E/R, BCM and combination meter
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> • Harness or connector between A/C and AV switch assembly and AV control unit • CAN communication signal between BCM and IPDM E/R

DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >

Symptom	Inspection contents		Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> • Front wipers • Tail lamps • License plate lamps • Parking lamps • Front fog lamps (if equipped) • Headlamps (Hi, Lo) 	Perform auto active test. Does the applicable system operate?	YES	BCM signal input system
		NO	<ul style="list-style-type: none"> • Lamp or front wiper motor malfunction • Lamp or front wiper motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R (integrated relay malfunction)
A/C compressor does not operate	Perform auto active test. Does the A/C compressor operate?	YES	<ul style="list-style-type: none"> • BCM signal input circuit • CAN communication signal between BCM and ECM • CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> • Magnetic clutch malfunction • Harness or connector between IPDM E/R and magnetic clutch • IPDM E/R (integrated relay malfunction)
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES	<ul style="list-style-type: none"> • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> • Cooling fan motor malfunction • Harness or connector between IPDM E/R and cooling fan • IPDM E/R (integrated relay malfunction)

CONSULT - III Function (IPDM E/R)

INFOID:000000005569600

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

SELF DIAGNOSTIC

Refer to [PCS-30, "DTC Index"](#).

DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIGNALS	Description
MOTOR FAN REQ [1/2/3/4]	×	Displays the status of the cooling fan speed request signal received from ECM via CAN communication.
A/C COMP REQ [OFF/ON]	×	Displays the status of the A/C request signal received from BCM via CAN communication.

DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >

Monitor Item [Unit]	MAIN SIG- NALS	Description	
TAIL&CLR REQ [OFF/ON]	×	Displays the status of the position light request signal received from BCM via CAN communication.	A
HL LO REQ [OFF/ON]	×	Displays the status of the low beam request signal received from BCM via CAN communication.	B
HL HI REQ [OFF/ON]	×	Displays the status of the high beam request signal received from BCM via CAN communication.	C
FR FOG REQ [OFF/ON]	×	Displays the status of the front fog lamp request signal received from BCM via CAN communication.	
FR WIP REQ [STOP/1LOW/LOW/HI]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.	D
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.	E
WIP PROT [OFF/Block]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.	
ST RLY REQ [OFF/ON]		Displays the status of the starter request signal received from ECM via CAN communication.	F
IGN RLY [OFF/ON]	×	Displays the status of the ignition relay judged by IPDM E/R.	G
RR DEF REQ [OFF/ON]	×	Displays the status of the rear defogger request signal received from AV control unit via CAN communication.	
OIL P SW [OPEN/CLOSE]		Displays the status of the oil pressure switch judged by IPDM E/R.	H
DTRL REQ [OFF]		Displays the status of the daytime light request signal received from BCM via CAN communication.	I
THFT HRN REQ [OFF/ON]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.	
HORN CHIRP [OFF/ON]		Displays the status of the horn reminder signal received from BCM via CAN communication.	J

ACTIVE TEST

Test item

Test item	Operation	Description	
REAR DEFOGGER	OFF	OFF	EXL
	ON	Operates rear window defogger relay.	
FRONT WIPER	OFF	OFF	M
	LO	Operates the front wiper relay.	
	HI	Operates the front wiper relay and front wiper high relay.	
MOTOR FAN	1	OFF	N
	2	OFF	
	3	Operates the cooling fan relay.	
	4	Operates the cooling fan relay.	
EXTERNAL LAMPS	OFF	OFF	P
	TAIL	Operates the tail lamp relay.	
	LO	Operates the headlamp low relay.	
	HI	Operates the headlamp low relay and the headlamp (LH/RH) high relays alternately at 1 second intervals.	
	FOG	Operates the front fog lamp relay	
HORN	ON	Operates horn relay for 20 ms.	

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000005569601

Regarding Wiring Diagram information, refer to [BCS-48, "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	18 (10A)
70		G (50A)
11	Ignition ACC or ON	4 (10A)
38	Ignition ON or START	1 (10A)

Is the fuse blown?


YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM harness connector and ground.

Connector	Terminals		Power source	Condition	Voltage (V) (Approx.)
	(+)	(-)			
M18	11	Ground	ACC power supply	Ignition switch ACC or ON	Battery voltage
	38	Ground	Ignition power supply	Ignition switch ON or START	Battery voltage
M20	57	Ground	Battery power supply	Ignition switch OFF	Battery voltage
	70	Ground	Battery power supply	Ignition switch OFF	Battery voltage



Is the measurement value normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT


< COMPONENT DIAGNOSIS >

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67		Yes

Does continuity exist?

- YES >> Inspection End.
NO >> Repair or replace harness.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000005569602

Regarding Wiring Diagram information, refer to [PCS-25. "Wiring Diagram"](#).

1. CHECK FUSIBLE LINKS

Check that the following IPDM E/R fusible links are not blown.

Terminal No.	Signal name	Fusible link No.
1	Battery	A, D
2		C
22		I


Is the fusible link blown?

- YES >> Replace the blown fusible link after repairing the affected circuit.
NO >> GO TO 2

2. CHECK BATTERY POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect IPDM E/R.
- Check voltage between IPDM E/R harness connectors and ground.

Terminals		Ignition switch position	Voltage (V) (Approx.)
(+)	(-)		
Connector	Terminal		
E118 (A)	1	OFF	Battery voltage
	2		
E120 (B)	22		



Is there voltage on all pins?

- YES >> GO TO 3
NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.

POWER SUPPLY AND GROUND CIRCUIT


< COMPONENT DIAGNOSIS >

- Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E122 (A)	38		Yes
E124 (B)	59		

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair or replace harness.



HEADLAMP (HI) CIRCUIT

< COMPONENT DIAGNOSIS >

HEADLAMP (HI) CIRCUIT

Description

INFOID:0000000005570629

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp LH high and headlamp RH high relays based on inputs from the BCM via the CAN communication lines. When the headlamp LH high and headlamp RH high relays are energized, power flows through fuses 34 and 35, located in the IPDM E/R. Power then flows to the front combination lamps to the headlamp high beam.

Component Function Check

INFOID:0000000005268565

1.CHECK HEADLAMP (HI) OPERATION

⊗WITHOUT CONSULT-III

1. Start IPDM E/R auto active test. Refer to [PCS-13, "Diagnosis Description"](#).
2. Check that the headlamp switches to the high beam.

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

ⓂCONSULT-III

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With the test item operating, check that the headlamp switches to high beam.

HI : Headlamp switches to the high beam.

OFF : Headlamp OFF

Does the headlamp switch to high beam?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-37, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000005570636

Regarding Wiring Diagram information, refer to [EXL-58, "Wiring Diagram"](#) (without DTRL) or [EXL-62, "Wiring Diagram"](#) (with DTRL).

1.CHECK HEADLAMP (HI) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	35	10A
Headlamp HI (RH)	IPDM E/R	34	10A

Is the fuse open?

YES >> Repair the harness and replace the fuse.

NO >> GO TO 2


2.CHECK HEADLAMP (HI) OUTPUT VOLTAGE

HEADLAMP (HI) CIRCUIT

< COMPONENT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector E7 (with DTRL), E11(without DTRL) or E107.
3. Turn the ignition switch ON.
4. Turn the high beam headlamps ON.
5. With the high beam headlamps ON, check the voltage between the combination lamp connector and ground.

(+) Connector		Terminal	(-)	Voltage
LH	E7 (with DTRL)	1	Ground	Battery voltage
	E11 (without DTRL)			
RH	E107			




Is battery voltage present?

- YES >> GO TO 4
NO >> GO TO 3

3.CHECK HEADLAMP (HI) CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector E123.
3. Check continuity between the IPDM E/R harness connector (A) and the front combination lamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
LH	E123	55	E7 (with DTRL)	Yes
		56	E11 (without DTRL)	
RH		56	E107	



Does continuity exist?

- YES >> GO TO 4
NO >> Repair the harnesses or connectors.


4.CHECK FRONT COMBINATION LAMP (HI) GROUND CIRCUIT

Check continuity between the front combination lamp harness connector terminal and ground.

Connector	Terminal	—	Continuity
LH	E7 (with DTRL)	2	Yes
	E11 (without DTRL)		
RH	E107		

Does continuity exist?

- YES >> Inspect the headlamp bulb.
NO >> Repair the harness.



HEADLAMP (LO) CIRCUIT

< COMPONENT DIAGNOSIS >

HEADLAMP (LO) CIRCUIT

Description

INFOID:000000005268567

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp low relay based on inputs from the BCM via the CAN communication lines. When the headlamp low relay is energized, power flows through fuses 40 and 41, located in the IPDM E/R. Power then flows to the front combination lamps to the headlamp low beam.

Component Function Check

INFOID:000000005268568

1.CHECK HEADLAMP (LO) OPERATION

⊗WITHOUT CONSULT-III

1. Start IPDM E/R auto active test. Refer to [PCS-13, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

ⓂCONSULT-III

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With the test items operating, check that the headlamp is turned ON.

LO : Headlamp ON

OFF : Headlamp OFF

Is the headlamp turned ON?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-39, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005570637

Regarding Wiring Diagram information, refer to [EXL-58, "Wiring Diagram"](#) (without DTRL) or [EXL-62, "Wiring Diagram"](#) (with DTRL).

1.CHECK HEADLAMP (LO) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Headlamp LO (LH)	IPDM E/R	40	15A
Headlamp LO (RH)	IPDM E/R	41	15A

Is the fuse open?

YES >> Repair the harness and replace the fuse.

NO >> GO TO 2


2.CHECK HEADLAMP (LO) OUTPUT VOLTAGE

HEADLAMP (LO) CIRCUIT

< COMPONENT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector.
3. Turn the ignition switch ON.
4. Turn the low beam headlamps ON.
5. With the low beam headlamps ON, check the voltage between the combination lamp connector and ground.

(+)			(-)	Voltage
Connector		Terminal		
LH	E7 (with DTRL)	3	Ground	Battery voltage
	E11 (without DTRL)			
RH	E107			




Is battery voltage present?

- YES >> GO TO 4
NO >> GO TO 3

3.CHECK HEADLAMP (LO) CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector (A) and the front combination lamp harness connector (B).

A			B		Continuity
Connector		Terminal	Connector	Terminal	
LH	E123	52	E7 (with DTRL)	3	Yes
			E11 (without DTRL)		
RH		54	E107		



Does continuity exist?

- YES >> GO TO 4
NO >> Repair the harnesses or connectors.


4.CHECK FRONT COMBINATION LAMP (LO) GROUND CIRCUIT

Check continuity between the front combination lamp harness connector terminal and ground.

Connector		Terminal	—	Continuity
LH	E7 (with DTRL)	2	Ground	Yes
	E11 (without DTRL)			
RH	E107			

Does continuity exist?

- YES >> Inspect the headlamp bulb.
NO >> Repair the harness.



OFF-ROAD LAMPS SWITCH CIRCUIT

< COMPONENT DIAGNOSIS >

OFF-ROAD LAMPS SWITCH CIRCUIT

Description

INFOID:000000005268570

The off-road lamps switch sends a momentary ground signal to the BCM requesting the off-road lamps be activated. The BCM controls the off-road lamps relay based on inputs from the combination switch, the off-road lamps switch and the off-road lamp cover sensors. If the headlamps are on high beam, the off-road lamp covers are removed and the off-road lamps switch is activated, the BCM grounds the off-road lamp relay. When the off-road lamps relay is energized, power flows from the off-road lamps relay to the off-road lamps assembly.

Component Function Check

INFOID:000000005268571

1.CHECK OFF-ROAD LAMPS SWITCH OPERATION

Check that the indicator lamp on the off-road lamps switch illuminates with the off-road lamps switch ON.

Is the inspection result normal?

- YES >> Off-road lamps switch function is OK.
NO >> Refer to [EXL-41, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005268572

Regarding Wiring Diagram information, refer to [EXL-74, "Wiring Diagram"](#).

1.CHECK OFF-ROAD LAMPS SWITCH VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the off-road lamps switch connector M80.
3. Turn the ignition switch ON.
4. Check the voltage between the off-road lamps switch connector M80 terminal 1 and ground.

(+)		(-)	Voltage
Connector	Terminal		
M80	1	Ground	5V

Is the inspection result normal?

- YES >> GO TO 3
NO >> GO TO 2.



2.CHECK OFF-ROAD LAMPS SWITCH SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector M18.
3. Check continuity between the off-road lamps switch harness connector M80 (A) terminal 1 and BCM harness connector M18 (B) terminal 31.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M80	1	M18	31	Yes

4. Check continuity between the off-road lamps switch harness connector M80 (A) terminal 1 and ground.

A		—	Continuity
Connector	Terminal		
M80	1	Ground	No



OFF-ROAD LAMPS SWITCH CIRCUIT

< COMPONENT DIAGNOSIS >

Is inspection result normal?

- YES >> GO TO 3.
NO >> Repair the harness.


3.CHECK OFF-ROAD LAMPS SWITCH GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between the off-road lamps switch harness connector M80 terminals 2, 6 and ground.

Connector	Terminal	—	Continuity
M80	2	Ground	Yes
	6		

Does continuity exist?

- YES >> Inspection End.
NO >> Repair the harness or connector.



OFF-ROAD LAMP COVER SENSOR CIRCUIT

< COMPONENT DIAGNOSIS >

OFF-ROAD LAMP COVER SENSOR CIRCUIT

Description

INFOID:000000005268573

The off-road lamp cover sensors sense the presence of the off-road lamp covers. If the off-road lamp covers are installed on the vehicle, the BCM will not activate the off-road lamps. The BCM controls the off-road lamps relay based on inputs from the combination switch, the off-road lamps switch and the off-road lamp cover sensors. When the off-road lamps relay is energized, power flows from the off-road lamps relay to the off-road lamps assembly.

Component Function Check

INFOID:000000005268574

1.CHECK OFF-ROAD LAMPS SWITCH OPERATION

Check that the indicator lamp on the off-road lamps switch illuminates with the off-road lamps switch ON.

Is the inspection result normal?

- YES >> Off-road lamps switch function is OK.
NO >> Refer to [EXL-43, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005268575

Regarding Wiring Diagram information, refer to [EXL-74, "Wiring Diagram"](#).

1.CHECK OFF-ROAD LAMPS FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Off road lamp cover sensor	Fuse block (J/B)	12	10A

Is the fuse open?

- YES >> Repair the harness and replace the fuse.
NO >> GO TO 2

2.CHECK OFF-ROAD LAMP COVER SENSOR VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the off-road lamp assembly connectors.
3. Turn the ignition switch ON.
4. Check the voltage between the off-road lamp assembly connectors and ground.


(+)			(-)	Voltage
Connector		Terminal		
LH	B527	1	Ground	Battery voltage
RH	B529	1		

Is battery voltage present?

- YES >> GO TO 3
NO >> Repair harness or connector.

3.CHECK OFF-ROAD LAMP COVER SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.



OFF-ROAD LAMP COVER SENSOR CIRCUIT


< COMPONENT DIAGNOSIS >

- Check continuity between the off-road lamp assembly harness connectors and ground.

Connector		Terminal	—	Continuity
LH	B527	2	Ground	Yes
RH	B529	2		

Does continuity exist?

- YES >> GO TO 4.
NO >> Repair the harness.




4.CHECK OFF-ROAD LAMP COVER SENSOR SIGNAL CIRCUIT

- Disconnect BCM connector M19.
- Check continuity between the off-road lamp assembly harness connectors (A) and BCM harness connector (B).

A			B		Continuity
Connector	Terminal		Connector	Terminal	
LH	B527	3	M19	42	Yes
RH	B529	3			

- Check continuity between the off-road lamp assembly harness connector and ground.



A			—	Continuity
Connector		Terminal		
LH	B527	3	Ground	No
RH	B529	3		

Is inspection result normal?

- YES >> Replace the off-road lamp cover sensor.
NO >> Repair the harness.

OFF-ROAD LAMPS CIRCUIT

< COMPONENT DIAGNOSIS >

OFF-ROAD LAMPS CIRCUIT

Description

INFOID:000000005268576

The BCM controls the off-road lamps relay based on inputs from the combination switch, the off-road lamps switch and the off-road lamp cover sensors. When the off-road lamps relay is energized, power flows from the off-road lamps relay to the off-road lamps assembly.

Component Function Check

INFOID:000000005268577

1.CHECK OFF-ROAD LAMPS SWITCH OPERATION

Check that the indicator lamp on the off-road lamps switch illuminates with the off-road lamps switch ON.

Is the inspection result normal?

- YES >> Off-road lamps switch function is OK.
NO >> Refer to [EXL-45, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005268578

Regarding Wiring Diagram information, refer to [EXL-74, "Wiring Diagram"](#).

1.CHECK OFF-ROAD LAMPS FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not open.

Unit	Location	Fuse No.	Capacity
Off road lamps assembly	Fuse block (J/B)	2	15A

Is the fuse open?

- YES >> Repair the harness and replace the fuse.
NO >> GO TO 2

2.CHECK OFF-ROAD LAMPS VOLTAGE


1. Turn the ignition switch OFF.
2. Disconnect the off-road lamps assembly connectors.
3. Remove the off-road lamps covers.
4. Turn the ignition switch ON.
5. Turn the high beam headlamps ON.
6. Turn the off-road lamps ON.
7. Check the voltage between the off-road lamp assembly connectors and ground.

(+)		Terminal	(-)	Voltage
Connector				
LH	B528	4	Ground	Battery voltage
RH	B530	4		

Is the inspection result normal?

- YES >> GO TO 3
NO >> GO TO 4

3.CHECK OFF-ROAD LAMPS GROUND CIRCUIT



OFF-ROAD LAMPS CIRCUIT


< COMPONENT DIAGNOSIS >

Check continuity between the off-road lamps assembly harness connector terminal and ground.

Connector		Terminal	—	Continuity
LH	B528	5	Ground	Yes
RH	B530	5		

Is the inspection result normal?

- YES >> Inspect the off-road lamp bulb.
NO >> Repair the harness.



4. CHECK OFF-ROAD LAMPS RELAY

- Turn the ignition switch OFF.
- Disconnect the off-road lamps relay connector.
- Check off-road lamps relay. Refer to [EXL-47, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5
NO >> Replace off-road lamps relay.


5. CHECK OFF-ROAD LAMPS RELAY POWER SUPPLY

- Turn the ignition switch ON.
- Check the voltage between the off-road lamps relay harness connector and ground.

(+) Connector		(-) Terminal	Voltage
M81		2	Battery voltage
		3	

Is the inspection result normal?

- YES >> GO TO 6
NO >> Inspect harness or connector.




6. CHECK OFF-ROAD LAMPS POWER SUPPLY CIRCUIT

- Turn the ignition switch OFF.
- Check continuity between the off-road lamps relay harness connector (A) and off-road lamp assembly harness connectors (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M81	5	LH B528	4	Yes
		RH B530	4	

Is inspection result normal?

- YES >> GO TO 7
NO >> Inspect harness or connector.



7. CHECK OFF-ROAD LAMPS RELAY CONTROL CIRCUIT

- Disconnect BCM connector.

OFF-ROAD LAMPS CIRCUIT


< COMPONENT DIAGNOSIS >

2. Check continuity between the off-road lamps relay harness connector (A) and BCM harness connectors (B).

A		A		Continuity
Connector	Terminal	Connector	Terminal	
M81	1	M19	50	Yes

Is inspection result normal?

- YES >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).
- NO >> Inspect harness or connectors.



INFOID:000000005268579

Component Inspection


1. CHECK OFF-ROAD LAMPS RELAY

Check off-road lamps relay.

Terminal		Condition	Continuity
Off-road lamps relay			
3	5	12V direct current supply between terminals 1 and 2.	Yes
		No current supply	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace off-road lamps relay.



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT FOG LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

FRONT FOG LAMP CIRCUIT

Description

INFOID:000000005268580

The IPDM E/R (intelligent power distribution module engine room) controls the front fog lamp relay based on inputs from the BCM via the CAN communication lines. When the front fog lamp relay is energized, power flows from the front fog lamp relay in the IPDM E/R to the front fog lamps.

Component Function Check

INFOID:000000005268581

1. CHECK FRONT FOG LAMP OPERATION

⊗ WITHOUT CONSULT-III

1. Activate IPDM E/R auto active test. Refer to [PCS-13, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

Ⓟ CONSULT-III

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, Check that the front fog lamp is turned ON.

FOG : Front fog lamp ON

OFF : Front fog lamp OFF

Is the front fog lamp turned ON?

- YES >> Front fog lamp circuit is normal.
NO >> Refer to [EXL-48, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005268582

Regarding Wiring Diagram information, refer to [EXL-70, "Wiring Diagram"](#).

1. CHECK FRONT FOG LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	56	20A

Is the fuse open?

- YES >> Repair the harness and replace the fuse.
NO >> GO TO 2


2. CHECK FRONT FOG LAMP OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front fog lamp connector.
3. Turn the ignition switch ON.
4. Turn the front fog lamps ON.
5. Check the voltage between the fog lamp connector and ground.

(+) Connector		Terminal	(-) Ground	Voltage
LH	E101	1	Ground	Battery voltage
RH	E102	1		

Is battery voltage present?

- YES >> GO TO 4
NO >> GO TO 3



FRONT FOG LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

3.CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front fog lamp harness connector.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
LH	E123	E101	1	Yes
RH			1	

Does continuity exist?

YES >> GO TO 4

NO >> Repair the harnesses or connectors.

4.CHECK FRONT FOG LAMP GROUND CIRCUIT



1. Disconnect the front fog lamp connector.
2. Check continuity between the front fog lamp harness connector terminal and ground.

Connector		Terminal	—	Continuity
LH	E101	2	Ground	Yes
RH	E102	2		

Does continuity exist?

YES >> Inspect the fog lamp bulb.

NO >> Repair the harness.



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

PARKING LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

PARKING LAMP CIRCUIT

Description

INFOID:000000005268583

The IPDM E/R (intelligent power distribution module engine room) controls the tail lamp relay based on inputs from the BCM via the CAN communication lines. When the tail lamp relay is energized, power flows through fuse 37, located in the IPDM E/R. Power then flows to the front and rear combination lamps.

Component Function Check

INFOID:000000005268584

1. CHECK PARKING LAMP OPERATION

⊗ WITHOUT CONSULT-III

1. Activate IPDM E/R auto active test. Refer to [PCS-13, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

Ⓟ CONSULT-III

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON

OFF : Parking lamp OFF

Is the parking lamp turned ON?

- YES >> Parking lamp circuit is normal.
NO >> Refer to [EXL-50, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005268585

Regarding Wiring Diagram information, refer to [EXL-85, "Wiring Diagram"](#).

1. CHECK PARKING LAMP FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Parking lamps	IPDM E/R	36	10A
		37	10A

Is the fuse open?

- YES >> Repair the harness and replace the fuse.
NO >> GO TO 2

2. CHECK TAIL LAMP RELAY OUTPUT (VOLTAGE)


1. Turn the ignition switch OFF.
2. Disconnect the front parking lamp connectors, front side marker lamp connectors, rear combination lamp connectors and license plate lamp connectors.
3. Turn the ignition switch ON.
4. Turn the parking lamps ON.

PARKING LAMP CIRCUIT

< COMPONENT DIAGNOSIS >


5. With the parking lamps ON, check voltage between the front parking lamp connectors and ground.

(+) Connector		Terminal	(-)	Voltage
LH	E27			
RH	E111	2	Ground	Battery voltage




6. With the parking lamps ON, check voltage between the front side marker lamp connectors and ground.

(+) Connector		Terminal	(-)	Voltage
LH	E17			
RH	E108	7	Ground	Battery voltage



7. With the parking lamps ON, check voltage between the rear combination lamp connectors and ground.

(+) Connector		Terminal	(-)	Voltage
LH	B35			
RH	B105	1	Ground	Battery voltage




8. With the parking lamps ON, check voltage between the license plate lamp connector and ground.

(+) Connector		Terminal	(-)	Voltage
C12				
		1	Ground	Battery voltage

Are voltage readings as specified?

- YES >> GO TO 4
NO >> GO TO 3



3. CHECK PARKING, LICENSE PLATE AND TAIL LAMP CIRCUIT (OPEN)


- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector.

PARKING LAMP CIRCUIT

< COMPONENT DIAGNOSIS >


- Check continuity between the IPDM E/R harness connector (A)(B) and the front parking lamp harness connector (C).

Connector		Terminal	Connector	Terminal	Continuity
LH	A: E121	28	C: E27	2	Yes
RH	B: E123	49	C: E111		




- Check continuity between the IPDM E/R harness connector (A)(B) and the front side marker lamp harness connector (C).

Connector		Terminal	Connector	Terminal	Continuity
LH	A: E121	28	C: E17	7	Yes
RH	B: E123	49	C: E108		



- Check continuity between the IPDM E/R harness connector (A) and the rear combination lamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
LH	E124	B35	1	Yes
RH		B105		



PARKING LAMP CIRCUIT

< COMPONENT DIAGNOSIS >


- Check continuity between the IPDM E/R harness connector (A) and license plate lamp connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
E124	57	C12	1	Yes

Are continuity results as specified?

YES >> GO TO 4


NO >> Repair the harnesses or connectors.



4. CHECK PARKING, LICENSE AND TAIL LAMP GROUND CIRCUITS


- Check continuity between the front parking lamp harness connectors and ground.

Connector		Terminal	—	Continuity
LH	E27	3	Ground	Yes
RH	E111			




- Check continuity between the front side marker lamp harness connectors and ground.

Connector		Terminal	—	Continuity
LH	E17	8	Ground	Yes
RH	E108			



- Check continuity between the rear combination lamp harness connectors and ground.

Connector		Terminal	—	Continuity
LH	B35	5	Ground	Yes
RH	B105			



PARKING LAMP CIRCUIT


< COMPONENT DIAGNOSIS >

4. Check continuity between the license plate lamp harness connector and ground.

Connector	Terminal	—	Continuity
C12	2	Ground	Yes

Are continuity results as specified?

- YES >> Inspect the parking lamp bulb.
NO >> Repair the harness.



TURN SIGNAL LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

TURN SIGNAL LAMP CIRCUIT

Description

INFOID:000000005268586

The BCM monitors inputs from the combination switch (lighting and turn signal switch) to determine when to activate the turn signals. The BCM outputs voltage direction to the left and right turn signals during turn signal operation or both during hazard warning operation. The BCM sends a turn signal indicator request to the combination meter via the CAN communication lines.

The BCM performs the fast flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

Component Function Check

INFOID:000000005268587

1.CHECK TURN SIGNAL LAMP

CONSULT-III

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp blinks.

LH : Turn signal lamp LH blinking

RH : Turn signal lamp RH blinking

OFF : The turn signal lamp OFF

Does the turn signal lamp blink?

YES >> Turn signal lamp circuit is normal.

NO >> Refer to [EXL-55, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005268588

Regarding Wiring Diagram information, refer to [EXL-79, "Wiring Diagram"](#).

1.CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb to be sure the proper bulb standard is in use and the bulb is not open.

Is the bulb OK?


YES >> GO TO 2

NO >> Replace the bulb.

2.CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE


1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connectors and the rear combination lamp connector.
3. Turn the ignition switch ON.
4. With turn signal switch operating, check the voltage between the BCM harness connector M20 and ground.

(+) (V)		(-)	Voltage
Connector	Terminal		



TURN SIGNAL LAMP CIRCUIT

< COMPONENT DIAGNOSIS >



Is voltage reading as specified?


YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).

3.CHECK TURN SIGNAL LAMP CIRCUIT FOR OPEN


1. Turn the ignition switch OFF.
2. Disconnect BCM connector M20.
3. Check continuity between the BCM harness connector M20 (A) and the front combination lamps (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
Front LH	M20	E27	1	Yes
Front RH		E111		



4. Check continuity between the BCM harness connector M20 (A) and the rear combination lamp connectors (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
Rear LH	M20	B35	4	Yes
Rear RH		B105	4	



Are continuity results as specified?

YES >> GO TO 4

NO >> Repair the harnesses or connectors.

4.CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between the BCM harness connector M20 and ground.


Connector	Terminal	—	Continuity
LH	M20	60	No
RH		61	

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5

5.CHECK TURN SIGNAL LAMP GROUND CIRCUIT




TURN SIGNAL LAMP CIRCUIT

< COMPONENT DIAGNOSIS >


1. Check continuity between the front combination lamp harness connectors and ground.

Connector		Terminal	—	Continuity
Front LH	E27	3	Ground	Yes
Front RH	E111			



2. Check continuity between the rear combination lamp harness connectors and ground.

Connector		Terminal	—	Continuity
Rear LH	B35	5	Ground	Yes
Rear RH	B105			



Are continuity results as specified?

- YES >> Replace the malfunctioning lamp.
NO >> Repair the harnesses or connectors.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


HEADLAMP

< COMPONENT DIAGNOSIS >

HEADLAMP

Wiring Diagram

INFOID:000000005268589



ABLWA0623GB

HEADLAMP

< COMPONENT DIAGNOSIS >

HEADLAMP CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



7P	8P	9P	4P	3P	2P	1P
10P	11P	12P	13P	14P	15P	16P

Terminal No.	Color of Wire	Signal Name
5P	W/G	-
8P	R/Y	-
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



3	2	1
6	5	4

Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4

Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			

Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

ABLIA1819GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP

< COMPONENT DIAGNOSIS >

Terminal No.	Color of Wire	Signal Name
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



12	13	10	9		8	7	
14	11	1	2	3	4	5	6

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3

Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
16	W/G	RUN START
23	B	POWER GND

Connector No.	E11
Connector Name	FRONT COMBINATION LAMP LH (WITHOUT DAYTIME LIGHT SYSTEM)
Connector Color	BLACK



3	2	1
---	---	---

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3
4	5	6

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7	6	5	4	3	2	1
16	15	14	13	12	11	10
					9	8

Terminal No.	Color of Wire	Signal Name
6	W	—

Terminal No.	Color of Wire	Signal Name
10	P	—
11	L	—

Terminal No.	Color of Wire	Signal Name
1	G	—
2	B	—
3	P	—

ABLIA0649GB

HEADLAMP

< COMPONENT DIAGNOSIS >

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E107
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	BLACK

3	2	1
---	---	---



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-
3	R	-

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE

42	41	40	39	38	37
48	47	46	45	44	43



Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN

51	50	49
56	55	54
53	52	



Terminal No.	Color of Wire	Signal Name
52	P	H/LAMP LO LH
54	R	H/LAMP LO RH
55	G	H/LAMP HI LH
56	L	H/LAMP HI RH

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK

59	58	57
62	61	60



Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)

AALIA0130GB


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

< COMPONENT DIAGNOSIS >

DAYTIME LIGHT SYSTEM

Wiring Diagram


INFOID:0000000005268590



ABLWA0624GB

DAYTIME LIGHT SYSTEM

< COMPONENT DIAGNOSIS >



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DAYTIME LIGHT SYSTEM

< COMPONENT DIAGNOSIS >

DAYTIME LIGHT SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



7P	6P	5P	4P	<div></div>	3P	2P	1P	
16P	15P	14P	13P	12P	11P	10P	9P	8P



3	2	1
6	5	4

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
5P	W/G	-
8P	R/Y	-
15P	W/R	-

Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4

Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			

Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

DAYTIME LIGHT SYSTEM


< COMPONENT DIAGNOSIS >

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3


Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	CHARGE (ALT) INPUT
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
16	W/G	RUN START
23	B	POWER GND
31	G	PARK BRAKE SW

Terminal No.	69G
Color of Wire	P
Signal Name	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA1820GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DAYTIME LIGHT SYSTEM


< COMPONENT DIAGNOSIS >

Connector No.	E7
Connector Name	FRONT COMBINATION LAMP LH (WITH DAYTIME LIGHT SYSTEM)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-
3	SB	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
68J	G	-

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
8	P	-

ABLIA1821GB

DAYTIME LIGHT SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	E103
Connector Name	DAYTIME LIGHT RELAY 1
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	R/B	-
3	B	-
4	GR	-
5	R/B	-

Connector No.	E104
Connector Name	DAYTIME LIGHT RELAY 2
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-
3	SB	-
5	P	-

Connector No.	E107
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-
3	R	-

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	R/B	DTRL RLY SUPPLY

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L
44	R	DTRL RLY CONT

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
52	P	H/LAMP LO LH
54	R	H/LAMP LO RH
55	G	H/LAMP HI LH
56	L	H/LAMP HI RH

ABLIA1823GB

DAYTIME LIGHT SYSTEM

< COMPONENT DIAGNOSIS >


Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



59	58	57
62	61	60


Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
69G	P	-

Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
8	P	-

Connector No.	E205
Connector Name	GENERATOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	P	L

Connector No.	E209
Connector Name	GENERATOR
Connector Color	-



Terminal No.	Color of Wire	Signal Name
5	B	E

ABLIA1822GB

DAYTIME LIGHT SYSTEM


< COMPONENT DIAGNOSIS >

Connector No.	B84
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
68J	G	-

ABLIA1825GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT FOG LAMP SYSTEM


< COMPONENT DIAGNOSIS >

FRONT FOG LAMP SYSTEM

Wiring Diagram

INFOID:000000005268591

FRONT FOG LAMP



ABLWA0626GB

FRONT FOG LAMP SYSTEM

< COMPONENT DIAGNOSIS >

FRONT FOG LAMP CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



7P	6P	5P	4P	3P	2P	1P
16P	15P	14P	13P	12P	11P	10P
9P	8P					

Terminal No.	Color of Wire	Signal Name
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



3	2	1
6	5	4

Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4

Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			

Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

ABLIA0655GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT FOG LAMP SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE

12	13	10	9		8	7	
14	11	1	2	3	4	5	6



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5

Terminal No.	Color of Wire	Signal Name
9	SB	OUTPUT 4
10	V	OUTPUT 3

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE

7	6	5	4	3	2	1		
16	15	14	13	12	11	10	9	8



Terminal No.	Color of Wire	Signal Name
10	P	—
11	L	—

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3
4	5	6



Terminal No.	Color of Wire	Signal Name
6	W	—

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16



Terminal No.	Color of Wire	Signal Name
10	P	—
11	L	—

Connector No.	E101
Connector Name	FRONT FOG LAMP LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	—
2	B	—

AWLIA0655GB

FRONT FOG LAMP SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	E102
Connector Name	FRONT FOG LAMP RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



42	41	40	39	38	37
48	47	46	45	44	43

Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



51	50	49
56	55	54
53	52	

Terminal No.	Color of Wire	Signal Name
50	W	FR FOG LAMP LH
51	V	FR FOG LAMP RH

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



59	58	57
62	61	60


Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)

AALIA0132GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

OFF-ROAD LAMPS CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2N	W/R	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	W/G	-
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
31	R	OFF ROAD LAMP SW
38	W/R	IGN SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
42	L	PCA OUTPUT
50	W	OFF ROAD LAMP OUTPUT

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

ABLIA0678GB

OFF-ROAD LAMPS

< COMPONENT DIAGNOSIS >


Connector No.	M80
Connector Name	OFF-ROAD LAMPS SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-
5	W/R	-
6	B	-

Terminal No.	Color of Wire	Signal Name
4J	L	-
9J	W/R	-
77J	W/G	-
78J	W/R	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M81
Connector Name	OFF-ROAD LAMPS RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W/R	-
3	W/R	-
5	W/R	-

ABLIA0679GB

OFF-ROAD LAMPS


< COMPONENT DIAGNOSIS >

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4J	L	-
9J	W/R	-
77J	W/G	-
78J	W/R	-

Connector No.	B79
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/R	-
2	L	-
3	B	-
4	W/G	-
5	W/R	-
6	B	-

Connector No.	B500
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/R	-
2	L	-
3	B	-
4	W/G	-
5	W/R	-
6	B	-

Connector No.	B501
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W/R	-
2	W/R	-
3	W/G	-
4	B	-
5	B	-
6	L	-

Connector No.	B526
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W/R	-
2	W/R	-
3	W/G	-
4	B	-
5	B	-
6	L	-

ABLIA1826GB

OFF-ROAD LAMPS

< COMPONENT DIAGNOSIS >

Connector No.	B527
Connector Name	OFF-ROAD LAMP ASSEMBLY LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/G	-
2	B	-
3	L	-

Connector No.	B528
Connector Name	OFF-ROAD LAMP ASSEMBLY LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	W/R	-
5	B	-

Connector No.	B529
Connector Name	OFF-ROAD LAMP ASSEMBLY RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/G	-
2	B	-
3	L	-

Connector No.	B530
Connector Name	OFF-ROAD LAMP ASSEMBLY RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	W/R	-
5	B	-

ABLIA1827GB


TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

Wiring Diagram

INFOID:000000005268593



ABLWA0627GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

TURN SIGNAL AND HAZARD WARNING LAMPS CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



7P	3P	5P	4P	16P	13P	12P	11P	10P	9P	8P
----	----	----	----	-----	-----	-----	-----	-----	----	----



3	2	1
6	5	4

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



6	5	4	3	2	1
12	11	10	9	8	7

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
5P	W/G	-
8P	R/Y	-
15P	W/R	-

Terminal No.	Color of Wire	Signal Name
6	W	-

Terminal No.	Color of Wire	Signal Name
2	G	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
29	G	HAZARD SW

Terminal No.	Color of Wire	Signal Name
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			

Terminal No.	Color of Wire	Signal Name
60	LG	FLASHER OUTPUT (LEFT)
61	G	FLASHER OUTPUT (RIGHT)
67	B	GND (POWER)
70	W	BAT (F/L)


ABLIA0656GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >


Terminal No.	Color of Wire	Signal Name
9	SB	OUTPUT 4
10	V	OUTPUT 3

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5


Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
16	W/G	RUN START
23	B	POWER GND

Terminal No.	Color of Wire	Signal Name
53G	G	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA0657GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >


Connector No.	M55
Connector Name	HAZARD SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	—
2	G	—

Terminal No.	Color of Wire	Signal Name
59J	G	—

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	LG	—

Terminal No.	Color of Wire	Signal Name
6	W	—

Terminal No.	Color of Wire	Signal Name
2	LG	—

ABLIA1828GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	E111
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	G	-
2	GR	-
3	B	-

Connector No.	E27
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	R	-
3	B	-


Connector No.	B35
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	G	-
5	B	-

Terminal No.	53G
Color of Wire	G
Signal Name	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA1903GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	B105
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




1	2
3	4
5	6

Terminal No.	Color of Wire	Signal Name
4	G	—
5	B	—

Terminal No.	Color of Wire	Signal Name
59J	G	—

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B162
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
2	G	—

ABLIA0660GB


PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

Wiring Diagram

INFOID:000000005268594



ABLWA0628GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

PARKING, LICENSE PLATE AND TAIL LAMPS CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



7P	6P	5P	4P	<div></div>	3P	2P	1P	
16P	15P	14P	13P	12P	11P	10P	9P	8P



3	2	1
6	5	4

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



6	5	4	3	2	1
12	11	10	9	8	7

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	15P
Color of Wire	W/R
Signal Name	—

Terminal No.	6
Color of Wire	W
Signal Name	—

Terminal No.	12
Color of Wire	V
Signal Name	—

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1

Terminal No.	Color of Wire	Signal Name
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			


Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< COMPONENT DIAGNOSIS >

Terminal No.	Color of Wire	Signal Name
49G	V	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3


Connector No.	E17
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	GRAY



Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	R	-
8	B	-

Terminal No.	Color of Wire	Signal Name
6	W	-

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

ABLIA1829GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Connector No.	E27
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	GRAY



1	3	2
---	---	---

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	WHITE



4	3	2	1
8	7	6	5

Terminal No.	Color of Wire	Signal Name
4	GR	-

Connector No.	E41
Connector Name	WIRE TO WIRE
Connector Color	BLACK



1C 10C	2C 11C	3C 12C	4C 13C	5C 14C	6C 15C	7C 16C	8C 17C	9C 18C
19C	20C 26C	21C 27C	22C 28C	23C 29C	24C 30C	25C	31C 40C	32C 41C
33C 42C	34C 43C	35C 44C	36C 45C	37C 46C	38C 47C	39C 48C		

Connector No.	E108
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	GRAY



8	7
---	---

Terminal No.	Color of Wire	Signal Name
7	R	-
8	B	-

Connector No.	E111
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	GRAY



1	3	2
---	---	---

Terminal No.	Color of Wire	Signal Name
1	G	-
2	GR	-
3	B	-

Terminal No.	Color of Wire	Signal Name
5C	V	-
6C	B	-

ABLIA1830GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN

29	28	27	26	25
36	35	34	33	32
31	30			



Terminal No.	Color of Wire	Signal Name
28	R	ILLUMINATION

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE

42	41	40	39	38	37
48	47	46	45	44	43



Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN

51	50	49
56	55	54
53	52	



Terminal No.	Color of Wire	Signal Name
49	GR	ILLUMINATION


Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK

59	58	57
62	61	60



Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
59	B	GND (POWER)

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
49G	V	-

Connector No.	B35
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE

1	2
3	4
5	6




Terminal No.	Color of Wire	Signal Name
1	GR	-
5	B	-

ABLIA0664GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< COMPONENT DIAGNOSIS >

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	GR	-

Connector No.	B105
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	-
2	L	-
3	BR	-
4	G	-
5	B	-

Connector No.	B162
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	V	-

Connector No.	C1
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
5C	V	-
6C	B	-

Connector No.	C12
Connector Name	LICENSE PLATE LAMP
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-

ABLIA0665GB


STOP LAMP

< COMPONENT DIAGNOSIS >

STOP LAMP

Wiring Diagram

INFOID:000000005268595




STOP LAMP

< COMPONENT DIAGNOSIS >


STOP LAMP CONNECTORS

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	L	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	R/B	-
3	R/B	-
5	G	-

Connector No.	E12
Connector Name	STOP LAMP RELAY
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
50G	L	-

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	Y	-

Connector No.	E38
Connector Name	STOP LAMP SWITCH (WITH M/T)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R/B	-
2	Y	-

Connector No.	E39
Connector Name	STOP LAMP SWITCH (WITH A/T)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/B	-
2	Y	-

STOP LAMP

< COMPONENT DIAGNOSIS >


Connector No.	E160
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



10	20	10
80	70	60
50	40	30

Terminal No.	Color of Wire	Signal Name
8Q	R/B	—

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
50G	L	—

Connector No.	E125
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48

Terminal No.	Color of Wire	Signal Name
35	V	STOP LAMP SW ON
39	SB	STOP LAMP SW

Connector No.	B35
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



1	2
3	4
5	6

Terminal No.	Color of Wire	Signal Name
2	Y	—
5	B	—

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4
5	6	7	8

Terminal No.	Color of Wire	Signal Name
3	Y	—

Connector No.	B48
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3
4	5	6
7	8	9

Terminal No.	Color of Wire	Signal Name
6	R	—

ABLIA0667GB

A B C D E F G H I J K EXL M N O P

STOP LAMP

< COMPONENT DIAGNOSIS >

Connector No.	B105
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE

1	2
3	4
5	6



Terminal No.	Color of Wire	Signal Name
2	L	—
5	B	—

Connector No.	B162
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5	6
7	8	9	10	11	12



Terminal No.	Color of Wire	Signal Name
11	L	—

Connector No.	D402
Connector Name	WIRE TO WIRE
Connector Color	WHITE

3	2	1
8	7	6
5	4	



Terminal No.	Color of Wire	Signal Name
6	R	—

Connector No.	D403
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Color	WHITE

2	1
---	---



Terminal No.	Color of Wire	Signal Name
1	R	—
2	B	—

Connector No.	D409
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2
---	---



Terminal No.	Color of Wire	Signal Name
2	B	—

Connector No.	D650
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2
---	---



Terminal No.	Color of Wire	Signal Name
2	B	—

ABLIA0668GB

BACK-UP LAMP


< COMPONENT DIAGNOSIS >

BACK-UP LAMP

Wiring Diagram

INFOID:000000005268596

A : WITH A/T
M : WITH M/T



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ABLWA0630GB

BACK-UP LAMP


EXL

BACK-UP LAMP

< COMPONENT DIAGNOSIS >


BACK-UP LAMP CONNECTORS

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	BR	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
54G	SB	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
58J	SB	-

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LG	-
10	W/G	-
11	SB	-

Connector No.	E45
Connector Name	BACK-UP LAMP RELAY (WITH A/T)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	W/G	-
3	SB	-
5	W/G	-
6	Y	-
7	W/G	-

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	W/G	REVERSE LAMP

BACK-UP LAMP

< COMPONENT DIAGNOSIS >


Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN

29	28		27	26	25	
36	35	34	33	32	31	30




Terminal No.	Color of Wire	Signal Name
27	W	T TOW REV LAMP

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	F9
Connector Name	A/T ASSEMBLY
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
7	LG	-

Terminal No.	Color of Wire	Signal Name
54G	SB	-

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LG	-
10	W/G	-
11	SB	-

Connector No.	F69
Connector Name	BACK-UP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/G	-
2	SB	-

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
7	O	REV LAMP RLY

ABLIA0670GB

BACK-UP LAMP

< COMPONENT DIAGNOSIS >


Connector No.	B35
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



1	2
3	4
5	6

Terminal No.	Color of Wire	Signal Name
3	SB	—
5	B	—

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B105
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE



1	2
3	4
5	6

Terminal No.	Color of Wire	Signal Name
3	BR	—
5	B	—

Terminal No.	Color of Wire	Signal Name
58J	SB	—

Connector No.	B162
Connector Name	WIRE TO WIRE
Connector Color	WHITE




1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
1	BR	—

TRAILER TOW

< COMPONENT DIAGNOSIS >



ABLWA0646GB

TRAILER TOW CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



7P	8P	9P	4P	3P	2P	1P
16P	15P	14P	13P	12P	11P	10P
9P	8P					

Terminal No.	Color of Wire	Signal Name
5P	W/G	-
8P	R/Y	-
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



3	2	1
6	5	4

Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1

Terminal No.	Color of Wire	Signal Name
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

Terminal No.	Color of Wire	Signal Name
51	O	TRAILER FLASHER OUTPUT (RIGHT)
52	LG	TRAILER FLASHER OUTPUT (LEFT)

ABLIA1832GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TRAILER TOW

< COMPONENT DIAGNOSIS >

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

56 57 58 59 60 61 62 63 64
165 166 167 168 169 170



Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

Connector No.	M24
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1
40 39 38 37 36 35 34 33 32 31 30 29 28 27 26 25 24 23 22 21

Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
16	W/G	RUN START
23	B	POWER GND
33	LG	BRAKE PEDAL SW


Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



12 13 10 9 8 7
14 11 1 2 3 4 5 6

Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1G	O	-
2G	BR	-
31G	O	-
32G	LG	-
62G	R	-
68G	LG	-

Connector No.	M76
Connector Name	ELECTRIC BRAKE (PRE-WIRING)
Connector Color	WHITE



2 6
1 3 4 5

Terminal No.	Color of Wire	Signal Name
1	B	GROUND
2	LG	STOP
3	BR	-
4	R	ILL (TAIL)
5	O	+B

TRAILER TOW

< COMPONENT DIAGNOSIS >

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3
4	5	6

Terminal No.	Color of Wire	Signal Name
6	W	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7	6	5	4	3	2	1		
16	15	14	13	12	11	10	9	8

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E41
Connector Name	WIRE TO WIRE
Connector Color	BLACK



1C	10C	19C	31C	40C
2C	11C	20C	32C	41C
3C	12C	21C	33C	42C
4C	13C	22C	34C	43C
5C	14C	23C	35C	44C
6C	15C	24C	36C	45C
7C	16C	25C	37C	46C
8C	17C		38C	47C
9C	18C		39C	48C

Connector No.	E39
Connector Name	STOP LAMP SWITCH (WITH A/T)
Connector Color	WHITE



3	4
1	2

Terminal No.	Color of Wire	Signal Name
1	R/B	-
2	Y	-

Connector No.	E38
Connector Name	STOP LAMP SWITCH (WITH M/T)
Connector Color	BLACK



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	R/B	-
2	Y	-

Terminal No.	Color of Wire	Signal Name
2C	G	-
3C	V	-
4C	Y	-
19C	V	-
20C	B	-
21C	R	-
22C	BR	-

ABLIA1833GB

TRAILER TOW

< COMPONENT DIAGNOSIS >

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



59	58	57
62	61	60

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



42	41	40	39	38	37
48	47	46	45	44	43

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



29	28		27	26	25
36	35	34	33	32	31
					30

Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
59	B	GND (POWER)
61	R/B	TRAILER RLY SUPPLY

Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
27	W/G	T TOW REV LAMP
29	G	TRAILER RLY CONT


Connector No.	E160
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



3Q	<div></div>	2Q	1Q	
8Q	7Q	6Q	5Q	4Q

Terminal No.	Color of Wire	Signal Name
1G	O	-
2G	BR	-
31G	O	-
32G	LG	-
62G	R	-
68G	LG	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA1863GB

TRAILER TOW

< COMPONENT DIAGNOSIS >

Connector No.	E168
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W/G	-
3	R/B	-
4	GR	-
5	Y	-
6	P	-
7	W/G	-
8	Y	-
9	V	-
10	R	-
11	V	-
12	G	-

Connector No.	E169
Connector Name	TRAILER TURN RELAY LH
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-
3	V	-
5	L	-

Connector No.	E170
Connector Name	TRAILER TURN RELAY RH
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-
3	G	-
5	L	-

Connector No.	E225
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W/G	-
3	R/B	-
4	GR	-
5	W	-
6	BR	-

Terminal No.	Color of Wire	Signal Name
7	W/G	-
8	SB	-
9	L	-
10	R	-
11	O	-
12	G	-

Connector No.	E226
Connector Name	BACK-UP LAMP RELAY (WITH W/T)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	BR	-
3	W/G	-
5	SB	-

ABLIA1864GB

< COMPONENT DIAGNOSIS >

TRAILER TOW


< COMPONENT DIAGNOSIS >

Connector No.	C150
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	L	-

Connector No.	C126
Connector Name	TRAILER
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	W	-
3	V	-
4	BR	-
5	L	-
6	G	-
7	B	-

ABLIA1866GB

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- EXL
- M
- N
- O
- P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000005570638

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF or ACC	OFF
	Ignition switch ON	ON
KEY ON SW	Mechanical key is removed from key cylinder	OFF
	Mechanical key is inserted to key cylinder	ON
CDL LOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the lock side	ON
CDL UNLOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the unlock side	ON
DOOR SW-DR	Driver's door closed	OFF
	Driver's door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear RH door closed	OFF
	Rear RH door opened	ON
DOOR SW-RL	Rear LH door closed	OFF
	Rear LH door opened	ON
BACK DOOR SW	Back door closed	OFF
	Back door opened	ON
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF
	Driver door key cylinder LOCK position	ON
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF
	Driver door key cylinder UNLOCK position	ON
KEYLESS LOCK	"LOCK" button of key fob is not pressed	OFF
	"LOCK" button of key fob is pressed	ON
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	OFF
	"UNLOCK" button of key fob is pressed	ON
ACC ON SW	Ignition switch OFF	OFF
	Ignition switch ACC or ON	ON
REAR DEF SW	Rear window defogger switch OFF	OFF
	Rear window defogger switch ON	ON
LIGHT SW 1ST	Lighting switch OFF	OFF
	Lighting switch 1ST	ON
BUCKLE SW	The seat belt (driver side) is unfastened. [Seat belt switch (driver side) OFF]	OFF
	The seat belt (driver side) is fastened. [Seat belt switch (driver side) ON]	ON
KEYLESS PANIC	PANIC button of key fob is not pressed	OFF
	PANIC button of key fob is pressed	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
HI BEAM SW	Lighting switch OFF	OFF	A
	Lighting switch HI	ON	
HEAD LAMP SW 1	Lighting switch OFF	OFF	B
	Lighting switch 2ND	ON	
HEAD LAMP SW 2	Lighting switch OFF	OFF	C
	Lighting switch 2ND	ON	
PASSING SW	Other than lighting switch PASS	OFF	D
	Lighting switch PASS	ON	
FR FOG SW	Front fog lamp switch OFF	OFF	E
	Front fog lamp switch ON	ON	
TURN SIGNAL R	Turn signal switch OFF	OFF	F
	Turn signal switch RH	ON	
TURN SIGNAL L	Turn signal switch OFF	OFF	G
	Turn signal switch LH	ON	
CARGO LAMP SW	Cargo lamp switch OFF	OFF	H
	Cargo lamp switch ON	ON	
IGN SW CAN	Ignition switch OFF or ACC	OFF	I
	Ignition switch ON	ON	
FR WIPER HI	Front wiper switch OFF	OFF	J
	Front wiper switch HI	ON	
FR WIPER LOW	Front wiper switch OFF	OFF	K
	Front wiper switch LO	ON	
FR WIPER INT	Front wiper switch OFF	OFF	EXL
	Front wiper switch INT	ON	
FR WASHER SW	Front washer switch OFF	OFF	M
	Front washer switch ON	ON	
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7	N
FR WIPER STOP	Any position other than front wiper stop position	OFF	
	Front wiper stop position	ON	O
VEHICLE SPEED	While driving	Equivalent to speedometer reading	
RR WIPER ON	Rear wiper switch OFF	OFF	P
	Rear wiper switch ON	ON	
RR WIPER INT	Rear wiper switch OFF	OFF	
	Rear wiper switch INT	ON	
RR WASHER SW	Rear washer switch OFF	OFF	
	Rear washer switch ON	ON	
RR WIPER STOP	Any position other than rear wiper stop position	OFF	
	Rear wiper stop position	ON	
HAZARD SW	Hazard switch OFF	OFF	
	Hazard switch ON	ON	
BRAKE SW	Brake pedal is not depressed	OFF	
	Brake pedal is depressed	ON	
FAN ON SIG	Blower fan motor switch OFF	OFF	
	Blower fan motor switch ON (other than OFF)	ON	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


Monitor Item	Condition	Value/Status
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	OFF
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	ON
OIL PRESS SW	<ul style="list-style-type: none"> Ignition switch OFF or ACC Engine running 	OFF
	Ignition switch ON	ON
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	DONE
	ID of front LH tire transmitter is not registered	YET
ID REGST FR1	ID of front RH tire transmitter is registered	DONE
	ID of front RH tire transmitter is not registered	YET
ID REGST RR1	ID of rear RH tire transmitter is registered	DONE
	ID of rear RH tire transmitter is not registered	YET
ID REGST RL1	ID of rear LH tire transmitter is registered	DONE
	ID of rear LH tire transmitter is not registered	YET
WARNING LAMP	Tire pressure indicator OFF	OFF
	Tire pressure indicator ON	ON
BUZZER	Tire pressure warning alarm is not sounding	OFF
	Tire pressure warning alarm is sounding	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal Layout

INFOID:000000005570639



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P





Physical Values

LIIA2443E

INFOID:000000005570640




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
1	BR	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)	Battery voltage
					Door is unlocked (SW ON)	0V
2	P	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
3	SB	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
4	V	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
5	L	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
6	R	Combination switch input 1				
7	GR	Front door lock assembly LH (key cylinder switch) and back door key cylinder switch (unlock)	Input	OFF	ON (open, 2nd turn)	Momentary 1.5V
					OFF (closed)	0V
8	SB	Front door lock assembly LH (key cylinder switch) and back door key cylinder switch (lock)	Input	OFF	ON (open)	Momentary 1.5V
					OFF (closed)	0V
9	Y	Rear window defogger switch	Input	ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
11	G/B	Ignition switch (ACC or ON)	Input	ACC or ON	Ignition switch ACC or ON	Battery voltage
12	LG	Front door switch RH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
13	L	Rear door switch RH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	W	Tire pressure warning check connector	Input	OFF	—	5V
18	BR	Remote keyless entry receiver (ground)	Output	OFF	—	0V
19	V	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	
20	G	Remote keyless entry receiver (signal)	Input	OFF	Stand-by (keyfob buttons released)	
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	
21	GR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
23	G	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
27	W	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	G	Hazard switch	Input	OFF	ON	0V
					OFF	5V
31	R	Off-road lamps switch	Input	ON	ON	0V
					OFF	5V

A

B

C

D

E

F

G

H

I

J

K

EXL

M





N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
32	O	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
33	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
34	G	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
35	BR	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
36	LG	Combination switch output 1				
37	B	Key switch and key lock solenoid	Input	OFF	Key inserted	Battery voltage
					Key inserted	0V
38	W/R	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN-H	—	—	—	—
40	P	CAN-L	—	—	—	—
42	L	Off-road lamps	Output	ON	Off-road lamps switch	ON: 0V OFF: Battery voltage
43	Y	Back door switch	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
44	O	Rear wiper auto stop switch	Input	ON	Rise up position (rear wiper arm on stopper)	0V
					A Position (full clockwise stop position)	Battery voltage
					Forward sweep (counterclockwise direction)	Fluctuating
					B Position (full counterclockwise stop position)	0V
					Reverse sweep (clockwise direction)	Fluctuating

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
45	V	Lock switch	Input	OFF	ON (lock)	0V
					OFF	Battery voltage
46	LG	Unlock switch	Input	OFF	ON (unlock)	0V
					OFF	Battery voltage
47	GR	Front door switch LH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
48	P	Rear door switch LH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
49	L	Cargo lamp	Output	OFF	Any door open (ON)	0V
					All doors closed (OFF)	Battery voltage
50	W	Off-road lamps relay	Output	ON	Off-road lamps switch	ON OFF
						0V Battery voltage
51	O	Trailer turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
52	LG	Trailer turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
55	W	Rear wiper output circuit 1	Output	ON	OFF	0
					ON	Battery voltage
56	R/Y	Battery saver output	Output	OFF	30 minutes after ignition switch is turned OFF	0V
				ON	—	Battery voltage
57	R/Y	Battery power supply	Input	OFF	—	Battery voltage
59	GR	Front door lock assembly LH actuator (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
60	LG	Turn signal (left)	Output	ON	Turn left ON	 SKIA3009J

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
61	G	Turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
63	BR	Interior room/map lamp	Output	OFF	Any door switch	ON (open) 0V OFF (closed) Battery voltage
					OFF (neutral)	0V
65	V	All door lock actuators (lock)	Output	OFF	ON (lock)	Battery voltage
					OFF (neutral)	0V
66	L	Front door lock actuator RH, rear door lock actuators LH/RH and back door lock actuator (unlock)	Output	OFF	ON (unlock)	Battery voltage
					OFF (neutral)	0V
67	B	Ground	Input	ON	—	0V
68	O	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
70	W	Battery power supply	Input	OFF	—	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


Wiring Diagram

INFOID:000000005570641



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

BCM (BODY CONTROL MODULE) CONNECTORS

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
1	BR	KEY RING OUTPUT
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1

Terminal No.	Color of Wire	Signal Name
7	GR	KEY CYLINDER UNLOCK SW
8	SB	KEY CYLINDER LOCK SW
9	Y	DEFOGGER SW
10	-	-
11	G/B	ACC_SW
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)
14	-	-
15	W	TPMS MODE TRIGGER SW
16	-	-
17	-	-
18	BR	KEYLESS & AUTO LIGHT SENSOR GND
19	V	KEYLESS TUNER POWER SUPPLY OUTPUT
20	G	KEYLESS TUNER SIGNAL
21	GR	IMMOBILIZER ANTENNA SIGNAL (CLOCK)

Terminal No.	Color of Wire	Signal Name
22	-	-
23	G	SECURITY INDICATOR OUTPUT
24	-	-
25	BR	IMMOBILIZER ANTENNA SIG (RX, TX)
26	-	-
27	W	AIRCON SW
28	R	BLOWER FAN SW
29	G	HAZARD SW
30	-	-
31	R	OFF ROAD LAMP SW
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
37	B	KEY SW
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

ABMIA0363GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE

12	13	10	9	8	7
14	11	1	2	3	4
5	6				



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3
11	O	WASH FR (-) RR (+)
12	B	GND
13	L	WASH FR (+) RR (-)
14	W/G	IGN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			



Terminal No.	Color of Wire	Signal Name
56	R/Y	BATTERY SAVER OUTPUT
57	R/Y	BAT (FUSE)
58	-	-
59	GR	DOOR UNLOCK OUTPUT (DR)
60	LG	FLASHER OUTPUT (LEFT)
61	G	FLASHER OUTPUT (RIGHT)
62	-	-
63	BR	ROOM LAMP OUTPUT
64	-	-
65	V	DOOR LOCK OUTPUT (ALL)
66	L	DOOR UNLOCK OUTPUT (OTHER)
67	B	GND (POWER)
68	O	POWER WINDOW POWER SUPPLY OUT (LINKED TO RAP)
69	-	-
70	W	BAT (F/L)

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE

41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			



Terminal No.	Color of Wire	Signal Name
41	-	-
42	L	PCA OUTPUT
43	Y	BACK DOOR SW
44	O	REAR WIPER AUTO STOP SW1
45	V	CDL LOCK SW
46	LG	CDL UNLOCK SW
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)
49	L	CARGO LAMP OUTPUT
50	W	OFF ROAD LAMP OUTPUT
51	O	TRAILER FLASHER OUTPUT (RIGHT)
52	LG	TRAILER FLASHER OUTPUT (LEFT)
53	-	-
54	-	-
55	W	REAR WIPER MOTOR OUTPUT 1

ABMIA1427GB

INFOID:000000005570642

Fail Safe

Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
U1000: CAN COMM CIRCUIT	Inhibit engine cranking	When the BCM re-establishes communication with the other modules.

DTC Inspection Priority Chart

INFOID:000000005570643

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	• U1000: CAN COMM CIRCUIT
2	• B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM
3	• C1729: VHCL SPEED SIG ERR • C1735: IGNITION SIGNAL
4	• C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL

DTC Index

INFOID:000000005570644

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	—	—	BCS-30

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
B2190: NATS ANTENNA AMP	—	—	SEC-18
B2191: DIFFERENCE OF KEY	—	—	SEC-21
B2192: ID DISCORD BCM-ECM	—	—	SEC-22
B2193: CHAIN OF BCM-ECM	—	—	SEC-24
C1708: [NO DATA] FL	—	—	WT-14
C1709: [NO DATA] FR	—	—	WT-14
C1710: [NO DATA] RR	—	—	WT-14
C1711: [NO DATA] RL	—	—	WT-14
C1712: [CHECKSUM ERR] FL	—	—	WT-16
C1713: [CHECKSUM ERR] FR	—	—	WT-16
C1714: [CHECKSUM ERR] RR	—	—	WT-16
C1715: [CHECKSUM ERR] RL	—	—	WT-16
C1716: [PRESSDATA ERR] FL	—	—	WT-18
C1717: [PRESSDATA ERR] FR	—	—	WT-18
C1718: [PRESSDATA ERR] RR	—	—	WT-18
C1719: [PRESSDATA ERR] RL	—	—	WT-18
C1720: [CODE ERR] FL	—	—	WT-16
C1721: [CODE ERR] FR	—	—	WT-16
C1722: [CODE ERR] RR	—	—	WT-16
C1723: [CODE ERR] RL	—	—	WT-16
C1724: [BATT VOLT LOW] FL	—	—	WT-16
C1725: [BATT VOLT LOW] FR	—	—	WT-16
C1726: [BATT VOLT LOW] RR	—	—	WT-16
C1727: [BATT VOLT LOW] RL	—	—	WT-16
C1729: VHCL SPEED SIG ERR	—	—	WT-19
C1735: IGNITION SIGNAL	—	—	—

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000005570645

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 - 100 %
A/C COMP REQ	A/C switch OFF		OFF
	A/C switch ON		ON
TAIL&CLR REQ	Lighting switch OFF		OFF
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		ON
HL LO REQ	Lighting switch OFF		OFF
	Lighting switch 2ND HI or AUTO (Light is illuminated)		ON
HL HI REQ	Lighting switch OFF		OFF
	Lighting switch HI		ON
FR FOG REQ	Lighting switch 2ND	Front fog lamp switch OFF	OFF
		Front fog lamp switch ON	ON
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	STOP
		Front wiper switch INT	1LOW
		Front wiper switch LO	LOW
		Front wiper switch HI	HI
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	OFF
		Front wiper stops at fail-safe operation	BLOCK
ST RLY REQ	Ignition switch OFF or ACC		OFF
	Ignition switch START		ON
IGN RLY	Ignition switch OFF or ACC		OFF
	Ignition switch ON		ON
RR DEF REQ	Rear defogger switch OFF		OFF
	Rear defogger switch ON		ON
OIL P SW	Ignition switch OFF, ACC or engine running		OPEN
	Ignition switch ON		CLOSE
DTRL REQ	Daytime light system requested OFF with CONSULT-III.		OFF
	Daytime light system requested ON with CONSULT-III.		ON
THFT HRN REQ	Not operated		OFF
	<ul style="list-style-type: none"> Panic alarm is activated Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM 		ON
HORN CHIRP	Not operated		OFF
	Door locking with keyfob (horn chirp mode)		ON


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal Layout

INFOID:000000005570646

TERMINAL LAYOUT —TYPE A




WKIA5883E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

TERMINAL LAYOUT —TYPE B



Physical Values

PHYSICAL VALUES

AAMIA0364GB

INFOID:000000005570647




IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
1	W	Battery power supply	Input	OFF	—	Battery voltage
2	R	Battery power supply	Input	OFF	—	Battery voltage
3	G	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
4	P	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
6	V	Throttle control motor relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
7	BR	ECM relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
8	W/R	Fuse 54	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
10	R/B	Fuse 45	Output	ON	Daytime light system active	0V
					Daytime light system inactive	Battery voltage
11	Y	A/C compressor	Output	ON or START	A/C switch ON or defrost A/C switch	Battery voltage
					A/C switch OFF or defrost A/C switch	0V
12	W/G	Ignition switch supplied power	Input	—	OFF or ACC	0V
					ON or START	Battery voltage
13	R	Fuel pump relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
14	W/G	Fuse 49	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
15	W/R	Fuse 50 (ABS)	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
16	W/G	Fuse 51	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
17	W/G	Fuse 55	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
19	W	Starter motor	Output	START	—	Battery voltage
20	BR	Cooling fan motor (low)	Output	ON or START	—	Battery voltage
21	GR	Ignition switch supplied power	Input	—	OFF or ACC	0V
					START	Battery voltage
22	G	Battery power supply	Output	OFF	—	Battery voltage
23	LG	Door mirror defogger output signal	Output	—	When rear defogger switch is ON	Battery voltage
					When raker defogger switch is OFF	0V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
24	P	Cooling fan motor (high)	Output	—	Conditions correct for cooling fan operation	Battery voltage
					Conditions not correct for cooling fan operation	0V
27	W/G	Fuse 38	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
28	R	LH front parking and front side marker lamp	Output	OFF	Lighting switch 1st position OFF	0V
					ON	Battery voltage
29	G	Trailer tow relay	Output	ON	Lighting switch 1st position OFF	0V
					ON	Battery voltage
30	R/B	Fuse 53	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
32	GR	Wiper low speed signal	Output	ON or START	Wiper switch OFF	Battery voltage
					LO or INT	0V
35	L	Wiper high speed signal	Output	ON or START	Wiper switch OFF, LO, INT	Battery voltage
					HI	0V
37	Y	Power generation command signal	Output	—	Ignition switch ON	 <p>JP MIA0001GB</p> <p>6.3 V</p>
					40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	 <p>JP MIA0002GB</p> <p>3.8 V</p>
					40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	 <p>JP MIA0003GB</p> <p>1.4 V</p>
38	B	Ground	Input	—	—	0V
39	L	CAN-H	—	ON	—	—
40	P	CAN-L	—	ON	—	—
42	GR	Oil pressure switch	Input	—	Engine running	Battery voltage
					Engine stopped	0V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition			Reference value (Approx.)
				Ignition switch	Operation or condition		
43	G	Wiper auto stop signal	Input	ON or START	Wiper switch	OFF, LO, INT	Battery voltage
44	R	Daytime light relay control (Canada only)	Input	ON	Daytime light system active		0V
					Daytime light system inactive		Battery voltage
45	LG	Horn relay control	Input	ON	When door locks are operated using keyfob (OFF → ON)*		Battery voltage → 0V
46	V	Fuel pump relay control	Input	—	Ignition switch ON or START		0V
					Ignition switch OFF or ACC		Battery voltage
47	O	Throttle control motor relay control	Input	—	Ignition switch ON or START		0V
					Ignition switch OFF or ACC		Battery voltage
48	R	Starter relay (inhibit switch)	Input	ON or START	Selector lever in "P" or "N"		0V
					Selector lever any other position		Battery voltage
49	GR	Front RH parking and front side marker lamp	Output	OFF	Lighting switch 1st position	OFF	0V
						ON	Battery voltage
50	W	Front fog lamp (LH)	Output	ON or START	Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch	OFF	0V
						ON	Battery voltage
51	V	Front fog lamp (RH)	Output	ON or START	Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch	OFF	0V
						ON	Battery voltage
52	P	LH low beam head-lamp	Output	—	Lighting switch in 2nd position		Battery voltage
54	R	RH low beam head-lamp	Output	—	Lighting switch in 2nd position		Battery voltage
55	G	LH high beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position		Battery voltage
56	L	RH high beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position		Battery voltage
57	GR	Parking, license and tail lamps and off-road lamp switch	Output	ON	Lighting switch 1st position	OFF	0V
						ON	Battery voltage
59	B	Ground	Input	—	—		0V
60	GR	Rear window defogger relay	Output	ON or START	Rear defogger switch ON		Battery voltage
					Rear defogger switch OFF		0V
61	R/B	Fuse 32	Output	OFF	—		Battery voltage


*: When horn reminder is ON

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Wiring Diagram


INFOID:000000005570648



ABMWA0530GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS

Connector No.	E30
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	—



Terminal No.	Color of Wire	Signal Name
3	R	—

Connector No.	E118
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	F/L USM
2	R	F/L MAIN


Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	IGN COIL
4	P	ECM
5	—	—
6	V	ETC

Terminal No.	Color of Wire	Signal Name
7	BR	ECM RLY CONT
8	W/R	O2 SENSOR
9	—	—
10	R/B	DTRL RLY SUPPLY
11	Y	A/C COMPRESSOR
12	W/G	IGN SW (IG)
13	R	FUEL PUMP
14	W/G	A/T ECU IGN SUPPLY
15	W/R	ABS IGN SUPPLY
16	W/G	REVERSE LAMP
17	W/G	INJECTOR
18	—	—

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	W	STARTER MTR
20	BR	MOTOR FAN 1
21	GR	IGN SW (ST)
22	G	F/L MOTOR FAN
23	LG	HEATED MIRROR
24	P	MOTOR FAN 2

ABMIA1496GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN

51	50	49
56	55	54
53	52	



Terminal No.	Color of Wire	Signal Name
49	GR	ILLUMINATION
50	W	FR FOG LAMP LH
51	V	FR FOG LAMP RH
52	P	H/LAMP LO LH
53	—	—
54	R	H/LAMP LO RH
55	G	H/LAMP HI LH
56	L	H/LAMP HI RH

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE

42	41	40	39	38	37
48	47	46	45	44	43



Terminal No.	Color of Wire	Signal Name
37	Y	ALT-C CONT
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L
41	—	—
42	GR	OIL PRESSURE SW
43	G	AUTO STOP SW
44	R	DTRL RLY CONT
45	LG	ANT THEFT HORN
46	V	FUEL PUMP RLY CONT
47	O	ETC RLY CONT
48	R	INHIBIT SW

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN

29	28	27	26	25
36	35	34	33	32
31	30			



Terminal No.	Color of Wire	Signal Name
25	—	—
26	—	—
27	W/G	TTOW REV LAMP
28	R	ILLUMINATION
29	G	TRAILER RLY CONT
30	R/B	ECM BAT
31	—	—
32	GR	FR WIPER LO
33	—	—
34	—	—
35	L	FR WIPER HI
36	—	—

Connector No.	E129
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	BLACK

2	1
---	---



Terminal No.	Color of Wire	Signal Name
1	W	—
2	R	—

Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
58	—	—
59	B	GND (POWER)
60	GR	RR DEF
61	R/B	TRAIL RLY SUPPLY
62	—	—

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK

59	58	57
62	61	60



ABMIA1414GB

INFOID:000000005570649

Fail Safe

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Control part	Fail-safe in operation
Cooling fan	<ul style="list-style-type: none">• Turns ON the cooling fan relay when the ignition switch is turned ON• Turns OFF the cooling fan relay when the ignition switch is turned OFF

If No CAN Communication Is Available With BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none">• Turns ON the headlamp low relay when the ignition switch is turned ON• Turns OFF the headlamp low relay when the ignition switch is turned OFF• Headlamp (LH/RH) high relays OFF
<ul style="list-style-type: none">• Parking lamps• License plate lamps• Tail lamps	<ul style="list-style-type: none">• Turns ON the tail lamp relay when the ignition switch is turned ON• Turns OFF the tail lamp relay when the ignition switch is turned OFF
Front wiper	<ul style="list-style-type: none">• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C relay OFF
Front fog lamps (if equipped)	Front fog lamp relay OFF

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Ignition switch	Ignition relay	Tail lamp relay
ON	ON	—
OFF	OFF	—

NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 second activation and 20 second stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

NOTE:

This operation status can be confirmed on the IPDM E/R “DATA MONITOR” that displays “Block” for the item “WIP PROT” while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

DTC Index

INFOID:000000005570650

CONSULT-III display	Fail-safe	TIME ^{NOTE}		Refer to
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	1 – 39	PCS-17

NOTE:

The details of TIME display are as follows.

- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

EXTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000005268611

CAUTION:

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp does not switch to the high beam.	One side	<ul style="list-style-type: none"> Fuse Harness between IPDM E/R and the front combination lamp Front combination lamp (High beam relay) IPDM E/R 	Headlamp (HI) circuit Refer to EXL-37, "Description" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM" Refer to EXL-137, "Diagnosis Procedure" .	
High beam indicator lamp is not turned ON. (Headlamp switches to the high beam.)		<ul style="list-style-type: none"> Combination meter BCM 	<ul style="list-style-type: none"> Combination meter. Data monitor "HI-BEAM IND" BCM (HEAD LAMP) Active test "HEADLAMP"
Headlamp does not switch to the low beam.	One side	Front combination lamp (Low beam relay)	—
	Both sides	<ul style="list-style-type: none"> Combination switch (lighting and turn signal switch) Harness between the combination switch (lighting and turn signal switch) and BCM BCM 	Combination switch (lighting and turn signal switch) Refer to BCS-7 .
		High beam request signal <ul style="list-style-type: none"> BCM IPDM E/R 	IPDM E/R Data monitor "HL HI REQ"
		IPDM E/R	—
Headlamp does not turn ON.	One side	<ul style="list-style-type: none"> Fuse Bulb Harness between IPDM E/R and the front combination lamp Front combination lamp IPDM E/R 	Headlamp (LO) circuit Refer to EXL-39, "Description" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-138, "Diagnosis Procedure" .	
Headlamp does not turn OFF.	When the ignition switch is turned ON	<ul style="list-style-type: none"> BCM Combination switch (lighting and turn signal switch) 	Combination switch (lighting and turn signal switch) Refer to BCS-7 .
Daytime light system does not activate.		<ul style="list-style-type: none"> Either high beam bulb Parking brake switch Combination switch (lighting and turn signal switch) BCM IPDM E/R Daytime light relay Harness between IPDM E/R and daytime light relay. 	Daytime light system description. Refer to EXL-9, "System Description" .

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

Symptom		Possible cause	Inspection item
Off-road lamps are not turned ON.	One side	<ul style="list-style-type: none"> Off-road lamps bulb Harness between Off-road lamps relay and the Off-road lamp assembly 	Off-road lamps circuit Refer to EXL-45 .
	Both side	<ul style="list-style-type: none"> Off-road lamps switch Fuse Off-road lamps relay Off-road lamp cover sensor BCM Harness between fuse block (J/B) and the Off-road lamp assembly 	<ul style="list-style-type: none"> Off-road lamps switch circuit Refer to EXL-41. Off-road lamp cover sensor circuit Refer to EXL-43. Off-road lamps circuit Refer to EXL-45.
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> Front fog lamp bulb Harness between IPDM E/R and the front combination lamp Front combination lamp IPDM E/R 	Front fog lamp circuit Refer to EXL-48 .
	Both side	Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-140, "Diagnosis Procedure" .	
Parking lamp is not turned ON.	One side	<ul style="list-style-type: none"> Fuse Parking lamp bulb Harness between IPDM E/R and the front/rear combination lamp Front/rear combination lamp IPDM E/R 	Parking lamp circuit Refer to EXL-50 .
	Both sides	Symptom diagnosis "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-139, "Diagnosis Procedure" .	
Turn signal lamp does not blink.	Indicator lamp is normal. (The applicable side performs the high flasher activation).	<ul style="list-style-type: none"> Harness between BCM and each turn signal lamp Turn signal lamp bulb 	Turn signal lamp circuit Refer to EXL-55 .
Turn signal indicator lamp does not blink.	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> Turn signal indicator lamp signal Combination meter BCM 	<ul style="list-style-type: none"> Combination meter. Data monitor "TURN IND" BCM (FLASHER) Active test "FLASHER"
	Both sides (Does blink when activating the hazard warning lamp with the ignition switch OFF)	<ul style="list-style-type: none"> The combination meter power supply and the ground circuit Combination meter 	Combination meter Power supply and the ground circuit Refer to MWI-29 .

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

< SYMPTOM DIAGNOSIS >

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

Description

INFOID:000000005570651

The headlamps (both sides) do not switch to high beam when the combination switch (lighting and turn signal switch) is in the HI or PASS setting.

Diagnosis Procedure

INFOID:000000005570652

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-37. "Diagnosis Procedure"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

CONSULT-III DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R DATA MONITOR item.

2. With operating the combination switch (lighting and turn signal switch), check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Combination switch (lighting and turn signal switch) (2ND position)	HI or PASS	ON
		Except for HI or PASS	OFF

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).

3.HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-37. "Description"](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-33. "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:000000005570653

The headlamps (both sides) do not turn ON in any combination switch (lighting and turn signal switch) setting.

Diagnosis Procedure

INFOID:000000005570654

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-37, "Diagnosis Procedure"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

CONSULT-III DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R DATA MONITOR item.

2. With operating the combination switch (lighting and turn signal switch), check the monitor status.

Monitor item	Condition	Monitor status
HL LO REQ	Combination switch (lighting and turn signal switch)	2ND ON
		OFF OFF

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-56, "Removal and Installation"](#).

3.HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-39, "Description"](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-33, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:000000005570655

The parking, license plate and tail lamps do not turn ON in with any combination switch (lighting and turn signal switch) setting.

Diagnosis Procedure

INFOID:000000005570656

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-37. "Diagnosis Procedure"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

CONSULT-III DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R DATA MONITOR item.

2. With operating the combination switch (lighting and turn signal switch), check the monitor status.

Monitor item	Condition		Monitor status
TAIL & CLR REQ	Combination switch (lighting and turn signal switch)	1ST	ON
		OFF	OFF

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-56. "Removal and Installation"](#).

3.PARK LAMP CIRCUIT INSPECTION

Check the parking lamp circuit. Refer to [EXL-50. "Description"](#).

Is the tail lamp circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-33. "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

INFOID:000000005570657

The front fog lamps do not turn ON in any combination switch (lighting and turn signal switch) setting.

Diagnosis Procedure

INFOID:000000005570658

1.COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-37, "Diagnosis Procedure"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

CONSULT-III DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R DATA MONITOR item.

2. With operating the combination switch (lighting and turn signal switch), check the monitor status.

Monitor item	Condition	Monitor status
FR FOG REQ	Combination switch (lighting and turn signal switch) (2ND)	ON
		OFF

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-56, "Removal and Installation"](#).

3.FRONT FOG LAMP CIRCUIT INSPECTION

Check the front fog lamp circuit. Refer to [EXL-48, "Description"](#).

Is the front fog lamp circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-33, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005522907

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

ADJUSTMENT AND INSPECTION

< ON-VEHICLE REPAIR >


ON-VEHICLE REPAIR

ADJUSTMENT AND INSPECTION

HEADLAMP

HEADLAMP : Aiming Adjustment

INFOID:000000005268620



A. Headlamp RH adjustment screw

B. Headlamp LH adjustment screw

For details, refer to the regulations in your area.

NOTE:


If vehicle front body has been repaired and /or the headlamp assembly has been replaced, check headlamp aiming.

- Before performing aiming adjustment, check the following:
 - Ensure all tires are inflated to correct pressure.
 - Place vehicle and screen on level surface.
 - Ensure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant and engine oil filled to correct level, and fuel tank full.
 - Confirm spare tire, jack and tools are properly stowed.
 - Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.
 - Use adjusting screw to perform aiming adjustment

LOW BEAM AND HIGH BEAM

ADJUSTMENT AND INSPECTION

< ON-VEHICLE REPAIR >



- | | | |
|---|--|---|
| 1 Adjustment screen | 2 Headlamp bulb center (HV point) | A Minimum acceptable vertical aim dimension (see aiming chart) |
| B Maximum acceptable vertical aim dimension (see aiming chart) | C H-V point | D Distance of headlamp aiming screen from vehicle 7.62 m (25 ft.) |
| E Maximum aim evaluation distance from vertical center on aiming screen 399mm (3° R). | F Minimum aim evaluation distance from vertical center on aiming screen 133 mm (1°R) | G Aim evaluation area |
| H Horizontal aiming evaluation line. | ⇒ Right | |

Aiming Chart

A (Minimum acceptable vertical aim dimension)	-3.3 mm (0.13 in)	0.025° up
B (Maximum acceptable vertical aim dimension)	36.6 mm (1.44 in)	0.275° down

NOTE:

- By regulation, no means for horizontal aim adjustment is provided from the factory; only vertical aim is adjustable.
- Basic illuminating area for evaluation and/or adjustment should be within range shown on aiming chart.

- Use adjustment screw to perform aiming adjustment.
 - Cover the opposite lamp and ensure fog lamps, if equipped, are turned off.

CAUTION:

Do not tighten adjustment screw beyond specified torque or damage may occur.

Adjustment torque **1.67 N.m (17 kg-cm, 14.8 in-lb)**

- Adjust beam pattern until cut-off line (top edge of illumination area) is positioned at the specified height off ground. Measure cut-off line within distance J on H-line. See aiming chart.

FRONT FOG LAMP

FRONT FOG LAMP : Aiming Adjustment

INFOID:000000005268621

The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.


ADJUSTMENT AND INSPECTION

< ON-VEHICLE REPAIR >


- Place vehicle on level ground.
 - See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.
- Adjust aiming in the vertical direction by turning the adjustment screw.

NOTE:


Use a Phillips screwdriver to adjust. Turn screw clockwise to raise pattern and counterclockwise to lower pattern.



1. Set the distance between the screen and the center of the fog lamp lens as shown.



2. Turn front fog lamps ON.
 3. Remove front portion of fender protector(s) for adjustment screw access. Refer to [EXT-19, "Removal and Installation"](#)
 4. Adjust front fog lamps using adjustment screw so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.



HEADLAMP

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

HEADLAMP

Bulb Replacement

INFOID:0000000005268622

HEADLAMP BULB

Removal

NOTE:

Reach through engine room for bulb replacement access.

CAUTION:

Grasp only the plastic base when handling the bulb. Never touch the glass envelope.

1. Turn front headlamp switch OFF.
2. Disconnect the electrical connector.
3. Rotate the headlamp bulb retaining ring counterclockwise and remove.
4. Pull the headlamp bulb straight out from the headlamp assembly.

NOTE:

Remove the headlamp bulb from the headlamp assembly just before a replacement bulb is installed. Dust, moisture, foreign materials, etc. entering headlamp body may affect performance.

Installation

Installation is in the reverse order of removal.

FRONT TURN SIGNAL/PARKING LAMP

Removal

NOTE:

Reach through engine room for bulb replacement access.

1. Turn the bulb socket counterclockwise to unlock it.
2. Pull the bulb to remove it from the socket.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing the bulb, be sure to install the bulb socket securely for watertightness.

FRONT SIDE MARKER LAMP

Removal

NOTE:

Reach through engine room for bulb replacement access.

1. Turn the bulb socket counterclockwise to unlock it.
2. Pull the bulb to remove it from the socket.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing the bulb, be sure to install the bulb socket securely for watertightness.

Removal and Installation

INFOID:0000000005268623

FRONT COMBINATION LAMP

Removal


1. Remove front portion of front fender protector. Refer to [EXT-18, "Removal and Installation"](#).
2. Remove the front fascia assembly. Refer to [EXT-13, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP

< REMOVAL AND INSTALLATION >

3. Remove the front combination lamp bolts.



4. Disconnect the front combination lamp connector and remove front combination lamp.

Installation


Installation is in the reverse order of removal.

Front combination lamp bolts : 6.0 Nm (0.61 kg-m, 53 in-lb)

Disassembly and Assembly

INFOID:000000005268624

FRONT COMBINATION LAMP



- | | | |
|----------------------------|--------------------------------|--|
| 1. Headlamp assembly | 2. Headlamp bulb | 3. Headlamp bulb retaining ring |
| 4. Wiring harness assembly | 5. Front side marker lamp bulb | 6. Front turn signal/parking lamp bulb |

OPTICAL SENSOR

< REMOVAL AND INSTALLATION >


OPTICAL SENSOR

Removal and Installation

INFOID:000000005268625

REMOVAL

1. Remove the defroster grille from the instrument panel. Refer to [IP-10, "Exploded View"](#).
2. Disconnect the optical sensor connector (2).
3. Twist the optical sensor (1) counter clockwise to remove it from the defroster grille.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT FOG LAMP

< REMOVAL AND INSTALLATION >

FRONT FOG LAMP


Bulb Replacement

INFOID:000000005268626

1. Remove front portion of fender protector. Refer to [EXT-18. "Removal and Installation"](#)
2. Disconnect fog lamp connector.
3. Turn the bulb counterclockwise to remove it.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of fog lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of fog lamp. When replacing bulb, be sure to replace it with new one.



Removal and Installation

INFOID:000000005268627

FRONT FOG LAMP


The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb.

CAUTION:

- Do not leave fog lamp assembly without bulb for a long period of time. Dust, moisture, smoke, etc. entering the fog lamp body may affect the performance. Remove the bulb from the headlamp assembly just before replacement bulb is installed.
- Grasp only the plastic base when handling the bulb. Never touch the glass envelope. Touching the glass could significantly affect the bulb life and/or fog lamp performance.

Removal

1. Remove front portion of fender protector. Refer to [EXT-18. "Removal and Installation"](#)
2. Disconnect fog lamp connector.
3. Remove fog lamp screws and pull fog lamp rearward out of front bumper.



Installation

Installation is in the reverse order of removal.

LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >


LIGHTING & TURN SIGNAL SWITCH

Removal and Installation

INFOID:000000005268628

REMOVAL

1. Remove instrument lower cover LH. Refer to [IP-10, "Exploded View"](#).
2. Remove steering column cover.
3. Disconnect the lighting and turn signal switch connector.
4. While pressing tabs, pull lighting and turn signal switch toward driver door and release from the steering column.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HAZARD SWITCH

< REMOVAL AND INSTALLATION >

HAZARD SWITCH

Removal and Installation

INFOID:000000005268629

REMOVAL

1. Remove cluster lid C. Refer to [IP-10. "Exploded View"](#).
2. Disconnect the hazard switch connector.
3. Remove the screws and remove the hazard switch.

INSTALLATION

Installation is in the reverse order of removal.

HIGH-MOUNTED STOP LAMP

< REMOVAL AND INSTALLATION >

HIGH-MOUNTED STOP LAMP

High-Mounted Stop Lamp

INFOID:000000005268630


BULB REPLACEMENT

The high-mounted stop lamp bulbs are not serviceable.

REMOVAL AND INSTALLATION

Removal

1. Remove back door window garnish.
2. Disconnect high-mounted stop lamp connector.
3. Remove nuts and remove high-mounted stop lamp.



Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

LICENSE PLATE LAMP

< REMOVAL AND INSTALLATION >

LICENSE PLATE LAMP

Bulb Replacement

INFOID:000000005268631

LICENSE PLATE LAMP

Removal

1. Remove back door finisher. Refer to [INT-13. "Removal and Installation"](#).
2. Turn bulb socket counterclockwise and remove bulb socket.
3. Remove license plate lamp bulb.

Installation

Installation is in the reverse order of removal.

Removal and Installation

INFOID:000000005268632

LICENSE PLATE LAMP

Removal

1. Remove license lamp finisher.
2. Disconnect license plate lamp harness connector.
3. Remove license plate lamp screw and remove license plate lamp.

Installation

Installation is in the reverse order of removal.

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


REAR COMBINATION LAMP

Bulb Replacement

INFOID:000000005613046

REMOVAL

1. Remove rear combination lamp. Refer to [EXL-153. "Removal and Installation"](#).
2. Rotate each bulb socket (1, 2, 3) counterclockwise to unlock it.
3. Pull bulb straight out away from socket to release.



INSTALLATION


Installation is in the reverse order of removal.

Removal and Installation

INFOID:000000005613047

REMOVAL

1. Remove rear combination lamp bolts (1).
 - Rear combination lamp locator (3)
2. Pull the lamp assembly (2) rearward to remove from the vehicle.
3. Disconnect the connector and remove the rear combination lamp.



REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

INSTALLATION

Installation is in the reverse order of removal.


OFF-ROAD LAMPS

< REMOVAL AND INSTALLATION >

OFF-ROAD LAMPS

Removal and Installation

INFOID:000000005268635



OFF ROAD LAMPS

Removal

1. Remove the screws.
2. Remove the lamp cover.
3. Disconnect the electrical connector and remove the off road lamp assembly.

Installation

Installation is in the reverse order of removal.

Disassembly and Assembly


INFOID:000000005268636

Disassembly


OFF-ROAD LAMPS

< REMOVAL AND INSTALLATION >

1. Remove the off road lamp assembly. Refer to [EXL-155. "Removal and Installation"](#)
2. Disconnect the electrical connectors (A). Remove the screws (B) and remove the lamp assembly (1).



3. Remove the harness bracket.
4. Remove the screw (A). Unclip the electrical connector from the lamp assembly (B) and remove the lamp cover sensor (1).
5. Remove the off road lamp bulb.



Assembly

Assembly is in the reverse order of disassembly.

BULB SPECIFICATIONS

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

BULB SPECIFICATIONS

Headlamp

INFOID:0000000005268637

Item	Wattage (W)*
Low/High	55/65

*: Always check with the Parts Department for the latest parts information.

Exterior Lamp

INFOID:0000000005268638

Item		Wattage (W)*
Front combination lamp	Turn signal lamp/parking lamp	29/8
	Side marker	3.8
Rear combination lamp	Stop/Tail lamp	27/7
	Turn signal lamp	27
	Back-up lamp	18
Front fog lamp		55
License plate lamp		5
High-mounted stop lamp		*
Off road lights		*

*: Always check with the Parts Department for the latest parts information.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P