

SECTION AV

AUDIO, VISUAL & NAVIGATION SYSTEM

CONTENTS

BASE AUDIO		
BASIC INSPECTION	4	
DIAGNOSIS AND REPAIR WORKFLOW	4	
Work Flow	4	
SYSTEM DESCRIPTION	6	
AUDIO SYSTEM	6	
System Diagram	6	
System Description	6	
Component Parts Location	7	
Component Description	7	
DTC/CIRCUIT DIAGNOSIS	8	
POWER SUPPLY AND GROUND CIRCUIT	8	
AUDIO UNIT	8	
AUDIO UNIT : Diagnosis Procedure	8	
FRONT DOOR SPEAKER	9	
Description	9	
Diagnosis Procedure	9	
FRONT TWEETER	11	
Description	11	
Diagnosis Procedure	11	
REAR DOOR SPEAKER	13	
Description	13	
Diagnosis Procedure	13	
ECU DIAGNOSIS INFORMATION	15	
AUDIO UNIT	15	
Reference Value	15	
WIRING DIAGRAM	17	
BASE AUDIO SYSTEM	17	
Wiring Diagram	17	
SYMPTOM DIAGNOSIS	23	
AUDIO SYSTEM	23	
Symptom Table	23	
NORMAL OPERATING CONDITION	24	
Description	24	
PRECAUTION	25	
PRECAUTIONS	25	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	25	
Precaution for Procedure without Cowl Top Cover	25	
Precaution for Work	25	
PREPARATION	27	
PREPARATION	27	
Special Service Tool	27	
Commercial Service Tools	27	
REMOVAL AND INSTALLATION	28	
AUDIO UNIT	28	
Removal and Installation (Type 1)	28	
Removal and Installation (Type 2)	29	
FRONT TWEETER	30	
Removal and Installation	30	
FRONT DOOR SPEAKER	31	
Removal and Installation	31	
REAR DOOR SPEAKER	32	
Removal and Installation	32	
AUDIO ANTENNA	33	
Location of Audio Antenna System Component	33	
Removal and Installation	33	
PREMIUM AUDIO		

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BASIC INSPECTION	35	SUBWOOFER	62
		Description	62
DIAGNOSIS AND REPAIR WORKFLOW	35	Diagnosis Procedure	62
Work Flow	35	AMP ON SIGNAL CIRCUIT	65
SYSTEM DESCRIPTION	37	Description	65
AUDIO SYSTEM	37	Diagnosis Procedure	65
System Diagram	37	STEERING SWITCH	66
System Description	37	Description	66
Component Parts Location	38	Diagnosis Procedure	66
Component Description	39	COMMUNICATION SIGNAL CIRCUIT	68
HANDS-FREE PHONE SYSTEM	40	SATELLITE RADIO TUNER	68
System Diagram	40	SATELLITE RADIO TUNER : Description	68
System Description	40	SATELLITE RADIO TUNER : Diagnosis Proce- dure	68
Component Parts Location	41	SOUND SIGNAL CIRCUIT	71
Component Description	42	SATELLITE RADIO TUNER	71
DIAGNOSIS SYSTEM (AUDIO UNIT)	43	SATELLITE RADIO TUNER : Description	71
Component Function Check	43	SATELLITE RADIO TUNER : Diagnosis Proce- dure	71
DIAGNOSIS SYSTEM (BLUETOOTH CON- CONTROL UNIT)	44	MICROPHONE SIGNAL CIRCUIT	73
Diagnosis Description	44	Description	73
Work Flow	44	Diagnosis Procedure	73
DTC/CIRCUIT DIAGNOSIS	45	ECU DIAGNOSIS INFORMATION	75
POWER SUPPLY AND GROUND CIRCUIT	45	AUDIO UNIT	75
AUDIO UNIT	45	Reference Value	75
AUDIO UNIT : Diagnosis Procedure	45	SATELLITE RADIO TUNER	78
SATELLITE RADIO TUNER	45	Reference Value	78
SATELLITE RADIO TUNER : Diagnosis Proce- dure	45	AUDIO AMP	80
AUDIO AMP	46	Reference Value	80
AUDIO AMP : Diagnosis Procedure	46	BLUETOOTH CONTROL UNIT	83
BLUETOOTH CONTROL UNIT	47	Reference Value	83
BLUETOOTH CONTROL UNIT : Diagnosis Pro- cedure	47	WIRING DIAGRAM	85
MICROPHONE	48	PREMIUM AUDIO SYSTEM	85
MICROPHONE : Diagnosis Procedure	48	Wiring Diagram	85
FRONT DOOR SPEAKER	50	SYMPTOM DIAGNOSIS	99
Description	50	AUDIO SYSTEM	99
Diagnosis Procedure	50	Symptom Table	99
FRONT TWEETER	53	NORMAL OPERATING CONDITION	101
Description	53	Description	101
Diagnosis Procedure	53	PRECAUTION	102
REAR DOOR SPEAKER	56	PRECAUTIONS	102
Description	56	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	102
Diagnosis Procedure	56		
REAR DOOR TWEETER	59		
Description	59		
Diagnosis Procedure	59		

Precaution for Procedure without Cowl Top Cover	102	STEERING SWITCH	110	
Precaution for Work	102	Removal and Installation	110	A
PREPARATION	104	SUBWOOFER	111	
PREPARATION	104	Removal and Installation	111	B
Special Service Tool	104	BLUETOOTH CONTROL UNIT	112	
Commercial Service Tools	104	Removal and Installation	112	C
REMOVAL AND INSTALLATION	105	MICROPHONE	114	
AUDIO UNIT	105	Removal and Installation	114	D
Removal and Installation	105	AUDIO ANTENNA	115	
AUDIO AMP	106	Location of Antenna	115	E
Removal and Installation	106	Removal and Installation	115	F
FRONT TWEETER	107	AUXILIARY INPUT JACK	117	
Removal and Installation	107	Removal and Installation	117	G
FRONT DOOR SPEAKER	108	SATELLITE RADIO ANTENNA	118	
Removal and Installation	108	Removal and Installation	118	H
REAR DOOR SPEAKER	109	SATELLITE RADIO TUNER	119	
Removal and Installation - Rear Door Speaker	109	Removal and Installation	119	I
Removal and Installation - Rear Tweeter	109			J
				K
				L
				M
				AV
				O
				P


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006252973

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[BASE AUDIO]

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

4.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

5.FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Has the symptom been repaired?

YES >> Inspection End.

NO >> GO TO 2

A

B

C

D

E

F

G

H

I

J

K

L

M

AV


O

P

SYSTEM DESCRIPTION

AUDIO SYSTEM

System Diagram



System Description

INFOID:000000006252975

AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Rod antenna
- Front door speakers
- Front tweeters
- Rear door speakers

When the audio system is on, radio signals are received by the rod antenna. The audio unit then sends audio signals to the front door speakers, front tweeters and rear door speakers.

Refer to Owner's Manual for audio system operating instructions.


AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BASE AUDIO]

Component Parts Location

INFOID:000000006252976



- | | | |
|--|--|--------------------------|
| 1. Front tweeter LH M109 | 2. Audio unit M43 | 3. Front tweeter RH M111 |
| 4. Front door speaker
LH D12
RH D112 | 5. Rear door speaker
LH D207
RH D307 | |

Component Description

INFOID:000000006252977

Part name	Description
Audio unit	Controls audio system functions
Front door speakers	<ul style="list-style-type: none"> Outputs audio signal from audio unit Outputs high, mid and low range sounds
Front tweeters	<ul style="list-style-type: none"> Outputs audio signal from audio unit Outputs high range sounds
Rear door speakers	<ul style="list-style-type: none"> Outputs audio signal from audio unit Outputs high, mid and low range sounds

DTC/CIRCUIT DIAGNOSIS

**POWER SUPPLY AND GROUND CIRCUIT
AUDIO UNIT**

AUDIO UNIT : Diagnosis Procedure

INFOID:000000006252978

Regarding Wiring Diagram information, refer to [AV-17, "Wiring Diagram"](#).

1.CHECK FUSES

Check that the following fuses of the audio unit are not are not blown.

Unit	Terminals	Signal name	Fuse No.
Audio unit	19	Battery power	29
	7	Ignition switch ACC or ON	4

Are the fuses OK?


YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.POWER SUPPLY CIRCUIT CHECK

1. Disconnect audio unit connector M43.
2. Check voltage between the audio unit connector M43 ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M43	7	Ground	0V	Battery voltage	Battery voltage
	19	Ground	Battery voltage	Battery voltage	Battery voltage



Are the voltage results as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

3.GROUND CIRCUIT CHECK

Inspect audio unit case ground.

Does case ground pass inspection?

YES >> Inspection end.

NO >> Repair audio unit case ground.

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

FRONT DOOR SPEAKER

Description

INFOID:000000006252979

The audio unit sends audio signals to the front door speakers using the front door speaker circuits.

Diagnosis Procedure

INFOID:000000006252980

Regarding Wiring Diagram information, refer to [AV-17, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.HARNES CHECK

1. Disconnect audio unit connector M43 and suspect speaker connector.
2. Check continuity between audio unit harness connector M43 (A) terminal and suspect speaker harness connector (B) terminal.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M43	2	D12	1	Yes
	3		2	
	11	D112	1	
	12		2	

3. Check continuity between audio unit harness connector M43 (A) terminal and ground.


A		—	Continuity
Connector	Terminal		
M43	2	Ground	No
	3		
	11		
	12		

Are continuity results as specified?

YES >> GO TO 3.

- NO >>
- Check connector housings for disconnected or loose terminals.
 - Repair harness or connector.

3.FRONT SPEAKER SIGNAL CHECK




FRONT DOOR SPEAKER

[BASE AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector M43 and front speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT-III or oscilloscope.

Con- nector	(+)		(-)		Condition	Reference signal
	Terminal	Terminal	Terminal	Terminal		
M43	2	3	11	12	Receive audio signal	 <p style="text-align: center; font-size: small;">SKIA0177E</p>
	11	12				

Is the audio signal voltage as specified?

- YES >> Replace speaker. Refer to [AV-31, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-29, "Removal and Installation \(Type 2\)"](#).



FRONT TWEETER

Description

INFOID:000000006252981

The audio unit sends audio signals to the front tweeters using the front tweeter circuits.

Diagnosis Procedure

INFOID:000000006252982

Regarding Wiring Diagram information, refer to [AV-17, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.HARNES CHECK

1. Disconnect audio unit connector M43 and suspect front tweeter connector.
2. Check continuity between audio unit harness connector M43 (A) and suspect front tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M43	2	M109	1	Yes
	3		2	
	11	M111	1	
	12		2	

3. Check continuity between audio unit harness connector M43 (A) and ground.


A		—	Continuity
Connector	Terminal		
M43	2	Ground	No
	3		
	11		
	12		

Are the continuity results as specified?

YES >> GO TO 3.

- NO >>
- Check connector housings for disconnected or loose terminals.
 - Repair harness or connector.

3.FRONT TWEETER SIGNAL CHECK




FRONT TWEETER

[BASE AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector M43 and front tweeter connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT-III or oscilloscope.

Con- nector	(+) Terminal		(-) Terminal	Condition	Reference signal
	2	3	3		
M43	2	3		Receive audio signal	
	11	12			

Is the audio signal voltage as specified?

- YES >> Replace the suspect front tweeter. Refer to [AV-30, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-29, "Removal and Installation \(Type 2\)"](#).



AWNIA003222

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

REAR DOOR SPEAKER

Description

INFOID:000000006252983

The audio unit sends audio signals to the rear door speakers using the rear door speaker circuits.

Diagnosis Procedure

INFOID:000000006252984

Regarding Wiring Diagram information, refer to [AV-17, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.HARNES CHECK

1. Disconnect audio unit connector M43 and suspect rear door speaker connector.
2. Check continuity between audio unit harness connector M43 (A) and suspect rear door speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M43	4	D207	1	Yes
	5		2	
	13	D307	1	
	14		2	

3. Check continuity between audio unit harness connector M43 (A) and ground.


A		—	Continuity
Connector	Terminal		
M43	4	Ground	No
	5		
	13		
	14		

Are the continuity results as specified?

YES >> GO TO 3

- NO >>
- Check connector housings for disconnected or loose terminals.
 - Repair harness or connector.

3.REAR DOOR SPEAKER SIGNAL CHECK





REAR DOOR SPEAKER

[BASE AUDIO]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector and rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT-III or oscilloscope.

Connector	(+)	(-)	Condition	Reference signal
	Terminal	Terminal		
M43	4	5	Receive audio signal	
	13	14		



Is the audio signal voltage as specified?

- YES >> Replace the suspect rear door speaker. Refer to [AV-32. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-29. "Removal and Installation \(Type 2\)"](#).

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[BASE AUDIO]


ECU DIAGNOSIS INFORMATION

AUDIO UNIT

Reference Value

INFOID:000000006252985

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output			
2 (BR)	3 (L)	Sound signal front door speaker and front tweeter LH	Output	Ignition switch ON	Audio output	
4 (G)	5 (B)	Sound signal rear door speaker LH	Output	Ignition switch ON	Audio output	
7 (G/B)	Ground	ACC power supply	Input	Ignition switch ACC or ON	—	Battery voltage
8 (GR)	Ground	ILL control	Input	Ignition switch ACC or ON	—	0V
9 (R)	Ground	Light switch	Input	Ignition switch ACC or ON	—	Battery voltage

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[BASE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
11 (LG)	12 (R)	Sound signal front door speaker and front tweeter RH	Output	Ignition switch ON	Audio output	
13 (GR)	14 (O)	Sound signal rear door speaker RH	Output	Ignition switch ON	Audio output	
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage


WIRING DIAGRAM

BASE AUDIO SYSTEM

Wiring Diagram

INFOID:000000006706737

BASE AUDIO SYSTEM




AANWA0036GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

BASE AUDIO SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4P	G/B	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN





Terminal No.	Color of Wire	Signal Name
2	L	-
3	BR	-

Connector No.	M17
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
11	GR	-
12	O	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
77G	Y	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3J	G	-
8J	B	-

BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]


Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
11	LG	-

Terminal No.	Color of Wire	Signal Name
9	R	LIGHT SW
10	-	-
11	LG	FR SP RH (+)
12	R	FR SP RH (-)
13	GR	RR SP RH (+)
14	O	RR SP RH (-)
15	-	-
16	-	-
17	-	-
18	-	-
19	Y	BAT
20	-	-

Connector No.	M43
Connector Name	AUDIO UNIT (WITH BASE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	BR	FR SP LH (+)
3	L	FR SP LH (-)
4	G	RR SP LH (+)
5	B	RR SP LH (-)
6	-	-
7	G/B	ACC
8	GR	ILL CONT

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-(WITH BASE AUDIO SYSTEM)

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-(WITH BASE AUDIO SYSTEM)
2	L	-(WITH BASE AUDIO SYSTEM)

ABNIA2715GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]



Terminal No.	Color of Wire	Signal Name
3J	G	-
8J	B	-



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
5	G	-
12	B	-



Terminal No.	Color of Wire	Signal Name
77G	Y	-



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
2	L/R	-
3	L/W	-



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

Terminal No.	Color of Wire	Signal Name
11	GR	-
12	O	-



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

ABNIA0557GB

BASE AUDIO SYSTEM

< WIRING DIAGRAM >


[BASE AUDIO]

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	L/B	-
11	W/B	-

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	L	-
12	O	-

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
12	O	-

ABNIA2716GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

ABNIA2717GB

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

Symptom Table

INFOID:000000006252987

AUDIO SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> • Audio unit power circuit • Audio unit 	<ul style="list-style-type: none"> • AV-8 • AV-29
All speakers do not sound	<ul style="list-style-type: none"> • Speaker circuit shorted to ground • Audio unit power circuit • Audio unit 	<ul style="list-style-type: none"> • AV-17 • AV-8 • AV-29
One or several speakers do not sound	<ul style="list-style-type: none"> • Front door speaker • Front tweeter • Rear door speaker 	<ul style="list-style-type: none"> • AV-9 • AV-11 • AV-13
Poor reception	<ul style="list-style-type: none"> • Rod antenna is not fully connected to antenna base • Base antenna/rod connection (thread zone) has foreign material or corrosion inside. 	—
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

CD

Symptom	Possible cause	Reference page
CD cannot be inserted	Audio unit	AV-29
CD cannot be ejected		
The CD cannot be played		
The sound skips, stops suddenly, or is distorted		

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

NORMAL OPERATING CONDITION

Description

INFOID:000000006252988

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> • Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> • Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> • Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> • Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> • Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> • Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006252989

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000008202948

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for Work

INFOID:000000006837965

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

PRECAUTIONS

< PRECAUTION >

[BASE AUDIO]

-
- Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.
Then rub with a soft and dry cloth.
 - Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[BASE AUDIO]


PREPARATION

PREPARATION

Special Service Tool


INFOID:000000006837966

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
<p>— (J-46534) Trim tool set</p>  <p style="text-align: center;">AWJIA04832Z</p>	<p>For removing trim</p>

Commercial Service Tools

INFOID:000000006252990

Tool name	Description
<p>Power tool</p>  <p style="text-align: center;">PBIC0191E</p>	<p>Loosening bolts and nuts</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV

REMOVAL AND INSTALLATION


AUDIO UNIT

Removal and Installation (Type 1)


INFOID:000000006252992

REMOVAL


1. Remove the cluster lid C. Refer to [JP-14. "Removal and Installation"](#).
2. Remove the RH and LH ventilator grilles. Refer to [VTL-21. "Removal and Installation"](#).
3. Remove the audio unit assembly screws (A).



4. Remove the audio unit bracket screws (A).



5. Remove the audio unit RH/LH bracket screws (A), using power tool and remove the audio unit brackets.




AUDIO UNIT


< REMOVAL AND INSTALLATION >

[BASE AUDIO]

6. Remove the audio unit screws (A), using power tool.



7. Release the audio unit tab (A) and remove the audio unit (1).



INSTALLATION


Installation is in the reverse order of removal.

Removal and Installation (Type 2)

INFOID:000000006252991

REMOVAL

1. Remove the cluster lid C. Refer to [IP-14. "Removal and Installation"](#).
2. Remove the audio unit screws, using power tool.
3. Pull out the audio unit from the instrument panel and disconnect the audio unit connectors.



INSTALLATION

Installation is in the reverse order of removal.

FRONT TWEETER

< REMOVAL AND INSTALLATION >

[BASE AUDIO]

FRONT TWEETER

Removal and Installation


INFOID:000000006252993

REMOVAL

CAUTION:

Use a suitable tool to prevent damage to the front tweeter speaker grille trim and the instrument panel.

1. Remove the front tweeter grille, using a suitable tool.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter speaker (1) and disconnect front tweeter connector, then remove the front tweeter speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BASE AUDIO]


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000006252994

REMOVAL

1. Remove the front door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1), and disconnect the front door speaker connector and remove the front door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BASE AUDIO]


REAR DOOR SPEAKER

Removal and Installation

INFOID:000000006252995

REMOVAL

1. Remove the rear door finisher. Refer to [INT-14. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the rear door speaker connector (B) and remove rear door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[BASE AUDIO]

AUDIO ANTENNA

Location of Audio Antenna System Component

INFOID:000000006252996



1. Audio antenna

2. Antenna feeder


3. Audio unit

Removal and Installation

INFOID:000000006252997

REMOVAL

1. Remove instrument lower panel RH and lower glove box. Refer to [IP-19, "Removal and Installation"](#).
2. Remove audio unit. Refer to [AV-28, "Removal and Installation \(Type 1\)"](#) or [AV-29, "Removal and Installation \(Type 2\)"](#).
3. Disconnect audio antenna cable from antenna feeder.
4. Remove antenna rod.
5. Remove rubber seal.
6. Remove cowl top. Refer to [EXT-20, "Removal and Installation"](#).
7. Remove front fender protector. Refer to [EXT-22, "Removal and Installation"](#).
8. Remove antenna base bolts.
9. Remove antenna base and cable.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

AUDIO ANTENNA

< REMOVAL AND INSTALLATION >

[BASE AUDIO]

Always properly tighten the antenna rod during installation or the antenna rod may bend or break during vehicle operation.


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006252998

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[PREMIUM AUDIO]

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

4. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

5. FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?


YES >> Inspection End.

NO >> GO TO 2

SYSTEM DESCRIPTION

AUDIO SYSTEM

System Diagram



System Description

INFOID:000000006795023

AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Audio amplifier
- Rod antenna
- Steering wheel audio control switch
- Front door speakers
- Front tweeters
- Rear door speakers
- Rear tweeters
- Subwoofer

When the audio system is on, radio signals are received by the rod antenna. The audio unit then sends audio signals to the audio amplifier. The audio amplifier amplifies the audio signals before sending them to the front door speakers, front tweeters, rear door speakers, rear tweeters and the subwoofer.

Refer to Owner's Manual for audio system operating instructions.

SATELLITE RADIO SYSTEM

The satellite radio system consists of the following components

- Satellite antenna
- Satellite radio tuner

When the satellite radio system is on, radio signals are supplied to the satellite radio tuner from the satellite antenna. The satellite radio tuner then sends audio signals to the audio unit.

Refer to Owner's Manual for satellite radio system operating instructions.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUDIO SYSTEM

< SYSTEM DESCRIPTION >


[PREMIUM AUDIO]

SPEED SENSITIVE VOLUME SYSTEM

Volume level of this system goes up and down automatically in proportion to the vehicle speed. The control level can be selected by the customer. Refer to Owner's Manual for operating instructions.

Component Parts Location

INFOID:000000006253001



AWNIA2027ZZ

AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[PREMIUM AUDIO]

↩:FRONT

- | | | |
|--|--|--|
| 1. Front tweeter LH M109 | 2. Steering wheel audio control switch | 3. Satellite radio tuner M41, M129 |
| 4. Audio unit M42, M44, M45, M46 | 5. Front tweeter RH M111 | 6. Aux in jack M85 |
| 7. Front door speaker
LH D12
RH D112 | 8. Rear door tweeter
LH D208
RH D308 | 9. Rear door speaker
LH D207
RH D307 |
| 10. Audio amplifier B158, B159 (view under passenger front seat) | 11. Bluetooth control unit B141, B142 | 12. Subwoofer B72 (under driver's seat) |
| 13. Microphone R8 | | |

Component Description

INFOID:000000006795024


Part name	Description
Audio unit	Controls audio system and satellite radio system functions
Rod antenna	Audio signal (AM/FM) is received and output to Audio unit
Audio amplifier	Receives power (amp ON) and audio signals from Audio unit and outputs audio signals to each speaker
Steering wheel audio control switch	<ul style="list-style-type: none"> Start a voice recognition session Answer and end telephone calls Adjust the volume level
Front door speakers	<ul style="list-style-type: none"> Outputs audio signal from audio amplifier Outputs high, mid and low range sounds
Front tweeters	<ul style="list-style-type: none"> Outputs audio signal from audio amplifier Outputs high range sounds
Rear door speakers	<ul style="list-style-type: none"> Outputs audio signal from audio amplifier Outputs high, mid and low range sounds
Rear door tweeters	<ul style="list-style-type: none"> Outputs audio signal from audio amplifier Outputs high range sounds
Subwoofer	<ul style="list-style-type: none"> Outputs audio signal from audio amplifier Outputs low range sounds
Satellite radio tuner	<ul style="list-style-type: none"> Receives radio signals from satellite antenna Sends audio signals to audio unit
Satellite antenna	Audio signal (satellite radio) is received and output to audio unit

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

HANDS-FREE PHONE SYSTEM

System Diagram



System Description

INFOID:000000006253004

Refer to the Owner's Manual for Bluetooth telephone system operating instructions.

NOTE:

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth telephone system.

Bluetooth telephone system allows users who have a Bluetooth equipped cellular telephone to make a wireless connection between their cellular telephone and the Bluetooth control unit. Hands-free cellular telephone calls can be sent and received. Some Bluetooth cellular telephones may not be recognized by the Bluetooth control unit. When a cellular telephone or the Bluetooth control unit is replaced, the telephone must be paired with the Bluetooth control unit. Different cellular telephones may have different pairing procedures. Refer to the cellular telephone operating manual.

BLUETOOTH CONTROL UNIT

When the ignition switch is turned to ACC or ON, the Bluetooth control unit will power up. During power up, the Bluetooth control unit is initialized and performs various self checks. Initialization may take up to 10 seconds. If a phone is present in the vehicle and paired with the Bluetooth control unit, Nissan Voice Recognition will then become active. Bluetooth telephone functions can be turned off using the Nissan Voice Recognition system.

STEERING WHEEL AUDIO CONTROL SWITCH

When buttons on the steering wheel audio control switch are pushed, the resistance in steering wheel audio control switch circuit changes depending on which button is pushed. The Bluetooth control unit uses this signal to perform various functions while navigating through the voice recognition system.

The following functions can be performed using the steering wheel audio control switch:

- Initiate Self Diagnosis of the Bluetooth telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls

MICROPHONE

The microphone is located in the roof console assembly. The microphone sends a signal to the Bluetooth control unit. The microphone can be actively tested during self-diagnosis.

AUDIO UNIT

The audio unit receives signals from the Bluetooth control unit and sends audio signals to the audio amplifier then on to the speakers.


HANDS-FREE PHONE SYSTEM

< SYSTEM DESCRIPTION >

[PREMIUM AUDIO]

Component Parts Location

INFOID:000000006795028



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

←:FRONT

- | | | |
|--|--|--|
| 1. Front tweeter LH M109 | 2. Steering wheel audio control switch | 3. Satellite radio tuner M41, M129 |
| 4. Audio unit M42, M44, M45, M46 | 5. Front tweeter RH M111 | 6. Aux in jack M85 |
| 7. Front door speaker
LH D12
RH D112 | 8. Rear door tweeter
LH D208
RH D308 | 9. Rear door speaker
LH D207
RH D307 |

AWNIA2027ZZ

HANDS-FREE PHONE SYSTEM

< SYSTEM DESCRIPTION >

[PREMIUM AUDIO]

10. Audio amplifier B158, B159 (view under passenger front seat) 11. Bluetooth control unit B141, B142 12. Subwoofer B72 (under driver's seat)
13. Microphone R8

Component Description

INFOID:000000006795026

Part name	Description
Audio unit	<ul style="list-style-type: none">• Receives telephone voice signal from Bluetooth control unit• Sends telephone voice and voice guidance signals to the speakers
Audio amplifier	<ul style="list-style-type: none">• Receives audio signals from the audio unit• Outputs amplified audio signals to the speakers
Front door speakers	Receives telephone voice and voice guidance signals from the audio amplifier
Front tweeters	
Steering wheel audio control switch	<ul style="list-style-type: none">• Start a voice recognition session• Answer and end telephone calls• Adjust the volume level
Microphone	Sends voice signals to Bluetooth control unit
Bluetooth control unit	Controls hands-free phone functions
Bluetooth antenna	Sends telephone voice signal to Bluetooth control unit


DIAGNOSIS SYSTEM (AUDIO UNIT)

Component Function Check

INFOID:000000006795027

STARTING THE SELF-DIAGNOSIS MODE

1. Turn ignition switch from OFF to ACC.
2. Press and hold the "DISP/CLOCK" switch and turn the volume control dial clockwise or counterclockwise for 30 clicks or more.



Then the self-diagnosis operates. A single beep indicates self-diagnosis mode is active.

3. Initially, all display segments will be illuminated.
4. Press each switch. When each switch is pressed, its name and communication code will be displayed

NOTE:

CD player LOAD and EJECT buttons are not included in this test and will not change the display when pressed.

DIAGNOSIS FUNCTION

- It can check for continuity of the switches by sounding the beep when each audio unit switch and steering wheel audio control switch is pressed.
- It can check for continuity of harness between audio unit switch and steering wheel audio control switch.

EXITING THE SELF-DIAGNOSIS MODE

Turn ignition switch OFF. Then the self-diagnosis ends.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

DIAGNOSIS SYSTEM (BLUETOOTH CONTROL UNIT)

< SYSTEM DESCRIPTION >

[PREMIUM AUDIO]

DIAGNOSIS SYSTEM (BLUETOOTH CONTROL UNIT)

Diagnosis Description

INFOID:000000006253008


The Bluetooth control unit has two diagnostic checks. The first diagnostic check is performed automatically every ignition cycle during control unit initialization. The second diagnostic check is performed by the technician using the steering wheel audio control switch prior to trouble diagnosis.

BLUETOOTH CONTROL UNIT (AUTOMATIC INITIALIZATION) CHECK


- Internal control unit failure
- Bluetooth antenna connection open or shorted
- Steering wheel audio control switch[SEND(☞ ↻)/END(MODE)] stuck closed
- Vehicle speed pulse count
- Microphone connection test (with playback to operator)
- Bluetooth inquiry check

BLUETOOTH CONTROL UNIT (STEERING WHEEL AUDIO CONTROL SWITCH) CHECK

1. Turn ignition switch to ACC or ON.
2. Wait for the Bluetooth system to complete initialization. This may take up to 10 seconds.
3. Press and hold the steering wheel audio control switch ☞ ↻ button for at least 5 seconds. The Bluetooth system will begin to play a verbal prompt.



4. While the prompt is playing, press and hold the steering wheel audio control switch MODE button until you hear the “Diagnostics mode” prompt. The Bluetooth system will sound a 5 second beep.
5. While the beep is sounding, press and hold the steering wheel audio control switch MODE button again until you hear prompts.
6. The Bluetooth system has now entered into the diagnostic mode. Results of the diagnostic checks will be verbalized to the technician. Refer to [AV-44. "Work Flow"](#).
7. After the failure records are reported, an interactive microphone test will be performed. Follow the voice prompt. If the microphone test fails refer to [AV-44. "Work Flow"](#).
8. Self-diagnosis mode is complete when the voice prompt says “All diagnostic functions completed”.



Work Flow

INFOID:000000006253009

Failure Message	Action
“Internal failure”	Replace Bluetooth control unit. Refer to AV-112. "Removal and Installation" .
“Bluetooth antenna open”	1. Inspect harness connection.
“Bluetooth antenna shorted”	2. Replace Bluetooth antenna. Refer to AV-112. "Removal and Installation" .
“Phone/Send for Hands Free System is stuck”	Check steering wheel audio control switch. Refer to AV-66. "Description" .
“Phone/End for the Hands Free System is stuck”	
“Microphone test” (failed interactive test)	1. Inspect harness between Bluetooth control unit and microphone. 2. Replace microphone. Refer to AV-114. "Removal and Installation" .

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT
AUDIO UNIT

AUDIO UNIT : Diagnosis Procedure

INFOID:000000006253010

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1.CHECK FUSES

Check that the following fuses of the audio unit are not are not blown.

Unit	Terminals	Signal name	Fuse No.
Audio unit	6	Battery power	29
	10	Ignition switch ACC or ON	4

Are the fuses OK?


YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [GL-40, "Circuit Inspection"](#).

2.POWER SUPPLY CIRCUIT CHECK

1. Disconnect audio unit connector M46.
2. Check voltage between the audio unit connector M46 and ground.

(+) Connector		(-)	OFF	ACC	ON
Terminal					
M46	6	Ground	Battery voltage	Battery voltage	Battery voltage
	10	Ground	0V	Battery voltage	Battery voltage



Are the voltage results as specified?

YES >> GO TO 3

NO >> • Check connector housing for disconnected or loose terminals.
• Repair harness or connector.

3.GROUND CIRCUIT CHECK

Inspect audio unit case ground.

Does case ground pass inspection?

YES >> Inspection End.

NO >> Repair audio unit case ground.

SATELLITE RADIO TUNER

SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000006253011

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1.CHECK FUSES

Check that the following fuses of the satellite radio tuner are not blown.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

Unit	Terminals	Signal name	Fuse No.
Satellite radio tuner	32	Battery power	17
	36	Ignition switch ACC or ON	4

Are the fuses OK?


YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [GL-40, "Circuit Inspection"](#).

2. POWER SUPPLY CIRCUIT CHECK

- Turn ignition switch OFF.
- Disconnect satellite radio tuner connector M41.
- Check voltage between the satellite radio tuner and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M41	32	Ground	Battery voltage	Battery voltage	Battery voltage
	36		0V	Battery voltage	Battery voltage



Are the voltage readings as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

3. GROUND CIRCUIT CHECK

Inspect satellite radio tuner case ground.

Does case ground pass inspection?

YES >> Inspection End.

NO >> Repair satellite radio tuner case ground.

AUDIO AMP

AUDIO AMP : Diagnosis Procedure

INFOID:000000006253012

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1. CHECK FUSE

Check that the audio amplifier fuses are not blown.

Unit	Terminal	Signal name	Fuse No.
Audio amplifier	1	Battery power	17
	17		

Are the fuses OK?

YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [GL-40, "Circuit Inspection"](#).

2. CHECK POWER SUPPLY CIRCUIT


POWER SUPPLY AND GROUND CIRCUIT

[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect audio amplifier connector.
3. Check voltage between audio amplifier harness connector B158 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
B158	1	Ground	Battery voltage
	17		




Is battery voltage present?

- YES >> GO TO 3
 NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio amplifier connector.
3. Check continuity between audio amplifier harness connector B158 and ground.

(+)		(-)	Continuity
Connector	Terminal		
B158	4	Ground	Yes
	20		



Does continuity exist?

- YES >> Inspection End.
 NO >> Repair harness or connector.

BLUETOOTH CONTROL UNIT

BLUETOOTH CONTROL UNIT : Diagnosis Procedure

INFOID:000000006253013

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1.CHECK FUSE

Check that the following fuses for the Bluetooth control unit are not blown.

Unit	Terminal	Signal name	Fuse No.
Bluetooth control unit	1	Battery power	29
	2	Ignition switch ACC or ON	4
	3	Ignition switch ON or START	12

Is inspection result OK?

- YES >> GO TO 2.
 NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [GL-40, "Circuit Inspection"](#).

2.CHECK POWER SUPPLY CIRCUIT


POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

Check voltage between Bluetooth control unit harness connector B141 and ground.

(+)		(-)	OFF	ON	ACC
Connector	Terminal				
B141	1	Ground	Battery voltage	Battery voltage	Battery voltage
	2		0V	Battery voltage	Battery voltage
	3		0V	Battery voltage	0V




Is battery voltage present as specified?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit connector.
3. Check continuity between Bluetooth control unit harness connector B141 and ground.

Connector	Terminal	—	Continuity
B141	4	Ground	Yes
	21		
	24		



Are continuity results as specified?

- YES >> Inspection End.
- NO >> Repair harness or connector.

MICROPHONE

MICROPHONE : Diagnosis Procedure

INFOID:000000006253014

Regarding Wiring Diagram information, refer to [AV-85. "Wiring Diagram"](#).


1.CHECK POWER SUPPLY CIRCUIT (MICROPHONE SIDE)

1. Turn ignition switch ON.
2. Check voltage between microphone harness connector R8 terminal 4 and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
R8	4	Ground	5V

Is approximately 5V present?

- YES >> GO TO 3
- NO >> GO TO 2




2.CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

1. Turn ignition switch OFF.
2. Disconnect microphone and Bluetooth control unit harness connectors.
3. Check continuity between microphone harness connector R8 (A) terminal 4 and Bluetooth control unit harness connector B141 (B) terminal 29.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
R8	4	B141	29	Yes

4. Check continuity between microphone harness connector R8 (A) terminal 4 and ground.


A		—	Continuity
Connector	Terminal		
R8	4	Ground	No

Are the continuity test results as specified?

- YES >> Replace the Bluetooth control unit. Refer to [AV-112, "Removal and Installation"](#).
 NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect microphone harness connector R8 and Bluetooth control unit harness connector B141.
3. Check continuity between microphone harness connector R8 (A) terminal 2 and Bluetooth control unit harness connector B141 (B) terminal 8.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
R8	2	B141	8	Yes

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

FRONT DOOR SPEAKER

Description

INFOID:000000006253015

The audio unit sends audio signals to the audio amplifier. The audio amplifier amplifies the audio signals before sending them to the front door speakers using the audio signal circuits.

Diagnosis Procedure

INFOID:000000006253016

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit, audio amplifier and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.SPEAKER HARNESS CHECK

1. Disconnect audio amplifier connector B159 and suspect speaker connector.
2. Check continuity between audio amplifier harness connector B159 (A) and suspect speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B159	15	D12	1	Yes
	31		2	
	16	D112	1	
	32		2	

3. Check continuity between audio amplifier harness connector B159 (A) and ground.


A		—	Continuity
Connector	Terminal		
B159	15	Ground	No
	31		
	16		
	32		

Are continuity test results as specified?

YES >> GO TO 3.

- NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

3.FRONT DOOR SPEAKER SIGNAL CHECK



ALNIA0718GB


FRONT DOOR SPEAKER

[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio amplifier connector B159 and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio amplifier harness connector B159 terminals with CONSULT-III or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
B159	15	31	Receive audio signal	
	16	32		



Is audio signal voltage as specified?

YES >> Replace suspect speaker. Refer to [AV-108. "Removal and Installation"](#).

NO >> GO TO 4.

4. AUDIO UNIT TO AUDIO AMPLIFIER HARNESS CHECK

1. Disconnect audio unit connector M46 and audio amplifier connector B159.
2. Check continuity between audio unit harness connector M46 (A) and audio amplifier harness connector B159 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M46	1	B159	6	Yes
	2		22	
	3		5	
	4		21	

3. Check continuity between audio unit harness connector M46 (A) and ground.


A		—	Continuity
Connector	Terminal		
M46	1	Ground	No
	2		
	3		
	4		

Are continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

5. AUDIO AMPLIFIER SIGNAL CHECK




FRONT DOOR SPEAKER

[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >


1. Connect audio unit connector and audio amplifier connector.
2. Turn ignition switch ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M46 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M46	2	1	Receive audio signal	
	4	3		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace audio amplifier. Refer to [AV-106. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-105. "Removal and Installation"](#).



AWNIA18032Z

FRONT TWEETER

Description

INFOID:000000006253017

The audio unit sends audio signals to the audio amplifier. The audio amplifier amplifies the audio signals before sending them to the tweeters using the audio signal circuits.

Diagnosis Procedure

INFOID:000000006253018

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit, audio amplifier and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.


2.HARNES CHECK

1. Disconnect audio amplifier connector B159 and suspect tweeter connector.
2. Check continuity between audio amplifier harness connector B159 (A) and suspect tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B159	14	M109	1	Yes
	30		2	
	13	M111	1	
	29		2	

3. Check continuity between audio amplifier harness connector B159 (A) and ground.

A		—	Continuity
Connector	Terminal		
B159	14	Ground	No
	30		
	13		
	29		



Are continuity test results as specified?

YES >> GO TO 3.

- NO >>
- Check connector housings for disconnected or loose terminals.
 - Repair harness or connector.

3.FRONT TWEETER SIGNAL CHECK


FRONT TWEETER

[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio amplifier connector B159 and suspect tweeter connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio amplifier harness connector B159 terminals with CONSULT-III or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
B159	14	30	Receive audio signal	
	13	29		



Is audio signal voltage as specified?

YES >> Replace suspect tweeter. Refer to [AV-107. "Removal and Installation"](#).

NO >> GO TO 4.


4. AUDIO UNIT AND AUDIO AMPLIFIER HARNESS CHECK

1. Disconnect audio unit connector M46 and audio amplifier connector B159.
2. Check continuity between audio unit harness connector M46 (A) and audio amplifier harness connector B159 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M46	1	B159	6	Yes
	2		22	
	3		5	
	4		21	

3. Check continuity between audio unit harness connector M46 (A) and ground.

A		—	Continuity
Connector	Terminal		
M46	1	Ground	No
	2		
	3		
	4		



Are continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

5. AUDIO AMPLIFIER SIGNAL CHECK

FRONT TWEETER

[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >


1. Connect audio unit connector and audio amplifier connector.
2. Turn ignition switch ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M46 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M46	2	1	Receive audio signal	
	4	3		

Are the audio signal voltage readings as specified?

YES >> Replace audio amplifier. Refer to [AV-106, "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-105, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

REAR DOOR SPEAKER

Description

INFOID:000000006253019

The audio unit sends audio signals to the audio amplifier. The audio amplifier amplifies the audio signals before sending them to the rear door speakers using the audio signal circuits.

Diagnosis Procedure

INFOID:000000006253020

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1. CONNECTOR CHECK

Check the audio unit, audio amplifier and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.


2. SPEAKER HARNESS CHECK

1. Disconnect audio amplifier connectors B159 and suspect speaker connector.
2. Check continuity between audio amplifier harness connectors B159 (A) and suspect speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B159	11	D207	1	Yes
	27		2	
	12	D307	1	
	28		2	

3. Check continuity between audio amplifier harness connectors B159 (A) and ground.

Connector	Terminal	-	Continuity
B159	11	Ground	No
	27		
	12		
	28		



ALNIA0726GB

Are the continuity test results as specified?

YES >> GO TO 3.

- NO >>
- Check connector housings for disconnected or loose terminals.
 - Repair harness or connector.

3. SPEAKER SIGNAL CHECK

REAR DOOR SPEAKER

[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio amplifier connectors and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio amplifier harness connectors B159 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B159	11	27	Receive audio signal	
	12	28		

Are audio signal voltage readings as specified?

YES >> Replace suspect speaker. Refer to [AV-109. "Removal and Installation - Rear Door Speaker"](#).

NO >> GO TO 4.

4. AUDIO UNIT AND AUDIO AMPLIFIER HARNESS CHECK

1. Disconnect audio unit connector M44 and audio amplifier connector B159.
2. Check continuity between audio unit harness connector M44 (A) and audio amplifier harness connector B159 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M44	13	B159	8	Yes
	14		24	
	15		7	
	16		23	

3. Check continuity between audio unit harness connector M44 (A) and ground.



A		—	Continuity
Connector	Terminal		
M44	13	Ground	No
	14		
	15		
	16		

Are the continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

5. AUDIO AMPLIFIER SIGNAL CHECK




REAR DOOR SPEAKER

[PREMIUM AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector M44 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M44 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M44	14	13	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	16	15		

Is the audio signal voltage reading as specified?

- YES >> Replace audio amplifier. Refer to [AV-106. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-105. "Removal and Installation"](#).



REAR DOOR TWEETER

Description

INFOID:000000006253021

The audio unit sends audio signals to the audio amplifier. The audio amplifier amplifies the audio signals before sending them to the rear door tweeters using the audio signal circuits.

Diagnosis Procedure

INFOID:000000006253022

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1. CONNECTOR CHECK

Check the audio unit, audio amplifier and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.


2. SPEAKER HARNESS CHECK

1. Disconnect audio amplifier connectors B159 and suspect speaker connector.
2. Check continuity between audio amplifier harness connectors B159 (A) and suspect speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B159	11	D208	1	Yes
	27		2	
	12	D308	1	
	28		2	

3. Check continuity between audio amplifier harness connectors B159 (A) and ground.

Connector	Terminal	-	Continuity
B159	11	Ground	No
	27		
	12		
	28		



Are the continuity test results as specified?

YES >> GO TO 3.

- NO >>
- Check connector housings for disconnected or loose terminals.
 - Repair harness or connector.

3. SPEAKER SIGNAL CHECK

REAR DOOR TWEETER


[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio amplifier connectors and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio amplifier harness connectors B159 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B159	11	27	Receive audio signal	
	12	28		

SKIA0177E



Are audio signal voltage readings as specified?

YES >> Replace suspect speaker. Refer to [AV-109, "Removal and Installation - Rear Tweeter"](#).

NO >> GO TO 4.


4. AUDIO UNIT AND AUDIO AMPLIFIER HARNESS CHECK

1. Disconnect audio unit connector M44 and audio amplifier connector B159.
2. Check continuity between audio unit harness connector M44 (A) and audio amplifier harness connector B159 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M44	13	B159	8	Yes
	14		24	
	15		7	
	16		23	

3. Check continuity between audio unit harness connector M44 (A) and ground.

A		—	Continuity
Connector	Terminal		
M44	13	Ground	No
	14		
	15		
	16		



Are the continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.


5. AUDIO AMPLIFIER SIGNAL CHECK

REAR DOOR TWEETER

[PREMIUM AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector M44 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M44 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M44	14	13	Receive audio signal	 <p>SKIA0177E</p>
	16	15		

Is the audio signal voltage reading as specified?

- YES >> Replace audio amplifier. Refer to [AV-106. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-105. "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

SUBWOOFER

Description

INFOID:000000006253023

The audio unit sends audio signals to the audio amplifier. The audio amplifier amplifies the audio signals before sending them to the subwoofer using the audio signal circuits.

Diagnosis Procedure

INFOID:000000006253024

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit, audio amplifier and subwoofer connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?


YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.SPEAKER HARNESS CHECK

1. Disconnect audio amplifier connector B158 and subwoofer connector B72.
2. Check continuity between audio amplifier harness connector B158 (A) and subwoofer harness connector B72 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B158	2	B72	1	Yes
	3		3	
	18		2	
	19		4	



3. Check continuity between audio amplifier harness connector B158 (A) and ground.

A		—	Continuity
Connector	Terminal		
B158	2	Ground	No
	3		
	18		
	19		

Are the continuity test results as specified?

YES >> GO TO 3.

- NO >> • Check connector housings for disconnected or loose terminals.
 • Repair harness or connector.

3.SPEAKER SIGNAL CHECK

SUBWOOFER

[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >


1. Connect audio amplifier connector B158 and subwoofer connector B72.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio amplifier harness connector B158 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B158	2	18	Receive audio signal	
	3	19		

Is the audio signal voltage as specified?

YES >> Replace subwoofer. Refer to [AV-111. "Removal and Installation"](#).

NO >> GO TO 4.



4. AUDIO UNIT AND AUDIO AMPLIFIER HARNESS CHECK

1. Disconnect audio unit connector M44 and audio amplifier connector B159.
2. Check continuity between audio unit harness connector M44 (A) and audio amplifier harness connector B159 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M44	13	B159	8	Yes
	14		24	
	15		7	
	16		23	

3. Check continuity between audio unit harness connector M44 (A) and ground.


A		—	Continuity
Connector	Terminal		
M44	13	Ground	No
	14		
	15		
	16		

Are the continuity test results as specified?

YES >> GO TO 5.

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

5. AUDIO AMPLIFIER SIGNAL CHECK




SUBWOOFER

[PREMIUM AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector M44 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M44 terminals with CONSULT-III or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M44	14	13	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	16	15		

Is the audio signal voltage reading as specified?

- YES >> Replace audio amplifier. Refer to [AV-106. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-105. "Removal and Installation"](#).



AMP ON SIGNAL CIRCUIT

Description

INFOID:000000006253025

When the audio system is turned on, a voltage signal is supplied from the audio unit to the audio amplifier. When this signal is received, the audio amplifier will turn on.

Diagnosis Procedure

INFOID:000000006253026

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).


1. CHECK AMP ON SIGNAL

1. Turn audio system ON.
2. Check voltage between audio amplifier harness connector B159 terminal 9 and ground.

9 - Ground : More than 6.5V

Is battery voltage present?

- YES >> Inspection End.
NO >> GO TO 2




2. CHECK AMP ON SIGNAL (AUDIO UNIT)

Check voltage between audio unit harness connector M44 terminal 12 and ground.

12 - Ground : More than 6.5V

Is battery voltage present?

- YES >> Repair harness or connector.
NO >> Replace audio unit. Refer to [AV-105, "Removal and Installation"](#).



STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

STEERING SWITCH

Description

INFOID:000000006253027

When one of the steering wheel audio control switch buttons are pushed, the resistance in the steering wheel audio control switch circuit changes depending on which button is pushed.


Diagnosis Procedure


INFOID:000000006253028

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Turn ignition switch OFF.
2. Disconnect steering wheel audio control switch connector M102.
3. Check resistance between steering switch connector terminals.

Terminal	Signal name	Condition	Resistance (Ω) (Approx.)
16 17	Seek (down)	Depress ▽ button	165
	Volume (down)	Depress VOL down button	652
	Mode/end	Depress MODE button	0
20 17	Seek (up)	Depress △ button	165
	Volume (up)	Depress VOL up button	652
	Phone/send	Depress  button	0



Do the steering wheel audio control switch buttons check OK?


YES >> GO TO 2

NO >> Replace steering wheel audio control switch. Refer to [AV-110, "Removal and Installation"](#).

2. CHECK HARNESS BETWEEN SPIRAL CABLE AND BLUETOOTH CONTROL UNIT

1. Disconnect Bluetooth control unit harness connector B141 and spiral cable harness connector M30.
2. Check continuity between Bluetooth control unit harness connector B141 (A) and spiral cable harness connector M30 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B141	12	M30	24	Yes
	13		32	
	14		31	



3. Check continuity between Bluetooth control unit connector B141 (A) and ground.

A		—	Continuity
Connector	Terminal		
B141	12	Ground	No
	13		
	14		

Are the continuity results as specified?

STEERING SWITCH

[PREMIUM AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3
 NO >> Repair harness.

3. SPIRAL CABLE CHECK

1. Disconnect spiral cable connector M102.
2. Check continuity between spiral cable harness connector M30 (A) and M102 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	20	Yes
	31		17	
	32		16	



Does the spiral cable check OK?

- YES >> GO TO 4
 NO >> Replace spiral cable. Refer to [SR-6. "Removal and Installation"](#).

4. CHECK HARNESS BETWEEN BLUETOOTH CONTROL UNIT AND AUDIO UNIT

1. Disconnect audio unit connector M45.
2. Check continuity between Bluetooth control unit harness connector B141 and audio unit harness connector M45.

Connector	Terminal	Connector	Terminal	Continuity
B141	17	M45	69	Yes
	18		70	
	19		71	

3. Check continuity between Bluetooth control unit connector B141 and ground.

Connector	Terminal	—	Continuity
B141	17	Ground	No
	18		
	19		

Are the continuity results as specified?

- YES >> GO TO 5.
 NO >> Repair harness.

5. CHECK AUDIO UNIT VOLTAGE

1. Connect audio unit harness connector M45 and Bluetooth control unit harness connector B141.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector M45 terminals.

(+)		(-)		Voltage (Approx.)
Audio unit		Audio unit		
Connector	Terminal	Connector	Terminal	
M45	69	M45	71	5V
	70			

Are the continuity results as specified?

- YES >> Replace Bluetooth control unit. Refer to [AV-112. "Removal and Installation"](#).
 NO >> Replace audio unit. Refer to [AV-105. "Removal and Installation"](#).

COMMUNICATION SIGNAL CIRCUIT SATELLITE RADIO TUNER

SATELLITE RADIO TUNER : Description

INFOID:000000006253029

Communication signals are exchanged between the audio unit and satellite radio tuner using the communication circuits.

SATELLITE RADIO TUNER : Diagnosis Procedure


INFOID:000000006253030

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1. CHECK HARNESS - REQ1

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner connector M41 and audio unit connector M42.
3. Check continuity between satellite radio tuner harness connector M41 (A) terminal 28 and audio unit harness connector M42 (B) terminal 48.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	28	M42	48	Yes



4. Check continuity between satellite radio tuner harness connector M41 (A) terminal 28 and ground.

A		—	Continuity
Connector	Terminal		
M41	28	Ground	No


Are continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.

2. CHECK HARNESS - TXD

1. Check continuity between satellite radio tuner harness connector M41 (A) terminal 29 and audio unit harness connector M42 (B) terminal 49.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	29	M42	49	Yes



2. Check continuity between satellite radio tuner harness connector M41 (A) terminal 29 and ground.

A		—	Continuity
Connector	Terminal		
M41	29	Ground	No

Are continuity results as specified?

- YES >> GO TO 3
 NO >> Repair harness or connector.

COMMUNICATION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

3. CHECK HARNESS - RXD

1. Check continuity between satellite radio tuner harness connector M41 (A) terminal 30 and audio unit harness connector M42 (B) terminal 50.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	30	M42	50	Yes

2. Check continuity between satellite radio tuner harness connector M41 (A) terminal 30 and ground.

A		—	Continuity
Connector	Terminal		
M41	30	Ground	No


Are continuity results as specified?

YES >> GO TO 4

NO >> Repair harness or connector.

4. CHECK REQ1 SIGNAL

1. Connect satellite radio tuner connector and audio unit connector.
2. Turn ignition switch to ACC
3. Check signal between satellite radio tuner harness connector M41 terminal 28 and ground with CONSULT-III or oscilloscope.

(+)		(-)	Reference signal
Connector	Terminal		
M41	28	Ground	 <p>SKIB3825E</p>


Are voltage readings as specified?

YES >> GO TO 5




NO >> Replace audio unit. Refer to [AV-105. "Removal and Installation"](#).

5. CHECK TXD SIGNAL

Check signal between satellite radio tuner harness connector M41 terminal 29 and ground with CONSULT-III or oscilloscope.

(+)		(-)	Reference signal
Connector	Terminal		
M41	29	Ground	 <p>SKIB3824E</p>

Are the voltage readings as specified?



COMMUNICATION SIGNAL CIRCUIT

[PREMIUM AUDIO]


< DTC/CIRCUIT DIAGNOSIS >


YES >> GO TO 6

NO >> Replace satellite radio tuner. Refer to [AV-119, "Removal and Installation"](#).

6. CHECK RXD SIGNAL

Check signal between satellite radio tuner harness connector M41 terminal 30 and ground with CONSULT-III or oscilloscope.

(+) Connector		Terminal	(-)	Reference signal
Terminal				
M41	30	Ground	 SKIB3826E	



Are the voltage readings as specified?

YES >> Replace satellite radio tuner. Refer to [AV-119, "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-105, "Removal and Installation"](#).

SOUND SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

SOUND SIGNAL CIRCUIT SATELLITE RADIO TUNER

SATELLITE RADIO TUNER : Description

INFOID:000000006253031

Left and right channel audio signals are supplied from the satellite radio tuner to the audio unit through the sound signal circuits.

SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000006253032


Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

LEFT CHANNEL

1. CHECK HARNESS

- Turn ignition switch OFF.
- Disconnect satellite radio tuner connector M41 and audio unit connector M42.
- Check continuity between satellite radio tuner connector M41 (A) and audio unit connector M42 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	21	M42	41	Yes
	22		42	



- Check continuity between satellite radio tuner connector M41 (A) and ground.

A		—	Continuity
Connector	Terminal		
M41	21	Ground	No
	22		

Are continuity results as specified?


YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK LEFT CHANNEL AUDIO SIGNAL

- Connect satellite radio tuner and audio unit.
- Turn ignition switch ON.
- Check signal between satellite radio tuner connector M41 terminals 21 and 22 with CONSULT-III or oscilloscope.

(+) Terminal		(-) Terminal	Reference signal
Connector	Terminal	Terminal	
M41	22	21	<p>SKIB3609E</p>



Are voltage readings as specified?

YES >> Replace audio unit. Refer to [AV-105, "Removal and Installation"](#).

SOUND SIGNAL CIRCUIT

[PREMIUM AUDIO]

< DTC/CIRCUIT DIAGNOSIS >


NO >> Replace satellite radio tuner. Refer to [AV-119, "Removal and Installation"](#).

RIGHT CHANNEL

1. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner connector M41 and audio unit connector M42.
3. Check continuity between satellite radio tuner M41 (A) and audio unit M42 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	23	M42	43	Yes
	24		44	



4. Check continuity between satellite radio tuner connector M41 (A) and ground.

A		—	Continuity
Connector	Terminal		
M41	23	Ground	No
	24		

Are continuity results as specified?


YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RIGHT CHANNEL AUDIO SIGNAL

1. Connect satellite radio tuner and audio unit.
2. Turn ignition switch ON.
3. Check signal between satellite radio tuner connector M41 terminals 23 and 24 with CONSULT-III or oscilloscope.

(+) Terminal		(-) Terminal	Reference signal
Connector	Terminal	Terminal	
M41	24	23	



Are voltage readings as specified?

YES >> Replace audio unit. Refer to [AV-105, "Removal and Installation"](#).

NO >> Replace satellite radio tuner. Refer to [AV-119, "Removal and Installation"](#).

MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

MICROPHONE SIGNAL CIRCUIT

Description

INFOID:000000006253033

Voice signals are transmitted from the microphone to the Bluetooth control unit using the microphone signal circuits.


Diagnosis Procedure

INFOID:000000006253034

Regarding Wiring Diagram information, refer to [AV-85, "Wiring Diagram"](#).

1. CHECK HARNESS BETWEEN BLUETOOTH CONTROL UNIT AND MICROPHONE

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit connector B141 and microphone connector R8.
3. Check continuity between Bluetooth control unit harness connector B141 (A) and microphone harness connector R8 (B).



A		B		Continuity
Connector	Terminal	Connector	Terminal	
B141	7	R8	1	Yes
	8		2	
	29		4	

4. Check continuity between Bluetooth control unit harness connector B141 (A) and ground.

A		—	Continuity
Connector	Terminal		
B141	7	Ground	No
	8		
	29		

Are the continuity test results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.


2. CHECK MICROPHONE POWER SUPPLY

1. Connect Bluetooth control unit connector B141 and microphone connector R8.
2. Turn ignition switch ON.
3. Check voltage between microphone harness connector R8 terminal 4 and ground.

4 - Ground : Approx. 5V

Is voltage reading approx. 5 volts?

- YES >> GO TO 3
 NO >> Replace Bluetooth control unit. Refer to [AV-112, "Removal and Installation"](#).




3. CHECK MICROPHONE SIGNAL


MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[PREMIUM AUDIO]

Check signal between Bluetooth control unit harness connector B141 terminals 7 and 8 with CONSULT-III or and oscilloscope.

Connector	(+)	(-)	Reference signal
	Terminal	Terminal	
B141	7	8	<p>While speaking into MIC</p>  <p style="text-align: right;">PKIB5037J</p>



Are voltage readings as specified?

- YES >> Replace Bluetooth control unit. Refer to [AV-112. "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-114. "Removal and Installation"](#).

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[PREMIUM AUDIO]


ECU DIAGNOSIS INFORMATION

AUDIO UNIT



Reference Value

INFOID:000000006253035

TERMINAL LAYOUT








PHYSICAL VALUES

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
2 (W)	1 (B)	Audio sound signal front LH	Output	Ignition switch ON	Receive audio sig- nal	 SKIA0177E
4 (Y)	3 (BR)	Audio sound signal front RH	Output	Ignition switch ON	Receive audio sig- nal	 SKIA0177E
6 (Y)	Ground	Battery power	Input	-	-	Battery voltage
7 (GR)	Ground	Illumination control signal	Input	Ignition switch ON	Illumination control switch is operated by lighting switch in 1st position.	Changes between 0 and 12V
8 (R)	Ground	Illumination signal	Input	OFF	Lighting switch is in 1st position.	Battery voltage
					Lighting switch is OFF.	0V
10 (G/B)	Ground	ACC signal	Input	Ignition switch ON	-	Battery voltage
12 (G/W)	Ground	Amp ON signal	Output	Ignition switch ON	-	Battery voltage

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >




[PREMIUM AUDIO]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
14 (BR)	13 (B/R)	Audio sound signal rear LH	Output	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
16 (L)	15 (B/W)	Audio sound signal rear RH	Output	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
42 (R)	41 (G)	Satellite radio au- dio signal LH	Input	Ignition switch ON	Satellite radio tuner operating	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
44 (B)	43 (W)	Satellite radio au- dio signal RH	Input	Ignition switch ON	Satellite radio tuner operating	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
48 (O)	-	REQ (SAT→ audio unit)	Input	Ignition switch ON	-	-
49 (P)	-	RX (SAT→ audio unit)	Input	Ignition switch ON	-	-
50 (L)	-	TX (audio unit→ SAT)	Input	Ignition switch ON	-	-
62 (W)	61 (B)	Telephone signal input	Input	Ignition switch ACC/ON	Bluetooth control unit sends audio signal	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
63 (R)	-	Mute control	-	-	-	-
67	-	Shield	-	Ignition switch ON	-	0V

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[PREMIUM AUDIO]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
69 (V)	71 (O)	Steering switch signal A	Input	Ignition switch ON	Pressing button	0V
					Pressing button	0.75
					Pressing VOL up button	2V
					Except for above	5V
70 (LG)	71 (O)	Steering switch signal B	Input	Ignition switch ON	Pressing switch	0V
					Pressing button	0.75V
					Pressing VOL down button	2V
					Except for above	5 V
73 (SB)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is approx. 25 MPH (40 km/h)	 <p style="text-align: right; font-size: small;">PKIA1935E</p>
74 (W)	Ground	Auxiliary audio input RH (+)	Input	Ignition switch ON	Receive audio signal (AUX input)	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
75 (B)	Ground	Auxiliary audio input LH (+)	Input	Ignition switch ON	Receive audio signal (AUX input)	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
76 (B)	-	Shield	-	-	-	0V

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

SATELLITE RADIO TUNER


< ECU DIAGNOSIS INFORMATION >

[PREMIUM AUDIO]

SATELLITE RADIO TUNER

Reference Value

INFOID:000000006253037



ANNIA17782Z

PHYSICAL VALUES

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output			
22 (R)	21 (G)	Satellite radio sound signal LH	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIB3609E</p>
24 (B)	23 (W)	Satellite radio sound signal RH	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIB3609E</p>
28 (O)	Ground	Request signal (SAT→CONT)	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIA9299J</p>
29 (P)	Ground	Communication signal (SAT→CONT)	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIA9300J</p>

SATELLITE RADIO TUNER

< ECU DIAGNOSIS INFORMATION >

[PREMIUM AUDIO]

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output			
30 (L)	Ground	Communication signal (CONT→SAT)	Input	Ignition switch ON	When satellite radio mode is selected	
32 (R/B)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
36 (G/B)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
37	—	Satellite antenna	Input	—	—	—

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

AUDIO AMP

< ECU DIAGNOSIS INFORMATION >


[PREMIUM AUDIO]

AUDIO AMP




Reference Value

INFOID:000000006253038

TERMINAL LAYOUT









PHYSICAL VALUES

Terminal (wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
1 (Y)	Ground	Battery	Input	-	-	Battery voltage
2 (W)	18 (G)	Subwoofer	Output	Ignition switch ON	Receive audio sig- nal	 <small>SKIA0177E</small>
3 (O)	19 (BR)	Subwoofer	Output	Ignition switch ON	Receive audio sig- nal	 <small>SKIA0177E</small>
4 (B)	Ground	Ground	-	Ignition switch ON	-	-
9 (G/W)	Ground	Amp. ON signal	Input	Ignition switch ON	-	More than 6.5V
11 (G)	27 (B)	Rear door speak- er LH and rear door tweeter LH	Output	Ignition switch ON	Receive audio sig- nal	 <small>SKIA0177E</small>

AUDIO AMP

< ECU DIAGNOSIS INFORMATION >

[PREMIUM AUDIO]




Terminal (wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
12 (GR)	28 (O)	Rear door speak- er RH and rear door tweeter RH	Output	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
13 (W)	29 (P)	Front door tweet- er RH	Output	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
14 (Y)	30 (GR)	Front tweeter LH	Output	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
15 (BR)	31 (L)	Front door speak- er LH	Output	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
16 (LG)	32 (R)	Front door speak- er RH	Output	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
17 (R/B)	Ground	Battery	Input	-	-	Battery voltage
20 (B)	Ground	Ground	-	Ignition switch ON	-	-
21 (Y)	5 (BR)	Audio sound sig- nal front RH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AUDIO AMP

< ECU DIAGNOSIS INFORMATION >

[PREMIUM AUDIO]

Terminal (wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-					
22 (W)	6 (B)	Audio sound sig- nal front LH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
23 (L)	7 (B/W)	Audio sound sig- nal rear RH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
24 (BR)	8 (B/R)	Audio sound sig- nal rear LH	Input	Ignition switch ON	Receive audio sig- nal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>

BLUETOOTH CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[PREMIUM AUDIO]

BLUETOOTH CONTROL UNIT

Reference Value

INFOID:000000006253039

TERMINAL LAYOUT







PHYSICAL VALUES

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/output			
1 (R/B)	Ground	Battery power	Input	-	-	Battery voltage
2 (G/Y)	Ground	ACC power	Input	Ignition switch ACC/ON	-	Battery voltage
3 (W/G)	Ground	IGN power	Input	Ignition switch ON/ START	-	Battery voltage
4 (B)	Ground	Ground	-	Ignition switch ON	-	0V
6	-	Shield	-	-	-	-
7 (G)	8 (L)	MIC in signal	Input	-	-	-
9 (W)	10 (B)	Audio out	Output	Ignition switch ACC/ON	Bluetooth control unit sends audio signal	<p>SKIB3609E</p>
11 (R)	-	Mute control	-	-	-	-
12 (BR)	14 (G)	Steering switch signal A	Input	Ignition switch ON	Pressing	0V
					Pressing	0.75
					Pressing VOL up button	2V
					Except for above	5V

BLUETOOTH CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[PREMIUM AUDIO]


Terminal (wire color)		Description		Condition	Reference value (Approx.)	
+	-	Signal name	Input/ output			
13 (L)	14 (G)	Steering switch signal B	Input	Ignition switch ON	Pressing MODE button 	0V
					Pressing ▽ button	0.75V
					Pressing VOL down button	2V
					Except for above	5 V
17 (V)	19 (O)	Steering switch signal A	Output	Ignition switch ON	Pressing  button	0V
					Pressing △ button	0.75
					Pressing VOL up button	2V
					Except for above	5V
18 (LG)	19 (O)	Steering switch signal B	Output	Ignition switch ON	Pressing MODE button 	0V
					Pressing ▽ button	0.75V
					Pressing VOL down button	2V
					Except for above	5V
21 (B)	Ground	Ground	-	-	-	0V
24 (B)	Ground	Ground	-	-	-	0V
28 (SB)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is approx. 25 MPH (40 km/h)	 <p style="text-align: right; font-size: small;">PKIA1935E</p>
29 (Y)	Ground	Microphone power	Output	Ignition switch ON	-	5V

WIRING DIAGRAM

PREMIUM AUDIO SYSTEM

Wiring Diagram

INFOID:000000006706738



ABNWA1441GB


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >


[PREMIUM AUDIO]



ABNWA1058GB


PREMIUM AUDIO SYSTEM CONNECTORS

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	-
3	BR	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	W/G	-
4P	G/B	-
16P	R/B	-

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
13	SHIELD	-
14	G	-
15	L	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
77G	Y	-

Connector No.	M30
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24	BR	STRG SW A (UP)
31	G	STRG SW GND
32	L	STRG SW B (DOWN)

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	SB	SPEED OUT 8

ABNIA2718GB


PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >

[PREMIUM AUDIO]



Terminal No.	Color of Wire	Signal Name
39M	SHIELD	-
40M	L	-
41M	Y	-
42M	W	-
43M	O	-
44M	LG	-
45M	L	-
46M	G	-
47M	SB	-
50M	G	-
51M	B/W	-
52M	L	-
54M	B/R	-
55M	BR	-
57M	BR	-
58M	Y	-
60M	B	-
61M	W	-
63M	G/W	-
72M	R	-
73M	BR	-
74M	W	-
76M	R/B	-
77M	LG	-
78M	O	-
79M	G	-



ABNIA2719GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >


[PREMIUM AUDIO]

Connector No.	M44
Connector Name	AUDIO UNIT (WITH PREMIUM AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	-	-
12	G/W	AMP ON/OFF SIG
13	B/R	RRSP LH (-)
14	BR	RRSP LH (+)
15	B/W	RRSP RH (-)
16	L	RRSP RH (+)

Connector No.	M42
Connector Name	AUDIO UNIT (WITH PREMIUM AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	G	L (-)
42	R	L (+)
43	W	R (-)
44	B	R (+)
45	-	-
46	-	-
47	-	-
48	O	REQ
49	P	RX
50	L	TX
51	-	-
52	-	-

Connector No.	M41
Connector Name	SATELLITE RADIO TUNER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	G	SAT LCH (-)
22	R	SAT LCH (+)
23	W	SAT RCH (-)
24	B	SAT RCH (+)
25	-	-
26	-	-
27	-	-
28	O	REQ1
29	P	TXD
30	L	RXD
31	-	-
32	R/B	BACKUP
33	-	-
34	-	-
35	-	-
36	G/B	ACC


ABNIA3607GB

PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >

[PREMIUM AUDIO]


Connector No.	M46
Connector Name	AUDIO UNIT (WITH PREMIUM AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	FRSP LH (-)
2	W	FRSP LH (+)
3	BR	FRSP RH (-)
4	Y	FRSP RH (+)
5	-	-
6	Y	BAT (BACK UP)
7	GR	ILL CONT
8	R	LIGHT SW
9	-	-
10	G/B	ACC


Terminal No.	Color of Wire	Signal Name
66	-	-
67	SHIELD	SHIELD
68	-	-
69	V	REMOTE_A_SWC
70	LG	REMOTE_B_SWC
71	O	REMOTE_GND_SWC
72	-	-
73	SB	SPEED SIGNAL
74	W	AUX_R+
75	B	AUX_L+
76	R	AUX_GND

Connector No.	M45
Connector Name	AUDIO UNIT (WITH PREMIUM AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
61	B	TEL_SIG_INPUT (-)
62	W	TEL_SIG_INPUT (+)
63	R	TEL_SIG_ON_TRIG
64	-	-
65	-	-

Connector No.	M85
Connector Name	AUX IN JACK
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	R+
2	R	COMMON
4	B	L+

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
11	LG	-

Connector No.	M68
Connector Name	WIRE TO WIRE
Connector Color	VIOLET



Terminal No.	Color of Wire	Signal Name
1	-	-

ABNIA3608GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >

[PREMIUM AUDIO]

Connector No.	M102
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
16	L	-
17	BR	-
20	W	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	Y	-(WITH PREMIUM AUDIO SYSTEM)
2	GR	-(WITH PREMIUM AUDIO SYSTEM)

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	P	-(WITH PREMIUM AUDIO SYSTEM)

Connector No.	M129
Connector Name	SATELLITE RADIO TUNER
Connector Color	VIOLET



Terminal No.	Color of Wire	Signal Name
37	-	-

Connector No.	M250
Connector Name	WIRE TO WIRE
Connector Color	VIOLET



Terminal No.	Color of Wire	Signal Name
1	-	-

Connector No.	M251
Connector Name	SATELLITE ANTENNA
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	-	-


ABNIA3609GB

PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >

[PREMIUM AUDIO]


Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	G	-
12	B	-

Terminal No.	Color of Wire	Signal Name
77G	Y	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B72
Connector Name	SUBWOOFER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	REAR LEFT (+)
2	G	REAR LEFT (-)
3	O	REAR RIGHT (+)
4	BR	REAR RIGHT (-)

Terminal No.	Color of Wire	Signal Name
1J	O	-
2J	BR	-
3J	G	-
6J	G	-
7J	W	-
8J	B	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABN1A2723GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >

[PREMIUM AUDIO]

Terminal No.	Color of Wire	Signal Name
12	BR	LAD IN1
13	L	LAD IN2
14	G	LAD IN GND
15	-	-
16	-	-
17	V	LAD OUT1
18	LG	LAD OUT2
19	O	LAD OUT GND
20	-	-
21	B	CONT 2
22	-	-
23	-	-
24	B	CONT 5
25	-	-
26	-	-
27	-	-
28	SB	SPEED SIGNAL
29	Y	MIC PWR
30	-	-
31	-	-
32	-	-

Connector No.	B141
Connector Name	BLUETOOTH CONTROL UNIT
Connector Color	WHITE



2	4	6	8	10	12	14	16	18	20	22	24	26	28	30	32
1	3	5	7	9	11	13	15	17	19	21	23	25	27	29	31

Terminal No.	Color of Wire	Signal Name
1	R/B	BATT
2	G/Y	ACC
3	W/G	IGN
4	B	GND
5	-	-
6	SHIELD	MIC_SHIELD
7	G	MIC_IN+
8	L	MIC_IN-
9	W	AUDIO_OUT+
10	B	AUDIO_OUT-
11	R	MUTE_CONTROL

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5		
6	7	8	9	10	11	12



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Connector No.	B142
Connector Name	BLUETOOTH CONTROL UNIT
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
33	B	BT ANTENNA
34	SHIELD	BT ANTENNA SHIELD

ABNIA2724GB


PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >

[PREMIUM AUDIO]

Terminal No.	Color of Wire	Signal Name
52M	L	-
54M	B/R	-
55M	BR	-
57M	BR	-
58M	Y	-
60M	B	-
61M	W	-
63M	G/W	-
72M	R	-
73M	BR	-
74M	W	-
76M	R/B	-
77M	LG	-
78M	O	-
79M	G	-

Terminal No.	Color of Wire	Signal Name
8M	B	-
9M	G	-
10M	G/Y	-
31M	B	-
33M	R	-
34M	V	-
35M	BR	-
37M	W/G	-
39M	SHIELD	-
40M	L	-
41M	Y	-
42M	W	-
43M	O	-
44M	LG	-
45M	L	-
46M	G	-
47M	SB	-
50M	G	-
51M	B/W	-



Terminal No.	Color of Wire	Signal Name
1M	GR	-
2M	Y	-
3M	P	-
4M	W	-
5M	R/B	-
6M	L	-
7M	BR	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

ABNIA2725GB


PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >

[PREMIUM AUDIO]

Terminal No.	Color of Wire	Signal Name
13	W	FR TW (+)
14	Y	FR TW (+)
15	BR	FRSP LH OUT (+)
16	LG	FRSP RH OUT (+)
21	Y	FRSP RH (+) IN
22	W	FRSP LH (+) IN
23	L	RRSP RH (+) IN
24	BR	RRSP LH (+) IN
25	-	-
26	-	-
27	B	RRSP LH OUT (-)
28	O	RRSP RH OUT (-)
29	P	FR TW (-)
30	GR	FR TW (-)
31	L	FRSP LH OUT (-)
32	R	FRSP RH OUT (-)

Connector No.	B159
Connector Name	AUDIO AMPLIFIER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	BR	FRSP RH (-) IN
6	B	FRSP LH (-) IN
7	B/W	RRSP RH (-) IN
8	B/R	RRSP LH (-) IN
9	G/W	AMP ON/OFF SIGNAL
10	-	-
11	G	RRSP LH OUT (+)
12	GR	RRSP RH OUT (+)

Connector No.	B158
Connector Name	AUDIO AMPLIFIER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	BAT
2	W	WOOFER(+1)
3	O	WOOFER(+2)
4	B	GND
17	R/B	BAT
18	G	WOOFER(-1)
19	BR	WOOFER(-2)
20	B	GND


Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	R8
Connector Name	MICROPHONE
Connector Color	WHITE



Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L/R	-
3	L/W	-

Terminal No.	Color of Wire	Signal Name
1	G	MIC OUT +
2	L	MIC OUT -
4	Y	MIC POWER

Terminal No.	Color of Wire	Signal Name
1	Y	-
13	SHIELD	-
14	G	-
15	L	-

ABNIA2726GB

PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >


[PREMIUM AUDIO]

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	L/B	-
11	W/B	-

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D208
Connector Name	REAR TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
12	O	-

ABNIA2727GB

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

PREMIUM AUDIO SYSTEM

< WIRING DIAGRAM >

[PREMIUM AUDIO]

Connector No.	D308
Connector Name	REAR TWEETER RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
12	O	-

ABNIA2728GB

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[PREMIUM AUDIO]

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

Symptom Table

INFOID:000000006253040

AUDIO SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> Audio unit power circuit Audio unit 	<ul style="list-style-type: none"> AV-45 AV-105
Steering wheel audio control switch does not operate	<ul style="list-style-type: none"> Steering wheel audio control switch Audio unit 	<ul style="list-style-type: none"> AV-110 AV-105
All speakers do not sound	<ul style="list-style-type: none"> Speaker circuit shorted to ground Audio unit power circuit Audio amplifier ON signal Audio amplifier power/ground circuit Audio amplifier Audio unit 	<ul style="list-style-type: none"> AV-85 AV-45 AV-65 AV-46 AV-106 AV-105
One or several speakers do not sound	<ul style="list-style-type: none"> Front door speaker Front tweeter Rear door speaker Rear door tweeter Subwoofer 	<ul style="list-style-type: none"> AV-50 AV-53 AV-56 AV-59 AV-62
Poor reception	<ul style="list-style-type: none"> Rod antenna is not fully connected to antenna base Base antenna/rod connection (thread zone) has foreign material or corrosion inside. 	—
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

CD

Symptom	Possible cause	Reference page
CD cannot be inserted	Audio unit	AV-105
CD cannot be ejected		
The CD cannot be played		
The sound skips, stops suddenly, or is distorted		

SATELLITE RADIO

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> Satellite radio tuner power or ground circuit Satellite radio tuner communication circuit Satellite radio tuner 	<ul style="list-style-type: none"> AV-45 AV-68 AV-119
Right or left channel does not sound	<ul style="list-style-type: none"> Satellite radio tuner right channel audio signal circuit Satellite radio tuner left channel audio signal circuit Satellite radio tuner 	<ul style="list-style-type: none"> AV-71

HANDS-FREE PHONE

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[PREMIUM AUDIO]

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none">• Bluetooth control unit power circuit• Bluetooth control unit	<ul style="list-style-type: none">• AV-47• AV-44
Steering wheel audio switch does not operate	<ul style="list-style-type: none">• Steering wheel audio control switch• Bluetooth control unit	<ul style="list-style-type: none">• AV-66• AV-44
Voice activated control does not activate	<ul style="list-style-type: none">• Microphone• Steering wheel audio control switch• Bluetooth control unit	<ul style="list-style-type: none">• AV-48• AV-66• AV-44

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[PREMIUM AUDIO]

NORMAL OPERATING CONDITION

Description

INFOID:000000006253041

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	• Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		• Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	• Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	• Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		• Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		• Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006253042

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000008202950

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for Work

INFOID:000000006837974

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.

PRECAUTIONS

< PRECAUTION >

[PREMIUM AUDIO]

- Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.
Then rub with a soft and dry cloth.
- Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

PREPARATION

< PREPARATION >

[PREMIUM AUDIO]


PREPARATION

PREPARATION

Special Service Tool


INFOID:000000006837975

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
<p>— (J-46534) Trim tool set</p>  <p>AWJIA04832Z</p>	<p>For removing trim</p>

Commercial Service Tools

INFOID:000000006253043

Tool name	Description
<p>Power tool</p>  <p>PBIC0191E</p>	<p>Loosening bolts and nuts</p>

REMOVAL AND INSTALLATION


AUDIO UNIT

Removal and Installation


INFOID:000000006253044

REMOVAL

1. Remove the cluster lid C. Refer to [IP-14. "Removal and Installation"](#).
2. Remove the RH and LH ventilator grilles. Refer to [VTL-21. "Removal and Installation"](#).
3. Remove the audio unit assembly screws (A), then remove the audio unit assembly, from cluster lid C.



4. Remove the audio unit screws (A), using power tool.
5. Remove the audio unit brackets (2), then pull out the audio unit (3) from the audio control panel (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AUDIO AMP


Removal and Installation

INFOID:000000006253045

REMOVAL

CAUTION:**Do not remove the RH front seat from the vehicle.**

1. Remove the RH front seat bolts, disconnect the RH front seat electrical connectors. Refer to [SE-17](#), "[Removal and Installation](#)".
2. Tilt the RH front seat back to access the audio amp (1), remove the audio amp kick shield screws (C).
 - ⇐: Vehicle front
3. Disconnect the audio amp connectors (A) and remove the audio amp (1) from the bracket (2).
4. Remove the audio amp bracket screws (B) and remove audio amp bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

FRONT TWEETER

< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]

FRONT TWEETER

Removal and Installation


INFOID:000000006253046

REMOVAL

CAUTION:

Use a suitable tool to prevent damage to the front tweeter speaker grille trim and the instrument panel.

1. Remove the front tweeter grille, using a suitable tool.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter speaker (1) and disconnect front tweeter connector, then remove the front tweeter speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000006253047

REMOVAL

1. Remove the front door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1), and disconnect the front door speaker connector and remove the front door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]


REAR DOOR SPEAKER

Removal and Installation - Rear Door Speaker

INFOID:000000006253048

REMOVAL

1. Remove the rear door finisher. Refer to [INT-14. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the rear door speaker connector (B) and remove rear door speaker (1).



INSTALLATION


Installation is in the reverse order of removal.

Removal and Installation - Rear Tweeter

INFOID:000000006253049

REMOVAL

1. Remove rear door finisher. Refer to [INT-14. "Removal and Installation"](#).
2. Remove the rear tweeter screws (A) and remove the rear tweeter (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

STEERING SWITCH


< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]

STEERING SWITCH

Removal and Installation

INFOID:000000006253050



1. Steering wheel


2. Steering wheel audio control switches


REMOVAL

1. Remove the driver air bag module. Refer to [SR-4, "Removal and Installation"](#).
2. Remove the steering wheel audio control switch assembly screws.
3. Disconnect the steering wheel audio control switches connector.
4. Remove the steering wheel audio control switches by pulling on steering wheel audio control switches to release the pawls.

CAUTION:

Do not tilt steering wheel audio control switches during removal or damage may occur to the pawls.

- :Pawl



INSTALLATION

Installation is in the reverse order of removal.

SUBWOOFER


< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]

SUBWOOFER

Removal and Installation

INFOID:000000006253051



1. Subwoofer connector

← Vehicle front

REMOVAL

1. Remove the LH front seat. Refer to [SE-17, "Removal and Installation"](#).
2. Remove subwoofer bolts.
3. Disconnect the subwoofer connector and remove the subwoofer.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

BLUETOOTH CONTROL UNIT


< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]

BLUETOOTH CONTROL UNIT

Removal and Installation

INFOID:00000006253053




1. Bluetooth control unit front bracket 2. Bluetooth control unit/antenna 3. Bluetooth control unit rear bracket

← Vehicle front

REMOVAL

1. Remove the RH front seat bolts, disconnect the RH front seat electrical connectors. Refer to [SE-17, "Removal and Installation"](#).
2. Disconnect the Bluetooth control unit harness connector (B).
3. Remove the Bluetooth control unit screws (A), then remove the Bluetooth control unit assembly (1).
4. Remove the Bluetooth control unit bracket screws and remove the Bluetooth control unit front and rear brackets.



BLUETOOTH CONTROL UNIT

< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]

INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P


MICROPHONE

Removal and Installation

INFOID:000000006253054

REMOVAL

1. Remove the front room/map lamp. Refer to [INT-21. "Removal and Installation"](#).
2. Detach the Bluetooth microphone (1) from the front room/map lamp tabs (A).
3. Detach the Bluetooth microphone connector (B) and remove the Bluetooth microphone (1).



INSTALLATION

Installation is in the reverse order of removal.

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]

AUDIO ANTENNA

Location of Antenna

INFOID:000000006253055




- | | | |
|-------------------------------|--------------------------------|-----------------------------|
| 1. Audio antenna | 2. Antenna feeder | 3. Audio unit |
| 4. Satellite radio tuner M129 | 5. Harness connector M250, M68 | 6. Satellite antenna feeder |
| 7. Harness connector M251 | 8. Satellite antenna | |

Removal and Installation

INFOID:000000006253056

REMOVAL

1. Remove instrument lower panel RH and lower glove box. Refer to [IP-19, "Removal and Installation"](#).
2. Remove audio unit. Refer to [AV-105, "Removal and Installation"](#).
3. Disconnect audio antenna cable from antenna feeder.
4. Remove antenna rod.
5. Remove rubber seal.
6. Remove cowl top. Refer to [EXT-20, "Removal and Installation"](#).
7. Remove front fender protector. Refer to [EXT-22, "Removal and Installation"](#).
8. Remove antenna base bolts.
9. Remove antenna base and cable.



AUDIO ANTENNA

< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Always properly tighten the antenna rod during installation or the antenna rod may bend or break during vehicle operation.

AUXILIARY INPUT JACK

< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]

AUXILIARY INPUT JACK

Removal and Installation

INFOID:000000006253057

Removal

1. Remove the lower instrument panel RH and lower glove box. Refer to [IP-19. "Removal and Installation"](#).
2. Remove the auxiliary input jack.

Installation

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

SATELLITE RADIO ANTENNA

< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]


SATELLITE RADIO ANTENNA

Removal and Installation

INFOID:000000006253058

REMOVAL

1. Remove the front cover. Refer to [EXT-26, "Removal and Installation"](#).
2. Remove the front room/map lamp assembly. Refer to [INL-58, "Removal and Installation"](#).
3. Disconnect the satellite radio antenna connector.
4. Remove the satellite radio antenna nut.
5. Remove the satellite radio antenna.



LKIA0679E

INSTALLATION

Installation is in the reverse order of removal.

SATELLITE RADIO TUNER

< REMOVAL AND INSTALLATION >

[PREMIUM AUDIO]


SATELLITE RADIO TUNER

Removal and Installation

INFOID:000000006253059

REMOVAL

1. Disconnect the battery negative terminal.
2. Disconnect the satellite radio tuner connectors.
3. Remove the satellite radio tuner screws (A), and remove satellite radio tuner.
4. Remove satellite radio tuner bracket screws and remove the satellite radio tuner brackets.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV