

SECTION EXL

EXTERIOR LIGHTING SYSTEM

CONTENTS

XENON TYPE

PRECAUTION	4
PRECAUTIONS	4
FOR USA AND CANADA	4
FOR USA AND CANADA : Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4
FOR USA AND CANADA : Precautions For Xenon Headlamp Service	4
FOR USA AND CANADA : Precaution for Battery Service	5
FOR USA AND CANADA : Precautions for Removing Battery Terminal	5
FOR MEXICO	5
FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5
FOR MEXICO : Precautions For Xenon Headlamp Service	5
FOR MEXICO : Precaution for Battery Service	6
FOR MEXICO : Precautions for Removing Battery Terminal	6
SYSTEM DESCRIPTION	7
COMPONENT PARTS	7
HEADLAMP SYSTEM	7
HEADLAMP SYSTEM : Component Parts Location	7
HEADLAMP SYSTEM : Component Description.....	7
AUTO LIGHT SYSTEM	7
AUTO LIGHT SYSTEM : Component Parts Location	8
AUTO LIGHT SYSTEM : Component Description....	8
DAYTIME RUNNING LIGHT SYSTEM	8

DAYTIME RUNNING LIGHT SYSTEM : Component Parts Location	8
DAYTIME RUNNING LIGHT SYSTEM : Component Description	10
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM	10
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : Component Parts Location	10
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : Component Description	10
PARKING, LICENSE PLATE AND TAIL LAMPS	11
PARKING, LICENSE PLATE AND TAIL LAMPS : Component Parts Location	11
PARKING, LICENSE PLATE AND TAIL LAMPS : Component Description	11
REAR FOG LAMP SYSTEM	11
REAR FOG LAMP SYSTEM : Component Parts Location	12
REAR FOG LAMP SYSTEM : Component Description	12
EXTERIOR LAMP BATTERY SAVER SYSTEM	12
EXTERIOR LAMP BATTERY SAVER SYSTEM : Component Parts Location	13
EXTERIOR LAMP BATTERY SAVER SYSTEM : Component Description	13
SYSTEM	14
HEADLAMP SYSTEM	14
HEADLAMP SYSTEM : System Diagram	14
HEADLAMP SYSTEM : System Description	14
AUTO LIGHT SYSTEM	15
AUTO LIGHT SYSTEM : System Diagram	15
AUTO LIGHT SYSTEM : System Description	15
DAYTIME RUNNING LIGHT SYSTEM	16
DAYTIME RUNNING LIGHT SYSTEM : System Diagram	16

DAYTIME RUNNING LIGHT SYSTEM : System Description	16
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM	17
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram	17
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description	17
PARKING, LICENSE PLATE AND TAIL LAMPS ...	18
PARKING, LICENSE PLATE AND TAIL LAMPS : System Diagram	18
PARKING, LICENSE PLATE AND TAIL LAMPS : System Description	18
REAR FOG LAMP SYSTEM	18
REAR FOG LAMP SYSTEM : System Diagram	19
REAR FOG LAMP SYSTEM : System Description..	19
EXTERIOR LAMP BATTERY SAVER SYSTEM	19
EXTERIOR LAMP BATTERY SAVER SYSTEM : System Diagram	19
EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description	19
DIAGNOSIS SYSTEM (BCM)	21
COMMON ITEM	21
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	21
HEADLAMP	22
HEADLAMP : CONSULT Function (BCM - HEAD LAMP)	22
FLASHER	24
FLASHER : CONSULT Function (BCM - FLASH-ER)	24
DIAGNOSIS SYSTEM (IPDM E/R)	26
Diagnosis Description	26
CONSULT Function (IPDM E/R)	28
ECU DIAGNOSIS INFORMATION	31
BCM, IPDM E/R	31
List of ECU Reference	31
WIRING DIAGRAM	32
HEADLAMP SYSTEM	32
Wiring Diagram	32
AUTO LIGHT SYSTEM	37
Wiring Diagram	37
DAYTIME RUNNING LIGHT SYSTEM	43
Wiring Diagram	43
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM	49
Wiring Diagram	49
PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM	55
Wiring Diagram	55
STOP LAMP	60
Wiring Diagram	60
BACK-UP LAMP	63
Wiring Diagram	63
REAR FOG LAMP SYSTEM	67
Wiring Diagram	67
BASIC INSPECTION	72
DIAGNOSIS AND REPAIR WORK FLOW	72
Work Flow	72
DTC/CIRCUIT DIAGNOSIS	75
HEADLAMP (HI) CIRCUIT	75
Description	75
Component Function Check	75
Diagnosis Procedure	75
HEADLAMP (LO) CIRCUIT	77
Description	77
Component Function Check	77
Diagnosis Procedure	77
XENON HEADLAMP	79
Description	79
Diagnosis Procedure	79
DAYTIME RUNNING LIGHT CIRCUIT	81
Component Function Check	81
Diagnosis Procedure	81
PARKING LAMP CIRCUIT	83
Component Function Check	83
Diagnosis Procedure	83
TURN SIGNAL LAMP CIRCUIT	85
Description	85
Component Function Check	85
Diagnosis Procedure	85
OPTICAL SENSOR	88
Description	88
Component Function Check	88
Diagnosis Procedure	88
HAZARD SWITCH	91
Component Function Check	91
Diagnosis Procedure	91
TAIL LAMP CIRCUIT	93
Component Function Check	93
Diagnosis Procedure	93
LICENSE PLATE LAMP CIRCUIT	95
Component Function Check	95

Diagnosis Procedure	95	Exploded View	111
REAR FOG LAMP CIRCUIT	96	Removal and Installation	111
Component Function Check	96	OPTICAL SENSOR	113
Diagnosis Procedure	96	Exploded View	113
SYMPTOM DIAGNOSIS	98	Removal and Installation	113
EXTERIOR LIGHTING SYSTEM SYMPTOMS...98		LIGHTING & TURN SIGNAL SWITCH	114
Symptom Table	98	Exploded View	114
NORMAL OPERATING CONDITION	101	HAZARD SWITCH	115
Description	101	Exploded View	115
BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM	102	Removal and Installation	115
Description	102	SIDE TURN SIGNAL LAMP	116
Diagnosis Procedure	102	Exploded View	116
BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON	103	Removal and Installation	116
Description	103	Replacement	116
Diagnosis Procedure	103	REAR COMBINATION LAMP	117
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON ...104		Exploded View	117
Description	104	Removal and Installation	117
Diagnosis Procedure	104	Replacement	118
PERIODIC MAINTENANCE	105	HIGH-MOUNTED STOP LAMP	119
HEADLAMP AIMING ADJUSTMENT	105	Exploded View	119
Description	105	Removal and Installation	119
Aiming Adjustment Procedure	106	LICENSE PLATE LAMP	120
REMOVAL AND INSTALLATION	107	Exploded View	120
FRONT COMBINATION LAMP	107	Removal and Installation	120
Exploded View	107	Replacement	120
Removal and Installation	108	REAR FOG LAMP	122
Replacement	108	Exploded View	122
Disassembly and Assembly	109	Removal and Installation	122
Inspection After Installation (HID Control Unit)109		Replacement	122
DAYTIME RUNNING LIGHT	111	SERVICE DATA AND SPECIFICATIONS (SDS)	124
		Bulb Specifications	124

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

< PRECAUTION >

PRECAUTION

PRECAUTIONS FOR USA AND CANADA

FOR USA AND CANADA : Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010840507

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precautions For Xenon Headlamp Service

INFOID:000000010840508

WARNING:

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector.
(Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

PRECAUTIONS

[XENON TYPE]

< PRECAUTION >

FOR USA AND CANADA : Precaution for Battery Service

INFOID:0000000010840509

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

FOR USA AND CANADA : Precautions for Removing Battery Terminal

INFOID:0000000011350216

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010840510

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO : Precautions For Xenon Headlamp Service

INFOID:0000000010840511

WARNING:

Comply with the following warnings to prevent any serious accident.

PRECAUTIONS

[XENON TYPE]

< PRECAUTION >

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

FOR MEXICO : Precaution for Battery Service

INFOID:0000000010840512

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

FOR MEXICO : Precautions for Removing Battery Terminal

INFOID:0000000011350217

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



SEF289H

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

COMPONENT PARTS

HEADLAMP SYSTEM

HEADLAMP SYSTEM : Component Parts Location

INFOID:0000000010840513



1. BCM
Refer to [BCS-10, "Component Parts Location"](#).
2. IPDM E/R
Refer to [PCS-5, "Component Parts Location"](#).
3. Headlamp
4. Combination meter
(High beam indicator lamp)
5. Combination switch

HEADLAMP SYSTEM : Component Description

INFOID:0000000010840514

Part	Description	
BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Judges that the headlamp is turned ON according to the vehicle condition. Requests the headlamp relay (HI/LO) ON to IPDM E/R (with CAN communication). Requests the high beam indicator lamp ON to the combination meter (with CAN communication). 	
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).	
Combination switch (Lighting & turn signal switch)	Refer to BCS-11, "System Diagram" .	
Combination meter (High beam indicator lamp)	Turns the high beam indicator lamp ON according to the request from BCM (with CAN communication).	
Headlamp assembly	• HID control unit • Xenon bulb	Refer to EXL-79, "Description" .
	High beam solenoid	Refer to EXL-75, "Description" .

AUTO LIGHT SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

AUTO LIGHT SYSTEM : Component Parts Location

INFOID:0000000010840515



- | | | |
|--|----------------------|--|
| 1. Door switch | 2. Optical sensor | 3. BCM
Refer to BCS-10, "Component Parts Location". |
| 4. IPDM E/R
Refer to PCS-5, "Component Parts Location". | 5. Combination meter | 6. Combination switch |

AUTO LIGHT SYSTEM : Component Description

INFOID:0000000010840516

Part	Description
BCM	<ul style="list-style-type: none">Detects each switch condition by the combination switch reading function.Judges the outside brightness from the optical sensor signal.Judges the OFF timing according to the vehicle condition.Judges the ON/OFF status of the exterior lamp and each illumination according to the outside brightness and the vehicle condition.Requests ON/OFF of each relay to IPDM E/R (with CAN communication).
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-11, "System Diagram".
Optical sensor	Refer to EXL-88, "Description".

DAYTIME RUNNING LIGHT SYSTEM

DAYTIME RUNNING LIGHT SYSTEM : Component Parts Location


INFOID:0000000010840517

EXCEPT NISMO

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[XENON TYPE]



JMLIA3016ZZ

- | | | |
|---|---|--|
| 1. BCM
Refer to BCS-10, "Component Parts Location" . | 2. IPDM E/R
Refer to PCS-5, "Component Parts Location" . | 3. ECM
Refer to EC-40, "Component Parts Location" . |
| 4. Daytime running light | 5. Combination meter | 6. Combination switch |
| 7. Parking brake switch | | |

NISMO



JMLIA5707ZZ

- | | | |
|---|---|--|
| 1. BCM
Refer to BCS-10, "Component Parts Location" . | 2. IPDM E/R
Refer to PCS-5, "Component Parts Location" . | 3. ECM
Refer to EC-40, "Component Parts Location" . |
| 4. Daytime running light | 5. Combination meter | 6. Combination switch |
| 7. Parking brake switch | | |

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

DAYTIME RUNNING LIGHT SYSTEM : Component Description


INFOID:000000010840518

Part	Description
BCM	<ul style="list-style-type: none"> Detects each switch condition with the combination switch reading function. Judges each lamps ON/OFF condition according to the vehicle condition. - Requests the each relay ON to IPDM E/R (with CAN communication).
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-11, "System Diagram" .
ECM	Transmits the engine status signal to BCM with CAN communication.
Combination meter	Transmits the parking brake switch signal to BCM with CAN communication.

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : Component Parts Location

INFOID:000000010840519



- | | | |
|---------------------------|---|---------------------------|
| 1. Hazard switch | 2. BCM
Refer to BCS-10, "Component Parts Location" . | 3. Front turn signal lamp |
| 4. Side turn signal lamp* | 5. Combination meter
(Turn signal indicator lamp) | 6. Combination switch |
| 7. Rear turn signal lamp | | |

*: With side turn signal lamp

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : Component Description

INFOID:000000010840520

Part	Description
BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Judges the blinks of the turn signal lamp and the hazard warning lamp from each switch status. The applicable turn signal lamp blinks. - Requests the turn signal indicator lamp blink to the combination meter (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-11, "System Diagram" .

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

A
B
C
D
E
F
G
H
I
J
K


EXL
M
N
O
P

Part	Description
Hazard switch	Inputs the hazard switch ON/OFF signal to BCM.
Combination meter (Turn signal indicator lamp & buzzer)	Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (with CAN communication).

PARKING, LICENSE PLATE AND TAIL LAMPS

PARKING, LICENSE PLATE AND TAIL LAMPS : Component Parts Location

INFOID:0000000010840521



- | | | |
|--|--|-----------------------|
| 1. BCM
Refer to BCS-10, "Component Parts Location". | 2. IPDM E/R
Refer to PCS-5, "Component Parts Location". | 3. Parking lamp |
| 4. Front side marker lamp | 5. Combination meter
(Tail lamp indicator lamp) | 6. Combination switch |
| 7. Rear side marker lamp | 8. Tail lamp | 9. License plate lamp |

PARKING, LICENSE PLATE AND TAIL LAMPS : Component Description

INFOID:0000000010840522

Part	Description
BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Judges the ON/OFF status of the parking, license plate, tail and side marker lamps according to the vehicle condition. Requests the tail lamp relay ON to IPDM E/R (with CAN communication). Requests the tail lamp indicator lamp ON to the combination meter (with CAN communication).
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-11, "System Diagram".
Combination meter (Tail lamp indicator lamp)	Turns the tail lamp indicator lamp ON according to the request from BCM (with CAN communication).

REAR FOG LAMP SYSTEM


COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

REAR FOG LAMP SYSTEM : Component Parts Location

INFOID:0000000010840523



JPLIA1563ZZ

1. BCM
Refer to [BCS-10, "Component Parts Location"](#).
2. Combination meter
(Rear fog lamp indicator lamp)
3. Combination switch
4. Rear fog lamp

REAR FOG LAMP SYSTEM : Component Description

INFOID:0000000010840524

Part	Description
BCM	<ul style="list-style-type: none">• Detects each switch condition by the combination switch reading function.• Judges that the rear fog lamp is turned ON according to the vehicle status- Supplies voltage to the rear fog lamp- Requests the rear fog lamp indicator lamp ON to the combination meter (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-11, "System Diagram" .
Combination meter (Rear fog lamp indicator lamp)	Turns the rear fog lamp indicator lamp ON according to the request from BCM (with CAN communication).

EXTERIOR LAMP BATTERY SAVER SYSTEM


COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

EXTERIOR LAMP BATTERY SAVER SYSTEM : Component Parts Location

INFOID:000000010840525



1. BCM
Refer to [BCS-10, "Component Parts Location"](#).
2. IPDM E/R
Refer to [PCS-5, "Component Parts Location"](#).
3. Combination meter
4. Combination switch

EXTERIOR LAMP BATTERY SAVER SYSTEM : Component Description

INFOID:000000010840526


Part	Description
BCM	<ul style="list-style-type: none">• Detects each switch condition by the combination switch reading function.• Judges the exterior lamp OFF according to the vehicle condition.- Requests each relay OFF to IPDM E/R (with CAN communication).- Turn rear fog lamp OFF.
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-11, "System Diagram" .

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL

< SYSTEM DESCRIPTION >

SYSTEM**HEADLAMP SYSTEM****HEADLAMP SYSTEM : System Diagram**

INFOID:0000000010840527

**HEADLAMP SYSTEM : System Description**

INFOID:0000000010840528

OUTLINE

- Mobile valve shade type is adopted. Xenon headlamp switches the high beam and the low beam with one xenon bulb each on right and left.
- Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

HEADLAMP BASIC OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp ON condition.

Headlamp ON condition

- Lighting switch 2ND
- Lighting switch PASS
- Lighting switch AUTO, and the auto light function ON judgment
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp ON according to the low beam request signal.

HEADLAMP HI/LO SWITCHING OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the high beam switching condition.

High beam switching condition


- Lighting switch HI with the headlamp ON
- Lighting switch PASS
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.

SYSTEM

[XENON TYPE]

< SYSTEM DESCRIPTION >

- When the headlamp high relay is turned ON, magnetic force is applied to the high beam solenoid (1) by a current. The mobile valve shade (3) is switched to the high beam position through the actuator rod (2).
- When the headlamp high relay is turned OFF, the current stops. The mobile valve shade returns to the low beam position automatically.




JPLIA1528ZZ

AUTO LIGHT SYSTEM

AUTO LIGHT SYSTEM : System Diagram

INFOID:0000000010840529



JPLIA1775GB

AUTO LIGHT SYSTEM : System Description

INFOID:0000000010840530

OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function and the delay timer function.
- Auto light function turns the exterior lamps* and each illumination ON/OFF automatically according to the outside brightness.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

SYSTEM

[XENON TYPE]

< SYSTEM DESCRIPTION >

- When auto light system turns the exterior lamps ON with the ignition switch OFF, delay timer function turns the exterior lamps OFF depending on the vehicle condition with the auto light function after a certain period of time.

*: Headlamp (LO/HI), parking lamp, side marker lamp, license plate lamp and tail lamp

NOTE:

Headlamp HI depend on the combination switch condition.

AUTO LIGHT FUNCTION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to optical sensor when the ignition switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges outside brightness from the optical sensor signal and judges ON/OFF condition of the exterior lamp and each illumination according to the outside brightness.
- BCM transmits each request signal to IPDM E/R with CAN communication according to ON/OFF condition by the auto light function.

NOTE:

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT. Refer to [EXL-22, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)".](#)

DELAY TIMER FUNCTION

BCM turns the exterior lamp OFF depending on the vehicle condition with the auto light function when the ignition switch is turned OFF.

- Turns the exterior lamp OFF 5 minutes after detecting that any door opens (Door switch ON).
- Turns the exterior lamp OFF a certain period of time* after closing all doors (Door switch ON→OFF).
- Turns the exterior lamp OFF with the ignition switch ACC or the light switch OFF.

*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [EXL-22, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)".](#)


NOTE:

When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

DAYTIME RUNNING LIGHT SYSTEM

DAYTIME RUNNING LIGHT SYSTEM : System Diagram

INFOID:0000000010840531



DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:0000000010840532

OUTLINE

- Daytime running light system is turned on daytime running light.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects the engine condition by the engine status signal received from ECM with CAN communication.

SYSTEM

[XENON TYPE]

< SYSTEM DESCRIPTION >

- BCM detects the parking brake condition by the parking brake switch signal received from combination meter with CAN communication.
- BCM detects ENGINE RUNNING condition by engine status signal and RELEASE condition by parking brake switch signal. And then, BCM transmits the daytime running light request signal to IPDM E/R with CAN communication according to any of the daytime running light ON condition.


Daytime running light ON condition

- Lighting switch OFF
- Lighting switch AUTO and auto light judgement OFF
- IPDM E/R turns the integrated front fog lamp relay ON, and turns the daytime running light ON according to the daytime running light request signal.

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram

INFOID:000000010840533



TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:000000010840534

OUTLINE

Turn signal and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is turned ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is turned ON. BCM blinks the hazard warning lamp.

TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn indicator signal to the combination meter with CAN communication while the turn signal lamp and the hazard warning lamp operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn indicator signal.

3-TIME FLASHER FUNCTION

- By a short touch of the turn signal lever, BCM blinks the turn signal lamps 3 times in the selected direction.
- Cancels the operation when short touch of the turn signal lever in the reverse direction during the 3-time flasher function operation.

HIGH FLASHER OPERATION

- BCM detects the turn signal lamp circuit status from the current value.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.


NOTE:

The blinking speed is normal while operating the hazard warning lamp.

PARKING, LICENSE PLATE AND TAIL LAMPS

PARKING, LICENSE PLATE AND TAIL LAMPS : System Diagram

INFOID:0000000010840535



PARKING, LICENSE PLATE AND TAIL LAMPS : System Description

INFOID:0000000010840536

OUTLINE

Parking, license plate, tail and side marker lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

PARKING, LICENSE PLATE, TAIL AND SIDE MARKER LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter with CAN communication according to the ON/OFF condition of the parking, license plate, tail and side marker lamps.

Parking, license plate, tail and side marker lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking, license plate, tail and side marker lamps ON according to the position light request signal.
- Combination meter turns the position lamp indicator lamp ON according to the position light request signal.

REAR FOG LAMP SYSTEM


SYSTEM

[XENON TYPE]

< SYSTEM DESCRIPTION >

REAR FOG LAMP SYSTEM : System Diagram

INFOID:0000000010840537



REAR FOG LAMP SYSTEM : System Description

INFOID:0000000010840538

OUTLINE

Rear fog lamp is controlled with the combination switch reading function and the rear fog lamp control function of BCM.

REAR FOG LAMP OPERATION

- BCM detects the condition of the combination switch by the combination switch reading function.
- BCM supplies voltage to rear fog lamp according to the rear fog lamp ON condition.

Rear fog lamp ON condition

- When rear fog lamp switch signal is input (OFF → ON) with headlamp ON and rear fog lamp OFF


Rear fog lamp OFF condition (satisfied any condition as follows)

- When rear fog lamp switch signal is input (OFF → ON) with rear fog lamp ON
- Headlamp OFF
- BCM transmits the rear fog lamp status signal to the combination meter with CAN communication.
- Combination meter turns the rear fog lamp indicator lamp ON according to the rear fog lamp status signal.

EXTERIOR LAMP BATTERY SAVER SYSTEM

EXTERIOR LAMP BATTERY SAVER SYSTEM : System Diagram

INFOID:0000000010840539



EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:0000000010840540

OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

SYSTEM

[XENON TYPE]

< SYSTEM DESCRIPTION >

Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

Control by IPDM E/R

- Relay control function
- BCM turns the exterior lamp* OFF after a period of time to prevent the battery from over-discharge when the ignition switch is turned OFF with the exterior lamp ON.

*: Headlamp (LO/HI), parking lamp, tail lamp, license plate lamp, side marker lamp and rear fog lamp.

NOTE:

When the lighting switch is turned AUTO, the exterior lamp battery saver switches to the auto light system.
Refer to [EXL-15, "AUTO LIGHT SYSTEM : System Diagram"](#).

EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 45 seconds after the ignition switch is turned from ON → OFF with the exterior lamps ON.

NOTE:

- Headlamp control function turns the exterior lamps ON normally when the ignition switch is turned ACC or the engine started (both before and after the exterior lamp battery saver is turned OFF).
- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamp OFF.

DIAGNOSIS SYSTEM (BCM)

[XENON TYPE]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000011287396

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> • Read and save the vehicle specification. • Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER*			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
NVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door/Trunk lid open	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x

NOTE:

*: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC	While turning power supply position from "LOCK"** to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Except emergency stop operation)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"**
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK"**.) to low power consumption mode
	LOCK	Power supply position is "LOCK"**
	OFF	Power supply position is "OFF" (Ignition switch OFF)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position (A/T models), and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:0000000010840542

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Service item	Setting item	Setting
BATTERY SAVER SET	On*	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function
ILL DELAY SET	MODE 1*	45 sec.
	MODE 2	Without the function
	MODE 3	30 sec.
	MODE 4	60 sec.
	MODE 5	90 sec.
	MODE 6	120 sec.
	MODE 7	150 sec.
	MODE 8	180 sec.
CUSTOM A/LIGHT SETTING	MODE 1*	Normal
	MODE 2	More sensitive setting than normal setting (Turns ON earlier than normal operation.)
	MODE 3	More sensitive setting than MODE 2 (Turns ON earlier than MODE 2.)
	MODE 4	Less sensitive setting than normal setting (Turns ON later than normal operation.)

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ENGINE STATE [Stop/Stall/Crank/Run]	The engine status received from ECM with CAN communication
VEH SPEED 1 [km/h]	The value of the vehicle speed received from combination meter with CAN communication
KEY SW-SLOT [On/Off]	Key switch status input from key slot
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW1 [On/Off]	
HEAD LAMP SW2 [On/Off]	The item is indicated, but not monitored.
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	
RR FOG SW [On/Off]	Each switch status that BCM judges from the combination switch reading function

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Monitor item [Unit]	Description
DOOR SW-DR [On/Off]	The switch status input from driver side door switch
DOOR SW-AS [On/Off]	The switch status input from passenger side door switch
DOOR SW-RR [On/Off]	
DOOR SW-RL [On/Off]	NOTE: The item is indicated, but not monitored.
DOOR SW-BK [On/Off]	
OPTICAL SENSOR [V]	The value of exterior brightness voltage input from the optical sensor

ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	Transmits the position light request signal to IPDM E/R with CAN communication to turn the tail lamp ON.
	Off	Stops the position light request signal transmission.
HEAD LAMP	Hi	Transmits the high beam request signal with CAN communication to turn the head-lamp (HI).
	Low	Transmits the low beam request signal with CAN communication to turn the head-lamp (LO).
	Off	Stops the high & low beam request signal transmission.
FR FOG LAMP	On	Transmits the daytime running light request signal with CAN communication to turn the daytime running light.
	Off	Stops the daytime running light request signal transmission.
RR FOG LAMP	On	<ul style="list-style-type: none"> Outputs the voltage to turn the rear fog lamp ON. Transmits the rear fog lamp status signal to the combination meter with CAN communication to turn the rear fog lamp indicator lamp ON.
	Off	<ul style="list-style-type: none"> Stops the voltage to turn the rear fog lamp OFF. Stops the rear fog lamp status signal transmission.
DAYTIME RUNNING LIGHT	On	NOTE: The item is indicated, but cannot be tested.
	Off	
CORNERRING LAMP	RH	
	LH	NOTE: The item is indicated, but cannot be tested.
	Off	
ILL DIM SIGNAL	On	NOTE: The item is indicated, but cannot be tested.
	Off	

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000010840543

WORK SUPPORT

Service item	Setting item	Setting
HAZARD ANSWER BACK	Lock Only*	With locking only
	Unlk Only	With unlocking only
	Lock/Unlk	With locking/unlocking
	Off	Without the function

DIAGNOSIS SYSTEM (BCM)

[XENON TYPE]

< SYSTEM DESCRIPTION >

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from the request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from the request switch (passenger side)
PUSH SW [On/Off]	The switch status input from the push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch condition that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch
RKE-LOCK [On/Off]	Lock signal status received from the remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from the remote keyless entry receiver
RKE-PANIC [On/Off]	Panic alarm signal status received from the remote keyless entry receiver

ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	Outputs the voltage to turn the right side turn signal lamps ON.
	LH	Outputs the voltage to turn the left side turn signal lamps ON.
	Off	Stops the voltage to turn the turn signal lamps OFF.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)**Diagnosis Description**

INFOID:0000000011287397

AUTO ACTIVE TEST**Description**

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Side maker lamps
- Tail lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (cooling fan control module)

Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the front door switch (driver side) 10 times. Then turn the ignition switch OFF.

CAUTION:

Close passenger door.

4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-89, "Component Function Check".](#)
- Do not start the engine.

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 6 steps are repeated 3 times.

Operation sequence	Inspection location	Operation
1	Oil pressure warning lamp	Blinks continuously during operation of auto active test
2	Front wiper	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"> • Parking lamps • License plate lamps • Side maker lamps • Tail lamps 	10 seconds
4	Headlamps	LO for 10 seconds → HI ON ⇄ OFF 5 times
5	A/C compressor (magnet clutch)	ON ⇄ OFF 5 times
6*	Cooling fan	MID for 5 seconds → HI for 5 seconds


*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

< SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate • Parking lamps • License plate lamps • Side maker lamps • Tail lamps • Headlamp (HI, LO) • Front wiper (HI, LO)	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES • Unified meter and A/C amp. signal input circuit • CAN communication signal between unified meter and A/C amp. and ECM • CAN communication signal between ECM and IPDM E/R
		NO • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES • Harness or connector between IPDM E/R and oil pressure switch • Oil pressure switch • IPDM E/R
		NO • CAN communication signal between IPDM E/R and BCM • CAN communication signal between BCM and unified meter and A/C amp. • Combination meter

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Symptom	Inspection contents	Possible cause
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	<ul style="list-style-type: none"> • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R <ul style="list-style-type: none"> • Cooling fan • Harness or connector between cooling fan and cooling fan control module • Cooling fan control module • Harness or connector between IPDM E/R and cooling fan control module • Cooling fan relay • Harness or connector between IPDM E/R and cooling fan relay • IPDM E/R

CONSULT Function (IPDM E/R)

INFOID:000000011287398

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

SELF DIAGNOSTIC RESULT

Refer to [PCS-33, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	MAIN SIG- NAL(S)	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the daytime running light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper stop position signal judged by IPDM E/R.

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Monitor Item [Unit]	MAIN SIG- NAL(S)	Description
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the clutch interlock switch (M/T models) or shift position (A/T models) judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ST ON/INHI ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the A/T shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		NOTE: The item is indicated, but not monitored.
S/L STATE [LOCK/UNLOCK/UNKWN]		NOTE: The item is indicated, but not monitored.
DTRL REQ [Off/On]		NOTE: The item is indicated, but not monitored.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off/On]		NOTE: The item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.
CRNRNG LMP REQ [Off/On]		NOTE: The item is indicated, but not monitored.

ACTIVE TEST

Test item	Operation	Description
CORNERING LAMP	Off	NOTE: The item is indicated, but cannot be tested.
	LH	
	RH	
HORN	On	Operates horn relay 1 and horn relay 2 for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Test item	Operation	Description
MOTOR FAN	1	OFF
	2	Outputs 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Outputs 80% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Outputs 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	On	NOTE: The item is indicated, but cannot be tested.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay and daytime running light relay. NOTE: Daytime running light relay is with daytime running light system only.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	NOTE: The item is indicated, but cannot be tested.

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000010840546

ECU	Reference
BCM	BCS-58, "Reference Value"
	BCS-97, "Fail-safe"
	BCS-98, "DTC Inspection Priority Chart"
	BCS-99, "DTC Index"
IPDM E/R	PCS-21, "Reference Value"
	PCS-31, "Fail-safe"
	PCS-33, "DTC Index"

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HEADLAMP SYSTEM

[XENON TYPE]


< WIRING DIAGRAM >

WIRING DIAGRAM

HEADLAMP SYSTEM

Wiring Diagram

INFOID:0000000010840547




JRLWC2576GB

2012/07/11

HEADLAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



JRLWD7855GB

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

EXL

HEADLAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


HEADLAMP		M1		M3		M24		M24		M24		M24		M24		M24		M24	
Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name
Connector No.	M1	Connector No.	M3	Connector No.	M24	Connector No.	M24	Connector No.	M24	Connector No.	M24	Connector No.	M24	Connector No.	M24	Connector No.	M24	Connector No.	M24
Connector Name	FUSE BLOCK (J/B)	Connector Name	FUSE BLOCK (J/B)	Connector Name	DATA LINK CONNECTOR	Connector Name	DATA LINK CONNECTOR	Connector Name	DATA LINK CONNECTOR	Connector Name	DATA LINK CONNECTOR	Connector Name	DATA LINK CONNECTOR	Connector Name	DATA LINK CONNECTOR	Connector Name	DATA LINK CONNECTOR	Connector Name	DATA LINK CONNECTOR
Connector Type	NS10FW-M2	Connector Type	NS10FW-CS	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW
																			
Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
1A	V	10C	L	45	O	21	R	31	BR	46	C	3	LG	11	P	12	FRASHER (-)	13	Y
2A	G	11C	LG	46	C	32	V	36	SB	47	BR	4	B	14	W	15	FRASHER (-)	5	BR
3A	L	12C	O	58	SHEILD	37	Y	38	LG	59	L	5	B	16	R	17	FRASHER (-)	6	LG
4A	P	6C	R	70	R	39	SB	40	W	71	GR	6	L	18	Y	19	FRASHER (-)	7	Y
5A	L	7C	B	80	LG	41	LG	42	R	81	GR	8	LG	20	Y	21	FRASHER (-)	9	LG
6A	Y	9C	O	82	V	83	V	84	L	85	BR	11	LG	22	Y	23	FRASHER (-)	12	Y
7A	BR			86	Y	87		88		89	P	13	Y	24	P	25	FRASHER (-)	14	Y
8A	L					90		91	W	92	P	15	Y	26	Y	27	FRASHER (-)	16	Y
Connector No.	M2	Connector Name	FUSE BLOCK (J/B)	Connector No.	M6	Connector Name	WIRE TO WIRE	Connector No.	M3	Connector Name	COMBINATION SWITCH	Connector No.	M24	Connector Name	COMBINATION SWITCH	Connector No.	M24	Connector Name	COMBINATION SWITCH
Connector Name	NS10FW-CS	Connector Type	NS10FW-CS	Connector Type	TS80MW-CS16-TM4	Connector Type	TS80MW-CS16-TM4	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW	Connector Type	ED10FW
																			
Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
1	Y	3	L	4	L	5	P	6	BR	7	BR	8	O	9	W	10	R	11	GR
3B	P	5B	O	6B	Y	7B	B	8B	BR	9B	BR	10B	R	11B	BR	12B	Y	13B	LG
4B	G	-	-	8B	R	12	R	13	L	14	G	15	P	16	W	17	BR	18	GR
5B	BR	-	-	9B	SB	-	-	10B	-	11B	-	12B	-	13B	-	14B	-	15B	-

JRLWD7856GB

HEADLAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



JRLWD7857GB

HEADLAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Terminal No.	Color Of Wire	Signal Name [Specification]
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	-
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR IN/LOCK SENSOR
121	R	KEY SLOT SW
123	W	(H/F/B)
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFOGGER SW
132	V	SW SW & SOFT TORQUE COMM (not available model)
132	Y	POWER WINDOW SW COMM (Corolla model)
133	G	PUSH BUTTON IGNITION SW/L/POWER
134	GR	LOCK IND
137	P	RECEIVER & SENSOR GND
138	V	RECEIVER & SENSOR POWER SUPPLY
139	L	TIRE PRESS RECEIV COMM
140	G	FIN POSITION
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT

JRLWD7858GB

AUTO LIGHT SYSTEM


[XENON TYPE]

< WIRING DIAGRAM >

AUTO LIGHT SYSTEM

Wiring Diagram

INFOID:0000000010840548



AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

AUTO LIGHT SYSTEM


Connector No.	B1	Terminal Color Of No.	Wire Signal Name [Specification]	Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Signal Name [Specification]
Connector Name	WIRE TO WIRE	42	GR	-	2	BR	- [Coupe models]
Connector Type	T160FW/CS16-TM4	43	R	-	3	Y	- [Roaster models]
		44	BG	-	4	P	-
		45	SB	-	5	V	-
		46	SHIELD	- [Roaster models] - [Coupe models]	6	W	-
		47	V	-	7	R	-
		48	SHIELD	-	8	G	- [Coupe models]
		51	W	-	9	LG	- [Roaster models]
		52	R	-	10	Y	-
		57	SHIELD	-	11	Y	-
		58	B	-	12	W	-
		60	V	-	13	R	-
		61	SB	-	14	LG	-
		62	SHIELD	-	15	B	-
		63	BR	-	16	V	-
		64	Y	-	17	R	-
		65	SHIELD	-	18	B	-
		66	P	-	20	SB	-
		67	L	-	21	G	-
		68	SHIELD	-	74	GR	-
		69	R	-	75	BG	-
		70	G	-	80	Y	-
		71	V	-	81	R	-
		72	P	-	82	B	-
		73	BR	-	83	GR	-
		74	GR	-	84	G	- [Coupe models]
		75	BG	-	84	L	- [Roaster models]
		80	Y	-	85	LG	-
		81	R	-	86	V	-
		82	B	-	87	BR	-
		83	GR	-	88	G	-
		84	G	-	93	Y	- [Roaster models]
		84	L	-	94	G	-
		85	LG	-	94	L	- [Coupe models]
		86	V	-	95	GR	- [Coupe models]
		87	BR	-	95	LG	- [Roaster models]
		88	G	-	96	L	-
		93	Y	-	97	Y	-
		94	G	-	98	W	- [Coupe models]
		94	L	-	98	YB	- [Roaster models]
		95	GR	-	99	LG	-
		95	LG	-	100	L	-
		96	L	-			
		97	Y	-			
		98	W	-			
		98	YB	-			
		99	LG	-			
		100	L	-			

JRLWD7865GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



JRLWD7866GE

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

AUTO LIGHT SYSTEM


Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
31	L	-	17	BR	-
32	Y	-	20	GR	-
36	Y	-	21	R	-
37	R	-	31	BR	-
38	R	-	32	V	-
39	B	-	36	SB	-
40	W	-	37	Y	-
41	LG	-	38	LG	-
42	SB	-	39	SB	-
43	GR	-	40	W	-
44	R	- Except for roadster models with M/T - [Roadster models with M/T]	41	LG	-
45	BG	-	42	R	-
46	W	-	43	G	-
47	P	-	44	G	- [With A/T] - [With M/T]
58	SHEILD	-	44	R	-
59	L	-	45	O	-
70	P	-	46	G	-
70	P	-	47	BR	-
80	W	-	58	SHEILD	-
81	P	-	59	L	-
82	G	-	70	R	-
83	V	-	80	LG	-
84	L	-	81	GR	-
85	BG	-	82	V	-
86	LG	-	83	V	-
87	R	-	84	L	-
89	P	-	85	BR	-
91	W	-	86	Y	-
92	L	-	87	G	-
93	G	-	89	P	-
94	Y	-	91	W	-
96	Y	-	92	P	-
97	BR	-	93	P	-
98	GR	-	94	Y	-
99	LG	-	96	P	-
100	BG	-	97	GR	-
1	Y	-	98	O	-
3	L	-	99	W	-
4	L	-	100	R	-
7	B	-	32	B	-
8	P	-	33	W	-
9	B	-	34	R	-
11	GR	-	35	B	-
12	R	-	36	L	-
13	L	-	40	L	-
14	G	-	41	R	-
15	P	-	42	GR	-
16	W	-	43	R	-
			44	R	-

JRLWD7867GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



JRLWD7868GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Terminal Color Of No.	Wire	Signal Name [Specification]	Terminal Color Of No.	Wire	Signal Name [Specification]	Terminal Color Of No.	Wire	Signal Name [Specification]
1	W	BAT (FIL)	72	L	ROOM ANT 2-	113	O	OPTICAL SENSOR
2	W	POWER WINDOW POWER SUPPLY (BAT)	73	P	ROOM ANT 2+	114	R	CLUTCH INTERLOCK SW
3	Y	POWER WINDOW POWER SUPPLY (IGN)	74	SE	PASSENGER DOOR ANT-	115	O	-
			75	BR	PASSENGER DOOR ANT+	116	SB	STOP LAMP SW 1
			76	V	DRIVER DOOR ANT-	118	P	STOP LAMP SW 2
			77	LG	DRIVER DOOR ANT +	119	SB	DR DOOR UNL/LOCK SENSOR
			78	L	ROOM ANT 1-	121	R	KEY SLOT SW
			79	R	ROOM ANT 1+	123	W	IGN FIB
			80	GR	NATS ANT AMP.	124	LG	PASSENGER DOOR SW
			81	W	NATS ANT AMP.	129	O	TRUNK LID OPENER CANCEL SW
			82	R	IGN RELAY (FB) CONT	130	L	REAR DEFOGGER SW
			83	GR	KYLS ENT RECEIVER (FRONT) COMM	132	V	POWER WINDOW SW COMM (Cable model)
			87	DR	COMBI SW INPUT 5	132	Y	POWER WINDOW SW COMM (Cable model)
			88	V	COMBI SW INPUT 3	133	G	PUSHBUTTON IGNITION SW (ILL POWER)
			90	P	CANL	134	GR	LOCK IND
			91	L	CANH	137	P	RECEIVER & SENSOR GND
			92	LG	KEY SLOT/LILL	138	V	RECEIVER & SENSOR POWER SUPPLY
			93	V	ON/IND	139	L	TIRE PRESS RECEIV. COMM
			95	O	ACC RELAY CONT	140	G	PIN POSITION
4	R	INTERIOR ROOMLAMP POWER SUPPLY	96	Y	ATT SHIFT SELECTOR POWER SUPPLY	141	Y	SECURITY INDICATOR
5	G	PASSENGER DOOR UNLOCK OUTPUT	99	R	SHIFT P/CLUTCH PEDAL POS SW	142	O	COMBI SW OUTPUT 5
8	V	ALL DOOR FUEL LID LOCK OUTPUT	100	GR	PASSENGER DOOR REQUEST SW	143	P	COMBI SW OUTPUT 1
9	G	DRIVER DOOR FUEL LID UNL/LOCK OUTPUT	101	Y	DRIVER DOOR REQUEST SW	144	G	COMBI SW OUTPUT 2
11	GR	BAT (FUSE)	102	O	BLOWER FAN MOTOR RELAY CONT	145	L	COMBI SW OUTPUT 3
13	B	GROUND	103	LG	KYLS ENT RECEIVER (FRONT) PAR SUPPLY	146	SB	COMBI SW OUTPUT 4
14	R	PUSH-BUTTON IGNITION SW/LILL GND	107	LG	COMBI SW INPUT 1	150	GR	DRIVER DOOR SW
15	Y	ACC IND	108	R	COMBI SW INPUT 4	151	G	REAR WINDOW DEFROGGER RELAY CONT
17	W	TURN SIGNAL RH (FRONT SIDE)	109	Y	COMBI SW INPUT 2			
18	O	TURN SIGNAL LH (FRONT SIDE)	110	P	HAZARD SW			
19	P	ROOM LAMP TIMER CONTROL						

JRLWD7869GB

DAYTIME RUNNING LIGHT SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

DAYTIME RUNNING LIGHT SYSTEM

Wiring Diagram

INFOID:0000000010840549



JRLWD7859GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No. E5 FROM LR INTELLIGENT POWER DISTRIBUTION MODULE Connector Name ENGINE ROOM Connector Type T120FW/CS12-M4-1V		Connector No. E79 DAYTIME RUNNING LIGHT RH Connector Name DAYTIME RUNNING LIGHT RH Connector Type RS02FB		Connector No. E30 FROM LR INTELLIGENT POWER DISTRIBUTION MODULE Connector Name ENGINE ROOM Connector Type NS01FW-CS																																																																																																																																																																																																																																																																																																																																																																																																																																																			
																																																																																																																																																																																																																																																																																																																																																																																																																																																							
<table border="1"> <thead> <tr> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>45</td> <td>G</td> <td>-</td> <td>-</td> <td>1</td> <td>Y</td> </tr> <tr> <td>46</td> <td>V</td> <td>-</td> <td>-</td> <td>2</td> <td>B</td> </tr> </tbody> </table>		Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	45	G	-	-	1	Y	46	V	-	-	2	B	<table border="1"> <thead> <tr> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>83</td> <td>R</td> <td>-</td> <td>-</td> <td>84</td> <td>P</td> </tr> <tr> <td>84</td> <td>P</td> <td>-</td> <td>-</td> <td>85</td> <td>Y</td> </tr> <tr> <td>85</td> <td>BG</td> <td>-</td> <td>-</td> <td>86</td> <td>BR</td> </tr> <tr> <td>86</td> <td>BR</td> <td>-</td> <td>-</td> <td>87</td> <td>R</td> </tr> <tr> <td>87</td> <td>R</td> <td>-</td> <td>-</td> <td>88</td> <td>G</td> </tr> <tr> <td>88</td> <td>G</td> <td>-</td> <td>-</td> <td>89</td> <td>LG</td> </tr> <tr> <td>89</td> <td>LG</td> <td>-</td> <td>-</td> <td>90</td> <td>LG</td> </tr> <tr> <td>90</td> <td>LG</td> <td>-</td> <td>-</td> <td>91</td> <td>LG</td> </tr> <tr> <td>91</td> <td>LG</td> <td>-</td> <td>-</td> <td>92</td> <td>LG</td> </tr> <tr> <td>92</td> <td>LG</td> <td>-</td> <td>-</td> <td>93</td> <td>LG</td> </tr> <tr> <td>93</td> <td>LG</td> <td>-</td> <td>-</td> <td>94</td> <td>LG</td> </tr> <tr> <td>94</td> <td>LG</td> <td>-</td> <td>-</td> <td>95</td> <td>LG</td> </tr> <tr> <td>95</td> <td>LG</td> <td>-</td> <td>-</td> <td>96</td> <td>LG</td> </tr> <tr> <td>96</td> <td>LG</td> <td>-</td> <td>-</td> <td>97</td> <td>LG</td> </tr> <tr> <td>97</td> <td>LG</td> <td>-</td> <td>-</td> <td>98</td> <td>LG</td> </tr> <tr> <td>98</td> <td>LG</td> <td>-</td> <td>-</td> <td>99</td> <td>LG</td> </tr> <tr> <td>99</td> <td>LG</td> <td>-</td> <td>-</td> <td>100</td> <td>LG</td> </tr> <tr> <td>100</td> <td>LG</td> <td>-</td> <td>-</td> <td>101</td> <td>LG</td> </tr> <tr> <td>101</td> <td>LG</td> <td>-</td> <td>-</td> <td>102</td> <td>LG</td> </tr> <tr> <td>102</td> <td>LG</td> <td>-</td> <td>-</td> <td>103</td> <td>LG</td> </tr> <tr> <td>103</td> <td>LG</td> <td>-</td> <td>-</td> <td>104</td> <td>LG</td> </tr> <tr> <td>104</td> <td>LG</td> <td>-</td> <td>-</td> <td>105</td> <td>LG</td> </tr> <tr> <td>105</td> <td>LG</td> <td>-</td> <td>-</td> <td>106</td> <td>LG</td> </tr> <tr> <td>106</td> <td>LG</td> <td>-</td> <td>-</td> <td>107</td> <td>LG</td> </tr> <tr> <td>107</td> <td>LG</td> <td>-</td> <td>-</td> <td>108</td> <td>LG</td> </tr> <tr> <td>108</td> <td>LG</td> <td>-</td> <td>-</td> <td>109</td> <td>LG</td> </tr> <tr> <td>109</td> <td>LG</td> <td>-</td> <td>-</td> <td>110</td> <td>LG</td> </tr> <tr> <td>110</td> <td>LG</td> <td>-</td> <td>-</td> <td>111</td> <td>LG</td> </tr> <tr> <td>111</td> <td>LG</td> <td>-</td> <td>-</td> <td>112</td> <td>LG</td> </tr> <tr> <td>112</td> <td>LG</td> <td>-</td> <td>-</td> <td>113</td> <td>LG</td> </tr> <tr> <td>113</td> <td>LG</td> <td>-</td> <td>-</td> <td>114</td> <td>GR</td> </tr> <tr> <td>114</td> <td>GR</td> <td>-</td> <td>-</td> <td>115</td> <td>P</td> </tr> <tr> <td>115</td> <td>P</td> <td>-</td> <td>-</td> <td>116</td> <td>W</td> </tr> <tr> <td>116</td> <td>W</td> <td>-</td> <td>-</td> <td>117</td> <td>SB</td> </tr> <tr> <td>117</td> <td>SB</td> <td>-</td> <td>-</td> <td>118</td> <td>LG</td> </tr> <tr> <td>118</td> <td>LG</td> <td>-</td> <td>-</td> <td>119</td> <td>LG</td> </tr> <tr> <td>119</td> <td>LG</td> <td>-</td> <td>-</td> <td>120</td> <td>LG</td> </tr> <tr> <td>120</td> <td>LG</td> <td>-</td> <td>-</td> <td>121</td> <td>BR</td> </tr> <tr> <td>121</td> <td>BR</td> <td>-</td> <td>-</td> <td>122</td> <td>G</td> </tr> <tr> <td>122</td> <td>G</td> <td>-</td> <td>-</td> <td>123</td> <td>Y</td> </tr> <tr> <td>123</td> <td>Y</td> <td>-</td> <td>-</td> <td>124</td> <td>LG</td> </tr> <tr> <td>124</td> <td>LG</td> <td>-</td> <td>-</td> <td>125</td> <td>Y</td> </tr> <tr> <td>125</td> <td>Y</td> <td>-</td> <td>-</td> <td>126</td> <td>LG</td> </tr> <tr> <td>126</td> <td>LG</td> <td>-</td> <td>-</td> <td>127</td> <td>Y</td> </tr> <tr> <td>127</td> <td>Y</td> <td>-</td> <td>-</td> <td>128</td> <td>LG</td> </tr> <tr> <td>128</td> <td>LG</td> <td>-</td> <td>-</td> <td>129</td> <td>Y</td> </tr> <tr> <td>129</td> <td>Y</td> <td>-</td> <td>-</td> <td>130</td> <td>LG</td> </tr> <tr> <td>130</td> <td>LG</td> <td>-</td> <td>-</td> <td>131</td> <td>LG</td> </tr> <tr> <td>131</td> <td>LG</td> <td>-</td> <td>-</td> <td>132</td> <td>Y</td> </tr> <tr> <td>132</td> <td>Y</td> <td>-</td> <td>-</td> <td>133</td> <td>LG</td> </tr> <tr> <td>133</td> <td>LG</td> <td>-</td> <td>-</td> <td>134</td> <td>LG</td> </tr> <tr> <td>134</td> <td>LG</td> <td>-</td> <td>-</td> <td>135</td> <td>LG</td> </tr> <tr> <td>135</td> <td>LG</td> <td>-</td> <td>-</td> <td>136</td> <td>LG</td> </tr> <tr> <td>136</td> <td>LG</td> <td>-</td> <td>-</td> <td>137</td> <td>Y</td> </tr> <tr> <td>137</td> <td>Y</td> <td>-</td> <td>-</td> <td>138</td> <td>R</td> </tr> <tr> <td>138</td> <td>R</td> <td>-</td> <td>-</td> <td>139</td> <td>B</td> </tr> <tr> <td>139</td> <td>B</td> <td>-</td> <td>-</td> <td>140</td> <td>W</td> </tr> <tr> <td>140</td> <td>W</td> <td>-</td> <td>-</td> <td>141</td> <td>LG</td> </tr> <tr> <td>141</td> <td>LG</td> <td>-</td> <td>-</td> <td>142</td> <td>SB</td> </tr> <tr> <td>142</td> <td>SB</td> <td>-</td> <td>-</td> <td>143</td> <td>G</td> </tr> <tr> <td>143</td> <td>G</td> <td>-</td> <td>-</td> <td>144</td> <td>GR</td> </tr> <tr> <td>144</td> <td>GR</td> <td>-</td> <td>-</td> <td>145</td> <td>BG</td> </tr> <tr> <td>145</td> <td>BG</td> <td>-</td> <td>-</td> <td>146</td> <td>W</td> </tr> <tr> <td>146</td> <td>W</td> <td>-</td> <td>-</td> <td>147</td> <td>P</td> </tr> <tr> <td>147</td> <td>P</td> <td>-</td> <td>-</td> <td>148</td> <td>SHEILD</td> </tr> <tr> <td>148</td> <td>SHEILD</td> <td>-</td> <td>-</td> <td>149</td> <td>L</td> </tr> <tr> <td>149</td> <td>L</td> <td>-</td> <td>-</td> <td>150</td> <td>P</td> </tr> <tr> <td>150</td> <td>P</td> <td>-</td> <td>-</td> <td>151</td> <td>W</td> </tr> <tr> <td>151</td> <td>W</td> <td>-</td> <td>-</td> </tr> </tbody> </table>		Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	83	R	-	-	84	P	84	P	-	-	85	Y	85	BG	-	-	86	BR	86	BR	-	-	87	R	87	R	-	-	88	G	88	G	-	-	89	LG	89	LG	-	-	90	LG	90	LG	-	-	91	LG	91	LG	-	-	92	LG	92	LG	-	-	93	LG	93	LG	-	-	94	LG	94	LG	-	-	95	LG	95	LG	-	-	96	LG	96	LG	-	-	97	LG	97	LG	-	-	98	LG	98	LG	-	-	99	LG	99	LG	-	-	100	LG	100	LG	-	-	101	LG	101	LG	-	-	102	LG	102	LG	-	-	103	LG	103	LG	-	-	104	LG	104	LG	-	-	105	LG	105	LG	-	-	106	LG	106	LG	-	-	107	LG	107	LG	-	-	108	LG	108	LG	-	-	109	LG	109	LG	-	-	110	LG	110	LG	-	-	111	LG	111	LG	-	-	112	LG	112	LG	-	-	113	LG	113	LG	-	-	114	GR	114	GR	-	-	115	P	115	P	-	-	116	W	116	W	-	-	117	SB	117	SB	-	-	118	LG	118	LG	-	-	119	LG	119	LG	-	-	120	LG	120	LG	-	-	121	BR	121	BR	-	-	122	G	122	G	-	-	123	Y	123	Y	-	-	124	LG	124	LG	-	-	125	Y	125	Y	-	-	126	LG	126	LG	-	-	127	Y	127	Y	-	-	128	LG	128	LG	-	-	129	Y	129	Y	-	-	130	LG	130	LG	-	-	131	LG	131	LG	-	-	132	Y	132	Y	-	-	133	LG	133	LG	-	-	134	LG	134	LG	-	-	135	LG	135	LG	-	-	136	LG	136	LG	-	-	137	Y	137	Y	-	-	138	R	138	R	-	-	139	B	139	B	-	-	140	W	140	W	-	-	141	LG	141	LG	-	-	142	SB	142	SB	-	-	143	G	143	G	-	-	144	GR	144	GR	-	-	145	BG	145	BG	-	-	146	W	146	W	-	-	147	P	147	P	-	-	148	SHEILD	148	SHEILD	-	-	149	L	149	L	-	-	150	P	150	P	-	-	151	W	151	W	-	-
Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]																																																																																																																																																																																																																																																																																																																																																																																																																																																		
45	G	-	-	1	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
46	V	-	-	2	B																																																																																																																																																																																																																																																																																																																																																																																																																																																		
Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]																																																																																																																																																																																																																																																																																																																																																																																																																																																		
83	R	-	-	84	P																																																																																																																																																																																																																																																																																																																																																																																																																																																		
84	P	-	-	85	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
85	BG	-	-	86	BR																																																																																																																																																																																																																																																																																																																																																																																																																																																		
86	BR	-	-	87	R																																																																																																																																																																																																																																																																																																																																																																																																																																																		
87	R	-	-	88	G																																																																																																																																																																																																																																																																																																																																																																																																																																																		
88	G	-	-	89	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
89	LG	-	-	90	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
90	LG	-	-	91	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
91	LG	-	-	92	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
92	LG	-	-	93	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
93	LG	-	-	94	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
94	LG	-	-	95	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
95	LG	-	-	96	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
96	LG	-	-	97	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
97	LG	-	-	98	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
98	LG	-	-	99	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
99	LG	-	-	100	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
100	LG	-	-	101	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
101	LG	-	-	102	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
102	LG	-	-	103	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
103	LG	-	-	104	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
104	LG	-	-	105	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
105	LG	-	-	106	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
106	LG	-	-	107	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
107	LG	-	-	108	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
108	LG	-	-	109	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
109	LG	-	-	110	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
110	LG	-	-	111	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
111	LG	-	-	112	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
112	LG	-	-	113	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
113	LG	-	-	114	GR																																																																																																																																																																																																																																																																																																																																																																																																																																																		
114	GR	-	-	115	P																																																																																																																																																																																																																																																																																																																																																																																																																																																		
115	P	-	-	116	W																																																																																																																																																																																																																																																																																																																																																																																																																																																		
116	W	-	-	117	SB																																																																																																																																																																																																																																																																																																																																																																																																																																																		
117	SB	-	-	118	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
118	LG	-	-	119	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
119	LG	-	-	120	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
120	LG	-	-	121	BR																																																																																																																																																																																																																																																																																																																																																																																																																																																		
121	BR	-	-	122	G																																																																																																																																																																																																																																																																																																																																																																																																																																																		
122	G	-	-	123	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
123	Y	-	-	124	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
124	LG	-	-	125	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
125	Y	-	-	126	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
126	LG	-	-	127	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
127	Y	-	-	128	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
128	LG	-	-	129	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
129	Y	-	-	130	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
130	LG	-	-	131	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
131	LG	-	-	132	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
132	Y	-	-	133	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
133	LG	-	-	134	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
134	LG	-	-	135	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
135	LG	-	-	136	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
136	LG	-	-	137	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
137	Y	-	-	138	R																																																																																																																																																																																																																																																																																																																																																																																																																																																		
138	R	-	-	139	B																																																																																																																																																																																																																																																																																																																																																																																																																																																		
139	B	-	-	140	W																																																																																																																																																																																																																																																																																																																																																																																																																																																		
140	W	-	-	141	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
141	LG	-	-	142	SB																																																																																																																																																																																																																																																																																																																																																																																																																																																		
142	SB	-	-	143	G																																																																																																																																																																																																																																																																																																																																																																																																																																																		
143	G	-	-	144	GR																																																																																																																																																																																																																																																																																																																																																																																																																																																		
144	GR	-	-	145	BG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
145	BG	-	-	146	W																																																																																																																																																																																																																																																																																																																																																																																																																																																		
146	W	-	-	147	P																																																																																																																																																																																																																																																																																																																																																																																																																																																		
147	P	-	-	148	SHEILD																																																																																																																																																																																																																																																																																																																																																																																																																																																		
148	SHEILD	-	-	149	L																																																																																																																																																																																																																																																																																																																																																																																																																																																		
149	L	-	-	150	P																																																																																																																																																																																																																																																																																																																																																																																																																																																		
150	P	-	-	151	W																																																																																																																																																																																																																																																																																																																																																																																																																																																		
151	W	-	-																																																																																																																																																																																																																																																																																																																																																																																																																																																				
<table border="1"> <thead> <tr> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>39</td> <td>P</td> <td>-</td> <td>-</td> <td>40</td> <td>L</td> </tr> <tr> <td>40</td> <td>L</td> <td>-</td> <td>-</td> <td>41</td> <td>B/W</td> </tr> <tr> <td>41</td> <td>B/W</td> <td>-</td> <td>-</td> <td>42</td> <td>Y</td> </tr> <tr> <td>42</td> <td>Y</td> <td>-</td> <td>-</td> <td>43</td> <td>SB</td> </tr> <tr> <td>43</td> <td>SB</td> <td>-</td> <td>-</td> <td>44</td> <td>W</td> </tr> <tr> <td>44</td> <td>W</td> <td>-</td> <td>-</td> </tr> </tbody> </table>		Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	39	P	-	-	40	L	40	L	-	-	41	B/W	41	B/W	-	-	42	Y	42	Y	-	-	43	SB	43	SB	-	-	44	W	44	W	-	-	<table border="1"> <thead> <tr> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> <th>Terminal Color Of No.</th> <th>Wire Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>45</td> <td>R</td> <td>-</td> <td>-</td> <td>46</td> <td>LG</td> </tr> <tr> <td>46</td> <td>LG</td> <td>-</td> <td>-</td> <td>47</td> <td>P</td> </tr> <tr> <td>47</td> <td>P</td> <td>-</td> <td>-</td> <td>48</td> <td>SHEILD</td> </tr> <tr> <td>48</td> <td>SHEILD</td> <td>-</td> <td>-</td> <td>49</td> <td>L</td> </tr> <tr> <td>49</td> <td>L</td> <td>-</td> <td>-</td> <td>50</td> <td>P</td> </tr> <tr> <td>50</td> <td>P</td> <td>-</td> <td>-</td> <td>51</td> <td>W</td> </tr> <tr> <td>51</td> <td>W</td> <td>-</td> <td>-</td> </tr> </tbody> </table>		Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	45	R	-	-	46	LG	46	LG	-	-	47	P	47	P	-	-	48	SHEILD	48	SHEILD	-	-	49	L	49	L	-	-	50	P	50	P	-	-	51	W	51	W	-	-																																																																																																																																																																																																																																																																																																																																																														
Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]																																																																																																																																																																																																																																																																																																																																																																																																																																																		
39	P	-	-	40	L																																																																																																																																																																																																																																																																																																																																																																																																																																																		
40	L	-	-	41	B/W																																																																																																																																																																																																																																																																																																																																																																																																																																																		
41	B/W	-	-	42	Y																																																																																																																																																																																																																																																																																																																																																																																																																																																		
42	Y	-	-	43	SB																																																																																																																																																																																																																																																																																																																																																																																																																																																		
43	SB	-	-	44	W																																																																																																																																																																																																																																																																																																																																																																																																																																																		
44	W	-	-																																																																																																																																																																																																																																																																																																																																																																																																																																																				
Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]																																																																																																																																																																																																																																																																																																																																																																																																																																																		
45	R	-	-	46	LG																																																																																																																																																																																																																																																																																																																																																																																																																																																		
46	LG	-	-	47	P																																																																																																																																																																																																																																																																																																																																																																																																																																																		
47	P	-	-	48	SHEILD																																																																																																																																																																																																																																																																																																																																																																																																																																																		
48	SHEILD	-	-	49	L																																																																																																																																																																																																																																																																																																																																																																																																																																																		
49	L	-	-	50	P																																																																																																																																																																																																																																																																																																																																																																																																																																																		
50	P	-	-	51	W																																																																																																																																																																																																																																																																																																																																																																																																																																																		
51	W	-	-																																																																																																																																																																																																																																																																																																																																																																																																																																																				

JRLWD7860GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

DAYTIME RUNNING LIGHT SYSTEM											
Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
81	P	-	21	R	-	31	BR	-	21	R	-
82	G	-	31	BR	-	22	Y	-	31	BR	-
83	V	-	32	Y	-	36	SB	-	32	Y	-
84	L	-	37	Y	-	38	LG	-	37	Y	-
85	BG	-	39	SB	-	40	W	-	39	SB	-
86	LG	-	41	LG	-	42	R	-	40	W	-
87	R	-	43	G	-	44	G	-	41	LG	-
88	P	-	44	R	-	45	O	-	42	R	-
91	W	-	46	G	-	47	LG	-	43	G	-
92	L	-	58	SHIELD	-	59	L	-	44	R	-
93	G	-	60	LG	-	61	GR	-	45	O	-
94	Y	-	62	V	-	63	V	-	46	G	-
95	BR	-	64	LG	-	65	W	-	47	LG	-
96	GR	-	66	Y	-	67	W	-	48	W	-
99	LG	-	68	BR	-	69	P	-	49	W	-
100	BG	-	69	BR	-	70	R	-	50	W	-
Connector No. E180											
Connector Name WIRE TO WIRE											
Connector Type R308FB-PR											
Connector No. M1											
Connector Name FUSE BLOCK (JB)											
Connector Type NS36FVN-M2											
											
Terminal Color Of Wire No. Signal Name [Specification]											
1	LG	-	2	R	-	3	Y	-	4	LG	-
2	R	-	4	BG	-	5	B	-	6	LG	-
4	BG	-	6	L	-	7	B	-	8	P	-
5	B	-	8	R	-	9	B	-	10	SB	-
6	L	-	9B	SB	-	11	GR	-	12	R	-
8	B	-				13	L	-	14	G	-
Connector No. M2											
Connector Name FUSE BLOCK (JB)											
Connector Type NS10FVN-CS											
											
Terminal Color Of Wire No. Signal Name [Specification]											
1B	P	-	2B	P	-	3B	P	-	4B	P	-
2B	P	-	3B	P	-	4B	P	-	5B	P	-
3B	P	-	4B	P	-	5B	P	-	6B	P	-
4B	P	-	5B	P	-	6B	P	-	7B	P	-
5B	P	-	6B	P	-	7B	P	-	8B	P	-
6B	P	-	7B	P	-	8B	P	-	9B	P	-
7B	P	-	8B	P	-	9B	P	-	10B	P	-
8B	P	-	9B	P	-	10B	P	-	11B	P	-
9B	P	-	10B	P	-	11B	P	-	12B	P	-
10B	P	-	11B	P	-	12B	P	-	13B	P	-
11B	P	-	12B	P	-	13B	P	-	14B	P	-
12B	P	-	13B	P	-	14B	P	-	15B	P	-
13B	P	-	14B	P	-	15B	P	-	16B	P	-
14B	P	-	15B	P	-	16B	P	-	17B	P	-
15B	P	-	16B	P	-	17B	P	-	18B	P	-
16B	P	-	17B	P	-	18B	P	-	19B	P	-
17B	P	-	18B	P	-	19B	P	-	20B	P	-
18B	P	-	19B	P	-	20B	P	-			
Connector No. M3											
Connector Name FUSE BLOCK (JB)											
Connector Type NS12FW-CS											
											
Terminal Color Of Wire No. Signal Name [Specification]											
1A	P	-	2A	P	-	3A	P	-	4A	P	-
2A	P	-	3A	P	-	4A	P	-	5A	P	-
3A	P	-	4A	P	-	5A	P	-	6A	P	-
4A	P	-	5A	P	-	6A	P	-	7A	P	-
5A	P	-	6A	P	-	7A	P	-	8A	P	-
6A	P	-	7A	P	-	8A	P	-	9A	P	-
7A	P	-	8A	P	-	9A	P	-	10A	P	-
8A	P	-	9A	P	-	10A	P	-	11A	P	-
9A	P	-	10A	P	-	11A	P	-	12A	P	-
10A	P	-	11A	P	-	12A	P	-	13A	P	-
11A	P	-	12A	P	-	13A	P	-	14A	P	-
12A	P	-	13A	P	-	14A	P	-	15A	P	-
13A	P	-	14A	P	-	15A	P	-	16A	P	-
14A	P	-	15A	P	-	16A	P	-	17A	P	-
15A	P	-	16A	P	-	17A	P	-	18A	P	-
16A	P	-	17A	P	-	18A	P	-	19A	P	-
17A	P	-	18A	P	-	19A	P	-	20A	P	-
18A	P	-	19A	P	-	20A	P	-			



JRLWD7861GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

DAYTIME RUNNING LIGHT SYSTEM

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M22</td></tr> <tr><td>Connector Name</td><td>KEY SLOT</td></tr> <tr><td>Connector Type</td><td>TH16FW/NH</td></tr> </table>  <p style="text-align: center;">H.S.</p>	Connector No.	M22	Connector Name	KEY SLOT	Connector Type	TH16FW/NH	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M33</td></tr> <tr><td>Connector Name</td><td>COMBINATION SWITCH</td></tr> <tr><td>Connector Type</td><td>TH16FW/NH</td></tr> </table>  <p style="text-align: center;">H.S.</p>	Connector No.	M33	Connector Name	COMBINATION SWITCH	Connector Type	TH16FW/NH	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of</td><td>No.</td><td>Signal Name [Specification]</td><td>Wire</td></tr> <tr><td>1</td><td>P</td><td>FR WASHER (-)</td><td>V</td></tr> <tr><td>2</td><td>GR</td><td>OUTPUT 4</td><td>O</td></tr> <tr><td>3</td><td>W</td><td>SB</td><td>L</td></tr> <tr><td>5</td><td>Y</td><td>DATA</td><td>GND</td></tr> <tr><td>6</td><td>B</td><td>ILL. BAT</td><td>B</td></tr> <tr><td>6</td><td>LG</td><td>ILL.</td><td>V</td></tr> <tr><td>7</td><td>B</td><td>GROUND</td><td>O</td></tr> <tr><td>9</td><td>R</td><td>KEY SWITCH SIGNAL</td><td>Y</td></tr> <tr><td>10</td><td>R</td><td>INPUT 2</td><td>R</td></tr> <tr><td>11</td><td>LG</td><td>INPUT 4</td><td>BR</td></tr> <tr><td>12</td><td>P</td><td>INPUT 1</td><td>L</td></tr> <tr><td>13</td><td>BR</td><td>OUTPUT 1</td><td>L</td></tr> <tr><td>14</td><td>G</td><td>INPUT 5</td><td>G</td></tr> <tr><td></td><td></td><td>OUTPUT 2</td><td>R</td></tr> </table>	Terminal Color Of	No.	Signal Name [Specification]	Wire	1	P	FR WASHER (-)	V	2	GR	OUTPUT 4	O	3	W	SB	L	5	Y	DATA	GND	6	B	ILL. BAT	B	6	LG	ILL.	V	7	B	GROUND	O	9	R	KEY SWITCH SIGNAL	Y	10	R	INPUT 2	R	11	LG	INPUT 4	BR	12	P	INPUT 1	L	13	BR	OUTPUT 1	L	14	G	INPUT 5	G			OUTPUT 2	R	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of</td><td>No.</td><td>Signal Name [Specification]</td><td>Wire</td></tr> <tr><td>1</td><td>P</td><td>BATTERY POWER SUPPLY</td><td>V</td></tr> <tr><td>2</td><td>GR</td><td>IGNITION SIGNAL</td><td>O</td></tr> <tr><td>3</td><td>W</td><td>VEHICLE SPEED SIGNAL (2-PULSE)</td><td>L</td></tr> <tr><td>4</td><td>Y</td><td>VEHICLE SPEED SIGNAL (PULSE) [For Mexico]</td><td>V</td></tr> <tr><td>4</td><td>Y</td><td>VEHICLE SPEED SIGNAL (PULSE) [Except in Mexico]</td><td>Y</td></tr> <tr><td>5</td><td>B</td><td>ILLUMINATION CONTROL SIGNAL</td><td>B</td></tr> <tr><td>6</td><td>LG</td><td>OUTPUT 5</td><td>R</td></tr> <tr><td>7</td><td>B</td><td>INPUT 2</td><td>BR</td></tr> <tr><td>8</td><td>LG</td><td>INPUT 4</td><td>BR</td></tr> <tr><td>9</td><td>LG</td><td>INPUT 1</td><td>L</td></tr> <tr><td>10</td><td>P</td><td>OUTPUT 1</td><td>L</td></tr> <tr><td>11</td><td>BR</td><td>INPUT 5</td><td>G</td></tr> <tr><td>12</td><td>BR</td><td>OUTPUT 2</td><td>R</td></tr> </table>	Terminal Color Of	No.	Signal Name [Specification]	Wire	1	P	BATTERY POWER SUPPLY	V	2	GR	IGNITION SIGNAL	O	3	W	VEHICLE SPEED SIGNAL (2-PULSE)	L	4	Y	VEHICLE SPEED SIGNAL (PULSE) [For Mexico]	V	4	Y	VEHICLE SPEED SIGNAL (PULSE) [Except in Mexico]	Y	5	B	ILLUMINATION CONTROL SIGNAL	B	6	LG	OUTPUT 5	R	7	B	INPUT 2	BR	8	LG	INPUT 4	BR	9	LG	INPUT 1	L	10	P	OUTPUT 1	L	11	BR	INPUT 5	G	12	BR	OUTPUT 2	R	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of</td><td>No.</td><td>Signal Name [Specification]</td><td>Wire</td></tr> <tr><td>1</td><td>P</td><td>ACC POWER SUPPLY</td><td>G</td></tr> <tr><td>2</td><td>GR</td><td>S-MODE SWITCH SIGNAL</td><td>BR</td></tr> <tr><td>3</td><td>W</td><td>PASSENGER SEAT BELT WARNING SIGNAL [For Mexico]</td><td>L</td></tr> <tr><td>4</td><td>Y</td><td>PASSENGER SEAT BELT WARNING SIGNAL [Except in Mexico]</td><td>Y</td></tr> <tr><td>5</td><td>B</td><td>AIR BAG SIGNAL</td><td>R</td></tr> <tr><td>6</td><td>LG</td><td>GROUND</td><td>V</td></tr> <tr><td>7</td><td>B</td><td>GROUND</td><td>BR</td></tr> <tr><td>8</td><td>LG</td><td>GROUND</td><td>L</td></tr> <tr><td>9</td><td>P</td><td>FUEL LEVEL SENSOR SIGNAL</td><td>GND</td></tr> <tr><td>10</td><td>Y</td><td>FUEL LEVEL SENSOR SIGNAL</td><td>BR</td></tr> <tr><td>11</td><td>BR</td><td>FUEL LEVEL SENSOR SIGNAL</td><td>L</td></tr> <tr><td>12</td><td>LG</td><td>FUEL LEVEL SENSOR SIGNAL</td><td>Y</td></tr> <tr><td>13</td><td>LG</td><td>FUEL LEVEL SENSOR SIGNAL</td><td>R</td></tr> <tr><td>14</td><td>P</td><td>FUEL LEVEL SENSOR SIGNAL</td><td>BR</td></tr> <tr><td>15</td><td>Y</td><td>FUEL LEVEL SENSOR SIGNAL</td><td>L</td></tr> <tr><td>16</td><td>Y</td><td>FUEL LEVEL SENSOR SIGNAL</td><td>Y</td></tr> </table>	Terminal Color Of	No.	Signal Name [Specification]	Wire	1	P	ACC POWER SUPPLY	G	2	GR	S-MODE SWITCH SIGNAL	BR	3	W	PASSENGER SEAT BELT WARNING SIGNAL [For Mexico]	L	4	Y	PASSENGER SEAT BELT WARNING SIGNAL [Except in Mexico]	Y	5	B	AIR BAG SIGNAL	R	6	LG	GROUND	V	7	B	GROUND	BR	8	LG	GROUND	L	9	P	FUEL LEVEL SENSOR SIGNAL	GND	10	Y	FUEL LEVEL SENSOR SIGNAL	BR	11	BR	FUEL LEVEL SENSOR SIGNAL	L	12	LG	FUEL LEVEL SENSOR SIGNAL	Y	13	LG	FUEL LEVEL SENSOR SIGNAL	R	14	P	FUEL LEVEL SENSOR SIGNAL	BR	15	Y	FUEL LEVEL SENSOR SIGNAL	L	16	Y	FUEL LEVEL SENSOR SIGNAL	Y	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal Color Of</td><td>No.</td><td>Signal Name [Specification]</td><td>Wire</td></tr> <tr><td>1</td><td>P</td><td>AMB. SENSORS SIGNAL</td><td>V</td></tr> <tr><td>2</td><td>GR</td><td>AC/AUTO/AWP CONNECTION RECOGNITION SIGNAL</td><td>BR</td></tr> <tr><td>3</td><td>W</td><td>AMBIENT SENSOR GROUND</td><td>L</td></tr> <tr><td>4</td><td>Y</td><td>CAN-H</td><td>Y</td></tr> <tr><td>5</td><td>B</td><td>CAN-L</td><td>R</td></tr> <tr><td>6</td><td>LG</td><td>GROUND</td><td>BR</td></tr> <tr><td>7</td><td>B</td><td>GROUND</td><td>L</td></tr> <tr><td>8</td><td>LG</td><td>GROUND</td><td>Y</td></tr> <tr><td>9</td><td>P</td><td>MANUAL MODE SHIFT UP SIGNAL</td><td>BR</td></tr> <tr><td>10</td><td>Y</td><td>MANUAL MODE SHIFT DOWN SIGNAL</td><td>L</td></tr> <tr><td>11</td><td>BR</td><td>MANUAL MODE SHIFT UP SIGNAL</td><td>Y</td></tr> <tr><td>12</td><td>LG</td><td>MANUAL MODE SHIFT DOWN SIGNAL</td><td>R</td></tr> <tr><td>13</td><td>LG</td><td>MANUAL MODE SIGNAL</td><td>BR</td></tr> <tr><td>14</td><td>P</td><td>MANUAL MODE SIGNAL</td><td>L</td></tr> </table>	Terminal Color Of	No.	Signal Name [Specification]	Wire	1	P	AMB. SENSORS SIGNAL	V	2	GR	AC/AUTO/AWP CONNECTION RECOGNITION SIGNAL	BR	3	W	AMBIENT SENSOR GROUND	L	4	Y	CAN-H	Y	5	B	CAN-L	R	6	LG	GROUND	BR	7	B	GROUND	L	8	LG	GROUND	Y	9	P	MANUAL MODE SHIFT UP SIGNAL	BR	10	Y	MANUAL MODE SHIFT DOWN SIGNAL	L	11	BR	MANUAL MODE SHIFT UP SIGNAL	Y	12	LG	MANUAL MODE SHIFT DOWN SIGNAL	R	13	LG	MANUAL MODE SIGNAL	BR	14	P	MANUAL MODE SIGNAL	L
Connector No.	M22																																																																																																																																																																																																																																																																				
Connector Name	KEY SLOT																																																																																																																																																																																																																																																																				
Connector Type	TH16FW/NH																																																																																																																																																																																																																																																																				
Connector No.	M33																																																																																																																																																																																																																																																																				
Connector Name	COMBINATION SWITCH																																																																																																																																																																																																																																																																				
Connector Type	TH16FW/NH																																																																																																																																																																																																																																																																				
Terminal Color Of	No.	Signal Name [Specification]	Wire																																																																																																																																																																																																																																																																		
1	P	FR WASHER (-)	V																																																																																																																																																																																																																																																																		
2	GR	OUTPUT 4	O																																																																																																																																																																																																																																																																		
3	W	SB	L																																																																																																																																																																																																																																																																		
5	Y	DATA	GND																																																																																																																																																																																																																																																																		
6	B	ILL. BAT	B																																																																																																																																																																																																																																																																		
6	LG	ILL.	V																																																																																																																																																																																																																																																																		
7	B	GROUND	O																																																																																																																																																																																																																																																																		
9	R	KEY SWITCH SIGNAL	Y																																																																																																																																																																																																																																																																		
10	R	INPUT 2	R																																																																																																																																																																																																																																																																		
11	LG	INPUT 4	BR																																																																																																																																																																																																																																																																		
12	P	INPUT 1	L																																																																																																																																																																																																																																																																		
13	BR	OUTPUT 1	L																																																																																																																																																																																																																																																																		
14	G	INPUT 5	G																																																																																																																																																																																																																																																																		
		OUTPUT 2	R																																																																																																																																																																																																																																																																		
Terminal Color Of	No.	Signal Name [Specification]	Wire																																																																																																																																																																																																																																																																		
1	P	BATTERY POWER SUPPLY	V																																																																																																																																																																																																																																																																		
2	GR	IGNITION SIGNAL	O																																																																																																																																																																																																																																																																		
3	W	VEHICLE SPEED SIGNAL (2-PULSE)	L																																																																																																																																																																																																																																																																		
4	Y	VEHICLE SPEED SIGNAL (PULSE) [For Mexico]	V																																																																																																																																																																																																																																																																		
4	Y	VEHICLE SPEED SIGNAL (PULSE) [Except in Mexico]	Y																																																																																																																																																																																																																																																																		
5	B	ILLUMINATION CONTROL SIGNAL	B																																																																																																																																																																																																																																																																		
6	LG	OUTPUT 5	R																																																																																																																																																																																																																																																																		
7	B	INPUT 2	BR																																																																																																																																																																																																																																																																		
8	LG	INPUT 4	BR																																																																																																																																																																																																																																																																		
9	LG	INPUT 1	L																																																																																																																																																																																																																																																																		
10	P	OUTPUT 1	L																																																																																																																																																																																																																																																																		
11	BR	INPUT 5	G																																																																																																																																																																																																																																																																		
12	BR	OUTPUT 2	R																																																																																																																																																																																																																																																																		
Terminal Color Of	No.	Signal Name [Specification]	Wire																																																																																																																																																																																																																																																																		
1	P	ACC POWER SUPPLY	G																																																																																																																																																																																																																																																																		
2	GR	S-MODE SWITCH SIGNAL	BR																																																																																																																																																																																																																																																																		
3	W	PASSENGER SEAT BELT WARNING SIGNAL [For Mexico]	L																																																																																																																																																																																																																																																																		
4	Y	PASSENGER SEAT BELT WARNING SIGNAL [Except in Mexico]	Y																																																																																																																																																																																																																																																																		
5	B	AIR BAG SIGNAL	R																																																																																																																																																																																																																																																																		
6	LG	GROUND	V																																																																																																																																																																																																																																																																		
7	B	GROUND	BR																																																																																																																																																																																																																																																																		
8	LG	GROUND	L																																																																																																																																																																																																																																																																		
9	P	FUEL LEVEL SENSOR SIGNAL	GND																																																																																																																																																																																																																																																																		
10	Y	FUEL LEVEL SENSOR SIGNAL	BR																																																																																																																																																																																																																																																																		
11	BR	FUEL LEVEL SENSOR SIGNAL	L																																																																																																																																																																																																																																																																		
12	LG	FUEL LEVEL SENSOR SIGNAL	Y																																																																																																																																																																																																																																																																		
13	LG	FUEL LEVEL SENSOR SIGNAL	R																																																																																																																																																																																																																																																																		
14	P	FUEL LEVEL SENSOR SIGNAL	BR																																																																																																																																																																																																																																																																		
15	Y	FUEL LEVEL SENSOR SIGNAL	L																																																																																																																																																																																																																																																																		
16	Y	FUEL LEVEL SENSOR SIGNAL	Y																																																																																																																																																																																																																																																																		
Terminal Color Of	No.	Signal Name [Specification]	Wire																																																																																																																																																																																																																																																																		
1	P	AMB. SENSORS SIGNAL	V																																																																																																																																																																																																																																																																		
2	GR	AC/AUTO/AWP CONNECTION RECOGNITION SIGNAL	BR																																																																																																																																																																																																																																																																		
3	W	AMBIENT SENSOR GROUND	L																																																																																																																																																																																																																																																																		
4	Y	CAN-H	Y																																																																																																																																																																																																																																																																		
5	B	CAN-L	R																																																																																																																																																																																																																																																																		
6	LG	GROUND	BR																																																																																																																																																																																																																																																																		
7	B	GROUND	L																																																																																																																																																																																																																																																																		
8	LG	GROUND	Y																																																																																																																																																																																																																																																																		
9	P	MANUAL MODE SHIFT UP SIGNAL	BR																																																																																																																																																																																																																																																																		
10	Y	MANUAL MODE SHIFT DOWN SIGNAL	L																																																																																																																																																																																																																																																																		
11	BR	MANUAL MODE SHIFT UP SIGNAL	Y																																																																																																																																																																																																																																																																		
12	LG	MANUAL MODE SHIFT DOWN SIGNAL	R																																																																																																																																																																																																																																																																		
13	LG	MANUAL MODE SIGNAL	BR																																																																																																																																																																																																																																																																		
14	P	MANUAL MODE SIGNAL	L																																																																																																																																																																																																																																																																		


JRLWD7862GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

DAYTIME RUNNING LIGHT SYSTEM



JRLWD7863GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

DAYTIME RUNNING LIGHT SYSTEM		
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	R	KEY SLOT SW
123	W	[GNF]6
124	LG	PASSENGER DOOR SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	REAR DEFROGGER SW
132	V	SW SW & SET TOR CU COMM [Steering wheel]
132	Y	POWER WINDOW SW [COMM] (Sport models)
133	G	PUSH BUTTON IGNITION SW [LL POWER
134	GR	LOCK IND
137	P	RECEIVER & SENSOR GND
138	V	RECEIVER & SENSOR POWER SUPPLY
139	L	TIRE PRESS RECEIV COMM
140	G	FIN POSITION
141	Y	SECURITY INDICATOR
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT

JRLWD7864GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

Wiring Diagram

INFOID:0000000010840550

TURN SIGNAL AND HAZARD WARNING LAMPS



2014/05/12


JRLWD7874GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	T800FW-C516-TM4
	



Terminal Color Of No.	Wire Signal Name [Specification]	Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Signal Name [Specification]
1	G	-	1	G	-
2	BG	-	2	R	- [Coupe models]
3	Y	-	2	V	- [Roaster models]
4	W	-	3	B	-
6	V	-	4	LG	-
7	LG	-	6	BG	-
8	GR	-	68	SHIELD	-
9	SB	-	69	R	-
11	Y	-	70	G	-
12	W	-	71	V	-
13	BR	-	72	P	-
14	LG	-	73	BR	-
15	B	-	74	GR	-
16	V	-	75	BG	-
17	R	-	80	Y	-
18	B	-	81	R	-
20	SB	-	82	B	-
21	G	-	83	GR	-
22	GR	-	84	G	- [Coupe models]
23	V	-	84	L	- [Roaster models]
24	BG	-	85	LG	-
25	L	-	86	V	-
26	P	-	87	BR	-
27	W	-	88	GR	-
28	SHIELD	-	93	Y	-
31	W	-	94	G	- [Roaster models]
32	B	-	94	L	- [Coupe models]
33	P	- [Coupe models]	95	GR	- [Coupe models]
33	W	- [Roaster models]	95	LG	- [Roaster models]
34	R	-	96	L	-
35	B	- [Roaster models]	97	Y	-
35	W	- [Coupe models]	98	W	- [Coupe models]
36	B	-	98	YB	- [Roaster models]
40	Y	-	99	LG	-
41	L	-	100	B	-

Connector No.	B60
Connector Name	REAR COMBINATION LAMP LH
Connector Type	RS50FFGY-PR



Connector No.	E24
Connector Name	SIDE TURN SIGNAL LAMP RH
Connector Type	RS50FFGY



Terminal Color Of No.	Wire Signal Name [Specification]	Signal Name [Specification]	Terminal Color Of No.	Wire Signal Name [Specification]	Signal Name [Specification]
1	G	-	1	G	-
2	BG	-	2	R	- [Coupe models]
3	Y	-	2	V	- [Roaster models]
4	W	-	3	B	-
6	V	-	4	LG	-
7	LG	-	6	BG	-
8	GR	-	68	SHIELD	-
9	SB	-	69	R	-
11	Y	-	70	G	-
12	W	-	71	V	-
13	BR	-	72	P	-
14	LG	-	73	BR	-
15	B	-	74	GR	-
16	V	-	75	BG	-
17	R	-	80	Y	-
18	B	-	81	R	-
20	SB	-	82	B	-
21	G	-	83	GR	-
22	GR	-	84	G	- [Coupe models]
23	V	-	84	L	- [Roaster models]
24	BG	-	85	LG	-
25	L	-	86	V	-
26	P	-	87	BR	-
27	W	-	88	GR	-
28	SHIELD	-	93	Y	-
31	W	-	94	G	- [Roaster models]
32	B	-	94	L	- [Coupe models]
33	P	- [Coupe models]	95	GR	- [Coupe models]
33	W	- [Roaster models]	95	LG	- [Roaster models]
34	R	-	96	L	-
35	B	- [Roaster models]	97	Y	-
35	W	- [Coupe models]	98	W	- [Coupe models]
36	B	-	98	YB	- [Roaster models]
40	Y	-	99	LG	-
41	L	-	100	B	-



JRLWD7875GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No. E55

Connector Name SIDE TURN SIGNAL LAMP LH


Connector Type R/K02FGY



Connector No. E106

Connector Name WIRE TO WIRE

Connector Type T/R05FW/CS16/TM4



Connector No. E106

Connector Name WIRE TO WIRE

Connector Type T/R05FW/CS16/TM4



Terminal Color Of

Wire No. Signal Name [Specification]

1 G - [Rearster models]

1 GR - [Coupe models]

2 B -

Terminal Color Of

Wire No. Signal Name [Specification]

82 G

83 V

85 BG

86 LG

87 R

89 P

91 W

92 L

93 G

94 Y

96 Y

97 BR

98 GR

99 LG

100 BG

Terminal Color Of

Wire No. Signal Name [Specification]

11 V

12 R

13 L

14 GR

15 P

16 W

17 SB

20 LG

21 BR - [Coupe models]

21 G - [Roaster models]

31 L

32 Y

36 V

37 Y

38 R

39 B

40 W

41 LG

42 SB

43 G

44 GR - Except for roaster models with M/T] [Roaster models with M/T]

45 BG

46 W

47 P

58 SHIELD

59 L

70 P

80 W

81 P

Connector No. E106

Connector Name FUSE BLOCK (J/E)

Connector Type NS105FW/VA2



Connector No. E106

Connector Name FUSE BLOCK (J/E)

Connector Type NS105FW/CS



Connector No. E106

Connector Name FUSE BLOCK (J/E)

Connector Type NS105FW/CS



Connector No. E106

Connector Name FUSE BLOCK (J/E)

Connector Type NS105FW/CS



Connector No. E106

Connector Name FUSE BLOCK (J/E)

Connector Type NS105FW/CS



JRLWD7876GB

O

M

Z

P

EXL

P

K

I

T

M

N

F

G

H

D

C

B

A


TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	T80MMW-CS16-TM4



Terminal Color Of Wire No.	Signal Name [Specification]
1 Y	-
3 L	-
4 L	-
7 B	-
8 P	-
9 B	-
11 GR	-
12 R	-
13 L	-
14 G	-
15 P	-
16 W	-
17 BR	-
20 GR	-
21 R	-
31 BR	-
32 V	-
36 SB	-
37 Y	-
38 LG	-
39 SB	-
40 W	-
41 LG	-
42 R	-
43 G	-
44 G	- [With A/T] - [With M/T]
45 O	-
46 G	-
47 BR	-
58 SHIELD	-
59 L	-
70 R	-
80 LG	-
81 GR	-
82 V	-

Connector No.	M7
Connector Name	WIRE TO WIRE



[With A/T]

- [With M/T]

Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
1 BR	-	3 R	- [Coupe models]
2 O	-	4 G	- [Roaster models]
3 LG	-	5 B	-
4 O	-	6 LG	-
5 LG	-	7 V	-
6 V	-	8 G	-
7 LG	-	10 P	- [Roaster models]
8 SB	-	11 V	- [Coupe models]
9 GR	-	12 P	-
11 Y	-	13 BR	-
12 V	-	14 GR	-
13 BR	-	15 O	-
14 V	-	16 Y	-
15 B	-	17 W	-
16 V	-	18 R	-
17 R	-	19 SB	-
18 L	-	20 SB	-
19 G	-	21 G	-
20 V	-	22 GR	-


JRLWD7877GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

TURN SIGNAL AND HAZARD WARNING LAMPS	
Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH3FVN-NH
Terminal Color Of No.	10 L 12 G 15 L 16 R 17 B 18 V 19 G 20 GR 21 L 22 P 23 B 24 Y
Wire	COMMUNICATION SIGNAL (TRIPLE METER-METER) SMODE SWITCH SIGNAL ACC POWER SUPPLY Y AIR BAG SIGNAL GROUND AMBIENT SENSOR SIGNAL AC AUTO COMP. CONNECTION RECOGNITION SIGNAL AMBIENT SENSOR GROUND CANH CANL GROUND FUEL LEVEL SENSOR GROUND



Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	W
1	P	2	W
2	GR	3	Y

Connector No.: M118
Connector Name: BCM (BODY CONTROL MODULE)
Connector Type: M03FBL-C

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	V
19	G	20	V
21	GR	23	L
22	L	23	Y
23	P	24	O
24	Y	25	LG

Connector No.: M120
Connector Name: BCM (BODY CONTROL MODULE)
Connector Type: NSTFVN-CS

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	V
20	V	21	W
23	L	24	O
25	LG	30	R

Connector No.: M120
Connector Name: BCM (BODY CONTROL MODULE)
Connector Type: NSTFVN-CS

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	W
1	W	2	W
2	Y	3	Y

Connector No.: M118
Connector Name: BCM (BODY CONTROL MODULE)
Connector Type: M03FBL-C



Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	V
1	W	2	Y
2	Y	3	Y

Connector No.: M119
Connector Name: BCM (BODY CONTROL MODULE)
Connector Type: NSTFVN-CS

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	V
1	W	2	Y
2	Y	3	Y

Connector No.: M122
Connector Name: BCM (BODY CONTROL MODULE)
Connector Type: T40FBN-H

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	V
1	W	2	Y
2	Y	3	Y

Connector No.: M122
Connector Name: BCM (BODY CONTROL MODULE)
Connector Type: T40FBN-H

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	W
1	W	2	Y
2	Y	3	Y




Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	W
1	W	2	Y
2	Y	3	Y

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	W
1	W	2	Y
2	Y	3	Y

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	W
1	W	2	Y
2	Y	3	Y

Terminal Color Of		Signal Name [Specification]	
No.	Wire	1	W
1	W	2	Y
2	Y	3	Y



A B C D E F G H I J K L M N O P Q R S T EXL Z O P

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Signal Name [Specification]	Terminal No.	Signal Name [Specification]
90 P	CANL	141 Y	SECURITY INDICATOR
91 L	CANH	142 O	COMBI SW OUTPUT 5
92 LG	KEY SLOT ILL	143 P	COMBI SW OUTPUT 1
93 V	ON IND	144 G	COMBI SW OUTPUT 2
95 O	ACC-RELAY CONF	145 L	COMBI SW OUTPUT 3
96 Y	ATT SHIFT SELECTOR POWER SUPPLY	146 SB	COMBI SW OUTPUT 4
99 R	SHIFT PEDAL/POLE POSITION SW	150 GR	DRIVER DOOR SW
100 GR	PASSENGER DOOR REQUEST SW	151 G	REAR WINDOW DEFROGGER RELAY CONT
101 O	DRIVER DOOR REQUEST SW		
102 O	BLOWER FAN MOTOR RELAY CONF		
103 LG	KLS RECEIVER (FRONT PARK SUPPLY)		
107 LG	COMB SW INPUT 1		
108 R	COMB SW INPUT 4		
109 Y	COMB SW INPUT 2		
110 P	HAZARD SW		

Connector No. M123

Connector Name BCM (BODY CONTROL MODULE)

Connector Type TH40FG-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	G	BCM
3	SB	ILL*
4	BG	ILL-[Coupe models]
5	O	ILL-[Roadster models]



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	GROUND
2	P	BCM
3	R	ILL*
4	B	ILL-



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	G	BCM
3	SB	ILL*- [Coupe models]
4	O	ILL-[Roadster models]



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	GROUND
2	P	BCM
3	R	ILL*
4	B	ILL-



JRLWD7879GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

Wiring Diagram

INFOID:0000000010840551



JRLWC2142GB

2012/04/18

EXL

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No. B9	Connector No. B64	Connector No. B151	Connector No. B152
Connector Name WIRE TO WIRE	Connector Name WIRE TO WIRE	Connector Name LICENSE PLATE LAMP RH	Connector Name LICENSE PLATE LAMP LH
Connector Type RS05FB-T/R	Connector Type RS05MB-B	Connector Type RS05FR	Connector Type RS05FL
Terminal Color Of No. Wire Signal Name [Specification]			
1 P - [Coupe models]	1 P - [Coupe models]	1 B -	1 B -
2 R - [Coupe models]	2 W - [Roaster models]	2 -	2 R -
3 V - [Roaster models]	3 R -	3 R -	3 -
4 Y -	4 W -	4 W -	4 -
5 G -	5 GR -	5 -	5 -
6 BG -	6 B -	6 B -	6 -
7 BR -	7 B -	7 B -	7 -
8 LG -	8 SHIELD -	8 L -	8 -
9 R -	10 G -	9 -	10 -

JRLWD7885GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

A B C D E F G H I J K L M N O P Q R EXL

PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	E28	Connector No.	E103
Connector Name	FRONT COMBINATION LAMP RH	Connector Name	FUSE BLOCK (L/E)
Connector Type	RS05FGY-PR	Connector Type	NS16FW-CS
			
			
Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
No.		No.	
39	P	1	SB
40	L	2	W
41	B/W	4	G
42	Y	6	LG
43	SB	7	BR
44	W	8	P
45	G	9	R
46	V	9	V
			- [Coupe models]
			- [Roadster models]

Connector No.	E6	Connector No.	E28
Connector Name	FRONT INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	FRONT COMBINATION LAMP RH
Connector Type	TH16FW-NH	Connector Type	RS05FGY-PR
			
			
Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
No.		No.	
42	41	40	39
43	45	44	43
			- [Coupe models]
			- [Roadster models]

Connector No.	E56	Connector No.	E106
Connector Name	FRONT COMBINATION LAMP LH	Connector Name	WIRE TO WIRE
Connector Type	RS05FGY-PR	Connector Type	TH05FW-CS16-TW4
			
			
Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
No.		No.	
3	B	1	SB
4	B/W	2	W
5	P	3	G
6	GR	4	LG
7	LG	7	B
8	BG	8	P
			- [Coupe models]
			- [Roadster models]

Connector No.	E9	Connector No.	E106
Connector Name	FRONT INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	Connector Name	WIRE TO WIRE
Connector Type	TH16FW-NH	Connector Type	TH05FW-CS16-TW4
			
			
Terminal Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
No.		No.	
91	P	1	Y
92	BG	2	L
97	V	3	B
104	LG	4	P
			- [Coupe models]
			- [Roadster models]

JRLWD7886GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	E117
Connector Name	WIRE TO WIRE
Connector Type	NSDGMW-GS




Terminal Color Of No.	Signal Name [Specification]
1	Y
2	R
3	Y
4	G
5	GR
6	BG
7	BR
8	P
9	R
10	R




Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NSDGMW-CS




Terminal Color Of No.	Signal Name [Specification]
3B	P
4B	G
5B	O
6B	Y
8B	R
9B	SB
7	BR
8	-
9	-
10	R




Terminal Color Of No.	Signal Name [Specification]
21	R
31	BR
32	V
36	SB
37	Y
38	LG
39	SB
40	W
41	LG
42	R
43	G
44	G



Terminal Color Of No.	Signal Name [Specification]
3	LG
4	Y
5	BR
58	SHEILD
59	L
70	R
80	LG
91	GR
82	V
83	V
84	L
85	BR
86	Y




Terminal Color Of No.	Signal Name [Specification]
1	P
2	SB
5	L
6	B
7	V
8	O
9	Y
10	R
11	LG




Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TS80MW-CS16-TM4



Terminal Color Of No.	Signal Name [Specification]
1	P
2	SB
3	L
4	V
5	Y
6	R
7	BR
8	-
9	-
10	-
11	-
12	-
13	-
14	-
15	-
16	-
17	-
18	-
19	-
20	-



Terminal Color Of No.	Signal Name [Specification]
1A	V
2A	G
3A	L
4A	P
5A	L
6A	Y
7A	A
8A	Y



JRLWD7887GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

PARKING, LICENSE PLATE AND TAIL LAMPS

Terminal Color Of No.	Wire	Signal Name [Specification]	Terminal Color Of No.	Wire	Signal Name [Specification]
12	P	OUTPUT 1	7	L	ROOM ANT 1-
13	BR	INPUT 5	8	R	ROOM ANT 1+
14	G	OUTPUT 2	9	P	ROOM ANT 2-
			10	S	ROOM ANT 2+
			11	GR	PASSANGER DOOR ANTI-
			12	Y	PASSANGER DOOR ANTI-
			13	W	DRIVER DOOR ANTI-
			14	BR	DRIVER DOOR ANTI-
			15	V	DRIVER DOOR ANTI-
			16	IG	DRIVER DOOR ANTI-
			17	LG	DRIVER DOOR ANTI-
			18	SB	DR DOOR UNLOCK SENSOR
			19	SB	KEY SLOT SW
			20	LG	IGN/FB
			21	W	PASSENGER DOOR SW
			22	LG	TRUNK LD OPENER CANCEL SW
			23	W	REAR DEFROGGER SW
			24	GR	SW SW & SOFT FOR CLIMATE CONTROL MODE
			25	GR	POWER WINDOW SW COMB (COURTESY NOADS)
			26	GR	PUSH-BUTTON IGNITION SW/ILL POWER
			27	GR	LOCK IND
			28	GR	RECEIVER & SENSOR GND
			29	GR	RECEIVER & SENSOR POWER SUPPLY
			30	GR	PIN POSITION
			31	GR	ACC RELAY CONT
			32	Y	SECURITY INDICATOR
			33	Y	COMBI SW INPUT 5
			34	Y	COMBI SW INPUT 6
			35	Y	COMBI SW INPUT 7
			36	Y	COMBI SW INPUT 8
			37	Y	COMBI SW INPUT 9
			38	Y	COMBI SW INPUT 10
			39	Y	COMBI SW INPUT 11
			40	Y	COMBI SW INPUT 12
			41	Y	COMBI SW INPUT 13
			42	O	COMBI SW INPUT 14
			43	P	COMBI SW INPUT 15
			44	G	COMBI SW INPUT 16
			45	L	COMBI SW INPUT 17
			46	SB	COMBI SW INPUT 18
			47	GR	DRIVER DOOR SW
			48	GR	REAR WINDOW DEFROGGER RELAY CONT
			49	GR	HAZARD SW
			50	GR	HAZARD SW
			51	GR	HAZARD SW

JRLWD7888GB

STOP LAMP

[XENON TYPE]

< WIRING DIAGRAM >


STOP LAMP

Wiring Diagram

INFOID:0000000010840552

STOP LAMP

⟨CP⟩ : Coupe models
⟨RS⟩ : Roadster models




2009/07/10

JCLWM4079GB

STOP LAMP

< WIRING DIAGRAM >

[XENON TYPE]



JRLWD7880GB

P

M

Z

O

K

EXL

A

B

C

D

E

F

G

H


I

J


STOP LAMP

< WIRING DIAGRAM >

[XENON TYPE]



Terminal No.	Color Of Wire	Signal Name [Specification]
1F	SB	-
2F	W	-
4F	G	-
6F	BG	-
8F	L	-
9F	R	- [Corvette models]
9F	V	- [Roadster models]



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	G	-
4	P	-

JRLWD7881GB

BACK-UP LAMP

[XENON TYPE]


< WIRING DIAGRAM >

BACK-UP LAMP

Wiring Diagram

INFOID:0000000010840553

BACK-UP LAMP



2014/05/12

JRLWD8057GB

BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]

BACK-UP LAMP			
Connector No.	B1	Connector No.	B60
Connector Name	WIRE TO WIRE	Connector Name	REAR COMBINATION LAMP LH
Connector Type	T800FW-C516-TM4	Connector Type	RS505FY-PR
			
Terminal Color Of No.	Signal Name [Specification]	Terminal Color Of No.	Signal Name [Specification]
1	G	1	Y
2	BG	2	BR
3	Y	2	- [Coupe models]
4	W	3	V
6	V	3	- [Roadster models]
7	LG	4	B
8	GR	4	K-LINE
9	SB	5	CANH
11	Y	6	GROUND
12	W	6	IGNITION POWER SUPPLY
13	BR	7	W
14	LG	8	BACK-UP LAMP RELAY
15	B	9	P
16	V	9	STARTER RELAY
17	R	10	GR
18	B		GROUND
20	SB		
21	G		
22	GR		
23	V		
24	BG		
25	L		
26	P		
27	W		
28	SHIELD		
31	W		
32	B		
33	P		
33	W		
34	R		
35	B		
35	W		
36	B		
40	Y		
41	L		
42	GR		
43	BR		
44	R		
45	BG		
46	SB		
46	SHIELD		
47	V		
48	SHIELD		
51	W		
52	R		
57	SHIELD		
58	B		
60	V		
61	SB		
62	SHIELD		
63	BR		
64	Y		
65	SHIELD		
66	P		
67	L		
68	SHIELD		
69	R		
70	G		
71	V		
72	P		
73	BR		
74	GR		
75	BG		
80	Y		
81	R		
82	B		
83	GR		
84	G		
84	L		
85	LG		
86	V		
87	BR		
88	GR		
93	Y		
94	G		
94	L		
95	GR		
96	L		
97	Y		
98	W		
98	YB		
99	LG		
100	B		

JRLWD7882GB

BACK-UP LAMP

< WIRING DIAGRAM >


[XENON TYPE]

BACK-UP LAMP

Connector No. F103

Connector Name WIRE TO WIRE

Connector Type T32FW-NS10



Terminal Color Of Wire

No. Signal Name [Specification]

1 W IGNITION POWER SUPPLY

2 B BATTERY POWER SUPPLY [MOTOR BACK-UP]

3 R CAN-H

4 O K-LINE

5 G GROUND

6 GR IGNITION POWER SUPPLY

7 L BACK-UP LAMP RELAY

8 BR CAN-L

9 Y STARTER RELAY

10 W/B GROUND

Terminal Color Of Wire

No. Signal Name [Specification]

1 M3

2 -

3 W FUSE BLOCK (J/F)

4 R -

5 B NS-12FW-CS

6 -

7 L -

8 -

9 Y -

10 GR -

11 O -

12 Y -

13 B -

14 L -

15 O -

16 V -

17 R -

18 L -

19 SB -

20 BR -

21 V -

22 BR -

23 V -

24 R -

25 L -

26 P -

27 B -

28 SHIELD -

29 W -

30 BR -

31 V -

32 B -

33 W -

34 R -

35 B -

36 L -

37 L -

38 BR -

39 V -

40 L -

41 R -

42 GR -

43 R -

44 R -

Terminal Color Of Wire

No. Signal Name [Specification]

1 M7 WIRE TO WIRE

2 - [Roaster models]

3 - [Coupe models]

4 T80MMW-CS16-TM4

5 H.S.

6 -

7 -

8 -

9 -

10 -

11 -

12 -

13 -

14 -

15 -

16 -

17 -

18 -

19 -

20 -

21 -

22 -

23 -

24 -

25 -

26 -

27 -

28 -

29 -

30 -

31 -

32 -

33 -

34 -

35 -

36 -

37 -

38 -

39 -

40 -

41 -

42 -

43 -

44 -

Terminal Color Of Wire

No. Signal Name [Specification]

1 M7 WIRE TO WIRE

2 - [Roaster models]

3 - [Coupe models]

4 T80MMW-CS16-TM4

5 H.S.

6 -

7 -

8 -

9 -

10 -

11 -

12 -

13 -

14 -

15 -

16 -

17 -

18 -

19 -

20 -

21 -

22 -

23 -

24 -

25 -

26 -

27 -

28 -

29 -

30 -

31 -

32 -

33 -

34 -

35 -

36 -

37 -

38 -

39 -

40 -

41 -

42 -

43 -

44 -


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
EXL

JRLWD7883GB

BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]



JRLWD7884GB

REAR FOG LAMP SYSTEM


[XENON TYPE]

< WIRING DIAGRAM >

REAR FOG LAMP SYSTEM

Wiring Diagram

INFOID:0000000010840554



REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

REAR FOG LAMP		
Connector No.	Signal Name [Specification]	Wire To Wire
B1		
1 G	GR	-
2 BG	BR	-
3 Y	R	-
4 W	SG	-
5 BR	SB	-
6 W	SHIELD	-
7 LG	V	-
8 GR	SHIELD	-
9 SB	BR	-
10 Y	Y	-
11 W	P	-
12 BR	P	-
13 LG	V	-
14 LG	L	-
15 B	LG	-
16 V	SG	-
17 R	BR	-
18 B	Y	-
19 SB	P	-
20 BR	P	-
21 G	V	-
22 GR	LG	-
23 V	LG	-
24 BG	LG	-
25 L	LG	-
26 P	LG	-
27 W	LG	-
28 SHIELD	LG	-
29 W	LG	-
30 B	LG	-
31 W	LG	-
32 B	P	-
33 P	W	-
34 R	R	-
35 B	W	-
36 B	W	-
37 Y	Y	-
38 R	R	-
39 B	B	-
40 W	W	-
41 LG	LG	-
42 SB	SB	-
43 G	G	-
44 GR	[Except for convertible models with MT] [Roadster models with MT]	-
45 BS	R	-
46 W	BS	-
47 P	W	-
48 SG	W	-
49 Y	W	-
50 R	W	-
51 LG	W	-
52 BR	W	-
53 SB	W	-
54 B	W	-
55 V	W	-
56 LG	W	-
57 BR	W	-
58 LG	W	-
59 SB	W	-
60 V	W	-
61 SB	W	-
62 SHIELD	W	-
63 BR	W	-
64 Y	W	-
65 SHIELD	W	-
66 P	W	-
67 L	W	-
68 SHIELD	W	-
69 R	W	-
70 G	W	-
71 V	W	-
72 P	W	-
73 BR	W	-
74 GR	W	-
75 BG	W	-
76 Y	W	-
77 R	W	-
78 B	W	-
79 SB	W	-
80 BR	W	-
81 R	W	-
82 B	W	-
83 GR	W	-
84 G	W	-
85 LG	W	-
86 V	W	-
87 BR	W	-
88 GR	W	-
89 Y	W	-
90 R	W	-
91 LG	W	-
92 BR	W	-
93 SB	W	-
94 Y	W	-
95 GR	W	-
96 P	W	-
97 SB	W	-
98 LG	W	-
99 YB	W	-
100 B	W	-


REAR FOG LAMP		
Connector No.	Signal Name [Specification]	Wire To Wire
B70		
1 REAR FOG LAMP	REAR FOG LAMP	-
2 RS02F/3Y	RS02F/3Y	-
3 -	-	-
4 -	-	-
5 -	-	-
6 -	-	-
7 -	-	-
8 -	-	-
9 -	-	-
10 -	-	-
11 -	-	-
12 -	-	-
13 -	-	-
14 -	-	-
15 -	-	-
16 -	-	-
17 -	-	-
18 -	-	-
19 -	-	-
20 -	-	-
21 -	-	-
22 -	-	-
23 -	-	-
24 -	-	-
25 -	-	-
26 -	-	-
27 -	-	-
28 -	-	-
29 -	-	-
30 -	-	-
31 -	-	-
32 -	-	-
33 -	-	-
34 -	-	-
35 -	-	-
36 -	-	-
37 -	-	-
38 -	-	-
39 -	-	-
40 -	-	-
41 -	-	-
42 -	-	-
43 -	-	-
44 -	-	-
45 -	-	-
46 -	-	-
47 -	-	-
48 -	-	-
49 -	-	-
50 -	-	-
51 -	-	-
52 -	-	-
53 -	-	-
54 -	-	-
55 -	-	-
56 -	-	-
57 -	-	-
58 -	-	-
59 -	-	-
60 -	-	-
61 -	-	-
62 -	-	-
63 -	-	-
64 -	-	-
65 -	-	-
66 -	-	-
67 -	-	-
68 -	-	-
69 -	-	-
70 -	-	-
71 -	-	-
72 -	-	-
73 -	-	-
74 -	-	-
75 -	-	-
76 -	-	-
77 -	-	-
78 -	-	-
79 -	-	-
80 -	-	-
81 -	-	-
82 -	-	-
83 -	-	-
84 -	-	-
85 -	-	-
86 -	-	-
87 -	-	-
88 -	-	-
89 -	-	-
90 -	-	-
91 -	-	-
92 -	-	-
93 -	-	-
94 -	-	-
95 -	-	-
96 -	-	-
97 -	-	-
98 -	-	-
99 -	-	-
100 -	-	-

JRLWD7870GB

REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
EXL


JRLWD7871GB

REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

REAR FOG LAMP



JRLWD7872GB

REAR FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

A B C D E F G H I J K L M N O P

EXL

REAR FOG LAMP		
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DEFROGGER SW
78	L	ROOM ANT 1-
79	R	ROOM ANT 1+
80	GR	NATS ANT AMP
81	W	NATS ANT AMP
82	R	IG RELAY (FB) CONT
83	GR	KTLS ENT RECEIVER (FRONT) COMM
87	BR	COMB SW INPUT 5
88	V	COMB SW INPUT 3
90	P	CANL
91	L	CANH
92	LG	KEY SLOT LLL
93	V	ON IND.
95	O	ACC RELAY CONT
96	Y	ATT SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT PULCUT-FEAD POS SW
100	GR	PASSENGER DOOR REQUEST SW
101	Y	DRIVER DOOR REQUEST SW
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KTLS ENT RECEIVER (FRONT) PWK SUPPLY
107	LG	COMB SW INPUT 1
108	R	COMB SW INPUT 4
109	Y	COMB SW INPUT 2
110	P	HAZARD SW
129	O	TRUNK LID OPENER CANCEL SW
130	L	[REAR DEFROGGER SW FRM SW & SOFT TOP CANCEL (some models)]
132	V	POWER WINDOW SW COMM (some models)
133	Y	FUSE BUTTON (IGNITION SW) LL POWER
134	GR	LOCK IND
137	P	RECEIVER & SENSOR SND
138	V	RECEIVER & SENSOR POWER SUPPLY
139	L	TIRE PRESS RECEIV COMM
140	G	PIN POSITION
141	Y	SECURITY INDICATOR R
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT
Connector No.		M123
Connector Name		BCM (BODY CONTROL MODULE)
Connector Type		TH4UFG3-NH



Terminal	Color Of	Signal Name / Specification
No.	Wire	
113	O	OPTICAL SENSOR
114	R	CLUTCH INTERLOCK SW
115	O	-
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR. DOOR UNLOCK SENS
121	R	KEY SLOT SW
123	W	IGN FB
124	LG	PASSENGER DOOR SW

JRLWD7873GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000010840555

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORK FLOW

[XENON TYPE]

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
 - Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
- If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-44, "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DIAGNOSIS AND REPAIR WORK FLOW

[XENON TYPE]

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44, "Intermittent Incident"](#).

8.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

 >> GO TO 9.

9.FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS


HEADLAMP (HI) CIRCUIT

Description

INFOID:0000000010840558

The high beam solenoid drives the mobile valve shade. And the mobile valve shade switches the high beam and low beam of headlamp.

- When the headlamp high relay is turned ON, magnetic force is applied to the high beam solenoid (1) by a current. The mobile valve shade (3) is switched to the high beam position through the actuator rod (2).
- When the headlamp high relay is turned OFF, the current stops. The mobile valve shade returns to the low beam position automatically.



JPLIA1528ZZ

Component Function Check

INFOID:0000000010840559

1. CHECK HEADLAMP (HI) OPERATION

IPDM E/R AUTO ACTIVE TEST

- Start IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
- Check that the headlamp switches to the high beam.

CONSULT ACTIVE TEST

- Select "EXTERNAL LAMPS" of IPDM E/R active test item.
- With operating the test items, check that the headlamp switches to the high beam.

Hi : Headlamp switches to the high beam.

Off : Headlamp OFF

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

Does the headlamp switch to the high beam?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-75, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840560

1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

- Turn the ignition switch OFF.
- Disconnect the front combination lamp connector.
- Turn the ignition switch ON.
- Select "EXTERNAL LAMPS" of IPDM E/R active test item.

HEADLAMP (HI) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMPS	Battery voltage
Connector	Terminal		
RH	89		0 V
LH	E8		0 V
	90		Battery voltage

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK HEADLAMP (HI) OPEN CIRCUIT

- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector.
- Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E8	89	E28	7
LH		90	E58	7

Does continuity exist?

YES >> Replace the front combination lamp.

NO >> Repair the harnesses or connectors.

3.CHECK HEADLAMP (HI) FUSE

- Turn the ignition switch OFF.
- Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#55	10 A
Headlamp HI (LH)	IPDM E/R	#54	10 A

Is the fuse fusing?

YES >> GO TO 4.

NO >> Replace IPDM E/R.

4.CHECK FRONT COMBINATION LAMP (HI) SHORT CIRCUIT

- Disconnect IPDM E/R connector.
- Check continuity between the IPDM E/R harness connector terminal and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E8	89	
LH		90	

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

HEADLAMP (LO) CIRCUIT

Description

INFOID:0000000010840561

Headlamp (LO) circuit is connected to HID control unit integrated in the headlamp. Headlamp (LO) circuit turns xenon headlamp ON.

For the details of HID control unit and the xenon headlamp, refer to [EXL-79, "Description"](#).

Component Function Check

INFOID:0000000010840562

1.CHECK HEADLAMP (LO) OPERATION

IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp is turned ON.

Lo : Headlamp ON

Off : Headlamp OFF

Is the headlamp turned ON?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-77, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840563

1.CHECK HEADLAMP (LO) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector.
3. Turn the ignition switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)	
(+)	(-)			
IPDM E/R		EXTERNAL LAMPS Ground		
Connector	Terminal			
RH	83		Lo Battery voltage	
E8	84		Off 0 V	
			Lo Battery voltage	
LH			Off 0 V	

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK HEADLAMP (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

EXL

M

N

O

P

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E8	83	E28	5
LH		84	E58	5

Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

3.CHECK HEADLAMP (LO) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Lotion	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#57	15 A
Headlamp LO (LH)	IPDM E/R	#56	15 A

Is the fuse fusing?

YES >> GO TO 4.

NO >> Replace IPDM E/R.

4.CHECK HEADLAMP (LO) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E8	83	Not existed
LH		84	

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

5.CHECK HEADLAMP GROUND OPEN CIRCUIT

Check continuity between the front combination lamp harness connector and the ground.

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E28	3	Existed
LH		3	

Does continuity exist?

YES >> Perform the xenon headlamp diagnosis. Refer to [EXL-79, "Description"](#).

NO >> Repair the harnesses or connectors.

< DTC/CIRCUIT DIAGNOSIS >

XENON HEADLAMP**Description**

INFOID:0000000010840564

OUTLINE


- The lamp light source is by the arch discharge by applying high voltage into the xenon gas-filled bulb instead of the halogen bulb filament.
- Sight becomes more natural and brighter because the amount of light are gained adequately and the color of light is sunshine-like white.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

ILLUMINATION PRINCIPLE

- Discharging starts in high voltage pulse between bulb electrodes.
- Xenon gas is activated by current between electrodes. Pale light is emitted.
- The luminous tube (bulb) temperature elevates. Evaporated halide is activated by discharge. The color of light changes into white.

NOTE:

- Brightness and the color of light may change slightly immediately after the headlamp turned ON until the xenon bulb becomes stable. This is not malfunction.
- Illumination time lag may occur between right and left. This is not malfunction.



JPLIA0421GB

PRECAUTIONS FOR TROUBLE DIAGNOSIS

Representative malfunction examples are; "Light does not turn ON", "Light blinks", and "Brightness is inadequate". The cause often be the xenon bulb. Such malfunctions, however, are occurred occasionally by HID control unit malfunction or lamp case malfunction. Specify the malfunctioning part with diagnosis procedure.

WARNING:

- Never touch the harness, HID control unit, the inside and metal part of lamp when turning the headlamp ON or operating the light switch.
- Never work with wet hands.

CAUTION:

- Never perform HID control unit circuit diagnosis with a circuit tester or an equivalent.
- Temporarily install the headlamp on the vehicle. Connect the battery to the connector (vehicle side) when checking ON/OFF status.
- Disconnect the battery negative terminal before disconnecting the lamp socket connector or the harness connector.
- Check for fusing of the fusible link(s), open around connector, short, disconnection if the symptom is caused by electric error.

NOTE:

- Turn the switch OFF once before turning ON, if the ON/OFF is inoperative.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

Diagnosis Procedure

INFOID:0000000010840565

1.CHECK XENON BULB

Install the normal bulb to the applicable headlamp. Check that the xenon bulb is turned ON.

Is the headlamp turned ON?

- YES >> Replace the xenon bulb.
NO >> GO TO 2.

2.CHECK HID CONTROL UNIT

Install the normal HID control unit to the applicable headlamp. Check that the lamp is turned ON.

Is the headlamp turned ON?

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

XENON HEADLAMP

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

- YES >> Replace HID control unit.
NO >> GO TO 3.

3.CHECK XENON HEADLAMP HOUSING ASSEMBLY

Install the normal xenon headlamp housing assembly to the applicable headlamp. Check that the xenon headlamp is turned ON.

Is the headlamp turned ON?

- YES >> Replace the front combination lamp. (Xenon headlamp housing voltage converter malfunctions.)
NO >> Xenon headlamp is normal. Check the headlamp control system.

DAYTIME RUNNING LIGHT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

DAYTIME RUNNING LIGHT CIRCUIT

Component Function Check

INFOID:0000000010840566

1. CHECK DAYTIME RUNNING LIGHT OPERATION

IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).

2. Check that the daytime running light is turned ON.

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

2. With operating the test items, Check that the daytime running light is turned ON.

Fog : Daytime running light ON

Off : Daytime running light OFF

Is the daytime running light turned ON?

YES >> Daytime running light circuit is normal.

NO >> Refer to [EXL-81, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840567

1. CHECK DAYTIME RUNNING LIGHT FUSE

1. Turn the ignition switch OFF.

2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Daytime running light	IPDM E/R	#58	15 A

Is the fuse fusing?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK DAYTIME RUNNING LIGHT SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the daytime running light connector.

2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E8	86	
LH		87	Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

3. CHECK DAYTIME RUNNING LIGHT UNIT

Check the applicable daytime running light unit.

Is the bulb normal?

YES >> GO TO 4.

NO >> Replace the daytime running light unit.

4. CHECK DAYTIME RUNNING LIGHT OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Disconnect the daytime running light connector.

2. Turn the ignition switch ON.

3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DAYTIME RUNNING LIGHT CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)	
(+)	(-)			
IPDM E/R		EXTERNAL LAMPS Ground	EXTERNAL LAMPS	
Connector	Terminal		Fog	
RH	86		Battery voltage	
E8	87		Off	
			0 V	
LH	87		Fog	
			Battery voltage	
			Off	
			0 V	

Is the measurement value normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R.

5.CHECK DAYTIME RUNNING LIGHT OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the daytime running light harness connector.

IPDM E/R		Daytime running light		Continuity
Connector	Terminal	Connector	Terminal	
RH	E8	86	E79	1
LH		87	E78	1

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harnesses or connectors.

6.CHECK DAYTIEM RUNNING LIGHT GROUND CIRCUIT OPEN CIRCUIT

Check continuity between the front fog lamp harness connector and the ground.

Daytime running light		Ground	Continuity
Connector	Terminal		
RH	E79	2	Existed
LH	E78		

Does continuity exist?

YES >> Refer to GI-44, "Intermittent Incident".

NO >> Repair the harnesses or connectors.

< DTC/CIRCUIT DIAGNOSIS >

PARKING LAMP CIRCUIT**Component Function Check**

INFOID:0000000010840568

1. CHECK PARKING LAMP OPERATION **IPDM E/R AUTO ACTIVE TEST**

1. Activate IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

 CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON**Off : Parking lamp OFF**Is the parking lamp turned ON?

- YES >> Parking lamp circuit is normal.
NO >> Refer to [EXL-83, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840569

1. CHECK PARKING LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not fusing.

Unit	Location	Fuse No.	Capacity
• Parking lamp • Front side marker lamp	IPDM E/R	#52	10 A

Is the fuse fusing?

- YES >> GO TO 2.
NO >> GO TO 3.

2. CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the front combination lamp connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E9	91	
LH		92	Not existed

Does continuity exist?

- YES >> Repair the harnesses or connectors. And then replace the fuse.
NO >> Replace the fuse. (Replace IPDM E/R if fusing is found again.)

3. CHECK PARKING LAMP BULB AND FRONT SIDE MARKER LAMP

Check the applicable lamp bulb.

Is the bulb normal?

- YES >> GO TO 4.
NO >> Replace the bulb.

4. CHECK PARKING LAMP OUTPUT VOLTAGE **CONSULT ACTIVE TEST**

1. Disconnect the front combination lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

PARKING LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)	
(+)	(-)			
IPDM E/R		EXTERNAL LAMPS Ground	TAIL	
Connector			Off	
RH	91		Battery voltage	
LH	E9		0 V	
	92		Battery voltage	
LH	Off		0 V	

Is the measurement value normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R.

5.CHECK PARKING LAMP OPEN CIRCUIT

- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector.
- Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E9	91	E28	8
LH		92	E58	8

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harnesses or connectors.

6.CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between the front combination lamp harness connector and the ground.

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E28		Existed
LH	E58		

Does continuity exist?

YES >> Replace the front combination lamp.

NO >> Repair the harnesses or connectors.

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

TURN SIGNAL LAMP CIRCUIT

Description

INFOID:0000000010840570

BCM performs the high flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

Component Function Check

INFOID:0000000010840571

1.CHECK TURN SIGNAL LAMP

(CONSULT ACTIVE TEST

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp turn ON.

LH : Turn signal lamp LH ON

RH : Turn signal lamp RH ON

Off : The turn signal lamp OFF

Does the turn signal lamp blink?

YES >> Turn signal lamp circuit is normal.

NO >> Refer to [EXL-85. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840572

1.CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 2.

NO >> Replace the bulb.

2.CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

(CONSULT ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector, side turn signal lamp connector or the rear combination lamp connector.
3. Turn the ignition switch ON.
4. Select "FLASHER" of BCM (FLASHER) active test item.
5. With operating the turn signal switch, check the voltage between the BCM harness connector and the ground.

EXL

Front/side

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		FLASHER	
Connector	Terminal		
RH	17	RH	12 V
M119		Off	0 V
LH	18	LH	12 V
		Off	0 V

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Rear

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		FLASHER	
Connector	Terminal		
RH	20		RH 12 V
LH	M120 25		Off 0 V
		Ground	LH 12 V
			Off 0 V

Is the measurement value normal?

YES >> GO TO 3.

NO >> Replace BCM.

3.CHECK TURN SIGNAL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check the continuity between the BCM harness connector and the front combination lamp, side turn signal lamp or rear combination lamp harness connector.

Front turn signal lamp

BCM		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M119	17	E28	6
LH		18	E58	6

Side turn signal lamp

BCM		Side turn signal lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M119	17	E24	1
LH		18	E55	1

Rear turn signal lamp

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M120	20	B67	4
LH		25	B60	4

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4.CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between the BCM harness connector and the ground.

Front/side

BCM		Ground	Continuity
Connector	Terminal		
RH	M119	17	
LH		18	Not existed

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Rear

BCM		Ground	Continuity
Connector	Terminal		
RH	M120		20
LH			25

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5.

5.CHECK TURN SIGNAL LAMP GROUND OPEN CIRCUIT

Check the continuity between the front combination lamp, side turn signal lamp or rear combination lamp and the ground.

Front turn signal lamp

Front combination lamp		Ground	Continuity
Connector	Terminal		
RH	E28		4
LH	E58		4

Side turn signal lamp

Side turn signal lamp		Ground	Continuity
Connector	Terminal		
RH	E24		2
LH	E55		2

Rear turn signal lamp

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B67		3
LH	B60		3

Does continuity exist?

YES >> Replace the front combination lamp, side turn signal lamp or rear combination lamp.

NO >> Repair the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

OPTICAL SENSOR

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

OPTICAL SENSOR

Description

INFOID:0000000010840573

Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.

Component Function Check

INFOID:0000000010840574

1.CHECK OPTICAL SENSOR SIGNAL BY CONSULT

④CONSULT DATA MONITOR

1. Turn the ignition switch ON.
2. Select "OPTICAL SENSOR" of BCM (HEADLAMP) data monitor item.
3. Turn the lighting switch AUTO.
4. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition		Voltage (Approx.)
OPTICAL SENSOR	Optical sensor	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the item status normal?

- YES >> Optical sensor is normal.
NO >> Refer to [EXL-88, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840575

1.CHECK OPTICAL SENSOR POWER SUPPLY INPUT

1. Turn the ignition switch ON.
2. Turn the lighting switch AUTO.
3. Check the voltage between the optical sensor harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Optical sensor		
Connector	Terminal	Ground
M94	1	5 V

Is the measurement value normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2.CHECK OPTICAL SENSOR GROUND INPUT

Check the voltage between the optical sensor harness connector and the ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Optical sensor		
Connector	Terminal	Ground
M94	3	0 V

Is the measurement value normal?

- YES >> GO TO 3.
NO >> GO TO 6.

3.CHECK OPTICAL SENSOR SIGNAL OUTPUT

OPTICAL SENSOR

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

With illuminating the optical sensor, check the voltage between the optical sensor harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Optical sensor	Ground	Optical sensor	
Connector		When illuminating	3.1 V or more *
M94		When shutting off light	0.6 V or less

*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

Is the measurement value normal?

YES >> GO TO 7.

NO >> Replace the optical sensor.

4.CHECK OPTICAL SENSOR OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and BCM connector.
3. Check continuity between the optical sensor harness connector and the BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	1	M123	138	Existed

Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5.CHECK OPTICAL SENSOR SHORT CIRCUIT

Check the continuity between the optical sensor harness connector and the ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M94	1		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

6.CHECK OPTICAL SENSOR GROUND OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and BCM connector.
3. Check continuity between the optical sensor harness connector and the BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	3	M123	137	Existed

Does continuity exist?

YES >> Replace BCM.

NO >> Repair the harnesses or connectors.

7.CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor connector and BCM connector.
3. Check continuity between the optical sensor harness connector and the BCM harness connector.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	2	M123	113	Existed

Does continuity exist?

YES >> GO TO 8.

NO >> Repair the harnesses or connectors.

8.CHECK OPTICAL SENSOR SHORT CIRCUIT

Check the continuity between the optical sensor harness connector and the ground.

Optical sensor		Ground	Continuity
Connector	Terminal		Not existed
M94	2		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

HAZARD SWITCH

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

HAZARD SWITCH

Component Function Check

INFOID:0000000010840576

1. CHECK HAZARD SWITCH SIGNAL BY CONSULT

(B) CONSULT DATA MONITOR

1. Turn the ignition switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the item status normal?


- YES >> Hazard switch circuit is normal.
NO >> Refer to [EXL-91, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840577

1. CHECK HAZARD SWITCH SIGNAL INPUT

With operating the hazard switch, check the voltage between the BCM harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
BCM		Hazard switch	0 V
Connector	Terminal		
M122	110	Ground	OFF
			 JPMA0012GB

Is the measurement value normal?

- YES >> Replace BCM.
NO >> GO TO 2.

2. CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the hazard switch connector and BCM connector.
3. Check continuity between the hazard switch harness connector and the BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M144	2	M122	110	Existed

Does continuity exist?

- YES >> GO TO 3.
NO >> Repair the harnesses or connectors.

3. CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between the hazard switch harness connector and the ground.

HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Hazard switch		Ground	Continuity
Connector	Terminal		Not existed
M144	2		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 4.

4.CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between the hazard switch harness connector and the ground.

Hazard switch		Ground	Continuity
Connector	Terminal		Existed
M144	1		

Does continuity exist?

YES >> Replace the hazard switch.

NO >> Repair the harnesses or connectors.

< DTC/CIRCUIT DIAGNOSIS >

TAIL LAMP CIRCUIT**Component Function Check**

INFOID:0000000010840578

1.CHECK TAIL LAMP OPERATION **IPDM E/R AUTO ACTIVE TEST**

1. Activate IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

 CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

TAIL : Tail lamp ON**Off : Tail lamp OFF**Is the tail lamp turned ON?

YES >> Tail lamp circuit is normal.

NO >> Refer to [EXL-93, "Diagnosis Procedure"](#).**Diagnosis Procedure**

INFOID:0000000010840579

1.CHECK TAIL LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
<ul style="list-style-type: none"> • Tail lamp • Rear side marker lamp • License plate lamp 	IPDM E/R	#53	10 A

Is the fuse fusing?

YES >> Repair the malfunctioning part before replacing the fuse.

NO >> GO TO 2.

2.CHECK TAIL LAMP OUTPUT VOLTAGE **CONSULT ACTIVE TEST**

1. Disconnect the rear combination lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMPS	Ground
Connector	Terminal		
E5	7		TAIL
			Battery voltage
			Off
			0 V

Is the measurement value normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R.

3.CHECK TAIL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.

TAIL LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between the IPDM E/R harness connector and the rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E5	7	B67	2
LH			B60	2

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4.CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between the rear combination lamp harness connector and the ground.

Rear combination lamp			Ground	Continuity
Connector	Terminal			
RH	B67	3		Existed
LH		3		

Does continuity exist?

YES >> Replace the rear combination lamp.

NO >> Repair the harnesses or connectors.

LICENSE PLATE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

LICENSE PLATE LAMP CIRCUIT

Component Function Check

INFOID:0000000010840580

NOTE:

Check the tail lamp circuit if the tail lamp and the license plate lamp are not turned ON.

1.CHECK LICENSE PLATE LAMP OPERATION

IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-10, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

CONSULT ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the lighting switch, check that the license plate lamp is turned ON.

TAIL : License plate lamp ON

Off : License plate lamp OFF

Is the license plate lamp turned ON?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-95, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840581

1.CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 2.

NO >> Replace the bulb.

2.CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.

2. Disconnect IPDM E/R connector and the license plate lamp connector.

3. Check continuity between the IPDM E/R harness connector and the license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E5	7	B153	2
LH			B152	2

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between the license plate lamp harness connector and the ground.

License plate lamp		Ground	Continuity
Connector	Terminal		
RH	B153		1
LH	B152		1

Does continuity exist?

YES >> Replace the license plate lamp.

NO >> Repair the harnesses or connectors.

EXL

REAR FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

REAR FOG LAMP CIRCUIT

Component Function Check

INFOID:0000000010840582

1.CHECK REAR FOG LAMP OPERATION

④ CONSULT ACTIVE TEST

1. Select "RR FOG LAMP" of BCM (HEAD LAMP) active test item.
2. With operating the test items, check that the rear fog lamp is turned ON.

On : Rear fog lamp ON

Off : Rear fog lamp OFF

Is rear fog lamp turned ON?

YES >> Rear fog lamp circuit is normal.

NO >> Refer to [EXL-96, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010840583

1.CHECK REAR FOG LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 2.

NO >> Replace the bulb.

2.CHECK REAR FOG LAMP OUTPUT VOLTAGE

④ CONSULT ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the rear fog lamp connector.
3. Turn the ignition switch ON.
4. Select "RR FOG LAMP" of BCM (HEAD LAMP) active test item.
5. With operating the test items, check voltage between BCM harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		RR FOG LAMP	
Connector	Terminal		
M120	24		
Ground		On	Battery voltage
		Off	0 V

Is the measurement value normal?

YES >> GO TO 3.

NO >> Replace BCM.

3.CHECK REAR FOG LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear fog lamp harness connector.

BCM		Rear fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
M120	24	B70	1	Existed

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

REAR FOG LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

4. CHECK REAR FOG LAMP SHORT CIRCUIT

Check for continuity between BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		Not existed
M120	24		

Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

5. CHECK REAR FOG LAMP GROUND OPEN CIRCUIT

Check for continuity between rear fog lamp harness connector and the ground.

Rear fog lamp		Ground	Continuity
Connector	Terminal		Existed
B70	2		

Does continuity exist?

YES >> Replace the rear fog lamp.

NO >> Repair the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

EXTERIOR LIGHTING SYSTEM SYMPTOMS

<SYMPTOM DIAGNOSIS>

[XENON TYPE]

SYMPTOM DIAGNOSIS

EXTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000010840584

NOTE:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp does not switch to the high beam.	One side	<ul style="list-style-type: none"> Fuse Harness between IPDM E/R and the front combination lamp Front combination lamp (High beam solenoid) IPDM E/R 	Headlamp (HI) circuit Refer to EXL-75 .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM" Refer to EXL-102 .	
High beam indicator lamp is not turned ON. (Headlamp switches to the high beam.)		Combination meter	<ul style="list-style-type: none"> Combination meter Data monitor "HI-BEAM IND" BCM (HEAD LAMP) Active test "HEADLAMP"
Headlamp does not switch to the low beam.	One side	Front combination lamp (High beam solenoid)	—
	Both sides	<ul style="list-style-type: none"> Combination switch Harness between the combination switch and BCM BCM 	Combination switch Refer to BCS-102 .
		High beam request signal <ul style="list-style-type: none"> BCM IPDM E/R 	IPDM E/R Data monitor "HL HI REQ"
		IPDM E/R	—
Headlamp is not turned ON.	One side	<ul style="list-style-type: none"> Fuse Xenon bulb Harness between IPDM E/R and the front combination lamp Front combination lamp (xenon headlamp) IPDM E/R 	Headlamp (LO) circuit Refer to EXL-77 .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-103 .	
Headlamp is not turned OFF.	When the ignition switch is turned ON	IPDM E/R	—
	The ignition switch is turned OFF (After activating the battery saver).	<ul style="list-style-type: none"> Combination switch Harness between the combination switch and BCM BCM 	Combination switch Refer to BCS-102 .
Headlamp is not turned ON/OFF with the lighting switch AUTO.		<ul style="list-style-type: none"> Optical sensor Harness between the optical sensor and BCM BCM 	Optical sensor Refer to EXL-88 .

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item	
Daytime running light is not turned ON.	<ul style="list-style-type: none"> • Fuse • IPDM E/R • Daytime running light assembly • Harness between IPDM E/R and the daytime running light • BCM • Combination meter 	Daytime running light circuit Refer to EXL-81 .	
Parking lamp is not turned ON.	<ul style="list-style-type: none"> • Fuse • Parking lamp bulb • Harness between IPDM E/R and the front combination lamp • Front combination lamp • IPDM E/R 	Parking lamp circuit Refer to EXL-83 .	
Tail lamp is not turned ON.	<ul style="list-style-type: none"> • Harness between IPDM E/R and the rear combination lamp • Rear combination lamp 	Tail lamp circuit Refer to EXL-93 .	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> • Harness between IPDM E/R and the license plate lamp • License plate lamp 	License plate lamp circuit Refer to EXL-95 .	
Tail lamp and license plate lamp are not turned ON. • Parking lamp, tail lamp and license plate lamp are not turned ON. • Parking lamp, tail lamp and license plate lamp are not turned OFF. (Each illumination is turned ON/OFF.)	<p>Symptom diagnosis "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-104.</p>	Tail lamp circuit Refer to EXL-93 .	
Turn signal lamp does not blink.	Indicator lamp is normal. (The applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> • Harness between BCM and each turn signal lamp • Turn signal lamp bulb 	Turn signal lamp circuit Refer to EXL-85 .
	Indicator lamp is included	<ul style="list-style-type: none"> • Combination switch • Harness between the combination switch and BCM • BCM 	Combination switch Refer to BCS-102 .
Turn signal indicator lamp does not blink. (The turn signal indicator lamp is normal.)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> • Turn signal indicator lamp signal - Combination meter - BCM • Combination meter 	<ul style="list-style-type: none"> • Combination meter Data monitor "TURN IND" • BCM (FLASHER) Active test "FLASHER"
	Both sides (Only when activating the hazard warning lamp with the ignition switch OFF)	<ul style="list-style-type: none"> • Combination meter power supply and the ground circuit • Combination meter 	Combination meter Power supply and the ground circuit Refer to MWI-45 .
• Hazard warning lamp does not activate. • Hazard warning lamp continues activating. (Turn signal is normal.)	<ul style="list-style-type: none"> • Hazard switch • Harness between the hazard switch and BCM • BCM 	Hazard switch Refer to EXL-91 .	

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item
Rear fog lamp is not turned ON.	Rear fog lamp indicator lamp is normal.	<ul style="list-style-type: none">• Harness between BCM and rear fog lamp• Rear fog lamp bulb• BCM Rear fog lamp circuit Refer to EXL-96 .
	Rear fog lamp indicator lamp is included.	<ul style="list-style-type: none">• Rear fog lamp indicator lamp is included.• Harness between combination switch and BCM• BCM Combination switch Refer to BCS-102 .

NORMAL OPERATING CONDITION

[XENON TYPE]

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:0000000010840585

XENON HEADLAMP

- Brightness and the color of light may change slightly immediately after turning the headlamp ON until the xenon bulb becomes stable. This is normal.
- Illumination time lag may occur between right and left. This is normal.

AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area etc.) while using the auto light system. This causes for the control difference. This is normal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

Description

INFOID:0000000010840586

The headlamp (both sides) does not switch to the high beam when setting to the lighting switch HI or PASS.

Diagnosis Procedure

INFOID:0000000010840587

1. COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-102, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2. CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		Except for HI or PASS	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

3. HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-75, "Description"](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:0000000010840588

The headlamps (both sides) are not turned ON in any condition.

Diagnosis Procedure

INFOID:0000000010840589

1.CHECK COMBINATION SWITCH

Check the combination switch. Refer to [BCS-102, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

3.HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-77, "Description"](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:0000000010840590

The parking, license plate, tail, side marker lamps and each illumination are not turned ON in any condition.

Diagnosis Procedure

INFOID:0000000010840591

1. COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-102, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2. CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM.

3. TAIL LAMP CIRCUIT INSPECTION

Check the tail lamp circuit. Refer to [EXL-93, "Component Function Check"](#).

Is the tail lamp circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

HEADLAMP AIMING ADJUSTMENT

Description

INFOID:000000010840592

PREPARATION BEFORE ADJUSTING

NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.


- Wipe out dirt on the headlamp.

CAUTION:

Never use organic solvent (thinner, gasoline etc.)

- Ride alone on the driver seat.

AIMING ADJUSTMENT SCREW



JPLIA1538ZZ

A. Headlamp (RH) adjustment screw B. Headlamp (LH) adjustment screw

←: Vehicle center

Adjustment screw		Screw driver rotation	Facing direction
A	Headlamp (RH)	Clockwise	UP
		Counterclockwise	DOWN

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

Adjustment screw		Screw driver rotation	Facing direction
B	Headlamp (LH)	Clockwise	UP
		Counterclockwise	DOWN

Aiming Adjustment Procedure

INFOID:000000010840593

1. Place the screen.

NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp center and the screen.

3. Start the engine. Turn the headlamp (LO) ON.

NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.


CAUTION:

Never cover the lens surface with a tape etc. The lens is made of resin.

4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

Light axis measurement range (R) : 350 ± 175 mm (13.78 ± 6.89 in)

Low beam distribution on the screen




JSLIA0005ZZ

5. Adjust the cutoff line height with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



JSLIA0006ZZ

**Distance between the headlamp center : 10 m (32.8 ft)
and the screen (L)**

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

REMOVAL AND INSTALLATION FRONT COMBINATION LAMP

Exploded View


INFOID:0000000010840594

REMOVAL



1. Front combination lamp

DISASSEMBLY



- | | | |
|--------------------------------|---------------------------------------|-------------------------------|
| 1. Front turn signal lamp bulb | 2. Front turn signal lamp bulb socket | 3. Parking lamp bulb |
| 4. Parking lamp bulb socket | 5. Resin cap | 6. Seal packing |
| 7. Xenon bulb socket | 8. Xenon bulb | 9. Seal packing |
| 10. HID control unit | 11. Bumper bracket | 12. Headlamp housing assembly |
| 13. Retaining spring | | |

✖ : Always replace after every disassembly.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

Removal and Installation


INFOID:0000000010840595

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-16, "Removal and Installation"](#).
2. Remove the headlamp mounting bolts and clip.
3. Remove the holding clip (A)* and harness clip.
*: Left side only
4. Pull out the headlamp assembly forward the vehicle.
5. Disconnect the connector before removing the headlamp housing assembly.



INSTALLATION

Install in the reverse order of removal.

NOTE:

- After installation, perform aiming adjustment. Refer to [EXL-105, "Description"](#).
- After installation, check that headlamp lighting. Refer to [EXL-109, "Inspection After Installation \(HID Control Unit\)"](#).

Replacement

INFOID:0000000010840596

CAUTION:


- Disconnect the battery negative terminal or remove the fuse.
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

HEADLAMP BULB

1. Remove the fender protector. Keep a service area. Refer to [EXT-35, "FENDER PROTECTOR : Removal and Installation"](#).
2. Rotate the resin cap counterclockwise and unlock it.
3. Rotate the bulb socket counterclockwise and unlock it.
4. Remove the retaining spring lock. Remove the bulb from the headlamp housing assembly.

CAUTION:

Never break the xenon bulb ceramic tube when replacing the bulb.



PARKING LAMP BULB

1. Remove the fender protector. Keep a service area. Refer to [EXT-35, "FENDER PROTECTOR : Removal and Installation"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the bulb socket.

FRONT COMBINATION LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

FRONT TURN SIGNAL LAMP BULB

1. Remove the fender protector. Keep a service area. Refer to [EXT-35, "FENDER PROTECTOR : Removal and Installation".](#)
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the bulb socket.

SIDE MARKER LAMP

Replacement integral with front combination lamp. Refer to [EXL-107, "Exploded View".](#)

Disassembly and Assembly

INFOID:0000000010840597

DISASSEMBLY


1. Rotate the resin cap counterclockwise and unlock it.
2. Rotate the xenon bulb socket counterclockwise and unlock it.
3. Remove the retaining spring lock. Remove the xenon bulb.
4. Remove the bumper bracket.
5. Remove the HID control unit installation screw.
6. Remove the screw. Disconnect the connector from HID control unit.
7. Pull out the xenon bulb socket from the headlamp housing assembly.
8. Rotate the parking lamp bulb socket counterclockwise and unlock it.
9. Remove the bulb from the parking lamp bulb socket.
10. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
11. Remove the bulb from the front turn signal lamp bulb socket.

ASSEMBLY

Assemble in the reverse order of disassembly.

CAUTION:

- When xenon bulb socket installation, fix xenon bulb socket harness (A) to a protruding portion (B) in a headlamp housing surely.



- Install HID control unit securely.
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.
- Seal packing cannot be reused.
- After installation, check that headlamp lighting. Refer to [EXL-109, "Inspection After Installation \(HID Control Unit\)".](#)

Inspection After Installation (HID Control Unit)

INFOID:0000000010840598

CAUTION:

Temporarily install the headlamp on the vehicle. Connect the battery to the connector (vehicle side) when checking ON/OFF status.

XENON HEADLAMP LIGHTING CHECK

When recycled HID Control Unit, check the following, when there is abnormality replace the HID Control Unit.

1. Xenon bulb is cold condition (turn OFF more than 10 minutes), and repetition does headlamp turned ON/OFF, check that a headlamp illuminated it surely.
2. Headlamp is turn ON until the xenon bulb becomes stable condition (for about 5 minutes) from cold condition, check that there are not on and off light, abnormality such as blinking.

FRONT COMBINATION LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

3. Xenon bulb is warm condition (turn ON more than 15 minutes and turn OFF for 1 minute), and repetition does headlamp turned ON/OFF, check that a headlamp illuminated it surely.
4. Headlamp is turn ON for about 30 minutes, check that there are not on and off light, abnormality such as blinking whether brightness of right and left does not have a difference.

DAYTIME RUNNING LIGHT

[XENON TYPE]


< REMOVAL AND INSTALLATION >

DAYTIME RUNNING LIGHT

Exploded View

INFOID:0000000010840599

FOR NISMO




1. Bumper fascia

2. U nut

3. Daytime running light

: N·m (kg-m, in-lb)

EXCEPT FOR NISMO



1. Bumper fascia

2. U nut

3. Daytime running light

A. Clip

: N·m (kg-m, in-lb)

Removal and Installation

INFOID:0000000010840600

CAUTION:

Disconnect the battery negative terminal or remove the fuse to prevent electric leakage.

REMOVAL

DAYTIME RUNNING LIGHT

[XENON TYPE]

< REMOVAL AND INSTALLATION >

For NISMO

1. Remove front fender protector to make work space. Refer to [EXT-35, "FENDER PROTECTOR : Removal and Installation"](#).
2. Disconnect daytime running light harness connector.
3. Remove daytime running light fixing screws, and then remove daytime running light.

Except For NISMO

1. Remove front fender protector to make work space. Refer to [EXT-35, "FENDER PROTECTOR : Removal and Installation"](#).
2. Disconnect daytime running light harness connector.
3. Remove daytime running light mounting bolts and clip, and then remove daytime running light.

INSTALLATION

Install in the reverse order of removal.

OPTICAL SENSOR


[XENON TYPE]

< REMOVAL AND INSTALLATION >

OPTICAL SENSOR

Exploded View

INFOID:0000000010840601



JPLIA1543ZZ

1. Optical sensor

Removal and Installation

INFOID:0000000010840602

REMOVAL

1. Insert an appropriate tool between the optical sensor and the instrument upper panel. Pull out the optical sensor upward.
2. Disconnect the connector. Remove the optical sensor.

INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[XENON TYPE]

LIGHTING & TURN SIGNAL SWITCH

Exploded View

INFOID:0000000010840603

The lighting & turn switch is integrated in the combination switch. Refer to [BCS-107, "Exploded View".](#)

HAZARD SWITCH


[XENON TYPE]

< REMOVAL AND INSTALLATION >

HAZARD SWITCH

Exploded View

INFOID:0000000010840604



1. Hazard switch

Removal and Installation

INFOID:0000000010840605

REMOVAL

1. Remove the console finisher. Refer to [IP-25, "Exploded View"](#).
2. Remove the hazard switch from the console finisher.

INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

SIDE TURN SIGNAL LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

SIDE TURN SIGNAL LAMP

Exploded View

INFOID:0000000010840606



1. Side turn signal lamp connector
2. Side turn signal lamp

Removal and Installation

INFOID:0000000010840607

CAUTION:

Disconnect battery negative terminal or remove the fuse.

REMOVAL


1. Remove the side turn signal lamp in numerical order shown in the figure.

◀ : Vehicle front

2. Disconnect the side turn signal lamp connector.

NOTE:

Support the vehicle-side harness of the side turn signal lamp with tape so that it does not drop inside the front fender.



INSTALLATION

1. Connect the connector.
2. Fix the pawl-side behind the side turn signal lamp housing first, then push the resin clip-side.

Replacement

INFOID:0000000010840608

SIDE TURN SIGNAL LAMP BULB

Replace the side turn signal lamp as an assembly because it cannot be disassembled.

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[XENON TYPE]

REAR COMBINATION LAMP

Exploded View

INFOID:0000000010840609


REMOVAL



1. EPT sealer
2. Seal packing
3. Rear combination lamp assembly
4. Rear combination lamp finisher

✖ : Always replace after every disassembly.

DISASSEMBLY



1. Rear turn signal lamp bulb
2. Rear turn signal lamp bulb socket
3. Back-up lamp bulb socket
4. Back-up lamp

Removal and Installation

INFOID:0000000010840610

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Remove the rear combination lamp finisher.
2. Remove the luggage side finisher upper / trunk side finisher.
Coupe models: Refer to [INT-31, "Exploded View"](#).
Roadster models: Refer to [INT-75, "Exploded View"](#).
3. Remove the rear combination lamp mounting nut and bolts.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

REAR COMBINATION LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

4. Pull the rear combination lamp toward rear of the vehicle.
5. Disconnect the rear combination lamp connector.

INSTALLATION


Install in the reverse order of removal.

CAUTION:

Always replace EPT sealer and seal packing with a new one, if rear combination lamp assembly is reused.

Installation EPT sealer

1. Remove the EPT sealer from rear combination lamp assembly.
2. Apply new EPT sealer within mark off line (A) surface while following the mark off line (B) as shown in the figure.



INFOID:000000010840611

Replacement

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

REAR TURN SIGNAL LAMP BULB

1. Remove the rear combination lamp assembly.
2. Turn the rear turn signal lamp bulb socket counterclockwise and unlock it.
3. Remove the bulb from the socket.

BACK-UP LAMP BULB

1. Remove the rear combination lamp assembly.
2. Turn the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the socket.

STOP/TAIL LAMP

Replacement integral with rear combination lamp. Refer to [EXL-117, "Exploded View"](#).

REAR SIDE MARKER LAMP


Replacement integral with rear combination lamp. Refer to [EXL-117, "Exploded View"](#).

< REMOVAL AND INSTALLATION >

HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:0000000010840612



1. Seal packing 2. High-mounted stop lamp

○ : Metal clip

✖ : Always replace after every disassembly.

Removal and Installation

INFOID:0000000010840613

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Wrap the tip of remover tool with a cloth to protect the body from damage.

REMOVAL

1. Remove the back door trim / trunk lid trim.
Coupe models: Refer to [INT-33, "Exploded View"](#).
Roadster models: Refer to [INT-79, "Exploded View"](#).
2. Remove the high-mounted stop lamp mounting nut.
3. Disconnect the high-mounted stop lamp connector.
4. Insert any appropriate tool in high-mounted stop lamp and a gap of the back door. Remove the metal clip.
5. Remove the high-mounted stop lamp from the back door.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Seal packing cannot be reused.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

LICENSE PLATE LAMP

Exploded View

INFOID:0000000010840614



1. License plate lamp

Removal and Installation


INFOID:0000000010840615

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Remove the license plate lamp in numerical order.
2. Disconnect the license plate lamp connector.
3. Remove the license plate lamp.



INSTALLATION

1. Connect the license plate lamp connector.
2. Fix the pawl side. And then push the resin clip side.

Replacement

INFOID:0000000010840616

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

LICENSE PLATE LAMP BULB


1. Remove the license plate lamp.

LICENSE PLATE LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

2. Turn the bulb socket (1) counterclockwise and unlock it.
3. Remove the bulb (2) from the socket.



A
B
C
D
E
F
G
H
I
J
K

EXL

M
N
O
P

REAR FOG LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

REAR FOG LAMP

Exploded View

INFOID:0000000010840617



1. Rear fog lamp bracket

2. Rear fog lamp

Removal and Installation


INFOID:0000000010840618

CAUTION:

Disconnect battery negative terminal or remove the fuse.

REMOVAL

1. Remove the clip (A), keep a service area.
2. Remove the rear fog lamp mounting nuts.
3. Turn the bulb socket counterclockwise and unlock it.
4. Remove the rear fog lamp from the rear fog lamp bracket.
5. Disconnect the rear fog lamp connector.
6. Remove the rear fog lamp bracket from the rear bumper fascia.



INSTALLATION

Installation is the reverse order of removal.

Replacement

INFOID:0000000010840619

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.


REAR FOG LAMP BULB

REAR FOG LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

1. Turn the bulb socket (1) counterclockwise and unlock it.
2. Remove the bulb (2) from the rear fog lamp bulb socket.



A
B
C
D
E
F
G
H
I
J
K

EXL

M
N
O
P

SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

[XENON TYPE]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:0000000010840620

Item	Type	Wattage (W)
Front combination lamp	Headlamp (HI/LO)	D2S (Xenon) 35
	Front turn signal lamp	7444NA (Amber) 28/8
	Parking lamp	W5W 5
	Front side marker lamp	LED —
Side turn signal lamp	LED	—
Daytime running light	LED	—
Rear combination lamp	Stop lamp/Tail lamp	LED —
	Rear turn signal lamp	WY21W (Amber) 21
	Rear side marker lamp	LED —
	Back-up lamp	W16W 16
License plate lamp	W5W	5
High-mounted stop lamp	LED	—
Rear fog lamp	W21W	21