

# SECTION ADP

## AUTOMATIC DRIVE POSITIONER

A  
B  
C  
D  
E

### CONTENTS

<b>BASIC INSPECTION .....</b>	<b>5</b>	AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram .....	<b>13</b>
<b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>	<b>5</b>	AUTOMATIC DRIVE POSITIONER SYSTEM : System Description .....	<b>13</b>
Work Flow .....	5	AUTOMATIC DRIVE POSITIONER SYSTEM : Component Parts Location .....	<b>15</b>
<b>INSPECTION AND ADJUSTMENT .....</b>	<b>8</b>	AUTOMATIC DRIVE POSITIONER SYSTEM : Component Description .....	<b>16</b>
<b>ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL .....</b>	<b>8</b>	<b>MANUAL FUNCTION .....</b>	<b>17</b>
ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description .....	8	MANUAL FUNCTION : System Diagram .....	18
ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement .....	8	MANUAL FUNCTION : System Description .....	18
<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT .....</b>	<b>8</b>	MANUAL FUNCTION : Component Parts Location .....	20
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....	8	MANUAL FUNCTION : Component Description .....	21
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement .....	8	<b>SEAT SYNCHRONIZATION FUNCTION .....</b>	<b>22</b>
<b>SYSTEM INITIALIZATION .....</b>	<b>9</b>	SEAT SYNCHRONIZATION FUNCTION : System Diagram .....	22
SYSTEM INITIALIZATION : Description .....	9	SEAT SYNCHRONIZATION FUNCTION : System Description .....	22
SYSTEM INITIALIZATION : Special Repair Requirement .....	9	SEAT SYNCHRONIZATION FUNCTION : Component Parts Location .....	24
<b>MEMORY STORING .....</b>	<b>9</b>	SEAT SYNCHRONIZATION FUNCTION : Component Description .....	25
MEMORY STORING : Description .....	9	<b>MEMORY FUNCTION .....</b>	<b>26</b>
MEMORY STORING : Special Repair Requirement .....	10	MEMORY FUNCTION : System Diagram .....	27
<b>SYSTEM SETTING .....</b>	<b>10</b>	MEMORY FUNCTION : System Description .....	27
SYSTEM SETTING : Description .....	11	MEMORY FUNCTION : Component Parts Location .....	29
SYSTEM SETTING : Special Repair Requirement .....	11	MEMORY FUNCTION : Component Description .....	30
<b>SYSTEM DESCRIPTION .....</b>	<b>13</b>	<b>EXIT ASSIST FUNCTION .....</b>	<b>31</b>
<b>AUTOMATIC DRIVE POSITIONER SYSTEM .....</b>	<b>13</b>	EXIT ASSIST FUNCTION : System Diagram .....	31
<b>AUTOMATIC DRIVE POSITIONER SYSTEM .....</b>	<b>13</b>	EXIT ASSIST FUNCTION : System Description .....	31
		EXIT ASSIST FUNCTION : Component Parts Location .....	33
		EXIT ASSIST FUNCTION : Component Description .....	34
		<b>ENTRY ASSIST FUNCTION .....</b>	<b>35</b>

ADP

K  
L  
M  
N  
O  
P

ENTRY ASSIST FUNCTION : System Diagram	35	DRIVER SEAT CONTROL UNIT .....	56
ENTRY ASSIST FUNCTION : System Description	35	DRIVER SEAT CONTROL UNIT :	
... 35		Diagnosis Procedure .....	56
ENTRY ASSIST FUNCTION : Component Parts		DRIVER SEAT CONTROL UNIT : Special Repair	
Location .....	37	Requirement .....	57
ENTRY ASSIST FUNCTION :		AUTOMATIC DRIVE POSITIONER CONTROL	
Component Description .....	38	UNIT .....	57
<b>INTELLIGENT KEY INTERLOCK FUNCTION .....</b>	<b>39</b>	AUTOMATIC DRIVE POSITIONER CONTROL	
INTELLIGENT KEY INTERLOCK FUNCTION :		UNIT : Diagnosis Procedure .....	57
System Diagram .....	39	AUTOMATIC DRIVE POSITIONER CONTROL	
INTELLIGENT KEY INTERLOCK FUNCTION :		UNIT : Special Repair Requirement .....	58
System Description .....	39	SLIDING SWITCH .....	59
INTELLIGENT KEY INTERLOCK FUNCTION :		Description .....	59
Component Parts Location .....	41	Component Function Check .....	59
INTELLIGENT KEY INTERLOCK FUNCTION :		Diagnosis Procedure .....	59
Component Description .....	42	Component Inspection .....	60
<b>DIAGNOSIS SYSTEM (DRIVER SEAT C/U) .....</b>	<b>43</b>	RECLINING SWITCH .....	61
Diagnosis Description .....	43	Description .....	61
CONSULT Function .....	43	Component Function Check .....	61
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>46</b>	Diagnosis Procedure .....	61
<b>U1000 CAN COMM CIRCUIT .....</b>	<b>46</b>	Component Inspection .....	62
Description .....	46	LIFTING SWITCH (FRONT) .....	63
DTC Logic .....	46	Description .....	63
Diagnosis Procedure .....	46	Component Function Check .....	63
Special Repair Requirement .....	46	Diagnosis Procedure .....	63
Component Inspection .....	64	Component Inspection .....	64
<b>U1010 CONTROL UNIT (CAN) .....</b>	<b>47</b>	LIFTING SWITCH (REAR) .....	65
DTC Logic .....	47	Description .....	65
Diagnosis Procedure .....	47	Component Function Check .....	65
<b>B2112 SLIDING MOTOR .....</b>	<b>48</b>	Diagnosis Procedure .....	65
Description .....	48	Component Inspection .....	66
DTC Logic .....	48	TILT SWITCH .....	67
Diagnosis Procedure .....	48	Description .....	67
<b>B2113 RECLINING MOTOR .....</b>	<b>50</b>	Component Function Check .....	67
Description .....	50	Diagnosis Procedure .....	67
DTC Logic .....	50	Component Inspection .....	68
Diagnosis Procedure .....	50	TELESCOPIC SWITCH .....	69
<b>B2116 TILT MOTOR .....</b>	<b>52</b>	Description .....	69
DTC Logic .....	52	Component Function Check .....	69
Diagnosis Procedure .....	52	Diagnosis Procedure .....	69
<b>B2128 UART COMMUNICATION LINE .....</b>	<b>54</b>	Component Inspection .....	70
Description .....	54	SEAT MEMORY SWITCH .....	71
DTC Logic .....	54	Description .....	71
Diagnosis Procedure .....	54	Component Function Check .....	71
<b>B2130 EEPROM .....</b>	<b>55</b>	Diagnosis Procedure .....	71
DTC Logic .....	55	Component Inspection .....	72
Diagnosis Procedure .....	55	DOOR MIRROR REMOTE CONTROL	
<b>POWER SUPPLY AND GROUND CIRCUIT .....</b>	<b>56</b>	SWITCH .....	74
<b>BCM .....</b>	<b>56</b>	CHANGE OVER SWITCH .....	74
BCM : Diagnosis Procedure .....	56	CHANGE OVER SWITCH : Description .....	74

CHANGE OVER SWITCH : Component Function Check .....	74
CHANGE OVER SWITCH : Diagnosis Procedure .....	74
CHANGE OVER SWITCH : Component Inspection .....	75
<b>MIRROR SWITCH .....</b>	<b>76</b>
MIRROR SWITCH : Description .....	76
MIRROR SWITCH : Component Function Check .....	76
MIRROR SWITCH : Diagnosis Procedure .....	76
MIRROR SWITCH : Component Inspection .....	78
<b>POWER SEAT SWITCH GROUND CIRCUIT .....</b>	<b>79</b>
Diagnosis Procedure .....	79
<b>TILT &amp; TELESCOPIC SWITCH GROUND CIRCUIT .....</b>	<b>80</b>
Diagnosis Procedure .....	80
<b>SLIDING SENSOR .....</b>	<b>81</b>
Description .....	81
Component Function Check .....	81
Diagnosis Procedure .....	81
<b>RECLINING SENSOR .....</b>	<b>84</b>
Description .....	84
Component Function Check .....	84
Diagnosis Procedure .....	84
<b>LIFTING SENSOR (FRONT) .....</b>	<b>87</b>
Description .....	87
Component Function Check .....	87
Diagnosis Procedure .....	87
<b>LIFTING SENSOR (REAR) .....</b>	<b>90</b>
Description .....	90
Component Function Check .....	90
Diagnosis Procedure .....	90
<b>TILT SENSOR .....</b>	<b>93</b>
Description .....	93
Component Function Check .....	93
Diagnosis Procedure .....	93
<b>TELESCOPIC SENSOR .....</b>	<b>96</b>
Description .....	96
Component Function Check .....	96
Diagnosis Procedure .....	96
<b>MIRROR SENSOR .....</b>	<b>99</b>
<b>DRIVER SIDE .....</b>	<b>99</b>
DRIVER SIDE : Description .....	99
DRIVER SIDE : Component Function Check .....	99
DRIVER SIDE : Diagnosis Procedure .....	99
<b>PASSENGER SIDE .....</b>	<b>100</b>
PASSENGER SIDE : Description .....	100
PASSENGER SIDE : Component Function Check .....	100
PASSENGER SIDE : Diagnosis Procedure .....	101
<b>SLIDING MOTOR .....</b>	<b>103</b>
Description .....	103
Component Function Check .....	103
Diagnosis Procedure .....	103
<b>RECLINING MOTOR .....</b>	<b>105</b>
Description .....	105
Component Function Check .....	105
Diagnosis Procedure .....	105
<b>LIFTING MOTOR (FRONT) .....</b>	<b>107</b>
Description .....	107
Component Function Check .....	107
Diagnosis Procedure .....	107
<b>LIFTING MOTOR (REAR) .....</b>	<b>109</b>
Description .....	109
Component Function Check .....	109
Diagnosis Procedure .....	109
<b>TILT MOTOR .....</b>	<b>111</b>
Description .....	111
Component Function Check .....	111
Diagnosis Procedure .....	111
<b>TELESCOPIC MOTOR .....</b>	<b>113</b>
Description .....	113
Component Function Check .....	113
Diagnosis Procedure .....	113
<b>DOOR MIRROR MOTOR .....</b>	<b>115</b>
Description .....	115
Component Function Check .....	115
Diagnosis Procedure .....	115
Component Inspection .....	116
<b>SEAT MEMORY INDICATOR .....</b>	<b>118</b>
Description .....	118
Component Function Check .....	118
Diagnosis Procedure .....	118
Component Inspection .....	119
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>120</b>
<b>DRIVER SEAT CONTROL UNIT .....</b>	<b>120</b>
Reference Value .....	120
Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM - .....	127
Fail Safe .....	140
DTC Index .....	141
<b>AUTOMATIC DRIVE POSITIONER CONTROL UNIT .....</b>	<b>142</b>
Reference Value .....	142
Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM - .....	145
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>159</b>
Reference Value .....	159
Wiring Diagram - BCM - .....	183
Fail-safe .....	197

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

ADP

DTC Inspection Priority Chart .....	198	<b>STEERING TILT .....</b>	210
DTC Index .....	199	STEERING TILT : Diagnosis Procedure .....	210
<b>SYMPTOM DIAGNOSIS .....</b>	202	<b>DOOR MIRROR .....</b>	211
<b>MANUAL FUNCTION DOES NOT OPERATE .....</b>	202	DOOR MIRROR : Diagnosis Procedure .....	211
<b>ALL COMPONENT .....</b>	202	<b>MEMORY INDICATE DOES NOT OPERATE .....</b>	212
ALL COMPONENT : Diagnosis Procedure .....	202	Diagnosis Procedure .....	212
<b>POWER SEAT .....</b>	202	<b>SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE .....</b>	213
POWER SEAT : Diagnosis Procedure .....	202	Diagnosis Procedure .....	213
<b>STEERING POSITION FUNCTION DOES NOT OPERATE .....</b>	202	<b>ENTRY/EXIT ASSIST FUNCTION DOES NOT OPERATE .....</b>	214
STEERING POSITION FUNCTION DOES NOT OPERATE : Diagnosis Procedure .....	202	Diagnosis Procedure .....	214
<b>SEAT SLIDING .....</b>	203	<b>INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE .....</b>	215
SEAT SLIDING : Diagnosis Procedure .....	203	Diagnosis Procedure .....	215
<b>SEAT RECLINING .....</b>	203	<b>NORMAL OPERATING CONDITION .....</b>	216
SEAT RECLINING : Diagnosis Procedure .....	203	Description .....	216
<b>SEAT LIFTING (FRONT) .....</b>	204	<b>PRECAUTION .....</b>	217
SEAT LIFTING (FRONT) : Diagnosis Procedure .....	204	<b>PRECAUTIONS .....</b>	217
<b>SEAT LIFTING (REAR) .....</b>	204	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	217
SEAT LIFTING (REAR) : Diagnosis Procedure ....	204	Precautions for Removing Battery Terminal .....	217
<b>STEERING TILT .....</b>	205	Service .....	217
STEERING TILT : Diagnosis Procedure .....	205	Work .....	218
<b>STEERING TELESCOPIC .....</b>	205	<b>REMOVAL AND INSTALLATION .....</b>	219
STEERING TELESCOPIC : Diagnosis Procedure .....	206	<b>DRIVER SEAT CONTROL UNIT .....</b>	219
<b>DOOR MIRROR .....</b>	206	Exploded View .....	219
DOOR MIRROR : Diagnosis Procedure .....	206	Removal and Installation .....	219
<b>MEMORY FUNCTION DOES NOT OPERATE .....</b>	208	<b>AUTOMATIC DRIVE POSITIONER CON- TROL UNIT .....</b>	220
<b>ALL COMPONENT .....</b>	208	Exploded View .....	220
ALL COMPONENT : Diagnosis Procedure .....	208	Removal and Installation .....	220
<b>SEAT SLIDING .....</b>	208	<b>SEAT MEMORY SWITCH .....</b>	221
SEAT SLIDING : Diagnosis Procedure .....	208	Exploded View .....	221
<b>SEAT RECLINING .....</b>	209	Removal and Installation .....	221
SEAT RECLINING : Diagnosis Procedure .....	209	<b>POWER SEAT SWITCH .....</b>	222
<b>SEAT LIFTING (FRONT) .....</b>	209	Exploded View .....	222
SEAT LIFTING (FRONT) : Diagnosis Procedure .....	209	Removal and Installation .....	222
<b>SEAT LIFTING (REAR) .....</b>	209	<b>TILT&amp;TELESCOPIC SWITCH .....</b>	223
SEAT LIFTING (REAR) : Diagnosis Procedure .....	209	Exploded View .....	223
<b>STEERING TELESCOPIC .....</b>	210	Removal and Installation .....	223
STEERING TELESCOPIC : Diagnosis Procedure .....	210		

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

#### Work Flow

INFOID:000000010596300

#### OVERALL SEQUENCE



#### DETAILED FLOW

A  
B  
C  
D  
E  
F  
G  
H  
I  
ADP  
K  
L  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

## 1. GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

## 2. CHECK DTC WITH AUTOMATIC DRIVE POSITIONER SYSTEM

Check "Self Diagnostic Result" with CONSULT. Refer to [ADP-141, "DTC Index"](#).

Is any symptom described and any DTC is displayed?

Symptom is described, DTC is displayed.>>GO TO 3.

Symptom is not described, DTC is displayed.>>GO TO 6.

Symptom is described, DTC is not displayed.>>GO TO 4.

## 3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

>> GO TO 6.

## 4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

>> GO TO 5.

## 5. CHECK NORMAL OPERATING CONDITION

Check normal operating condition. Refer to [ADP-216, "Description"](#).

Is the incident normal operation?

YES >> INSPECTION END

NO >> GO TO 7.

## 6. PERFORM DTC CONFIRMATION PROCEDURE

Perform the confirmation procedure for the detected DTC.

Is the DTC displayed?

YES >> GO TO 8.

NO >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

## 7. PERFORM COMPONENT FUNCTION CHECK

Perform the component function check for the isolated malfunctioning point.

>> GO TO 8.

## 8. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Isolate the malfunctioning point by performing the diagnosis procedure relevant to the symptom during the component diagnosis.

>> GO TO 9.

## 9. REPAIR OR REPLACE

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. FINAL CHECK

Perform the DTC confirmation procedure (if DTC is detected) or component function check (if no DTC is detected) again, and then check that the malfunction can be repaired securely.

Are all malfunctions corrected?

## DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

YES >> INSPECTION END

Symptom is detected.>> GO TO 5.

DTC is detected.>> GO TO 6.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

#### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000010596301

Each function is reset to the following condition when the battery terminal is disconnected. Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Function	Condition	Procedure
Memory (Seat, steering, mirror)	Erased	Perform storing
Entry/exit assist	ON	Perform initialization
		Set slide amount*
Intelligent Key interlock	Erased	Perform storing
Seat synchronization	OFF	—

\* : Default value is 40mm.

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000010596302

#### 1. SYSTEM INITIALIZATION

Perform system initialization. Refer to [ADP-9, "SYSTEM INITIALIZATION : Description"](#).

>> GO TO 2.

#### 2. SYSTEM SETTING

Perform system setting. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

>> GO TO 3.

#### 3. MEMORY STORAGE

Perform memory storage. Refer to [ADP-9, "MEMORY STORING : Description"](#).

>> END

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000010596303

Each function is reset to the following condition when the driver seat control unit is replaced. Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Function	Condition	Procedure
Memory (Seat, steering, mirror)	Erased	Perform storing
Entry/exit assist	ON	Perform initialization
		Set slide amount*
Intelligent Key interlock	Erased	Perform storing
Seat synchronization	OFF	—

\* : Default value is 40mm.

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Re-

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

quirement

INFOID:0000000010596304

A

## 1. SYSTEM INITIALIZATION

Perform system initialization. Refer to [ADP-9, "SYSTEM INITIALIZATION : Description"](#).

>> GO TO 2.

## 2. SYSTEM SETTING

Perform system setting. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

>> GO TO 3.

## 3. MEMORY STORAGE

Perform memory storage. Refer to [ADP-9, "MEMORY STORING : Description"](#).

>> END

## SYSTEM INITIALIZATION

### SYSTEM INITIALIZATION : Description

INFOID:0000000010596305

G

Always perform the initialization when the battery terminal is disconnected or the driver seat control unit is replaced.

The entry/exit assist function will not operate normally if no initialization is performed. Refer to [ADP-9, "SYSTEM INITIALIZATION : Special Repair Requirement"](#).

### SYSTEM INITIALIZATION : Special Repair Requirement

INFOID:0000000010596306

I

#### INITIALIZATION PROCEDURE

##### 1. CHOOSE METHOD

There are two initialization methods.

ADP

Which method do you use?

K

With door switch>>GO TO 2.

L

With vehicle speed>>GO TO 4.

##### 2. STEP A-1

M

Turn ignition switch from ACC to OFF position.

N

>> GO TO 3.

##### 3. STEP A-2

O

Driver door switch is ON (open) → OFF (close) → ON (open).

P

>> END

##### 4. STEP B-1

Q

Drive the vehicle at more than 25 km/h (16 MPH).

R

>> END

## MEMORY STORING

### MEMORY STORING : Description

INFOID:0000000010596307

S

Always perform the memory storage when the battery terminal is disconnected or the driver seat control unit is replaced. The memory function and Intelligent Key interlock function will not operate normally if no memory storage is performed. Refer to [ADP-10, "MEMORY STORING : Special Repair Requirement"](#).

T

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## MEMORY STORING : Special Repair Requirement

INFOID:0000000010596308

### Memory Storage Procedure

Two positions for the driver seat, steering column and outside mirror can be stored for memory operation by following procedure.

#### 1. STEP 1

Check all of the following conditions are satisfied.

- Engine is not in running status.
- Power seat switch, tilt & telescopic switch, door mirror remote control switch are OFF.
- Automatic drive positioner system any function are not operating.
- CONSULT is not connected.

>> GO TO 2.

#### 2. STEP 2

Adjust driver seat, steering column and outside mirror position manually.

>> GO TO 3.

#### 3. STEP 3

1. Push set switch.

**NOTE:**

- Memory indicator for which driver seat position is already retained in memory is illuminated for 5 seconds.
- Memory indicator for which driver seat position is not retained in memory is illuminated for 0.5 second.

2. Push the memory switch (1 or 2) for at least 1 second within 5 seconds after pushing the set switch.

**NOTE:**

- When registration is performed correctly, the combination meter buzzer sounds.
- If memory is stored in the same memory switch, the previous memory will be deleted.

Do you need linking of Intelligent Key?

YES >> GO TO 5.

NO >> GO TO 4.

#### 4. STEP 4

Confirm the operation of each part with memory operation.

>> END

#### 5. STEP 5

Push the Intelligent Key unlock button within 5 seconds after pushing memory switch (while the memory indicator is turned ON).

**NOTE:**

When registration is performed correctly, the memory indicator blinks for 5 seconds and combination meter buzzer sounds.

>> GO TO 6.

#### 6. STEP 6

Confirm the operation of each part with memory operation and Intelligent Key interlock operation.

>> END

## SYSTEM SETTING

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## SYSTEM SETTING : Description

INFOID:000000010596309

The settings of the automatic driving positioner system can be changed, using CONSULT, the set switch. Always check the settings before and after disconnecting the battery terminal or replacing driver seat control unit. Refer to [ADP-11, "SYSTEM SETTING : Special Repair Requirement"](#).

### Setting Change

x: Applicable

Item	Content	CONSULT	Set switch	Factory setting
Amount of seat sliding for entry/exit assist	The amount of seat sliding for entry/exit assist can be selected from 3 items. [40mm/80mm/150mm]	x	—	40mm
Entry/exit assist (seat)	Entry/exit assist (seat) can be selected: ON (operated) – OFF (not operated)	x	x	OFF
Entry/exit assist (steering column)	Entry/exit assist (steering column) can be selected: ON (operated) – OFF (not operated)	x		ON
Seat synchronization	Seat synchronization can be selected: ON (operated) – OFF (not operated)	—	x	OFF

## SYSTEM SETTING : Special Repair Requirement

INFOID:000000010596310

### 1. CHOOSE METHOD

There are two ways of setting method.

Which method do you choose?

With CONSULT>>GO TO 2.

With set switch>>GO TO 5.

### 2. WITH CONSULT - STEP 1

Select "Work support".

ADP

>> GO TO 3.

### 3. WITH CONSULT - STEP 2

1. Select "EXIT SEAT SLIDE SETTING", or "EXIT TILT SETTING" then touch display to change between ON and OFF.
  - EXIT SEAT SLIDE SETTING: Entry/exit assist (seat)
  - EXIT TILT SETTING: Entry/exit assist (steering column)
2. Select "SEAT SLIDE VOLUME SET" and touch either of "40 mm", "80 mm", or "150 mm".
3. Then touch "OK".

>> GO TO 4.

### 4. CONFIRM THE OPERATION

Check the entry/exit assist function setting is changed.

Is the setting changed?

YES >> END

NO >> GO TO 1.

### 5. WITH SET SWITCH - STEP 1

1. Turn ignition switch OFF.
2. Push setting button and hold for more than 10 seconds.

>> GO TO 6.

### 6. CONFIRM THE OPERATION

K

L

M

N

O

P

## **INSPECTION AND ADJUSTMENT**

### < BASIC INSPECTION >

Check the entry/exit assist function setting is changed.

#### Is the setting changed?

YES    >> GO TO 7.

NO      >> GO TO 1.

### **7. WITH SET SWITCH - STEP 2**

1. Turn ignition switch ACC

2. Push setting button and hold for more than 10 seconds.

    >> GO TO 8.

### **8. CONFIRM THE OPERATION**

Check the seat synchronization function setting is changed.

#### Is the setting changed?

YES    >> END

NO      >> GO TO 7.

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### AUTOMATIC DRIVE POSITIONER SYSTEM

### AUTOMATIC DRIVE POSITIONER SYSTEM

### AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram

INFOID:0000000010596311



INFOID:0000000010596312

### AUTOMATIC DRIVE POSITIONER SYSTEM : System Description

#### OUTLINE

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

The system automatically moves the driver seat, steering column and door mirror position by the driver seat control unit and the automatic drive positioner control unit. The driver seat control unit corresponds with the automatic drive positioner control unit by UART communication.

Function		Description
Manual function		The driving position (seat, steering column and door mirror position) can be adjusted by using the power seat switch, tilt & telescopic switch or door mirror remote control switch.
Seat synchronization function		The positions of the steering column and door mirror are adjusted to the proper position automatically while linking with manual operation [seat sliding, seat lifting (rear) or seat reclining].
Memory function		The seat, steering column and outside mirror move to the stored driving position by pressing seat memory switch (1 or 2).
Entry/Exit assist function	Exit	On exit, the seat moves backward and the steering column moves upward and forward.
	Entry	On entry, the seat and steering column returns from exiting position to the previous driving position.
Intelligent Key interlock function		Perform memory operation, exiting operation and entry operation by Intelligent Key unlock operation or driver side door request switch unlock operation.

### NOTE:


The lumbar support system and the side support system are controlled independently with no link to the automatic drive positioner system.

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

AUTOMATIC DRIVE POSITIONER SYSTEM : Component Parts Location

INFOID:000000010596313



JMJIA147ZZ

ADP

K

L

M

N


O

P

- |  |  |  |
|--|--|--|
| 1. BCM   | 2. Automatic drive positioner control unit         | 3. Tilt motor  |
| 4. Telescopic motor  | 5. Unified meter and A/C amp.                      | 6. AV control unit   |
| 7. AT assembly connector                                   | 8. Tilt & telescopic switch                        | 9. Key slot  |
| 10. Tilt sensor  | 11. Telescopic sensor                              | 12. Seat memory switch                                     |
| 13. Door mirror remote control switch                      |  |  |
| A. Dash side lower (Passenger side)                        | B. View with instrument driver lower panel removed | C. View with steering column cover lower and upper removed |
| D. Behind cluster lid C                                    | E. A/T assembly<br>(TCM is built in A/T assembly)  | F. View with instrument driver lower panel removed         |
| G. View with steering column cover lower and upper removed |  |  |

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >



14. Front door switch (driver side)  
 15. A/T shift selector (detention switch)  
 16. Sliding, lifting switch (Power seat switch)  
 17. Reclining switch (power seat switch)  
 18. Door mirror (driver side)  
 19. Reclining motor  
 20. Driver seat control unit  
 21. Lifting motor (front)  
 22. Lifting motor (rear)  
 23. Sliding motor  
 24. Sliding sensor  
 H. View with center console assembly removed  
 I. View with seat cushion pad and seat back pad removed  
 J. Backside of the seat cushion

INFOID:0000000010596314

## AUTOMATIC DRIVE POSITIONER SYSTEM : Component Description

### CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> <li>Main units of automatic drive positioner system</li> <li>It is connected to the CAN.</li> <li>It communicates with the automatic drive positioner control via UART communication.</li> </ul>
Automatic drive positioner control unit	<ul style="list-style-type: none"> <li>It communicates with the driver seat control unit via UART communication.</li> <li>Perform various controls with the instructions of driver seat control unit.</li> <li>Perform the controls of the tilt &amp; telescopic and door mirror.</li> </ul>
BCM	<ul style="list-style-type: none"> <li>Transmit the following status to the driver seat control unit via CAN communication.</li> <li>Driver door: OPEN/CLOSE</li> <li>Ignition switch position: ACC/ON</li> <li>Door lock: UNLOCK (with Intelligent Key or driver side door request switch operation)</li> <li>Key ID</li> <li>Key switch: Insert/Pull out Intelligent Key</li> <li>Starter: CRANKING/OTHER</li> </ul>
Unified meter and A/C amp.	Transmit the vehicle speed signal to the driver seat control unit via CAN communication.
TCM	Transmit the shift position signal (P range) to the driver seat control unit via CAN communication.

### INPUT PARTS

#### Switches

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

Item	Function
Key slot	The key switch is installed to detect the key inserted/removed status.
Front door switch (driver side)	Detect front door (driver side) open/close status.
A/T shift selector (detention switch)	Detect the P range position of A/T selector lever.
Set switch	The registration and system setting can be performed with its operation.
Memory switch 1/2	The registration and operation can be performed with its operation.
Power seat switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> <li>• Reclining switch</li> <li>• Lifting switch (front)</li> <li>• Lifting switch (rear)</li> <li>• Sliding switch</li> </ul> <p>The specific parts can be operated with the operation of each switch.</p>
Tilt & telescopic switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> <li>• Tilt switch</li> <li>• Telescopic switch</li> </ul> <p>The specific parts can be operated with the operation of each switch.</p>
Door mirror remote control switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> <li>• Mirror switch</li> <li>• Changeover switch</li> </ul> <p>The specific parts can be operated with the operation of each switch.</p>

## Sensors

Item	Function
Door mirror sensor (driver side/passenger side)	Detect the up/down and left/right position of outside mirror face.
Tilt and telescopic sensor	Detect the up/down and left/right position of steering column.
Lifting sensor (front)	Detect the up/down position of seat lifting (front).
Lifting sensor (rear)	Detect the up/down position of seat lifting (rear).
Reclining sensor	Detect the tilt of seatback.
Sliding sensor	Detect the front/rear position of seat.

## OUTPUT PARTS

Item	Function
Door mirror motor (driver side/passenger side)	Move the outside mirror face upward/downward and leftward/rightward.
Tilt and telescopic motor	Move the steering column upward/downward and frontward/rearward.
Lifting motor (front)	Move the seat lifting (front) upward/downward.
Lifting motor (rear)	Move the seat lifting (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat frontward/rearward.
Memory indicator	Illuminates or flashes according to the registration/operation status.


## MANUAL FUNCTION

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

## MANUAL FUNCTION : System Diagram

INFOID:0000000010596315



## MANUAL FUNCTION : System Description

INFOID:0000000010596316

### OUTLINE

The driving position (seat, steering column and door mirror position) can be adjusted manually with power seat switch, tilt & telescopic switch and door mirror remote control switch.

### OPERATION PROCEDURE

1. Turn ignition switch ON.
2. Operate power seat switch, tilt & telescopic switch or door mirror remote control switch.
3. The driver seat, steering column or door mirror operates according to the operation of each switch.

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

### DETAIL FLOW

#### Seat

Order	Input	Output	Control unit condition
1	Power seat switch (sliding, lifting, reclining)	—	The power seat switch signal is inputted to the driver seat control unit when the power seat switch is operated.
2	—	Motors (sliding, lifting, reclining)	The driver seat control unit outputs signals to each motor according to the power seat switch input signal.

#### Tilt & Telescopic

Order	Input	Output	Control unit condition
1	Tilt & telescopic switch	—	The tilt & telescopic switch signal is inputted to the automatic drive positioner control unit when the tilt & telescopic switch is operated.
2	—	Motors (Tilt, telescopic)	The automatic drive positioner control unit actuates each motor according to the operation of the tilt & telescopic switch.
3	Sensors (Tilt, telescopic)	—	The automatic drive positioner control unit recognizes any operation limit of each actuator via each sensor and will not operate the actuator anymore at that time.*

\*: Tilt does not operates upward when tilt sensor volume is less than 1.2 V, tilt does not operate downward when the sensor value is bigger than 3.4 V. Telescopic does not operates backward when telescopic sensor value is less than 0.8 V, telescopic does not operate forward when the sensor value is bigger than 3.4 V.

#### Door Mirror

Order	Input	Output	Control unit condition
1	Door mirror remote control switch	—	The door mirror remote control switch signal is inputted to the automatic drive positioner control unit when the door mirror remote control switch is operated.
2	—	Motors (Door mirror motor)	The automatic drive positioner control unit actuates each motor according to the operation of the door mirror remote control switch.

#### NOTE:

The door mirrors can be operated manually when ignition switch is in either ACC or ON position. The ignition switch signal (ACC/ON) is transmitted from BCM to the driver seat control unit via CAN communication and from the driver seat control unit to the automatic drive positioner control unit via UART communication.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O


P

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

MANUAL FUNCTION : Component Parts Location

INFOID:0000000010596317




JMJA1472ZZ

- |  |  |  |
|--|--|--|
| 1. BCM   | 2. Automatic drive positioner control unit         | 3. Tilt motor  |
| 4. Telescopic motor  | 5. Unified meter and A/C amp.                      | 6. AV control unit   |
| 7. AT assembly connector                                   | 8. Tilt & telescopic switch                        | 9. Key slot  |
| 10. Tilt sensor  | 11. Telescopic sensor                              | 12. Seat memory switch                                     |
| 13. Door mirror remote control switch                      |  |  |
| A. Dash side lower (Passenger side)                        | B. View with instrument driver lower panel removed | C. View with steering column cover lower and upper removed |
| D. Behind cluster lid C                                    | E. A/T assembly<br>(TCM is built in A/T assembly)  | F. View with instrument driver lower panel removed         |
| G. View with steering column cover lower and upper removed |  |  |

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >



14. Front door switch (driver side)  
 15. A/T shift selector (detention switch)  
 16. Sliding, lifting switch (Power seat switch)  
 17. Reclining switch (power seat switch)  
 18. Door mirror (driver side)  
 19. Reclining motor  
 20. Driver seat control unit  
 21. Lifting motor (front)  
 22. Lifting motor (rear)  
 23. Sliding motor  
 24. Sliding sensor  
 H. View with center console assembly removed  
 I. View with seat cushion pad and seat back pad removed  
 J. Backside of the seat cushion

INFOID:0000000010596318

## MANUAL FUNCTION : Component Description

### CONTROL UNITS

ADP

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> <li>Operates the specific seat motor with the signal from the power seat switch.</li> <li>Transmits the ignition switch signal (ACC/ON) via UART communication to the automatic drive positioner control unit.</li> </ul>
Automatic drive positioner control unit	Operates the specific motor with the signal from tilt & telescopic switch or door mirror remote control switch.
BCM	<ul style="list-style-type: none"> <li>Recognizes the following status and transmits it to the driver seat control unit via CAN communication.</li> <li>Ignition position: ACC/ON</li> </ul>

### INPUT PARTS

#### Switches

Item	Function
Power seat switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> <li>Reclining switch</li> <li>Lifting switch (front)</li> <li>Lifting switch (rear)</li> <li>Sliding switch</li> </ul> <p>The specific parts can be operated with the operation of each switch.</p>

A  
B  
C  
D  
E  
F  
G  
H  
I

K  
L  
M  
N  
O  
P

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

Item	Function
Tilt & telescopic switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> <li>• Tilt switch</li> <li>• Telescopic switch</li> </ul> <p>The specific parts can be operated with the operation of each switch.</p>
Door mirror remote control switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> <li>• Mirror switch</li> <li>• Changeover switch</li> </ul> <p>The specific parts can be operated with the operation of each switch.</p>

## Sensors

Item	Function
Tilt and telescopic sensor	Detect the up/down and left/right position of steering column.


## OUTPUT PARTS

Item	Function
Door mirror motor (driver side/passenger side)	Move the outside mirror face upward/downward and leftward/rightward.
Tilt & telescopic motor	Move the steering column upward/downward and frontward/rearward.
Lifting motor (front)	Move the seat lifter (front) upward/downward.
Lifting motor (rear)	Move the seat lifter (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat frontward/rearward.

## SEAT SYNCHRONIZATION FUNCTION

### SEAT SYNCHRONIZATION FUNCTION : System Diagram

INFOID:0000000010596319



### SEAT SYNCHRONIZATION FUNCTION : System Description

INFOID:0000000010596320

## OUTLINE

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

The steering column position and door mirror position is adjusted to the position automatically according to the direction and distance of seat movement when performing the manual operation of sliding, reclining or lifting (rear). This function saves adjusting the mirror and steering column when adjusting the seat.

### NOTE:

- This function is set to OFF before delivery (initial setting).
- For the system setting procedure. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

## OPERATION PROCEDURE

1. Turn ignition switch ON.
2. Adjust seat position [sliding, reclining, lifting (rear)].
3. The steering and outside mirror is adjusted automatically.

### NOTE:

- The seat synchronization function will not operate if seat adjusting value is more than limit value.

Item	Limit value
Seat sliding	76 [mm]
Seat reclining	9.1 [degrees]
Seat lifter (rear)	20 [mm]

- The seat synchronization function will not operate if the steering column or door mirror moves to the operating end while this function is operating. Perform memory function or drive the vehicle at vehicle speed of 7 km/h or more once to activate this function again.
- If the seat position is uncomfortable after the adjustment, seat position can be adjusted easily by memory operation.

## OPERATION CONDITION

Satisfy all of the following items. The seat synchronization function is not performed if these items are not satisfied.

Item	Request status
Ignition position	ON
System setting	ON
Switch inputs	OFF (Not operated)
• Power seat switch	
• Tilt & telescopic switch	
• Door mirror remote control switch	
• Set switch	
• Memory switch	
A/T selector lever	P position

## DETAIL FLOW


Order	Input	Output	Control unit condition
1	—	—	Perform Manual operation [Sliding, reclining or lifting (rear)].
2	Sensors [Sliding, reclining, lifting (rear)]	—	The driver seat control unit judges the direction and distance of seat movement according to the signal input from each seat sensor during manual operation.
3	—	Motors (Tilt, telescopic, outside mirror)	Driver seat control unit requests the operation to position according to the direction and distance of seat movement to the automatic drive positioner control unit via UART communication. The automatic drive positioner control unit operates each motor.
	Sensors (Tilt, telescopic, outside mirror)	—	Driver seat control unit stops the operation of each motor when the value of each sensor that is input to automatic drive positioner control unit via UART communication reaches the target address.

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

SEAT SYNCHRONIZATION FUNCTION : Component Parts Location

INFOID:0000000010596321




JMJA1472ZZ

- |  |  |  |
|--|--|--|
| 1. BCM   | 2. Automatic drive positioner control unit         | 3. Tilt motor  |
| 4. Telescopic motor  | 5. Unified meter and A/C amp.                      | 6. AV control unit   |
| 7. AT assembly connector                                   | 8. Tilt & telescopic switch                        | 9. Key slot  |
| 10. Tilt sensor  | 11. Telescopic sensor                              | 12. Seat memory switch                                     |
| 13. Door mirror remote control switch                      |  |  |
| A. Dash side lower (Passenger side)                        | B. View with instrument driver lower panel removed | C. View with steering column cover lower and upper removed |
| D. Behind cluster lid C                                    | E. A/T assembly<br>(TCM is built in A/T assembly)  | F. View with instrument driver lower panel removed         |
| G. View with steering column cover lower and upper removed |  |  |

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >



14. Front door switch (driver side)  
 15. A/T shift selector (detention switch)  
 16. Sliding, lifting switch (Power seat switch)  
 17. Reclining switch (power seat switch)  
 18. Door mirror (driver side)  
 19. Reclining motor  
 20. Driver seat control unit  
 21. Lifting motor (front)  
 22. Lifting motor (rear)  
 23. Sliding motor  
 24. Sliding sensor  
 H. View with center console assembly removed  
 I. View with seat cushion pad and seat back pad removed  
 J. Backside of the seat cushion

INFOID:0000000010596322

## SEAT SYNCHRONIZATION FUNCTION : Component Description

### CONTROL UNITS

ADP

Item	Function
Driver seat control unit	Operates the specific seat motor with the signal from the power seat switch.
Automatic drive positioner control unit	Operates the steering motor and door mirror with the instructions from the driver seat control unit.

### INPUT PARTS

#### Switches

K

L

M

N

O

P

Item	Function
Power seat switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> <li>• Reclining switch</li> <li>• Lifting switch (front)</li> <li>• Lifting switch (rear)</li> <li>• Sliding switch</li> </ul> <p>The specific parts can be operated with the operation of each switch.</p>

#### Sensors

Item	Function
Door mirror sensor (driver side/passenger side)	Detect the up/down and left/right position of outside mirror face.
Tilt and telescopic sensor	Detect the up/down and left/right position of steering column.
Lifting sensor (rear)	Detect the up/down position of seat lifter (rear).
Reclining sensor	Detect the tilt of seatback.
Sliding sensor	Detect the front/rear position of seat.

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

### OUTPUT PARTS

Item	Function
Door mirror motor (driver side/passenger side)	Move the outside mirror face upward/downward and leftward/rightward.
Tilt & telescopic motor	Move the steering column upward/downward and frontward/rearward.
Lifting motor (rear)	Move the seat lifter (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat frontward/rearward.


### MEMORY FUNCTION

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

## MEMORY FUNCTION : System Diagram

INFOID:000000010596323



## MEMORY FUNCTION : System Description

INFOID:000000010596324

### OUTLINE

The driver seat control unit can store the optimum driving positions (seat, steering column and door mirror position) for 2 people. If the front seat position is changed, one-touch (pressing desired memory switch for more than 0.5 second) operation allows changing to the other driving position.

### NOTE:

Further information for the memory storage procedure. Refer to [ADP-9, "MEMORY STORING : Description"](#).

### OPERATION PROCEDURE

- Check shift selector lever is in the P position.

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

2. Press desired memory switch for more than 0.5 second.
3. Driver seat, steering and door mirror will move to the memorized position.

## OPERATION CONDITION

Satisfy all of the following items. The memory function is not performed if these items are not satisfied.

Item	Request status
Switch inputs <ul style="list-style-type: none"><li>• Power seat switch</li><li>• Tilt &amp; telescopic switch</li><li>• Door mirror control switch</li><li>• Set switch</li><li>• Memory switch</li></ul>	OFF (Not operated)
A/T selector lever	P position
Memory function	Registered
Vehicle speed	0 km/h (0 MPH)
CONSULT	Not connected

## DETAIL FLOW


Order	Input	Output	Control unit condition
1	Memory switch	—	The memory switch signal is inputted to the automatic drive positioner control unit when memory switch 1 or 2 is operated.
2	—	Motors (Seat, Steering, door mirror)	Driver seat control unit operates each motor of seat when it recognizes the memory switch pressed for 0.5 second or more and requests each motor operation to automatic drive positioner control unit via UART communication. The automatic drive positioner control unit operates each motor.
		Memory switch Indicator	Driver seat control unit illuminates the memory indicator while either of the motors is operating.
3	Sensors (Seat, steering column, door mirror)	—	Driver seat control unit judges the operating seat position with each seat sensor input. The positions of the steering column and outside mirror are monitored with each sensor signal. Driver seat control unit stops the operation of each motor when each part reaches the recorded address.
4	—	Memory switch Indicator	Driver seat control unit illuminates the memory indicator for 5 seconds after all motors stop.

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

MEMORY FUNCTION : Component Parts Location

INFOID:000000010596325



JMJIA147ZZ

ADP

K

L

M

N


O

P

- |  |  |  |
|--|--|--|
| 1. BCM   | 2. Automatic drive positioner control unit         | 3. Tilt motor  |
| 4. Telescopic motor  | 5. Unified meter and A/C amp.                      | 6. AV control unit   |
| 7. AT assembly connector                                   | 8. Tilt & telescopic switch                        | 9. Key slot  |
| 10. Tilt sensor  | 11. Telescopic sensor                              | 12. Seat memory switch                                     |
| 13. Door mirror remote control switch                      |  |  |
| A. Dash side lower (Passenger side)                        | B. View with instrument driver lower panel removed | C. View with steering column cover lower and upper removed |
| D. Behind cluster lid C                                    | E. A/T assembly<br>(TCM is built in A/T assembly)  | F. View with instrument driver lower panel removed         |
| G. View with steering column cover lower and upper removed |  |  |

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >



14. Front door switch (driver side)  
 15. A/T shift selector (detention switch)  
 16. Sliding, lifting switch (Power seat switch)  
 17. Reclining switch (power seat switch)  
 18. Door mirror (driver side)  
 19. Reclining motor  
 20. Driver seat control unit  
 21. Lifting motor (front)  
 22. Lifting motor (rear)  
 23. Sliding motor  
 24. Sliding sensor  
 H. View with center console assembly removed  
 I. View with seat cushion pad and seat back pad removed  
 J. Backside of the seat cushion

INFOID:0000000010596326

## MEMORY FUNCTION : Component Description

### CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> <li>The address of each part is recorded.</li> <li>Operates each motor of seat to the registered position.</li> <li>Requests the operations of steering column and door mirror to automatic drive positioner control unit</li> </ul>
Automatic drive positioner control unit	Operates the steering column and door mirror with the instructions from the driver seat control.

### INPUT PARTS

#### Switches

Item	Function
Memory switch 1/2	The registration and memory function can be performed with its operation.

#### Sensors

Item	Function
Door mirror sensor (driver side/passenger side)	Detect the up/down and left/right position of outside mirror face.
Tilt & telescopic sensor	Detect the up/down and left/right position of steering column.
Lifting sensor (front)	Detect the up/down position of seat lifting (front).
Lifting sensor (rear)	Detect the up/down position of seat lifting (rear).
Reclining sensor	Detect the tilt of seatback.
Sliding sensor	Detect the front/rear position of seat.

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >


### OUTPUT PARTS

Item	Function
Door mirror motor (driver side/passenger side)	Move the outside mirror face upward/downward and leftward/rightward.
Tilt and telescopic motor	Move the steering column upward/downward and frontward/rearward.
Lifting motor (front)	Move the seat lifter (front) upward/downward.
Lifting motor (rear)	Move the seat lifter (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat frontward/rearward.
Memory indicator	Illuminates or blinks according to the registration/operation status.

### EXIT ASSIST FUNCTION

#### EXIT ASSIST FUNCTION : System Diagram

INFOID:0000000010596327



#### EXIT ASSIST FUNCTION : System Description

INFOID:0000000010596328

### OUTLINE

When exiting, the condition is satisfied, the seat is moved backward 40 mm (1.57 in) from normal sitting position and the steering is moved to the most upper position and front position.

The seat slide amount and the steering operation at entry/exit operation can be changed.

### NOTE:

- This function is set to ON before delivery (initial setting).
- Further information for the system setting procedure. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

### OPERATION PROCEDURE

1. Open the driver door with ignition switch in ON position.
2. Driver seat and steering column will move to the exiting position.

### OPERATION CONDITION

Satisfy all of the following items. The exit assist function is not performed if these items are not satisfied.

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

Item	Request status
Ignition position	OFF
System setting	ON
Initialization	Done
Switch inputs	
<ul style="list-style-type: none"> <li>• Power seat switch</li> <li>• Tilt &amp; telescopic switch</li> <li>• Door mirror remote control switch</li> <li>• Set switch</li> <li>• Memory switch</li> </ul>	OFF (Not operated)
A/T selector lever	P position

## DETAIL FLOW


Order	Input	Output	Control unit condition
1	Door switch (Driver side)	—	Driver seat control unit receives door switch signal (driver side/open) from BCM via CAN communication.
2	—	Motors (Seat sliding, tilt, telescopic)	Driver seat control unit operates the seat sliding motor, which recognizes that the driver side door is opened with ignition switch OFF. Driver seat control unit then requests the operations of tilt motor and telescopic motor to auto drive positioner control unit via UART communication. The automatic drive positioner control unit operates each motor for a constant amount.

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

EXIT ASSIST FUNCTION : Component Parts Location

INFOID:000000010596329



JMJIA147ZZ

ADP

K

L

M

N


O

P

- |  |  |  |
|--|--|--|
| 1. BCM   | 2. Automatic drive positioner control unit         | 3. Tilt motor  |
| 4. Telescopic motor  | 5. Unified meter and A/C amp.                      | 6. AV control unit   |
| 7. AT assembly connector                                   | 8. Tilt & telescopic switch                        | 9. Key slot  |
| 10. Tilt sensor  | 11. Telescopic sensor                              | 12. Seat memory switch                                     |
| 13. Door mirror remote control switch                      |  |  |
| A. Dash side lower (Passenger side)                        | B. View with instrument driver lower panel removed | C. View with steering column cover lower and upper removed |
| D. Behind cluster lid C                                    | E. A/T assembly<br>(TCM is built in A/T assembly)  | F. View with instrument driver lower panel removed         |
| G. View with steering column cover lower and upper removed |  |  |

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >



14. Front door switch (driver side)  
 15. A/T shift selector (detention switch)  
 16. Sliding, lifting switch (Power seat switch)  
 17. Reclining switch (power seat switch)  
 18. Door mirror (driver side)  
 19. Reclining motor  
 20. Driver seat control unit  
 21. Lifting motor (front)  
 22. Lifting motor (rear)  
 23. Sliding motor  
 24. Sliding sensor  
 H. View with center console assembly removed  
 I. View with seat cushion pad and seat back pad removed  
 J. Backside of the seat cushion

INFOID:0000000010596330

## EXIT ASSIST FUNCTION : Component Description

### CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> <li>Operates the seat sliding motor for a constant amount.</li> <li>Requests the operations of tilt motor and telescopic motor to automatic drive positioner control unit.</li> </ul>
Automatic drive positioner control unit	Operates the tilt motor and telescopic motor with the request from the driver seat control.
BCM	<ul style="list-style-type: none"> <li>Recognizes the following status and transmits it to the driver seat control unit via CAN communication.</li> <li>Driver door: OPEN/CLOSE</li> </ul>

### INPUT PARTS

#### Switches

Item	Function
Front door switch (driver side)	Detect front door (driver side) open/close status.

#### Sensors

Item	Function
Tilt and telescopic sensor	Detect the up/down and left/right position of steering column.
Sliding sensor	Detect the front/rear position of seat.

### OUTPUT PARTS

# AUTOMATIC DRIVE POSITIONER SYSTEM


## < SYSTEM DESCRIPTION >

Item	Function
Tilt and telescopic motor	Move the steering column upward/downward and frontward/rearward.
Sliding motor	Slide the seat frontward/rearward.

## ENTRY ASSIST FUNCTION

### ENTRY ASSIST FUNCTION : System Diagram

INFOID:0000000010596331



A  
B  
C  
D  
E  
F  
G  
H  
I  
ADP

### ENTRY ASSIST FUNCTION : System Description

INFOID:0000000010596332

#### OUTLINE

The seat is in the exiting position when either following condition (A or B) is satisfied, the seat returns from exiting position to the previous driving position.

#### NOTE:

- This function is set to ON before delivery (initial setting).
- Further information for the system setting procedure. Refer to [ADP-11, "SYSTEM SETTING : Description"](#).

#### OPERATION PROCEDURE

1. A: Turn the ignition switch ON.  
B: Turn the ignition switch from OFF to ACC after closing the driver door.
2. Driver seat and steering column will return from the exiting position to entry position.

#### OPERATION CONDITION

Satisfy all of the following items. The entry assist function is not performed if these items are not satisfied.

K  
L  
M  
N  
O  
P

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

Item	Request status
Seat, steering column	The vehicle is not moved after performing the exit assist function.
Switch inputs <ul style="list-style-type: none"> <li>• Power seat switch</li> <li>• Tilt &amp; telescopic switch</li> <li>• Door mirror control switch</li> <li>• Set switch</li> <li>• Memory switch</li> </ul>	OFF (Not operated)
A/T selector lever	P position

## DETAIL FLOW


Order	Input	Output	Control unit condition
1	Door switch/Ignition switch	—	Driver seat control unit receives the signals of [ignition switch signal] and [driver side door switch] from BCM via CAN communication.
2	—	Motors (Sliding, tilt, telescopic)	Driver side control unit operates the sliding motor when the operating conditions are satisfied and requests the operations of tilt motor and telescopic motor to automatic drive positioner control unit via UART communication. The automatic drive positioner operates each motor.
	Sensors (Sliding, tilt, telescopic)	—	Each sensor monitors the operating positions of seat and steering, and then stops the operation of each motor when each part reaches the recorded address.

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

ENTRY ASSIST FUNCTION : Component Parts Location

INFOID:000000010596333



JMJIA147ZZ

ADP

K

L

M

N


O

P

- |  |  |  |
|--|--|--|
| 1. BCM   | 2. Automatic drive positioner control unit         | 3. Tilt motor  |
| 4. Telescopic motor  | 5. Unified meter and A/C amp.                      | 6. AV control unit   |
| 7. AT assembly connector                                   | 8. Tilt & telescopic switch                        | 9. Key slot  |
| 10. Tilt sensor  | 11. Telescopic sensor                              | 12. Seat memory switch                                     |
| 13. Door mirror remote control switch                      |  |  |
| A. Dash side lower (Passenger side)                        | B. View with instrument driver lower panel removed | C. View with steering column cover lower and upper removed |
| D. Behind cluster lid C                                    | E. A/T assembly<br>(TCM is built in A/T assembly)  | F. View with instrument driver lower panel removed         |
| G. View with steering column cover lower and upper removed |  |  |

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >



14. Front door switch (driver side)  
 15. A/T shift selector (detention switch)  
 16. Sliding, lifting switch (Power seat switch)  
 17. Reclining switch (power seat switch)  
 18. Door mirror (driver side)  
 19. Reclining motor  
 20. Driver seat control unit  
 21. Lifting motor (front)  
 22. Lifting motor (rear)  
 23. Sliding motor  
 24. Sliding sensor  
 H. View with center console assembly removed  
 I. View with seat cushion pad and seat back pad removed  
 J. Backside of the seat cushion

INFOID:0000000010596334

## ENTRY ASSIST FUNCTION : Component Description

### CONTROL UNITS

Item	Function
Driver seat control unit	According to the ignition signal and door switch signal (driver side) from BCM, <ul style="list-style-type: none"> <li>• Operates the seat sliding motor for a constant amount.</li> <li>• Requests the operations of tilt motor and telescopic motor to automatic drive positioner control unit.</li> </ul>
Automatic drive positioner control unit	Operates the tilt motor and telescopic motor with the instructions from the driver seat control.
BCM	Recognizes the following status and transmits it to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> <li>• Driver door: OPEN/CLOSE</li> <li>• Ignition switch position: ACC/ON</li> </ul>

### INPUT PARTS

#### Switches

Item	Function
Front door switch (driver side)	Detect front door (driver side) open/close status.

#### Sensors

Item	Function
Tilt & telescopic sensor	Detect the up/down and left/right position of steering column.
Sliding sensor	Detect the front/rear position of seat.

### OUTPUT PARTS

# AUTOMATIC DRIVE POSITIONER SYSTEM


## < SYSTEM DESCRIPTION >

Item	Function
Tilt & telescopic motor	Move the steering column upward/downward and frontward/rearward.
Sliding motor	Slide the seat frontward/rearward.

## INTELLIGENT KEY INTERLOCK FUNCTION

### INTELLIGENT KEY INTERLOCK FUNCTION : System Diagram

INFOID:0000000010596335



A  
B  
C  
D  
E  
F  
G  
H  
I  
  
ADP

### INTELLIGENT KEY INTERLOCK FUNCTION : System Description

INFOID:0000000010596336

K  
L  
  
M  
N  
  
O  
P

#### OUTLINE

When unlocking doors by using Intelligent Key or driver side door request switch, the system performs memory operation, exiting operation then entry operation.

#### OPERATION PROCEDURE

1. Unlock doors by using Intelligent Key or driver side door request switch.
2. The system performs memory operation, and then performs exit assist operation.

#### NOTE:

If the seat position is in memorized position before unlocking doors, memory operation does not perform.

#### NOTE:

Further information for Intelligent Key interlock function. Refer to [ADP-9, "MEMORY STORING : Description"](#).

#### OPERATION CONDITION

Satisfy all of the following items. The Intelligent Key interlock function is not performed if these items are not satisfied.

Item	Request status
Ignition switch	LOCK
Memory storing	Completed
Key switch	OFF (Key is removed from key slot)

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >

Item	Request status
Switch inputs <ul style="list-style-type: none"> <li>• Power seat switch</li> <li>• Tilt &amp; telescopic switch</li> <li>• Door mirror control switch</li> <li>• Set switch</li> <li>• Memory switch</li> </ul>	OFF (Not operated)
AT selector lever	P position
Automatic drive position system any function	Not operating
CONSULT	Not connected


## DETAIL FLOW

Order	Input	Output	Control unit condition
1	<ul style="list-style-type: none"> <li>• Door unlock signal (CAN)</li> <li>• Key ID signal (CAN)</li> </ul>	—	Driver seat control unit receives the door unlock signal and the key ID signal from BCM when unlocking the door with Intelligent Key or driver side door request switch.
2	—	—	Driver seat control unit performs the memory function.
3	—	—	Driver seat control unit performs the exit assist function after performing the memory function.
4	—	—	Driver seat control unit performs the entry assist function.

# AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

INTELLIGENT KEY INTERLOCK FUNCTION : Component Parts Location INFOID:000000010596337



A  
B  
C  
D  
E  
F  
G  
H  
I

ADP


K  
L  
M

N  
O  
P

- |  |  |  |
|--|--|--|
| 1. BCM   | 2. Automatic drive positioner control unit         | 3. Tilt motor  |
| 4. Telescopic motor  | 5. Unified meter and A/C amp.                      | 6. AV control unit   |
| 7. AT assembly connector                                   | 8. Tilt & telescopic switch                        | 9. Key slot  |
| 10. Tilt sensor  | 11. Telescopic sensor                              | 12. Seat memory switch                                     |
| 13. Door mirror remote control switch                      |  |  |
| A. Dash side lower (Passenger side)                        | B. View with instrument driver lower panel removed | C. View with steering column cover lower and upper removed |
| D. Behind cluster lid C                                    | E. A/T assembly<br>(TCM is built in A/T assembly)  | F. View with instrument driver lower panel removed         |
| G. View with steering column cover lower and upper removed |  |  |

# AUTOMATIC DRIVE POSITIONER SYSTEM

## < SYSTEM DESCRIPTION >



14. Front door switch (driver side)  
 15. A/T shift selector (detention switch)  
 16. Sliding, lifting switch  
 (Power seat switch)  
 17. Reclining switch (power seat switch)  
 18. Door mirror (driver side)  
 19. Reclining motor  
 20. Driver seat control unit  
 21. Lifting motor (front)  
 22. Lifting motor (rear)  
 23. Sliding motor  
 24. Sliding sensor  
 H. View with center console assembly  
 removed  
 I. View with seat cushion pad and seat-  
 back pad removed  
 J. Backside of the seat cushion

INFOID:0000000010596338

## INTELLIGENT KEY INTERLOCK FUNCTION : Component Description

### CONTROL UNITS

Item	Function
Driver seat control unit	It performs memory function and entry/exit assist function after receiving the door unlock signal from BCM.
Automatic drive positioner control unit	Operates the steering column and door mirror with the instructions from the driver seat control unit.
BCM	Recognizes the following status and transmits it to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> <li>Door lock: UNLOCK            (with Intelligent Key or driver side door request switch)</li> </ul>

# DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

### Diagnosis Description

INFOID:0000000010596339

The auto drive positioner system can be checked and diagnosed for component operation with CONSULT.

### DIAGNOSTIC MODE

Diagnostic mode [AUTO DRIVE POS.]	Description
WORK SUPPORT	Changes the setting of each function.
SELF-DIAG RESULTS	Performs self-diagnosis for the auto drive positioner system and displays the results.
DATA MONITOR	Displays input signals transmitted from various switches and sensors to driver seat control unit in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Drive each output device.
ECU PART NUMBER	Displays part numbers of driver seat control unit parts.

### CONSULT Function

INFOID:0000000010596340

#### SELF-DIAGNOSIS RESULTS

Refer to [ADP-141, "DTC Index"](#).

#### DATA MONITOR

##### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Unit	Contents
STARTER SW	"ON/OFF"	Ignition key switch ON (START, ON) /OFF (ACC, OFF) status judged from the ignition switch signal.
SET SW	"ON/OFF"	ON/OFF status judged from the setting switch signal.
MEMORY SW 1	"ON/OFF"	ON/OFF status judged from the seat memory switch 1 signal.
MEMORY SW 2	"ON/OFF"	ON/OFF status judged from the seat memory switch 2 signal.
R POSITION SW	"ON/OFF"	<b>NOTE:</b> This item is display, but cannot be used.
DETENT SW	"ON/OFF"	The selector lever position "OFF (P position) / ON (other than P position)" judged from the detention switch signal.
STEERING STATUS	"LOCK/UNLOCK"	LOCK/UNLOCK status judged from steering lock unit.
PARK BRAKE SW	"ON/OFF"	<b>NOTE:</b> This item is display, but cannot be used.
SLIDE SW-FR	"ON/OFF"	ON/OFF status judged from the sliding switch (forward) signal.
SLIDE SW-RR	"ON/OFF"	ON/OFF status judged from the sliding switch (backward) signal.
RECLN SW-FR	"ON/OFF"	ON/OFF status judged from the reclining switch (forward) signal.
RECLN SW-RR	"ON/OFF"	ON/OFF status judged from the reclining switch (backward) signal.
LIFT SW-UP	"ON/OFF"	ON/OFF status judged from the lifting switch front (up) signal.
LIFT SW-DOWN	"ON/OFF"	ON/OFF status judged from the lifting switch front (down) signal.
TILT SW-UP	"ON/OFF"	ON/OFF status judged from the tilt switch (up) signal.
TILT SW-DOWN	"ON/OFF"	ON/OFF status judged from the tilt switch (down) signal.
TELESCO SW-FR	"ON/OFF"	ON/OFF status judged from the telescoping switch (forward) signal.
TELESCO SW-RR	"ON/OFF"	ON/OFF status judged from the telescoping switch (backward) signal.
MIR CON SW-UP	"ON/OFF"	ON/OFF status judged from the mirror switch (up) signal.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

## < SYSTEM DESCRIPTION >

Monitor Item	Unit	Contents
MIR CON SW-DN	"ON/OFF"	ON/OFF status judged from the mirror switch (down) signal.
MIR CON SW-RH	"ON/OFF"	ON/OFF status judged from the door mirror remote control switch (passenger side) signal.
MIR CON SW-LH	"ON/OFF"	ON/OFF status judged from the door mirror remote control switch (driver side) signal.
MIR CHNG SW-R	"ON/OFF"	ON/OFF status judged from the door mirror remote control switch (switching to right) signal.
MIR CHNG SW-L	"ON/OFF"	ON/OFF status judged from the door mirror remote control switch (switching to left) signal.
TILT PULSE	—	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
TELESCO PULSE	—	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
MIR/SEN RH U-D	"V"	Voltage input from door mirror sensor (passenger side) up/down is displayed.
MIR/SEN RH R-L	"V"	Voltage input from door mirror sensor (passenger side) left/right is displayed.
MIR/SEN LH U-D	"V"	Voltage input from door mirror sensor (driver side) up/down is displayed.
MIR/SEN LH R-L	"V"	Voltage input from door mirror sensor (driver side) left/right is displayed.
SLIDE PULSE	—	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
RECLN PULSE	—	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
LIFT PULSE	—	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
VEHICLE SPEED	—	Display the vehicle speed signal received from combination meter by numerical value [km/h]
P RANG SW CAN	"ON/OFF"	ON/OFF status judged from P range switch signal.
R RANG (CAN)	"ON/OFF"	ON/OFF status judged from R range switch signal.
DOOR SW-FL	"OPEN/CLOSE"	ON/OFF status judged from front door switch LH switch signal.
DOOR SW-FR	"OPEN/CLOSE"	ON/OFF status judged from front door switch RH switch signal.
IGN ON SW	"ON/OFF"	ON/OFF status judged from ignition switch signal.
ACC ON SW	"ON/OFF"	ON/OFF status judged from ACC switch signal.
KYLS DR UNLK	"ON/OFF"	ON/OFF status judged from driver door unlock status.
KEYLESS ID	—	Key ID status judged from key ID signal.
VHCL SPEED (ABS)	"NORCV/RCV"	ON/OFF status judged from vehicle speed signal.
HANDLE	"RHD/LHD"	RHD/LHD status judged from handle position signal.
TRANSMISSION	"[A/T]/[M/T]"	Transmission type judged from TCM.

## ACTIVE TEST

### CAUTION:

When driving vehicle, do not perform active test.

Test item	Description
SEAT SLIDE	Activates/deactivates the sliding motor.
SEAT RECLINING	Activates/deactivates the reclining motor.
SEAT LIFTER FR	Activates/deactivates the lifting motor (front).
SEAT LIFTER RR	Activates/deactivates the lifting motor (rear).
TILT MOTOR	Activates/deactivates the tilt motor.
TELESCO MOTOR	Activates/deactivates the telescopic motor.

# DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

## < SYSTEM DESCRIPTION >

Test item	Description
MIRROR MOTOR RH	Activates/deactivates the mirror motor (passenger side).
MIRROR MOTOR LH	Activates/deactivates the mirror motor (driver side).
MEMORY SW INDCTR	Turns ON/OFF the memory indicator.

## WORK SUPPORT

Work item	Content	Item
SEAT SLIDE VOLUME SET	The amount of seat sliding for entry/exit assist can be selected from 3 items.	40 mm
		80 mm
		150 mm
EXIT TILT SETTING	Entry/exit assist (steering column) can be selected: ON (operated) – OFF (not operated)	ON
		OFF
EXIT SEAT SLIDE SETTING	Entry/exit assist (seat) can be selected: ON (operated) – OFF (not operated)	ON
		OFF

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:0000000010596341

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

#### DTC Logic

INFOID:0000000010596342

#### DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000	CAN COMM CIRCUIT	<ul style="list-style-type: none"><li>Driver seat control unit cannot communicate to other control units.</li><li>Driver seat control unit cannot communicate for more than the specified time.</li></ul>	<ul style="list-style-type: none"><li>Harness or connectors (CAN communication line is open or shorted)</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. STEP 1

Turn ignition switch ON and wait at least 3 seconds.

>> GO TO 2.

##### 2. STEP 2

Check "Self diagnostic result" with CONSULT.

Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-46, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:0000000010596343

Refer to [LAN-16, "Trouble Diagnosis Flow Chart"](#).

#### Special Repair Requirement

INFOID:0000000010596344

Refer to [ADP-9, "SYSTEM INITIALIZATION : Description"](#).

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### DTC Logic

INFOID:0000000011010994

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of driver seat control unit.	Driver seat control unit

### Diagnosis Procedure

INFOID:0000000011010995

#### 1. REPLACE DRIVER SEAT CONTROL UNIT

When DTC [U1010] is detected, replace driver seat control unit.

>> Replace driver seat control unit.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

## B2112 SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

### B2112 SLIDING MOTOR

#### Description

INFOID:0000000010596345

- The seat sliding motor is installed to the seat cushion frame.
- The seat sliding motor is installed with the driver seat control unit.
- Slides the seat frontward/ rearward by changing the rotation direction of sliding motor.

#### DTC Logic

INFOID:0000000010596346

#### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2112	SEAT SLIDE	The driver seat control unit detects the output of sliding motor output terminal for 0.1 second or more even if the sliding switch is not input.	<ul style="list-style-type: none"><li>• Driver seat control unit</li><li>• Slide motor harness is power shorted</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. RERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT.

###### Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-48, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

###### **NOTE:**

First perform diagnosis for B2126 if B2126 is detected.

#### Diagnosis Procedure

INFOID:0000000010596347

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT.
3. Erase the DTC.
4. Perform DTC confirmation procedure. Refer to [ADP-48, "DTC Logic"](#).

###### Is the DTC displayed again?

YES >> GO TO 2.  
NO >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

##### 2. CHECK SLIDING MOTOR CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect sliding motor and driver seat control unit connector.
3. Check voltage between sliding motor harness connector and ground.

(+) Sliding motor		(-)	Voltage (V) (Approx.)
Connector	Terminals		
B461	34	Ground	0 – 1 V
	38		

###### Is the inspection result normal?

YES >> GO TO 3.  
NO >> Repair or replace harness or connector.

##### 3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

## B2112 SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Voltage (V) (Approx.)
Driver seat control unit			
Connector	Terminals		
B452	34	Ground	0 – 1 V
	38		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#)

### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

## B2113 RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

### B2113 RECLINING MOTOR

#### Description

INFOID:0000000010596348

- The seat reclining motor is installed to the seatback frame.
- The seat reclining motor is activated with the driver seat control unit.
- Tilts the seatback frontward/rearward by changing the rotation direction of reclining motor.

#### DTC Logic

INFOID:0000000010596349

#### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2113	SEAT RECLINING	The driver seat control unit detects the output of reclining motor output terminal for 0.1 second or more even if the reclining switch is not input.	<ul style="list-style-type: none"><li>• Driver seat control unit</li><li>• Reclining motor harness is power shorted</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. REFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT.

###### Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-50, "Diagnosis Procedure"](#).

NO >> INSPECTION END

###### **NOTE:**

First perform diagnosis for B2126 if B2126 is detected.

#### Diagnosis Procedure

INFOID:0000000010596350

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT.
3. Erase the DTC.
4. Perform DTC confirmation procedure. Refer to [ADP-50, "DTC Logic"](#).

###### Is the DTC displayed again?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

##### 2. CHECK RECLINING MOTOR CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect reclining motor and driver seat control unit connector.
3. Check voltage between reclining motor harness connector and ground.

(+) Reclining motor		(-)	Voltage (Approx.)
Connector	Terminals		
B454	35	Ground	0 – 1 V
	39		

###### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

##### 3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

## B2113 RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Voltage (Approx.)
Driver seat control unit			
Connector	Terminals		
B452	35	Ground	0 – 1 V
	39		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# B2116 TILT MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## B2116 TILT MOTOR

### DTC Logic

INFOID:0000000011010997

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2116	STEERING TILT	The automatic drive positioner control unit detects the output of tilt motor output terminal for 0.1 second or more even if the tilt switch is not input.	<ul style="list-style-type: none"><li>• Automatic drive positioner control unit</li><li>• Tilt motor harness is shorted</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. STEP 1

Turn ignition switch ON.

>> GO TO 2.

#### 2. STEP 2

Check "Self diagnostic result" with CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-52, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:0000000011010998

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT.
3. Erase the DTC.
4. Perform DTC confirmation procedure. Refer to [ADP-141, "DTC Index"](#).

Is the DTC displayed again?

- YES >> GO TO 2.  
NO >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

#### 2. CHECK TILT MOTOR CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt motor connector.
3. Check voltage between tilt motor harness connector and ground.

( + )		(-)	Voltage (V) (Approx.)
Tilt & telescopic motor			
Connector	Terminals		
M80	3	Ground	0 – 1 V
	7		

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connector.

#### 3. CHECK AUTOMATIC DRIVER POSITIONER CONROL UNIT OUTPUT SIGNAL

1. Connect automatic drive positioner control unit connector.
2. Check voltage between automatic drive positioner control unit harness connector and ground.

## B2116 TILT MOTOR

< DTC/CIRCUIT DIAGNOSIS >

(+) Automatic drive positioner control unit		(-)	Voltage (V) (Approx.)
Connector	Terminals		
M79	28	Ground	0 – 1 V
	29		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace automatic drive positioner control unit.

### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# B2128 UART COMMUNICATION LINE

< DTC/CIRCUIT DIAGNOSIS >

## B2128 UART COMMUNICATION LINE

### Description

INFOID:0000000010596360

Driver seat control unit performs UART communication with the automatic drive positioner control unit using 2 communication lines, TX and RX line. Driver seat control unit receives the operation signals of tilt & telescopic switch, door mirror remote control switch, set switch and memory switch and the position signals of tilt & telescopic sensor and door mirror sensor from the automatic drive positioner control unit and transmits the operation request signal.

### DTC Logic

INFOID:0000000010596361

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2128	UART COMM	The communication between driver seat control unit and auto drive positioner control unit is interrupted for a period of time.	<ul style="list-style-type: none"><li>UART communication line (UART communication line is open or shorted)</li><li>Driver seat control unit</li><li>Automatic drive positioner control unit</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. RERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Operate tilt & telescopic switch for more than 2 seconds.
- Check "Self diagnostic result" with CONSULT.

#### Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-54, "Diagnosis Procedure"](#).

NO >> INSPECTION END

### Diagnosis Procedure

INFOID:0000000010596362

#### 1. CHECK UART COMMUNICATION LINE CONTINUITY

- Turn ignition switch OFF.
- Disconnect driver seat control unit and automatic drive positioner control unit connector.
- Check continuity between driver seat control unit harness connector and automatic drive positioner control unit harness connector.

Driver seat control unit		Automatic drive positioner control unit		Continuity
Connector	Terminal	Connector	Terminal	
B451	2	M78	8	Existed

- Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		Not existed
B451	2		

#### Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> Repair or replace harness.

# B2130 EEPROM

< DTC/CIRCUIT DIAGNOSIS >

## B2130 EEPROM

### DTC Logic

INFOID:0000000011010999

#### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2130	EEPROM	Driver seat control unit detected CPU malfunction.	Driver seat control unit

#### DTC CONFIRMATION PROCEDURE

##### 1. STEP 1

Turn ignition switch ON.

>> GO TO 2.

##### 2. STEP 2

Check "Self diagnostic result" with CONSULT.

Is the DTC detected?

- YES >> Perform diagnosis procedure. Refer to [ADP-55, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:0000000011011000

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT.
3. Erase the DTC.
4. Perform DTC confirmation procedure. Refer to [ADP-55, "DTC Logic"](#).

Is the DTC displayed again?

- YES >> GO TO 2.  
NO >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

##### 2. REPLACE DRIVER SEAT CONTROL UNIT

Replace driver seat control unit.

>> INSPECTION END

ADP

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT BCM

### BCM : Diagnosis Procedure

INFOID:0000000011011028

#### 1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Battery power supply	K
	10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

#### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		
Connector	Terminal	
M118	1	
M119	11	Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

## DRIVER SEAT CONTROL UNIT

### DRIVER SEAT CONTROL UNIT : Diagnosis Procedure

INFOID:0000000010596364

#### NOTE:

Do not disconnect the battery negative terminal and the driver seat control unit connector until DTC is confirmed with CONSULT.

#### 1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between driver seat control unit harness connector and ground.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

(+) (+)		(-)	Voltage (V) (Approx.)
Driver seat control unit	Terminal		
Connector	Terminal	Ground	9 – 16 V
B452	33	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following.

- Repair or replace harness between driver seat control unit and fuse block (J/B).
- Circuit breaker.

## 2.CHECK GROUND CIRCUIT

Check continuity between the driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B452	43	Ground	Existed

Is the inspection result normal?

YES >> Driver seat control unit power supply and ground circuit are OK.

NO >> Repair or replace harness between driver seat control unit and ground.

## DRIVER SEAT CONTROL UNIT : Special Repair Requirement

INFOID:0000000010596365

## 1.PERFORM ADDITIONAL SERVICE

Perform additional service when removing battery negative terminal.

>> Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

## AUTOMATIC DRIVE POSITIONER CONTROL UNIT

ADP

## AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure

INFOID:0000000010596366

### NOTE:

Do not disconnect the battery negative terminal and the driver seat control unit connector until DTC is confirmed with CONSULT.

## 1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Check voltage between automatic drive positioner control unit harness connector and ground.

(+) (+)		(-)	Voltage (V) (Approx.)
Automatic drive positioner control unit	Terminal		
Connector	Terminal	Ground	9 – 16 V
M79	25	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness between automatic drive positioner control unit and fuse block (J/B).

## 2.CHECK GROUND CIRCUIT

Check continuity between the automatic drive positioner control unit harness connector and ground.

## POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M79	30		Existed

Is the inspection result normal?

YES >> Automatic drive positioner control unit power supply and ground circuit are OK.

NO >> Repair or replace harness between automatic drive positioner control unit and ground.

## AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Special Repair Requirement

INFOID:0000000010596367

### 1. PERFORM ADDITIONAL SERVICE

Perform additional service when removing battery negative terminal.

>> Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description".](#)

# SLIDING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## SLIDING SWITCH

### Description

INFOID:0000000010596368

Sliding switch is equipped to the power seat switch on the seat cushion side surface. The operation signal is inputted to the driver seat control unit when the sliding switch is operated.

### Component Function Check

INFOID:0000000010596369

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SLIDE SW-FR", "SLIDE SW-RR" in "Data monitor" mode with CONSULT.
3. Check sliding switch signal under the following conditions.

Monitor item	Condition	Status
SLIDE SW-FR	Sliding switch (forward)	Operate
		Release
SLIDE SW-RR	Sliding switch (backward)	Operate
		Release

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-59, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000010596370

#### 1.CHECK SLIDING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

(+) Power seat switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B459	8	Ground	9 – 16 V
	24		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK SLIDING SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

Driver seat control unit		Power seat switch		Continuity
Connector	Terminal	Connector	Terminal	
B451	8	B459	8	Existed
	24		24	

4. Check continuity between driver seat control unit harness connector and ground.

# SLIDING SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	8		Not existed
	24		

### Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).  
NO >> Repair or replace harness or connector.

## 3.CHECK SLIDING SWITCH

Refer to [ADP-60, "Component Inspection"](#).

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace power seat switch. Refer to [ADP-222, "Removal and Installation"](#).

## 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000010596371

## 1.CHECK SLIDING SWITCH

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

Power seat switch		Condition	Continuity	
Terminal			Operate	Existed
43	8	Sliding switch (backward)	Release	Not existed
			Operate	Existed
	24	Sliding switch (forward)	Release	Not existed
			Operate	Existed

### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace power seat switch. Refer to [ADP-222, "Removal and Installation"](#).

# RECLINING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## RECLINING SWITCH

### Description

INFOID:0000000010596372

Reclining switch is equipped to the power seat switch on the seat cushion side surface. The operation signal is inputted to the driver seat control unit when the reclining switch is operated.

### Component Function Check

INFOID:0000000010596373

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "RECLN SW-FR", "RECLN SW-RR" in "Data monitor" mode with CONSULT.
3. Check reclining switch signal under the following conditions.

Monitor item	Condition	Status
RECLINE SW-FR	Reclining switch (forward)	Operate
		Release
RECLINE SW-RR	Reclining switch (backward)	Operate
		Release

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-61, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000010596374

#### 1.CHECK RECLINING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

(+) Power seat switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B459	9	Ground	9 – 16 V
	25		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK RECLINING SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

Driver seat control unit		Power seat switch		Continuity
Connector	Terminal	Connector	Terminal	
B451	9	B459	9	Existed
	25		25	

4. Check continuity between driver seat control unit harness connector and ground.

A

B

C

D

E

F

G

H

ADP

K

L

M

N

O

P

# RECLINING SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	9		Existed
	25		Not existed

### Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).  
NO >> Repair or replace harness or connector.

## 3.CHECK RECLINING SWITCH

Refer to [ADP-62, "Component Inspection"](#).

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace power seat switch. Refer to [ADP-222, "Removal and Installation"](#).

## 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000010596375

## 1.CHECK RECLINING SWITCH

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

Power seat switch		Condition	Continuity	
Terminal			Operate	Release
43	9	Reclining switch (backward)	Existed	Not existed
	25		Existed	Not existed

### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace power seat switch. Refer to [ADP-222, "Removal and Installation"](#).

# LIFTING SWITCH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

## LIFTING SWITCH (FRONT)

### Description

INFOID:0000000010596376

Lifting switch (front) is equipped to the power seat switch on the seat cushion side surface. The operation signal is inputted to the driver seat control unit when the lifting switch (front) is operated.

### Component Function Check

INFOID:0000000010596377

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT FR SW-UP", "LIFT FR SW-DN" in "Data monitor" mode with CONSULT.
3. Check lifting switch (front) signal under the following conditions.

Monitor item	Condition	Status
LIFT FR SW-UP	Lifting switch front (up)	Operate
		Release
LIFT FR SW-DN	Lifting switch front (down)	Operate
		Release

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-63, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000010596378

#### 1.CHECK LIFTING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

(+) Power seat switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B459	10	Ground	9 – 16 V
	26		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK LIFTING SWITCH (FRONT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

Driver seat control unit		Power seat switch		Continuity
Connector	Terminal	Connector	Terminal	
B451	10	B459	10	Existed
	26		26	

4. Check continuity between driver seat control unit harness connector and ground.

# LIFTING SWITCH (FRONT)

## < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	10		Existed
	26		Not existed

### Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).  
NO >> Repair or replace harness or connector.

## 3.CHECK LIFTING SWITCH (FRONT)

Refer to [ADP-64, "Component Inspection"](#).

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace power seat switch. Refer to [ADP-222, "Removal and Installation"](#).

## 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000010596379

## 1.CHECK LIFTING SWITCH (FRONT)

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

Power seat switch		Condition	Continuity	
Terminal			Operate	Release
43	10	Lifting switch front (down)	Operate	Existed
			Release	Not existed
	26	Lifting switch front (up)	Operate	Existed
			Release	Not existed

### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace power seat switch. Refer to [ADP-222, "Removal and Installation"](#).

# LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

## LIFTING SWITCH (REAR)

### Description

INFOID:0000000010596380

Lifting switch (rear) is equipped to the power seat switch on the seat cushion side surface. The operation signal is inputted to the driver seat control unit when the lifting switch (rear) is operated.

### Component Function Check

INFOID:0000000010596381

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT RR SW-UP", "LIFT RR SW-DN" in "Data monitor" mode with CONSULT.
3. Check lifting switch (rear) signal under the following conditions.

Monitor item	Condition	Status
LIFT RR SW-UP	Lifting switch rear (up)	Operate
		Release
LIFT RR SW-DN	Lifting switch rear (down)	Operate
		Release

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-65, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000010596382

#### 1.CHECK LIFTING SWITCH (REAR) SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between power seat switch harness connector and ground.

(+) Power seat switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B459	11	Ground	9 – 16 V
	27		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK LIFTING SWITCH (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and power seat switch harness connector.

Driver seat control unit		Power seat switch		Continuity
Connector	Terminal	Connector	Terminal	
B451	11	B459	11	Existed
	27		27	

4. Check continuity between driver seat control unit harness connector and ground.

## LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	11		Existed
	27		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

### 3.CHECK LIFTING SWITCH (REAR)

Refer to [ADP-66, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power seat switch. Refer to [ADP-222, "Removal and Installation"](#).

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000010596383

### 1.CHECK LIFTING SWITCH (REAR)

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch terminals.

Power seat switch		Condition	Continuity	
Terminal				
43	11	Lifting switch rear (up)	Operate	Existed
			Release	Not existed
	27	Lifting switch rear (down)	Operate	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace power seat switch. Refer to [ADP-222, "Removal and Installation"](#).

# TILT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## TILT SWITCH

### Description

INFOID:0000000010596384

Tilt switch is equipped to the steering column. The operation signal is inputted to the automatic drive positioner control unit when the tilt switch is operated.

### Component Function Check

INFOID:0000000010596385

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TILT SW-UP", "TILT SW-DN" in "Data monitor" mode with CONSULT.
3. Check tilt switch signal under the following conditions.

Monitor item	Condition	Status
TILT SW-UP	Tilt switch (up)	Operate
		Release
TILT SW-DN	Tilt switch (down)	Operate
		Release

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-67, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000010596386

#### 1.CHECK TILT SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Turn ignition switch ON.
4. Check voltage between tilt & telescopic switch harness connector and ground.

(+) Tilt & telescopic switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
M31	4	Ground	4 – 6 V
	5		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK TILT SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic switch harness connector.

Automatic drive positioner control unit		Tilt & telescopic switch		Continuity
Connector	Terminal	Connector	Terminal	
M78	1	M31	4	Existed
	13		5	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

# TILT SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		Not existed
M78	1		
	13		

### Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).  
NO >> Repair or replace harness or connector.

## 3.CHECK TILT SWITCH

Refer to [ADP-68, "Component Inspection"](#).

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace tilt & telescopic switch. Refer to [ADP-223, "Removal and Installation"](#).

## 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000010596387

### 1.CHECK TILT SWITCH

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Check continuity between tilt & telescopic switch terminals.

Tilt & telescopic switch		Condition		Continuity
Terminal				
1	4	Tilt switch (up)	Operate	Existed
			Release	Not existed
	5	Tilt switch (down)	Operate	Existed
			Release	Not existed

### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace tilt & telescopic switch. Refer to [ADP-223, "Removal and Installation"](#).

# TELESCOPIC SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## TELESCOPIC SWITCH

### Description

INFOID:0000000010596388

Telescopic switch is equipped to the steering column. The operation signal is inputted to the automatic drive positioner control unit when the telescopic switch is operated.

### Component Function Check

INFOID:0000000010596389

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "TELESCO SW-FR", "TELESCO SW-RR" in "Data monitor" mode with CONSULT.
3. Check telescopic switch signal under the following conditions.

Monitor item	Condition	Status	
TELESCO SW-FR	Telescopic switch (forward)	Operate	ON
		Release	OFF
TELESCO SW-RR	Telescopic switch (backward)	Operate	ON
		Release	OFF

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-69, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000010596390

#### 1.CHECK TELESCOPIC SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Turn ignition switch ON.
4. Check voltage between tilt & telescopic switch harness connector and ground.

(+) Tilt & telescopic switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
M31	2	Ground	4 – 6 V
	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK TELESCOPIC SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic switch harness connector.

Automatic drive positioner control unit		Tilt & telescopic switch		Continuity
Connector	Terminal	Connector	Terminal	
M78	7	M31	2	Existed
	19		3	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

# TELESCOPIC SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		Not existed
M78	7		
	19		

### Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).  
NO >> Repair or replace harness or connector.

## 3.CHECK TELESCOPIC SWITCH

Refer to [ADP-70, "Component Inspection"](#).

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace tilt & telescopic switch. Refer to [ADP-223, "Removal and Installation"](#).

## 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000010596391

### 1.CHECK TELESCOPIC SWITCH

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Check continuity between tilt & telescopic switch terminals.

Tilt & telescopic switch		Condition	Continuity	
Terminal			Operate	Existed
1	2	Telescopic switch (forward)	Release	Not existed
		Telescopic switch (backward)	Operate	Existed
	3	Telescopic switch (forward)	Release	Not existed
		Telescopic switch (backward)	Operate	Existed

### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace tilt & telescopic switch. Refer to [ADP-223, "Removal and Installation"](#).

# SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## SEAT MEMORY SWITCH

### Description

INFOID:0000000010596392

Memory switch is equipped on the seat set switch and seat memory switch installed to the driver side door trim. The operation signal is inputted to the automatic drive positioner control unit when the set switch or memory switch is operated.

### Component Function Check

INFOID:0000000010596393

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MEMORY SW 1", "MEMORY SW 2" "SET SW" in "Data monitor" mode with CONSULT.
3. Check seat memory switch signal under the following conditions.

Monitor item	Condition	Status
SET SW	SET SW	Push
		Release
MEMORY SW 1	Memory switch 1	Push
		Release
MEMORY SW 2	Memory switch 2	Push
		Release

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-71, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000010596394

#### 1.CHECK SEAT MEMORY SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect seat memory switch connector.
3. Turn ignition switch ON.
4. Check voltage between seat memory switch harness connector and ground.

(+) Seat memory switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
D5	3	Ground	4 – 6 V
	1		
	2		

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK MEMORY SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and seat memory switch harness connector.

# SEAT MEMORY SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Seat memory switch		Continuity
Connector	Terminal	Connector	Terminal	
M451	28	D5	3	Existed
	22		1	
	6		2	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
M451	28		
	22		
	6		

Is the inspection result normal?

- YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).  
NO >> Repair or replace harness or connector.

## 3.CHECK MEMORY SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.  
2. Check continuity between seat memory switch harness connector and ground.

Seat memory switch		Ground	Continuity
Connector	Terminal		
D5	4		Existed

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness or connector.

## 4.CHECK SEAT MEMORY SWITCH

Refer to [ADP-72, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Replace seat memory switch. Refer to [ADP-221, "Removal and Installation"](#).

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000010596395

### 1.CHECK SEAT MEMORY SWITCH

1. Turn ignition switch OFF.  
2. Disconnect seat memory switch connector.  
3. Check continuity between seat memory switch terminals.

## SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Seat memory switch		Condition		Continuity
Terminal				
4	3	Set switch	Push	Existed
			Release	Not existed
	1	Memory switch 1	Push	Existed
			Release	Not existed
	2	Memory switch 2	Push	Existed
			Release	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat memory switch. Refer to [ADP-221, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## DOOR MIRROR REMOTE CONTROL SWITCH CHANGEOVER SWITCH

### CHANGEOVER SWITCH : Description

INFOID:0000000010596396

Changover switch is integrated into door mirror remote control switch.

Changover switch has three positions (L, N and R).

It changes door mirror motor operation by transmitting control signal to automatic drive positioner control unit.

### CHANGEOVER SWITCH : Component Function Check

INFOID:0000000010596397

#### 1. CHECK CHANGEOVER SWITCH FUNCTION

Check the operation on "MIR CHNG SW-R" or "MIR CHNG SW-L" in "DATA MONITOR" mode with CONSULT.

Refer to [ADP-43, "CONSULT Function"](#).

Is the inspection result normal?

YES >> Changover switch function is OK.

NO >> Refer to [ADP-74, "CHANGEOVER SWITCH : Diagnosis Procedure"](#).

### CHANGEOVER SWITCH : Diagnosis Procedure

INFOID:0000000010596398

#### 1. CHECK CHANGEOVER SWITCH SIGNAL

1. Turn ignition switch ON.
2. Check voltage between automatic drive positioner control unit connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
M78	2	Ground	Change over switch	RIGHT
	14			0 – 1
			Other than above	4 – 6
			LEFT	0 – 1
			Other than above	4 – 6

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 2.

#### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and door mirror remote control switch connector.
3. Check continuity between automatic drive positioner control unit connector and door mirror remote control switch connector.

Automatic drive positioner control unit		Door mirror remote control switch		Continuity
Connector	Terminal	Connector	Terminal	
M78	2	D17	11	Existed
	14		10	

4. Check continuity between automatic drive positioner control unit connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	2		
	14		

Is the inspection result normal?

# DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Repair or replace harness.

## 3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

Check continuity between door mirror remote control switch connector and ground.

Door mirror remote control switch		Ground	Continuity
Connector	Terminal		
D17	7		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT OUTPUT SIGNAL

1. Connect automatic drive positioner control unit connector.

2. Turn ignition switch ON.

3. Check voltage between automatic drive positioner control unit connector and ground.

(+) Automatic drive positioner control unit		(-)	Voltage (V) (Approx.)
Connector	Terminal		
M78	2		Ground
	14		4 – 6

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).

## 5.CHECK CHANGEOVER SWITCH

Check changeover switch.

Refer to [ADP-75, "CHANGEOVER SWITCH : Component Inspection"](#).

ADP

Is the inspection result normal?

YES >> Refer to [GI-45, "Intermittent Incident"](#).

NO >> Replace door mirror remote control switch. Refer to [MIR-125, "Removal and Installation"](#).

## 6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-45, "Intermittent Incident"](#).

K

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning parts.

L

## CHANGEOVER SWITCH : Component Inspection

INFOID:000000010596399

M

### 1.CHECK CHANGEOVER SWITCH

Check door mirror remote control switch.

N

Door mirror remote control switch		Change over switch	Condition		Continuity	
Terminal						
10	7		LEFT		Existed	
			Other than above		Not existed	
11			RIGHT		Existed	
			Other than above		Not existed	

Is the inspection result normal?

O

YES >> INSPECTION END

P

# DOOR MIRROR REMOTE CONTROL SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

NO    >> Replace door mirror remote control switch. Refer to [MIR-125, "Removal and Installation".](#)  
MIRROR SWITCH

## MIRROR SWITCH : Description

INFOID:0000000010596400

It operates angle of the door mirror face.

It transmits mirror face adjust operation to AUTOMATIC DRIVE POSITIONER CONTROL UNIT.

## MIRROR SWITCH : Component Function Check

INFOID:0000000010596401

### 1. CHECK MIRROR SWITCH FUNCTION

Check the operation on "MIR CON SW-UP/DN" and "MIR CON SW-RH/LH" in "DATA MONITOR" mode with CONSULT.

Refer to [ADP-43, "CONSULT Function".](#)

Is the inspection result normal?

YES    >> Mirror switch function is OK.

NO    >> Refer to [ADP-76, "MIRROR SWITCH : Diagnosis Procedure".](#)

## MIRROR SWITCH : Diagnosis Procedure

INFOID:0000000010596402

### 1. CHECK MIRROR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Check voltage between automatic drive positioner control unit connector and ground.

(+) Automatic drive positioner control unit		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
M78	3	Ground	Mirror switch	UP
	4			Other than above
	15			LEFT
	16			Other than above
				DOWN
				Other than above
				RIGHT
				Other than above

Is the inspection result normal?

YES    >> GO TO 6.

NO    >> GO TO 2.

### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and door mirror remote control switch connector.
3. Check continuity between automatic drive positioner control unit connector and door mirror remote control switch connector.

Automatic drive positioner control unit		Door mirror remote control switch		Continuity
Connector	Terminal	Connector	Terminal	
M78	3	D17	15	Existed
	4		13	
	15		12	
	16		4	

4. Check continuity between automatic drive positioner control unit connector and ground.

# DOOR MIRROR REMOTE CONTROL SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	3		Not existed
	4		
	15		
	16		Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

## 3.CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

Check continuity between door mirror remote control switch connector and ground.

Door mirror remote control switch		Ground	Continuity
Connector	Terminal		
D17	7		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT OUTPUT SIGNAL

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between automatic drive positioner control unit and ground.

(+)		(-)	Voltage (V) (Approx.)
Automatic drive positioner control unit			
M78	Connector	Terminal	Ground
		3	
		4	
		15	
		16	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).

## 5.CHECK MIRROR SWITCH

Check mirror switch

Refer to [ADP-78, "MIRROR SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Refer to [GI-45, "Intermittent Incident"](#).

NO >> Replace door mirror remote control switch. Refer to [MIR-125, "Removal and Installation"](#).

## 6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-45, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

ADP

K

L

M

N

O

P

# DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## MIRROR SWITCH : Component Inspection

INFOID:0000000010596403

### 1. CHECK MIRROR SWITCH

Check door mirror remote control switch.

Door mirror remote control switch		Condition	Continuity
Terminal			
4	7	RIGHT	Existed
		Other than above	Not existed
13		LEFT	Existed
		Other than above	Not existed
15		UP	Existed
		Other than above	Not existed
12		DOWN	Existed
		Other than above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace door mirror remote control switch. Refer to [MIR-125, "Removal and Installation".](#)

# POWER SEAT SWITCH GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SEAT SWITCH GROUND CIRCUIT

### Diagnosis Procedure

INFOID:0000000010596404

#### 1.CHECK POWER SEAT SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power seat switch connector.
3. Check continuity between power seat switch connector and ground.

Power seat switch		Ground	Continuity
Connector	Terminal		Existed
B459	43		

Is the inspection result normal?

- YES    >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).  
NO    >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# TILT & TELESCOPIC SWITCH GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## TILT & TELESCOPIC SWITCH GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000010596405

#### 1. CHECK TILT & TELESCOPIC SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect tilt & telescopic switch connector.
3. Check continuity between tilt & telescopic switch and ground.

Tilt & telescopic switch		Ground	Continuity
Connector	Terminal		Existed
M31	1		

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> Repair or replace harness.

# SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## SLIDING SENSOR

### Description

INFOID:000000010596414

- The sliding sensor is installed to the seat slide cushion frame.
- The pulse signal is inputted to the driver seat control unit when sliding is performed.
- The driver seat control unit counts the pulse and calculates the sliding amount of the seat.

### Component Function Check

INFOID:000000010596415

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "SLIDE PULSE" in "Data monitor" mode with CONSULT.
- Check sliding sensor signal under the following conditions.

Monitor item	Condition		Valve
SLIDE PULSE	Seat sliding	Operate (forward)	Change (increase) <sup>*1</sup>
		Operate (backward)	Change (decrease) <sup>*1</sup>
		Release	No change <sup>*1</sup>

<sup>\*1</sup>: The value at the seat position attained when the battery is connected is considered to be 32768.

#### Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-81, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010596416

#### 1.CHECK SLIDING SENSOR SIGNAL

- Turn ignition switch ON.
- Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

(+)	Driver seat control unit	(−)	Condition		Voltage (V) (Approx.)
Connector			Seat sliding	Operate	
B451	18	Ground		Operate	 JMJIA0119ZZ
				Other than above	0 or 5

#### Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> GO TO 2.

#### 2.CHECK SLIDING SENSOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect driver seat control unit and sliding sensor connector.
- Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

# SLIDING SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Sliding sensor		Continuity
Connector	Terminal	Connector	Terminal	
B451	18	B453	18	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		Not existed
B451	18		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

## 3.CHECK SLIDING SENSOR POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between sliding sensor harness connector and ground.

(+) Sliding sensor		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B453	12	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK SLIDING SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

Driver seat control unit		Sliding sensor		Continuity
Connector	Terminal	Connector	Terminal	
B451	12	B453	12	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		Not existed
B451	12		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

## 5.CHECK SLIDING SENSOR GROUND

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding sensor harness connector.

Sliding sensor		Ground	Continuity
Connector	Terminal		Existed
B453	43		

## SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES    >> Replace sliding sensor.

NO    >> Repair or replace harness or connector.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## RECLINING SENSOR

### Description

INFOID:0000000010596417

- The reclining motor is installed to the seatback frame.
- The pulse signal is inputted to the driver seat control unit when the reclining is operated.
- The driver seat control unit counts the pulse and calculates the reclining amount of the seat.

### Component Function Check

INFOID:0000000010596418

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "RECLN PULSE" in "Data monitor" mode with CONSULT.
- Check reclining sensor signal under the following conditions.

Monitor item	Condition		Value
RECLN PULSE	Seat reclining	Operate (forward)	Change (increase) <sup>*1</sup>
		Operate (backward)	Change (decrease) <sup>*1</sup>
		Release	No change <sup>*1</sup>

<sup>\*1</sup>: The value at the seat position attained when the battery is connected is considered to be 32768.

#### Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-84, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000010596419

#### 1.CHECK RECLINING SENSOR SIGNAL

- Turn ignition switch ON.
- Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

(+)	Driver seat control unit	(-)	Condition	Voltage (V) (Approx.)		
Connector						
B451	4	Ground	Seat reclining	Operate		
				 JMJA0119ZZ		
				Other than above		
				0 or 5		

#### Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> GO TO 2.

#### 2.CHECK RECLINING SENSOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect driver seat control unit and reclining motor connector.
- Check continuity between driver seat control unit harness connector and reclining motor harness connector.

# RECLINING SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Reclining motor		Continuity
Connector	Terminal	Connector	Terminal	
B451	4	B454	4	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	4		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

## 3.CHECK RECLINING SENSOR POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between reclining motor harness connector and ground.

(+) Reclining motor		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B454	12	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK RECLINING SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

ADP

Driver seat control unit		Reclining motor		Continuity
Connector	Terminal	Connector	Terminal	
B451	12	B454	12	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	12		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

## 5.CHECK RECLINING SENSOR GROUND

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

P

Reclining motor		Ground	Continuity
Connector	Terminal		
B454	43		Existed

## RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES    >> Replace reclining motor.

NO    >> Repair or replace harness or connector.

# LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

## LIFTING SENSOR (FRONT)

### Description

INFOID:000000010596420

- The lifting sensor (front) is installed to the seat slide cushion frame.
- The pulse signal is inputted to the driver seat control unit when the lifting (front) is operated.
- The driver seat control unit counts the pulse and calculates the lifting (front) amount of the seat.

### Component Function Check

INFOID:000000010596421

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "LIFT FR PULSE" in "Data monitor" mode with CONSULT.
- Check the lifting sensor (front) signal under the following conditions.

Monitor item	Condition	Value
LIFT FR PULSE	Seat lifting (front)	Operate (Up) Change (increase)*1
		Operate (Down) Change (decrease)*1
		Release No change*1

\*1:The value at the seat position attained when the battery is connected is considered to be 32768.

#### Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-87, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010596422

#### 1.CHECK LIFTING SENSOR (FRONT) SIGNAL

- Turn ignition switch ON.
- Check the voltage signal driver seat control unit harness connector and ground with an oscilloscope.

(+)	Driver seat control unit	(-)	Condition	Voltage (V) (Approx.)
Connector				
B451	19	Ground	Seat Lifting (front)	Operate  JMJIA0119ZZ
				Other than above 0 or 5

#### Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> GO TO 2.

#### 2.CHECK LIFTING SENSOR (FRONT) CIRCUIT

- Turn ignition switch OFF.
- Disconnect driver seat control unit and lifting motor (front) connector.
- Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

# LIFTING SENSOR (FRONT)

## < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Lifting motor (front)		Continuity
Connector	Terminal	Connector	Terminal	
B451	19	B455	19	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		Not existed
B451	19		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

## 3.CHECK LIFTING SENSOR (FRONT) POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between lifting motor (front) harness connector and ground.

(+) Lifting motor (front)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B455	12	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK LIFTING SENSOR (FRONT) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

Driver seat control unit		Lifting motor (front)		Continuity
Connector	Terminal	Connector	Terminal	
B451	12	B455	12	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		Not existed
B451	12		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

## 5.CHECK LIFTING SENSOR (FRONT) GROUND

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

Lifting motor (front)		Ground	Continuity
Connector	Terminal		
B455	43		Existed

## LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES    >> Replace lifting motor (front).  
NO    >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

## LIFTING SENSOR (REAR)

### Description

INFOID:0000000010596423

- The lifting sensor (rear) is installed to the seat slide cushion frame.
- The pulse signal is inputted to the driver seat control unit when the lifting (rear) is operated.
- The driver seat control unit counts the pulse and calculates the lifting (rear) amount of the seat.

### Component Function Check

INFOID:0000000010596424

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "LIFT RR PULSE" in "Data monitor" mode with CONSULT.
3. Check lifting sensor (rear) signal under the following conditions.

Monitor item	Condition		Value
LIFT RR PULSE	Seat lifting (rear)	Operate (Up)	Change (increase) <sup>*1</sup>
		Operate (Down)	Change (decrease) <sup>*1</sup>
		Release	No change <sup>*1</sup>

<sup>\*1</sup>: The value at the seat position attained when the battery is connected is considered to be 32768.

#### Is the indication normal?

YES >> INSPECTION END


NO >> Perform diagnosis procedure. Refer to [ADP-90, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000010596425

#### 1.CHECK LIFTING SENSOR (REAR) SIGNAL

1. Turn ignition switch ON.
2. Check voltage signal between driver seat control unit harness connector and ground with oscilloscope.

(+)	(−)	Condition	Voltage (V) (Approx.)
Driver seat control unit			
Connector	Terminal		
B451	20	Ground	 2V/div      10mSec/div JMJA0119ZZ
		Seat Lifting (rear)	Operate
			Other than above
			0 or 5

#### Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> GO TO 2.

#### 2.CHECK LIFTING SENSOR (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and lifting motor (rear) connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

## LIFTING SENSOR (REAR)

### < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Lifting motor (rear)		Continuity
Connector	Terminal	Connector	Terminal	
B451	20	B456	20	Existed

4. Check the continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	20		Not Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

### 3.CHECK LIFTING SENSOR (REAR) POWER SUPPLY

1. Connect driver seat control unit connector.
2. Turn ignition switch ON.
3. Check the voltage between lifting motor (rear) harness connector and ground.

(+) Lifting motor (rear)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B456	12	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

### 4.CHECK LIFTING SENSOR (REAR) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

ADP

Driver seat control unit		Lifting motor (rear)		Continuity
Connector	Terminal	Connector	Terminal	
B451	12	B456	12	Existed

4. Check the continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	12		Not existed

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

### 5.CHECK LIFTING SENSOR (REAR) GROUND

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

P

Lifting motor (rear)		Ground	Continuity
Connector	Terminal		
B456	43		Existed

## LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES    >> Replace lifting motor (rear).

NO    >> Repair or replace harness or connector.

# TIlt Sensor

< DTC/CIRCUIT DIAGNOSIS >

## TIlt Sensor

### Description

INFOID:000000010596426

- The tilt sensor is installed to the steering column assembly.
- The resistance of tilt sensor is changed according to the up/down position of steering column.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of tilt sensor resistance. Automatic drive positioner control unit calculates the tilt position from the voltage.

### Component Function Check

INFOID:000000010596427

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "TIlt PULSE" in "Data monitor" mode with CONSULT.
- Check the tilt sensor signal under the following condition.

Monitor item	Condition		Value
TIlt PULSE	Steering column	Operate (up)	Change (increase)
		Operate (down)	Change (decrease)
		Release	Not change

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-93, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010596428

#### 1.CHECK TIlt SENSOR SIGNAL

- Turn ignition switch ON.
- Check voltage signal between drive seat control unit harness connector and ground with oscilloscope.

(+)	(-)	Condition	Voltage (V) (Approx.)
Drive seat control unit			
Connector	Terminal	Steering tilt	10mSec/div 2V/div JMJA0119ZZ
B451	21	Ground	Operate
		Other than the above	0 or 5

Is the inspection result normal?

YES >> Replace drive seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> GO TO 2.

#### 2.CHECK TIlt SENSOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect drive seat control unit and tilt & telescopic motor connector.
- Check continuity between drive seat control unit harness connector and tilt & telescopic motor harness connector.

# TIlt SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

Drive seat control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
B451	21	M80	1	Existed

4. Check continuity between drive seat control unit harness connector and ground.

Drive seat control unit		Ground	Continuity
Connector	Terminal		
B451	21		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

## 3.CHECK TIlt SENSOR POWER SUPPLY

1. Connect drive seat control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic motor harness connector and ground.

(+) Tilt & telescopic motor		(-)	Voltage (V) (Approx.)
Connector	Terminal		
M80	2	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK TIlt SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

Automatic drive positioner control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
M78	27	M80	2	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	27		Not existed

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

## 5.CHECK TIlt SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

Automatic drive positioner control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
M78	20	M80	8	Existed

## TILT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES    >> Replace tilt & telescopic motor.  
NO    >> Repair or replace harness or connector.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## TELESCOPIC SENSOR

### Description

INFOID:0000000010596429

- The telescopic sensor is installed to the steering column assembly.
- The resistance of telescopic sensor is changed according to the forward/backward position of steering column.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of telescopic sensor resistance. Automatic drive positioner control unit calculates the telescopic position from the voltage.

### Component Function Check

INFOID:0000000010596430

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "TELESCO PULSE" in "Data monitor" mode with CONSULT.
- Check the tilt sensor signal under the following conditions.

Monitor item	Condition		Value
TELESCO PULSE	Steering column	Operate (forward)	Change (increase)
		Operate (backward)	Change (decrease)
		Release	Not change

Is the indication normal?

YES >> INSPECTION END.


NO >> Perform diagnosis procedure. Refer to [ADP-96, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000010596431

#### 1.CHECK TELESCOPIC SENSOR SIGNAL

- Turn ignition switch ON.
- Check voltage signal between drive seat control unit harness connector and ground with oscilloscope.

(+)	(-)	Condition	Voltage (V) (Approx.)
Drive seat control unit			
Connector	Terminal	Operate	 JMJIA0119ZZ
B451	5		
		Ground	2V/div
		Steering tilt	Other than the above
			0 or 5

Is the inspection result normal?

YES >> Replace drive seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> GO TO 2.

#### 2.CHECK TELESCOPIC SENSOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect driver seat control unit and tilt & telescopic motor connector.
- Check continuity between driver seat control unit harness connector and tilt & telescopic motor harness connector.

# TELESCOPIC SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

Drive seat control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
B451	5	M80	5	Existed

4. Check continuity between driver seat control unit harness connector and ground.

Drive seat control unit		Ground	Continuity
Connector	Terminal		
B451	5		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

## 3.CHECK TELESCOPIC SENSOR POWER SUPPLY

1. Connect automatic drive positioner control unit connector.
2. Turn ignition switch ON.
3. Check voltage between tilt & telescopic motor harness connector and ground.

(+) Tilt & telescopic motor		(-)	Voltage (V) (Approx.)
Connector	Terminal		
M80	6	Ground	9 – 16 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK TELESCOPIC SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

ADP

Automatic drive positioner control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
M78	27	M80	6	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	27		

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

## 5.CHECK TELESCOPIC SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

P

Automatic drive positioner control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
M78	20	M80	9	Existed

## TELESCOPIC SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES    >> Replace tilt & telescopic motor.

NO    >> Repair or replace harness.

# MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## MIRROR SENSOR DRIVER SIDE

### DRIVER SIDE : Description

INFOID:0000000010596432

- The mirror sensor (driver side) is installed to the door mirror (driver side).
- The resistance of 2 sensors (horizontal and vertical) is changed when the door mirror (driver side) is operated.
- Automatic drive positioner control unit calculates the door mirror position according to the change of the voltage of 2 sensor input terminals.

### DRIVER SIDE : Component Function Check

INFOID:0000000010596433

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "MIR/SEN LH U-D", "MIR/SEN LH R-L" in "Data monitor" with CONSULT.
- Check mirror sensor (driver side) signal under the following condition.

Monitor item	Condition	Value
MIR/SEN LH U-D	Door mirror (driver side)	Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley)
MIR/SEN LH R-L		Change between 0.6 [V] (close to left edge) 3.4 [V] (close to right edge)

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-99, "DRIVER SIDE : Diagnosis Procedure".](#)

### DRIVER SIDE : Diagnosis Procedure

INFOID:0000000010596434

ADP

#### 1.CHECK DOOR MIRROR (DRIVER SIDE) SENSOR POWER SUPPLY

- Turn ignition switch OFF.
- Disconnect door mirror (driver side) connector.
- Turn ignition switch ON.
- Check voltage between door mirror (driver side) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Door mirror (driver side)			
Connector	Terminal		
D3	23	Ground	4 – 6 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK DOOR MIRROR (DRIVER SIDE) SENSOR POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit connector.
- Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

Automatic drive positioner control unit connector	Terminal	Door mirror (driver side) connector	Terminal	Continuity
M78	21	D3	23	Existed

- Check continuity between automatic drive positioner control unit harness connector and ground.

# MIRROR SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		Not existed
M78	21		

### Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to ADP-220, "Removal and Installation".  
NO >> Repair or replace harness or connector.

## 3.CHECK DOOR MIRROR (DRIVER SIDE) SENSOR GROUND

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

Automatic drive positioner control unit		Door mirror (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M78	20	D3	24	

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness or connector.

## 4.CHECK DOOR MIRROR (DRIVER SIDE) SENSOR CIRCUIT

1. Check continuity between automatic drive positioner control unit harness connector and door mirror (driver side) harness connector.

Automatic drive positioner control unit		Door mirror (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
M78	6	D3	21	

2. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	6		Existed

- |    |    |
|----|----|
| 18 | 22 |
|----|----|

### Is the inspection result normal?

- YES >> Replace door mirror sensor. (Built in driver side mirror.)  
NO >> Repair or replace harness or connector.

## PASSENGER SIDE

### PASSENGER SIDE : Description

INFOID:0000000010596435

- The mirror sensor (passenger side) is installed to the door mirror (passenger side).
- The resistance of 2 sensors (horizontal and vertical) is changed when the door mirror (passenger side) is operated.
- Automatic drive positioner control unit calculates the door mirror position according to the change of the voltage of 2 sensor input terminals.

## PASSENGER SIDE : Component Function Check

INFOID:0000000010596436

### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "MIR/SEN RH U-D", "MIR/SEN RH R-L" in "Data monitor" with CONSULT.
3. Check the mirror sensor (passenger side) signal under the following conditions.

# MIRROR SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

Monitor item	Condition	Value
MIR/SEN RH U-D	Door mirror (passenger side)	Change between 3.4 [V] (close to peak) 0.6 [V] (close to valley)
MIR/SEN RH R-L		Change between 3.4 [V] (close to left edge) 0.6 [V] (close to right edge)

Is the indication normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-101, "PASSENGER SIDE : Diagnosis Procedure".](#)

## PASSENGER SIDE : Diagnosis Procedure

INFOID:000000010596437

### 1.CHECK DOOR MIRROR SENSOR (PASSENGER SIDE) POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect door mirror (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between door mirror (passenger side) harness connector and ground.

(+) Door mirror (passenger side)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
D33	23	Ground	4 – 6 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

### 2.CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) harness connector.

Automatic drive positioner control unit		Door mirror (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M78	21	D33	23	Existed

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	21		Not existed

Is the inspection result normal?

YES >> Replace automatic driver positioner control unit. Refer to [ADP-220, "Removal and Installation".](#)  
NO >> Repair or replace harness or connector.

### 3.CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR GROUND

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) connector.

A

B

C

D

E

F

G

H

ADP

K

L

M

N

O

P

# MIRROR SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Door mirror (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M78	20	D33	24	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connector.

## 4. CHECK DOOR MIRROR (PASSENGER SIDE) SENSOR HARNESS CONTINUITY

1. Check continuity between automatic drive positioner control unit harness connector and door mirror (passenger side) harness connector.

Automatic drive positioner control unit		Door mirror (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M78	5	D33	21	Existed
	17		22	

2. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	5		
	17		Not existed

Is the inspection result normal?

YES >> Replace door mirror sensor. (Built in passenger side door mirror).

NO >> Repair or replace harness or connector.

# SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## SLIDING MOTOR

### Description

INFOID:000000010596438

- The seat sliding motor is installed to the seat cushion frame.
- The seat sliding motor is installed with the driver seat control unit.
- The seat is slid frontward/rearward by changing the rotation direction of sliding motor.

### Component Function Check

INFOID:000000010596439

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT SLIDE" in "Active test" mode with CONSULT.
3. Check the sliding motor operation.

Test item		Description		
SEAT SLIDE	OFF	Seat sliding	Stop	
	FR		Forward	
	RR		Backward	

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-103, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:000000010596440

#### 1.CHECK SLIDING MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect sliding motor connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT SLIDE") with CONSULT.
5. Check voltage between sliding motor harness connector and ground.

(+) Sliding motor		(-)	Condition	Voltage (V) (Approx.)			
Connector	Terminal						
B461	34	Ground	SEAT SLIDE	OFF	0 – 1 V		
				FR (forward)	9 – 16 V		
				RR (backward)	0 – 1 V		
	38			OFF	0 – 1 V		
				FR (forward)	0 – 1 V		
				RR (backward)	9 – 16 V		

Is the inspection result normal?

YES >> Replace sliding motor. (Built in seat slide cushion frame.)

NO >> GO TO 2.

#### 2.CHECK SLIDING MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and sliding motor harness connector.

## SLIDING MOTOR

### < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Sliding motor		Continuity
Connector	Terminal	Connector	Terminal	
B452	34	B461	34	Existed
	38		38	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B452	34		Not existed
	38		

Is the inspection result normal?

YES >> Replace driver control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

# RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## RECLINING MOTOR

### Description

INFOID:000000010596441

- The seat reclining motor is installed to the seat back frame.
- The seat reclining motor is activated with the driver seat control unit.
- The seatback is reclined frontward/rearward by changing the rotation direction of reclining motor.

### Component Function Check

INFOID:000000010596442

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT RECLINING" in "Active test" mode with CONSULT.
3. Check the reclining motor operation.

Test item		Description	
SEAT RECLINING	OFF	Seat reclining	Stop
	FR		Forward
	RR		Backward

Is the operation of relevant parts normal?

- YES >> INSPECTION END  
NO >> Perform diagnosis procedure. Refer to [ADP-105, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:000000010596443

#### 1.CHECK RECLINING MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect reclining motor connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT RECLINING") with CONSULT
5. Check voltage between reclining motor harness connector and ground.

(+) Reclining motor		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
B454	39	Ground	SEAT RECLINING	OFF	0 – 1 V
	35			FR (forward)	9 – 16 V
				RR (backward)	0 – 1 V
				OFF	0 – 1 V
				FR (forward)	0 – 1 V
				RR (backward)	9 – 16 V

Is the inspection result normal?

- YES >> Replace reclining motor. (Built in seat back frame.)  
NO >> GO TO 2.

#### 2.CHECK RECLINING MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector.
3. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

## RECLINING MOTOR

### < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Reclining motor		Continuity
Connector	Terminal	Connector	Terminal	
B452	35	B454	35	Existed
	39		39	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B452	35		Not existed
	39		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

# LIFTING MOTOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

## LIFTING MOTOR (FRONT)

### Description

INFOID:0000000010596444

- The lifting motor (front) is installed to the seat slide cushion frame.
- The lifting motor (front) is activated with the driver seat control unit.
- The lifter (front) is moved upward/downward by changing the rotation direction of lifting motor (front).

### Component Function Check

INFOID:0000000010596445

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "SEAT LIFTER FR" in "Active test" mode with CONSULT.
- Check the lifting motor (front) operation.

Test item		Description	
SEAT LIFTER FR	OFF	Seat lifting (front)	Stop
	UP		Upward
	DWN		Downward

Is the operation of relevant parts normal?

- YES >> INSPECTION END  
NO >> Perform diagnosis procedure. Refer to [ADP-107, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000010596446

#### 1.CHECK LIFTING MOTOR (FRONT) POWER SUPPLY

- Turn ignition switch OFF.
- Disconnect lifting motor (front) connector.
- Turn the ignition switch ON.
- Perform "Active test" ("SEAT LIFTER FR") with CONSULT.
- Check voltage between lifting motor (front) harness connector and ground.

(+) Lifting motor (front)		(-)	Condition	Voltage (V) (Approx.)		
Connector	Terminal			SEAT LIFTER FR		
B455	40	Ground	OFF	0 – 1 V		
			UP	0 – 1 V		
			DWN (down)	9 – 16 V		
	36		OFF	0 – 1 V		
			UP	9 – 16 V		
			DWN (down)	0 – 1 V		

Is the inspection result normal?

- YES >> Replace lifting motor (front). (Built in seat slide cushion frame.)  
NO >> GO TO 2.

#### 2.CHECK LIFTING MOTOR (FRONT) CIRCUIT

- Turn ignition switch OFF.
- Disconnect driver seat control unit connector.
- Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

## LIFTING MOTOR (FRONT)

### < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Lifting motor (front)		Continuity
Connector	Terminal	Connector	Terminal	
B452	36	B455	36	Existed
	40		40	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B452	36		Not existed
	40		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

# LIFTING MOTOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

## LIFTING MOTOR (REAR)

### Description

INFOID:0000000010596447

- The lifting motor (rear) is installed to the seat slide cushion frame.
- The lifting motor (rear) is activated with the driver seat control unit.
- The seat lifter (rear) is moved upward/downward by changing the rotation direction of lifting motor (rear).

### Component Function Check

INFOID:0000000010596448

#### 1.CHECK FUNCTION

1. Turn ignition switch ON.
2. Select "SEAT LIFTER RR" in "Active test" mode with CONSULT.
3. Check the lifting motor (rear) operation.

Test item		Description		
SEAT LIFTER RR	OFF	Seat lifting (rear)	Stop	
	UP		Upward	
	DWN		Downward	

Is the operation of relevant parts normal?

- YES >> INSPECTION END  
NO >> Perform diagnosis procedure. Refer to [ADP-109, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000010596449

#### 1.CHECK LIFTING MOTOR (REAR) POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect lifting motor (rear) connector.
3. Turn the ignition switch ON.
4. Perform "Active test" ("SEAT LIFTER RR") with CONSULT
5. Check voltage between lifting motor (rear) harness connector and ground.

(+) Lifting motor (rear)		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
B456	42	Ground	SEAT LIFTER RR	OFF	0 – 1 V
	41			UP	9 – 16 V
				DWN (DOWN)	0 – 1 V
				OFF	0 – 1 V
				UP	0 – 1 V
				DWN (DOWN)	9 – 16 V

Is the inspection result normal?

- YES >> Replace lifting motor (rear). (Built in seat slide cushion frame.)  
NO >> GO TO 2.

#### 2.CHECK LIFTING MOTOR (REAR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit connector and lifting motor (rear) connector.
3. Check continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

## LIFTING MOTOR (REAR)

### < DTC/CIRCUIT DIAGNOSIS >

Driver seat control unit		Lifting motor (rear)		Continuity
Connector	Terminal	Connector	Terminal	
B452	41	B456	41	Existed
	42		42	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B452	41		Not existed
	42		

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

# TILT MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## TILT MOTOR

### Description

INFOID:000000010596450

- The tilt motor is installed to the steering column assembly.
- The tilt motor is activated with the automatic drive positioner control unit.
- The steering column is tilted upward/downward by changing the rotation direction of tilt motor.

### Component Function Check

INFOID:000000010596451

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "TILT MOTOR" in "Active test" mode with CONSULT.
- Check the tilt motor operation.

Test item		Description	
TILT MOTOR	OFF	Steering tilt	Stop
	UP		Upward
	DWN		Downward

Is the operation of relevant parts normal?

- YES >> INSPECTION END  
NO >> Perform diagnosis procedure. Refer to [ADP-111, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010596452

#### 1.CHECK TILT MOTOR POWER SUPPLY

- Turn ignition switch OFF.
- Disconnect tilt & telescopic motor connector.
- Turn the ignition switch ON.
- Perform "Active test" ("TILT MOTOR") with CONSULT.
- Check voltage between tilt & telescopic motor harness connector and ground.

(+) Tilt & telescopic motor		(-)	Condition	Voltage (V) (Approx.)			
Connector	Terminal						
M80	7	Ground	TILT MOTOR	OFF	0 – 1 V		
				UP	0 – 1 V		
				DWN (down)	9 – 16 V		
	3			OFF	0 – 1 V		
				UP	9 – 16 V		
				DWN (down)	0 – 1 V		

Is the inspection result normal?

- YES >> Replace tilt motor. (Built in steering column assembly.)  
NO >> GO TO 2.

#### 2.CHECK TILT MOTOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit and tilt & telescopic motor connector.
- Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

## TILT MOTOR

### < DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
M79	28	M80	7	Existed
	29		3	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M79	28		Not existed
	29		

Is the inspection result normal?

- YES    >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).  
NO    >> Repair or replace harness or connector.

# TELESCOPIC MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## TELESCOPIC MOTOR

### Description

INFOID:000000010596453

- The telescopic motor is installed to the steering column assembly.
- The telescopic motor is activated with the automatic drive positioner control unit.
- Compresses the steering column by changing the rotation direction of telescopic motor.

### Component Function Check

INFOID:000000010596454

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "TELESCO MOTOR" in "Active test" mode with CONSULT.
- Check the telescopic motor operation.

Test item		Description		
TELESCO MOTOR	OFF	Steering telescopic	Stop	
	FR		Forward	
	RR		Backward	

Is the operation of relevant parts normal?

- YES >> INSPECTION END  
NO >> Perform diagnosis procedure. Refer to [ADP-113, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010596455

#### 1.CHECK TELESCOPIC MOTOR POWER SUPPLY

- Turn ignition switch OFF.
- Disconnect tilt & telescopic motor connector.
- Turn the ignition switch ON.
- Perform "Active test" ("TELESCO MOTOR") with CONSULT
- Check voltage between tilt & telescopic motor harness connector and ground.

(+) Tilt & telescopic motor		(-)	Condition	Voltage (V) (Approx.)			
Connector	Terminal						
M80	10	Ground	TELESCOPIC MOTOR	OFF	0 – 1 V		
				FR (forward)	0 – 1 V		
				RR (backward)	9 – 16 V		
	4			OFF	0 – 1 V		
				FR (forward)	9 – 16 V		
				RR (backward)	0 – 1 V		

Is the inspection result normal?

- YES >> Replace telescopic motor. (Built in steering column assembly.)  
NO >> GO TO 2.

#### 2.CHECK TELESCOPIC MOTOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit and tilt & telescopic motor connector.
- Check continuity between automatic drive positioner control unit harness connector and tilt & telescopic motor harness connector.

## TELESCOPIC MOTOR

### < DTC/CIRCUIT DIAGNOSIS >

Automatic drive positioner control unit		Tilt & telescopic motor		Continuity
Connector	Terminal	Connector	Terminal	
M79	26	M80	10	Existed
	29		4	

4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M79	26		Not existed
	29		

Is the inspection result normal?

- YES    >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).  
NO    >> Repair or replace harness or connector.

# DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## DOOR MIRROR MOTOR

### Description

INFOID:0000000010596456

It makes mirror face operate from side to side and up and down with the electric power that AUTOMATIC DRIVE POSITIONER CONTROL UNIT supplies.

### Component Function Check

INFOID:0000000010596457

#### 1. CHECK DOOR MIRROR MOTOR FUNCTION

Check the operation with "MIRROR MOTOR RH" and "MIRROR MOTOR LH" in "ACTIVE TEST" mode with CONSULT

Refer to [ADP-43, "CONSULT Function"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Refer to [ADP-115, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000010596458

#### 1. CHECK DOOR MIRROR MOTOR INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between door mirror connector and ground.

( + )		(-)	Condition	Voltage (V) (Approx.)
Door mirror				
Connector	Terminal			
D3 (Driver side) D33 (Passenger side)	12	Ground	Door mirror remote control switch	UP
	11			Other than above
	10			LEFT
				Other than above
				DOWN / RIGHT
				Other than above

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit connector.
3. Check continuity between automatic drive positioner control unit connector and door mirror connector.

[Door mirror driver side]		Automatic drive positioner control unit		Door mirror (driver side)		Continuity	
Connector	Terminal	Connector	Terminal				
M78	12	D3	10	Existed			
	23		12				
	24		11				

[Door mirror passenger side]		Automatic drive positioner control unit		Door mirror (passenger side)		Continuity	
Connector	Terminal	Connector	Terminal				
M78	22	D33	10	Existed			
	10		12				
	11		11				

# DOOR MIRROR MOTOR

## < DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between automatic drive positioner control unit connector and ground.

[Door mirror driver side]

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	12		Not existed
	23		
	24		

[Door mirror passenger side]

Automatic drive positioner control unit		Ground	Continuity
Connector	Terminal		
M78	22		Not existed
	10		
	11		

Is the inspection result normal?

- YES >> Replace automatic drive positioner control unit. Refer to [ADP-220, "Removal and Installation"](#).  
NO >> Repair or replace harness or connector.

## 3.CHECK DOOR MIRROR MOTOR

Check door mirror motor.

Refer to [ADP-116, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace door mirror. Refer to [MIR-123, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

## 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000010596459

### 1.CHECK DOOR MIRROR MOTOR-I

Check that door mirror motor does not trap foreign objects and does not have any damage.

Refer to [MIR-123, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace door mirror. Refer to [MIR-123, "DOOR MIRROR ASSEMBLY : Removal and Installation"](#).

### 2.CHECK DOOR MIRROR MOTOR-II

1. Turn ignition switch OFF.
2. Disconnect door mirror connector.
3. Apply 12V to each power supply terminal of door mirror motor.

Door mirror		Operational direction	
Connector	Terminal		
	(+)	(-)	
D3 (Driver side) D33 (Passenger side)	10	11	RIGHT
	11	10	LEFT
	12	10	UP
	10	12	DOWN

Is the inspection result normal?

- YES >> INSPECTION END

## DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

NO    >> Replace door mirror. Refer to [MIR-123, "DOOR MIRROR ASSEMBLY : Removal and Installation".](#)

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# SEAT MEMORY INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

## SEAT MEMORY INDICATOR

### Description

INFOID:0000000010596460

- Memory switch is equipped on the seat memory switch installed to the driver side door trim. The operation signal is inputted to the automatic drive positioner control unit when the memory switch is operated.
- The status of automatic drive positioner system can be checked according to the illuminating/flashing status.

### Component Function Check

INFOID:0000000010596461

#### 1.CHECK FUNCTION

- Turn ignition switch ON.
- Select "MEMORY SW INDCTR" in "Active test" mode with CONSULT.
- Check the memory indicator operation.

Test item		Description	
MEMORY SW INDCTR	OFF	Memory switch indicator	OFF
	ON-1		Indicator 1: ON
	ON-2		Indicator 2: ON

Is the operation of relevant parts normal?

YES >> INSPECTION END

NO >> Perform diagnosis procedure. Refer to [ADP-118, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000010596462

#### 1.CHECK MEMORY INDICATOR POWER SUPPLY

Check voltage between seat memory switch harness connector and ground.

(+) Seat memory switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
D5	5	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following.

- 10A fuse [No.10 located in fuse block (J/B)].
- Harness for open or short between memory indicator and fuse.

#### 2.CHECK MEMORY INDICATOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect driver seat control unit and seat memory switch connector.
- Check continuity between driver seat control unit harness connector and seat memory switch harness connector.

Driver seat control unit		Seat memory switch		Continuity
Connector	Terminal	Connector	Terminal	
B451	23	D5	6	Existed
	7		7	

- Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit		Ground	Continuity
Connector	Terminal		
B451	23		
	7		Not existed

# SEAT MEMORY INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

## 3.CHECK MEMORY INDICATOR

Refer to [ADP-119, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace seat memory switch. Refer to [ADP-221, "Removal and Installation"](#).

## 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

### Component Inspection

INFOID:000000010596463

#### 1.CHECK SEAT MEMORY INDICATOR

1. Turn ignition switch OFF.
2. Disconnect seat memory switch connector.
3. Check continuity between seat memory switch terminals.

Seat memory switch		Continuity
Terminal		
(+)	(-)	
5	6	
	7	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat memory switch. Refer to [ADP-221, "Removal and Installation"](#).

ADP

K

L

M

N

O

P

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION DRIVER SEAT CONTROL UNIT

### Reference Value

INFOID:0000000010596464

### VALUES ON THE DIAGNOSIS TOOL

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

#### CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
SET SW	Set switch	Push
		Release
MEMORY SW1	Memory switch 1	Push
		Release
MEMORY SW2	Memory switch 2	Push
		Release
SLIDE SW-FR	Sliding switch (front)	Operate
		Release
SLIDE SW-RR	Sliding switch (rear)	Operate
		Release
RECLN SW-FR	Reclining switch (front)	Operate
		Release
RECLN SW-RR	Reclining switch (rear)	Operate
		Release
LIFT SW-UP	Lifting switch front (up)	Operate
		Release
LIFT SW-DOWN	Lifting switch front (down)	Operate
		Release
MIR CON SW-UP	Mirror switch	Up
		Other than above
MIR CON SW-DN	Mirror switch	Down
		Other than above
MIR CON SW-RH	Mirror switch	Right
		Other than above
MIR CON SW-LH	Mirror switch	Left
		Other than above
MIR CHNG SW-R	Changeover switch	Right
		Other than above
MIR CHNG SW-L	Changeover switch	Left
		Other than above
TILT SW-UP	Tilt switch	Up
		Other than above
TILT SW-DOWN	Tilt switch	Down
		Other than above

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
TELESCO SW-FR	Telescopic switch	Forward	ON
		Other than above	OFF
TELESCO SW-RR	Tilt switch	Backward	ON
		Other than above	OFF
DETENT SW	AT selector lever	P position	OFF
		Other than above	ON
STARTER SW	Ignition position	Cranking	ON
		Other than above	OFF
SLIDE PULSE	Seat sliding	Forward	The numeral value decreases * <sup>1</sup>
		Backward	The numeral value increases * <sup>1</sup>
		Other than above	No change to numeral value * <sup>1</sup>
RECLN PULSE	Seat reclining	Forward	The numeral value decreases * <sup>1</sup>
		Backward	The numeral value increases * <sup>1</sup>
		Other than above	No change to numeral value * <sup>1</sup>
LIFT PULSE	Seat lifter	Up	The numeral value decreases * <sup>1</sup>
		Down	The numeral value increases * <sup>1</sup>
		Other than above	No change to numeral value * <sup>1</sup>
MIR/SEN RH U-D	Door mirror (passenger side)		Change between 3.4 (close to peak) 0.6 (close to valley)
MIR/SEN RH R-L	Door mirror (passenger side)		Change between 3.4 (close to left edge) 0.6 (close to right edge)
MIR/SEN LH U-D	Door mirror (driver side)		Change between 3.4 (close to peak) 0.6 (close to valley)
MIR/SEN LH R-L	Door mirror (driver side)		Change between 0.6 (close to left edge) 3.4 (close to right edge)
TILT PULSE	Tilt position	Upward	The numeral value decreases * <sup>1</sup>
		Downward	The numeral value increases * <sup>1</sup>
		Other than above	No change to numeral value * <sup>1</sup>
TELESCO PULSE	Telescopic position	Forward	The numeral value decreases * <sup>1</sup>
		Backward	The numeral value increases * <sup>1</sup>
		Other than above	No change to numeral value * <sup>1</sup>
STEERING STATUS	Steering lock unit	Lock	LOCK
		Unlock	UNLOCK
VEHICLE SPEED	The condition of vehicle speed is display		km/h
P RANG SW CAN	A/T shift selector	P position	ON
		Other than above	UNLOCK
R RANG (CAN)	A/T shift selector	R position	ON
		Other than above	UNLOCK
DOOR SW-FL	Driver door	Open	OPEN
		Close	CLOSE
DOOR SW-FR	Passenger door	Open	OPEN
		Close	CLOSE


# DRIVER SEAT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status
IGN ON SW	Ignition switch	ON position	ON
		Other than above	OFF
ACC ON SW	Ignition switch	ACC position	ON
		Other than above	OFF
KEYLESS ID	Intelligent Key button	Pressed	MEMORY1/2/3/4/5
		Other than above	OFF
KYLS DR UNLOCK	Intelligent Key or door request switch	ON	ON
		OFF	OFF
VHCL SPEED (ABS)	Vehicle speed signal (ABS)	Received	RCV
		Not received	NORCV
HANDLE	Vehicle	left handle models	LHD
		Right handle models	RHD
TRANSMISSION	Transmission	M/T	M/T
		A/T	A/T

\*1: The value at the position attained when the battery is connected is regarded as 32768.

## TERMINAL LAYOUT





## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value
+	-	Signal name	Input/ output		
1 (L)	—	CAN-H	—	—	—
2 (BR)	Ground	UART communication (TX/RX)	Input/ output	Ignition switch ON	

# DRIVER SEAT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value
+	-	Signal name	Input/ output			
4 (W/G)	Ground	Reclining sensor signal	Input	Seat reclining	Operate	 JMJIA0119ZZ
					Other than the above	0 or 5 V
5 (V)	Ground	Telescopic sen- sor signal	Input	Steering telescopic	Operate	 JMJIA0119ZZ
					Other than the above	0 or 5 V
6 (GY)	Ground	Memory switch 2 signal	Input	Memory switch 2	Press	0 - 1 V
					Other than the above	4 - 6 V
7 (G)	Ground	Memory indica- tor 2 signal	Out- put	Memory indicator 2	Illuminate	0 - 1 V
					Other than the above	9 - 16 V
8 (BR)	Ground	Sliding switch backward signal	Input	Sliding switch	Operate (backward)	0 - 1 V
					Other than the above	9 - 16 V
9 (SB)	Ground	Reclining switch backward signal	Input	Reclining switch	Operate (backward)	0 - 1 V
					Other than the above	9 - 16 V
10 (LG/R)	Ground	Lifting switch (front) down sig- nal	Input	Lifting switch (front)	Operate (down)	0 - 1 V
					Other than the above	9 - 16 V
11 (G/B)	Ground	Lifting switch (rear) down sig- nal	Input	Lifting switch (rear)	Operate (down)	0 - 1 V
					Other than the above	9 - 16 V
12 (O)	Ground	Sensor power supply	Out- put	—		9 - 16 V
17 (P)	—	CAN-L	—	—		—

A

B

C

D

E

F

G

H

ADP

K

L

M




N

O

P

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value
+	-	Signal name	Input/ output		
18 (R)	Ground	Sliding sensor signal	Input	Seat sliding	Operate   JMJIA0119ZZ
					Other than the above 0 or 5 V
19 (Y/B)	Ground	Lifting sensor (front) signal	Input	Seat lifting (front)	Operate   JMJIA3675ZZ
					Other than the above 0 or 12 V
20 (P/B)	Ground	Lifting sensor (rear) signal	Input	Seat lifting (rear)	Operate   JMJIA3675ZZ
					Other than the above 0 or 12 V
21 (SB)	Ground	Tilt sensor signal	Input	Steering tilt	Operate   JMJIA0119ZZ
					Other than the above 0 or 5 V
22 (O)	Ground	Memory switch 1 signal	Input	Memory switch 1	Press 0 - 1 V
					Other than the above 4 - 6 V
23 (W)	Ground	Memory indicator 1 signal	Out- put	Memory indicator 1	Illuminate 0 - 1 V
					Other than the above 9 - 16 V
24 (Y)	Ground	Sliding switch forward signal	Input	Sliding switch	Operate (forward) 0 - 1 V
					Other than the above 9 - 16 V

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value
+	-	Signal name	Input/ output			
25 (R/G)	Ground	Reclining switch forward signal	Input	Reclining switch	Operate (forward)	0 - 1 V
					Other than the above	9 - 16 V
26 (W/B)	Ground	Lifting switch (front) up signal	Input	Lifting switch (front)	Operate (up)	0 - 1 V
					Other than the above	9 - 16 V
27 (P/L)	Ground	Lifting switch (rear) up signal	Input	Lifting switch (rear)	Operate (up)	0 - 1 V
					Other than the above	9 - 16 V
28 (Y)	Ground	Set switch signal	Input	Set switch	Press	0 - 1 V
					Other than the above	4 - 6 V
33 (R)	Ground	Battery power supply	Input	—		9 - 16 V
34 (W/B)	Ground	Sliding motor backward output signal	Out- put	Seat sliding	Operate (backward)	9 - 16 V
					Other than the above	0 - 1 V
35 (G/Y)	Ground	Reclining motor forward output signal	Out- put	Seat reclining	Operate (forward)	9 - 16 V
					Other than the above	0 - 1 V
36 (G/W)	Ground	Lifting motor (front) down out- put signal	Out- put	Seat lifting (front)	Operate (down)	9 - 16 V
					Other than the above	0 - 1 V
38 (W/R)	Ground	Sliding motor forward output signal	Out- put	Seat sliding	Operate (forward)	9 - 16 V
					Other than the above	0 - 1 V
39 (P)	Ground	Reclining motor backward output signal	Out- put	Seat reclining	Operate (backward)	9 - 16 V
					Other than the above	0 - 1 V
40 (L/R)	Ground	Lifting motor (front) up output signal	Out- put	Seat lifting (front)	Operate (up)	9 - 16 V
					Other than the above	0 - 1 V
41 (L/Y)	Ground	Lifting motor (rear) up output signal	Out- put	Seat lifting (rear)	Operate (up)	9 - 16 V
					Other than the above	0 - 1 V

# DRIVER SEAT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition		Value
+	-	Signal name	Input/ output			
42 (R/B)	Ground	Lifting motor (rear) down out- put signal	Out- put	Seat lifting (rear)	Operate (down)	9 - 16 V
					Other than the above	0 - 1 V
43 (B)	Ground	Ground	—	—		0 - 1 V

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -


INFOID:000000010596465



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# DRIVER SEAT CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >



JRJWC5606GB

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >




JRJWC5607GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



JRJWC5608GB


# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## AUTOMATIC DRIVE POSITIONER

Connector No.	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
51	R	3	LG
5	G	5	R
6	SB	2	SB
7	Y	3	Y
8	L	4	R
11	V	5	W
12	SB	6	G
13	LG	7	LG
14	GR	8	B
15	LG	14	SB
16	R	15	GR
17	W	16	P
18	SB	21	G
19	LG	22	B
20	BR	23	SHEILD
21	SHEILD	24	BR
22	Y	91	G
24	P	92	BR
27	B	93	G
38	R	94	SB
29	W	95	C
30	SHEILD	96	Y
31	SHEILD	97	W
32	W	99	GR
33	SB		
34	L		
35	P		
36	L		
37	P		
38	P		
39	Y		
40	SB		
44	Y		
45	GR		
46	LG		

Connector No.	Signal Name [Specification]	Wire To Wire	Connector No.	Signal Name [Specification]
47	SE	-	55	B11
48	BG	-		WIRE TO WIRE
49	R	-		CONNECTOR TYPE
50	L	-		NSIIFY-CS
60	P	-		
61	L	-		
62	SHIELD	-		
63	R	-		
64	G	-		
65	SHIELD	-		
66	W	-		
67	Y	-		
68	SB	-		
69	SHIELD	-		
70	W	-		
73	SB	-		
74	L	-		
75	W	-		
76	BR	-		
77	R	-		
78	P	-		
79	GR	-		
83	BG	-		
85	V	-		
86	LG	-		
87	Y	-		
88	R	-		
89	B	-		
90	BG	-		
91	G	-		
92	BR	-		
93	G	-		
94	SB	-		
95	C	-		
96	Y	-		
97	W	-		
99	GR	-		



Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-	3	L	-
2	SB	-	5	R	-
3	Y	-	6	SB	-
4	R	-	7	P	-
5	W	-	17	Y	-
6	G	-	19	P	-
7	LG	-	21	V	-
8	B	-	22	L	-
14	SB	-	23	BG	-
15	GR	-	28	R	-
16	LG	-	32	P	-
17	P	-	33	R	-
18	SB	-	43	B	-
19	LG	-	60	G	-
20	BR	-	66	GR	-
21	SHEILD	-	67	Y	-
22	Y	-	76	Y	-
24	P	-	27	W	-
27	B	-	38	R	-
38	R	-	39	L	-
29	W	-	30	SHEILD	-
31	SHEILD	-	31	Y	-

Connector No.	Signal Name [Specification]	Wire To Wire	Connector No.	Signal Name [Specification]
55	B11	-		WIRE TO WIRE
				CONNECTOR TYPE

Terminal No.	Color Of Wire	Signal Name [Specification]
2	-	-
3	-	-

Terminal No.	Color Of Wire	Signal Name [Specification]
2	-	-
3	-	-

ADP

K

M

O

P

A B C D E F G H I J L M N O P

JRJWC5650GB

# DRIVER SEAT CONTROL UNIT

**< ECU DIAGNOSIS INFORMATION >**


---

## AUTOMATIC DRIVE POSITIONER

Connector No.	B46	Connector No.	B451
Connector Name	GROUND/VIEW MONITOR CONTROL UNIT	Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	T140F-TV-H41	Connector Type	T132FW




Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
1	B	GROUND	CAN-H
2	Y	BATTERY	UART (TX/RX)
3	P	IGNITION SIGNAL	FUSE SET (RECLINER)
4	GR	ACC	PULSE (TELESCOPIC)
5	EG	ILLUMINATION SIGNAL	ADDRESS 2
6	SB	VEHICLE SPEED SIGNAL (3-POLE)	SW1 (IND 2)
7	V	REVERSE SIGNAL	SW2 (BACKWARD)
9		CONTROL SIGNAL	RECLINER SW (BACKWARD)
13	B	CONTROL SIGNAL	FRONT LIFTER SW (DOWNWARD)
17	SB	AV COMM (H)	FRONT LIFTER SW (DOWNWARD)
18	LG	AV COMM (L)	POWER SUPPLY (ENCODER)
21	SB	AV COMM (H)	CAN-L
22	LG	AV COMM (L)	PULSE (SIDE)
23	LG	-	PULSE (FRONT LIFTER)
24	G	-	PULSE (REAR LIFTER)
27	W	CAMERA IMAGE SIGNAL	PULSE (LIFT)
28	SHIELD	CAMERA IMAGE SIGNAL GND	ADDRESS 1
29	Y	SIDE CAMERA RH IMAGE SIGNAL	IND 1
30	G	SIDE CAMERA RH IMAGE GND	SW1 (FORWARD)
31	SHIELD	SHIELD	RECLINER SW (FORWARD)
32	B	SIDE CAMERA RH GND	FRONT LIFTER SW (UPWARD)
33	W	SIDE CAMERA RH GND	REAR LIFTER SW (UPWARD)
34	R	SIDE CAMERA RH POWER SUPPLY	SET SW
35	L	REAR CAMERA COMM	-
36	BR	REAR CAMERA POWER SUPPLY	-
37	SHIELD	SHIELD	-
38	R	REAR CAMERA GND	-
39	Y	REAR CAMERA IMAGE SIGNAL	-
40	W	REAR CAMERA IMAGE GND	-




Connector No.	B452	Connector No.	B454
Connector Name	DRIVER SEAT CONTROL UNIT	Connector Name	RECLINING MOTOR
Connector Type	NS16FW-CS	Connector Type	NS16FW-CS




Connector No.	B454	Connector No.	B454
Connector Name	RECLINING MOTOR	Connector Name	RECLINING MOTOR
Connector Type	NS16FW-CS	Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
1	W	BA1 (PTC)	SLIDE MOTOR (BACKWARD)
2	G	SLIDE MOTOR (FORWARD)	RECLINER MOTOR (FORWARD)
35	P	FRONT LIFTER MOTOR (FORWARD)	FRONT LIFTER MOTOR (FORWARD)
36	G/Y	SLIDE MOTOR (FORWARD)	RECLINER MOTOR (FORWARD)
39	GR	FRONT LIFTER MOTOR (UPWARD)	REAR LIFTER MOTOR (UPWARD)
40	-	REAR LIFTER MOTOR (DOWNWARD)	REAR LIFTER MOTOR (DOWNWARD)
41	-	REAR LIFTER MOTOR (UPWARD)	REAR LIFTER MOTOR (UPWARD)
42	-	FRONT LIFTER MOTOR (DOWNWARD)	FRONT LIFTER MOTOR (DOWNWARD)
43	GND	FRONT LIFTER MOTOR (DOWNWARD)	FRONT LIFTER MOTOR (DOWNWARD)



Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
33	-	BA1 (PTC)	SLIDE MOTOR (BACKWARD)
34	-	SLIDE MOTOR (FORWARD)	RECLINER MOTOR (FORWARD)
35	P	FRONT LIFTER MOTOR (FORWARD)	FRONT LIFTER MOTOR (FORWARD)
39	G/Y	SLIDE MOTOR (FORWARD)	RECLINER MOTOR (FORWARD)
43	GR	FRONT LIFTER MOTOR (UPWARD)	REAR LIFTER MOTOR (UPWARD)
44	-	REAR LIFTER MOTOR (DOWNWARD)	REAR LIFTER MOTOR (DOWNWARD)
45	-	REAR LIFTER MOTOR (UPWARD)	REAR LIFTER MOTOR (UPWARD)
46	GND	FRONT LIFTER MOTOR (DOWNWARD)	FRONT LIFTER MOTOR (DOWNWARD)



Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
36	O	SLIDING SENSOR	SLIDING SENSOR
40	G/W	IND 1	IND 1
43	GR	IND 2	IND 2



Terminal No.	Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
12	O	IND 1	IND 1
13	G	IND 2	IND 2
36	L/R	IND 3	IND 3
43	GR	IND 4	IND 4



# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## AUTOMATIC DRIVE POSITIONER

Connector No.	Connector Name	Signal Name [Specification]	Terminal Color Of Wire No.	Color Of Wire	Signal Name [Specification]	Terminal Color Of Wire No.	Color Of Wire	Signal Name [Specification]		
B456	LIFTING MOTOR (REAR)	-	12	O	-	1	R	-		
	Connector Type	NSD0FBR-CS	20	P/B	-	2	B	-		
			41	R/B	-	3	Y	-		
			42	L/Y	-	4	W	-		
			43	GR	-	5	L	-		
					17	Y/R	-	32	R	-
					19	V	-	6	O	-
					21	L/Y	-	7	GR	-
					22	-	-	8	W	-
					23	-	-	9	O	-
					28	-	-	10	BR	-
					32	B/W	-	11	P	-
					33	R	-	12	LG	-
					43	-	-	13	B	-
					60	Y/R	-	14	Y	-
					66	B	-	15	W	-
					67	L	-	16	R	-
								17	W	-
								18	G	-
								19	Y	-
								20	W	-
								21	O	-
								22	P	-
								23	BR	-
								24	V	-
								25	GR	-
								26	Y	-
								27	B	-
								28	SHEILD	-
								29	LG	-
								30	G	-
								31	W	-
								32	G	-
								33	L	-
								34	SB	-
								35	R	-
								36	LG	-

ADP

O

Z

M

K

L

—

H

—

G

T

M

D

C

B

A

JRJWC5652GB

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## AUTOMATIC DRIVE POSITIONER

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-	7	R	-
2	BR	-	8	BR	-
3	GR	-	9	V	-
4	B	-	12	V	-
5	R	-	13	LG	-
6	O	-	14	B	-
7	P	-	15	W	-
18	R	-	16	BR	-
19	Y	-	17	GR	-
20	B	-	18	Y	-
21	BR	-	20	R	-
22	G	-	21	G	-
23	V	-	22	Y	-
24	P	-	23	B	-
25	W	-	24	P	-
26	SB	-	25	Y	-
29	SHIELD	-	26	Y	-
30	LG	-	27	W	-
31	LG	-	28	G	-
32	BR	-	31	BG	-
33	O	-	32	W	-
34	GR	-	33	B	-
35	G	-	34	R	-
36	R	-	35	G	-
37	G	-	36	SHIELD	-
43	Y	-	37	V	-
44	Y	-	38	BR	-
45	P	-	39	BG	-
46	W	-	41	W	-
47	SHEILD	-	42	G	-
52	G	-			
53	GR	-			
54	O	-			
55	L	-			

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
13	W	-	46	W	-
15	Y	-	47	SHEILD	-
22	BR	-	52	G	-
23	Y	-	53	GR	-
24	V	-	54	O	-
25	V	-	55	L	-

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-	10	W	-
2	LG	-	11	Y	-
3	BR	-	12	BR	-
4	SB	-	13	SB	-
5	LG	-	14	LG	SIDE CAMERA RH IMAGE SIGNAL
6	BR	-	15	BR	SIDE CAMERA RH POWER SUPPLY
7	SB	-	16	LG	-
17	BR	-	17	LG	-
18	BR	-	18	Y	-
19	Y	-	19	Y	-
20	Y	[With BOSE audio] - Without BOSE audio	20	Y	[With BOSE audio] - Without BOSE audio
21	BR	-	21	G	SIDE CAMERA RH IMAGE GND
22	G	-	22	Y	SIDE CAMERA RH GND
23	V	-	23	B	-
24	P	-	24	P	-
25	W	-	25	Y	-
26	SB	-	26	Y	-
29	SHIELD	-	27	W	-
30	LG	-	28	G	-
31	LG	-	31	BG	-
32	BR	-	32	W	-
33	O	-	33	B	-
34	GR	-	34	R	-
35	G	-	35	G	-
36	R	-	36	SHIELD	-
37	G	-	37	V	-
43	Y	-	38	BR	-
44	Y	-	39	BG	-
45	P	-	41	W	-
46	W	-	42	G	-

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-	7	B	-
2	BR	-	8	B	-
3	Y	-	9	R	-
4	V	-	10	GR	-
5	LG	-	11	LG	-
6	G	-	12	G	-
7	BR	-	13	LG	-
8	BR	-	14	LG	-
9	Y	-	15	Y	-
10	Y	-	16	Y	-
11	LG	-	17	LG	-
12	G	-	18	Y	-
13	LG	-	19	Y	-
14	LG	-	20	Y	-
15	Y	-	21	P	-
16	Y	-	22	Y	-
17	Y	-	23	W	-
18	Y	-	24	V	-
19	Y	-	25	Y	-
20	Y	-	26	R	-
21	Y	-	27	W	-
22	Y	-	28	G	-
23	Y	-	29	Y	-
24	Y	-	30	LG	-
25	Y	-	31	BG	-
26	Y	-	32	W	-
27	Y	-	33	B	-
28	Y	-	34	R	-
29	Y	-	35	G	-
30	Y	-	36	SHIELD	-
31	Y	-	37	V	-
32	Y	-	38	BR	-
33	Y	-	39	BG	-
34	Y	-	41	W	-
35	Y	-	42	G	-

JRJWC5653GB

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		IGNITION POWER SUPPLY		IGNITION POWER SUPPLY		IGNITION POWER SUPPLY		IGNITION POWER SUPPLY	
43	BR	-	-	5	-	5	-	5	-
45	W	-	-	6	-	6	-	6	W
49	L	-	-	7	-	7	-	7	LG
50	P	-	-	8	-	8	-	8	B
51	L	-	-	9	-	9	-	14	V
54	BG	-	-	10	-	10	-	15	V
57	BR	-	-	11	-	11	-	16	W
59	W	-	-	12	-	12	-	21	G
60	LG	-	-	13	-	13	-	22	B
61	G	-	-	14	-	14	-	23	SHIELD
62	SB	-	-	15	-	15	-	24	R
63	W	-	-	16	-	16	-	25	R
64	B	-	-	17	-	17	-	26	Y
65	G	-	-	18	-	18	-	27	G
66	R	-	-	19	-	19	-	28	B
67	SHIELD	-	-	20	-	20	-	29	W
68	Y	-	-	30	-	30	-	31	Y
69	LG	-	-	31	-	31	-	32	SHIELD
70	W	-	-	33	-	33	-	34	-
71	R	-	-	35	-	35	-	36	-
72	Y	-	-	37	-	37	-	38	-
73	B	-	-	39	-	39	-	39	-
74	BR	-	-	40	-	40	-	40	-
74	L	-	-	41	-	41	-	41	-
75	G	-	-	42	-	42	-	42	-
75	W	-	-	43	-	43	-	43	-
76	W	-	-	44	-	44	-	44	-
76	Y	-	-	45	-	45	-	45	-
77	P	-	-	46	-	46	-	46	-
77	R	-	-	47	-	47	-	47	-
78	BR	-	-	48	-	48	-	48	-
78	L	-	-	49	-	49	-	49	-
79	LG	-	-	50	-	50	-	50	-
79	Y	-	-	51	-	51	-	51	-
80	SB	-	-	52	-	52	-	52	-
81	R	-	-	53	-	53	-	53	-
82	SB	-	-	54	-	54	-	54	-
83	BG	-	-	55	-	55	-	55	-
84	G	-	-	56	-	56	-	56	-
85	P	-	-	57	-	57	-	57	-
86	V	-	-	58	-	58	-	58	-
87	GR	-	-	59	-	59	-	59	-
89	SHIELD	-	-	60	-	60	-	60	-
91	W	-	-	61	-	61	-	61	-
92	Y	-	-	62	-	62	-	62	-
93	V	-	-	63	-	63	-	63	-
94	LG	-	-	64	-	64	-	64	-
95	BG	-	-	65	-	65	-	65	-
96	P	-	-	66	-	66	-	66	-

JRJWC5654GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		Connector No.	MS	98	SHIELD	-
		Connector Name	WIRE TO WIRE	99	V	-
		Connector Type	T180MM-CS16-TM4 <th>100</th> <th>SB</th> <th>-</th>	100	SB	-
17	B			43	BR	-
18	G			45	W	-
19	Y			49	L	-
20	L			50	P	-
21	LG			51	BR	-
22	L			54	Y	-
23	G			57	G	-
24	Y			59	W	-
25	GR			60	L	-
26	R			61	G	-
27	W			62	SB	-
28	SHIELD			63	G	-
29	Y			64	B	-
30	Y			65	W	-
31	R			66	R	-
32	BR			67	SHIELD	-
33	SB			68	Y	-
34	Y			69	OR	-
35	P			70	LG	-
36	LG			71	LG	-
37	BR			72	Y	-
38	P			73	SB	-
39	BG			74	BR	-
40	SB			74	L	-
41	L			75	G	-
42	R			76	GR	-
43	BR			76	W	-
44	V			77	P	-
45	G			77	R	-
46	SB		- [With automatic drive positioner]	78	L	-
47	Y		- [Without automatic drive positioner]	78	R	-
48	R			79	W	-
49	G			79	Y	-
50	P			80	SB	-
51	SHIELD			81	SB	-
52	R			82	SB	-
53	V			83	Y	-
54	LG			84	G	-
55	SB			85	L	-
				86	P	-
				87	W	-
				89	GR	-
				90	SHIELD	-
				91	W	-
				92	Y	-
				93	BR	-
				94	P	-
				95	GR	-
				96	W	-
				97	L	-
				32	P	-
				33	SB	-
				34	L	-
				35	P	-
				36	L	-
				37	P	-
				38	P	-

JRJWC5655GB

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		
39	Y	
40	SB	
44	L	
45	GR	
46	LG	
47	SB	
48	BG	
49	R	
50	L	
60	P	
61	L	
62	SHIELD	
63	R	
64	G	
65	SHELD	
66	SB	
67	Y	
68	LG	
69	SHELD	
70	W	
73	G	
74	R	
75	W	
76	W	
77	B	
78	P	
79	GR	
33	BG	
35	LG	
36	R	
37	Y	
38	W	
39	BR	
40	EG	
51	G	
52	V	
33	BR	
34	V	
35	G	
36	Y	
38	W	
39	R	

M22		
Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.
KEY SLOT	BAT	1 B
TILT & TELESCOPIC SWITCH	CLOCK	2 GR
TILT & TELESCOPIC SWITCH	DATA	3 G
TILT & TELESCOPIC SWITCH	ILL BAT	4 Y
TILT & TELESCOPIC SWITCH	ILL	5 W
TILT & TELESCOPIC SWITCH	GROUND	7
TILT & TELESCOPIC SWITCH	KEY SWITCH SIGNAL	11 BR

M51		
Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.
KEY SLOT	TILT & TELESCOPIC SWITCH	1 Y
TILT & TELESCOPIC SWITCH	TK06FV	2 GR
TILT & TELESCOPIC SWITCH	TK06FV	3 G
TILT & TELESCOPIC SWITCH	TK06FV	4 Y
TILT & TELESCOPIC SWITCH	TK06FV	5 W

M67		
Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.
UNIFIED METER AND A/C AMP.	ACC POWER SUPPLY	41 Y
UNIFIED METER AND A/C AMP.	FUEL LEVEL SENSOR SIGNAL	42 Y
UNIFIED METER AND A/C AMP.	INTAKE AIR TEMP SENSOR SIGNAL	43 R
UNIFIED METER AND A/C AMP.	IN-VEHICLE SENSOR SIGNAL	44 G
UNIFIED METER AND A/C AMP.	AMBIENT SENSOR SIGNAL	45 P
UNIFIED METER AND A/C AMP.	SUNLOAD SENSOR SIGNAL	46 BG
UNIFIED METER AND A/C AMP.	EVAPORATOR FAN DEFROSTING SENSOR SIGNAL	47 G
UNIFIED METER AND A/C AMP.	IGNITION POWER SUPPLY	53 G
UNIFIED METER AND A/C AMP.	BATTERY POWER SUPPLY	54 Y
UNIFIED METER AND A/C AMP.	GROUND	55 B

M62		
Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.
CIRCUIT BREAKER	CIRCUIT BREAKER	56 L
M02FV-P-LC	M02FV-P-LC	57 W
M02FV-P-LC	BRAKE FLUID LEVEL SWITCH SIGNAL	58 BR
M02FV-P-LC	FUEL LEVEL SENSOR GROUND	59 GR
M02FV-P-LC	INTAKE AIR TEMP SENSOR GROUND	60 L
M02FV-P-LC	IN-VEHICLE SENSOR GROUND	61 BR
M02FV-P-LC	AMBIENT SENSOR GROUND	62 SB
M02FV-P-LC	SUNLOAD SENSOR GROUND	63 R
M02FV-P-LC	-	65 BG
M02FV-P-LC	ECV SIGNAL	66 L
M02FV-P-LC	A/C CAN SIGNAL	67 R
M02FV-P-LC	EACH DOOR MOTOR POWER SUPPLY GROUND	71 B
M02FV-P-LC	CAN_L	72 P

M24		
Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.
DATA LINK CONNECTOR	DATA	1 W
BD16FW	DATA	2 SB

M62		
Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.
CIRCUIT BREAKER	CIRCUIT BREAKER	3 LG
CIRCUIT BREAKER	CIRCUIT BREAKER	4 B
CIRCUIT BREAKER	CIRCUIT BREAKER	5 B
CIRCUIT BREAKER	CIRCUIT BREAKER	6 L
CIRCUIT BREAKER	CIRCUIT BREAKER	7 V
CIRCUIT BREAKER	CIRCUIT BREAKER	8 G
CIRCUIT BREAKER	CIRCUIT BREAKER	11 SB
CIRCUIT BREAKER	CIRCUIT BREAKER	14 P
CIRCUIT BREAKER	CIRCUIT BREAKER	16 Y

JRJWC5656GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# DRIVER SEAT CONTROL UNIT

**< ECU DIAGNOSIS INFORMATION >**

## AUTOMATIC DRIVE POSITIONER

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND	1	V	-
3	V	ACC	2	P	-
4	R	ILL. CONN.	3	LG	-
5	Y	AV COMM(R)	4	LG	-
6	SB	AV COMM(L)	5	R	-
8	LG	SW GND	6	P	-
9	B	DISK EJECT SIGNAL	7	G	-
14	Y	HAZARD ON	8	Y	-
16	G		9	BR	-
			10	L	-



Connector No.	Connector Name	Connector Type	Terminal No.	Color Of Wire	Signal Name
M72	MULTIFUNCTION SWITCH	TH1HFV-NH	13	W	DOWNWARD
			14	P	SELECT LH
			15	SE	DOWNWARD
			16	BR	RIGHTWARD
			17	L	MIR SENS LEFT/BRIGHT(RH)
			18	G	MIR SENS LEFT/BRIGHT(LH)
			19	G	BACKWARD
			20	Y	POWER SUPPLY (SENSOR)
			21	R	MIR MTR DOWN RIGHT(RH)
			22	R	MIR MTR DOWN UP(LH)
			23	LG	MIR MTR UP(LH)
			24	L	MIR MTR LEFT(LH)



Connector No.	Connector Name	Connector Type	Terminal No.	Color Of Wire	Signal Name
M60	TILT & TELESCOPIC MOTOR	NS10FW-CS	13	W	DOWNWARD
			14	P	SELECT LH
			15	SE	DOWNWARD
			16	BR	RIGHTWARD
			17	L	MIR SENS LEFT/BRIGHT(RH)
			18	G	MIR SENS LEFT/BRIGHT(LH)
			19	G	BACKWARD
			20	Y	POWER SUPPLY (SENSOR)
			21	R	MIR MTR DOWN RIGHT(RH)
			22	R	MIR MTR DOWN UP(LH)
			23	LG	MIR MTR UP(LH)
			24	L	MIR MTR LEFT(LH)



Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-	4	LG	INTERIOR FROM LAMP POWER SUPPLY
2	P	-	5	L	PASSENGER DOOR UNLOCK OUTPUT
3	LG	-	7	Y	STEP LAMP CONT.
4	LG	-	8	V	ALL DOOR FUEL INJECTION OUTPUT
5	R	-	9	G	DRIVE DOOR FUEL INJECTION OUTPUT
6	P	-	10	BR	REAR DOOR UNLOCK OUTPUT
7	G	-	11	R	BAT FUSE
8	Y	-	13	B	GROUND
9	BR	-	14	W	PUSH-BUTTON IGNITION SW. (ILL. GRID)
10	L	-	15	Y	ACC IND.
			17	W	TURN SIGNAL RH (FRONT)
			18	BG	TURN SIGNAL LH (FRONT)
			19	V	INT ROOM LAMP CONTROL



Connector No.	Connector Name	Connector Type	Terminal No.	Color Of Wire	Signal Name
M79	AUTOMATIC DRIVE POSITIONER CONTROL UNIT	TH24FN-NH	1	B	GND
			3	V	ACC
			4	R	ILL. CONN.
			5	Y	AV COMM(R)
			6	SB	AV COMM(L)
			8	LG	SW GND
			9	B	DISK EJECT SIGNAL
			14	Y	HAZARD ON
			16	G	



Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
25	SB	BAT	1	W	BAT (F.L.)
26	L	BACKWARD	2	W	POWER WINDOW POWER SUPPLY(YEARF)
27	P	STROBE VCC	3	Y	POWER WINDOW POWER SUPPLY(YEARF)
28	G	DOWNWARD			
29	LG	UPWARD			
30	B	LEFT/FORWARD			
31	BR	MIR SENS UP(DOWN)(RH)			
32	LG	MIR SENS UP(DOWN)(LH)			
33	B	FORWARD			
34	Y	SELECT RH			
35	LG	UPWARD			
36	V	LEFT/FORWARD			
37	GR	MIR SENS UP(DOWN)LH			
38	Y	RX/TX			
39	W	MIR MTR UP(RH)			
40	W	MIR MTR LEFT(RH)			
41	G	MIR MTR DOWN RIGHT(LH)			
42	Y	MIR MTR DOWN RIGHT(LH)			



Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name
1	W	BAT (F.L.)	4	W	PASSANGER DOOR ANTI-
2	W	POWER WINDOW POWER SUPPLY(YEARF)	5	BR	DRIVER DOOR ANTI-
3	Y	POWER WINDOW POWER SUPPLY(YEARF)	7	LG	PASSANGER DOOR ANTI-
			76	V	DRIVER DOOR ANTI-
			77	LG	DRIVER DOOR ANTI-
			78	Y	ROOM ANTI-
			79	BR	ROOM ANTI+
			80	GR	NATS ANTI AMP



# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER			
31	W	SHIFT N/P NATS AND AMP.	34 V
32	R	IGN RELAY/F/B CONT	35 G
33	Y	KEYLESS ENTRY RECEIVER COMM	36 -
37	BR	COMBI SW INPUT1	37 BR
38	V	COMBI SW INPUT2	38 -
39	P	COMBI SW INPUT3	39 R
91	L	CAN-L	-
92	LG	KEY SLOT/L CONT	140 GR
93	V	ON IND	141 G
94	Y	PUDDLE LAMP CONT	142 BG
95	BG	ACC RELAY CONT	143 P
96	GR	A/T SHIFT SELECTOR POWER SUPPLY	144 G
99	R	SHEET P.	145 L
100	G	PASSENGER DOOR REQUEST SW	146 SB
101	SB	DRIVER DOOR REQUEST SW	150 LG
102	BG	BL DOME FAN MOTOR RELAY CONT	151 G
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY	152 -
107	LG	COMBI SW INPUT1	153 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
108	R	COMBI SW INPUT4	154 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
109	Y	COMBI SW INPUT2	155 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
110	G	HAZARD SW	156 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
Connector No. M123		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	BCM (BODY CONTROL MODULE)	7 Y	-
Connector Type	TH40FG-HH	8 LG	-
Connector No. M124		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	9 Y	-
Connector Type	MSMFN-LC	10 W	-
Connector No. M125		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	11 R	-
Connector Type	MSMFN-LC	12 L	-
Connector No. M126		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	13 V	-
Connector Type	MSMFN-LC	14 B	-
Connector No. M151		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	AV CONTROL UNIT	15 W	-
Connector Type	TH3FV-HH	16 BR	-
Connector No. M152		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	17 S	-
Connector Type	MSMFN-LC	18 R	-
Connector No. M153		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	AV CONTROL UNIT	19 B	[Without BOSE audio]
Connector Type	TH3FV-HH	20 W	-
Connector No. M154		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	21 Y	(With BOSE audio)
Connector Type	MSMFN-LC	22 G	- (With BOSE audio)
Connector No. M155		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	23 L	- (Without BOSE audio)
Connector Type	MSMFN-LC	24 GR	-
Connector No. M156		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	25 Y	-
Connector Type	MSMFN-LC	26 R	-
Connector No. M157		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	27 W	-
Connector Type	MSMFN-LC	28 LG	-
Connector No. M158		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	29 BR	-
Connector Type	MSMFN-LC	30 G	-
Connector No. M159		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	31 LG	-
Connector Type	MSMFN-LC	32 G	-
Connector No. M160		Terminal Color Of Wire Signal Name [Specification]	
Connector Name	WIRE TO WIRE	33 BR	-
Connector Type	MSMFN-LC	34 BR	-

ADP

Z

M

K

—

G

T

D

A

P

O

N

—

—

—

—

—

—

—

—

# DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		H.S.		AUTOMATIC DRIVE POSITIONER		H.S.	
12	R	SIGNAL	SIGNAL	57	SIGNAL	SIGNAL	SIGNAL
13	R	MICROPHONE VCC	SIGNAL	58	SIGNAL	SIGNAL	SIGNAL
14	P	CAMERA POWER SUPPLY	SIGNAL	59	SIGNAL	SIGNAL	SIGNAL
15	LG	CAN-L	SIGNAL	60	SIGNAL	SIGNAL	SIGNAL
16	LG	AV COMM(L)	SIGNAL	61	SIGNAL	SIGNAL	SIGNAL
19	R	ILLUMINATION	SIGNAL	62	SIGNAL	SIGNAL	SIGNAL
30	BG	IGNITION SIGNAL	SIGNAL	63	SIGNAL	SIGNAL	SIGNAL
31	BG	REVERSE SIGNAL	SIGNAL	64	SIGNAL	SIGNAL	SIGNAL
32	R	VEHICLE SPEED SIGNAL (8-PULSE)	SIGNAL	65	SIGNAL	SIGNAL	SIGNAL
33	SIGNAL	SIGNAL	SIGNAL	66	SIGNAL	SIGNAL	SIGNAL
37	G	SIGNAL	SIGNAL	67	SIGNAL	SIGNAL	SIGNAL
38	SIGNAL	SIGNAL	SIGNAL	68	SIGNAL	SIGNAL	SIGNAL
39	G	COMM(DISP>>CONT)	SIGNAL	69	SIGNAL	SIGNAL	SIGNAL
90	L	CAN-H	SIGNAL	70	SIGNAL	SIGNAL	SIGNAL
91	SB	AV COMM(H)	SIGNAL	71	SIGNAL	SIGNAL	SIGNAL
92	SB	AV COMM(H)	SIGNAL	72	SIGNAL	SIGNAL	SIGNAL
AUTOMATIC DRIVE POSITIONER		H.S.		AUTOMATIC DRIVE POSITIONER		H.S.	
Terminal No.	Color Of Wire	Signal Name [Specification]		Terminal No.	Color Of Wire	Signal Name [Specification]	
76	LG	AV COMM(L)		76	LG	AV COMM(L)	
77	SB	AV COMM(H)		77	SB	AV COMM(H)	
78	LG	AV COMM(L)		78	LG	AV COMM(H)	
79	SB	AV COMM(H)		79	SB	AV COMM(H)	
80	P	CAN-L		80	L	CAN-H	
81	B	SIGNAL		81	B	SIGNAL	
82	B	SIGNAL		82	B	SIGNAL	
86	SIGNAL	SW GND		86	SIGNAL	SW GND	
87	L	TELEPHONE SIGNAL (+)		87	L	TELEPHONE SIGNAL (-)	
88	P	TELEPHONE SIGNAL (-)		88	P	TELEPHONE SIGNAL (+)	
92	R	VEHICLE SPEED SIGNAL (8-PULSE)		92	R	VEHICLE SPEED SIGNAL (8-PULSE)	
93	V	PARKING BRAKE SIGNAL		93	V	PARKING BRAKE SIGNAL	
94	BG	REVERSE SIGNAL		94	BG	REVERSE SIGNAL	
95	G	IGNITION SIGNAL		95	G	IGNITION SIGNAL	
96	Y	DISK EJECT SIGNAL		96	Y	DISK EJECT SIGNAL	

JRJWC5659GB

INFOID:0000000010596466

## Fail Safe

The fail-safe mode may be activated if the following symptoms are observed.

# DRIVER SEAT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Operating in fail-safe mode	Malfunction Item	Related DTC	Diagnosis
Only manual functions operate normally.	CAN communication	U1000	<a href="#">ADP-46</a>
	CONTROL UNIT (CAN)	U1010	<a href="#">ADP-47</a>
	EEPROM	B2130	<a href="#">ADP-55</a>
Only manual functions, except door mirror, operate normally.	UART communication	B2128	<a href="#">ADP-54</a>
Only manual functions, except seat sliding, operate normally.	Seat sliding output	B2112	<a href="#">ADP-48</a>
Only manual functions, except seat reclining, operate normally.	Seat reclining output	B2113	<a href="#">ADP-50</a>
Only manual functions, except steering tilt, operate normally.	Steering column tilt output	B2116	<a href="#">ADP-55</a>

## DTC Index

INFOID:0000000010596467

CONSULT display	Timing <sup>*1</sup>		Item	Reference page
	Current malfunction	Previous malfunction		
CAN COMM CIRCUIT [U1000]	0	1-39	CAN communication	<a href="#">ADP-46</a>
CONTROL UNIT (CAN) [U1010]	0	1-39	Control unit	<a href="#">ADP-47</a>
SEAT SLIDE [B2112]	0	1-39	Seat slide motor output	<a href="#">ADP-48</a>
SEAT RECLINING [B2113]	0	1-39	Seat reclining motor output	<a href="#">ADP-50</a>
STEERING TILT [B2116]	0	1-39	Tilt motor output	<a href="#">ADP-52</a>
UART COMM [B2128]	0	1-39	UART communication	<a href="#">ADP-54</a>
EEPROM [B2130]	0	1-39	EEPROM	<a href="#">ADP-55</a>

\*1:

- 0: Current malfunction is present
- 1-39: Displayed if any previous malfunction is present when current condition is normal. The numeral value increases by one at each IGN ON to OFF cycle from 1 to 39. The counter remains at 39 even if the number of cycles exceeds it. However, the counter is reset to 1 if any malfunction is detected again, the normal operation is resumed and the ignition switch is turned from OFF to ON.

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

## AUTOMATIC DRIVE POSITIONER CONTROL UNIT

### Reference Value

INFOID:0000000010596468

### TERMINAL LAYOUT



### PHYSICAL VALUES

Terminal No. (wire color)		Description		Condition		Voltage
+	-	Signal name	Input/ Output			Voltage
1 (Y)	Ground	Tilt switch up signal	Input	Tilt switch	Operate (up)	0 - 1 V
					Other than the above	4 - 6 V
2 (LG)	Ground	Changeover switch RH signal	Input	Changeover switch position	RH	0 - 1 V
					Neutral or LH	4 - 6 V
3 (G)	Ground	Mirror switch up signal	Input	Mirror switch	Operate (up)	0 - 1 V
					Other than the above	4 - 6 V
4 (V)	Ground	Mirror switch left signal	Input	Mirror switch	Operate (left)	0 - 1 V
					Other than the above	4 - 6 V
5 (R)	Ground	Door mirror sensor (pas- senger side) up/down sig- nal	Input	Door mirror RH position		Change between 3.4 (close to peak) 0.6 (close to valley)
6 (GR)	Ground	Door mirror sensor (driver side) up/down signal	Input	Door mirror LH position		Change between 3.4 (close to peak) 0.6 (close to valley)
7 (GR)	Ground	Telescopic switch forward signal	Input	Telescopic switch	Operate (forward)	0 - 1 V
					Other than the above	4 - 6 V
8 (Y)	Ground	UART communication (TX/RX)	Input/ Output	Ignition switch ON		<p>5V/div      10msec/div</p> <p>JMJIA1391ZZ</p>

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (wire color)		Description		Condition		Voltage	A B C D E F G H I ADP K L M N O P
+	-	Signal name	Input/ Output				
10 (W)	Ground	Door mirror motor (passenger side) up/right output signal	Output	Door mirror RH	Operate (up/right)	9 - 16 V	A B C
					Other than the above	0 - 1 V	D E
11 (G)	Ground	Door mirror motor (passenger side) down/left output signal	Output	Door mirror RH	Operate (down/left)	9 - 16 V	F G
					Other than the above	0 - 1 V	H I
12 (Y)	Ground	Door mirror motor (driver side) down/right output signal	Output	Door mirror (LH)	Operate (down/right)	9 - 16 V	J
					Other than the above	0 - 1 V	K
13 (W)	Ground	Tilt switch down signal	Input	Tilt switch	Operate (down)	0 - 1 V	L
					Other than the above	4 - 6 V	M
14 (P)	Ground	Changeover switch LH signal	Input	Changeover switch position	LH	0 - 1 V	N
					Neutral or RH	4 - 6 V	O
15 (SB)	Ground	Mirror switch down signal	Input	Mirror switch	Operate (down)	0 - 1 V	P
					Other than the above	4 - 6 V	Q
16 (BR)	Ground	Mirror switch right signal	Input	Mirror switch	Operate (right)	0 - 1 V	R
					Other than the above	4 - 6 V	S
17 (L)	Ground	Door mirror sensor (passenger side) left/right signal	Input	Door mirror RH position		Change between 3.4 (close to left edge) 0.6 (close to right edge)	T
18 (G)	Ground	Door mirror sensor (driver side) left/right signal	Input	Door mirror LH position		Change between 0.6 (close to left edge) 3.4 (close to right edge)	U
19 (G)	Ground	Telescopic switch backward signal	Input	Telescopic switch	Operate (backward)	0 - 1 V	V
					Other than the above	4 - 6 V	W
20 (Y)	Ground	Ground (sensor)	—	—		0 - 1 V	X
21 (R)	Ground	Door mirror motor sensor power supply	Output	—		4 - 6 V	Y
22 (R)	Ground	Door mirror motor (passenger side) down/right output signal	Output	Door mirror (RH)	Operate (down/right)	9 - 16 V	Z
					Other than the above	0 - 1 V	A
23 (LG)	Ground	Door mirror motor (driver side) up/right output signal	Output	Door mirror (LH)	Operate (up/right)	9 - 16 V	B
					Other than the above	0 - 1 V	C

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (wire color)		Description		Condition		Voltage	
+	-	Signal name	Input/ Output			Voltage	
24 (L)	Ground	Door mirror motor (driver side) down/left output signal	Output	Door mirror (LH)	Operate (down/left)	9 - 16 V	
					Other than the above	0 - 1 V	
25 (SB)	Ground	Battery power supply	Input	—		9 - 16 V	
26 (L)	Ground	Telescopic motor backward output signal	Output	Steering telescopic	Operate (backward)	9 - 16 V	
					Other than the above	0 - 1 V	
27 (P)	Ground	Tilt & telescopic sensor power supply	Output	—		9 - 16 V	
28 (G)	Ground	Tilt motor down output signal	Output	Steering tilt	Operate (down)	9 - 16 V	
					Other than the above	0 - 1 V	
29 (LG)	Ground	Tilt motor up output signal	Output	Steering tilt	Operate (up)	9 - 16 V	
					Other than the above	0 - 1 V	
		Telescopic motor forward output signal		Steering telescopic	Operate (forward)	9 - 16 V	
					Other than the above	0 - 1 V	
30 (B)	Ground	Ground (power)	—	—		0 - 1 V	

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - AUTOMATIC DRIVE POSITIONER CONTROL SYSTEM -


INFOID:000000010596469



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >



JRJWC5606GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >



JRJWC5607GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



JRJWC5608GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## AUTOMATIC DRIVE POSITIONER

Connector No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]
B1	WIRE TO WIRE	3	R	1	LG
	CONNECTOR NAME: T11BPFV-CS16-TM4	5	G	2	SB
	CONNECTOR TYPE: T11B2DW-NM1	6	SB	3	Y
		8	L	4	R
		11	V	5	BR
		12	SB	7	R
		13	LG	8	P
		14	GR	9	GR
		15	LG	10	BR
		16	R	11	BR
		17	W	12	BR
		18	SB	13	BR
		19	LG	14	BR
		20	BR	15	BR
		21	SHEILD	16	BR
		22	Y	17	Y
		24	P	18	Y
		27	B	19	Y
		28	R	20	Y
		29	W	21	Y
		30	SHEILD	22	Y
		31	SHEILD	23	Y
		32	W	24	Y
		33	SB	25	Y
		34	L	26	Y
		35	P	27	Y
		36	L	28	Y
		37	P	29	Y
		38	P	30	Y
		39	Y	31	Y
		40	SB		
		44	Y		
		45	GR		
		46	LG		

Connector No.	Signal Name [Specification]	Connector No.	Signal Name [Specification]
B11	-	B11	-
	WIRE TO WIRE		WIRE TO WIRE
	CONNECTOR NAME: NS11FV-CS16		CONNECTOR NAME: NS11FV-CS16



Connector No.	Signal Name [Specification]	Connector No.	Signal Name [Specification]
SE	-	1	1
EC	-	2	2
R	-	3	3
L	-	4	4
P	-	5	5
L	-	6	6
		7	7
		8	8
		9	9
		10	10
		11	11
		12	12
		13	13
		14	14
		15	15
		16	16
		17	17
		18	18
		19	19
		20	20
		21	21
		22	22
		23	23
		24	24
		25	25
		26	26
		27	27
		28	28
		29	29
		30	30
		31	31
		32	32
		33	33
		34	34
		35	35
		36	36
		37	37
		38	38
		39	39
		40	40
		44	44
		45	45
		46	46



Connector No.	Signal Name [Specification]	Connector No.	Signal Name [Specification]
B11	-	B11	-
	WIRE TO WIRE		WIRE TO WIRE
	CONNECTOR NAME: NS11FV-CS16		CONNECTOR NAME: NS11FV-CS16
	CONNECTOR TYPE: T11B2DW-NM1		CONNECTOR TYPE: T11B2DW-NM1



Terminal No.	Color Of Wire	Terminal No.	Color Of Wire
1	LG	1	LG
2	SB	2	SB
3	Y	3	Y
4	R	4	R
5	BR	5	BR
6	G	6	G
7	LG	7	LG
8	B	8	B
9	BR	9	BR
10	BR	10	BR
11	BR	11	BR
12	BR	12	BR
13	BR	13	BR
14	BR	14	SB
15	GR	15	GR
16	LG	16	P
17	LG	17	G
18	BR	18	B
19	BR	19	BR
20	BR	20	BR
21	SHEILD	21	SHEILD
22	Y	22	Y
23	Y	23	Y
24	P	24	Y
27	B	27	W
28	R	28	R
29	Y	29	Y
30	W	30	Y
31	SHEILD	31	Y

Connector No.	Signal Name [Specification]	Connector No.	Signal Name [Specification]
B16	-	B16	-
	FRONT DOOR SWITCH (DRIVER SIDE)		FRONT DOOR SWITCH (DRIVER SIDE)
	CONNECTOR NAME: AGFW		CONNECTOR NAME: AGFW
	CONNECTOR TYPE: T11B2DW-NM1		CONNECTOR TYPE: T11B2DW-NM1

Terminal No.	Color Of Wire	Terminal No.	Color Of Wire
1	Y	1	Y
2	V	2	V



ADP

JRJWC5650GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## AUTOMATIC DRIVE POSITIONER

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND	1	CAN-H	UART (TX/RX)	33	-	BA1 (PTC)
2	Y	BATTERY	2	-	FUSE (RECLINER)	34	-	SIDE MOTOR (BACKWARD)
3	P	IGNITION SIGNAL	4	-	PULSE (TELESCOPIC)	35	O	RECLINER MOTOR (FORWARD)
4	GR	ACC	5	-	ADDRESS 2	36	-	FRONT LIFTER MOTOR (FORWARD)
5	EG	ILLUMINATION SIGNAL	6	-	IND 2	39	-	SIDE MOTOR (FORWARD)
6	SB	VEHICLE SPEED SIGNAL (3-POLSE)	7	-	SIDE SW (BACKWARD)	39	-	RECLINER MOTOR (BACKWARD)
7	V	REVERSE SIGNAL	8	-	RECLINER SW (BACKWARD)	40	-	FRON LIFTER MOTOR (UPWARD)
9	Y	CONTROL SIGNAL	9	-	FRONT LIFTER SW (DOWNWARD)	41	-	REAR LIFTER MOTOR (UPWARD)
13	B	CONTROL SIGNAL	10	-	FRONT LIFTER SW (DOWNWARD)	42	-	REAR LIFTER MOTOR (DOWNWARD)
17	SB	AV COMM (H)	11	-	POWER SUPPLY (INCODER)	43	-	GND
18	LG	AV COMM (L)	12	-	CAN-L			
21	SB	AV COMM (H)	17	-	PULSE (SIDE)			
22	LG	AV COMM (L)	18	-	PULSE (FRONT LIFTER)			
23	LG	-	19	-	PULSE (REAR LIFTER)			
24	G	-	20	-	PULSE (FRONT LIFTER)			
27	W	CAMERA IMAGE SIGNAL	21	-	PULSE (LIFT)			
28	SHIELD	CAMERA IMAGE SIGNAL GND	22	-	ADDRESS 1			
29	Y	SIDE CAMERA RH IMAGE SIGNAL	23	-	IND 1			
30	G	SIDE CAMERA RH IMAGE GND	24	-	SIDE SW (FORWARD)			
31	SHIELD	SHIELD	25	-	RECLINER SW (FORWARD)			
32	B	SIDE CAMERA RH GND	26	-	FRONT LIFTER SW (UPWARD)			
33	W	SIDE CAMERA RH GND	27	-	REAR LIFTER SW (UPWARD)			
34	R	SIDE CAMERA RH POWER SUPPLY	28	-	SET SW			
35	L	REAR CAMERA COMM						
36	BR	REAR CAMERA POWER SUPPLY						
37	SHIELD	SHIELD						
38	R	REAR CAMERA GND						
39	Y	REAR CAMERA IMAGE SIGNAL						
40	W	REAR CAMERA IMAGE GND						

JRJWC5651GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		
Connector No.	Connector Name	Connector Type
B456	LIFTING MOTOR (REAR)	NSD0FBR-CS
Connector No.	Connector Name	Connector Type
B460	WIRE TO WIRE	TH16FW-CSS
Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
12 O	-	1 R
20 P/B	R/Y	2 B
41 R/B	-	3 Y
42 L/T	-	4 W
43 GR	-	5 L
		6 O
		7 GR
		8 W
		9 O
		10 BR
		11 P
		12 LG
		13 B
		14 Y
		15 W
		16 R
		17 W
		18 G
		19 W
		20 BR
		21 O
		22 P
		23 BR
		24 LG
		25 Y
		26 R/G
		27 W/B
		28 P/L
		29 B/W
		30 G
		31 W
		32 G
		33 L
		34 SB
		35 R
		36 LG
		37 R
		38 P
		39 O
		40 BR
		41 L
		42 GR
		43 BR
		44 O
		45 GR
		46 W
		47 G
		48 G
		49 GD
		50 SHIELD
		52 R
		53 SB
		54 O
		55 Y

POWER SEAT SWITCH		
Connector No.	Connector Name	Connector Type
B459	NSDHFY-CS	
Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
23 -	-	1 R
28 -	-	2 B
32 B/W	-	3 Y
33 R	-	4 W
43 -	-	5 L
60 Y/R	-	6 O
66 B	-	7 GR
67 L	-	8 W
		9 O
		10 BR
		11 P
		12 LG
		13 B
		14 Y
		15 W
		16 R
		17 W
		18 G
		19 W
		20 BR
		21 O
		22 P
		23 BR
		24 V
		25 GR
		26 Y
		27 B
		28 SHIELD
		29 LG
		30 G
		31 W
		32 G
		33 L
		34 SB
		35 R
		36 LG
		37 R
		38 P

SLIDING MOTOR		
Connector No.	Connector Name	Connector Type
B461	6096-0239	
Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
8 BR	-	1 V
9 SB	-	2 GR
10 L/G/R	-	3 Y
11 G/B	-	4 B
24 Y	-	5 Y
25 R/G	-	6 R
26 W/B	-	7 SHIELD
27 P/L	-	8 LG
43 B/W	-	9 W
		10 G
		11 P
		12 O
		14 LG
		17 G
		18 W
		19 B

DOOR MIRROR (DRIVER SIDE)		
Connector No.	Connector Name	Connector Type
D3	DOOR MIRROR (DRIVER SIDE)	TH24MMH-NH
Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
121	110	1 R
123	221	2 G
242	187	3 B
243	187	4 W
		5 2
		6 3
		7 5
		8 6
		9 7
		10 14

SIDE CAMERA LH IMAGE SIGNAL		
Connector No.	Connector Name	Connector Type
HS		
Terminal Color Of Wire	Signal Name [Specification]	Signal Name [Specification]
34 B	38	1 Color Off
35 W/B	-	2 Wire
36 W/B	-	3 O
		4 B
		5 Y
		6 R
		7 W
		8 G
		9 P
		10 G
		12 O
		14 LG
		17 G
		18 W
		19 B

ADP

O

Z

P

K

A B C D E F G H I J

JRJWC5652GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		Connector No.		Connector Name		Connector Type	
21	GR	13	W	-		46	W
22	BR	15	Y	-		47	SHEILD
23	Y	-				52	G
24	V	-				53	GR
						54	O
						55	L
Connector No.		D51		WIRE TO WIRE		Signal Name [Specification]	
Connector Name		TH40FW-CS1.5		DOOR MIRROR (PASSENGER SIDE)		Terminal No.	
Connector Type		TH40FW-NH1		[2][1][10] 7 6 5 4 3		Color Of Wire	
Connector No.		D33		[24][3][22] 19[8][17] 16		-	
Connector Name		HS.		Signal Name [Specification]		-	
Connector Type		HS.		SIDECAMERA RH COMM.		Terminal No.	
Connector No.		D17		SIDECAMERA RH IMAGE SIGNAL		Color Of Wire	
Connector Name		DOOR MIRROR CONTROL SWITCH		[1][2][3] 9 8 7 6 5 4 3 2 1		-	
Connector Type		TKIFER		SIDECAMERA RH POWER SUPPLY		-	
Connector No.		D17		[14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector Name		HS.		[13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector Type		HS.		[15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector No.		D17		[16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector Name		HS.		[17][16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector Type		HS.		[18][17][16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector No.		D17		[19][18][17][16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector Name		HS.		[20][19][18][17][16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector Type		HS.		[21][20][19][18][17][16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector No.		D17		[22][21][20][19][18][17][16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector Name		HS.		[23][22][21][20][19][18][17][16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	
Connector Type		HS.		[24][23][22][21][20][19][18][17][16][15][14][13][12][11][10][9][8][7][6][5][4][3][2][1]		-	

JRJWC5653GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		Signal Name [Specification]		Signal Name [Specification]		Signal Name [Specification]		Signal Name [Specification]	
43	BR	-	-	5	-	GROUND	-	5	W
45	W	-	-	6	-	IGNITION POWER SUPPLY	-	6	G
49	L	-	-	7	-	BACK-UP LAMP RELAY	-	7	LG
50	P	-	-	8	-	CAN-L	-	8	B
51	L	-	-	9	-	STARTER RELAY	-	14	V
54	BG	-	-	10	-	GROUND	-	15	V
57	BR	-	-					16	W
59	W	-	-					21	G
60	LG	-	-					22	B
61	G	-	-					23	SHIELD
62	SB	-	-					24	R
63	W	-	-					25	R
64	B	-	-					26	Y
65	G	-	-					27	G
66	R	-	-					28	B
67	SHEILD	-	-					29	W
68	Y	-	-					30	SHIELD
69	LG	-	-					31	Y
70	W	-	-						
71	R	-	-						
72	Y	-	-						
73	B	-	-						
74	BR	-	-						
74	L	-	-						
75	G	-	-						
75	W	-	-						
76	W	-	-						
76	Y	-	-						
77	P	-	-						
77	R	-	-						
78	BR	-	-						
78	L	-	-						
79	LG	-	-						
79	Y	-	-						
80	SB	-	-						
81	R	-	-						
82	SB	-	-						
83	BG	-	-						
84	G	-	-						
85	L	-	-						
86	P	-	-						
87	V	-	-						
89	GR	-	-						
90	SHEILD	-	-						
91	W	-	-						
92	Y	-	-						
93	V	-	-						
94	LG	-	-						
95	BG	-	-						
96	P	-	-						

JRJWC5654GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		
Connector No.	MS	SIGNAL
17	B	-
18	G	-
19	Y	-
20	L	-
21	LG	-
22	L	-
23	G	-
24	Y	-
25	GR	-
26	R	-
27	W	-
28	SHIELD	-
29	Y	-
30	Y	-
31	R	-
32	BR	-
33	SB	-
34	Y	-
35	P	-
36	LG	-
37	BR	-
38	P	-
39	BG	-
40	SB	-
41	L	-
42	R	-
43	BR	-
44	V	-
45	G	-
46	SB	- [With automatic drive positioner] - [Without automatic drive positioner]
47	Y	-
48	R	-
49	G	-
50	SHIELD	-
52	R	-
53	V	-
54	LG	-
55	SB	-
13	G	-
14	R	-
15	P	-
16	V	-
17	SB	-
18	Y	-
19	BR	-
20	BG	-
21	L	-
22	W	-
23	P	-
24	BR	-
25	Y	-
26	V	-
27	G	-
28	G	-
31	L	-
32	G	-
33	B	-
34	W	-
35	R	-
36	SHIELD	-
37	V	-
38	BR	-
39	BR	-
41	W	-
42	BG	-
43	BG	-
45	W	-
49	L	-
50	P	-
51	BR	-
54	Y	-
57	G	-
59	W	-
60	L	-
61	G	-
62	SB	-
63	G	-
64	B	-
65	W	-
66	R	-
67	SHIELD	-
68	Y	-
69	OR	-
70	LG	-
71	LG	-
72	Y	-
73	SB	-
74	BR	-
74	L	- [With CC]
75	G	-
76	GR	- [Without CC]
76	W	- [Without CC]
77	P	- [Without CC]
77	R	- [Without CC]
78	L	- [With CC]
78	R	- [Without CC]
79	W	- [Without CC]
79	Y	- [With CC]
80	SB	-
81	SB	-
82	SB	-
83	Y	-
84	G	-
85	L	-
86	P	-
87	W	-
89	GR	-
90	SHIELD	-
91	W	-
92	Y	-
93	BR	-
94	P	-
95	GR	-
96	W	-
97	L	-
32	P	-
33	SB	-
34	L	-
35	P	-
36	W	-
37	L	-
38	W	-
39	R	-
40	P	-
41	P	-
42	P	-
43	P	-
44	P	-
45	P	-
46	P	-
47	P	-
48	P	-
49	P	-
50	P	-
51	P	-
52	P	-
53	P	-
54	P	-
55	P	-
56	P	-
57	P	-
58	P	-
59	P	-
60	P	-
61	P	-
62	P	-
63	P	-
64	P	-
65	P	-
66	P	-
67	P	-
68	P	-
69	P	-
70	P	-
71	P	-
72	P	-
73	P	-
74	P	-
75	P	-
76	P	-
77	P	-
78	P	-
79	P	-
80	P	-
81	P	-
82	P	-
83	P	-
84	P	-
85	P	-
86	P	-
87	P	-
88	P	-
89	P	-
90	P	-
91	P	-
92	P	-
93	P	-
94	P	-
95	P	-
96	P	-
97	P	-

JRJWC5655GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

**< ECU DIAGNOSIS INFORMATION >**

AUTOMATIC DRIVE POSITIONER		
39	Y	
40	SB	
44	L	
45	GR	
46	LG	
47	SB	
48	BG	
49	R	
50	L	
60	P	
61	L	
62	SHIELD	
63	R	
64	G	
65	SHELD	
66	SB	
67	V	
68	LG	
69	SHELD	
70	W	
73	G	
74	R	
75	W	
76	W	
77	B	
78	P	
79	GR	
33	BG	
35	LG	
98	R	
87	Y	
98	W	
99	BR	
91	EG	
92	V	
93	BR	
94	V	
95	G	
96	Y	
98	W	
99	R	
14	P	
16	Y	

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	BAT	1	B	ACC POWER SUPPLY
2	GR	CLOCK	2	GR	FUEL LEVEL SENSOR SIGNAL
3	W	DATA	3	G	INTAKE AIR TEMP SENSOR SIGNAL
5	V	ILL BAT	4	Y	IN VEHICLE SENSOR SIGNAL
6	LG	ILL	5	W	AMBIENT SENSOR SIGNAL
7	LG	GROUND	7		SUNLOAD SENSOR SIGNAL
11	B	KEY SWITCH SIGNAL	11		EXHAUST GAS CONCENTRATION SENSOR SIGNAL

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1		CIRCUIT BREAKER	1		IGNITION POWER SUPPLY
2			2		BATTERY POWER SUPPLY
55	B	GROUND	55	Y	GROUND
56	L	CAN-H	56	B	CAN-L
57	W	BRAKE FLUID LEVEL SWITCH SIGNAL	57	W	FUEL LEVEL SENSOR SIGNAL
58	BR	FUEL LEVEL SENSOR GROUND	58	BR	INTAKE AIR TEMP SIGNAL
59	GR	INTAKE AIR TEMP GROUND	59	GR	IN VEHICLE SENSOR GROUND
60	L	IN VEHICLE SENSOR GROUND	60	L	AMBIENT SENSOR GROUND
61	BR	AMBIENT SENSOR GROUND	61	BR	SUNLOAD SENSOR GROUND
62	SB	SUNLOAD SENSOR GROUND	62	SB	-
63	R	-	63	R	ECV SIGNAL
65	BG	-	65	BG	A/C CAN SIGNAL
69	L	-	69	L	EACH DOOR MOTOR POWER SUPPLY
70	R	-	70	R	GROUND
71	B	-	71	B	CAN-L
72	P	-	72	P	CAN-H

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-	1	W	-
2	SB	-	2	SB	-

JRWJC5656GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
JRJWC5656GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## AUTOMATIC DRIVE POSITIONER

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND	1	V	INTERIOR FROM LAMP POWER SUPPLY
3	V	ACC	2	P	PASSENGER DOOR UNLOCK OUTPUT
4	R	ILL. CONN.	3	LG	STEP LAMP CONST.
5	Y	AV COMM (R)	4	LG	ALL DOOR FUEL INDOOR COCK OUTPUT
6	SB	AV COMM (L)	5	R	DRIVE DOOR FUEL INDOOR COCK OUTPUT
8	LG	SW GND	6	P	REAR DOOR UNLOCK OUTPUT
9	B	DISK EJECT SIGNAL	7	G	BAT FUSE
14	Y	HAZARD ON	8	Y	GROUND
16	G		9	BR	PUSH-BUTTON IGNITION SW. (ILL. GRID)
			10	L	ACC IND.
					17 W TURN SIGNAL RH (FRONT)
					18 BG TURN SIGNAL LH (FRONT)
					19 V INT ROOM LAMP CONST.

Connector No.	Connector Name	Connector Type	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
M72	MULTIFUNCTION SWITCH	TH1HFV-NH	13	W	DOWNWARD	4	LG	INTERIOR FROM LAMP POWER SUPPLY
			14	P	SELECT LH	5	L	PASSENGER DOOR UNLOCK OUTPUT
			15	SE	DOWNWARD	7	Y	STEP LAMP CONST.
			16	DR	RIGHTWARD	8	V	ALL DOOR FUEL INDOOR COCK OUTPUT
			17	L	MIR. SENS. LEFT/RIGHT (RH)	9	G	DRIVE DOOR FUEL INDOOR COCK OUTPUT
			18	G	MIR. SENS. LEFT/RIGHT (LH)	10	BR	REAR DOOR UNLOCK OUTPUT
			19	G	BACKWARD	11	R	BAT FUSE
			20	Y	SENS. GRID	13	B	GROUND
			21	R	POWER SUPPLY (SENSOR)	14	W	PUSH-BUTTON IGNITION SW. (ILL. GRID)
			22	R	MIR. MTR. DOWN (RIGHT/RH)	15	Y	TURN SIGNAL RH (FRONT)
			23	LG	MIR. MTR. UP (LH)	17	W	TURN SIGNAL LH (FRONT)
			24	L	MIR. MTR. LEFT (LH)	18	BG	

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND	1	V	INTERIOR FROM LAMP POWER SUPPLY
3	V	ACC	2	P	PASSENGER DOOR UNLOCK OUTPUT
4	R	ILL. CONN.	3	LG	STEP LAMP CONST.
5	Y	AV COMM (R)	4	LG	ALL DOOR FUEL INDOOR COCK OUTPUT
6	SB	AV COMM (L)	5	R	DRIVE DOOR FUEL INDOOR COCK OUTPUT
8	LG	SW GND	6	P	REAR DOOR UNLOCK OUTPUT
9	B	DISK EJECT SIGNAL	7	G	BAT FUSE
14	Y	HAZARD ON	8	Y	GROUND
16	G		9	BR	PUSH-BUTTON IGNITION SW. (ILL. GRID)
			10	L	ACC IND.
					17 W TURN SIGNAL RH (FRONT)
					18 BG TURN SIGNAL LH (FRONT)
					19 V INT ROOM LAMP CONST.

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND	1	V	INTERIOR FROM LAMP POWER SUPPLY
3	V	ACC	2	P	PASSENGER DOOR UNLOCK OUTPUT
4	R	ILL. CONN.	3	LG	STEP LAMP CONST.
5	Y	AV COMM (R)	4	LG	ALL DOOR FUEL INDOOR COCK OUTPUT
6	SB	AV COMM (L)	5	R	DRIVE DOOR FUEL INDOOR COCK OUTPUT
8	LG	SW GND	6	P	REAR DOOR UNLOCK OUTPUT
9	B	DISK EJECT SIGNAL	7	G	BAT FUSE
14	Y	HAZARD ON	8	Y	GROUND
16	G		9	BR	PUSH-BUTTON IGNITION SW. (ILL. GRID)
			10	L	ACC IND.
					17 W TURN SIGNAL RH (FRONT)
					18 BG TURN SIGNAL LH (FRONT)
					19 V INT ROOM LAMP CONST.

JRJWC5657GB

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER		Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
31	W	SHFT N/P NATS AND AMP	34	V	-
32	R	IGN RELAY/F/B CONT	35	G	-
33	Y	KEYLESS ENTRY RECEIVER COMM	36	Y	-
37	BR	COMBI SW INPUT 5	37	Y	-
38	V	COMBI SW INPUT 1	43	L	-
39	P	COMBI SW INPUT 3	44	Y	-
91	L	CAN-L	45	R	-
92	LG	KEY SLOT/L CONT	146	SB	-
93	V	ON IND	150	LG	DRIVER DOOR SW
94	Y	PUDDLE LAMP CONT	151	G	REAR WINDOW DEFOGGER RELAY CONT
95	BG	ACC RELAY CONT	152	Y	-
96	GR	A/T SHIFT SELECTION POWER SUPPLY	153	G	-
99	R	SHEET P.	154	W	-
100	G	PASSENGER DOOR REQUEST SW	155	BG	-
101	SB	DRIVER DOOR REQUEST SW			
102	BG	BL DOME FAN MOTOR RELAY CONT			
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY			
107	LG	COMBI SW INPUT 1			
108	R	COMBI SW INPUT 4			
109	Y	COMBI SW INPUT 2			
110	G	HAZARD SW			
Connector No. M123		Signal Name [Specification]	7	Y	-
Connector Name BCM (BODY CONTROL MODULE)			8	LG	-
Connector Type TH4HFG-HH			9	Y	-
Connector No. M124		Signal Name [Specification]	12	L	-
Connector Name A/T SHIFT SELECTION POWER SUPPLY			13	Y	-
Connector Type TH4HFN-LC			14	W	-
Connector No. M125		Signal Name [Specification]	15	W	-
Connector Name WIRE TO WIRE			16	BR	-
Connector Type M05MF-LC			17	S	-
Connector No. M126		Signal Name [Specification]	19	R	-
Connector Name AV CONTROL UNIT			20	W	[Without BOSE audio]
Connector Type TH4HFN-LC			21	Y	- (With BOSE audio)
Connector No. M151		Signal Name [Specification]	21	G	- (With BOSE audio)
Connector Name AV CONTROL UNIT			22	BR	- (Without BOSE audio)
Connector Type TH4HFG-HH			23	GR	-
Connector No. M152		Signal Name [Specification]	24	G	-
Connector Name H.S.			25	Y	-
Connector Type M05MF-LC			26	R	-
Connector No. M153		Signal Name [Specification]	29	SHIELD	-
Connector Name H.S.			30	W	-
Connector Type M05MF-LC			31	LG	-
Connector No. M154		Signal Name [Specification]	32	G	-
Connector Name H.S.			33	BR	-
Connector Type M05MF-LC					

JRJWC5658GB

ADP

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER			
Terminal No.	Signal Name [Specification]	Terminal No.	Signal Name [Specification]
71	SHEILD	57	SHEILD
72	R	58	SHEILD
73	R	MICROPHONE VCC	
74	P	CAMERA POWER SUPPLY	
75	LG	CAN-L	
76	LG	AV COMM(L)	
79	R	AV COMM(R)	
80	G	ILLUMINATION	
81	BG	REVERSE SIGNAL	
82	R	VEHICLE SPEED SIGNAL (8-PULSE)	
83	SHEILD	SHIELD	
87	G	MICROPHONE SIGNAL	
88	SHEILD	SHIELD	
89	G	COMM(DISP>CONT)	
90	L	CAN-H	
91	SB	AV COMM(H)	
92	SB	AV COMM(H)	
Connector No.	M215	Terminal Color Of Wire	Signal Name [Specification]
		LG	AV COMM(L)
		SB	AV COMM(H)
		LG	AV COMM(L)
		LG	AV COMM(H)
		CAN-L	CAN-H
		P	CAN-H
		B	SW GND
		SHIELD	SHIELD
		L	TEL VOICE SIGNAL (+)
		L	TEL VOICE SIGNAL (-)
		P	TELE SPEED SIGNAL (S-PULSE)
		R	VEHICLE SPEED SIGNAL (S-PULSE)
		V	PARKING BRAKE SIGNAL
		BG	REVERSE SIGNAL
		G	IGNITION SIGNAL
		Y	DISK EJECT SIGNAL

AUTOMATIC DRIVE POSITIONER			
Terminal No.	Signal Name [Specification]	Terminal No.	Signal Name [Specification]
36	BG	39	SIGNAL VCC
37	LG	40	SIGNAL GND
38	R	41	RGB(G>>CONT)
39	BR	42	RGB(B>>CONT)
40	B	43	RGB(A>>CONT)
41	SHLD	44	RGB SYNC
42	W	45	RGB SYNC
43	G	46	RGB(G>GREEN SIGNAL)
44	L	47	RGB(B>BLUE SIGNAL)
45	P	48	COMPOSITE IMAGE SIGNAL QND
46	V	49	INVERTER VCC
47	SB	50	INVERTER GND
48	Y	51	VP
49	BR	52	SHEILD

JRJWC5659GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## BCM (BODY CONTROL MODULE)

### Reference Value

INFOID:0000000011067197

### VALUES ON THE DIAGNOSIS TOOL

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

#### CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR CANCEL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REVERSE SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the key is not pressed	Off
	LOCK button of the key is pressed	On
RKE-UNLOCK	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed	On
RKE-TR/BD	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the key is not pressed	Off
	PANIC button of the key is pressed	On
RKE-P/W OPEN	UNLOCK button of the key is not pressed	Off
	UNLOCK button of the key is pressed and held	On

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RKE-MODE CHG	LOCK/UNLOCK button of the key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -RL	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
ACC RLY -F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
CLUCH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L -UNLOCK	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L RELAY-F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 L  
 M  
 N  
 O  
 P

ADP

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	<b>NOTE:</b> The item is indicated, but not monitored.	Off
S/L RELAY-REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Driver side door is open after ignition switch is turned OFF (Shift position is in the P position)	Reset
	Ignition switch ON	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The key is not inserted into key slot	Off
	The key is inserted into key slot	On
RKE OPE COUN1	During the operation of the key	Operation frequency of the key
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives does not accord with any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives does not accord with the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives does not accord with the third key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the third key ID registered to BCM.	Done

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >


Monitor Item	Condition	Value/Status
CONFIRM ID2	The key ID that the key slot receives does not accord with the second key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives does not accord with the first key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with the first key ID registered to BCM.	Done
TP 4	The ID of fourth key is not registered to BCM	Yet
	The ID of fourth key is registered to BCM	Done
TP 3	The ID of third key is not registered to BCM	Yet
	The ID of third key is registered to BCM	Done
TP 2	The ID of second key is not registered to BCM	Yet
	The ID of second key is registered to BCM	Done
TP 1	The ID of first key is not registered to BCM	Yet
	The ID of first key is registered to BCM	Done
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 ADP  
 K  
 L  
 M  
 N  
 O  
 P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT



JPMIA0062ZZ


## PHYSICAL VALUES

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (W)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
3 (Y)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	Battery voltage
5 (L)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors	LOCK (Actuator is activated)
					Other than LOCK (Actuator is not activated)
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	
13 (B)	Ground	Ground	—	Ignition switch ON	
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF or ON
					ACC

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P




JSNIA0010GB


# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON
18 (BG)	Ground	Turn signal LH (Front)	Output	Ignition switch ON
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON
23 (G)	Ground	Back door open	Output	Back door
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON
26 (G)	Ground	Rear wiper	Output	Rear wiper




PKID0926E



PKID0926E









PKID0926E



PKID0926E

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-	Signal name	Input/ Output		
34 (SB)	Ground	Luggage room antenna (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
35 (V)	Ground	Luggage room antenna (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
38 (B)	Ground	Back door antenna (-)	Output	When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>

A

B

C

D

E

F

G

H

I

ADP

K

L

M





N

O

P





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
					When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	Battery voltage
					When selector lever is not in P or N position	0 V
60 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ignition switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
61 (W)	Ground	Back door opener request switch	Input	Back door opener request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms <small>JPMIA0016GB</small>
64 (V)	Ground	Intelligent Key warning buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding	0 V
					Not sounding	Battery voltage
65 (BG)	Ground	Rear wiper stop position	Input	Rear wiper	In stop position	 (V) 15 10 5 0 10 ms <small>JPMIA0016GB</small>
					Not in stop position	0 V

# BCM (BODY CONTROL MODULE)







## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-				
66 (R)	Ground	Back door switch	Input	Back door switch	OFF (Door close)	 JPMIA0011GB 11.8 V
					ON (Door open)	0 V
67 (GR)	Ground	Back door opener switch	Input	Back door opener switch	Pressed	0 V
					Not pressed	 JPMIA0011GB 11.8 V
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (Door close)	 JPMIA0011GB 11.8 V
					ON (Door open)	0 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (Door close)	 JPMIA0011GB 11.8 V
					ON (Door open)	0 V

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 ADP  
 K  
 L  
 M  
 N  
 O  
 P







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-	Signal name	Input/ Output	
74 (SB)	Ground	Passenger door antenna (-)	When the passenger door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
				When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
75 (GR)	Ground	Passenger door antenna (+)	When the passenger door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
				When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
76 (V)	Ground	Driver door antenna (-)	When the driver door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
				When Intelligent Key is not in the antenna detection area	 JMKIA0063GB

# BCM (BODY CONTROL MODULE)



## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	+	-	Signal name	Input/ Output	
77 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the antenna detection area	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	Ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	Ignition switch OFF	 (V) 15 10 5 0 1 s <small>JMKIA0062GB</small>
				When Intelligent Key is not in the passenger compartment	 (V) 15 10 5 0 1 s <small>JMKIA0063GB</small>

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 ADP  
 K  
 L  
 M  
 N  
 O  
 P





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp.	Input/ Output	During waiting Ignition switch is pressed while inserting the key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch OFF or ACC 0 V ON Battery voltage
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	During waiting  JMKA0064GB
				When operating either button on the key  JMKA0065GB

# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
87 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)
					 JPMIA0041GB 1.4 V
					Front fog lamp switch ON (Wiper intermittent dial 4)
					 JPMIA0037GB 1.3 V
					Rear wiper switch ON (Wiper intermittent dial 4)
					 JPMIA0039GB 1.3 V
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>
					 JPMIA0040GB 1.3 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
  
ADP  
  
K  
L  
  
M  
N  
  
O  
P




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
88 (V)	Ground	Combination switch INPUT 3	Input	 All switches OFF (Wiper intermittent dial 4)   Lighting switch HI (Wiper intermittent dial 4)   Lighting switch 2ND (Wiper intermittent dial 4)   Rear washer switch ON (Wiper intermittent dial 4)   Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>
				JPMIA0041GB 1.4 V
				JPMIA0036GB 1.3 V
				JPMIA0037GB 1.3 V
				JPMIA0039GB 1.3 V
90 (P)	Ground	CAN-L	Input/ Output	—
91 (L)	Ground	CAN-H	Input/ Output	—

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	Battery voltage
					Blinking	 (V) 15 10 5 0 1 s <small>JPMIA0015GB</small>
					ON	6.5 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V
94 (Y)	Ground	Puddle lamp control	Output	Puddle lamp	OFF	Battery voltage
					ON	0 V
95 (BG)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—		Battery voltage
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms <small>JPMIA0016GB</small>
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 (V) 15 10 5 0 10 ms <small>JPMIA0016GB</small>
102 (BG)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage

A

B

C

D

E

F

G

H

I

ADP

K

L

M






N

O

P





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
107 (LG)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermittent dial 4)	All switches OFF   1.4 V
				Turn signal switch LH   1.3 V
				Turn signal switch RH   1.3 V
				Front wiper switch LO   1.3 V
				Front washer switch ON   1.3 V

# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)
					 JPMIA0041GB 1.4 V
					Lighting switch AUTO (Wiper intermittent dial 4)
					 JPMIA0038GB 1.3 V
					Lighting switch 1ST (Wiper intermittent dial 4)
					Rear wiper switch INT (Wiper intermittent dial 4)
					 JPMIA0040GB 1.3 V
					Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6
					 JPMIA0039GB 1.3 V

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 ADP  
 K  
 L  
 M  
 N  
 O  
 P



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
109 (Y)	Ground	Combination switch INPUT 2	Combination switch (Wiper intermittent dial 4)	All switches OFF
				 1.4 V <small>JPMIA0041GB</small>
				 1.3 V <small>JPMIA0037GB</small>
				 1.3 V <small>JPMIA0036GB</small>
				 1.3 V <small>JPMIA0038GB</small>
110 (G)	Ground	Hazard switch	Hazard switch	ON
				 0 V
			OFF	 1.1 V <small>JPMIA0012GB</small>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage	
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
					ON (Brake pedal is depressed)	Battery voltage	
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage	
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 JPMIA0012GB 1.1 V	
					UNLOCK status (Unlock switch sensor ON)	0 V	
121 (BR)	Ground	Key slot switch	Input	When the key is inserted into key slot		Battery voltage	
				When the key is not inserted into key slot		0 V	
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V	
					ON	Battery voltage	
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 JPMIA0011GB 11.8 V	
					ON (Door open)	0 V	
132 (BR)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 JPMIA0013GB 10.2 V	
				Ignition switch OFF or ACC		Battery voltage	

A

B

C

D

E

F

G

H

I

ADP

K

L

M





N

O

P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON (Tail lamps OFF)	9.5 V
					ON (Tail lamps ON)	<p><b>NOTE:</b> The pulse width of this wave is varied by the illumination brightening/dimming level.</p>  <p>JPMIA0159GB</p>
					OFF	0 V
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (BG)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V
138 (Y)	Ground	Receiver and sensor power supply	Output	Ignition switch	OFF	0 V
					ACC or ON	5.0 V
139 (L)	Ground	Tire pressure receiver communication	Input/ Output	Ignition switch ON	Standby state	 <p>OCC3881D</p>
					When receiving the signal from the transmitter	 <p>OCC3880D</p>
140 (GR)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	Battery voltage
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 <p>JPMIA0014GB</p> <p>11.3 V</p>
					OFF	Battery voltage

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
142 (BG)	Ground	Combination switch OUTPUT 5	Output Combination switch (Wiper intermittent dial 4)	All switches OFF
				Lighting switch 1ST
				Lighting switch HI
				Lighting switch 2ND
				Turn signal switch RH
143 (P)	Ground	Combination switch OUTPUT 1	Output Combination switch	0 V
				All switches OFF (Wiper intermittent dial 4)
				Front wiper switch HI (Wiper intermittent dial 4)
				Rear wiper switch INT (Wiper intermittent dial 4)
				Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>
144 (G)	Ground	Combination switch OUTPUT 2	Output Combination switch	0 V
				All switches OFF (Wiper intermittent dial 4)
				Front washer switch ON (Wiper intermittent dial 4)
				Rear wiper switch ON (Wiper intermittent dial 4)
				Rear washer switch ON (Wiper intermittent dial 4)
145 (L)	Ground	Combination switch OUTPUT 3	Output Combination switch (Wiper intermittent dial 4)	0 V
				All switches OFF
				Front wiper switch INT
				Front wiper switch LO
				Lighting switch AUTO

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 K  
 L  
 M  
 N  
 O  
 P  
 ADP

# BCM (BODY CONTROL MODULE)


## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
146 (SB)	Ground	Combination switch OUTPUT 4	Combination switch (Wiper intermit- tent dial 4)	All switches OFF
				Front fog lamp switch ON
				Lighting switch 2ND
				Lighting switch PASS
				Turn signal switch LH
150 (LG)	Ground	Driver door switch	Driver door switch	OFF (Door close)
				ON (Door open)
151 (G)	Ground	Rear window defog- ger relay control	Rear window de- fogger	Active
				Not activated



JPMIA0035GB

10.7 V



JPMIA0011GB


11.8 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - BCM -

INFOID:000000011067198




2014/03/21

JRMWF4610GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWF4611GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

- ⟨RF⟩ : With sunroof
- ⟨PM⟩ : With automatic drive positioner
- ⟨OP⟩ : Without automatic drive positioner



\* : This connector is not shown in "Harness Layout".


JRMWF4612GB

A B C D E F G H I J K L M O P

ADP

# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JRMWF4613GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JRMWF4614GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

---

## BCM (BODY CONTROL MODULE)

Connector No.		Terminal Color Of Wire		Signal Name [Specification]	
Connector No.	B16	1	B	FRONT DOOR SWITCH DRIVER SIDE:	
Connector Name	FRONT DOOR SWITCH DRIVER SIDE:	2	L	-	
Connector Type	A03FW			-	


**H.S.**

 | Connector No.  |                                   | Terminal Color Of Wire |    | Signal Name [Specification]       |  | |----------------|-----------------------------------|------------------------|----|-----------------------------------|--| | Connector No.  | B228                              | 1                      | V  | INSIDE KEY ANTENNA (LUGGAGE ROOM) |  | | Connector Name | INSIDE KEY ANTENNA (LUGGAGE ROOM) | 2                      | SB | -                                 |  | | Connector Type | TRK02GY                           |                        |    | -                                 |  |     **H.S.** | | Connector No.  |                                    | Terminal Color Of Wire |    | Signal Name [Specification]        |  | |----------------|------------------------------------|------------------------|----|------------------------------------|--| | Connector No.  | B216                               | 1                      | V  | FRONT DOOR SWITCH (PASSENGER SIDE) |  | | Connector Name | FRONT DOOR SWITCH (PASSENGER SIDE) | 2                      | SB | -                                  |  | | Connector Type | A03FW                              |                        |    | -                                  |  |     **H.S.** | | Connector No.  |                                  | Terminal Color Of Wire |    | Signal Name [Specification]      |  | |----------------|----------------------------------|------------------------|----|----------------------------------|--| | Connector No.  | B229                             | 1                      | V  | LUGGAGE ROOM LAMP (LUGGAGE SIDE) |  | | Connector Name | LUGGAGE ROOM LAMP (LUGGAGE SIDE) | 2                      | SB | -                                |  | | Connector Type | TRK02W                           |                        |    | -                                |  |     **H.S.** | | Connector No.  |                     | Terminal Color Of Wire |    | Signal Name [Specification] |  | |----------------|---------------------|------------------------|----|-----------------------------|--| | Connector No.  | B223                | 1                      | V  | REAR DOOR SWITCH RH         |  | | Connector Name | REAR DOOR SWITCH RH | 2                      | SB | -                           |  | | Connector Type | A03FW               |                        |    | -                           |  |     **H.S.** | | Connector No.  |             | Terminal Color Of Wire |    | Signal Name [Specification] |  | |----------------|-------------|------------------------|----|-----------------------------|--| | Connector No.  | B47         | 1                      | GR | DOOR                        |  | | Connector Name | DOOR        | 2                      | L  | -                           |  | | Connector Type | 24335.C9800 |                        |    | -                           |  |     **H.S.** |

JRMWF4748GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

## BCM (BODY CONTROL MODULE)

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>G</td><td>R</td></tr> <tr><td>2</td><td>B</td><td>B</td></tr> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>-</td><td>-</td></tr> <tr><td>2</td><td>-</td><td>-</td></tr> <tr><td>3</td><td>Q/Y</td><td>-</td></tr> <tr><td>4</td><td>P</td><td>-</td></tr> <tr><td>5</td><td>W</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>L/Y</td><td>-</td></tr> <tr><td>8</td><td>L</td><td>-</td></tr> <tr><td>9</td><td>L/R</td><td>-</td></tr> <tr><td>10</td><td>G/W</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	G	R	2	B	B	Terminal No.	Color Of Wire	Signal Name [Specification]	1	-	-	2	-	-	3	Q/Y	-	4	P	-	5	W	-	6	V	-	7	L/Y	-	8	L	-	9	L/R	-	10	G/W	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>-</td><td>CAN-H</td></tr> <tr><td>2</td><td>-</td><td>UART (TX-RX)</td></tr> <tr><td>4</td><td>-</td><td>PULSE (RECILINER)</td></tr> <tr><td>5</td><td>-</td><td>BU (SETELESCOPIC)</td></tr> <tr><td>6</td><td>-</td><td>ADDRESS 2</td></tr> <tr><td>7</td><td>-</td><td>IND.2</td></tr> <tr><td>8</td><td>-</td><td>SIDE SW (BACKWARD)</td></tr> <tr><td>9</td><td>-</td><td>RECILINER SW (BACKWARD)</td></tr> <tr><td>10</td><td>-</td><td>FRONT LIFTER SW (DOWNWARD)</td></tr> <tr><td>11</td><td>-</td><td>REAR LIFTER SW (DOWNWARD)</td></tr> <tr><td>12</td><td>-</td><td>POWER SUPPLY (ENCODER)</td></tr> <tr><td>17</td><td>-</td><td>CAN-L</td></tr> <tr><td>18</td><td>-</td><td>PULSE (SLIDE)</td></tr> <tr><td>19</td><td>-</td><td>PULSE (FRONT LIFTER)</td></tr> <tr><td>20</td><td>-</td><td>PULSE (REAR LIFTER)</td></tr> <tr><td>21</td><td>-</td><td>FRONT LIFTER SW (UPWARD)</td></tr> <tr><td>22</td><td>-</td><td>REAR LIFTER SW (UPWARD)</td></tr> <tr><td>23</td><td>-</td><td>Y</td></tr> <tr><td>24</td><td>-</td><td>V</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	-	CAN-H	2	-	UART (TX-RX)	4	-	PULSE (RECILINER)	5	-	BU (SETELESCOPIC)	6	-	ADDRESS 2	7	-	IND.2	8	-	SIDE SW (BACKWARD)	9	-	RECILINER SW (BACKWARD)	10	-	FRONT LIFTER SW (DOWNWARD)	11	-	REAR LIFTER SW (DOWNWARD)	12	-	POWER SUPPLY (ENCODER)	17	-	CAN-L	18	-	PULSE (SLIDE)	19	-	PULSE (FRONT LIFTER)	20	-	PULSE (REAR LIFTER)	21	-	FRONT LIFTER SW (UPWARD)	22	-	REAR LIFTER SW (UPWARD)	23	-	Y	24	-	V	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>Q/Y</td><td>-</td></tr> <tr><td>4</td><td>P</td><td>-</td></tr> <tr><td>5</td><td>W</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>L/Y</td><td>-</td></tr> <tr><td>8</td><td>L</td><td>-</td></tr> <tr><td>9</td><td>L/R</td><td>-</td></tr> <tr><td>10</td><td>G/W</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	R	-	2	B	-	3	Q/Y	-	4	P	-	5	W	-	6	V	-	7	L/Y	-	8	L	-	9	L/R	-	10	G/W	-
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																							
1	G	R																																																																																																																																							
2	B	B																																																																																																																																							
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																							
1	-	-																																																																																																																																							
2	-	-																																																																																																																																							
3	Q/Y	-																																																																																																																																							
4	P	-																																																																																																																																							
5	W	-																																																																																																																																							
6	V	-																																																																																																																																							
7	L/Y	-																																																																																																																																							
8	L	-																																																																																																																																							
9	L/R	-																																																																																																																																							
10	G/W	-																																																																																																																																							
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																							
1	-	CAN-H																																																																																																																																							
2	-	UART (TX-RX)																																																																																																																																							
4	-	PULSE (RECILINER)																																																																																																																																							
5	-	BU (SETELESCOPIC)																																																																																																																																							
6	-	ADDRESS 2																																																																																																																																							
7	-	IND.2																																																																																																																																							
8	-	SIDE SW (BACKWARD)																																																																																																																																							
9	-	RECILINER SW (BACKWARD)																																																																																																																																							
10	-	FRONT LIFTER SW (DOWNWARD)																																																																																																																																							
11	-	REAR LIFTER SW (DOWNWARD)																																																																																																																																							
12	-	POWER SUPPLY (ENCODER)																																																																																																																																							
17	-	CAN-L																																																																																																																																							
18	-	PULSE (SLIDE)																																																																																																																																							
19	-	PULSE (FRONT LIFTER)																																																																																																																																							
20	-	PULSE (REAR LIFTER)																																																																																																																																							
21	-	FRONT LIFTER SW (UPWARD)																																																																																																																																							
22	-	REAR LIFTER SW (UPWARD)																																																																																																																																							
23	-	Y																																																																																																																																							
24	-	V																																																																																																																																							
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																							
1	R	-																																																																																																																																							
2	B	-																																																																																																																																							
3	Q/Y	-																																																																																																																																							
4	P	-																																																																																																																																							
5	W	-																																																																																																																																							
6	V	-																																																																																																																																							
7	L/Y	-																																																																																																																																							
8	L	-																																																																																																																																							
9	L/R	-																																																																																																																																							
10	G/W	-																																																																																																																																							

JRMWF4749GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

---

## BCM (BODY CONTROL MODULE)

Connector No.		Signal Name [Specification]		Terminal Color Of Wire		Signal Name [Specification]	
5	O	—	—	1	Y	—	—
6	Y	—	—	2	B	—	—
7	BR	—	—	3	—	—	—
8	L	—	—	4	—	—	—
9	O	—	—	5	Y	—	—
10	Y	—	—	6	V	—	—
11	G	—	—	7	—	—	—
13	P	—	—	8	—	—	—
14	V	—	—	9	—	—	—
15	B	—	—	10	—	—	—
Connector No.		Signal Name [Specification]		Terminal Color Of Wire		Signal Name [Specification]	
D9		POWER WINDOW MAIN SWITCH		1 LG		1 R	
Connector Name		NS05FW-CS		2 P		2 SB	
Connector Type		—		3 L		—	
							
Connector No.		Signal Name [Specification]		4 B		5 Y	
D13		FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)		6 V		6 V	
Connector Name		FR02FL		7 —		7 —	
Connector Type		—		8 —		8 —	
							
Connector No.		Signal Name [Specification]		9 —		10 —	
D14		FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)		11 —		12 —	
Connector Name		FR02FL		13 —		14 —	
Connector Type		—		15 —		16 —	
							
Connector No.		Signal Name [Specification]		17 —		18 —	
D12		STEP LAMP (PASSENGER SIDE)		19 W		20 —	
Connector Name		TB02FW		21 —		22 —	
Connector Type		—					
Connector No.		Signal Name [Specification]		23 —		24 —	
D15		FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)		25 —		26 —	
Connector Name		EGEF0Y-TS		27 —		28 —	
Connector Type		TE02FW					
							
Connector No.		Signal Name [Specification]		29 —		30 —	
D43		FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)		31 —		32 —	
Connector Name		RU02FL		33 —		34 —	
Connector Type		—					
							
Connector No.		Signal Name [Specification]		35 —		36 —	
D38		FRONT REAR WINDOW WASH (PASSENGER SIDE)		37 —		38 —	
Connector Name		NST16W-CS		39 —		40 —	
Connector Type		—					
							
Connector No.		Signal Name [Specification]		41 —		42 —	
D44		FRONT REAR WINDOW WASH (DRIVER SIDE)		43 —		44 —	
Connector Name		NST16W-CS		45 —		46 —	
Connector Type		—					
							

JRMWF4750GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

## BCM (BODY CONTROL MODULE)

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D44</td></tr> <tr><td>Connector Name</td><td>FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA</td></tr> <tr><td>Connector Type</td><td>IK02MGY</td></tr> </table> 	Connector No.	D44	Connector Name	FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA	Connector Type	IK02MGY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D54</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH LH</td></tr> <tr><td>Connector Type</td><td>NS08FW-CS</td></tr> </table> 	Connector No.	D54	Connector Name	REAR POWER WINDOW SWITCH LH	Connector Type	NS08FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D74</td></tr> <tr><td>Connector Name</td><td>REAR POWER WINDOW SWITCH RH</td></tr> <tr><td>Connector Type</td><td>NS08FW-CS</td></tr> </table> 	Connector No.	D74	Connector Name	REAR POWER WINDOW SWITCH RH	Connector Type	NS08FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>-</td><td>1</td><td>V</td><td>-</td></tr> <tr><td>2</td><td>V</td><td>-</td><td>2</td><td>P</td><td>-</td></tr> <tr><td>3</td><td>G</td><td>-</td><td>3</td><td>-</td><td>-</td></tr> <tr><td>4</td><td>L</td><td>-</td><td>4</td><td>-</td><td>-</td></tr> <tr><td>5</td><td>W</td><td>-</td><td>5</td><td>-</td><td>-</td></tr> <tr><td>7</td><td>B</td><td>-</td><td>7</td><td>-</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	1	P	-	1	V	-	2	V	-	2	P	-	3	G	-	3	-	-	4	L	-	4	-	-	5	W	-	5	-	-	7	B	-	7	-	-
Connector No.	D44																																																														
Connector Name	FRONT OUTSIDE HANDLE RH/OUTSIDE KEY ANTENNA																																																														
Connector Type	IK02MGY																																																														
Connector No.	D54																																																														
Connector Name	REAR POWER WINDOW SWITCH LH																																																														
Connector Type	NS08FW-CS																																																														
Connector No.	D74																																																														
Connector Name	REAR POWER WINDOW SWITCH RH																																																														
Connector Type	NS08FW-CS																																																														
Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]																																																										
1	P	-	1	V	-																																																										
2	V	-	2	P	-																																																										
3	G	-	3	-	-																																																										
4	L	-	4	-	-																																																										
5	W	-	5	-	-																																																										
7	B	-	7	-	-																																																										
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D45</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY/PASSENGER SIDE</td></tr> <tr><td>Connector Type</td><td>E06FGY-RS</td></tr> </table> 	Connector No.	D45	Connector Name	FRONT DOOR LOCK ASSEMBLY/PASSENGER SIDE	Connector Type	E06FGY-RS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D55</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY LH</td></tr> <tr><td>Connector Type</td><td>E06FGY-RS</td></tr> </table> 	Connector No.	D55	Connector Name	REAR DOOR LOCK ASSEMBLY LH	Connector Type	E06FGY-RS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D75</td></tr> <tr><td>Connector Name</td><td>REAR DOOR LOCK ASSEMBLY RH</td></tr> <tr><td>Connector Type</td><td>E06FGY-RS</td></tr> </table> 	Connector No.	D75	Connector Name	REAR DOOR LOCK ASSEMBLY RH	Connector Type	E06FGY-RS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>-</td><td>1</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>LG</td><td>-</td><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>-</td><td>-</td><td>3</td><td>V</td><td>-</td></tr> <tr><td>4</td><td>-</td><td>-</td><td>4</td><td>B</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	1	P	-	1	Y	-	2	LG	-	2	B	-	3	-	-	3	V	-	4	-	-	4	B	-												
Connector No.	D45																																																														
Connector Name	FRONT DOOR LOCK ASSEMBLY/PASSENGER SIDE																																																														
Connector Type	E06FGY-RS																																																														
Connector No.	D55																																																														
Connector Name	REAR DOOR LOCK ASSEMBLY LH																																																														
Connector Type	E06FGY-RS																																																														
Connector No.	D75																																																														
Connector Name	REAR DOOR LOCK ASSEMBLY RH																																																														
Connector Type	E06FGY-RS																																																														
Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]																																																										
1	P	-	1	Y	-																																																										
2	LG	-	2	B	-																																																										
3	-	-	3	V	-																																																										
4	-	-	4	B	-																																																										
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D46</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY/DRIVER SIDE</td></tr> <tr><td>Connector Type</td><td>E06FGY-RS</td></tr> </table> 	Connector No.	D46	Connector Name	FRONT DOOR LOCK ASSEMBLY/DRIVER SIDE	Connector Type	E06FGY-RS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>-</td><td>1</td><td>Q</td><td>-</td></tr> <tr><td>2</td><td>LG</td><td>-</td><td>2</td><td>V</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	1	P	-	1	Q	-	2	LG	-	2	V	-																																						
Connector No.	D46																																																														
Connector Name	FRONT DOOR LOCK ASSEMBLY/DRIVER SIDE																																																														
Connector Type	E06FGY-RS																																																														
Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]																																																										
1	P	-	1	Q	-																																																										
2	LG	-	2	V	-																																																										

JRMWF4751GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

---

## BCM (BODY CONTROL MODULE)

<table border="1"> <tr><td>Connector No.</td><td>D114</td></tr> <tr><td>Connector Name</td><td>BACK DOOR OPENER SWITCH</td></tr> <tr><td>Connector Type</td><td>TK02MBR-P</td></tr> </table>  	Connector No.	D114	Connector Name	BACK DOOR OPENER SWITCH	Connector Type	TK02MBR-P	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 GR</td><td>-</td></tr> <tr><td>2 B</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 GR	-	2 B	-	No.	Color Of Wire	Signal Name [Specification]	1	W	-	2	B	-	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 G</td><td>-</td></tr> <tr><td>2 R</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>G</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 G	-	2 R	-	No.	Color Of Wire	Signal Name [Specification]	1	G	-	2	R	-																																																																																																																																																																																																												
Connector No.	D114																																																																																																																																																																																																																																																	
Connector Name	BACK DOOR OPENER SWITCH																																																																																																																																																																																																																																																	
Connector Type	TK02MBR-P																																																																																																																																																																																																																																																	
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 GR	-																																																																																																																																																																																																																																																	
2 B	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	W	-																																																																																																																																																																																																																																																
2	B	-																																																																																																																																																																																																																																																
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 G	-																																																																																																																																																																																																																																																	
2 R	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	G	-																																																																																																																																																																																																																																																
2	R	-																																																																																																																																																																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>D115</td></tr> <tr><td>Connector Name</td><td>REAR WIPER MOTOR</td></tr> <tr><td>Connector Type</td><td>TH02FW-IV</td></tr> </table>  	Connector No.	D115	Connector Name	REAR WIPER MOTOR	Connector Type	TH02FW-IV	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 O</td><td>-</td></tr> <tr><td>2 R</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>O</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 O	-	2 R	-	No.	Color Of Wire	Signal Name [Specification]	1	O	-	2	R	-	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 G</td><td>-</td></tr> <tr><td>2 R</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>G</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 G	-	2 R	-	No.	Color Of Wire	Signal Name [Specification]	1	G	-	2	R	-																																																																																																																																																																																																												
Connector No.	D115																																																																																																																																																																																																																																																	
Connector Name	REAR WIPER MOTOR																																																																																																																																																																																																																																																	
Connector Type	TH02FW-IV																																																																																																																																																																																																																																																	
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 O	-																																																																																																																																																																																																																																																	
2 R	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	O	-																																																																																																																																																																																																																																																
2	R	-																																																																																																																																																																																																																																																
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 G	-																																																																																																																																																																																																																																																	
2 R	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	G	-																																																																																																																																																																																																																																																
2	R	-																																																																																																																																																																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>D116</td></tr> <tr><td>Connector Name</td><td>BACK DOOR REQUEST SWITCH</td></tr> <tr><td>Connector Type</td><td>TK02MBR-P</td></tr> </table>  	Connector No.	D116	Connector Name	BACK DOOR REQUEST SWITCH	Connector Type	TK02MBR-P	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 W</td><td>-</td></tr> <tr><td>2 B</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 W	-	2 B	-	No.	Color Of Wire	Signal Name [Specification]	1	W	-	2	B	-	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 V</td><td>-</td></tr> <tr><td>2 L</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> <tr><td>2</td><td>L</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 V	-	2 L	-	No.	Color Of Wire	Signal Name [Specification]	1	V	-	2	L	-																																																																																																																																																																																																												
Connector No.	D116																																																																																																																																																																																																																																																	
Connector Name	BACK DOOR REQUEST SWITCH																																																																																																																																																																																																																																																	
Connector Type	TK02MBR-P																																																																																																																																																																																																																																																	
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 W	-																																																																																																																																																																																																																																																	
2 B	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	W	-																																																																																																																																																																																																																																																
2	B	-																																																																																																																																																																																																																																																
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 V	-																																																																																																																																																																																																																																																	
2 L	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	V	-																																																																																																																																																																																																																																																
2	L	-																																																																																																																																																																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>D117</td></tr> <tr><td>Connector Name</td><td>OUTSIDE KEY ANTENNA (BACK DOOR)</td></tr> <tr><td>Connector Type</td><td>TH02FW-IV</td></tr> </table>  	Connector No.	D117	Connector Name	OUTSIDE KEY ANTENNA (BACK DOOR)	Connector Type	TH02FW-IV	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 G</td><td>-</td></tr> <tr><td>2 R</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>G</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 G	-	2 R	-	No.	Color Of Wire	Signal Name [Specification]	1	G	-	2	R	-	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 Y</td><td>-</td></tr> <tr><td>2 Q</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>Y</td><td>-</td></tr> <tr><td>2</td><td>Q</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 Y	-	2 Q	-	No.	Color Of Wire	Signal Name [Specification]	1	Y	-	2	Q	-																																																																																																																																																																																																												
Connector No.	D117																																																																																																																																																																																																																																																	
Connector Name	OUTSIDE KEY ANTENNA (BACK DOOR)																																																																																																																																																																																																																																																	
Connector Type	TH02FW-IV																																																																																																																																																																																																																																																	
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 G	-																																																																																																																																																																																																																																																	
2 R	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	G	-																																																																																																																																																																																																																																																
2	R	-																																																																																																																																																																																																																																																
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 Y	-																																																																																																																																																																																																																																																	
2 Q	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	Y	-																																																																																																																																																																																																																																																
2	Q	-																																																																																																																																																																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>D118</td></tr> <tr><td>Connector Name</td><td>OUTSIDE KEY ANTENNA (FRONT DOOR)</td></tr> <tr><td>Connector Type</td><td>TH02FW-IV</td></tr> </table>  	Connector No.	D118	Connector Name	OUTSIDE KEY ANTENNA (FRONT DOOR)	Connector Type	TH02FW-IV	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 G</td><td>-</td></tr> <tr><td>2 R</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>G</td><td>-</td></tr> <tr><td>2</td><td>R</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 G	-	2 R	-	No.	Color Of Wire	Signal Name [Specification]	1	G	-	2	R	-	<table border="1"> <tr><td>Terminal Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1 R</td><td>-</td></tr> <tr><td>2 G</td><td>-</td></tr> </table> <table border="1"> <tr><td>No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>2</td><td>G</td><td>-</td></tr> </table>	Terminal Color Of Wire	Signal Name [Specification]	1 R	-	2 G	-	No.	Color Of Wire	Signal Name [Specification]	1	R	-	2	G	-																																																																																																																																																																																																												
Connector No.	D118																																																																																																																																																																																																																																																	
Connector Name	OUTSIDE KEY ANTENNA (FRONT DOOR)																																																																																																																																																																																																																																																	
Connector Type	TH02FW-IV																																																																																																																																																																																																																																																	
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 G	-																																																																																																																																																																																																																																																	
2 R	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	G	-																																																																																																																																																																																																																																																
2	R	-																																																																																																																																																																																																																																																
Terminal Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																	
1 R	-																																																																																																																																																																																																																																																	
2 G	-																																																																																																																																																																																																																																																	
No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	R	-																																																																																																																																																																																																																																																
2	G	-																																																																																																																																																																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>E26</td></tr> <tr><td>Connector Name</td><td>FRONT COMBINATION LAMP RH</td></tr> <tr><td>Connector Type</td><td>RS05FB-R/R</td></tr> </table>  	Connector No.	E26	Connector Name	FRONT COMBINATION LAMP RH	Connector Type	RS05FB-R/R	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>B/Y</td><td>-</td></tr> <tr><td>4</td><td>B/W</td><td>-</td></tr> <tr><td>5</td><td>B/G</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>BR</td><td>-</td></tr> <tr><td>8</td><td>P</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	2	B	-	3	B/Y	-	4	B/W	-	5	B/G	-	6	V	-	7	BR	-	8	P	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>B/Y</td><td>-</td></tr> <tr><td>4</td><td>B/W</td><td>-</td></tr> <tr><td>5</td><td>B/G</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>BR</td><td>-</td></tr> <tr><td>8</td><td>P</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	2	B	-	3	B/Y	-	4	B/W	-	5	B/G	-	6	V	-	7	BR	-	8	P	-																																																																																																																																																																																										
Connector No.	E26																																																																																																																																																																																																																																																	
Connector Name	FRONT COMBINATION LAMP RH																																																																																																																																																																																																																																																	
Connector Type	RS05FB-R/R																																																																																																																																																																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
2	B	-																																																																																																																																																																																																																																																
3	B/Y	-																																																																																																																																																																																																																																																
4	B/W	-																																																																																																																																																																																																																																																
5	B/G	-																																																																																																																																																																																																																																																
6	V	-																																																																																																																																																																																																																																																
7	BR	-																																																																																																																																																																																																																																																
8	P	-																																																																																																																																																																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
2	B	-																																																																																																																																																																																																																																																
3	B/Y	-																																																																																																																																																																																																																																																
4	B/W	-																																																																																																																																																																																																																																																
5	B/G	-																																																																																																																																																																																																																																																
6	V	-																																																																																																																																																																																																																																																
7	BR	-																																																																																																																																																																																																																																																
8	P	-																																																																																																																																																																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>E41</td></tr> <tr><td>Connector Name</td><td>AIR ACTUATOR AND ELECTRIC UNIT (DASH/ROOF INT)</td></tr> <tr><td>Connector Type</td><td>BAAA2FB-AHZL-LH</td></tr> </table>  	Connector No.	E41	Connector Name	AIR ACTUATOR AND ELECTRIC UNIT (DASH/ROOF INT)	Connector Type	BAAA2FB-AHZL-LH	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>GR</td><td>-</td></tr> <tr><td>3</td><td>GR</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> <tr><td>5</td><td>GR</td><td>-</td></tr> <tr><td>6</td><td>GR</td><td>-</td></tr> <tr><td>7</td><td>GR</td><td>-</td></tr> <tr><td>8</td><td>GR</td><td>-</td></tr> <tr><td>9</td><td>GR</td><td>-</td></tr> <tr><td>10</td><td>GR</td><td>-</td></tr> <tr><td>11</td><td>GR</td><td>-</td></tr> <tr><td>12</td><td>GR</td><td>-</td></tr> <tr><td>13</td><td>GR</td><td>-</td></tr> <tr><td>14</td><td>GR</td><td>-</td></tr> <tr><td>15</td><td>GR</td><td>-</td></tr> <tr><td>16</td><td>GR</td><td>-</td></tr> <tr><td>17</td><td>GR</td><td>-</td></tr> <tr><td>18</td><td>GR</td><td>-</td></tr> <tr><td>19</td><td>GR</td><td>-</td></tr> <tr><td>20</td><td>GR</td><td>-</td></tr> <tr><td>21</td><td>GR</td><td>-</td></tr> <tr><td>22</td><td>GR</td><td>-</td></tr> <tr><td>23</td><td>GR</td><td>-</td></tr> <tr><td>24</td><td>GR</td><td>-</td></tr> <tr><td>25</td><td>GR</td><td>-</td></tr> <tr><td>26</td><td>GR</td><td>-</td></tr> <tr><td>27</td><td>GR</td><td>-</td></tr> <tr><td>28</td><td>GR</td><td>-</td></tr> <tr><td>29</td><td>GR</td><td>-</td></tr> <tr><td>30</td><td>GR</td><td>-</td></tr> <tr><td>31</td><td>GR</td><td>-</td></tr> <tr><td>32</td><td>GR</td><td>-</td></tr> <tr><td>33</td><td>GR</td><td>-</td></tr> <tr><td>34</td><td>GR</td><td>-</td></tr> <tr><td>35</td><td>GR</td><td>-</td></tr> <tr><td>36</td><td>GR</td><td>-</td></tr> <tr><td>37</td><td>GR</td><td>-</td></tr> <tr><td>38</td><td>GR</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	W	-	2	GR	-	3	GR	-	4	G	-	5	GR	-	6	GR	-	7	GR	-	8	GR	-	9	GR	-	10	GR	-	11	GR	-	12	GR	-	13	GR	-	14	GR	-	15	GR	-	16	GR	-	17	GR	-	18	GR	-	19	GR	-	20	GR	-	21	GR	-	22	GR	-	23	GR	-	24	GR	-	25	GR	-	26	GR	-	27	GR	-	28	GR	-	29	GR	-	30	GR	-	31	GR	-	32	GR	-	33	GR	-	34	GR	-	35	GR	-	36	GR	-	37	GR	-	38	GR	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>GR</td><td>-</td></tr> <tr><td>3</td><td>GR</td><td>-</td></tr> <tr><td>4</td><td>GR</td><td>-</td></tr> <tr><td>5</td><td>GR</td><td>-</td></tr> <tr><td>6</td><td>GR</td><td>-</td></tr> <tr><td>7</td><td>GR</td><td>-</td></tr> <tr><td>8</td><td>GR</td><td>-</td></tr> <tr><td>9</td><td>GR</td><td>-</td></tr> <tr><td>10</td><td>GR</td><td>-</td></tr> <tr><td>11</td><td>GR</td><td>-</td></tr> <tr><td>12</td><td>GR</td><td>-</td></tr> <tr><td>13</td><td>GR</td><td>-</td></tr> <tr><td>14</td><td>GR</td><td>-</td></tr> <tr><td>15</td><td>GR</td><td>-</td></tr> <tr><td>16</td><td>GR</td><td>-</td></tr> <tr><td>17</td><td>GR</td><td>-</td></tr> <tr><td>18</td><td>GR</td><td>-</td></tr> <tr><td>19</td><td>GR</td><td>-</td></tr> <tr><td>20</td><td>GR</td><td>-</td></tr> <tr><td>21</td><td>GR</td><td>-</td></tr> <tr><td>22</td><td>GR</td><td>-</td></tr> <tr><td>23</td><td>GR</td><td>-</td></tr> <tr><td>24</td><td>GR</td><td>-</td></tr> <tr><td>25</td><td>GR</td><td>-</td></tr> <tr><td>26</td><td>GR</td><td>-</td></tr> <tr><td>27</td><td>GR</td><td>-</td></tr> <tr><td>28</td><td>GR</td><td>-</td></tr> <tr><td>29</td><td>GR</td><td>-</td></tr> <tr><td>30</td><td>GR</td><td>-</td></tr> <tr><td>31</td><td>GR</td><td>-</td></tr> <tr><td>32</td><td>GR</td><td>-</td></tr> <tr><td>33</td><td>GR</td><td>-</td></tr> <tr><td>34</td><td>GR</td><td>-</td></tr> <tr><td>35</td><td>GR</td><td>-</td></tr> <tr><td>36</td><td>GR</td><td>-</td></tr> <tr><td>37</td><td>GR</td><td>-</td></tr> <tr><td>38</td><td>GR</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	W	-	2	GR	-	3	GR	-	4	GR	-	5	GR	-	6	GR	-	7	GR	-	8	GR	-	9	GR	-	10	GR	-	11	GR	-	12	GR	-	13	GR	-	14	GR	-	15	GR	-	16	GR	-	17	GR	-	18	GR	-	19	GR	-	20	GR	-	21	GR	-	22	GR	-	23	GR	-	24	GR	-	25	GR	-	26	GR	-	27	GR	-	28	GR	-	29	GR	-	30	GR	-	31	GR	-	32	GR	-	33	GR	-	34	GR	-	35	GR	-	36	GR	-	37	GR	-	38	GR	-
Connector No.	E41																																																																																																																																																																																																																																																	
Connector Name	AIR ACTUATOR AND ELECTRIC UNIT (DASH/ROOF INT)																																																																																																																																																																																																																																																	
Connector Type	BAAA2FB-AHZL-LH																																																																																																																																																																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	W	-																																																																																																																																																																																																																																																
2	GR	-																																																																																																																																																																																																																																																
3	GR	-																																																																																																																																																																																																																																																
4	G	-																																																																																																																																																																																																																																																
5	GR	-																																																																																																																																																																																																																																																
6	GR	-																																																																																																																																																																																																																																																
7	GR	-																																																																																																																																																																																																																																																
8	GR	-																																																																																																																																																																																																																																																
9	GR	-																																																																																																																																																																																																																																																
10	GR	-																																																																																																																																																																																																																																																
11	GR	-																																																																																																																																																																																																																																																
12	GR	-																																																																																																																																																																																																																																																
13	GR	-																																																																																																																																																																																																																																																
14	GR	-																																																																																																																																																																																																																																																
15	GR	-																																																																																																																																																																																																																																																
16	GR	-																																																																																																																																																																																																																																																
17	GR	-																																																																																																																																																																																																																																																
18	GR	-																																																																																																																																																																																																																																																
19	GR	-																																																																																																																																																																																																																																																
20	GR	-																																																																																																																																																																																																																																																
21	GR	-																																																																																																																																																																																																																																																
22	GR	-																																																																																																																																																																																																																																																
23	GR	-																																																																																																																																																																																																																																																
24	GR	-																																																																																																																																																																																																																																																
25	GR	-																																																																																																																																																																																																																																																
26	GR	-																																																																																																																																																																																																																																																
27	GR	-																																																																																																																																																																																																																																																
28	GR	-																																																																																																																																																																																																																																																
29	GR	-																																																																																																																																																																																																																																																
30	GR	-																																																																																																																																																																																																																																																
31	GR	-																																																																																																																																																																																																																																																
32	GR	-																																																																																																																																																																																																																																																
33	GR	-																																																																																																																																																																																																																																																
34	GR	-																																																																																																																																																																																																																																																
35	GR	-																																																																																																																																																																																																																																																
36	GR	-																																																																																																																																																																																																																																																
37	GR	-																																																																																																																																																																																																																																																
38	GR	-																																																																																																																																																																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
1	W	-																																																																																																																																																																																																																																																
2	GR	-																																																																																																																																																																																																																																																
3	GR	-																																																																																																																																																																																																																																																
4	GR	-																																																																																																																																																																																																																																																
5	GR	-																																																																																																																																																																																																																																																
6	GR	-																																																																																																																																																																																																																																																
7	GR	-																																																																																																																																																																																																																																																
8	GR	-																																																																																																																																																																																																																																																
9	GR	-																																																																																																																																																																																																																																																
10	GR	-																																																																																																																																																																																																																																																
11	GR	-																																																																																																																																																																																																																																																
12	GR	-																																																																																																																																																																																																																																																
13	GR	-																																																																																																																																																																																																																																																
14	GR	-																																																																																																																																																																																																																																																
15	GR	-																																																																																																																																																																																																																																																
16	GR	-																																																																																																																																																																																																																																																
17	GR	-																																																																																																																																																																																																																																																
18	GR	-																																																																																																																																																																																																																																																
19	GR	-																																																																																																																																																																																																																																																
20	GR	-																																																																																																																																																																																																																																																
21	GR	-																																																																																																																																																																																																																																																
22	GR	-																																																																																																																																																																																																																																																
23	GR	-																																																																																																																																																																																																																																																
24	GR	-																																																																																																																																																																																																																																																
25	GR	-																																																																																																																																																																																																																																																
26	GR	-																																																																																																																																																																																																																																																
27	GR	-																																																																																																																																																																																																																																																
28	GR	-																																																																																																																																																																																																																																																
29	GR	-																																																																																																																																																																																																																																																
30	GR	-																																																																																																																																																																																																																																																
31	GR	-																																																																																																																																																																																																																																																
32	GR	-																																																																																																																																																																																																																																																
33	GR	-																																																																																																																																																																																																																																																
34	GR	-																																																																																																																																																																																																																																																
35	GR	-																																																																																																																																																																																																																																																
36	GR	-																																																																																																																																																																																																																																																
37	GR	-																																																																																																																																																																																																																																																
38	GR	-																																																																																																																																																																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>E26</td></tr> <tr><td>Connector Name</td><td>FRONT COMBINATION LAMP RH</td></tr> <tr><td>Connector Type</td><td>RS05FB-R/R</td></tr> </table>  	Connector No.	E26	Connector Name	FRONT COMBINATION LAMP RH	Connector Type	RS05FB-R/R	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>B/Y</td><td>-</td></tr> <tr><td>4</td><td>B/W</td><td>-</td></tr> <tr><td>5</td><td>B/G</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>BR</td><td>-</td></tr> <tr><td>8</td><td>P</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	2	B	-	3	B/Y	-	4	B/W	-	5	B/G	-	6	V	-	7	BR	-	8	P	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>B/Y</td><td>-</td></tr> <tr><td>4</td><td>B/W</td><td>-</td></tr> <tr><td>5</td><td>B/G</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>BR</td><td>-</td></tr> <tr><td>8</td><td>P</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	2	B	-	3	B/Y	-	4	B/W	-	5	B/G	-	6	V	-	7	BR	-	8	P	-																																																																																																																																																																																										
Connector No.	E26																																																																																																																																																																																																																																																	
Connector Name	FRONT COMBINATION LAMP RH																																																																																																																																																																																																																																																	
Connector Type	RS05FB-R/R																																																																																																																																																																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
2	B	-																																																																																																																																																																																																																																																
3	B/Y	-																																																																																																																																																																																																																																																
4	B/W	-																																																																																																																																																																																																																																																
5	B/G	-																																																																																																																																																																																																																																																
6	V	-																																																																																																																																																																																																																																																
7	BR	-																																																																																																																																																																																																																																																
8	P	-																																																																																																																																																																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																																																																																																																
2	B	-																																																																																																																																																																																																																																																
3	B/Y	-																																																																																																																																																																																																																																																
4	B/W	-																																																																																																																																																																																																																																																
5	B/G	-																																																																																																																																																																																																																																																
6	V	-																																																																																																																																																																																																																																																
7	BR	-																																																																																																																																																																																																																																																
8	P	-																																																																																																																																																																																																																																																

JRMWF4752GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

BCM (BODY CONTROL MODULE)		Connector No.	Connector Name	Connector Type	Connector No.	Connector Name	Connector Type	Connector No.	Connector Name	Connector Type	
25 Y BUS-L		E58	FRONT COMBINATION LAMP LH	RS208FB-PR	E110	STOP/LAMP SWITCH	MDHFN-IC	F301	IGNITION POWER SUPPLY	SP10FG	
26 LG DIP TL	GR DS RL							1	IGNITION POWER SUPPLY		
27 G UZ	LG DS RR							2	BATTERY POWER SUPPLY		
28 SB BLS	R VDC OFF SW							3	CAN-H		
29 SB CAN-H	L BLS+H							4	K-LINE		
30 BLS	VDC OFF SW							5	GROUND		
31 R CAN-H	B BLS+H							6	IGNITION POWER SUPPLY		
32 SB	CAN-H							7	BACK-UP LAMP RELAY		
33 B BLS+H								8	CAN-L		
34 L BLS+H								9	STARTER RELAY		
35 B BLS+H								10	GROUND		
Connector No. E50		Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	
Connector Name IFC BRAKE HOLD RELAY		2 B	-	1 L	-	2 W	-	1 Y	-	1 A	-
Connector Type M06F0Y-R-US		3 B/Y	-	2 W	-	3 Y	-	2 G	-	2 A	-
		4 B/W	-	3 SB	-	4 SB	-	3 G	-	3 A	-
		5 V	-					4 P	-	4 A	-
		6 G	-					5 P	-	5 A	-
		7 P	-					6 BG	-	6 A	-
		8 BG	-								
Connector No. E51		Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	
Connector Name A/T ASSEMBLY		5 4 3 2 1	-	10 9 8 7 6	-	5 4 3 2 1	-	10 9 8 7 6	-	5 4 3 2 1	-
Connector Type RK10FG-DQY											
Connector No. E52		Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	
Connector Name FUSE BLOCK (J/B)		6F 4F 2F 1F	-	9F 8F	-	6F 4F 2F 1F	-	9F 8F	-	6A 7A 8A 9A	-
Connector Type NS16FW-CS											
Connector No. E57		Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	
Connector Name INTELLIGENT KEY WARNING BUZZER (ENGINE ROOM)		1F SB	-	1F SB	-	2 BR	IGNITION POWER SUPPLY	3 O	CAN-H	4 V	
Connector Type RK010FB-R		2F W	-	2F W	-	5 B	BATTERY POWER SUPPLY	6 Y	K-LINE	7 R	
		4F G	-	4F G	-	6 G	IGNITION POWER SUPPLY	7 R	GROUND	8 G	
		6F BR	-	6F BR	-	7 R	BACK-UP LAMP RELAY	8 G	CAN-L	9 GR	
		8F L	-	8F L	-	9 GR	STARTER RELAY	10 B	GROUND	10 B	
		9F R	-								
Connector No. E58		Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	Signal Name [Specification]	Terminal Color Of Wire No.	
Connector Name INTELLIGENT KEY WARNING BUZZER (ENGINE ROOM)		1 Y	-	1 Y	-	2 V	-	3 R	-	4 A	-
Connector Type RS208FB-PR		3 V	-								

JRMWF4753GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
ADP

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

---

## BCM (BODY CONTROL MODULE)

<table border="1"> <tr><td>Connector No.</td><td>M2</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (&lt; U/E )</td></tr> <tr><td>Connector Type</td><td>NS12FW-CS</td></tr> </table> 	Connector No.	M2	Connector Name	FUSE BLOCK (< U/E )	Connector Type	NS12FW-CS	<table border="1"> <tr><td>Connector No.</td><td>M9</td></tr> <tr><td>Connector Name</td><td>DIODE</td></tr> <tr><td>Connector Type</td><td>24335.C3990</td></tr> </table> 	Connector No.	M9	Connector Name	DIODE	Connector Type	24335.C3990	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	R	-	2	W	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>3</td><td>P</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> <tr><td>5</td><td>BG</td><td>-</td></tr> <tr><td>6</td><td>Y</td><td>-</td></tr> <tr><td>7</td><td>P</td><td>-</td></tr> <tr><td>8</td><td>R</td><td>-</td></tr> <tr><td>9</td><td>SB</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	3	P	-	4	G	-	5	BG	-	6	Y	-	7	P	-	8	R	-	9	SB	-																																																		
Connector No.	M2																																																																																																	
Connector Name	FUSE BLOCK (< U/E )																																																																																																	
Connector Type	NS12FW-CS																																																																																																	
Connector No.	M9																																																																																																	
Connector Name	DIODE																																																																																																	
Connector Type	24335.C3990																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	R	-																																																																																																
2	W	-																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
3	P	-																																																																																																
4	G	-																																																																																																
5	BG	-																																																																																																
6	Y	-																																																																																																
7	P	-																																																																																																
8	R	-																																																																																																
9	SB	-																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>M24</td></tr> <tr><td>Connector Name</td><td>DATA LINK CONNECTOR</td></tr> <tr><td>Connector Type</td><td>BD16W</td></tr> </table> 	Connector No.	M24	Connector Name	DATA LINK CONNECTOR	Connector Type	BD16W	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>LG</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>GR</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> <tr><td>5</td><td>L</td><td>-</td></tr> <tr><td>6</td><td>B</td><td>-</td></tr> <tr><td>7</td><td>V</td><td>-</td></tr> <tr><td>8</td><td>O</td><td>-</td></tr> <tr><td>9</td><td>SB</td><td>-</td></tr> <tr><td>10</td><td>Y</td><td>-</td></tr> <tr><td>11</td><td>P</td><td>-</td></tr> <tr><td>12</td><td>BR</td><td>-</td></tr> <tr><td>13</td><td>RG</td><td>-</td></tr> <tr><td>14</td><td>G</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	LG	-	2	B	-	3	GR	-	4	G	-	5	L	-	6	B	-	7	V	-	8	O	-	9	SB	-	10	Y	-	11	P	-	12	BR	-	13	RG	-	14	G	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>P</td><td>FR WASHER(-)</td></tr> <tr><td>2</td><td>SB</td><td>OUTPUT 4</td></tr> <tr><td>3</td><td>GR</td><td>FR WASHER(+)</td></tr> <tr><td>4</td><td>G</td><td>IGN</td></tr> <tr><td>5</td><td>L</td><td>OUTPUT 3</td></tr> <tr><td>6</td><td>B</td><td>GROUND</td></tr> <tr><td>7</td><td>V</td><td>INPUT 3</td></tr> <tr><td>8</td><td>O</td><td>INPUT 5</td></tr> <tr><td>9</td><td>SB</td><td>INPUT 2</td></tr> <tr><td>10</td><td>Y</td><td>INPUT 4</td></tr> <tr><td>11</td><td>P</td><td>INPUT 1</td></tr> <tr><td>12</td><td>BR</td><td>INPUT 5</td></tr> <tr><td>13</td><td>RG</td><td>OUTPUT 2</td></tr> <tr><td>14</td><td>G</td><td>OUTPUT 1</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	P	FR WASHER(-)	2	SB	OUTPUT 4	3	GR	FR WASHER(+)	4	G	IGN	5	L	OUTPUT 3	6	B	GROUND	7	V	INPUT 3	8	O	INPUT 5	9	SB	INPUT 2	10	Y	INPUT 4	11	P	INPUT 1	12	BR	INPUT 5	13	RG	OUTPUT 2	14	G	OUTPUT 1
Connector No.	M24																																																																																																	
Connector Name	DATA LINK CONNECTOR																																																																																																	
Connector Type	BD16W																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	LG	-																																																																																																
2	B	-																																																																																																
3	GR	-																																																																																																
4	G	-																																																																																																
5	L	-																																																																																																
6	B	-																																																																																																
7	V	-																																																																																																
8	O	-																																																																																																
9	SB	-																																																																																																
10	Y	-																																																																																																
11	P	-																																																																																																
12	BR	-																																																																																																
13	RG	-																																																																																																
14	G	-																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	P	FR WASHER(-)																																																																																																
2	SB	OUTPUT 4																																																																																																
3	GR	FR WASHER(+)																																																																																																
4	G	IGN																																																																																																
5	L	OUTPUT 3																																																																																																
6	B	GROUND																																																																																																
7	V	INPUT 3																																																																																																
8	O	INPUT 5																																																																																																
9	SB	INPUT 2																																																																																																
10	Y	INPUT 4																																																																																																
11	P	INPUT 1																																																																																																
12	BR	INPUT 5																																																																																																
13	RG	OUTPUT 2																																																																																																
14	G	OUTPUT 1																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>M3</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (&lt; U/E )</td></tr> <tr><td>Connector Type</td><td>NS12FW-CS</td></tr> </table> 	Connector No.	M3	Connector Name	FUSE BLOCK (< U/E )	Connector Type	NS12FW-CS	<table border="1"> <tr><td>Connector No.</td><td>M22</td></tr> <tr><td>Connector Name</td><td>KEY SLOT</td></tr> </table> 	Connector No.	M22	Connector Name	KEY SLOT	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>LG</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>GR</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> <tr><td>5</td><td>L</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>O</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	LG	-	2	B	-	3	GR	-	4	G	-	5	L	-	6	V	-	7	O	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>LG</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>GR</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> <tr><td>5</td><td>L</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>O</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	LG	-	2	B	-	3	GR	-	4	G	-	5	L	-	6	V	-	7	O	-																																					
Connector No.	M3																																																																																																	
Connector Name	FUSE BLOCK (< U/E )																																																																																																	
Connector Type	NS12FW-CS																																																																																																	
Connector No.	M22																																																																																																	
Connector Name	KEY SLOT																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	LG	-																																																																																																
2	B	-																																																																																																
3	GR	-																																																																																																
4	G	-																																																																																																
5	L	-																																																																																																
6	V	-																																																																																																
7	O	-																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	LG	-																																																																																																
2	B	-																																																																																																
3	GR	-																																																																																																
4	G	-																																																																																																
5	L	-																																																																																																
6	V	-																																																																																																
7	O	-																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>M27</td></tr> <tr><td>Connector Name</td><td>FOOT LAMP (DRIVER SIDE)</td></tr> <tr><td>Connector Type</td><td>A02FW</td></tr> </table> 	Connector No.	M27	Connector Name	FOOT LAMP (DRIVER SIDE)	Connector Type	A02FW	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>LG</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>GR</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> <tr><td>5</td><td>L</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>O</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	LG	-	2	B	-	3	GR	-	4	G	-	5	L	-	6	V	-	7	O	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>LG</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>GR</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> <tr><td>5</td><td>L</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>O</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	LG	-	2	B	-	3	GR	-	4	G	-	5	L	-	6	V	-	7	O	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>LG</td><td>-</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>3</td><td>GR</td><td>-</td></tr> <tr><td>4</td><td>G</td><td>-</td></tr> <tr><td>5</td><td>L</td><td>-</td></tr> <tr><td>6</td><td>V</td><td>-</td></tr> <tr><td>7</td><td>O</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	LG	-	2	B	-	3	GR	-	4	G	-	5	L	-	6	V	-	7	O	-																	
Connector No.	M27																																																																																																	
Connector Name	FOOT LAMP (DRIVER SIDE)																																																																																																	
Connector Type	A02FW																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	LG	-																																																																																																
2	B	-																																																																																																
3	GR	-																																																																																																
4	G	-																																																																																																
5	L	-																																																																																																
6	V	-																																																																																																
7	O	-																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	LG	-																																																																																																
2	B	-																																																																																																
3	GR	-																																																																																																
4	G	-																																																																																																
5	L	-																																																																																																
6	V	-																																																																																																
7	O	-																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	LG	-																																																																																																
2	B	-																																																																																																
3	GR	-																																																																																																
4	G	-																																																																																																
5	L	-																																																																																																
6	V	-																																																																																																
7	O	-																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>M50</td></tr> <tr><td>Connector Name</td><td>PUSH-BUTTON IGNITION SWITCH</td></tr> <tr><td>Connector Type</td><td>TKOFFER</td></tr> </table> 	Connector No.	M50	Connector Name	PUSH-BUTTON IGNITION SWITCH	Connector Type	TKOFFER	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>BAT</td></tr> <tr><td>2</td><td>GR</td><td>CLOCK</td></tr> <tr><td>3</td><td>W</td><td>DATA</td></tr> <tr><td>4</td><td>Y</td><td>ILL BAT</td></tr> <tr><td>5</td><td>LG</td><td>KEY SWITCH SIGNAL</td></tr> <tr><td>6</td><td>Y</td><td>GROUND</td></tr> <tr><td>7</td><td>BR</td><td>-</td></tr> <tr><td>11</td><td>BR</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	R	BAT	2	GR	CLOCK	3	W	DATA	4	Y	ILL BAT	5	LG	KEY SWITCH SIGNAL	6	Y	GROUND	7	BR	-	11	BR	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>2</td><td>BR</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	R	-	2	BR	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>B</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> <tr><td>3</td><td>W</td><td>-</td></tr> <tr><td>4</td><td>BR</td><td>-</td></tr> <tr><td>5</td><td>GR</td><td>-</td></tr> <tr><td>6</td><td>Y</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	B	-	2	W	-	3	W	-	4	BR	-	5	GR	-	6	Y	-																																
Connector No.	M50																																																																																																	
Connector Name	PUSH-BUTTON IGNITION SWITCH																																																																																																	
Connector Type	TKOFFER																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	R	BAT																																																																																																
2	GR	CLOCK																																																																																																
3	W	DATA																																																																																																
4	Y	ILL BAT																																																																																																
5	LG	KEY SWITCH SIGNAL																																																																																																
6	Y	GROUND																																																																																																
7	BR	-																																																																																																
11	BR	-																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	R	-																																																																																																
2	BR	-																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	B	-																																																																																																
2	W	-																																																																																																
3	W	-																																																																																																
4	BR	-																																																																																																
5	GR	-																																																																																																
6	Y	-																																																																																																

JRMWF4754GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

## BCM (BODY CONTROL MODULE)

<table border="1"> <tr> <td>7</td><td>V</td><td>-</td></tr> <tr> <td>8</td><td>P</td><td>-</td></tr> </table>	7	V	-	8	P	-	<table border="1"> <tr> <td>Connector No.</td><td>M67</td></tr> <tr> <td>Connector Name</td><td>UNIFIED METER AND A/C AMP.</td></tr> <tr> <td>Connector Type</td><td>TH32FW-NH</td></tr> </table>	Connector No.	M67	Connector Name	UNIFIED METER AND A/C AMP.	Connector Type	TH32FW-NH	<table border="1"> <tr> <td>Connector No.</td><td>M101</td></tr> <tr> <td>Connector Name</td><td>TIRE PRESSURE RECEIVER</td></tr> <tr> <td>Connector Type</td><td>TK04FW</td></tr> </table>	Connector No.	M101	Connector Name	TIRE PRESSURE RECEIVER	Connector Type	TK04FW																																																																																																																																										
7	V	-																																																																																																																																																												
8	P	-																																																																																																																																																												
Connector No.	M67																																																																																																																																																													
Connector Name	UNIFIED METER AND A/C AMP.																																																																																																																																																													
Connector Type	TH32FW-NH																																																																																																																																																													
Connector No.	M101																																																																																																																																																													
Connector Name	TIRE PRESSURE RECEIVER																																																																																																																																																													
Connector Type	TK04FW																																																																																																																																																													
<table border="1"> <tr> <td>Connector No.</td> <td>M53</td> </tr> <tr> <td>Connector Name</td> <td>COMBINATION METER</td> </tr> <tr> <td>Connector Type</td> <td>TH40FN-HH</td> </tr> </table>	Connector No.	M53	Connector Name	COMBINATION METER	Connector Type	TH40FN-HH	<table border="1"> <tr> <td>Connector No.</td> <td>M72</td> </tr> <tr> <td>Connector Name</td> <td>MULTIFUNCTION SWITCH</td> </tr> <tr> <td>Connector Type</td> <td>TH16IW-NH</td> </tr> </table>	Connector No.	M72	Connector Name	MULTIFUNCTION SWITCH	Connector Type	TH16IW-NH	<table border="1"> <tr> <td>Terminal No.</td> <td>Color Of Wire</td> <td>Signal Name [Specification]</td> <td>Terminal No.</td> <td>Color Of Wire</td> <td>Signal Name [Specification]</td> </tr> <tr> <td>41</td> <td>V</td> <td>ACC POWER SUPPLY</td> <td>1</td> <td>B</td> <td>GROUND</td> </tr> <tr> <td>42</td> <td>Y</td> <td>FUEL LEVEL SENSOR SIGNAL</td> <td>3</td> <td>V</td> <td>ACC</td> </tr> <tr> <td>43</td> <td>R</td> <td>INTAKE SENSOR SIGNAL</td> <td>4</td> <td>R</td> <td>ILL.</td> </tr> <tr> <td>44</td> <td>LG</td> <td>IN-VEHICLE SENSOR SIGNAL</td> <td>5</td> <td>Y</td> <td>ILL. CONT.</td> </tr> <tr> <td>45</td> <td>P</td> <td>AMBIENT SENSOR SIGNAL</td> <td>6</td> <td>SB</td> <td>AV COMM.(H)</td> </tr> <tr> <td>46</td> <td>EG</td> <td>SUNROOF SENSOR SIGNAL</td> <td>8</td> <td>LG</td> <td>AV COMM.(L)</td> </tr> <tr> <td>47</td> <td>G</td> <td>EVAPORATOR CANISTER FLOW SENSOR</td> <td>9</td> <td>B</td> <td>SH. GND</td> </tr> <tr> <td>53</td> <td>G</td> <td>IGNITION POWER SUPPLY</td> <td>14</td> <td>Y</td> <td>DISK EJECT. SIGNAL</td> </tr> <tr> <td>54</td> <td>Y</td> <td>BATTERY POWER SUPPLY</td> <td>16</td> <td>G</td> <td>HAZARD ON</td> </tr> <tr> <td>55</td> <td>B</td> <td>CAN-H</td> <td></td> <td></td> <td></td> </tr> <tr> <td>56</td> <td>L</td> <td>BRAKE FLUID LEVEL SWITCH SIGNAL</td> <td></td> <td></td> <td></td> </tr> <tr> <td>57</td> <td>W</td> <td>FUEL LEVEL SENSOR GROUND</td> <td></td> <td></td> <td></td> </tr> <tr> <td>58</td> <td>BR</td> <td>INTAKE AIR FLOW METER GROUND</td> <td></td> <td></td> <td></td> </tr> <tr> <td>59</td> <td>GR</td> <td>OPTICAL SENSOR</td> <td></td> <td></td> <td></td> </tr> <tr> <td>60</td> <td>L</td> <td>IN-VEHICLE SENSOR GROUND</td> <td></td> <td></td> <td></td> </tr> <tr> <td>61</td> <td>BR</td> <td>MATERIAL SENSOR GROUND</td> <td></td> <td></td> <td></td> </tr> <tr> <td>62</td> <td>SB</td> <td>SUNROOF SENSOR GROUND</td> <td></td> <td></td> <td></td> </tr> <tr> <td>63</td> <td>R</td> <td>-</td> <td></td> <td></td> <td></td> </tr> <tr> <td>65</td> <td>EG</td> <td>-</td> <td></td> <td></td> <td></td> </tr> <tr> <td>69</td> <td>L</td> <td>ECU SIGNAL</td> <td></td> <td></td> <td></td> </tr> <tr> <td>70</td> <td>R</td> <td>A/C CLN SIGNAL</td> <td></td> <td></td> <td></td> </tr> <tr> <td>71</td> <td>B</td> <td>EACH DOOR MOTOR POWER SUPPLY GROUND</td> <td></td> <td></td> <td></td> </tr> <tr> <td>72</td> <td>P</td> <td>CAN-L</td> <td></td> <td></td> <td></td> </tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]	41	V	ACC POWER SUPPLY	1	B	GROUND	42	Y	FUEL LEVEL SENSOR SIGNAL	3	V	ACC	43	R	INTAKE SENSOR SIGNAL	4	R	ILL.	44	LG	IN-VEHICLE SENSOR SIGNAL	5	Y	ILL. CONT.	45	P	AMBIENT SENSOR SIGNAL	6	SB	AV COMM.(H)	46	EG	SUNROOF SENSOR SIGNAL	8	LG	AV COMM.(L)	47	G	EVAPORATOR CANISTER FLOW SENSOR	9	B	SH. GND	53	G	IGNITION POWER SUPPLY	14	Y	DISK EJECT. SIGNAL	54	Y	BATTERY POWER SUPPLY	16	G	HAZARD ON	55	B	CAN-H				56	L	BRAKE FLUID LEVEL SWITCH SIGNAL				57	W	FUEL LEVEL SENSOR GROUND				58	BR	INTAKE AIR FLOW METER GROUND				59	GR	OPTICAL SENSOR				60	L	IN-VEHICLE SENSOR GROUND				61	BR	MATERIAL SENSOR GROUND				62	SB	SUNROOF SENSOR GROUND				63	R	-				65	EG	-				69	L	ECU SIGNAL				70	R	A/C CLN SIGNAL				71	B	EACH DOOR MOTOR POWER SUPPLY GROUND				72	P	CAN-L			
Connector No.	M53																																																																																																																																																													
Connector Name	COMBINATION METER																																																																																																																																																													
Connector Type	TH40FN-HH																																																																																																																																																													
Connector No.	M72																																																																																																																																																													
Connector Name	MULTIFUNCTION SWITCH																																																																																																																																																													
Connector Type	TH16IW-NH																																																																																																																																																													
Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																																																																									
41	V	ACC POWER SUPPLY	1	B	GROUND																																																																																																																																																									
42	Y	FUEL LEVEL SENSOR SIGNAL	3	V	ACC																																																																																																																																																									
43	R	INTAKE SENSOR SIGNAL	4	R	ILL.																																																																																																																																																									
44	LG	IN-VEHICLE SENSOR SIGNAL	5	Y	ILL. CONT.																																																																																																																																																									
45	P	AMBIENT SENSOR SIGNAL	6	SB	AV COMM.(H)																																																																																																																																																									
46	EG	SUNROOF SENSOR SIGNAL	8	LG	AV COMM.(L)																																																																																																																																																									
47	G	EVAPORATOR CANISTER FLOW SENSOR	9	B	SH. GND																																																																																																																																																									
53	G	IGNITION POWER SUPPLY	14	Y	DISK EJECT. SIGNAL																																																																																																																																																									
54	Y	BATTERY POWER SUPPLY	16	G	HAZARD ON																																																																																																																																																									
55	B	CAN-H																																																																																																																																																												
56	L	BRAKE FLUID LEVEL SWITCH SIGNAL																																																																																																																																																												
57	W	FUEL LEVEL SENSOR GROUND																																																																																																																																																												
58	BR	INTAKE AIR FLOW METER GROUND																																																																																																																																																												
59	GR	OPTICAL SENSOR																																																																																																																																																												
60	L	IN-VEHICLE SENSOR GROUND																																																																																																																																																												
61	BR	MATERIAL SENSOR GROUND																																																																																																																																																												
62	SB	SUNROOF SENSOR GROUND																																																																																																																																																												
63	R	-																																																																																																																																																												
65	EG	-																																																																																																																																																												
69	L	ECU SIGNAL																																																																																																																																																												
70	R	A/C CLN SIGNAL																																																																																																																																																												
71	B	EACH DOOR MOTOR POWER SUPPLY GROUND																																																																																																																																																												
72	P	CAN-L																																																																																																																																																												

| |    |    |   |   |   |        | |----|----|---|---|---|--------| | 21 | EG | IGNITION SIGNAL                                 | 1 | Y | POWER  | | 22 | B  | COMMUNICATION SIGNAL (LCD->AMP)                 | 2 | P | OUTPUT | | 24 | BR | COMMUNICATION SIGNAL (AMP->LCD)                 | 3 | B | GROUND | | 25 | Y  | VEHICLE SPEED SIGNAL (G-PULSE)                  |   |   |        | | 26 | R  | PARKING BRAKE SWITCH SIGNAL                     |   |   |        | | 27 | V  | BRAKE FLUID LEVEL SWITCH SIGNAL                 |   |   |        | | 29 | SB | SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE) |   |   |        | | 30 | G  | WASHER LEVEL SWITCH SIGNAL (PASSENGER SIDE)     |   |   |        | | 31 | L  | ILLUMINATION CONTROL SIGNAL                     |   |   |        | | 33 | B  | SELECT SWITCH SIGNAL                            |   |   |        | | 36 | G  | ENTER SWITCH SIGNAL                             |   |   |        | | 37 | SB | TRIP A/B RESE. SWITCH SIGNAL                    |   |   |        | | 39 | P  | ILLUMINATION CONTROL SWITCH SIGNAL (-)          |   |   |        | | 40 | BG | ILLUMINATION CONTROL SWITCH SIGNAL (+)          |   |   |        | | |              |               |                             |              |               |                             | |--------------|---------------|-----------------------------|--------------|---------------|-----------------------------| | Terminal No. | Color Of Wire | Signal Name [Specification] | Terminal No. | Color Of Wire | Signal Name [Specification] | | 1            | BG            | GROUND                      | 1            | BG            | GROUND                      | | 2            | Y             | SIGNAL OUTPUT               | 2            | Y             | SIGNAL OUTPUT               | | 4            | LG            | BATTERY                     | 4            | LG            | BATTERY                     | |

JRMWF4755GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

## BCM (BODY CONTROL MODULE)

<table border="1"> <tr><td>Connector No.</td><td>M113</td></tr> <tr><td>Connector Name</td><td>FOOT LAMP (PASSENGER SIDE)</td></tr> <tr><td>Connector Type</td><td>A02EW</td></tr> </table> <p><b>HS.</b></p>	Connector No.	M113	Connector Name	FOOT LAMP (PASSENGER SIDE)	Connector Type	A02EW	<table border="1"> <tr><td>Connector No.</td><td>M119</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>NS16FW-CS</td></tr> </table> <p><b>HS.</b></p>	Connector No.	M119	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	NS16FW-CS	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>R</td><td>INTERIOR ROOM LAMP POWER SUPPLY</td></tr> <tr><td>2</td><td>BR</td><td>-</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	R	INTERIOR ROOM LAMP POWER SUPPLY	2	BR	-	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>4</td><td>LG</td><td>INTERIOR ROOM ANT-</td></tr> <tr><td>5</td><td>L</td><td>PASSENGER DOOR UNLOCK OUTPUT</td></tr> <tr><td>7</td><td>Y</td><td>STEP LAMP CONT</td></tr> <tr><td>8</td><td>Y</td><td>ALL DOOR FUEL IDL LOCK OUTPUT</td></tr> <tr><td>9</td><td>G</td><td>DRIVER DOOR FUEL IDL UNLOCK OUTPUT</td></tr> <tr><td>10</td><td>BR</td><td>REAR DOOR UNLOCK OUTPUT</td></tr> <tr><td>11</td><td>R</td><td>BATT FUSE</td></tr> <tr><td>13</td><td>B</td><td>GROUND</td></tr> <tr><td>14</td><td>W</td><td>PUSH-BUTTON IGNITION SWILL GRID</td></tr> <tr><td>15</td><td>Y</td><td>ACCD IND</td></tr> <tr><td>17</td><td>W</td><td>TURN SIGNAL RH (FRONT)</td></tr> <tr><td>18</td><td>BG</td><td>TURN SIGNAL LH (FRONT)</td></tr> <tr><td>19</td><td>V</td><td>INT ROOM LAMP CONT</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	4	LG	INTERIOR ROOM ANT-	5	L	PASSENGER DOOR UNLOCK OUTPUT	7	Y	STEP LAMP CONT	8	Y	ALL DOOR FUEL IDL LOCK OUTPUT	9	G	DRIVER DOOR FUEL IDL UNLOCK OUTPUT	10	BR	REAR DOOR UNLOCK OUTPUT	11	R	BATT FUSE	13	B	GROUND	14	W	PUSH-BUTTON IGNITION SWILL GRID	15	Y	ACCD IND	17	W	TURN SIGNAL RH (FRONT)	18	BG	TURN SIGNAL LH (FRONT)	19	V	INT ROOM LAMP CONT																																
Connector No.	M113																																																																																																	
Connector Name	FOOT LAMP (PASSENGER SIDE)																																																																																																	
Connector Type	A02EW																																																																																																	
Connector No.	M119																																																																																																	
Connector Name	BCM (BODY CONTROL MODULE)																																																																																																	
Connector Type	NS16FW-CS																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	R	INTERIOR ROOM LAMP POWER SUPPLY																																																																																																
2	BR	-																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
4	LG	INTERIOR ROOM ANT-																																																																																																
5	L	PASSENGER DOOR UNLOCK OUTPUT																																																																																																
7	Y	STEP LAMP CONT																																																																																																
8	Y	ALL DOOR FUEL IDL LOCK OUTPUT																																																																																																
9	G	DRIVER DOOR FUEL IDL UNLOCK OUTPUT																																																																																																
10	BR	REAR DOOR UNLOCK OUTPUT																																																																																																
11	R	BATT FUSE																																																																																																
13	B	GROUND																																																																																																
14	W	PUSH-BUTTON IGNITION SWILL GRID																																																																																																
15	Y	ACCD IND																																																																																																
17	W	TURN SIGNAL RH (FRONT)																																																																																																
18	BG	TURN SIGNAL LH (FRONT)																																																																																																
19	V	INT ROOM LAMP CONT																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>M120</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>NS12FW-CS</td></tr> </table> <p><b>HS.</b></p>	Connector No.	M120	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	NS12FW-CS	<table border="1"> <tr><td>Connector No.</td><td>M122</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>TH10FB-NH1</td></tr> </table> <p><b>HS.</b></p>	Connector No.	M122	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	TH10FB-NH1	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>W</td><td>BAT (F-L)</td></tr> <tr><td>2</td><td>W</td><td>POWER WINDOW POWER SUPPLY(+)</td></tr> <tr><td>3</td><td>Y</td><td>POWER WINDOW POWER SUPPLY(-)</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	W	BAT (F-L)	2	W	POWER WINDOW POWER SUPPLY(+)	3	Y	POWER WINDOW POWER SUPPLY(-)	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>20</td><td>V</td><td>TURN SIGNAL RH (REAR)</td></tr> <tr><td>23</td><td>G</td><td>BACK DOOR OPEN OUTPUT</td></tr> <tr><td>25</td><td>G</td><td>TURN SIGNAL LH (REAR)</td></tr> <tr><td>26</td><td>G</td><td>REAR WIPER OUTPUT</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	20	V	TURN SIGNAL RH (REAR)	23	G	BACK DOOR OPEN OUTPUT	25	G	TURN SIGNAL LH (REAR)	26	G	REAR WIPER OUTPUT																																																								
Connector No.	M120																																																																																																	
Connector Name	BCM (BODY CONTROL MODULE)																																																																																																	
Connector Type	NS12FW-CS																																																																																																	
Connector No.	M122																																																																																																	
Connector Name	BCM (BODY CONTROL MODULE)																																																																																																	
Connector Type	TH10FB-NH1																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	W	BAT (F-L)																																																																																																
2	W	POWER WINDOW POWER SUPPLY(+)																																																																																																
3	Y	POWER WINDOW POWER SUPPLY(-)																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
20	V	TURN SIGNAL RH (REAR)																																																																																																
23	G	BACK DOOR OPEN OUTPUT																																																																																																
25	G	TURN SIGNAL LH (REAR)																																																																																																
26	G	REAR WIPER OUTPUT																																																																																																
<table border="1"> <tr><td>Connector No.</td><td>M123</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Type</td><td>TH14DFG-E-HH</td></tr> </table> <p><b>HS.</b></p>	Connector No.	M123	Connector Name	BCM (BODY CONTROL MODULE)	Connector Type	TH14DFG-E-HH	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>GR</td><td>NATS ANT AMP</td></tr> <tr><td>2</td><td>W</td><td>NATS ANT AMP</td></tr> <tr><td>3</td><td>R</td><td>HIGH RELAY (F/B) CONT</td></tr> <tr><td>4</td><td>Y</td><td>KEYLESS ENTRY RECEIVER COMM</td></tr> <tr><td>5</td><td>BR</td><td>COMBI SW INPUT 5</td></tr> <tr><td>6</td><td>V</td><td>COMBI SW INPUT 3</td></tr> <tr><td>7</td><td>P</td><td>CAN-L</td></tr> <tr><td>8</td><td>V</td><td>CAN-H</td></tr> <tr><td>9</td><td>Y</td><td>KEY SLOT TILT CONT</td></tr> <tr><td>10</td><td>Y</td><td>ON IND</td></tr> <tr><td>11</td><td>L</td><td>PUDLE LAMP CONT</td></tr> <tr><td>12</td><td>LG</td><td>ACC RELAY CONT</td></tr> <tr><td>13</td><td>Y</td><td>A/T SHIFT SELECTOR POWER SUPPLY</td></tr> <tr><td>14</td><td>R</td><td>SHFT P</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	1	GR	NATS ANT AMP	2	W	NATS ANT AMP	3	R	HIGH RELAY (F/B) CONT	4	Y	KEYLESS ENTRY RECEIVER COMM	5	BR	COMBI SW INPUT 5	6	V	COMBI SW INPUT 3	7	P	CAN-L	8	V	CAN-H	9	Y	KEY SLOT TILT CONT	10	Y	ON IND	11	L	PUDLE LAMP CONT	12	LG	ACC RELAY CONT	13	Y	A/T SHIFT SELECTOR POWER SUPPLY	14	R	SHFT P	<table border="1"> <tr><td>Terminal No.</td><td>Color Of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>15</td><td>SB</td><td>PASSENGER DOOR REQUEST SW</td></tr> <tr><td>16</td><td>SB</td><td>DRIVER DOOR REQUEST SW</td></tr> <tr><td>17</td><td>LG</td><td>BLOWER FAN MOTOR RELAY CONT</td></tr> <tr><td>18</td><td>LG</td><td>KEYLESS ENTRY RECEIVER POWER SUPPLY</td></tr> <tr><td>19</td><td>LG</td><td>COMBI SW INPUT 4</td></tr> <tr><td>20</td><td>LG</td><td>STARTER RELAY CONT</td></tr> <tr><td>21</td><td>BR</td><td>FUSI SH</td></tr> <tr><td>22</td><td>W</td><td>BACK DOOR OPERATOR REQUEST SW</td></tr> <tr><td>23</td><td>V</td><td>I-KEY WIPER BUZZER (ENG ROOM)</td></tr> <tr><td>24</td><td>BR</td><td>REAR WIPER STOP POSITION</td></tr> <tr><td>25</td><td>R</td><td>BACK DOOR SW</td></tr> <tr><td>26</td><td>BR</td><td>BACK DOOR OPERNER SW</td></tr> <tr><td>27</td><td>BR</td><td>REAR RH DOOR SW</td></tr> <tr><td>28</td><td>R</td><td>REAR LH DOOR SW</td></tr> </table>	Terminal No.	Color Of Wire	Signal Name [Specification]	15	SB	PASSENGER DOOR REQUEST SW	16	SB	DRIVER DOOR REQUEST SW	17	LG	BLOWER FAN MOTOR RELAY CONT	18	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY	19	LG	COMBI SW INPUT 4	20	LG	STARTER RELAY CONT	21	BR	FUSI SH	22	W	BACK DOOR OPERATOR REQUEST SW	23	V	I-KEY WIPER BUZZER (ENG ROOM)	24	BR	REAR WIPER STOP POSITION	25	R	BACK DOOR SW	26	BR	BACK DOOR OPERNER SW	27	BR	REAR RH DOOR SW	28	R	REAR LH DOOR SW
Connector No.	M123																																																																																																	
Connector Name	BCM (BODY CONTROL MODULE)																																																																																																	
Connector Type	TH14DFG-E-HH																																																																																																	
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
1	GR	NATS ANT AMP																																																																																																
2	W	NATS ANT AMP																																																																																																
3	R	HIGH RELAY (F/B) CONT																																																																																																
4	Y	KEYLESS ENTRY RECEIVER COMM																																																																																																
5	BR	COMBI SW INPUT 5																																																																																																
6	V	COMBI SW INPUT 3																																																																																																
7	P	CAN-L																																																																																																
8	V	CAN-H																																																																																																
9	Y	KEY SLOT TILT CONT																																																																																																
10	Y	ON IND																																																																																																
11	L	PUDLE LAMP CONT																																																																																																
12	LG	ACC RELAY CONT																																																																																																
13	Y	A/T SHIFT SELECTOR POWER SUPPLY																																																																																																
14	R	SHFT P																																																																																																
Terminal No.	Color Of Wire	Signal Name [Specification]																																																																																																
15	SB	PASSENGER DOOR REQUEST SW																																																																																																
16	SB	DRIVER DOOR REQUEST SW																																																																																																
17	LG	BLOWER FAN MOTOR RELAY CONT																																																																																																
18	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY																																																																																																
19	LG	COMBI SW INPUT 4																																																																																																
20	LG	STARTER RELAY CONT																																																																																																
21	BR	FUSI SH																																																																																																
22	W	BACK DOOR OPERATOR REQUEST SW																																																																																																
23	V	I-KEY WIPER BUZZER (ENG ROOM)																																																																																																
24	BR	REAR WIPER STOP POSITION																																																																																																
25	R	BACK DOOR SW																																																																																																
26	BR	BACK DOOR OPERNER SW																																																																																																
27	BR	REAR RH DOOR SW																																																																																																
28	R	REAR LH DOOR SW																																																																																																

JRMWF4756GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**ADP**

## BCM (BODY CONTROL MODULE)

Connector No.	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
M129	OPTION CONNECTOR (1)	1 W	—
	CONNECTOR NAME THBMW-NH	2 V	—
	CONNECTOR TYPE RKOZFY	3 L	—
		4 B	—
		5 G	—
		6 R	—
		7 SB	—
		9 B	—
		10 GR	—
		11 R	—

Connector No.	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
M130	L SHIFT IN P	1 G	—
	G SECURITY IND LAMP CONT	2 R	—
	P COMBI SW OUTPUT 1	3 —	—
	COMBI SW OUTPUT 2	4 —	—
	COMBI SW OUTPUT 3	5 —	—
	COMBI SW OUTPUT 4	6 —	—
	SB DINNER DOOR SW	7 —	—
	LG REAR WINDOW DEFROGGER RELAY CONT	8 —	—
	G —	9 —	—
		10 —	—
		11 —	—

Connector No.	Signal Name [Specification]	Terminal Color Of Wire	Signal Name [Specification]
M131	INSIDE KEY ANTENNA (INSTRUMENT CENTER)	1 BR	—
	CONNECTOR TYPE RKOZFY	2 Y	—
		3 —	—
		4 —	—
		5 —	—
		6 —	—
		7 —	—
		8 —	—
		9 —	—
		10 —	—
		11 —	—
		12 —	—

JRMWF4757GB

INFOID:0000000011067199

## Fail-safe

### FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent • Starter control relay signal • Starter relay status signal
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent • Starter motor relay control signal • Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled • Power position changes to ACC • Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization

## REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

### Condition of cancellation

1. More than 1 minute is passed after the rear wiper stops.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

## DTC Inspection Priority Chart

INFOID:000000011067200

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> <li>• U1000: CAN COMM CIRCUIT</li> <li>• U1010: CONTROL UNIT (CAN)</li> </ul>
3	<ul style="list-style-type: none"> <li>• B2190: NATS ANTENNA AMP</li> <li>• B2191: DIFFERENCE OF KEY</li> <li>• B2192: ID DISCORD BCM-ECM</li> <li>• B2193: CHAIN OF BCM-ECM</li> <li>• B2195: ANTI SCANNING</li> </ul>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Priority	DTC	
4	<ul style="list-style-type: none"> <li>• B2553: IGNITION RELAY</li> <li>• B2555: STOP LAMP</li> <li>• B2556: PUSH-BTN IGN SW</li> <li>• B2557: VEHICLE SPEED</li> <li>• B2560: STARTER CONT RELAY</li> <li>• B2601: SHIFT POSITION</li> <li>• B2602: SHIFT POSITION</li> <li>• B2603: SHIFT POSI STATUS</li> <li>• B2604: PNP SW</li> <li>• B2605: PNP SW</li> <li>• B2608: STARTER RELAY</li> <li>• B260A: IGNITION RELAY</li> <li>• B260F: ENG STATE SIG LOST</li> <li>• B2614: ACC RELAY CIRC</li> <li>• B2615: BLOWER RELAY CIRC</li> <li>• B2616: IGN RELAY CIRC</li> <li>• B2617: STARTER RELAY CIRC</li> <li>• B2618: BCM</li> <li>• B261A: PUSH-BTN IGN SW</li> <li>• B261E: VEHICLE TYPE</li> <li>• B26EA: KEY REGISTRATION</li> <li>• C1729: VHCL SPEED SIG ERR</li> <li>• U0415: VEHICLE SPEED SIG</li> </ul>	A B C D E F G
5	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1716: [PRESSDATA ERR] FL</li> <li>• C1717: [PRESSDATA ERR] FR</li> <li>• C1718: [PRESSDATA ERR] RR</li> <li>• C1719: [PRESSDATA ERR] RL</li> <li>• C1734: CONTROL UNIT</li> </ul>	H I ADP
6	<ul style="list-style-type: none"> <li>• B2621: INSIDE ANTENNA</li> <li>• B2623: INSIDE ANTENNA</li> </ul>	K L M N O P

## DTC Index

INFOID:000000011067201

### NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-19. "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)".](#)

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	—	<a href="#">BCS-42</a>
U1010: CONTROL UNIT (CAN)	—	—	—	—	<a href="#">BCS-43</a>
U0415: VEHICLE SPEED SIG	—	—	—	—	<a href="#">BCS-44</a>
B2190: NATS ANTENNA AMP	×	—	—	—	<a href="#">SEC-40</a>

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
B2191: DIFFERENCE OF KEY	×	—	—	—	<a href="#">SEC-43</a>
B2192: ID DISCORD BCM-ECM	×	—	—	—	<a href="#">SEC-44</a>
B2193: CHAIN OF BCM-ECM	×	—	—	—	<a href="#">SEC-45</a>
B2195: ANTI SCANNING	×	—	—	—	<a href="#">SEC-46</a>
B2553: IGNITION RELAY	—	×	—	—	<a href="#">PCS-51</a>
B2555: STOP LAMP	—	×	—	—	<a href="#">SEC-47</a>
B2556: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-49</a>
B2557: VEHICLE SPEED	×	×	×	—	<a href="#">SEC-51</a>
B2560: STARTER CONT RELAY	×	×	×	—	<a href="#">SEC-52</a>
B2562: LOW VOLTAGE	—	×	—	—	<a href="#">BCS-45</a>
B2601: SHIFT POSITION	×	×	×	—	<a href="#">SEC-53</a>
B2602: SHIFT POSITION	×	×	×	—	<a href="#">SEC-56</a>
B2603: SHIFT POSI STATUS	×	×	×	—	<a href="#">SEC-59</a>
B2604: PNP SW	×	×	×	—	<a href="#">SEC-62</a>
B2605: PNP SW	×	×	×	—	<a href="#">SEC-64</a>
B2608: STARTER RELAY	×	×	×	—	<a href="#">SEC-66</a>
B260A: IGNITION RELAY	×	×	×	—	<a href="#">PCS-53</a>
B260F: ENG STATE SIG LOST	×	×	×	—	<a href="#">SEC-68</a>
B2614: ACC RELAY CIRC	—	×	×	—	<a href="#">PCS-55</a>
B2615: BLOWER RELAY CIRC	—	×	×	—	<a href="#">PCS-58</a>
B2616: IGN RELAY CIRC	—	×	×	—	<a href="#">PCS-61</a>
B2617: STARTER RELAY CIRC	×	×	×	—	<a href="#">SEC-71</a>
B2618: BCM	×	×	×	—	<a href="#">PCS-64</a>
B261A: PUSH-BTN IGN SW	—	×	×	—	<a href="#">SEC-73</a>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-76</a>
B2621: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-58</a>
B2623: INSIDE ANTENNA	—	×	—	—	<a href="#">DLK-60</a>
B26E1: ENG STATE NO RES	×	×	×	—	<a href="#">SEC-69</a>
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	—	<a href="#">SEC-70</a>
C1704: LOW PRESSURE FL	—	—	—	×	<a href="#">WT-24</a>
C1705: LOW PRESSURE FR	—	—	—	×	
C1706: LOW PRESSURE RR	—	—	—	×	
C1707: LOW PRESSURE RL	—	—	—	×	
C1708: [NO DATA] FL	—	—	—	×	<a href="#">WT-26</a>
C1709: [NO DATA] FR	—	—	—	×	
C1710: [NO DATA] RR	—	—	—	×	
C1711: [NO DATA] RL	—	—	—	×	

## BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS INFORMATION >**

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
C1716: [PRESSDATA ERR] FL	—	—	—	×	<a href="#">WT-29</a>
C1717: [PRESSDATA ERR] FR	—	—	—	×	
C1718: [PRESSDATA ERR] RR	—	—	—	×	
C1719: [PRESSDATA ERR] RL	—	—	—	×	
C1729: VHCL SPEED SIG ERR	—	—	—	×	<a href="#">WT-31</a>
C1734: CONTROL UNIT	—	—	—	×	<a href="#">WT-33</a>

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

MANUAL FUNCTION DOES NOT OPERATE

ALL COMPONENT

ALL COMPONENT : Diagnosis Procedure

INFOID:0000000010596475

### 1. CHECK DRIVER SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check driver seat control unit power supply and ground circuit.

Refer to [ADP-56, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

### 2. CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check automatic drive positioner control unit power supply and ground circuit.

Refer to [ADP-57, "AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## POWER SEAT

POWER SEAT : Diagnosis Procedure

INFOID:0000000010596476

### 1. CHECK POWER SEAT SWITCH GROUND CIRCUIT

Check power seat switch ground circuit.

Refer to [ADP-79, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## STEERING POSITION FUNCTION DOES NOT OPERATE

STEERING POSITION FUNCTION DOES NOT OPERATE : Diagnosis Procedure

INFOID:0000000010596477

### 1. CHECK TILT & TELESCOPIC SWITCH GROUND CIRCUIT

Check tilt & telescopic switch ground circuit.

Refer to [ADP-80, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

### 2. CONFIRM THE OPERATION

# MANUAL FUNCTION DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

Confirm the operation again.

### Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## SEAT SLIDING

### SEAT SLIDING : Diagnosis Procedure

INFOID:000000010596478

#### 1.CHECK SLIDING MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

#### 2.CHECK SLIDING SWITCH

Check sliding switch.

Refer to [ADP-59, "Component Function Check"](#).

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

#### 3.CHECK SLIDING MOTOR

Check sliding motor.

Refer to [ADP-103, "Component Function Check"](#).

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunction parts.

#### 4.CONFIRM THE OPERATION

Check the operation again.

### Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## SEAT RECLINING

### SEAT RECLINING : Diagnosis Procedure

INFOID:000000010596479

#### 1.CHECK RECLINING MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

#### 2.CHECK RECLINING SWITCH

Check reclining switch.

Refer to [ADP-61, "Component Function Check"](#).

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

#### 3.CHECK RECLINING MOTOR

Check reclining motor.

A

B

C

D

E

F

G

H

ADP

K

L

M

N

O

P

# MANUAL FUNCTION DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

Refer to [ADP-105, "Component Function Check"](#).

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunction parts.

## 4.CONFIRM THE OPERATION

Check the operation again.

### Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## SEAT LIFTING (FRONT)

### SEAT LIFTING (FRONT) : Diagnosis Procedure

INFOID:0000000010596480

#### 1.CHECK LIFTING (FRONT) MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

#### 2.CHECK LIFTING SWITCH (FRONT)

Check lifting switch (front).

Refer to [ADP-63, "Component Function Check"](#).

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

#### 3.CHECK LIFTING MOTOR (FRONT)

Check lifting motor (front).

Refer to [ADP-107, "Component Function Check"](#).

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunction parts.

#### 4.CONFIRM THE OPERATION

Check the operation again.

### Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## SEAT LIFTING (REAR)

### SEAT LIFTING (REAR) : Diagnosis Procedure

INFOID:0000000010596481

#### 1.CHECK LIFTING (REAR) MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

#### 2.CHECK LIFTING SWITCH (REAR)

Check lifting switch (rear).

Refer to [ADP-65, "Component Function Check"](#).

# MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

## 3.CHECK LIFTING MOTOR (REAR)

Check lifting motor (rear).

Refer to [ADP-109, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunction parts.

## 4.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## STEERING TILT

### STEERING TILT : Diagnosis Procedure

INFOID:0000000010596482

## 1.CHECK STEERING TILT MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

## 2.CHECK TILT SWITCH

Check tilt switch.

Refer to [ADP-67, "Component Function Check"](#).

ADP

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

## 3.CHECK TILT SENSOR

Check tilt sensor.

Refer to [ADP-93, "Component Function Check"](#).

K

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunction parts.

## 4.CHECK TILT MOTOR

Check tilt motor.

Refer to [ADP-111, "Component Function Check"](#).

L

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunction parts.

M

## 5.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

N

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

O

NO >> GO TO 1.

P

## STEERING TELESCOPIC

# MANUAL FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## STEERING TELESCOPIC : Diagnosis Procedure

INFOID:0000000010596483

### 1. CHECK STEERING TELESCOPIC MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

### 2. CHECK TELESCOPIC SWITCH

Check telescopic switch.

Refer to [ADP-69, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

### 3. CHECK TELESCOPIC SENEOR

Check telescopic sensor.

Refer to [ADP-96, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunction parts.

### 4. CHECK TELESCOPIC MOTOR

Check telescopic motor.

Refer to [ADP-113, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunction parts.

### 5. CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## DOOR MIRROR

### DOOR MIRROR : Diagnosis Procedure

INFOID:0000000010596484

### 1. CHECK DOOR MIRROR MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.
- Interference with other parts because of poor installation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

### 2. CHECK MIRROR SWITCH

Check mirror switch.

Refer to [ADP-76, "MIRROR SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

### 3. CHECK MIRROR MOTOR

# MANUAL FUNCTION DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

Check mirror motor.

Refer to [ADP-115, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunction parts.

## 4. CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## MEMORY FUNCTION DOES NOT OPERATE ALL COMPONENT

### ALL COMPONENT : Diagnosis Procedure

INFOID:0000000010596485

#### 1. CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

#### 2. PERFORM INITIALIZATION AND MEMORY STORING PROCEDURE

1. Perform initialization procedure.

Refer to [ADP-9, "SYSTEM INITIALIZATION : Special Repair Requirement"](#).

2. Perform memory storing procedure.

Refer to [ADP-10, "MEMORY STORING : Special Repair Requirement"](#).

3. Check memory function.

Refer to [ADP-27, "MEMORY FUNCTION : System Description"](#).

Is the inspection result normal?

YES >> Memory function is normal.

NO >> GO TO 3.

#### 3. CHECK SEAT MEMORY SWITCH

Check seat memory switch.

Refer to [ADP-71, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace seat memory switch.

#### 4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## SEAT SLIDING

### SEAT SLIDING : Diagnosis Procedure

INFOID:0000000010596486

#### 1. CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-203, "SEAT SLIDING : Diagnosis Procedure"](#)

#### 2. CHECK SLIDING SENSOR

Check sliding sensor.

Refer to [ADP-81, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

#### 3. CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

# MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> GO TO 1.

## SEAT RECLINING

### SEAT RECLINING : Diagnosis Procedure

INFOID:000000010596487

#### 1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-203, "SEAT RECLINING : Diagnosis Procedure"](#)

#### 2.CHECK RECLINING SENSOR

Check reclining sensor.

Refer to [ADP-84, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

#### 3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## SEAT LIFTING (FRONT)

### SEAT LIFTING (FRONT) : Diagnosis Procedure

INFOID:000000010596488

#### 1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-204, "SEAT LIFTING \(FRONT\) : Diagnosis Procedure"](#)

#### 2.CHECK LIFTING SENSOR (FRONT)

Check lifting sensor (front).

Refer to [ADP-87, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

#### 3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## SEAT LIFTING (REAR)

### SEAT LIFTING (REAR) : Diagnosis Procedure

INFOID:000000010596489

#### 1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-204, "SEAT LIFTING \(REAR\) : Diagnosis Procedure"](#)

A

B

C

D

E

F

G

H

ADP

K

L

M

N

O

P

# MEMORY FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## 2.CHECK LIFTING SENSOR (REAR)

Check lifting sensor (rear).

Refer to [ADP-90, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

## 3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

# STEERING TELESCOPIC

## STEERING TELESCOPIC : Diagnosis Procedure

INFOID:0000000010596490

### 1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-206, "STEERING TELESCOPIC : Diagnosis Procedure"](#).

### 2.CHECK TELESCOPIC SENSOR

Check steering telescopic sensor.

Refer to [ADP-96, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

### 3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

# STEERING TILT

## STEERING TILT : Diagnosis Procedure

INFOID:0000000010596491

### 1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-205, "STEERING TILT : Diagnosis Procedure"](#).

### 2.CHECK TILT SENSOR

Check steering tilt sensor.

Refer to [ADP-93, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

### 3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

# MEMORY FUNCTION DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

## DOOR MIRROR

### DOOR MIRROR : Diagnosis Procedure

INFOID:000000010596492

#### 1.CHECK MANUAL OPERATION

Check manual operation.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [ADP-206, "DOOR MIRROR : Diagnosis Procedure"](#)

#### 2.CHECK MIRROR SENSOR

Check mirror sensor.

Refer to [ADP-99, "DRIVER SIDE : Component Function Check"](#). (Driver side)

Refer to [ADP-100, "PASSENGER SIDE : Component Function Check"](#). (Passenger side)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunction parts.

#### 3.CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# **MEMORY INDICATE DOES NOT OPERATE**

< SYMPTOM DIAGNOSIS >

## **MEMORY INDICATE DOES NOT OPERATE**

### **Diagnosis Procedure**

INFOID:0000000010596493

#### **1.CHECK MEMORY INDICATOR**

Check memory indicator.

Refer to [ADP-118, "Component Function Check".](#)

Is the inspection result normal?

YES    >> GO TO 2.

NO      >> Repair or replace the malfunction parts.

#### **2.CONFIRM THE OPERATION**

Confirm the operation again.

Is the result normal?

YES    >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident".](#)

NO      >> GO TO 1.

# SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## SEAT SYNCHRONIZATION FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000010596494

#### 1. CHECK SYSTEM SETTING

Check system setting.

Refer to [ADP-11, "SYSTEM SETTING : Special Repair Requirement"](#).

Is the inspection result normal?

YES    >> Synchronization function is normal.

NO    >> GO TO 2.

#### 2. CONFIRM THE OPERATION

Check the operation again.

Is the result normal?

YES    >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO    >> GO TO 1.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# ENTRY/EXIT ASSIST FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## ENTRY/EXIT ASSIST FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000010596495

#### 1. CHECK SYSTEM SETTING

1. Check system setting.  
Refer to [ADP-11, "SYSTEM SETTING : Special Repair Requirement"](#).
2. Check the operation.

Is the inspection result normal?

- YES    >> Entry/Exit function is OK.  
NO    >> GO TO 2.

#### 2. PERFORM SYSTEM INITIALIZATION

1. Perform system initialization.  
Refer to [ADP-9, "SYSTEM INITIALIZATION : Special Repair Requirement"](#).
2. Check the operation.

Is the inspection result normal?

- YES    >> Entry/Exit function is OK.  
NO    >> GO TO 3.

#### 3. CHECK FRONT DOOR SWITCH (DRIVER SIDE)

Check front door switch (driver side).

Refer to [DLK-63, "Component Function Check"](#).

Is the inspection result normal?

- YES    >> GO TO 4.  
NO    >> Repair or replace the malfunction parts.

#### 4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES    >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).  
NO    >> GO TO 1.

# INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## INTELLIGENT KEY INTERLOCK FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000010596496

#### 1. CHECK DOOR LOCK FUNCTION

Check door lock function.

Refer to [DLK-7, "Work Flow"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunction parts.

#### 2. PERFORM MEMORY STORING PROCEDURE

1. Perform memory storing procedure.

Refer to [ADP-10, "MEMORY STORING : Special Repair Requirement"](#).

2. Check Intelligent Key interlock function.

Refer to [ADP-39, "INTELLIGENT KEY INTERLOCK FUNCTION : System Description"](#).

Is the inspection result normal?

YES >> Intelligent Key inter lock function is normal.

NO >> Replace driver seat control unit. Refer to [ADP-219, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

## NORMAL OPERATING CONDITION

### Description

INFOID:0000000010596497

The following symptoms are normal operations, and they do not indicate a malfunction.

Symptom	Cause	Action to take	Reference page
Entry/exit assist function does not operate.	No initialization has been performed.	Perform initialization.	<a href="#">ADP-27</a>
	<b>NOTE:</b> The entry/exit assist function are enabled before delivery (initial setting).	Change the settings.	<a href="#">ADP-11</a>
Entry assist function does not operate.	Manual operation with power seat switch was performed after exit assist function execution.	Perform the memory function.	<a href="#">ADP-27</a>
Seat synchronization function does not operate.	Seat synchronization function is disabled. <b>NOTE:</b> The entry/exit assist function are disabled before delivery (initial setting).	Change the settings.	<a href="#">ADP-11</a>
	The synchronization function will not operate if the steering (tilt, telescopic) or the door mirror moves to the operating end while the seat synchronization function is operating.	Perform the memory function or drive the vehicle at more than 7 km/h (4 MPH).	<a href="#">ADP-27</a>
	Seat adjustment load has exceed any of the volumes below. • Seat sliding: 76 mm • Seat reclining: 9.1 degrees • Seat lifting (rear): 20 mm	—	—
Lumbar support does not perform memory operation.	The lumbar support system are controlled independently with no link to the automatic drive positioner system.	—	Lumbar support system: <a href="#">SE-10</a>
Memory function, entry/exit assist function, seat synchronization function, or Intelligent Key interlock function does not operate.	The operating conditions are not fulfilled.	Fulfill the operation conditions.	Memory function: <a href="#">ADP-27</a> Exit assist function: <a href="#">ADP-31</a> Entry assist function: <a href="#">ADP-35</a> Seat synchronization function: <a href="#">ADP-22</a> Intelligent Key interlock function: <a href="#">ADP-39</a>

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010596498

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### Precautions for Removing Battery Terminal

INFOID:0000000011008072

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

#### **NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


#### **NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

#### **NOTE:**

The removal of 12V battery may cause a DTC detection error.



SEF289H

### Service

INFOID:0000000010596499

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.

## PRECAUTIONS

### < PRECAUTION >

- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

### Work

INFOID:0000000010596500

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
  - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.  
Then rub with a soft and dry cloth.
  - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.  
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

# DRIVER SEAT CONTROL UNIT

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### DRIVER SEAT CONTROL UNIT

#### Exploded View

INFOID:0000000010596501

Refer to [SE-129, "Exploded View"](#).

#### Removal and Installation


INFOID:0000000010596502

##### REMOVAL

###### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the driver seat (1). Refer to [SE-132, "Removal and Installation"](#).
2. Remove the mounting bolts (A).
3. Remove driver seat control unit (2).



##### INSTALLATION

Install in the reverse order of removal.

###### CAUTION:

Be sure to clump the harness to the right place.

###### NOTE:

After installing the driver seat, perform additional service when replacing control unit. Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description"](#).

A

B

C

D

E

F

G

H

I

K

L

M

N

O

P

ADP

# AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< REMOVAL AND INSTALLATION >

## AUTOMATIC DRIVE POSITIONER CONTROL UNIT

### Exploded View

INFOID:0000000010596503

Refer to [IP-12, "Exploded View".](#)

### Removal and Installation


INFOID:0000000010596504

#### REMOVAL

##### **CAUTION:**

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the instrument driver lower panel. Refer to [IP-13, "Removal and Installation".](#)
2. Remove the screws (A).
3. Remove automatic drive positioner control unit (1).



#### INSTALLATION

Install in the reverse order of removal.

##### **CAUTION:**

Be sure to clump the harness to the right place.

##### **NOTE:**

After installing the driver seat, perform additional service when removing battery negative terminal. Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description".](#)

# SEAT MEMORY SWITCH

< REMOVAL AND INSTALLATION >

## SEAT MEMORY SWITCH

### Exploded View

INFOID:0000000010596505

Refer to [INT-12, "DRIVER SIDE : Exploded View".](#)

### Removal and Installation

INFOID:0000000010596506


#### REMOVAL

##### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the front door finisher (1). Refer to [INT-12, "DRIVER SIDE : Removal and Installation".](#)
2. Press pawls and remove seat memory switch (2) from front door finisher (1).

 : Pawl



#### INSTALLATION

Install in the reverse order of removal.

##### CAUTION:

Be sure to clump the harness to the right place.

##### NOTE:

After installing the driver seat, perform additional service when removing battery negative terminal. Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description".](#)

ADP

K

L

M

N

O

P

# POWER SEAT SWITCH

< REMOVAL AND INSTALLATION >

## POWER SEAT SWITCH

### Exploded View

INFOID:0000000010596507

Refer to [SE-129, "Exploded View"](#).

### Removal and Installation


INFOID:0000000010596508

#### REMOVAL

##### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat cushion outer finisher (1). Refer to [SE-133, "Disassembly and Assembly"](#).
2. Remove the screws (A).
3. Remove the power seat switch (2) from the seat cushion outer finisher (1).



#### INSTALLATION

Install in the reverse order of removal.

##### CAUTION:

Be sure to clamp the harness to the right place.

##### NOTE:

After installing the driver seat, perform additional service when removing battery negative terminal. Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

# TILT&TELESCOPIC SWITCH

< REMOVAL AND INSTALLATION >

## TILT&TELESCOPIC SWITCH

### Exploded View

INFOID:0000000010596509

Refer to [IP-12, "Exploded View"](#).

### Removal and Installation

INFOID:0000000010596510


#### REMOVAL

##### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the steering column mask (1).  
Refer to [IP-13, "Removal and Installation"](#).
2. Press pawls and remove tilt & telescopic switch (2) from the steering column mask (1).

 : Pawl



JMJIA1467ZZ

#### INSTALLATION

Install in the reverse order of removal.

##### CAUTION:

Be sure to clump the harness to the right place.

##### NOTE:

After installing the driver seat, perform additional service when removing battery negative terminal. Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

ADP

K

L

M

N

O

P