



## GENUINE PARTS

### INSTALLATION INSTRUCTIONS

1. **DESCRIPTION:** First Aid Kit

2. **APPLICATION:** Maxima, Altima, Sentra, Pathfinder, Murano, 350Z Coupe & Roadster, 370Z, Quest (2002 and earlier), Quest (2004 and later), Frontier Crew Cab, Frontier King Cab, Titan Crew Cab, Titan King Cab, Armada, Rogue, Versa, cube

3. **PART NUMBER:** 999M1 ST000

4. **KIT CONTENTS:**

Item	Qty.	Description	Part Number	Service Part Number
A	1	First Aid Kit	059T5FRSTK92	999M1 ST000



A

5. **TOOLS REQUIRED:**

None

6. **INSTALLATION PRECAUTIONS / NOTES:**

**▲ WARNING**

- Install first aid kit per instructions to avoid sliding or shifting.
- In a sudden stop or collision unsecured cargo could cause personal injury.

### 7. INSTALLATION PROCEDURE:

- 350Z: Behind passenger seat in storage compartment with lid closed.
- 370Z: With spare tire
- QUEST (2002 and earlier): Behind rear seat attached to hanging carpet strip on passenger side.
- QUEST (2004 and later): In small storage area on driver's side of third row seating.
- PATHFINDER / MURANO: In rear under floor compartment with lid closed.
- FRONTIER KING CAB:
  - 1) Jump seat option models:
    - a) Remove twist nuts on plastic seat cover for rear seat base on passenger side.
    - b) Place kit in location, replace cover and replace twist bolts.
  - 2) Without Jump seat option:
    - a) Under driver seat behind metal seat brace, with Velcro side down.
- FRONTIER CREW CAB: Behind right rear folding seat back.
- TITAN CREW CAB / KING CAB: Behind rear seat with Velcro towards rear of vehicle.
- ARMADA and Rogue: In rear under floor compartment with lid closed.
- VERSA: In map pockets of front doors.
- cube: In glove box
- ALL VEHICLES WITH TRUNK: Inside trunk with Velcro side down.

**INSTALLATION INSTRUCTIONS – First Aid Kit**