
PRESSURE SW. (FOR AIR COND)
F.I.C.D VALVE (FOR AIR COND.)
MAGNET VALVE
COMPRESSOR RELAY (FOR AIR COND.)
EMERGENCY SWITCT NOT EQUIPPED
ADAPTER
FOR CANADA
INTER LOCK RELAY
SEAT BELT RELAY (A/T ONLY)
WATER TEMP. RELAY (EXCEPT CALIFORNIA)
FUSIBLE LINK
VOLTAGE REGURATOR
CONDENSER
SIDE MARKER LAMP (R.H.)
HEAD LAMP (R.H.)
T/S & PARK LAMP (R.H.)
HORN
FOG LAMP (OPTION)
SHUNT
RESISTOR
FUSIBLE LINK
BODY EARTH
NEUTRAL SW. (M/T ONLY)
BATTERY
(A/T ONLY) KICK DOWN SOLENOID
BACK-UP LAMP SW. (M/T ONLY)
TOP GEAR SW. (EXCEPT CALIFORNIA)(M/T ONLY)
CYLINDER NO.(INJECTOR) DROPPING
FOG LAMP (OPTION)
HORN
T/S & PARK LAMP (L.H.)
HEAD LAMP (L.H.)
SIDE MARKER LAMP (L.H.)
ALTERNATER
INHIBITOR SWITCH (A/T ONLY)
OIL PRESSURE SWITCH
STARTER MOTOR
IGNITION COIL & RESISTOR
TERMINAL BLOCK
DISTRIBUTOR
SPARK PLUGS
CONDENSER
THERMAL TRANSMITTER
VACUUM SW. SOLENOID (M/T ONLY) (FOR CALIFORNIA)
B.C.D.D CUT SOLENOID
MAGNET CLUTCH (FOR AIR COND.)
E.G.R CUT SOLENOID (FOR CALIFORNIA)
(EXCEPT CALIFORNIA)
ENGINE EARTH (M/T ONLY)
WATER TEMPERATURE SW.
ENGINE EARTH
WATER TEMPERATURE SENSOR
THERMOTIME SWITCH
COLD START VALVE
AIR-REGULATOR
THROTTLE VALVE SW.
AIR FLOW METER
CHECKER
AIR FLOW METER
BODY EARTH

WIRING DIAGRA



AM


(U.S.A ONLY)
1 W 2 B PE 3 AMP. ASSY INT. WIPER
DOOR SW. (R.H.)
HORN RELAY
DEFOGGER RELAY
AIR COND. RELAY
IGN. INTER LOCK UNIT(FOR U.S.A.)
ADAPTER HARNESS
(FOR CANADA)
CLOCK
FUSE BOX
CONTROL PANEL ILLUMINATION LAMP
AMP & FUEL GAUGE
GAUGE WATER TEMP & OIL PRESSURE
TACHO METER
SPEEDO METER
RESISTOR (FOR ILLUMI-CONTROL)
THERMO SW. (FOR AIR COND.)
CONTROL SW. (FOR AIR COND.)
FAN SW. (FOR AIR COND.)
RESISTOR (FOR AIR COND.)
FAN MOTOR
FAN SW. (FOR HETER)
RESISTOR (FOR HETER)
STG. LOCK SW.
STOP SW.
COMBINATION SW.
LIGHT
WIPER
WASHER
T/S
BEAM
HORN
TURN SIGNAL FLASHER UNIT
HAZARD FLASHER UNIT
CATALYZER HOLD RELAY (FOR CALIFORNIA)
PARKING BRAKE SW.
ASSIST SEAT SW.
INDICATOR LAMP (A/T ONLY)
FOG LAMP SW. (OPTION)
AUTO ANTENNA SW.
RADIO
REAR DEFOGGER SW.
DEFOGGER WARNING LAMP
SEAT BELT WARNING LAMP
HAZARD SW.
FUEL WARNING LAMP
SWITCHING MODULE (FOR CALIFORNIA)
CATALYZER TEMPERATURE SENSOR (FOR CALIFORNIA)
ASSIST BELT SW.
FLOOR TEMPERATURE RELAY (FOR CALIFORNIA)



NOTE

B — BLACK
W — WHITE
R — RED
G — GREEN
Y — YELLOW
L — BLUE
Lg — LIGHT GREEN
Br — BROWN

Ⓐ AUTOMATIC TRANSMISSION
Ⓜ MANUAL TRANSMISSION
Ⓒ FOR CALIFORNIA
Ⓕ EXCEPT CALIFORNIA
Ⓕⓜ EXCEPT CALIFORNIA MANUAL TRANSMISSION
Ⓚ AIR CONDITIONER
Ⓗ HEATER

SWITCH AND RELAY POSITIONS
1 IGNITION SWITCH IN LOCK (KEY REMOVED)
2 LIGHTING SWITCH WIPER SWITCH IN OFF
3 SEATS UNOCCUPIED
4 DOORS CLOSED
5 TRANSMISSION IN NEUTRAL
6 HAND BRAKE RELEASED

NORMAL OPEN
NORMAL CLOSE