Edition: February 2015	QUICK REFERENCE INDEX		
Revision: June 2015	A GENERAL INFORMATION	GI General Information	
Publication No. SM16E00Z34U0	B ENGINE	EM Engine Mechanical	
		LU Engine Lubrication System	n
		CO Engine Cooling System EC Engine Control System	
		EC Engine Control System FL Fuel System	
		EX Exhaust System	
		STR Starting System	
		ACC Accelerator Control Syste	m
	C ELECTRIC POWER TRAIN	According Common Cycle	
	D TRANSMISSION & DRIVEL		
		TM Transaxle & Transmission	
		DLN Driveline	
		FAX Front Axle RAX Rear Axle	
NISSAN	E CHEDENCION		
IVIDDAIV	E SUSPENSION	FSU Front Suspension RSU Rear Suspension	
370Z		N30 Real Suspension	
0.0 —		WT Road Wheels & Tires	
MODEL Z34 SERIES	F BRAKES	BR Brake System	
		PB Parking Brake System	
		BRC Brake Control System	
	G STEERING	ST Steering System	
		STC Steering Control System	
	H RESTRAINTS	SB Seat Belt	
		SBC Seat Belt Control System	
		SR SRS Airbag	
		SRC SRS Airbag Control Syste	m
	I VENTILATION, HEATER & A		
	CONDITIONER	HA Heater & Air Conditioning	
		HAC Heater & Air Conditioning	Control System
	J BODY INTERIOR	INT Interior	
		IP Instrument Panel SE Seat	
		SE Seat	
	K BODY EXTERIOR, DOORS,	DLK Door & Lock	
	ROOF & VEHICLE SECURI	SEC Security Control System	
		GW Glass & Window System	
		PWC Power Window Control Sy	stem
		RF Roof	<u> </u>
		EXT Exterior	
		BRM Body Repair	
	L DRIVER CONTROLS	MIR Mirrors	
		EXL Exterior Lighting System	
		INL Interior Lighting System	
		WW Wiper & Washer	
		DEF Defogger	
		HRN Horn	
© 2015 NISSAN MOTOR CO.,LTD.			
	M ELECTRICAL & POWER CO		
	INOL	BCS Body Control System	
All Rights Reserved. No part		LAN LAN System	
of this Service Manual may		PCS Power Control System	
be reproduced or stored in a		CHG Charging System PG Power Supply, Ground & 0	Pirouit Elemente
retrieval system, or transmit-	N DRIVER INFORMATION &	PG Power Supply, Ground & (MWI Meter, Warning Lamp & In	
	MULTIMEDIA	WCS Warning Chime System	ulcator
ted in any form, or by any		Warning Chille System	
means, electronic, mechani-		AV Audio, Visual & Navigation	System
cal, recording or otherwise,	O CRUISE CONTROL &	CCS Cruise Control System	
without the prior written per-	DRIVER ASSISTANCE		
mission of NISSAN MOTOR			
mission of NISSAN MOTOR CO., LTD.	P MAINTENANCE	MA Maintenance	

A

B

Ξ

G

M

N

0

P

FOREWORD

This manual contains maintenance and repair procedure for the 2016 NISSAN 370Z.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.

NISSAN MOTOR CO., LTD.



PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals. Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc. Technical Service Information 39001 Sunrise Drive, P.O. Box 9200 Farmington Hills, MI USA 48331 FAX: (248) 488-3880

SERVICE MANUAL: Model: ______ Year: _____ PUBLICATION NO. (Refer to Quick Reference Index): _____ Please describe any Service Manual issues or problems in detail: Page number(s) ______ Note: Please include a copy of each page, marked with your comments. Are the trouble diagnosis procedures logical and easy to use? (circle your answer) NO If no, what page number(s)?_____Note: Please include a copy of each page, marked with your comments. Please describe the issue or problem in detail: Is the organization of the manual clear and easy to follow? (circle your answer) NO Please comment: What information should be included in NISSAN Service Manuals to better support you in servicing or repairing customer vehicles? DATE: _____ YOUR NAME: ____ _____ POSITION: _____ DEALER: _____ DEALER NO.: ____ ADDRESS: ___ _____ STATE/PROV./COUNTRY: _____ ZIP/POSTAL CODE: ____

QUICK REFERENCE CHART 370Z

QUICK REFERENCE CHART 370Z ENGINE TUNE-UP DATA (VQ37VHR)

PFP:00000

ELS0003W

Engine model		VQ37VHR	
Firing order		1-2-3-4-5-6	
Idle speed A/T (In "P" or "N" position M/T (In Neutral position	,	rpm	650 ± 50
Ignition timing (BTDC a A/T (In "P" or "N" positio M/T (In Neutral position	on)		10° ± 5°
Tensions of drive belt			Belt tension is not necessary, as it is automatically adjusted by drive belt auto-tensioner.
Radiater cap relief pres	sure	kPa (kg/cm², psi)	
	Standard		78.2 - 97.8 (0.8 - 1.0, 11 - 14)
Limit			59 (0.6, 9)
Cooling system leakage testing pressure kPa (kg/cm², psi)		kPa (kg/cm², psi)	157 (1.6, 23)
Compression pressure		kPa (kg/cm ² , psi)/200 rpm	
	Standard		1,667 - 2,354 (17 - 24, 242 - 341)
	Minimum		1,226 (12.5, 178)
	Differential limit b	etween cylinders	98 (1.0, 14)
	Make		DENSO
	Standard type		FXE24HR11
Spark plug (Iridium-tipped type)		Standard	1.1 mm (0.043 in)
(maiam appea type)	Gap(Nominal)	Limit (Except for NISMO)	1.4 mm (0.055 in)
		Limit (For NISMO)	1.3 mm (0.051 in)

FRONT WHEEL ALIGNMENT

Except for NISMO

	ltem		Standard
Camber Degree minute (Decimal degree)		Minimum	-1° 25′ (-1.41°)
		Nominal	-0° 40′ (-0.67°)
		Maximum	0° 05′ (0.08°)
		Left and right difference	0° 33′ (0.55°) or less
		Minimum	4° 25′ (4.42°)
Caster		Nominal	5° 10′ (5.17°)
Degree r	minute (Decimal degree)	Maximum	5° 55′ (5.91°)
		Left and right difference	0° 39′ (0.65°) or less
		Minimum	6° 55′ (6.92°)
	nclination minute (Decimal degree)	Nominal	7° 40′ (7.67°)
		Maximum	8° 25′ (8.41°)
		Minimum	Out 1 mm (0.04 in)
	Total toe-in Distance Toe-in	Nominal	In 1 mm (0.04 in)
Too in		Maximum	In 3 mm (0.12 in)
106-111		Minimum	In 0° 04′ (0.07°)
	Toe angle (left wheel or right wheel) Degree minute (Decimal degree)	Nominal	In 0° 05′ (0.08°)
	= -5 (2 - 5	Maximum	In 0° 06′ (0.10°)

Measure value under unladen* conditions.

For NISMO

ltem		Standard	
Camber Degree minute (Decimal degree)		Minimum	-1° 30′ (-1.50°)
		Nominal	-0° 45′ (-0.75°)
		Maximum	0° 00′ (0.00°)
		Left and right difference	0° 33′ (0.55°) or less
		Minimum	4° 30′ (4.50°)
Caster		Nominal	5° 15′ (5.25°)
Degree r	minute (Decimal degree)	Maximum	6° 00′ (6.00°)
		Left and right difference	0° 39′ (0.65°) or less
		Minimum	7° 00′ (7.00°)
	inclination minute (Decimal degree)	Nominal	7° 45′ (7.75°)
Dog.co.	imate (Desimal degree)	Maximum	8° 30′ (8.50°)
		Minimum	In 1 mm (0.04 in)
	Total toe-in Distance Toe-in	Nominal	In 2 mm (0.08 in)
Too in		Maximum	In 3 mm (0.11 in)
106-111		Minimum	In 0° 03′ (0.05°)
	Toe angle (left wheel or right wheel) Degree minute (Decimal Degree)	Nominal	In 0° 05′ (0.08°)
	= -g (= comman 2 cg. cc)	Maximum	In 0° 07′ (0.11°)

Measure value under unladen* conditions.

^{*:} Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

^{*:} Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

REAR WHEEL ALIGNMENT

Except for NISMO

Item		Standard		
Wheel si	ze		18 inch	19 inch
Camber Degree minute (Decimal degree)		Minimum	-2° 10′ (-2.16°)	
		Nominal	-1° 40′ (-1.67°)	
		Maximum	-1° 10′ (-1.17°)	
	Total toe-in Distance	Minimum	In 2.0 mm (0.079 in)	In 2.0 mm (0.079 in)
		Nominal	In 3.8 mm (0.150 in)	In 3.7 mm (0.146 in)
Toe-in		Maximum	In 5.6 mm (0.221 in)	In 5.4 mm (0.213 in)
Toe angle (Left wheel or right wheel) Degree minute (Decimal degree)	Minimum	In 0° 05′ (0.09°)		
	Nominal	In 0° 09′ (0.15°)		
Degree minute (Desimal degree)		Maximum	In 0° 13′ (0.21°)	

Measure value under unladen* conditions.

For NISMO

	Item		Standard
Camber Degree minute (Decimal degree)		Minimum	-2° 10′ (-2.16°)
		Nominal	-1° 40′ (-1.67°)
		Maximum	-1° 10′ (-1.17°)
	Total toe-in Distance Toe-in	Minimum	In 2.0 mm (0.079 in)
		Nominal	In 3.8 mm (0.150 in)
Too-in		Maximum	In 5.6 mm (0.221 in)
106-111		Minimum	In 0° 05′ (0.09°)
	Toe angle (left wheel or right wheel) Degree minute (Decimal degree)	Nominal	In 0° 09′ (0.15°)
	209.00 (200	Maximum	In 0° 13′ (0.21°)

Measure value under unladen* conditions.

BRAKE PEDAL

Unit: mm (in.)

Brake pedal height	171.5 - 181.5 (6.75 - 7.15)
Depressed brake pedal height [Depressing 490 N (50 kg, 110 lb) while turning the engine ON]	124.0 (4.88) or more

^{*:} Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

^{*:} Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

FRONT DISC BRAKE

2 Piston Type	Unit: mm (in.)
---------------	----------------

	Item	Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	26.0 (1.024)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.035 (0.0014)

4 Piston Type Unit: mm (in.)

	Item	Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	30.0 (1.181)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.035 (0.0014)

REAR DISC BRAKE

1 Piston Type Unit: mm (in.)

	Item	Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	14.0 (0.551)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.055 (0.0022)

2 Piston Type Unit: mm (in.)

	Item	Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	18.0 (0.709)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.055 (0.0022)

REFILL CAPACITIES

UNIT		Liter	US measure
Fuel tank		71.9	19 gal
Engine Coolant (With reservoir tank) at MAX level	A/T models	9.1	9-5/8 qt
	M/T models	9.2	9-3/4 qt
Engine oil	Drain and refill		
	With oil filter change	4.9	5-1/8 qt
	Without oil filter change	4.6	4-7/8 qt
	Dry engine (Overhaul)	5.7	6 qt
Transmission	A/T	9.2	9-3/4 qt
	M/T	2.83	6 pt
Final drive	Rear	1.4	3 pt
Power steering system		1.0	1-1/8 qt
Air conditioning system	Compressor oil	0.15	5.07 fl oz
	Refrigerant	0.5 kg	1.1 lb