

QUICK REFERENCE INDEX



A GENERAL INFORMATION	GI General Information
B ENGINE	EM Engine Mechanical
	LU Engine Lubrication System
	CO Engine Cooling System
	EC Engine Control System
	FL Fuel System
	EX Exhaust System
	STR Starting System
C ELECTRIC POWER TRAIN	ACC Accelerator Control System
D TRANSMISSION & DRIVELINE	TM Transaxle & Transmission
	DLN Driveline
	FAX Front Axle
	RAX Rear Axle
E SUSPENSION	FSU Front Suspension
	RSU Rear Suspension
F BRAKES	WT Road Wheels & Tires
	BR Brake System
	PB Parking Brake System
G STEERING	BRC Brake Control System
	ST Steering System
	STC Steering Control System
H RESTRAINTS	SB Seat Belt
	SR SRS Airbag
	SRC SRS Airbag Control System
	VTL Ventilation System
I VENTILATION, HEATER & AIR CONDITIONER	HA Heater & Air Conditioning System
	HAC Heater & Air Conditioning Control System
J BODY INTERIOR	INT Interior
	IP Instrument Panel
	SE Seat
K BODY EXTERIOR, DOORS, ROOF & VEHICLE SECURITY	
	DLK Door & Lock
	SEC Security Control System
	GW Glass & Window System
	PWC Power Window Control System
	RF Roof
	EXT Exterior
BRM Body Repair	
L DRIVER CONTROLS	MIR Mirrors
	EXL Exterior Lighting System
	INL Interior Lighting System
	WW Wiper & Washer
	DEF Defogger
	HRN Horn
M ELECTRICAL & POWER CONTROL	PWO Power Outlet
	BCS Body Control System
	LAN LAN System
	PCS Power Control System
	CHG Charging System
	PG Power Supply, Ground & Circuit Elements
N DRIVER INFORMATION & MULTIMEDIA	MWI Meter, Warning Lamp & Indicator
	WCS Warning Chime System
O CRUISE CONTROL & DRIVER ASSISTANCE	AV Audio, Visual & Navigation System
	CCS Cruise Control System
P MAINTENANCE	MA Maintenance

All Rights Reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, recording or otherwise, without the prior written permission of NISSAN MOTOR CO., LTD.

A

B

D

E

F

G

H

I

J

K

L

M

N

O

P

FOREWORD

This manual contains maintenance and repair procedure for the 2015 INFINITI Q40.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



INFINITI®



PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

INFINITI®

Your comments are important to INFINITI and will help us to improve our Service Manuals.

Use this form to report any issues or comments you may have regarding our Service Manuals.

Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc.
Technical Service Information
39001 Sunrise Drive, P.O. Box 9200
Farmington Hills, MI USA 48331
FAX: (248) 488-3880

SERVICE MANUAL: Model: _____ **Year:** _____

PUBLICATION NO. (Refer to Quick Reference Index): _____

Please describe any Service Manual issues or problems in detail:

Page number(s) _____ *Note: Please include a copy of each page, marked with your comments.*

Are the trouble diagnosis procedures logical and easy to use? (circle your answer) YES NO

If no, what page number(s)? _____ *Note: Please include a copy of each page, marked with your comments.*

Please describe the issue or problem in detail: _____

Is the organization of the manual clear and easy to follow? (circle your answer) YES NO

Please comment: _____

What information should be included in INFINITI Service Manuals to better support you in servicing or repairing customer vehicles?

DATE: _____ YOUR NAME: _____ POSITION: _____

DEALER: _____ DEALER NO.: _____ ADDRESS: _____

CITY: _____ STATE/PROV./COUNTRY: _____ ZIP/POSTAL CODE: _____

QUICK REFERENCE CHART Q40
ENGINE TUNE-UP DATA (VQ37VHR)

PPF:00000

ELS0003W

Engine model		VQ37VHR	
Firing order		1-2-3-4-5-6	
Idle speed A/T (In "P or N" position)	rpm	650 ± 50	
Ignition timing (BTDC at idle speed)		10° ± 5°	
Tension of drive belt		Belt tension is not necessary, as it is automatically adjusted by drive belt auto-tensioner.	
Radiator cap relief pressure	Standard	kPa (kg/cm ² , psi) 122.3 - 151.7 (1.2 - 1.5, 18 - 22)	
	Limit		107 (1.1, 16)
Cooling system leakage testing pressure	kPa (kg/cm ² , psi)	157 (1.6, 23)	
Compression pressure	Standard	kPa (kg/cm ² , psi)/rpm 1,667 - 2,354 (17 - 24, 242 - 341)/200	
	Minimum		1,226 (12.5, 178)/200
	Differential limit between cylinders		98 (1.0, 14)/200
Spark plug (Iridium-tipped type)	Make	DENSO	
	Standard type	FXE24HR11	
	Gap(Nominal)	mm (in) 1.1 (0.043)	

**FRONT WHEEL ALIGNMENT
2WD**

Camber Degree minute (Decimal degree)		Minimum	-1° 05' (-1.08°)
		Nominal	-0° 20' (-0.33°)
		Maximum	0° 25' (0.42°)
		Left and right difference	0° 33' (0.55°) or less
Caster Degree minute (Decimal degree)		Minimum	3° 50' (3.83°)
		Nominal	4° 35' (4.58°)
		Maximum	5° 20' (5.33°)
		Left and right difference	0° 39' (0.65°) or less
Kingpin inclination Degree minute (Decimal degree)		Minimum	6° 35' (6.58°)
		Nominal	7° 20' (7.33°)
		Maximum	8° 05' (8.08°)
Toe-in	Total toe-in Distance	Minimum	Out 1 mm (Out 0.03 in)
		Nominal	In 1 mm (In 0.04 in)
		Maximum	In 3 mm (In 0.11 in)
	Total toe-angle Degree minute (Decimal degree)	Minimum	Out 0° 04' 48" (Out 0.08°)
		Nominal	In 0° 04' 48" (In 0.08°)
		Maximum	In 0° 15' 00" (In 0.25°)

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

AWD

Camber Degree minute (Decimal degree)		Minimum	-1° 10' (-1.16°)
		Nominal	-0° 25' (-0.42°)
		Maximum	0° 20' (0.33°)
		Left and right difference	0° 33' (0.55°) or less
Caster Degree minute (Decimal degree)		Minimum	3° 20' (3.34°)
		Nominal	4° 05' (4.08°)
		Maximum	4° 50' (4.83°)
		Left and right difference	0° 39' (0.65°) or less
Kingpin inclination Degree minute (Decimal degree)		Minimum	6° 40' (6.67°)
		Nominal	7° 25' (7.42°)
		Maximum	8° 10' (8.16°)
Toe-in	Total toe-in Distance	Minimum	Out 1 mm (Out 0.03 in)
		Nominal	In 1 mm (In 0.04 in)
		Maximum	In 3 mm (In 0.11 in)
	Total toe-angle Degree minute (Decimal degree)	Minimum	Out 0° 04' 48" (Out 0.08°)
		Nominal	In 0° 04' 48" (In 0.08°)
		Maximum	In 0° 15' 00" (In 0.25°)

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

REAR WHEEL ALIGNMENT

Applied model			2WD	AWD
Camber Degree minute (Decimal degree)	Minimum		-1° 20' (-1.33°)	-1° 25' (-1.42°)
	Nominal		-0° 50' (-0.83°)	-0° 55' (-0.92°)
	Maximum		-0° 20' (-0.33°)	-0° 25' (-0.42°)
Toe-in	Total toe-in Distance	Minimum	0 mm (0 in)	
		Nominal	In 2.8 mm (0.110 in)	
		Maximum	In 5.6 mm (0.220 in)	
	Total toe-angle Degree minute (Decimal degree)	Minimum	In 0° 00' 00" (In 0.00°)	
		Nominal	In 0° 14' 24" (In 0.24°)	
		Maximum	In 0° 28' 12" (In 0.47°)	

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

BRAKE PEDAL

Unit: mm (in)

Brake pedal height	171.5 - 181.5 (6.75 - 7.15)
Brake pedal reserve height [Depressing 490 N (50 kg, 110 lb) while turning the engine ON]	124.0 (4.88) or more

FRONT DISC BRAKE

Unit: mm (in)

Brake pad	Wear limit thickness	2.0 (0.079)
Disc rotor	Wear limit thickness	26.0 (1.024)

REAR DISC BRAKE

Unit: mm (in)

Brake pad	Wear limit thickness	2.0 (0.079)
Disc rotor	Wear limit thickness	14.0 (0.551)

REFILL CAPACITIES

UNIT		Liter	US measure
Fuel tank		75.6	20 gal
Engine coolant (With reservoir tank) at MAX level	A/T models	8.5	9 qt
Engine oil	Drain and refill		
	With oil filter change	4.9	5-1/8 qt
	Without oil filter change	4.6	4-7/8 qt
	Dry engine (Overhaul)	5.7	6 qt
Transmission		9.2	9-3/4 qt
Transfer		1.0	2-1/8 pt
Final drive	Front	0.65	1-3/8 pt
	Rear	1.4	3 pt
Power steering system		1.0	1-1/8 qt
Air conditioning system	Compressor oil	0.15	5.07 fl oz
	Refrigerant	0.55 kg	1.21 lb