


Edition: November 2009
 Publication No. SM0E-1H36U0



QUICK REFERENCE INDEX

A GENERAL INFORMATION	GI General Information
B ENGINE	EM Engine Mechanical
	LU Engine Lubrication System
	CO Engine Cooling System
	EC Engine Control System
	FL Fuel System
	EX Exhaust System
	STR Starting System
ACC Accelerator Control System	
C HYBRID	
D TRANSMISSION & DRIVE-LINE	CL Clutch
	TM Transaxle & Transmission
	DLN Driveline
	FAX Front Axle
	RAX Rear Axle
E SUSPENSION	FSU Front Suspension
	RSU Rear Suspension
	WT Road Wheels & Tires
F BRAKES	BR Brake System
	PB Parking Brake System
	BRC Brake Control System
G STEERING	ST Steering System
	STC Steering Control System
H RESTRAINTS	SB Seat Belt
	SBC Seat Belt Control System
	SR SRS Airbag
	SRC SRS Airbag Control System
I VENTILATION, HEATER & AIR CONDITIONER	VTL Ventilation System
	HA Heater & Air Conditioning System
J BODY INTERIOR	HAC Heater & Air Conditioning Control System
	INT Interior
K BODY EXTERIOR, DOORS, ROOF & VEHICLE SECURITY	IP Instrument Panel
	SE Seat
	ADP Automatic Drive Positioner
	DLK Door & Lock
	SEC Security Control System
	GW Glass & Window System
	PWC Power Window Control System
	RF Roof
	EXT Exterior
	BRM Body Repair
L DRIVER CONTROLS	MIR Mirrors
	EXL Exterior Lighting System
	INL Interior Lighting System
	WW Wiper & Washer
	DEF Defogger
	HRN Horn
M ELECTRICAL & POWER CONTROL	PWO Power Outlet
	BCS Body Control System
	LAN LAN System
	PCS Power Control System
	CHG Charging System
	PG Power Supply, Ground & Circuit Elements
N DRIVER INFORMATION & MULTIMEDIA	MWI Meter, Warning Lamp & Indicator
	WCS Warning Chime System
	SN Sonar System
	AV Audio, Visual & Navigation System
O CRUISE CONTROL	CCS Cruise Control System
P MAINTENANCE	MA Maintenance

All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, recording or otherwise, without the prior written permission of NISSAN MOTOR CO., LTD.



FOREWORD

This manual contains maintenance and repair procedure for the 2010 INFINITI G37 Convertible.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



INFINITI®

QUICK REFERENCE CHART G37 CONVERTIBLE

PFP:00000

ENGINE TUNE-UP DATA (VQ37VHR)

ELS0003W

Engine model	VQ37VHR		
Firing order	1-2-3-4-5-6		
Idle speed A/T (In "P or N" position) M/T (In Neutral position)	rpm	650 ± 50	
Ignition timing (BTDC at idle speed)	10° ± 5°		
CO% at idle	0.7 - 9.9 % and engine runs smoothly		
Tensions of drive belt	Auto adjustment by auto tensioner		
Radiator cap relief pressure	kPa (kg/cm ² , psi)		
	Standard	122.3 - 151.7 (1.2 - 1.5, 18 - 22)	
	Limit	107 (1.1, 16)	
Cooling system leakage testing pressure	kPa (kg/cm ² , psi)	157 (1.6, 23)	
Compression pressure	kPa (kg/cm ² , psi)/200 rpm		
	Standard	1,667 - 2,354 (17 - 24, 242 - 341)	
	Minimum	1,226 (12.5, 178)	
	Differential limit between cylinders	98 (1.0, 14)	
Spark plug (Iridium-tipped type)	Make	DENSO	
	Standard type	FXE24HR11	
	Gap	Standard	1.1 mm (0.043 in)
		Limit	1.4 mm (0.055 in)

FRONT WHEEL ALIGNMENT

ELS0003X

Wheel size		225/50R18	225/45R19	
Camber Degree minute (Decimal degree)	Minimum	-1° 10' (-1.16°)		
	Nominal	-0° 25' (-0.41°)		
	Maximum	0° 20' (0.33°)		
	Left and right difference	0° 33' (0.55°) or less		
Caster Degree minute (Decimal degree)	Minimum	4° 05' (4.08°)	4° 10' (4.17°)	
	Nominal	4° 50' (4.83°)	4° 55' (4.92°)	
	Maximum	5° 35' (5.58°)	5° 40' (5.66°)	
	Left and right difference	0° 39' (0.65°) or less		
Kingpin inclination Degree minute (Decimal degree)	Minimum	6° 40' (6.67°)		
	Nominal	7° 25' (7.42°)		
	Maximum	8° 10' (8.16°)		
Toe-in	Total toe-in Distance	Minimum	0 mm (0.00 in)	
		Nominal	In 1 mm (0.04 in)	
		Maximum	In 2 mm (0.08 in)	
	Toe-angle (left wheel or right wheel) Degree minute (Decimal degree)	Minimum	0° 00' (0.00°)	
		Nominal	In 0° 03' (0.05°)	
		Maximum	In 0° 05' (0.08°)	

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

REAR WHEEL ALIGNMENT

ELS0003Y

Camber Degree minute (Decimal degree)	Minimum	-1° 50' (-1.84°)		
	Nominal	-1° 20' (-1.33°)		
	Maximum	-0° 50' (-0.83°)		
Toe-in	Total toe-in Distance	Minimum	0 mm (0.00 in)	
		Nominal	In 2.8 mm (0.110 in)	
		Maximum	In 5.6 mm (0.220 in)	
	Toe angle (left wheel or right wheel) Degree minute (Decimal degree)	Minimum	0° 00' (0.00°)	
		Nominal	In 0° 07' (0.12°)	
		Maximum	In 0° 14' (0.23°)	

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

BRAKE PEDAL

Unit: mm (in)

Brake pedal height (H1)	171.5 - 181.5 (6.75 - 7.15)
Depressed brake pedal height (H2) [Depressing 490 N (50 kg, 110 lb) while turning the engine ON]	124.0 (4.88) or more

FRONT DISK BRAKE

1 Piston Type

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
Disc rotor	Wear thickness	30.0 (1.181)
	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.035 (0.0014)

4 Piston Type

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
Disc rotor	Wear thickness	30.0 (1.181)
	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.035 (0.0014)

REAR DISK BRAKE

1 Piston Type

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
Disc rotor	Wear thickness	15.0 (0.591)
	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.055 (0.0022)

2 Piston Type

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
Disc rotor	Wear thickness	18.0 (0.709)
	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.055 (0.0022)

QUICK REFERENCE CHART G37 CONVERTIBLE

2010

REFILL CAPACITIES

ELSS00040

UNIT		Liter	US measure
Fuel tank		75.6	20 gal
Engine Coolant (With reservoir tank) at MAX level	A/T models	8.5	9 qt
	M/T models	8.6	9-1/8 qt
Engine oil	Drain and refill		
	With oil filter change	4.9	5-1/8 qt
	Without oil filter change	4.6	4-7/8 qt
	Dry engine (Overhaul)	5.7	6 qt
Transmission	A/T	9.2	9-3/4 qt
	M/T	2.83	6 pt
Final drive		1.4	3 pt
Power steering system		1.0	1-1/8 qt
Air conditioning system	Compressor oil	0.15	5.07 fl oz
	Refrigerant	0.55 kg	1.21 lb