

FOREWORD

This manual contains maintenance and repair procedure for the 2014 INFINITI Q50.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



INFINITI®



PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

INFINITI®

Your comments are important to INFINITI and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals.

Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc.
Technical Service Information
39001 Sunrise Drive, P.O. Box 9200
Farmington Hills, MI USA 48331
FAX: (248) 488-3880

SERVICE MANUAL: Model: _____ **Year:** _____

PUBLICATION NO. (Refer to Quick Reference Index): _____

Please describe any Service Manual issues or problems in detail:

Page number(s) _____ *Note: Please include a copy of each page, marked with your comments.*

Are the trouble diagnosis procedures logical and easy to use? (circle your answer) YES NO

If no, what page number(s)? _____ *Note: Please include a copy of each page, marked with your comments.*

Please describe the issue or problem in detail: _____

Is the organization of the manual clear and easy to follow? (circle your answer) YES NO

Please comment: _____

What information should be included in INFINITI Service Manuals to better support you in servicing or repairing customer vehicles?

DATE: _____ YOUR NAME: _____ POSITION: _____

DEALER: _____ DEALER NO.: _____ ADDRESS: _____

CITY: _____ STATE/PROV./COUNTRY: _____ ZIP/POSTAL CODE: _____

QUICK REFERENCE CHART Q50

2014

QUICK REFERENCE CHART Q50
ENGINE TUNE-UP DATA (VQ37VHR)

PF0:00000

Engine model		VQ37VHR
Firing order		1-2-3-4-5-6
Idle speed (In "P" or "N" position)	rpm	650 ± 50
Ignition timing (BTDC at idle speed) (In "P" or "N" position)		10° ± 2°
Tensions of drive belt		Belt tension is not necessary, as it is automatically adjusted by drive belt auto-tensioner.
Radiator cap relief pressure	kPa (kg/cm ² , psi)	
	Standard	122.3 - 151.7 (1.2 - 1.5, 18 - 22)
	Limit	107 (1.1, 16)
Cooling system leakage testing pressure	kPa (kg/cm ² , psi)	220 (2.2, 32)
Compression pressure	kPa (kg/cm ² , psi)/rpm	
	Standard	1,667 - 2,354 (17 - 24, 242 - 341)/200
	Minimum	1,226 (12.5, 178)/200
	Differential limit between cylinders	98 (1.0, 14)/200
Spark plug (Iridium-tipped type)	Make	DENSO
	Standard type	FXE24HR11
	Gap (Nominal)	mm (in) 1.1 (0.043)

QUICK REFERENCE CHART Q50

2014

FRONT WHEEL ALIGNMENT 2WD

ELS0003X

Item		Standard		
Suspension type		base	Sports	
Camber Degree minute (Decimal degree)	Minimum	-1° 10' (-1.16°)	-1° 05' (-1.08°)	
	Nominal	-0° 25' (-0.42°)	-0° 20' (-0.33°)	
	Maximum	0° 20' (0.33°)	0° 25' (0.41°)	
	Left and right difference	0° 33' (0.55°) or less		
Caster Degree minute (Decimal degree)	Minimum	3° 20' (3.34°)		
	Nominal	4° 40' (4.62°)		
	Maximum	6° 00' (6.00°)		
	Left and right difference	0° 30' (0.50°) or less		
Kingpin inclination Degree minute (Decimal degree)	Minimum	6° 40' (6.67°)	6° 35' (6.59°)	
	Nominal	7° 25' (7.42°)	7° 20' (7.33°)	
	Maximum	8° 10' (8.16°)	8° 05' (8.08°)	
Toe-in	Total toe-in Distance	Minimum	Out 1 mm (Out 0.03 in)	
		Nominal	In 1 mm (In 0.04 in)	
		Maximum	In 3 mm (In 0.11 in)	
	Total toe-angle Degree minute (Decimal degree)	Minimum	Out 0° 04' 48" (Out 0.08°)	
		Nominal	In 0° 04' 48" (In 0.08°)	
		Maximum	In 0° 14' 24" (In 0.24°)	

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

AWD

Item		Standard		
Camber Degree minute (Decimal degree)	Minimum	-1° 20' (-1.33°)		
	Nominal	-0° 35' (-0.58°)		
	Maximum	0° 10' (0.16°)		
	Left and right difference	0° 30' (0.50°) or less		
Caster Degree minute (Decimal degree)	Minimum	2° 55' (2.92°)		
	Nominal	4° 15' (4.25°)		
	Maximum	5° 35' (5.58°)		
	Left and right difference	0° 30' (0.50°) or less		
Kingpin inclination Degree minute (Decimal degree)	Minimum	6° 45' (6.75°)		
	Nominal	7° 30' (7.50°)		
	Maximum	8° 15' (8.25°)		
Toe-in	Total toe-in Distance	Minimum	Out 1 mm (Out 0.03 in)	
		Nominal	In 1 mm (In 0.04 in)	
		Maximum	In 3 mm (In 0.11 in)	
	Total toe-angle Degree minute (Decimal degree)	Minimum	Out 0° 04' 48" (Out 0.08°)	
		Nominal	In 0° 04' 48" (In 0.08°)	
		Maximum	In 0° 14' 24" (In 0.24°)	

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

QUICK REFERENCE CHART Q50

2014

REAR WHEEL ALIGNMENT

ELS0003Y

Item		Standard	
Camber Degree minute (Decimal degree)	Minimum	-1° 40' (-1.66°)	
	Nominal	-1° 10' (-1.17°)	
	Maximum	-0° 40' (-0.67°)	
Toe-in	Total toe-in Distance	Minimum	0 mm (0 in)
		Nominal	In 2.8 mm (In 0.110 in)
		Maximum	In 5.6 mm (In 0.220 in)
	Total toe-angle Degree minute (Decimal degree)	Minimum	0° 00' (0.00°)
		Nominal	In 0° 14' (In 0.23°)
		Maximum	In 0° 28' (In 0.46°)

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

BRAKE PEDAL

Unit: mm (in)

Item	Standard
Brake pedal height	183.0 - 193.0 (7.20 - 7.60)
Depressed brake pedal height [Depressing 490 N (50 kg, 110 lb) while turning the engine ON]	126.0 (4.96) or more

FRONT DISC BRAKE

2 Piston Type

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	1.5 (0.059)
	Wear thickness	26.0 (1.024)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.035 (0.0014)

4 Piston Type

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	30.0 (1.181)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.035 (0.0014)

QUICK REFERENCE CHART Q50

2014

REAR DISC BRAKE

1 Piston Type

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
Disc rotor	Wear thickness	14.0 (0.551)
	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.055 (0.0022)

2 Piston Type

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
Disc rotor	Wear thickness	18.0 (0.709)
	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.055 (0.0022)

REFILL CAPACITIES

EL500040

UNIT		Liter	US measure
Fuel tank	Except for Mexico	75.6	20 gal
	For Mexico	80.0	21-1/8 gal
Engine coolant (With reservoir tank) at MAX level		10.9	11-4/8 qt
Engine oil	Drain and refill		
	With oil filter change	4.9	5-1/8 qt
	Without oil filter change	4.6	4-7/8 qt
Dry engine (Overhaul)		5.7	6 qt
Transmission		9.2	9-3/4 qt
Transfer		1.0	2-1/8 pt
Final drive	Front	0.65	1-3/8 pt
	Rear	1.05	2-1/4 pt
Power steering system		1.0	1-1/8 qt
Air conditioning system	Compressor oil	0.09	3.04 fl oz
	Refrigerant	0.5 kg	1.1 lb