SECTION **PB** PARKING BRAKE SYSTEM С

CONTENTS

PARKING BRAKE CONTROL	2	
Components	2	
Removal and Installation		
Inspection	2	
Adjustment		

SERVICE DATA AND SPECIFICATIONS (SDS) 4	PB
Drum Brake4	
Parking Brake Control4	
	G

Μ

А

В

D

Е

Н

J


Κ

L

PARKING BRAKE CONTROL


PARKING BRAKE CONTROL

Components



Removal and Installation

- 1. To remove parking brake pedal, remove lower instrument panel on driver side. Refer to <u>IP-10, "INSTRUMENT PANEL ASSEM-BLY"</u>.
- 2. Disconnect parking brake switch electrical connector.
- 3. Remove nuts, slacken off and remove adjusting nut.
- 4. Remove pedal assembly from vehicle and remove front cable from pedal assembly.



Inspection

- 1. Check parking brake pedal assembly for wear or other damage. Replace if necessary.
- 2. Check cables for discontinuity or deterioration. Replace if necessary.
- 3. Check warning lamp and switch. Replace if necessary.
- 4. Check parts at each connection portion and, if found deformed or damaged, replace.

PFP:36010

EFS003G9

EFS003GA


EFS003GB

Adjustment

Pay attention to the following point after adjustment.

- 1. Ensure there is no drag when pedal is released.
- 2. Loosen parking brake cable.
- 3. Depress parking brake pedal fully more than five times.
- 4. Operate control pedal 10 times or more with a full stroke [169 mm (6.6 in)].
- 5. Adjust cable by turning adjusting nut.
- 6. Depress pedal with specified amount of force. Check pedal stroke and ensure smooth operation.

Force: 196 N (20 kg, 44 lb)Number of notchesKA24DE models: 6 - 8VG33E and VG33ER: 7 - 9models



7. Bend warning lamp switch plate. Warning lamp should come on when pedal is depressed "A" notches. It should go off when the pedal is fully released.

Number of "A" notches for : 1 warning lamp actuation G

Е

PΒ

Н

J

Κ

L

Μ

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Drum Brake

PFP:00030

EFS003GD

Unit: mm (in)

Brake model		LT26		LT30	
Lining wear limit	Minimum thickness		1.5 (0.059)		
Drum repair limit	Maximum inner diameter	261.5 (10.30))	296.5 (11.67)	
	Out-of-round limit		0.03 (0.0012)		
Parking Brake (EFS003GE	
Control Type				Unit: notch Pedal	
Control Type Pedal stroke		KA24DE			
	kg, 44 lb)]	KA24DE VG33E and VG33ER		Pedal	
Pedal stroke				Pedal 6 - 8	