

EDITION: NOVEMBER 2000  
REVISION: DECEMBER 2001  
PUBLICATION NO. SM2E-1P11U1



**INFINITI**®  
**G20**  
**MODEL P11 SERIES**



**INFINITI**®

© 2001 NISSAN MOTOR CO., LTD.

All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Nissan Motor Company Ltd., Tokyo, Japan.

## QUICK REFERENCE INDEX

<b>GENERAL INFORMATION</b> _____	<b>GI</b>
<b>MAINTENANCE</b> _____	<b>MA</b>
<b>ENGINE MECHANICAL</b> _____	<b>EM</b>
<b>ENGINE LUBRICATION &amp; COOLING SYSTEMS</b> _____	<b>LC</b>
<b>ENGINE CONTROL SYSTEM</b> _____	<b>EC</b>
<b>ACCELERATOR CONTROL, FUEL &amp; EXHAUST SYSTEMS</b> _____	<b>FE</b>
<b>CLUTCH</b> _____	<b>CL</b>
<b>MANUAL TRANSAXLE</b> _____	<b>MT</b>
<b>AUTOMATIC TRANSAXLE</b> _____	<b>AT</b>
<b>FRONT &amp; REAR AXLE</b> _____	<b>AX</b>
<b>FRONT &amp; REAR SUSPENSION</b> _____	<b>SU</b>
<b>BRAKE SYSTEM</b> _____	<b>BR</b>
<b>STEERING SYSTEM</b> _____	<b>ST</b>
<b>RESTRAINT SYSTEM</b> _____	<b>RS</b>
<b>BODY &amp; TRIM</b> _____	<b>BT</b>
<b>HEATER &amp; AIR CONDITIONER</b> _____	<b>HA</b>
<b>STARTING &amp; CHARGING SYSTEM</b> _____	<b>SC</b>
<b>ELECTRICAL SYSTEM</b> _____	<b>EL</b>
<b>ALPHABETICAL INDEX</b> _____	<b>IDX</b>

# FOREWORD

---

This manual contains maintenance and repair procedures for the 2002 INFINITI G20.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

---

## IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by INFINITI must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



INFINITI®



NISSAN MOTOR CO., LTD.

Overseas Service Department

Tokyo, Japan



**PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!**

**INFINITI**®

Your comments are important to INFINITI and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals. Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc.  
Technical Service Information  
39001 Sunrise Drive, P.O. Box 9200  
Farmington Hills, MI USA 48331  
FAX: (248) 488-3910

**SERVICE MANUAL: Model:** \_\_\_\_\_ **Year:** \_\_\_\_\_

**PUBLICATION NO. (Please photocopy back cover):** \_\_\_\_\_

**VEHICLE INFORMATION VIN:** \_\_\_\_\_ **Production Date:** \_\_\_\_\_

Please describe any issues or problems in detail:

Page number(s) \_\_\_\_\_ *Note: Please include a copy of each page, marked with your comments.*

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**Are the trouble diagnosis procedures logical and easy to use? (circle your answer) YES NO**

If no, what page number(s)? \_\_\_\_\_ *Note: Please include a copy of each page, marked with your comments.*

Please describe the issue or problem in detail: \_\_\_\_\_

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**Is the organization of the manual clear and easy to follow? (circle your answer) YES NO**

Please comment: \_\_\_\_\_

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**What information should be included in INFINITI Service Manuals to better support you in servicing or repairing customer vehicles?**

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**DATE:** \_\_\_\_\_ **YOUR NAME:** \_\_\_\_\_ **POSITION:** \_\_\_\_\_

**DEALER:** \_\_\_\_\_ **DEALER NO.:** \_\_\_\_\_ **ADDRESS:** \_\_\_\_\_

**CITY:** \_\_\_\_\_ **STATE/PROV./COUNTRY:** \_\_\_\_\_ **ZIP/POSTAL CODE:** \_\_\_\_\_

## INCH TO METRIC CONVERSION TABLE

(Rounded-off for automotive use)

inches	mm	inches	mm
.100	<b>2.54</b>	.610	<b>15.49</b>
.110	<b>2.79</b>	.620	<b>15.75</b>
.120	<b>3.05</b>	.630	<b>16.00</b>
.130	<b>3.30</b>	.640	<b>16.26</b>
.140	<b>3.56</b>	.650	<b>16.51</b>
.150	<b>3.81</b>	.660	<b>16.76</b>
.160	<b>4.06</b>	.670	<b>17.02</b>
.170	<b>4.32</b>	.680	<b>17.27</b>
.180	<b>4.57</b>	.690	<b>17.53</b>
.190	<b>4.83</b>	.700	<b>17.78</b>
.200	<b>5.08</b>	.710	<b>18.03</b>
.210	<b>5.33</b>	.720	<b>18.29</b>
.220	<b>5.59</b>	.730	<b>18.54</b>
.230	<b>5.84</b>	.740	<b>18.80</b>
.240	<b>6.10</b>	.750	<b>19.05</b>
.250	<b>6.35</b>	.760	<b>19.30</b>
.260	<b>6.60</b>	.770	<b>19.56</b>
.270	<b>6.86</b>	.780	<b>19.81</b>
.280	<b>7.11</b>	.790	<b>20.07</b>
.290	<b>7.37</b>	.800	<b>20.32</b>
.300	<b>7.62</b>	.810	<b>20.57</b>
.310	<b>7.87</b>	.820	<b>20.83</b>
.320	<b>8.13</b>	.830	<b>21.08</b>
.330	<b>8.38</b>	.840	<b>21.34</b>
.340	<b>8.64</b>	.850	<b>21.59</b>
.350	<b>8.89</b>	.860	<b>21.84</b>
.360	<b>9.14</b>	.870	<b>22.10</b>
.370	<b>9.40</b>	.880	<b>22.35</b>
.380	<b>9.65</b>	.890	<b>22.61</b>
.390	<b>9.91</b>	.900	<b>22.86</b>
.400	<b>10.16</b>	.910	<b>23.11</b>
.410	<b>10.41</b>	.920	<b>23.37</b>
.420	<b>10.67</b>	.930	<b>23.62</b>
.430	<b>10.92</b>	.940	<b>23.88</b>
.440	<b>11.18</b>	.950	<b>24.13</b>
.450	<b>11.43</b>	.960	<b>24.38</b>
.460	<b>11.68</b>	.970	<b>24.64</b>
.470	<b>11.94</b>	.980	<b>24.89</b>
.480	<b>12.19</b>	.990	<b>25.15</b>
.490	<b>12.45</b>	1.000	<b>25.40</b>
.500	<b>12.70</b>	2.000	<b>50.80</b>
.510	<b>12.95</b>	3.000	<b>76.20</b>
.520	<b>13.21</b>	4.000	<b>101.60</b>
.530	<b>13.46</b>	5.000	<b>127.00</b>
.540	<b>13.72</b>	6.000	<b>152.40</b>
.550	<b>13.97</b>	7.000	<b>177.80</b>
.560	<b>14.22</b>	8.000	<b>203.20</b>
.570	<b>14.48</b>	9.000	<b>228.60</b>
.580	<b>14.73</b>	10.000	<b>254.00</b>
.590	<b>14.99</b>	20.000	<b>508.00</b>
.600	<b>15.24</b>		

## METRIC TO INCH CONVERSION TABLE

(Rounded-off for automotive use)

mm	inches	mm	inches
<b>1</b>	.0394	<b>51</b>	2.008
<b>2</b>	.079	<b>52</b>	2.047
<b>3</b>	.118	<b>53</b>	2.087
<b>4</b>	.157	<b>54</b>	2.126
<b>5</b>	.197	<b>55</b>	2.165
<b>6</b>	.236	<b>56</b>	2.205
<b>7</b>	.276	<b>57</b>	2.244
<b>8</b>	.315	<b>58</b>	2.283
<b>9</b>	.354	<b>59</b>	2.323
<b>10</b>	.394	<b>60</b>	2.362
<b>11</b>	.433	<b>61</b>	2.402
<b>12</b>	.472	<b>62</b>	2.441
<b>13</b>	.512	<b>63</b>	2.480
<b>14</b>	.551	<b>64</b>	2.520
<b>15</b>	.591	<b>65</b>	2.559
<b>16</b>	.630	<b>66</b>	2.598
<b>17</b>	.669	<b>67</b>	2.638
<b>18</b>	.709	<b>68</b>	2.677
<b>19</b>	.748	<b>69</b>	2.717
<b>20</b>	.787	<b>70</b>	2.756
<b>21</b>	.827	<b>71</b>	2.795
<b>22</b>	.866	<b>72</b>	2.835
<b>23</b>	.906	<b>73</b>	2.874
<b>24</b>	.945	<b>74</b>	2.913
<b>25</b>	.984	<b>75</b>	2.953
<b>26</b>	1.024	<b>76</b>	2.992
<b>27</b>	1.063	<b>77</b>	3.031
<b>28</b>	1.102	<b>78</b>	3.071
<b>29</b>	1.142	<b>79</b>	3.110
<b>30</b>	1.181	<b>80</b>	3.150
<b>31</b>	1.220	<b>81</b>	3.189
<b>32</b>	1.260	<b>82</b>	3.228
<b>33</b>	1.299	<b>83</b>	3.268
<b>34</b>	1.339	<b>84</b>	3.307
<b>35</b>	1.378	<b>85</b>	3.346
<b>36</b>	1.417	<b>86</b>	3.386
<b>37</b>	1.457	<b>87</b>	3.425
<b>38</b>	1.496	<b>88</b>	3.465
<b>39</b>	1.535	<b>89</b>	3.504
<b>40</b>	1.575	<b>90</b>	3.543
<b>41</b>	1.614	<b>91</b>	3.583
<b>42</b>	1.654	<b>92</b>	3.622
<b>43</b>	1.693	<b>93</b>	3.661
<b>44</b>	1.732	<b>94</b>	3.701
<b>45</b>	1.772	<b>95</b>	3.740
<b>46</b>	1.811	<b>96</b>	3.780
<b>47</b>	1.850	<b>97</b>	3.819
<b>48</b>	1.890	<b>98</b>	3.858
<b>49</b>	1.929	<b>99</b>	3.898
<b>50</b>	1.969	<b>100</b>	3.937

**TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)**

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

: Applicable : : Not applicable

SRT item	Self-diagnostic test item	DTC	Test value (GST display)		Test limit	Application	Unit
			TID	CID			
CATALYST	Three way catalyst function	P0420	01H	01H	Max.	X	-
		P0420	02H	81H	Min.	X	-
EVAP SYSTEM	EVAP control system (Small leak)	P0440	05H	03H	Max.	X	-
		P1440	05H	03H	Max.	X	-
	EVAP control system purge flow monitoring	P1447	06H	83H	Min.	X	mV
H02S	Heated oxygen sensor 1	P0133	09H	04H	Max.	X	ms
		P0131	0AH	84H	Min.	X	mV
		P0130	0BH	04H	Max.	X	mV
		P0132	0CH	04H	Max.	X	mV
		P0134	0DH	04H	Max.	X	s
	Heated oxygen sensor 2	P0139	19H	86H	Min.	X	mV/500ms
		P0137	1AH	86H	Min.	X	mV
		P0140	1BH	06H	Max.	X	mV
		P0138	1CH	06H	Max.	X	mV
		P0135	29H	08H	Max.	X	mV
H02S HTR	Heated oxygen sensor 1 heater	P0135	2AH	88H	Min.	X	mV
		P0141	2DH	0AH	Max.	X	mV
	Heated oxygen sensor 2 heater	P0141	2EH	8AH	Min.	X	mV
EGR SYSTEM	EGR function	P0400	31H	8CH	Min.	X	°C
		P0400	32H	8CH	Min.	X	°C
		P0400	33H	8CH	Min.	X	°C
		P0400	34H	8CH	Min.	X	°C
		P1402	35H	0CH	Max.	X	°C