

**QUICK REFERENCE INDEX**

**NISSAN  
 GT-R  
 MODEL R35 SERIES**

<b>A GENERAL INFORMATION</b>	GI	General Information
<b>B ENGINE</b>	EM	Engine Mechanical
	LU	Engine Lubrication System
	CO	Engine Cooling System
	EC	Engine Control System
	FL	Fuel System
	EX	Exhaust System
	STR	Starting System
<b>C ELECTRIC POWER TRAIN</b>	ACC	Accelerator Control System
<b>D TRANSMISSION &amp; DRIVELINE</b>	TM	Transaxle & Transmission
	DLN	Driveline
	FAX	Front Axle
	RAX	Rear Axle
<b>E SUSPENSION</b>	FSU	Front Suspension
	RSU	Rear Suspension
	SCS	Suspension Control System
	WT	Road Wheels & Tires
<b>F BRAKES</b>	BR	Brake System
	PB	Parking Brake System
	BRC	Brake Control System
<b>G STEERING</b>	ST	Steering System
	STC	Steering Control System
<b>H RESTRAINTS</b>	SB	Seat Belt
	SBC	Seat Belt Control System
	SR	SRS Airbag
	SRC	SRS Airbag Control System
<b>I VENTILATION, HEATER &amp; AIR CONDITIONER</b>	VTL	Ventilation System
	HA	Heater & Air Conditioning System
	HAC	Heater & Air Conditioning Control System
<b>J BODY INTERIOR</b>	INT	Interior
	IP	Instrument Panel
	SE	Seat
<b>K BODY EXTERIOR, DOORS, ROOF &amp; VEHICLE SECURITY</b>	DLK	Door & Lock
	SEC	Security Control System
	GW	Glass & Window System
	PWC	Power Window Control System
<b>L DRIVER CONTROLS</b>	EXT	Exterior
	BRM	Body Repair
	MIR	Mirrors
	EXL	Exterior Lighting System
	INL	Interior Lighting System
	WW	Wiper & Washer
	DEF	Defogger
HRN	Horn	
<b>M ELECTRICAL &amp; POWER CONTROL</b>	PWO	Power Outlet
	BCS	Body Control System
	LAN	LAN System
	PCS	Power Control System
	CHG	Charging System
	PG	Power Supply, Ground & Circuit Elements
<b>N DRIVER INFORMATION &amp; MULTIMEDIA</b>	MWI	Meter, Warning Lamp & Indicator
	WCS	Warning Chime System
<b>O CRUISE CONTROL &amp; DRIVER ASSISTANCE</b>	AV	Audio, Visual & Navigation System
	CCS	Cruise Control System
<b>P MAINTENANCE</b>	DMS	Drive Mode System
	MA	Maintenance

© 2011 NISSAN MOTOR CO.,LTD.

All Rights Reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, recording or otherwise, without the prior written permission of NISSAN MOTOR CO., LTD.



# FOREWORD

---

This manual contains maintenance and repair procedure for the 2013 NISSAN R35.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

## IMPORTANT SAFETY NOTICE

---

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.

Some works can be performed by GT-R certified NISSAN dealer only. Check the works able to be performed at your dealership by referring "Always read before works".

**NISSAN MOTOR CO., LTD.**











