

FOREWORD

This manual contains maintenance and repair procedure for the 2013 NISSAN JUKE.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.

NISSAN MOTOR CO., LTD.



PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals. Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc.
Technical Service Information
39001 Sunrise Drive, P.O. Box 9200
Farmington Hills, MI USA 48331
FAX: (248) 488-3880

SERVICE MANUAL: Model: _____ **Year:** _____

PUBLICATION NO. (Refer to Quick Reference Index): _____

Please describe any Service Manual issues or problems in detail:

Page number(s) _____ *Note: Please include a copy of each page, marked with your comments.*

Are the trouble diagnosis procedures logical and easy to use? (circle your answer) YES NO

If no, what page number(s)? _____ *Note: Please include a copy of each page, marked with your comments.*

Please describe the issue or problem in detail: _____

Is the organization of the manual clear and easy to follow? (circle your answer) YES NO

Please comment: _____

What information should be included in NISSAN Service Manuals to better support you in servicing or repairing customer vehicles?

DATE: _____ YOUR NAME: _____ POSITION: _____

DEALER: _____ DEALER NO.: _____ ADDRESS: _____

CITY: _____ STATE/PROV./COUNTRY: _____ ZIP/POSTAL CODE: _____

**QUICK REFERENCE CHART JUKE
ENGINE TUNE-UP DATA (MR16DDT)**

PFP:00000

ELS0003W

Engine model		MR16DDT
Firing order		1 - 3 - 4 - 2
Idle speed	rpm	
	CVT: No load* (in P or N position)	650 ± 50
	M/T: No load* (in Neutral position)	600 ± 50
Ignition timing (BTDC at idle speed)		
	CVT: No load* (in P or N position)	6° ± 2°
	M/T: No load* (in Neutral position)	8° ± 2°
Tensions of drive belt		Belt tension is not necessary, as it is automatically adjusted by drive belt auto-tensioner.
Radiator cap relief pressure	kPa (kg/cm ² , psi)	
	Standard	78 - 98 (0.8 - 1.0, 11 - 14)
	Limit	59 (0.6, 9)
Cooling system leakage testing pressure	kPa (kg/cm ² , psi)	98 (1.0, 14)
Compression pressure	kPa (kg/cm ² , psi)/rpm	
	Standard	1,560 (15.9, 226.2)/250
	Minimum	1,190 (12.1, 172.6)/250
	Differential limit between cylinders	100 (1.0, 14.5)/250
	Make	NTK
Spark plug (Iridium-tipped type)	Standard type	DILKAR7C9H
	Gap(Nominal) Standard	0.9 (0.035)
	Limit	1.1 (0.043)

*: Under the following conditions

- A/C switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

FRONT WHEEL ALIGNMENT

ELS0003X

Item		Standard		
Axle type		2WD	AWD	
Camber Degree minute (Decimal degree)	Minimum	-1° 10' (-1.16°)		
	Nominal	-0° 25' (-0.42°)		
	Maximum	0° 20' (0.33°)		
	Left and right difference*1	-0° 45' (-0.75°) - 0° 45' (0.75°)		
Caster Degree minute (Decimal degree)	Minimum	3° 45' (3.75°)	3° 50' (3.84°)	
	Nominal	4° 30' (4.50°)	4° 35' (4.58°)	
	Maximum	5° 15' (5.25°)	5° 20' (5.33°)	
	Left and right difference*1	-0° 45' (-0.75°) - 0° 45' (0.75°)		
Kingpin inclination Degree minute (Decimal degree)	Minimum	10° 40' (10.67°)		
	Nominal	11° 25' (11.42°)		
	Maximum	12° 10' (12.16°)		
Toe-in	Total toe-in Distance	Minimum	0 mm (0.00 in)	
		Nominal	In 2 mm (In 0.08 in)	
		Maximum	In 4 mm (In 0.16 in)	
	Total toe-angle Degree minute (Decimal degree)	Minimum	Out 0° 02' 00" (Out 0.03°)	
		Nominal	In 0° 10' 00" (In 0.17°)	
		Maximum	In 0° 22' 00" (In 0.36°)	

Measure value under unladen*2 conditions.

*1: A difference when assumed the left side a standard.

*2: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

REAR WHEEL ALIGNMENT

2WD

FOR USA MODELS

Item		Standard		
Camber Degree minute (Decimal degree)	Minimum	-2° 01' (-2.01°)		
	Nominal	-1° 31' (-1.52°)		
	Maximum	-1° 01' (-1.02°)		
Toe-in	Total toe-in Distance	Minimum	Out 1.1 mm (Out 0.043 in)	
		Nominal	In 2.9 mm (In 0.114 in)	
		Maximum	In 6.9 mm (In 0.272 in)	
	Toe angle (left wheel and right wheel)*1 Degree minute (Decimal degree)	Minimum	Out 0° 05' 00" (Out 0.08°)	
		Nominal	In 0° 15' 00" (In 0.25°)	
		Maximum	In 0° 35' 00" (In 0.58°)	

Measure value under unladen*2 conditions.

*1: Since adjustment mechanism is not included, the value of the left and right wheels (both wheels) must be used as the standard value.

*2: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

FOR CANADA MODELS

Item		Standard	
Camber Degree minute (Decimal degree)	Minimum	-2° 01' (-2.01°)	
	Nominal	-1° 31' (-1.52°)	
	Maximum	-1° 01' (-1.02°)	
Toe-in	Total toe-in Distance	Minimum	Out 1.2 mm (Out 0.047 in)
		Nominal	In 2.8 mm (In 0.11 in)
		Maximum	In 6.8 mm (In 0.268 in)
	Toe angle (left wheel and right wheel) ^{*1} Degree minute (Decimal degree)	Minimum	Out 0° 06' 00" (Out 0.10°)
		Nominal	In 0° 14' 00" (In 0.23°)
		Maximum	In 0° 35' 00" (In 0.58°)

Measure value under unladen^{*2} conditions.

*1: Since adjustment mechanism is not included, the value of the left and right wheels (both wheels) must be used as the standard value.

*2: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

AWD

FOR USA MODELS

Item		Standard	
Camber Degree minute (Decimal degree)	Minimum	-0° 45' (-0.75°)	
	Nominal	0° 00' (0.00°)	
	Maximum	0° 45' (0.75°)	
Toe-in	Total toe-in Distance	Minimum	In 1.0 mm (In 0.04 in)
		Nominal	In 3.0 mm (In 0.12 in)
		Maximum	In 5.0 mm (In 0.20 in)
	Total toe-angle Degree minute (Decimal degree)	Minimum	In 0° 05' 00" (In 0.09°)
		Nominal	In 0° 16' 00" (In 0.27°)
		Maximum	In 0° 26' 00" (In 0.43°)

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

FOR CANADA MODELS

Item		Standard	
Camber Degree minute (Decimal degree)	Minimum	-0° 43' (-0.71°)	
	Nominal	0° 02' (0.03°)	
	Maximum	0° 47' (0.78°)	
Toe-in	Total toe-in Distance	Minimum	In 1.0 mm (In 0.04 in)
		Nominal	In 3.0 mm (In 0.12 in)
		Maximum	In 5.0 mm (In 0.20 in)
	Total toe-angle Degree minute (Decimal degree)	Minimum	In 0° 05' 00" (In 0.09°)
		Nominal	In 0° 16' 00" (In 0.27°)
		Maximum	In 0° 26' 00" (In 0.43°)

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

BRAKE PEDAL

Unit: mm (in)

Brake pedal height	160.4 - 170.4 (6.31 - 6.71)
Depressed brake pedal height [Depressing 490 N (50 kg, 110 lb) while turning the engine ON]	70.0 (2.756) or more

FRONT DISC BRAKE

Unit: mm (in)

Brake pad	Wear limit thickness	2.0 (0.079)
Disc rotor	Wear limit thickness	24.0 (0.945)

REAR DISC BRAKE

Unit: mm (in)

Brake pad	Wear limit thickness	2.0 (0.079)
Disc rotor	Wear limit thickness	8.0 (0.315)

REFILL CAPACITIES

ELS00040

UNIT		Liter	US measure	
Fuel tank	2WD models	50.0	13-1/4 gal	
	AWD models	45.0	11-7/8 gal	
Engine Coolant (With reservoir tank) at MAX level	CVT	8.1	8-1/2 qt	
	M/T	7.9	8-3/8 qt	
Engine oil	Drain and refill			
	With oil filter change	4.5	4-6/8 qt	
	Without oil filter change	4.3	4-4/8 qt	
	Dry engine (Overhaul)	5.4	5-6/8 qt	
Transaxle	CVT	2WD	8.2	8-5/8 qt
		AWD	8.6	9-1/8 qt
	M/T	2.0	4-1/4 pt	
Transfer		0.37	3/4 pt	
Final drive		0.4	7/8 pt	
Air conditioning system	Compressor oil	0.12	4.1 fl oz	
	Refrigerant	0.40 kg	0.9 lb	