Edition: April 2013	QUICK REFERENCE INDE	X
Revision: April 2013	A GENERAL INFORMATION	Gl General Information
Publication No. SM14E1N17U0	B ENGINE	EM Engine Mechanical
		LU Engine Lubrication System
		CO Engine Cooling System
		EC Engine Control System
		FL Fuel System
		EX Exhaust System
		STR Starting System
		ACC Accelerator Control System
	С	
	D TRANSMISSION & DRIVE-	- CL Clutch
	LINE	TM Transaxle & Transmission
		DLN Driveline
		FAX Front Axle
NISSAN	E SUSPENSION	RAX Rear Axle FSU Front Suspension
	E SUSPENSION	RSU Rear Suspension
VERSA		SCS Suspension Control System
VERJA		WT Road Wheels & Tires
	F BRAKES	BR Brake System
MODEL N17 SERIES	1 BIVALES	PB Parking Brake System
		BRC Brake Control System
	G STEERING	ST Steering System
		STC Steering Control System
	H RESTRAINTS	SB Seat Belt
		SBC Seat Belt Control System
		SR SRS Airbag
		SRC SRS Airbag Control System
	I VENTILATION, HEATER & AIR CONDITIONER	
		HA Heater & Air Conditioning System
		HAC Heater & Air Conditioning Control System
	J BODY INTERIOR	INT Interior
		IP Instrument Panel
		SE Seat
		ADP Automatic Drive Positioner
	K BODY EXTERIOR, DOORS, ROOF & VEHICLI	DLK Door & Lock
	SECURITY	SEC Security Control System
		GW Glass & Window System
		PWC Power Window Control System
		RF Roof
		EXT Exterior  BRM Body Repair Manual
	L DRIVER CONTROLS	MIR Mirrors
	L DRIVER CONTROLS	EXL Exterior Lighting System
		INL Interior Lighting System
		WW Wiper & Washer
		DEF Defogger
		HRN Horn
All rights reserved. No part	M ELECTRICAL & POWER	PWO Power Outlet
of this Service Manual may	CONTROL	BCS Body Control System
		LAN LAN System
be reproduced or stored in a		PCS Power Control System
retrieval system, or transmit-		CHG Charging System
ted in any form, or by any		PG Power Supply, Ground & Circuit Elements
means, electronic, mechani-	N DRIVER INFORMATION &	
cal, photo-copying, record-	MULTIMEDIA	WCS Warning Chime System
ing or otherwise, without the		SN Sonar System
prior written permission of		AV Audio, Visual & Navigation System
Nissan North America, Inc.	O CRUISE CONTROL	CCS Cruise Control System
	P MAINTENANCE	MA Maintenance

A B

F G

K I

M N

0

# **FOREWORD**

This manual contains maintenance and repair procedure for the 2014 NISSAN VERSA SEDAN.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

#### IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.





#### PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals. Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc. Technical Service Information 39001 Sunrise Drive, P.O. Box 9200 Farmington Hills, MI USA 48331 FAX: (248) 488-3880

SERVICE MANUAL: Model: \_\_\_\_\_\_ Year: \_\_\_\_\_ PUBLICATION NO. (Refer to Quick Reference Index): \_\_\_\_\_ Please describe any Service Manual issues or problems in detail: Page number(s) \_\_\_\_\_\_ Note: Please include a copy of each page, marked with your comments. Are the trouble diagnosis procedures logical and easy to use? (circle your answer) NO If no, what page number(s)?\_\_\_\_\_Note: Please include a copy of each page, marked with your comments. Please describe the issue or problem in detail: Is the organization of the manual clear and easy to follow? (circle your answer) YES NO Please comment: What information should be included in NISSAN Service Manuals to better support you in servicing or repairing customer vehicles? DATE: \_\_\_\_\_ YOUR NAME: \_\_\_\_\_ \_\_\_\_\_ POSITION: \_\_\_\_\_ DEALER: \_\_\_\_\_ DEALER NO.: \_\_\_\_ ADDRESS: \_\_\_ \_\_\_\_\_ STATE/PROV./COUNTRY: \_\_\_\_\_ ZIP/POSTAL CODE: \_\_\_\_

INFOID:0000000008955451

## QUICK REFERENCE CHART: VERSA SEDAN


# Engine Tune-up Data

#### **GENERAL SPECIFICATIONS**

Engine type		HR16DE
Cylinder arrangement		In-line 4
Displacement	cm <sup>3</sup> (cu in)	1,598 (97.51)
Bore and stroke	mm (in)	78.0× 83.6 (3.071 ×3.291)
Valve arrangement		DOHC
Firing order		1-3-4-2
Number of piston rings	Compression	2
Number of pistori rings	Oil	1
Compression ratio		9.8
Standard		1,510 (15.4, 219)
Compression pressure kPa (kg/cm <sup>2</sup> , psi) / 200 rpm	Minimum	1,270 (12.95, 184)
a (1.9/5 , p51) / 200 ipin	Differential limit between cylinders	100 (1.0, 14.5)

Valve Timing

Unit: degree



( ): Valve timing control "ON"

Drive Belt

#### **DRIVE BELT**

Belt Deflection

Location		Deflec	Deflection adjustment *		
			Used belt		
		Limit	After adjusted	New belt	
Drive belt	With A/C	10 (0.39)	4.9 - 5.2 (0.19 - 0.20)	4.1 - 4.4 (0.16 - 0.17)	
Drive beit	Without A/C	9.1 (0.36)	4.3 - 4.7 (0.17 - 0.19)	3.7 - 3.9 (0.14 - 0.15)	
Applied	pushing force	98 N (10 kg-f, 22 lb-f)			

<sup>\*:</sup> When engine is cold.

Belt Tension and Frequency

		Tension ad	justment *	Unit: N (kg-f, lb-f)	Frequency adjustment *		Unit: Hz
	Location Used belt		belt	New belt		sed belt	New belt
		Limit	After adjusted	New Deit	Limit	After adjusted	New beit
Drive belt	With A/C	350 (35.7, 78.7)	881 - 951 (89.8 - 97.0, 198.1 - 213.8)	1070 - 1138 (109.1 - 116.0, 240.6 - 255.8)	145.5	230.5 - 239.5	254 - 262
	Without A/C	330 (33.7, 76.7)	876 - 964 (89.3 - 98.3, 196.9 - 216.7)	1064 - 1152 (108.5 - 117.5, 239.2 - 259.0)	162	256.5 - 268.5	282.5 - 293.5

<sup>\*:</sup> When engine is cold.

Spark Plug

## SPARK PLUG (PLATINUM-TIPPED TYPE)


Make	NGK
Standard type*	PLZKAR6A-11
Gap (nominal)	1.1 mm (0.043 in)

<sup>\*:</sup> Always check with the Parts Department for the latest parts information.

## Front Wheel Alignment

INFOID:0000000008955358

Item		Standard
	Minimum	-0° 50′ (-0.83°)
Camber	Nominal	-0° 05′ (-0.08°)
Degree minute (Decimal degree)	Maximum	0° 40′ (0.66°)
	Left and right differ- ence	0° 35′ (0.58°)
	Minimum	2° 55′ (2.92°)
Contor	Nominal	3° 40′ (3.67°)
Caster Degree minute (Decimal degree)	Maximum	4° 25′ (4.41°)
Degree minute (Decimal degree)	Left and right differ- ence	0° 45′ (0.75°)
	Minimum	11° 00′ (11.00°)
Kingpin inclination Degree minute (Decimal degree)	Nominal	11° 45′ (11.75°)
	Maximum	12° 30′ (12.50°)




	Item		Standard
	Distance (A - B)	Minimum	Out 1 mm (0.03 in)
		Nominal	In 1 mm (0.05 in)
Total toe-in		Maximum	In 3 mm (0.11 in)
Total toe-III	Angle	Minimum	Out 0° 4′ 48″ (0.08°)
	Degree minute second (Decimal degree)	Nominal	In 0° 4′ 48″ (0.08°)
		Maximum	In 0° 14′ 24″ (0.24°)

Measure value under unladen\* conditions.

# Rear Wheel Alignment

INFOID:0000000008955356




Item		Standard	
		Minimum	-1° 55′ (-1.91°)
	Camber Degree minute (Decimal degree)		-1° 25′ (-1.42°)
Dogree Himate (E	comia acgree)	Maximum	-0° 55′ (-0.92°)
		Minimum	Out 2.0 mm (0.079 in)
	Distance (A - B)	Nominal	In 2.0 mm (0.079 in)
Total too in		Maximum	In 6.0 mm (0.236 in)
Total toe-in	Total toe-in	Minimum	Out 0° 2′ (0.03°)
	Angle Degree minute (Decimal degree)	Nominal	In 0° 10′ (0.17°)
	Dogroo minuto (Doomia, dogroo)	Maximum	In 0° 22′ (0.37°)

Measure value under unladen\* conditions.

# Wheelarch Height

INFOID:0000000008955357

Unit: mm (in)



LE	IZ	40	0	8	5	Ε

<sup>\*:</sup> Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

<sup>\*:</sup> Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

Front (Hf)	683 (26.89)	684 (26.93)
Rear (Hr)	668 (26.30)	668 (26.30)

Measure value under unladen\* conditions.

#### **Brake Specifications**

INFOID:0000000008955354

Unit: mm (in)

	Cylinder bore diameter	54.025 (2.13)
Front brake	Pad length × width × thickness	115.0 × 41.0 × 9.0 (4.53 × 1.614 × 0.354)
	Rotor outer diameter × thickness	260 × 22.0 (10.24 × 0.87)
	Cylinder bore diameter	19.05 (3/4)
Rear brake	Lining length × width × thickness	Trailing: $172 \times 37 \times 4.8 \ (6.77 \times 1.46 \times 0.19)$ Leading: $155 \times 37 \times 4.8 \ (6.10 \times 1.46 \times 0.19)$
	Drum inner diameter - new	203.2 (8.00)
Master cylinder	Cylinder bore diameter	19 (0.75)
Control valve	Valve type	Electric brake force distribution
Brake booster	Diaphragm diameter	255 (10)

#### Brake Pedal

INFOID:0000000008955355

Unit: mm (in)

Item	Standard	
Brake pedal height	158 ±5 (6.22 ±0.20)	
Clearance among the brake pedal lever and the stop lamp switch threaded end	0.2 – 1.96 (0.008 – 0.0772)	
Brake pedal full stroke	128 (5.04)	

## Front Disc Brake

INFOID:0000000008955352

Unit: mm (in)

Item		Limit	
Brake pad Wear thickness		2.0 (0.08)	
Disc rotor	Wear thickness	20.0 (0.787)	
	Thickness variation (measured at 8 positions)	0.013 (0.001)	
	Runout (with it attached to the vehicle)	0.055 (0.002)	

#### Rear Drum Brake

INFOID:0000000008955353

Unit: mm (in)

Item		Limit	
Brake lining	Wear thickness	1.0 (0.04)	
Brake drum	Wear inner diameter- maximum	204.2 (8.04)	

#### Fluids and Lubricants

INFOID:0000000008955351

Description			Capacity (Approximate)		
		Metric	US measure	Imp measure	
Fuel		41.0 ℓ	10-7/8 gal	9 gal	
Engine oil Drain and refill	With oil filter change	3.5 ℓ	3-3/4 qt	3-1/8 qt	
	Without oil filter change	3.2 ℓ	3-3/8 qt	2-7/8 qt	

<sup>\*:</sup> Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

Description		Capacity (Approximate)			
		Metric	US measure	Imp measure	
		41.0 ℓ	10-7/8 gal	9 gal	
		3.5 ℓ	3-3/4 qt	3-1/8 qt	
Cooling system	With reservoir tank at "MAX" level	CVT	7.2 ℓ	7-5/8 qt	6-3/8 qt
		M/T - A/T	6.3 ℓ	6-5/8 qt	5-1/2 qt
	Reservoir tank capac (at "MAX" level)	ity	0.7 ℓ	3/4 qt	5/8 qt
Automatic transmission fluid		5.2 ℓ	5-1/2 qt	4-5/8 qt	
Manual transaxle fluid (MTF)		2.67 ℓ	5-5/8 pt	4-3/4 pt	
CVT fluid		6.9 ℓ	7-1/4 qt	6-1/8 qt	
Brake and clutch fluid		_	_	_	
Multi-purpose grease		_	_	_	
Windshield washer fluid		4.5 <i>Q</i>	4-3/4 qt	4 qt	
Air conditioning system refrigerant		0.40 kg	0.88 lb	0.88 lb	
Air conditioning system oil		120 m ℓ	4.1 fl oz	4.2 fl oz	